

Driver Annotations in Depth Part II



Donn Terry
Senior SDE
Static Analysis for Drivers
sdvpfdex@microsoft.com



Driver Annotations

- The "basic" annotations are a single identifier usually with "in"-ness or "out"-ness as part of the name
- Driver annotations are too rich for that to scale
- Use __drv_in(<annotation>) (etc.) instead



Problem

'Kinds' of Code

- Not all driver code is kernel mode.
- Not all kernel code is driver code
- Choose the proper mode of analysis
 - _kernel_driver; For kernel-mode driver code.
 This is the default for PREfast for Drivers (PFD).
 - _kernel_code; For non-driver kernel-mode code
 - _user_driver; For user-mode driver code
 - _user_code; For non-driver user-mode code
- Place anywhere as a declaration after driverspecs.h (or wdm.h) is included



Problem

Typos

- PFD can check for many simple but common errors
 - Passing an incorrect enum value
 - __drv_strictType, __drv_strictTypeMatch
 - Passing an incorrect pointer to a PVOID
 - __drv_isObjectPointer
 - Constants where variables are needed
 - Variables where constants are needed
 - __drv_constant, __drv_nonconstant



Enums

```
NTSTATUS KewaitForMultipleObjects(
    __in ULONG Count,
    __in PVOID Object[],
    in
      __drv_strictTypeMatch(__drv_typeConst)
    WAIT_TYPE WaitType,
    in
      __drv_strictTypeMatch(__drv_typeConst)
     KWAIT_REASON WaitReason,
    in
      __drv_strictType(KPROCESSOR_MODE/enum _MODE,
           __drv_typeCond)
    KPROCESSOR_MODE WaitMode,
    __in BOOLEAN Alertable,
     __in_opt PLARGE_INTEGER Timeout,
    __in_opt PKWAIT_BLOCK WaitBlockArray);
```

Never confuse WaitType, WaitReason, and WaitMode again



Pointers

Never pass &p when you meant p again



Constants

```
UCHAR
  READ_PORT_UCHAR(
    __in __drv_nonConstant PUCHAR Port
  );
```

```
LONG
  KeSetEvent(
    __in PRKEVENT Event,
    __in KPRIORITY Increment,
    __in __drv_constant BOOLEAN Wait
    );
```

Avoid unjustified assumptions



Working smarter

- PFD can check for known errors
- __drv_reportError
 - Some combination of parameters and state isn't a good idea.
- __drv_preferredFunction
 - There's a better way.



Checking for errors

Avoid illegal parameters and combinations



Preferred Function

Encourage good coding practice



Problem Floating point

- If your driver uses floating point you must be very careful to protect the hardware.
- It's easy to forget that you used it.
- Very hard to find during testing, typically not repeatable, and bluescreen is the usual symptom.
- Can span multiple functions
- __drv_floatUsed



Floating point

```
long
intSqrt(long i)
{
    return (long) sqrt((double)i);
}
```



Floating point

```
long
intSqrt(long i)
    return (long) sqrt((double)i);
if (KeSaveFloatingPointState(b))
    ... intSqrt(...) ...
    KeRestoreFloatingPointState(b);
else // deal with error
    intSqrt(...) ...
```



Floating point

```
__drv_floatUsed
long
intSqrt(long i)
    return (long) sqrt((double)i);
if (KeSaveFloatingPointState(b))
    ... intSqrt(...) ...
    KeRestoreFloatingPointState(b);
else // deal with error
    intSqrt(...) ...
```



TipTransitivity

- Check both sides of contract.
- __drv_floatUsed relies on it to work.
- Used for utility functions with side effects.
 - PFD's single function scope seems a problem.
 - But PFD checks both sides of the contract.
 - Correctly stated contracts solve the problem.
- Use on wrapper functions.



Problem Memory leaks

- PFD has always checked, but sometimes was noisy
- Checks for using freed memory as well



Memory Leaks Acquire/Release

- __drv_allocatesMem(): the function (optionally via out parameter) allocates memory
- __drv_freesMem(): the memory is freed (and is no longer accessible)
- __drv_aliasesMem: the memory won't leak and remains accessible



Memory Leaks Requirements

- Allocated memory must be:
 - Freed (reach a __drv_freesMem)
 - Aliased by exiting the function (via global, out parameter, or function result).
 - Aliased by reaching __drv_aliasesMem.
- Complex data structures.
 - PFD keeps a "contained by" relationship
 - If allocated memory has not been freed at the end of the function, PFD follows the "contained by" links until it finds a container that exits the function via a global or function result. (Up to 5 levels, which is a lot statically.)
 - If it fails, it's reported as a leak.



Memory Leaks "Possibly Leaking" messages

- The "Possibly Leaking" messages indicate that the value reached a call that if annotated with __drv_aliasesMem would not have reported a warning.
- Does the called function really "keep" the value?
 - Yes: fix with annotation (likely will fix a lot).
 - No: you've found a leak.



Example Memory allocation

Detect many leaks



Aliasing memory

```
PDEVICE_OBJECT
__checkReturn
IoAttachDeviceToDeviceStack(
    __in PDEVICE_OBJECT SourceDevice,
    __in
          __drv_in(__drv_mustHold(Memory)
          __drv_when(return!=0, __drv_aliasesMem))
          PDEVICE_OBJECT TargetDevice
);
```

Reduce false positives



Freeing memory

```
NTKERNELAPI
VOID
IoDeleteDevice(
    __in __drv_freesMem(Memory)
         PDEVICE_OBJECT DeviceObject
);
```

Don't access freed memory



Problem Leaked locks (or other resources)

- "Things" you acquire and release are resources.
- They can "leak" like memory, but the memory annotations don't quite work for Lock type objects (I tried).
- Resources are also "richer":
 - Must or never hold. (And no double take/free.)
 - Can be put into/taken out of other objects.
 - Some can be "named".



Resources Acquire/Release

- __drv_acquiresResource(kind)
- __drv_releasesResource(kind)
- __drv_acquiresResourceGlobal(kind,param)
- __drv_releasesResourceGlobal(kind,param)
- 'kind' is just a name (an arbitrary string)
- 'param' is "named by" (when there are many)



Resources Holding

- __drv_mustHold(kind)
- __drv_neverHold(kind)
- __drv_mustHoldGlobal(kind,param)
- __drv_neverHoldGlobal(kind,param)
- Implements:
 - Exclusivity/Non-recursion
 - Unsafe situations (e.g. loCompleteRequest)



Resources Specializations

Exclusive (shorthand)

- __drv_acquiresExclusiveResource(kind)
- __drv_releasesExclusiveResource(kind)
- __drv_acquiresExclusiveResourceGlobal(kind, param)
- __drv_releasesExclusiveResourceGlobal(kind, param)

The cancel spin lock

- __drv_acquiresCancelSpinLock
- __drv_releasesCancelSpinLock
- __drv_mustHoldCancelSpinLock
- __drv_neverHoldCancelSpinLock

The critical region

- __drv_acquiresCriticalRegion
- __drv_releasesCriticalRegion
- __drv_mustHoldCriticalRegion
- __drv_neverHoldCriticalRegion



Acquire/Release

```
_drv_maxIRQL(DISPATCH_LEVEL)
__drv_savesIRQL
 _drv_setsIRQL(DISPATCH_LEVEL)
_DECL_HAL_KE_IMPORT
KIRQL
FASTCALL
KfAcquireSpinLock (
    __inout __deref __drv_acquiresExclusiveResource(SpinLock)
    PKSPIN_LOCK SpinLock);
__drv_maxIRQL(DISPATCH_LEVEL)
 _drv_minIRQL(DISPATCH_LEVEL)
_DECL_HAL_KE_IMPORT
VOID
FASTCALL
KfReleaseSpinLock (
    __inout __deref __drv_releasesExclusiveResource(SpinLock)
    PKSPIN_LOCK SpinLock,
    __in __drv_restoresIRQL KIRQL NewIrql
   );
```



Must/Never Hold

```
__drv_mustHoldCriticalRegion
__drv_valuels(==1)
__drv_when(Wait==0, __drv_valuels(==0;==1) __checkReturn)
NTKERNELAPI
BOOLEAN
ExAcquireResourceSharedLite (
__inout __deref __drv_neverHold(ResourceLite)
__deref __drv_when(return!=0, __drv_acquiresResource(ResourceLite))
PERESOURCE Resource,
__in BOOLEAN Wait);
```



Example Spin lock wrapper

```
VOID
   GetMySpinLock(
    __inout
        __drv_deref(__drv_acquiresResource(SpinLock))
   PKSPIN_LOCK SpinLock
)
{
    (void)KeAcquireSpinLock(SpinLock);
}
(Ignoring old IRQL value for clarity.)
```

Transitive annotations empower checks



Problem Wrong IRQL

- Some functions can only be called at raised IRQL. Some must never be.
- Some functions can change the IRQL. Some can never do so.
- Some functions can temporarily change the IRQL, some shouldn't.
- How high is safe?
- Tracking the combinations can be hard.



IRQLs

- Many things can be done wrong.
 - Some are simply losing track of the context.
 - Some are due to incomplete analysis in code changes.
 - Some are not understanding what IRQLs do.
- Static analysis can find many of these, and the better the annotation, the more it can find.



Function changes the IRQL

- __drv_sameIRQL: modifies the IRQL but promises to put it back where it was.
- __drv_raisesIRQL: raises it.
- __drv_setsIRQL: changes it (use rarely).
- __drv_restoresIRQL, __drv_restoresIRQLGlobal: undoes a raise/set.



Required IRQLs

- __drv_maxIRQL: maximum you can call it at.
- __drv_minIRQL: minimum you can call it at.
- __drv_requiresIRQL: just exactly one.
- __drv_functionMaxIRQL: function never exceeds.
- __drv_functionMinIRQL: function never goes below.



Saving

- __drv_savesIRQL, __drv_savesIRQLGlobal
- The "Global" annotations save/restore from a PFD-created location invisible to the program, matching the semantics of some functions.



PFD will report an error at the call to F0, although it could be the F13 call that's wrong.

- If the call to F13 is successful, then the call to F0 can't be.
- If the call to F0 is required, then F13 must be protected (or not used).
- Usually F13 and F0 are far apart. PFD tries to find the "other one".



```
__drv_raisesIRQL(APC_LEVEL)
 _drv_savesIRQL
int raise();
void lower (__drv_restoresIRQL int i);
  _drv_sameIRQL
void F()
    old = raise();
    F13();
    lower(old)
    F0();
```

No error reported here: this is safe.



```
_drv_raisesIRQL(APC_LEVEL)
 _drv_savesIRQL
int raise();
void lower (__drv_restoresIRQL int i);
  _drv_functionMaxIRQL(PASSIVE_LEVEL)
 __drv_sameIRQL
void F()
    old = raise();
    F13();
    lower(old)
    F0();
}
```

Error reported: raise() raises to APC_LEVEL, but this function says that's not OK.



```
_drv_raisesIRQL(APC_LEVEL)
 _drv_savesIRQL
int raise();
void lower (__drv_restoresIRQL int i);
 _drv_minIRQL(DISPATCH_LEVEL)
 _drv_sameIRQL
void F()
    old = raise();
    F13();
    lower(old)
}
```

Error reported: we know we're at DISPATCH (or higher). We can't *raise* to a lower level.



```
drv_functionMaxIRQL(APC_LEVEL)
 _drv_sameIRQL
void F()
    old = raise();
    F13();
    lower(old)
    F0();
}
__drv_functionMaxIRQL(PASSIVE_LEVEL)
void G()
         F();
```

Error reported in G(): G() should never raise above passive level.



Callbacks

```
typedef
__drv_sameIRQL
__drv_clearDoInit(yes)
__drv_functionClass(DRIVER_ADD_DEVICE)
NTSTATUS
DRIVER_ADD_DEVICE (
    __in struct _DRIVER_OBJECT *DriverObject,
    __in struct _DEVICE_OBJECT *PhysicalDeviceObject
    );

typedef DRIVER_ADD_DEVICE *PDRIVER_ADD_DEVICE;
```

Check for correct implementation



__drv_inTry

Required Exception Handler

- __drv_inTry
 - Code must be inside the body of a structured exception handler (SEH): try/except, try/finally.
- __drv_notInTry
 - Code cannot be inside a SEH body.
- Transitive just like __drv_floatUsed

```
__drv_inTry
__drv_maxIRQL(APC_LEVEL)
NTKERNELAPI
VOID
NTAPI
ProbeForRead (
...
__drv_inTry
void ProbeDWORD(void *p)
{
    ProbeForRead(p, 4, 4);
}
```



Problem Paged functions

- PAGED_CODE must be used with #pragma alloc_text
- Frequently one or the other is missed
- Not quite an annotation, but a lot like one
- Predates PFD
- Sets <u>__drv_maxFunctionIRQL</u>
- PAGED_CODE_LOCKED needed in some special cases
- Works with (dynamic) Driver Verifier



Tip Things to remember

- There's more:
 - Read the documents
 - Read the documentation on warning messages as you get them.
- Always use the macros that's what will be supported
- Stick to the predefined macros
- Annotate for the success case
- Annotate to the design, not the implementation
- Look at issues by line number, not warning number.
- Start early



Running PFD

- Preferred: Microsoft Automated Code Review (OACR)
 - Runs automatically in the background
- If needed: stand-alone PREfast command
 - Works from many environments besides the normal build environment.
- Identical versions, but OACR has a richer filter capability, so some warnings may differ.



OACR Customization

Add/modify %INIT%\oacruser.ini (pick one or make your own)

```
[defaults]
;All PFD rules
ErrorNumbers=<level0>;<level1>;<level2>;<level3_PFD_samples>;<level_4_PFD>

[defaults]
;All rules
ErrorNumbers=<all>

[defaults]
;Specific ones
ErrorNumbers=<level0>;<level1>;<level2>;281xx;281yy;...
```

- Don't Forget:
 - oacr set all
- OACR chalk talk later.



On Correctness

- Annotations help with assuring correctness.
- In a recent IEEE Computer article, the writer asserts that for "critical" code, the code should be "obviously correct".
 - Modulo Hoare Expression proofs or equivalent.
- Windows is critical for business infrastructure.



On Correctness

Code which is not obviously correct...

--- is obviously not correct.



Additional Resources

- Web resources
 - WHDC Web site
 - PREfast step-by-step http://www.microsoft.com/whdc/DevTools/tools/PREfast_steps.mspx
 - PREfast annotations http://www.microsoft.com/whdc/DevTools/tools/annotations.mspx
 - How to Use Function typedefs in C++ Driver Code to Improve PREfast Results http://go.microsoft.com/fwlink/?LinkId=87238
 - Blog: http://blogs.msdn.com/staticdrivertools/default.aspx
 - WDK documentation on MSDN
 - PREfast for Drivers <u>http://msdn.microsoft.com/en-us/library/aa468782.aspx</u>
- Chapter 23 in Developing Drivers with the Windows Driver Foundation
 - http://www.microsoft.com/MSPress/books/10512.aspx
- E-mail <u>sdvpfdex @ microsoft.com</u>



Related Sessions

Design

Session	Day / Time
Using Static Analysis Tools When Developing Drivers	Mon. 8:30-9:30
Driver Annotations in Depth: Part 1	Mon. 1:30-2:30
Lab: PREfast for Drivers	Mon. 11-12 and Wed. 8:30-9:30
Lab: Static Driver Verifier for WDM, KMDF, and NDIS	Mon. 5:15-6:15 and Wed. 11-12
Integrating PREfast into Your Build by Using Microsoft Auto Code Review	Tues. 4-5
Using Static Driver Verifier to Analyze KMDF Drivers	Mon. 4-5
Using Static Driver Verifier to Analyze NDIS Drivers	Tues. 9:45-10:45
Using Static Driver Verifier to Analyze Windows Driver Model Drivers	Wed. 9:45-10:45



Questions?

