

Memory Hierarchy (Part 1)

Instructor: Luan Duong, Ph.D.

CSE 2431: Introduction to Operating Systems

Reading: **Chap. 6** from Computer Systems: A Programmer's Perspective by Randal E. Bryant and David R. O'Halloran, 3rd edition, Pearson/Prentice Hall, 2016



Previous lecture

- Memory overview (part 1)
- Virtual memory procedures (part 2-3-4)
 - Dynamic relocation
 - Paging
 - Swaping



Motivation

- Briefly seen previously, an actual computer system contains a *hierarchy* of storage devices with different costs, capacities, and access times.
- With a memory hierarchy, a faster storage device at one level of the hierarchy acts as a staging area for a slower storage device at the next lower level.
- Well-written software exploits the hierarchy, accessing the faster storage device at a particular level more frequently than the storage at the next level.
- As a programmer, understanding the memory hierarchy will result in better application performance.



Outline: Memory Hierarchy

- Storage Technologies
- Locality
- Memory Hierarchy
- Cache Memories
- Writing Cache-friendly Code
- Impact of Caches on Program Performance



Storage Technologies


- Random-Access Memory (RAM)
- Disk Storage (Disk)
- Solid State Disks (SSD)
- Storage Technology Trends



- Features:
 - Basic storage unit is usually a cell (one pit per cell)
 - RAM is traditionally packaged as a chip
 - Multiple chips form memory
- Different RAM:
 - Static RAM (sRAM)
 - Dynamic RAM (DRAM)



A SRAM from Nintendo Entertainment System (wiki)



Typical DRAM



Static RAM (SRAM) and Dynamic RAM (DRAM)

Static RAM (SRAM)	Dynamic RAM (DRAM)
+ Each cell implemented with a six- transistor circuit	+ Each bit stored as charge on a capacitor
+ Holds value while power is maintained: volatile	+ Value must be refreshed every 10 msec–100 msec: volatile
+ Insensitive to disturbances such as electrical noise, radiation, etc.	+ Sensitive to disturbances
+ Faster and more expensive than DRAM	+ Slower and cheaper than SRAM




Static RAM (SRAM) and Dynamic RAM (DRAM)

RAM Type	Transistors / Bit	Access Time	Needs Refresh?	Sensitive?	Cost	Applications
SRAM	4 or 6	1×	No	No	100×	Cache memories
DRAM	1	10×	Yes	Yes	1×	Main memories, cache buffers




Static RAM (SRAM) and Dynamic RAM (DRAM)



A cell of DRAM only consists of 1 transistor/ capacitor (1T cell)

1 cell of SRAM. It is also called "6T cell, or 6 Transistors per bit






Conventional DRAM Organization

• $d \times w$ DRAM: dw total bits organized as d supercells of size w

bits






Reading DRAM Supercell (2,1) (1)

• Step 1(a): Row access strobe (RAS) selects row 2.

 Step 1(b): Row 2 copied from DRAM array to row buffer.






Reading DRAM Supercell (2,1) (1)

 Step 2(a): Column access strobe (CAS) selects column 1.


 Step 2(b): Supercell (2,1) copied from buffer to data lines, and eventually back to the CPU.






DRAM Memory Modules

- From 1 bit \rightarrow a byte read \rightarrow A bank.
- 8 banks → included in a single micro-chip (typically 4, 8, 16/chip) (bank address)




8 chips will be fit into a single circuit (DIMM – Dual Inline Memory Module)
 Ref: https://www.youtube.com/watch?v=Mhqi700PW00






Memory Modules



Did you ever notice why there are different 'black cells' on your DRAMs?





Enchanced DRAMs

 Enhanced DRAMs have optimizations that improve the speed with which basic DRAM cells are accessed.

• Examples:

- Fast page mode DRAM (FPM DRAM)
- Extended data out DRAM (EDO DRAM)
- Synchronous DRAM (SDRAM)
- Double Data-Rate Synchronous DRAM (DDR SDRAM)
- Rambus DRAM (RDRAM)
- Video RAM (VRAM)



But...

- DRAMs and SRAMs are volatile memory!
- It means "information will NOT be retained if supply voltage is turned off".
- Is that what you want from your computers? Isn't a computer supposed to process the data AND still retain the data in case of power outage?



Non-volatile Memory

- Information retained if supply voltage is turned off
- Collectively referred to as read-only memories (ROM)
 although some may be written to as well as read
- Distinguishable by the number of times they can be reprogrammed (written to) and by the mechanism for reprogramming them
- Used for firmware programs (BIOS, controllers for disks, network cards, graphics accelerators, security subsystems...), solid state disks, disk caches




Non-volatile Memory

Term	Abbreviation	Definition	# of Times Programmed
Read-only memory	ROM	Programmed during production	0
Programmable ROM	PROM	Fuse associated with NAND, NOR cell that's blown once (zapping with electrical current)	1
Erasable ROM	EPROM Cells cleared by shining ultraviolet light, special device used to write 1s		1,000
Electrically erasable PROM	EEPROM	Like EPROM, but doesn't require separate programming device; can be programmed on printed circuit boards	100,000
Flash memory	_	Based on EEPROM; wears out after ~100,000 repeated writes	100,000



Traditional Bus Structure Connect Bus, Memory

If you recall... from the first lesson...




- A bus is a collection of parallel wires that carry address, data, and control signals.
- Buses are typically shared by multiple devices.



Memory **READ** Transaction (1)


CPU places address A on the memory bus.





Memory **READ** Transaction (2)


 Main memory reads A from the memory bus, retrieves word x, and places it on the bus.





Memory **READ** Transaction (3)


• CPU reads word x from the bus and copies it into register %rax.





Memory WRITE Transaction (1)


 CPU places address A on bus. Main memory reads it and waits for the corresponding data word to arrive.





Memory WRITE Transaction (2)


• CPU places data word **y** on the bus.





Memory WRITE Transaction (3)

 Main memory reads data word y from the bus and stores it at address A.





Another type of Non-volatile Memory: Disk

- Disks hold enormous amount of data on the order of hundreds to thousands of gigabytes compared to hundreds to thousands of megabytes in memory.
- Disks are slower than RAM-based memory on the order of milliseconds to read info on (hard) disk, 100,000 times longer than from DRAM and 1,000,000 times longer than SRAM.
- Solid-state disks (SSDs) are faster than hard disk drives (HDD), but slower than DRAM and SRAM
- SSDs also have one disadvantage: limited number of writes! (Typical SSDs: ~100,000 write cycles). How about HDDs?



Another type of Non-volatile Memory: Disk


- Write cycles' comparison:
 - SSDs: typically 100,000 write cycles
 - NAND: 10,000 write cycles
 - 3D NAND: **35,000** write cycles.
 - How about HDDs? Typically unlimited write cycles. But we can still measure by DWPD = Drive Writes Per Day.
- Seagate Enterprise Capacity 3.5" drive 10TB (<u>spec</u>) 550TB/year, or 0.15 DWPD (drive writes per day)
- Seagate Archive 3.5" drive (5TB 8TB) (<u>spec</u>) 180TB/year or 0.06 0.1 DWPD
- Seagate Enterprise NAS drive (2TB 8TB) (spec) 300TB/year or 0.1 0.4 DWPD
- Kinetic HDD 4TB (spec) 180TB/year or 0.12 DWPD
- WD Gold (4TB 8TB) 550TB/year or 0.2 0.4 DWPD
- WD Re (250GB 1TB) (spec) 550TB/year or 1.5 6 DWPD
- WD Re (1TB 6TB) (spec) 550TB/year or 0.25 1.5 DWPD

- Intel SSD DC S3710 (200GB 1.2TB) 10 DWPD (<u>spec</u>)
- Intel SSD DCP3500 (400GB 2TB) 1095 TBW (assuming a five year lifetime, 0.3 1.5 DWPD) (spec)
- SanDisk Lightning (200GB to 1.6TB) between 3-25 DWPD depending on model (<u>specs</u>)

- Source: https://www.techtarget.com/searchstorage/definition/write-cycle#:~:text=The%20number%20of%20write%20cycles,up%20to%20100%2C000%20write%20cycles.
- Source: https://www.theregister.com/2016/05/03/when_did_hard_drives_get_workload_rate_limits/



Anatomy of A Disk Drive




Source: Seagate Technology



Disk Geometry


- Disks consist of platters, each with two surfaces.
- Each surface consists of concentric rings called tracks.
- Each track consists of sectors separated by gaps.





Disk Geometry (Multi-Platter View)

Aligned tracks form a cylinder.





Disk Capacity (1)

Capacity defined to be the maximum number of bits that can be recorded on a disk. Determined by the following factors:

- Recording density (bits/in): The number of bits on a 1-inch segment of a track.
- Track density (tracks/in): The number of tracks on a 1-inch segment of radius extending from the center of the platter.
- Areal density (bits/in²): product of recording density and track density



Disk Capacity (2)

Determining areal density:

- Original disks partitioned every track into the same number of sectors, which was determined by the innermost track. Resulted in sectors being spaced further apart on outer tracks.
- Modern disks partition into disjoint subsets called recording zones.
 - Each track within zone same number of sectors, determined by the innermost track.
 - Each zone has a different number of sectors/track.



How to compute Disk Capacity?

Capacity = (#bytes/sector) × (avg #sectors/track) × (#tracks/surface) × (#surfaces/platter) × (#platters/disk)

Example:


- 512 bytes/sector
- Average of 300 sectors/track
- 20,000 tracks/surface
- 2 surfaces/platter
- 5 platters/disk

Capacity = $512 \times 300 \times 20,000 \times 2 \times 5 = 30,720,000,000 = 30.72$ GB.




Disk Operation (Single-Platter View)

The disk surface spins at a fixed rotational rate






Disk Operation (Multi-Platter View)





Disk Structure: Top view of a Single Platter



Surface organized into tracks


Tracks divided into sectors

7200RPM Hard Drive running without the cover: https://www.youtube.com/watch?v=ZBx4H908_xl

If you do not see the multiple platters in this video, then check this out: https://www.youtube.com/watch?v=w3bt5yNt3xY




Disk Access (step 1)



Head in position above a track




Disk Access (step 2)



Rotation is counter-clockwise




Disk Access: Read (1-A)



About to read **BLUE** sector




Disk Access: Read (1-B)



After reading **BLUE** sector




Disk Access: Read (1-C)



ORANGE request scheduled next




Disk Access: Seek



Seek to **ORANGE**'s track




Disk Access: Rotational Latency



Wait for Orange sector to rotate around




Disk Access: Read (2)



Complete read of **ORANGE** sector



Disk Access: Service Time Components





Calculating Access Time (1)

Average access time for a sector:

$$T_{\text{access}} = T_{\text{avg_seek}} + T_{\text{avg_rotation}} + T_{\text{avg_transfer}}$$

Seek time (**T**_{avg_seek}):

- Time to position heads over cylinder
- Typical $T_{\text{avg seek}}$ is 3–9 msec, 20-msec maximum

Rotational latency (*T*_{avg_rotation}):

- After head is positioned over track, the time it takes for the first bit of the sector to pass under the head
- Worst case: head just misses the sector and waits for the disk to rotate 360

$$T_{\text{max_rotation}} = (1/\text{RPM}) \times (60 \text{ secs/1 min})$$

• Average case is **half** of worst case:

$$T_{avg\ rotation} = (1/2) \times (1/RPM) \times (60 \text{ secs/1 min})$$

• Typical $T_{avg_rotation} = 5400-7200 \text{ RPM}$



Calculating Access Time (2)

Transfer time (T_{avg_transfer}):

- Time to read bits in the sector
- Time depends on rotational speed, number of sectors per track.
- Estimate of the average transfer time:
 - $T_{\text{avg_transfer}} = (1/\text{RPM}) \times (1/(\text{avg #sectors/track})) \times (60 \text{ secs/1 min}) \times (1000 \text{ msec/1 sec})$

Example:

- Rotational rate = 7200 RPM
- Average seek time = 9 msec
- Avg #sectors/track = 400

```
T_{\text{avg\_rotation}} = 1/2 \times (60 \text{ secs/}7200 \text{ RPM}) \times (1000 \text{ msec/sec}) = 4 \text{ msec}
T_{\text{avg\_transfer}} = (60/7200 \text{ RPM}) \times (1/400 \text{ secs/track}) \times (1000 \text{ msec/sec}) = 0.02 \text{ msec}
T_{\text{access}} = 9 \text{ msec} + 4 \text{ msec} + 0.02 \text{ msec} = 13.02 \text{ msec}
```



Access Time

Time to access the <u>512 bytes</u> in a disk sector is dominated by the seek time (<u>9 msec</u>) and rotational latency (<u>4 msec</u>).

Accessing the sector takes a long time but transferring bits is basically *free*.

Since seek time and rotational latency are roughly the same, at least same order of magnitude, doubling the seek time is a reasonable estimate for access time.

Comparison of access times of various storage devices when reading a comparable 512-byte sector sized block:

SRAM: 256 nanoseconds (nsec)

• DRAM: 5000 nsec

• Disk: 10 msec

Disk is ~40,000 times slower than SRAM, 2,500 times slower than DRAM.



Logical Disk Blocks and Formatted Disk Capacity

Logical Disk Blocks

- Although modern disks have complex geometries, they present a simpler abstract view as a sequence of B sector-sized logical blocks, numbered 0, 1, 2, ... B-1.
- Disk controller maintains the mapping between the logical and actual (physical) disk sectors and converts requests for block into a surface, track, and sector by performing a fast table lookup.

Formatted Disk Capacity

- Before disks can be used for the first time, they must be formatted by the disk controller.
- Gaps between sectors filled in with info to identify sectors.
- Finds surface defects and sets aside cylinders to be used for spares.
- Formatted capacity is less than the maximum capacity.




Connecting I/O Devices

- I/O devices such as disks, graphics cards, monitors, mice, and keyboards connect to the CPU and main memory via an I/O bus.
- Unlike the system bus and memory bus which are CPU specific, the I/O bus is independent of the underlying CPU.
- The I/O bus is slower than the system and memory buses but can accommodate a wide variety of third-party I/O devices. For instance, USB, graphics card or adapter, host bus adapter (SCSI/SATA).
- Network adapters can be connected to the I/O bus by plugging the adapter into an empty expansion slot on the motherboard.




I/O Bus






Reading a Disk Sector (1)

OLLEGE OF ENGINEERING




CPU initiates a disk read by writing a command, logical block number, and destination memory address to a port (address) associated with disk controller.

Reading a Disk Sector (2)




Disk controller reads the sector and performs a direct memory access (DMA) transfer into main memory.

Reading a Disk Sector (3)



Solid State Drive/Disks (SSDs)

- Pages: 512 KB to 4 KB, Blocks: 32 to 128 pages
- Data read/written in units of pages.
- Page can be written only after its block has been erased
- A block wears out after 100,000 repeated writes





SSD Performance Characteristics

Description of Statistic	Speed, Time	Description of Statistic	Speed, Time
Sequential read throughput	550 MB/sec	Sequential write throughput	470 MB/sec
Random read throughput	365 MB/sec	Random write throughput	303 MB/sec
Random read access	50 µsec	Random write access	60 µsec

Source: Intel SSD 730 product specification

- Why are random writes so slow?
 - Erasing a block is slow (around 1 msec)
 - Write to a page triggers a copy of all useful pages in the block
 - Find a used block (new block) and erase it
 - Write the page into the new block
 - Copy other pages from old block to the new block



SSDs vs Rotating (Hard) Disks

Advantages:

- No moving parts (semiconductor memory); more rugged
- Much faster random-access times
- Use less power

Disadvantages:

- SSDs wear out with usage
- More expensive than hard disks



Storage Technology Trends

SRAM

Metric	1985	1990	1995	2000	2005	2010	2015	2015:1985
\$/MB	2,900	320	256	100	75	60.0	32	116
Access (nsec)	150	35	15	3	2	1.5	2	115

DRAM

Metric	1985	1990	1995	2000	2005	2010	2015	2015:1985
\$/MB	880.00	100	30	1	0.1	0.06	0.02	44,000
Access (nsec)	200.00	100	70	60	50.0	40.00	20.00	10
Typical Size (MB)	0.25	4	16	64	2,000.0	8,000.00	16,000.00	62,500

Disk

Metric	1985	1990	1995	2000	2005	2010	2015	2015:1985
\$/GB	100,000.00	8,000.00	300	10	5	0.3	0.03	3,333,333
Access (msec)	75.00	28.00	10	8	5	3.0	3.00	25
Typical Size (GB)	0.01	0.16	1	20	160	1,500.0	3,000.00	300,000



CPU Trends

Inflection point in computer history when designers hit the "Power Wall"

	1985	1990	1995	2000	2003	2005	2010	2015	2015:1985
CPU	802868	0386	Pentium	P-III	P-4	Core 2	Core i7 (N)	Core i7 (H)	_
Clock rate (MHz)	6	20	150	600.0	3,300.0	2,000.00	2,500.0	3,000.00	500
Cycle time (nsec)	166	50	6	1.6	0.3	0.50	0.4	0.33	500
Cores	1	1	1	1.0	1.0	2.00	4.0	4.00	4
Effective cycle time (nsec)	166	50	6	1.6	0.3	0.25	0.1	0.08	2,075


^{* (}N) indicates Intel's Nehalem architecture; (H) indicates Intel's Haswell architecture.

- Around 2003, system designers reached a limit regarding the exploitation of instruction-level parallelism (ILP) in sequential programs.
- Since 2000, processor speed has not greatly increased; instead, multicore CPUs.



The CPU-Memory Gap

The gap widens between DRAM, disk, and CPU speeds.



Summary of Storage Technologies

- Storage Technologies in Computer have a lot of diversities. Two main types:
 - Volatile memory (DRAM, SRAM)
 - Non-Volatile Memory (ROM, Flash-Drive)
 - Non-Volatile Memories for storage: HDDs, SSDs
- No matter what storage technologies are chosen, one thing we have to care is the CPU Performance. Without an improvement for CPU, even when we have the fastest SSDs in the world it's still useless.

