

Circuit Diagrams Scrambler 1200 X

This document is protected by copyright and may not, in whole or part be stored in a retrieval system, or transmitted in any form or by any means, copied, photocopied, translated or reduced to any machine-readable form without prior consent in writing from Triumph Motorcycles Limited.

No liability can be accepted for any inaccuracies or omissions in this publication, although every possible care has been taken to make it as complete and accurate as possible.

Triumph Motorcycles Limited reserves the right to make changes and alter specifications without prior notice and without incurring an obligation to make such changes to products manufactured previously. See your authorised Triumph dealer for the latest information on product improvements incorporated after this publication.

All information contained in this publication is based on the latest product information available at the time of publication. Illustrations in this publication are intended for reference use only and may not depict actual model component parts.

© Triumph Motorcycles Ltd. 12.2023 Issue 1






TABLE OF CONTENTS


Circuit Diagrams	Page
1 - Power Distribution Circuit	L
2 - Battery System Circuit	
3 - Ignition Circuit	6
4 - ABS Circuit	$\overline{7}$
5 - Engine Management Circuit 1	8
6 - Engine Management Circuit 2	<u>C</u>
7 - Engine Management Circuit 3	10
8 - Throttle Body Circuit	1
9 - Instruments Circuit	12
10 - Rider Controls Circuit	13
11 - Lighting Circuit	14
12 - Accessories Circuit	15
13 - Miscellaneous Circuit	16
14 - CAN Communication Circuit	17
15 - Ground Circuit	18


01 POWER DISTRIBUTION







03 IGNITION SYSTEM









07 ENGINE MANAGEMENT SYSTEM 3

