



Lecture 16

Physical Design, Part 2


Xuan ‘Silvia’ Zhang
Washington University in St. Louis

<http://classes.engineering.wustl.edu/ese461/>

- Place logic cells within the flexible blocks
- Ideal objectives
 - guarantee the router can complete the routing step
 - minimize all the critical net delays
 - make the chip as dense as possible
 - minimize power, crosstalk between signals
- Realistic objectives
 - minimize total estimated interconnect length
 - meet the timing requirement for critical nets
 - minimize the interconnect congestion

Placement Terms


- Over the cell routing (OTC)
- Channel capacity
- Feedthroughs (feedthrus)
- Jumper (unused vertical track in a cell)



Placement Terms






- Manhattan distance vs Euclidean distance
- Minimum Rectilinear Steiner Tree (MRST)



Placement Algorithms




- Constructive placement method
 - Min-cut algorithm
 - cut the placement area into two pieces
 - swap logic cells to minimize cut cost
 - repeat and cut smaller pieces till all cells placed



Placement Algorithms

- Constructive placement method
 - Eigenvalue placement algorithm
 - cost matrix or weighted connectivity matrix
 - quadratic optimization problem
- Iterative placement method
 - take existing placement and improve it
 - pairwise interchange algorithm
 - force-directed algorithm




Physical Design Flow



- Design entry
 - logic description with no physical information
- Logic synthesis
- Initial floorplan
- Synthesis with load constraints
- Timing-driven placement
- Synthesis with in-place optimization
- Detailed placement
- Global routing
- Detailed routing

Physical Design Flow





Global Routing



- Two types of areas to global route
 - inside the flexible blocks
 - between blocks
- Objectives
 - start from a floorplan and placement
 - minimize the total interconnect length
 - maximize the probability that the detailed router can complete the routing
 - minimize the critical path delay

Measurement of Interconnect Delay


- Elmore delay model
 - after placement, the logic cell position fixed



Global Routing Between Blocks




- Numbering channels
- Channels form the edge of a graph
- Each channel has a capacity



Global Routing Between Blocks

- Find terminals of nets
- Find minimum-length tree
- Minimum-length tree \neq Minimized delay between terminals (A1 to D1)




Detailed Routing




- Goal
 - complete all connections between logic cells
- Objectives
 - minimize total interconnect length and area
 - minimize # of layer changes (vias)
 - minimize delay of critical paths

Detailed Routing

- Routing pitch rules
 - via-to-via (VTV) pitch
 - via-to-line (VTL) pitch
 - line-to-line (LTL) pitch




- Waffle via
- Stacked via



Router's View of the Cell



- Phantom




Terms in Detailed Routing



- Trunks
 - running in parallel to the channel
- Branches
 - connecting trunk to terminals
- Tracks
 - horizontal track spacing
- Terminal
 - column spacing


Terms in Detailed Routing

W
SL




Channel Density

- Global density
- Local density



Detailed Routing

- Manhattan routing
 - preferred direction
 - preferred metal layer
 - logic cell connectors on 1 metal only




2-Layer Routing



- Left-edge algorithm
 - 1. sort the nets from the leftmost edge
 - 2. assign first net to the first free track
 - 3. assign next net that can fit to the track
 - 4. repeat step 3 until no more net can fit
 - 5. repeat step 2-4 until all nets assigned

Left-Edge Algorithm Example

W
SL




Multi-Layer Routing



- Polysilicon + 2-level metal
 - 2.5-layer routing
 - poly only for short connections
- 3-layer routing
 - M1 horizontal, M2 vertical, M3 horizontal (HVH)
 - M1 vertical, M2 horizontal, M3 vertical (VHV)
 - M3 pitch is multiples of M1

3-Layer Routing Example





Final Routing Steps



- Timing-driven detailed routing
 - reduce # of vias
 - alter interconnect width
 - minimize overlap capacitance
- Unroutes
 - leave problematic nets unconnected
 - complete interconnects with violation
- To resolve
 - discover the reason and revisit synthesis and floorplan
 - return to global router, change bin size
 - engineering change orders (ECO)
 - via removal and routing compaction

Special Routing

- Clock Routing
 - minimize clock skew
 - clock tree synthesis
 - clock-buffer insertion



- Activity-induced skew
 - supply noise

Special Routing





- Power Routing
 - electromigration
 - size the power buses according to the current

TABLE 17.1 Metallization reliability rules for a typical 0.5 micron ($l = 0.25 \text{ m m}$) CMOS process.

Layer/contact/via	Current limit ¹	Metal thickness ²	Resistance ³
m1	1 mA m m^{-1}	7000 \AA	95 m W /square
m2	1 mA m m^{-1}	7000 \AA	95 m W /square
m3	2 mA m m^{-1}	$12,000 \text{ \AA}$	48 m W /square
...			

- tap-cell
- end-cap cell
- de-cap cell



- Encounter tutorial to be discuss next lecture
- Detailed class project description
 - to be release by Friday
 - behavioral code to be submitted
 - account for 30% of the project
 - by 11/22 before thanksgiving
 - if late, by 11/28, discount by 40%

Questions?

Comments?

Discussion?