- 1- Consider the SHORTDELAY subroutine that is outlined below. Write AVR assembly so that it utilizes the 16-bit Timer/Counter1 to delay for 201 milliseconds (0.201 seconds). Assume that the system clock frequency is 16 MHz. Note the following requirements:
- (a) Timer/Counter1 must be initialized to operate in the Normal mode.
- (b) The SHORTDELAY subroutine loads the proper value into TCNT1 and waits until TOV1 is set. Once TOV is set, it is cleared and the SHORTDELAY subroutine returns.
- (c) The code must utilize a polling strategy to check TOV1 (do not use interrupt vectors in this homework problem).

$$Delay_{Normal} = \frac{(Max+1-value)^*prescale}{clk_{I/0}}$$

$$value = 65535 - \frac{201ms}{prescale^*62.5ns} = 65535 - \frac{201ms}{64^*62.5ns} = 15285 = 0x3BB5$$

.include "m128def.inc"

.def mpr = r16

..

.ORG \$0000

RJMP Initialize

.ORG \$0046 ; End of interrupt vectors

Initialize:

. . .

; initialize stack

LDI mpr, high(RAMEND)

OUT SPH, mpr

LDI mpr, low(RAMEND)

OUT SPL, mpr

; initialize TCNT1

SBI DDRB, PB7 ; set bit 7 of Port B for output

LDI mpr, 0b00000000 ; activate Normal mode, OC1A, OC1B, and OC1C

disconnected

OUT TCCR1A, mpr

LDI mpr, 0b00000001 ; set prescale to 64

OUT TCCR1B, mpr LDI mpr, 0b00000000 OUT TCCR1C, mpr

...

SHORTDELAY:

...

; load value into TCNT1 LDI mpr. 0x3

mpr, 0x3B ; load 0x3B to mpr

TCNT1H, mpr ; write to high byte first

mpr, 0xB5 ; load 0xB5 to mpr

TCNT1L, mpr ; write to low byte second

OUT CHECK:

OUT

LDI

IN mpr, TIFR ; read in TIFR

ANDI mpr, 0b00000100 ; check if TOV1 is set
BREQ CHECK ; loop if TOV1 is not set
LDI mpr 0b00000100 ; otherwise, reset TOV1
OUT TIFR, mpr ; note - write 1 to reset

... RET

- 2- Imagine that you want to program your lab board to handle the I/O configuration illustrated in the image below. Review the starter code that is provided below and fill in the missing lines (based on the instructions) to accomplish the given tasks. mpr is the only general purpose register that you are allowed to use in the code.
- (a) Fill in lines 1-2 so that the pin directions are properly configured to control the engine enable and engine direction for both left and right wheels. Any unused pins must be configured as inputs

```
(1) LDI mpr, (1 << 0) | (1 << 1) | (1 << 2) | (1 << 3); DDRA = 00001111 for output (2) OUT DDRA, mpr ; set DDR register for Port A
```

(b) Fill in lines 3-4 so that the pin directions are properly configured to detect left and right bumper movements. Once again, any unused pins must be configured as inputs.

```
(3) LDI mpr, (0 << 4) \mid (0 << 5) ; DDRE = 00000000 for input 
(4) OUT DDRE, mpr ; set DDRE register for Port E
```

(c) What are the addresses needed in lines (i) and (ii) to properly control the execution of interrupt service routines for left and right bumpers? Fill in lines 5-6 to enable the pull-up resisters for these whiskers.

(i) \$000A ; INT4 is located at address \$000A

(ii) \$000C ; INT5 is located at address \$000C

(5) LDI mpr, (1<<4) | (1<<5)

(6) OUT PORTE, mpr ; activate pull-up resistors

(d) Fill in lines 7-8 with the necessary code to set External Input Sense Control to detect bumper hits (i.e., interrupts) on a falling edge.

(7) LDI mpr, (1<<ISC01) | (0<<ISC00) | (1<<ISC11) | (0<<ISC10)

(8) STS EICRA, mpr ; EICRA = 00001010 => detect on falling edge

(e) Fill in lines 9-10 to unmask the interrupts for whisker movements.

(9) LDI mpr, (1<<INT4) | (1<<INT5) ; turn on interrupts for L/R bumpers

(10) OUT EIMSK, mpr ; EIMSK = 00110000

3- Consider the AVR code segment shown below (with some missing information) that configures Timer/Counter0 for Fast PWM operation, and modifies the Fast PWM duty cycle whenever a specific button on Port D is pressed.

01101010

(a) Fill in lines (1-2) with the instructions necessary to configure Timer/Counter0 for Fast PWM mode, non-inverting output, and a prescale value of 8.

(1) LDI mpr, 0b01101010 ; activate Fast PWM with toggle

(2) OUT TCCR0, mpr ; (non-inverting) and set prescale to 8

(b) Based on the prescale value used in part (a), what is the frequency of the PWM signal (fPWM) being generated by Timer/Counter0? Assume the system clock frequency is 16 MHz.

$$f_{PWM} = \frac{clk_{I/0}}{prescale*256} = \frac{16MHz}{8*256} = 0.0078125 MHz$$

(c) Fill in lines (3-4) to provide the compare value for Timer/Counter0 so that the initial duty cycle is 51% (use the closest available settings).

(4) LDI mpr, 131 ; set compare value

(5) OUT OCR0, mpr ; (131/256)*0.51 = 131

(d) What would be the value necessary for the variable step to increase the duty cycle by 12.5% each time the DUTY_STEP subroutine is executed? Ignore the case when/if the compare value overflows.

$$\frac{x}{256} = 0.125 \Rightarrow x = 256 * 0.125 = 32$$