


SinoVoip CO.,LTD

Banana PI BPI-M3 User Manual

<Version: V1.0 >





Banana PI BPI-M3 is the open source hardware platform, Banana PI BPI-M3 is an Octa-core version of Banana Pi, Banana PI BPI-M3 is the octa core better than the Banana Pi BPI-M1, it support WIFI+BT on board.

Banana Pi BPI-M3 series run Android, Debian linux, Ubuntu linux, Raspberry Pi image and others OS.

Banana PI PBI-M3 hardware: 1.8GHz ARM Cortex-A7 Octa-core processor, 2GB LPDDR3 SDRAM,

Banana PI BPI-M3with Gigabit Ethernet port, It can run with Android 5.1 smoothly. The size of Banana PI BPI-M3 same as banana pi M1, it can easily run with the game it support 1080P high definition video output, the GPIO compatible with Raspberry Pi B+ and can run the ROM Image



Hardware Specification of Banana pi BPI-M3

Soc Allwinner A83T ARM Cortex-A7

CPU A83T ARM Cortex-A7 octa-core,512 KB L1 cache 1 MB L2 cache

GPU PowerVR SGX544MP1· Comply with OpenGL ES 2.0, OpenCL 1.x, DX 9_3

SDRAM 2GB LPDDR3 (shared with GPU)

Power 5V @ 2A via DC power and/or MicroUSB (OTG)

Features

40 Pins Header, 28×GPIO, some of which can be used for specific functions Low-level peripherals

including UART, I2C, SPI, PWM, I2S.

On board Network 10/100/1000Mbps ethernet (Realtek RTL8211E/D)

Wifi Module WiFi 802.11 b/g/n (AP 6212 module on board)

Bluetooth BT4.0

On board Storage MicroSD (TF) card,SATA2.0 ,eMMC

Supports multi-channel HD display:

HDMI 1.4 (Type A - full)

Display

MIPI Display Serial Interface (DSI) for raw LCD panels

11 HDMI resolutions from 640×480 to 1920×1200

Multi-format FHD video decoding, including Mpeg1/2, Mpeg4, H.263, H.264, etc

Video H.264 high profile 1080p@60fps or 720p@120fps encoding

HEVC/H.265 decoder 1080P@30fps with software

Audio outputs

HDMI,analog audio (via 3.5 mm TRRS jack),I2S audio (also potentially for audio

input)

Parallel 8-bit camera interface

MIPI Camera serial Interface(CSI)

Audio input On board micphone

USB 2.0 host, 1 USB 2.0 OTG

Buttons Reset button, Power button, U-boot button

Leds Power status Led and RJ45 Led

Other IR reciever

Interface definition

Sizes 92 mm × 60mm


Weight 45g


3





Interface:









Use method

Step 1: Get what you need

First time to enjoy your Banana Pi, you need at least the accessories in the table below.

| No. | Item | Minimum recommended specification & notes |
|-----|---|---|
| 1 | MicroSD card | SD card is optional. But if need boot form SD card, Minimum size 8GB, class 10 (the class indicates how fast the card is). We recommend using branded SD cards as they are more reliable. |
| 2a | HDMI(Full sized) to HDMI / DVI lead | HDMI to HDMI lead (for HD TVs and monitors with HDMI input). OR HDMI to DVI lead (for monitors with DVI input). |
| 3 | Keyboard and mouse | Any standard USB keyboard and mouse should work. Keyboards or mice that take a lot of power from the USB ports, however, may need a powered USB hub. This may include some wireless devices. |
| 4 | Ethernet cable | • Networking is optional, although it makes updating and getting new software for your Banana Pi much easier. |
| 5 | DC/ Micro USB power adapter | A good quality, DC power supply that can provide at least 2A at 5Vis essential. OTG also can power the board, but it is not recommended. |
| 6 | Audio lead (Optional) | You can choose a 3.5mm jack audio led to connect to audio port to get stereo audio. |
| 7 | Mobile Hard disk (Optional) | You can choose to connect a mobile hard disk to usb port to store more files. |





HDMI to HDMI lead



HDMI to DVI lead







DC power adapter

Step 2: Download the relevant Image file:

Please visit our webmaster: www.bananapi.com to download image, banana pi all image can be download form this web.

Step3: Prepare your SD card for the Banana Pi M3

In order to enjoy your Banana Pi M3, you will need to install an Operating System (OS) onto an SD card or eMMC Flash. Instructions below will teach you how to write an OS image to your SD card or eMMC Flash under Windows and Linux.

- 1. Insert your SD card into your computer. The size of SD should be larger than the OS image size, generally 8GB or greater.
- 2. Format the SD card.




Windows:

Download the a SD card format tool such as **SD Formatter** from https://www.sdcard.org/downloads/formatter_4/eula_windows/

- i. Unzip the download file and run the setup.exe to install the tool on your machine.
- ii. In the "Options" menu, set "FORMAT TYPE" option to QUICK,"FORMAT SIZE ADJUSTMENT" option to "ON".





- iii. Check that the SD card you inserted matches the one selected by the Tool.
- iv. Click the "Format" button.





Linux:

- v. Run *fdisk –l* command to check the SD card node.
- vi. Run *sudo fdisk /dev/sdx* command to delete all partition of SD card.
- vii. Run *mkfs -t vfat /dev/sdx* command to format the entire SD card as FAT.

(x should be replaced according to your SD card node)

- 3. Download the OS image from Download district.
- 4. Unzip the download file to get the OS image.

Windows: Right click on the file and choose "Extract all".

Linux: Run unzip [downloaded filename] command.

5. Write the image file to the SD card.


5.1 Linux image:

Windows:

i. Download a tool that can wirte image to SD card, such as Win32Diskimager from:

http://sourceforge.net/projects/win32diskimager/files/Archive/

ii. Open the unzipped image file.



iii. Click Write button. Wait patiently to successfully complete writing.





Linux:

- iv. Run *fdisk –l* command to check the SD card node.
- v. Run *dd if=[imagename] of=/dev/sdx* command to write image file to SD card. Wait patiently to successfully complete writing.

5.2 Android image


Windows:

i. You need to use Phoenix Card to make the SD card.

Download the Phoenix Card from


https://drive.google.com/file/d/0B_VynIqhAcB7NTg2UkRDdHRWX2s/edit?usp=sharing

ii. Run PhoenixCard.exe, Press "Disk Check" and select disk of SD Card.






iii. Press "Img File" and Select system.img.




iv. Select "Startup" and press "確定"





v. Press "Burn" to start upgrading, Upgraded complete, Press "Exit".



Step4: Set up your Banana Pi M3


According to the set up diagram below, you can easily set up your Banana Pi.

- 1. Insert the written-image SD card that to the SD card spot on the left side edge of the underside of the board.
- 2. On the bottom "edge" in the middle of the board is the HDMI Type A (Full sized) port. Just connect any HDMI cable from the board to your TV or HDMI Monitor.
- 3. Plug a USB keyboard and mouse into the USB slots located on the right edge.
- 4. Just under the USB ports on the right edge is the ethernet connector for anyone who wants to plug the Banana Pi into a wired network.
- 5. Finally, at the very left of the bottom edge is the DC power connector. Plug in a regulated power supply that is rated at $5V \pm 5\% / 2000 \text{mA}$ (or 2A). Any number bigger than 700 mA will also work. Avoid using the smaller chargers



used for small GSM phones, as these are often unregulated, even if they claim "5V 1A", they may do "5V" and may do "1A", but not at the same time!

The DC PLUG: 4.0*1.7mm, inside"+", outside"-"



The mini-USB (on the left) is the wrong one. It's thicker and looks like a trapezoid with its sides pinched in. The micro-USB (on the right) is the correct one. It is thinner and also looks like a trapezoid except it's sides are rounded outward.





If all goes well, the Banana Pi will boot in a few minutes. The screen will display the OS GUI.



Step5: Shut down your Banana Pi M3

You can use the GUI to shut down the Banana Pi safely.

Also you can run the command in the terminal:

sudo halt

or

sudo shutdown -h.

This will shut down the PI safely, (just use the power key to turn off might damage the SD-cards file system). After that you can press the power key for 5 seconds to turn it off.


If all is well, so you can use banana pi M3 now.



GPIO specification

Banana Pi 40-pin GPIO

Banana Pi has a 40-pin GPIO header that matches that of the Model B+ Raspberry Pi. Following is the Banana Pi GPIO Pinout:



www.bananapi.com www.banana-pi.com



| GPIO Pin Name | Default Function | Function2: GPIO | Function3 |
|----------------------|------------------|-----------------|-----------|
| CON1-P01 | VCC-3V3 | | |
| CON1-P02 | DCIN | | |
| CON1-P03 | TWI2-SDA | PH5-EINT5 | |
| CON1-P04 | DCIN | | |
| CON1-P05 | TWI2-SCK | PH4-EINT4 | |
| CON1-P06 | GND | | |
| CON1-P07 | S-PWM | PL10-S-EINT10 | |
| CON1-P08 | UART2-TX | PBO-EINTO | |
| CON1-P09 | GND | | |
| CON1-P10 | UART2-RX | PB1-EINT1 | |
| CON1-P11 | PC4 | PC4 | |
| CON1-P12 | UART2-CTS | PB3-EINT3 | |
| CON1-P13 | PC7 | PC7 | |
| CON1-P14 | GND | | |
| CON1-P15 | PC17 | PC17 | |
| CON1-P16 | UART2-RTS | PB2-EINT2 | |
| CON1-P17 | VCC-3V3 | | |
| CON1-P18 | PL8-ENT8 | PL8-S-ENT8 | |
| CON1-P19 | SPIO_MOSI | PC0 | |
| CON1-P20 | GND | | |
| CON1-P21 | SPIO_MISO | PC1 | |
| CON1-P22 | PL9-EINT9 | PL9-S-EINT9 | |
| CON1-P23 | SPIO_CLK | PC2 | |
| CON1-P24 | SPIO_CS | PC3 | |
| CON1-P25 | GND | | |
| CON1-P26 | PH10-ENT10 | PH10-ENT10 | |
| CON1-P27 | TWI1-SDA | PH3-EINT3 | |
| CON1-P28 | TWI1-SCK | PH2-EINT2 | |
| CON1-P29 | PC18 | PC18 | |
| CON1-P30 | GND | | |
| CON1-P31 | I2S1-BCLK | PG10-EINT10 | UART3-TX |
| CON1-P32 | I2S1-DIN | PG13-EINT13 | UART3-CTS |
| CON1-P33 | I2S1-LRCK | PG11-EINT11 | UART3-RX |
| CON1-P34 | GND | | |
| CON1-P35 | I2S1-DOUT | PG12-EINT12 | UART3-RTS |
| CON1-P36 | PE5 | PE5 | |
| CON1-P37 | PE4 | PE4 | |
| CON1-P38 | OWA-DOUT | PE18 | |



| CON1-P39 | GND | | |
|----------|------|------|--|
| CON1-P40 | PE19 | PE19 | |

CSI Camera Connector specification:

CSI Camera Connector

The CSI Camera Connector is a 40-pin FPC connector which can connect external camera module with proper signal pin mappings. The pin definitions of the CSI interface are shown as below. This is marked on the Banana Pi board as "CSI".

| CSI Pin Name | Default Function | Function2: GPIO |
|--------------|------------------|-----------------|
| CN7-P01 | IPSOUT | |
| CN7-P02 | AFVCC | |
| CN7-P03 | IPSOUT | |
| CN7-P04 | IOVDD | |
| CN7-P05 | GND | |
| CN7-P06 | GND | |
| CN7-P07 | CSI2-D3N | |
| CN7-P08 | AVDD-CSI | |
| CN7-P09 | CSI2-D3P | |
| CN7-P10 | DVDD-CSI-R | |
| CN7-P11 | GND | |
| CN7-P12 | NC | |
| CN7-P13 | CSI2-D2N | |
| CN7-P14 | CSI-RST-R | PE16 |
| CN7-P15 | CSI2-D2P | |
| CN7-P16 | CSI-STBY-R | PE17 |
| CN7-P17 | GND | |
| CN7-P18 | CSI-PCLK | PE0 |
| CN7-P19 | CSI2-CKN | |
| CN7-P20 | CSI-MCLK | PE1 |
| CN7-P21 | CSI2-CKP | |
| CN7-P22 | CSI-HSYNC | PE2 |
| CN7-P23 | GND | |
| CN7-P24 | CSI-VSYNC | PE3 |
| CN7-P25 | CSI2-D1N | |



| CN7-P26 | CSI-D9 | PE13 |
|---------|----------|------|
| CN7-P27 | CSI2-D1P | |
| CN7-P28 | CSI-D8 | PE12 |
| CN7-P29 | GND | |
| CN7-P30 | CSI-D7 | PE11 |
| CN7-P31 | CSI2-DON | |
| CN7-P32 | CSI-D6 | PE10 |
| CN7-P33 | CSI2-DOP | |
| CN7-P34 | CSI-D5 | PE9 |
| CN7-P35 | GND | |
| CN7-P36 | CSI-D4 | PE8 |
| CN7-P37 | CSI-SCK | PE14 |
| CN7-P38 | CSI-D3 | PE7 |
| CN7-P39 | CSI-SDA | PE15 |
| CN7-P40 | CSI-D2 | PE6 |

Display specification

MIPI DSI (Display Serial Interface)

The display Connector is a 40-pin FPC connector which can connect external LCD panel (MIPI DSI) and touch screen (I2C) module as well. The pin definitions of this connector are shown as below. This is marked on the Banana Pi board as "DSI".

| DSI Pin Name | Default Function | Function2: GPIO |
|--------------|------------------|-----------------|
| CN6-P01 | VCC-MIPI | |
| CN6-P02 | IPSOUT | |
| CN6-P03 | VCC-MIPI | |
| CN6-P04 | IPSOUT | |
| CN6-P05 | GND | |
| CN6-P06 | IPSOUT | |
| CN6-P07 | GND | |
| CN6-P08 | IPSOUT | |
| CN6-P09 | NC | |
| CN6-P10 | GND | |
| CN6-P11 | NC | |
| CN6-P12 | DSI-DON | |
| CN6-P13 | NC | |
| CN6-P14 | DSI-DOP | |



| CN6-P15 | NC | |
|---------|------------|-------------|
| CN6-P16 | GND | |
| CN6-P17 | TWIO-SDA | PH1-EINT1 |
| CN6-P18 | DSI-D1N | |
| CN6-P19 | TWIO-SCK | PHO-EINTO |
| CN6-P20 | DSI-D1P | |
| CN6-P21 | TP-INT | PL7-S-EINT7 |
| CN6-P22 | GND | |
| CN6-P23 | TP-RST | PL6-S-EINT6 |
| CN6-P24 | DSI-CKN | |
| CN6-P25 | GND | |
| CN6-P26 | DSI-CKP | |
| CN6-P27 | LCD-BL-EN | PD29 |
| CN6-P28 | GND | |
| CN6-P29 | LCD-RST | PD26 |
| CN6-P30 | DSI-D2N | |
| CN6-P31 | LCD-PWR-EN | PD27 |
| CN6-P32 | DSI-D2P | |
| CN6-P33 | GND | |
| CN6-P34 | GND | |
| CN6-P35 | LCD-PWM | PD28 |
| CN6-P36 | DSI-D3N | |
| CN6-P37 | GND | |
| CN6-P38 | DSI-D3P | |
| CN6-P39 | AP-RESET# | |
| CN6-P40 | GND | |

UART specification:

The header CON4 is the UART interface. For developers of Banana Pi, this is an easy way to get the UART console output to check the system status and log message.

| CON2 Pin Name | Default Function | GPIO |
|---------------|------------------|------|
| CON2 P03 | UART0-TXD | PB8 |
| CON2 P02 | UART0-RXD | PB9 |
| CON2 P01 | GND | |