7. ATmega328P Code

main.cpp

```
\begin{tabular}{ll} // Configuration and initialization of the analog-to-digital converter: \\ \end{tabular}
    #include "ADC.hpp'
    // Capacitive touch sensing:
 3
    #include "Touch.hpp"
    // PID controller:
    #include "Controller.hpp"
     // Configuration of PWM and Timer2/0 for driving the motor:
    #include "Motor.hpp"
    // Reference signal for testing the performance of the controller:
#include "Reference.hpp"
 q
10
    // Helpers for low-level AVR Timer2/0 and ADC registers:
11
    #include "Registers.hpp"
12
    // Parsing incoming messages over Serial using SLIP packets: \#include "SerialSLIP.hpp"
13
    #include <Arduino.h>
                                    // setup, loop, analogRead
    #include <Arduino_Helpers.h> // EMA.hpp
17
    #include <Wire.h>
                                    // I<sup>2</sup>C slave
18
19
    #include "SMA.hpp"
                                     // SMA filter
20
    #include <AH/Filters/EMA.hpp> // EMA filter
21
22
          -----/Description -----//
23
24
25
    // This sketch drives up to four motorized faders using a PID controller. The
26
    \ensuremath{//} motor is disabled when the user touches the knob of the fader
27
28
    // Everything is driven by Timer2, which runs (by default) at a rate of
29
    // 31.250 kHz. This high rate is used to eliminate audible tones from the PWM
    // drive for the motor. Timer0 is used for the PWM outputs of faders 3 and 4. // Every 30 periods of Timer2 (960 \mu s), each analog input is sampled, and
30
31
    // this causes the PID control loop to run in the main loop function.
32
    // Capacitive sensing is implemented by measuring the RC time on the touch pin // in the Timer2 interrupt handler. The "touched" status is sticky for >20 ms \,
    \ensuremath{\text{//}} to prevent interference from the 50 Hz mains.
35
36
    ^{\prime\prime} // There are options to (1) follow a test reference (with ramps and jumps), (2)
37
38
    // to receive a target position over \ensuremath{\text{I}}^2 C, or (3) to run experiments based on
    // commands received over the serial port. The latter is used by a Python script
39
    // that performs experiments with different tuning parameters for the
40
    // controllers.
41
42
    // ------ Hardware ------ //
43
44
    // Fader 0:
45
    // - A0: wiper of the potentiometer
                                                        (ADC0)
46
    // - D8: touch pin of the knob
                                                        (PB0)
47
        - D2: input 1A of L293D dual H-bridge 1
48
                                                        (PD2)
    // - D3: input 2A of L293D dual H-bridge 1
49
                                                        (OC2B)
    //
50
    // Fader 1:
51
    // - A1: wiper of the potentiometer
52
                                                        (ADC1)
    // - D9: touch pin of the knob
// - D7: input 3A of L293D dual H-bridge 1
                                                        (PB1)
                                                         (PD7)
55
    // - D11: input 4A of L293D dual H-bridge 1
                                                        (0C2A)
56
    //
    // Fader 2:
57
    // - A2: wiper of the potentiometer
58
                                                        (ADC2)
    // - D10: touch pin of the knob
// - D4: input 1A of L293D dual H-bridge 2
// - D5: input 2A of L293D dual H-bridge 2
                                                        (PB2)
59
                                                        (PD4)
60
61
                                                        (OCOB)
62
    // Fader 3:
    // - A3: wiper of the potentiometer
                                                        (ADC3)
    // - D12: touch pin of the knob
                                                        (PB4)
       - D13: input 3A of L293D dual H-bridge 2
66
                                                        (PB5)
67
    // - D6: input 4A of L293D dual H-bridge 2
                                                        (OCOA)
    //
68
    // If fader 1 is unused:
69
    // - D13: LED or scope as overrun indicator
70
                                                        (PB5)
71
72
    // For communication:
    // - D0: UART TX
73
                                                        (TXD)
74
    // - D1: UART RX
                                                        (RXD)
75
    //
       - A4:
                I2C data
                                                         (SDA)
76
    // - A5: I2C clock
                                                        (SCL)
77
    ^{\prime\prime} Connect the outer connections of the potentiometers to ground and Vcc, it's
78
    // recommended to add a 100 nF capacitor between each wiper and ground.
79
    // Connect the 1,2EN and 3,4EN enable pins of the L293D chips to Vcc.
80
    // Connect a 500k\Omega pull-up resistor between each touch pin and Vcc.
    // On an Arduino Nano, you can set an option to use pins A6/A7 instead of A2/A3.
    // Note that D13 is often pulsed by the bootloader, which might cause the fader
83
84
    // to move when resetting the Arduino. You can either disable this behavior in
85
    // the bootloader, or use a different pin (e.g. A2 or A3 on an Arduino Nano).
    // The overrun indicator is only enabled if the number of faders is less than 4,
86
    // because it conflicts with the motor driver pin of Fader 1. You can choose a
87
    // different pin instead.
88
          ----- Configuration -----//
    // Enable MIDI input/output.
    #define WITH_MIDI 0
93
```

```
94 / // Print to the Serial monitor instead of sending actual MIDI messages.
 95
     #define MIDI DEBUG 0
 96
 97
      struct Config {
 98
           // Print the control loop and interrupt frequencies to Serial at startup:
 99
           static constexpr bool print_frequencies = true;
100
           // Print the setpoint, actual position and control signal to Serial.
          // Note that this slows down the control loop significantly, it probably
101
          // won't work if you are using more than one fader without increasing // `interrupt_divisor`:
102
103
104
           static constexpr bool print_controller_signals = false;
           static constexpr uint8_t controller_to_print = 0;
105
           // Follow the test reference trajectory (true) or receive the target
           // position over I2C or Serial (false):
107
           static constexpr bool test_reference = false;
108
109
           \ensuremath{//} Increase this divisor to slow down the test reference:
          static constexpr uint8_t test_reference_speed_div = 4;
110
          // Allow control for tuning and starting experiments over Serial:
static constexpr bool serial_control = true;
111
112
           // I<sup>2</sup>C slave address (zero to disable I<sup>2</sup>C):
113
           static constexpr uint8_t i2c_address = 8;
114
           // The baud rate to use for the Serial interface (e.g. for MIDI_DEBUG,
           // print_controller_signals, serial_control, etc.)
116
117
           static constexpr uint32_t serial_baud_rate = 10000000;
          // The baud rate to use for MIDI over Serial.
// Use 31'250 for MIDI over 5-pin DIN, HIDUINO/USBMidiKliK.
118
119
           // Hairless MIDI uses 115'200 by default.
// The included python/SerialMIDI.py script uses 1'000'000.
120
121
          static constexpr uint32_t midi_baud_rate = serial_baud_rate;
122
123
124
           // Number of faders, must be between 1 and 4:
           static constexpr size_t num_faders = 1;
125
           // Actually drive the motors. If set to false, runs all code as normal, but
127
           // doesn't turn on the motors.
128
           static constexpr bool enable_controller = true;
129
           // Use analog pins (A0, A1, A6, A7) instead of (A0, A1, A2, A3), useful for
          \ensuremath{//} saving digital pins on an Arduino Nano:
130
           static constexpr bool use_A6_A7 = false;
131
           // Use pin A2 instead of D13 as the motor driver pin for the fourth fader.
132
           // Allows D13 to be used as overrun indicator, and avoids issues with the
          // bootloader blinking the LED.
// Can only be used if `use_A6_A7` is set to true.
134
135
           static constexpr bool fader_3_A2 = false;
136
137
          // Capacitive touch sensing RC time threshold.
138
          // Increase this time constant if the capacitive touch sense is too
139
           // sensitive or decrease it if it's not sensitive enough:
140
141
          static constexpr float touch_rc_time_threshold = 150e-6; // seconds
           // Bit masks of the touch pins (must be on port B):
142
          static constexpr uint8_t touch_masks[] = {1 << PB0, 1 << PB1, 1 << PB2, 1 << PB4};
143
144
145
146
           // Use phase-correct PWM (true) or fast PWM (false), this determines the
147
           // timer interrupt frequency, prefer phase-correct PWM with prescaler 1 on
148
           // 16 MHz boards, and fast PWM with prescaler 1 on 8 MHz boards, both result
149
          // in a PWM and interrupt frequency of 31.250 kHz // (fast PWM is twice as fast):
150
          static constexpr bool phase_correct_pwm = true;
// The fader position will be sampled once per `interrupt_divisor` timer
151
152
153
           // interrupts, this determines the sampling frequency of the control loop.
          // Some examples include 20 \rightarrow 320 \mu s, 30 \rightarrow 480 \mu s, 60 \rightarrow 960 \mu s, // 90 \rightarrow 1,440 \mu s, 124 \rightarrow 2,016 \mu s, 188 \rightarrow 3,008 \mu s, 250 \rightarrow 4,000 \mu s. // 60 is the default, because it works with four faders. If you only use
155
156
157
           // a single fader, you can go as low as 20 because you only need a quarter
158
           // of the computations and ADC time:
          static constexpr uint8_t interrupt_divisor = 60 / (1 + phase_correct_pwm);
159
           // The prescaler for the timer, affects PWM and control loop frequencies: static constexpr unsigned prescaler_fac = 1;
160
161
           // The prescaler for the ADC, affects speed of analog readings:
           static constexpr uint8_t adc_prescaler_fac = 64;
163
164
165
           \ensuremath{//} Turn off the motor after this many seconds of inactivity:
166
          static constexpr float timeout = 2;
167
           // EMA filter factor for fader position filters:
168
          static constexpr uint8_t adc_ema_K = 2;
169
           // SMA filter length for setpoint filters, improves tracking of ramps if the
170
          // setpoint changes in steps (e.g. when the DAW only updates the reference // every 20 ms). Powers of two are significantly faster (e.g. 32 works well):
171
172
           static constexpr uint8_t setpoint_sma_length = 0;
173
174
175
           // ----- Computed Quantities ----- //
176
          177
178
179
180
           // Frequency at which the interrupt fires:
          constexpr static float interrupt_freq =
               1. * F_CPU / prescaler_fac / 256 / (1 + phase_correct_pwm);
182
183
           // Clock speed of the ADC:
184
           constexpr static float adc_clock_freq = 1. * F_CPU / adc_prescaler_fac;
           // Pulse pin D13 if the control loop took too long:
185
186
          constexpr static bool enable_overrun_indicator =
               num_faders < 4 || fader_3_A2;</pre>
187
188
```

```
189
         static_assert(0 < num_faders && num_faders <= 4,</pre>
190
                        "At most four faders supported");
          static_assert(use_A6_A7 || !fader_3_A2,
191
                        "Cannot use A2 for motor driver "
192
                        "and analog input at the same time");
193
194
          static_assert(!WITH_MIDI || !serial_control,
195
                        "Cannot use MIDI and Serial control at the same time");
196
          static_assert(!WITH_MIDI || !print_controller_signals,
                        "Cannot use MIDI while printing controller signals");
197
198
199
     constexpr uint8_t Config::touch_masks[];
     constexpr float Ts = Config::Ts;
200
201
     // ----- ADC, Capacitive Touch State and Motors -----//
202
203
204
     ADCManager<Config> adc;
     TouchSense<Config> touch;
205
     Motors<Config> motors;
206
207
     // ------ Setpoints and References ----- //
208
209
     // Setpoints (target positions) for all faders:
210
211
     Reference<Config> references[Config::num_faders];
212
213
     // ------ Controllers -----//
214
215
     // The main PID controllers. Need tuning for your specific setup:
216
217
     PID controllers[] {
218
         // This is an example of a controller with very little overshoot
219
         {
220
                     // Kp: proportional gain
             2, // Ki: integral gain 0.035, // Kd: derivative gain Ts, // Ts: sampling time
221
222
223
             60, // fc: cutoff frequency of derivative filter (Hz), zero to disable
224
225
         // This one has more overshoot, but less ramp tracking error
226
227
228
                     // Kp: proportional gain
                    // Ki: integral gain
229
230
             0.028, // Kd: derivative gain
231
                    // Ts: sampling time
             Ts,
             40, // fc: cutoff frequency of derivative filter (Hz), zero to disable
232
233
         // This is a very aggressive controller
234
235
             8.55, // Kp: proportional gain
236
             440, // Ki: integral gain
0.043, // Kd: derivative gain
Ts, // Ts: sampling time
237
238
239
240
             70, // fc: cutoff frequency of derivative filter (Hz), zero to disable
241
242
         // Fourth controller
243
244
                    // Kp: proportional gain
// Ki: integral gain
245
             0.035, // Kd: derivative gain
246
                    // Ts: sampling time
247
248
              60, // fc: cutoff frequency of derivative filter (Hz), zero to disable
250
     };
251
     // ----- MTDT ----- //
252
253
     #if WITH_MIDI
254
     #include <Control Surface.h>
255
257
     USBDebugMIDI_Interface midi {Config::serial_baud_rate};
258
259
260
     HardwareSerialMIDI_Interface midi {Serial, Config::midi_baud_rate};
261
     #endif
262
263
     template <uint8 t Idx>
     void sendMIDIMessages(bool touched) {
   // Don't send if the UART buffer is (almost) full
264
265
266
         if (Serial.availableForWrite() < 6) return;</pre>
267
         // Touch
         static bool prevTouched = false; // Whether the knob is being touched
268
269
         if (touched != prevTouched) {
270
              const MIDIAddress addr = MCU::FADER_TOUCH_1 + Idx;
271
              touched ? midi.sendNoteOn(addr, 127) : midi.sendNoteOff(addr, 127);
272
             prevTouched = touched;
273
         }
// Position
274
275
         static Hysteresis<6 - Config::adc_ema_K, uint16_t, uint16_t> hyst;
         if (prevTouched && hyst.update(adc.readFiltered(Idx))) {
276
              auto value = AH::increaseBitDepth<14, 10, uint16_t>(hyst.getValue());
277
278
             midi.sendPitchBend(MCU::VOLUME_1 + Idx, value);
279
         }
     }
280
281
     void updateMIDISetpoint(ChannelMessage msg) {
282
283
         auto type = msg.getMessageType();
```

```
284
          auto channel = msg.getChannel().getRaw();
285
          if (type == MIDIMessageType::PITCH_BEND && channel < Config::num_faders)</pre>
286
              references[channel].setMasterSetpoint(msg.getData14bit() >> 4);
287
     }
288
289
     void initMIDI() { midi.begin(); }
290
291
     void updateMIDI() {
         while (1) {
    auto evt = midi.read();
292
293
294
              if (evt == MIDIReadEvent::NO_MESSAGE)
295
                  break;
296
              else if (evt == MIDIReadEvent::CHANNEL_MESSAGE)
                  updateMIDISetpoint(midi.getChannelMessage());
297
298
     }
299
300
301
     #endif
302
     // ----- Printing all signals for serial plotter ----- //
303
304
305
      template <uint8_t Idx>
306
     void printControllerSignals(int16_t setpoint, int16_t adcval, int16_t control) {
307
          // Send (binary) controller signals over Serial to plot in Python
308
          if (Config::serial_control && references[Idx].experimentInProgress()) {
309
              const int16_t data[3] {setpoint, adcval, control};
310
              SLIPSender(Serial).writePacket(reinterpret_cast<const uint8_t *>(data),
                                              sizeof(data));
311
312
313
          // Print signals as text
314
         else if (Config::print_controller_signals &&
                   Idx == Config::controller_to_print) {
315
              Serial.print(setpoint);
317
              Serial.print('\t');
318
              Serial.print(adcval);
             Serial.print('\t');
Serial.print((control + 256) * 2);
319
320
321
              Serial.println();
322
323
     }
324
325
     // ------ Control logic -----//
326
327
      template <uint8_t Idx>
     void updateController(uint16 t setpoint, int16 t adcval, bool touched) {
328
329
         auto &controller = controllers[Idx];
330
          // Prevent the motor from being turned off after being touched
331
         if (touched) controller.resetActivityCounter();
332
333
334
          // Set the target position
335
          if (Config::setpoint_sma_length > 0) {
336
              static SMA<Config::setpoint_sma_length, uint16_t, uint32_t> sma;
337
              uint16_t filtsetpoint = sma(setpoint);
338
              controller.setSetpoint(filtsetpoint);
339
         } else {
             controller.setSetpoint(setpoint):
340
         }
341
342
343
          // Update the PID controller to get the control action
         int16_t control = controller.update(adcval);
345
346
          // Apply the control action to the motor
347
         if (Config::enable_controller) {
              if (touched) // Turn off motor if knob is touched
348
349
                  motors.setSpeed<Idx>(0);
350
              else
351
                  motors.setSpeed<Idx>(control);
352
         }
353
     #if WITH_MIDI
354
355
          sendMIDIMessages<Idx>(touched);
356
         printControllerSignals<Idx>(controller.getSetpoint(), adcval, control);
357
358
     #endif
359
     }
360
361
     template <uint8_t Idx>
362
     void readAndUpdateController() {
    // Read the ADC value for the given fader:
363
          int16_t adcval = adc.read(Idx);
364
365
          // If the ADC value was updated by the ADC interrupt, run the control loop:
         if (adcval >= 0) {
    // Check if the fader knob is touched
366
367
             bool touched = touch.read(Idx);
// Read the target position
368
369
370
              uint16_t setpoint = references[Idx].getNextSetpoint();
              // Run the control loop
371
              updateController<Idx>(setpoint, adcval, touched);
372
373
              // Write -1 so the controller doesn't run again until the next value is
374
              // available:
375
              adc.write(Idx, -1);
              if (Config::enable_overrun_indicator)
376
                  cbi(PORTB, 5); // Clear overrun indicator
377
378
         }
```

```
379
     }
380
381
                     -----//
382
383
     void onRequest();
384
     void onReceive(int);
385
     void updateSerialIn();
386
387
     void setup()
          // Initialize some globals
388
389
          for (uint8_t i = 0; i < Config::num_faders; ++i) {</pre>
              // all fader positions for the control loop start of as -1 (no reading)
390
391
              adc.write(i, -1);
              // reset the filter to the current fader position to prevent transients
392
393
              adc.writeFiltered(i, analogRead(adc.channel_index_to_mux_address(i)));
              // after how many seconds of not touching the fader and not changing // the reference do we turn off the motor?
394
395
396
              controllers[i].setActivityTimeout(Config::timeout);
397
         }
398
          // Configure the hardware
399
          if (Config::enable_overrun_indicator) sbi(DDRB, 5); // Pin 13 output
400
401
402
     #if WITH_MIDI
403
         initMIDI();
404
     #else
405
          if (Config::print_frequencies || Config::print_controller_signals ||
406
              Config::serial control)
407
              Serial.begin(Config::serial_baud_rate);
408
     #endif
409
410
          adc.begin();
411
          touch.begin()
412
         motors.begin();
413
414
          // Print information to the serial monitor or legends to the serial plotter
          if (Config::print_frequencies) {
415
              Serial.println();
Serial.print(F("Interrupt frequency (Hz): "));
416
417
418
              Serial.println(Config::interrupt_freq);
              Serial.print(F("Controller sampling time (μs): "));
Serial.println(Config::Ts * 1e6);
419
420
421
              Serial.print(F("ADC clock rate (Hz): "));
              Serial.println(Config::adc_clock_freq);
Serial.print(F("ADC sampling rate (Sps): "));
422
423
424
              Serial.println(adc.adc_rate);
425
426
         if (Config::print_controller_signals) {
              Serial.println();
Serial.println(F("Reference\tActual\tControl\t-"));
427
428
              Serial.println(F("0\t0\t0\t0\t0\t0\t0\t1024"));
429
430
431
432
          // Initalize I<sup>2</sup>C slave and attach callbacks
433
         if (Config::i2c_address) {
434
              Wire.begin(Config::i2c_address);
435
              Wire.onRequest(onRequest):
              Wire.onReceive(onReceive);
436
437
438
439
          // Enable Timer2 overflow interrupt, this starts reading the touch sensitive
440
          // knobs and sampling the ADC, which causes the controllers to run in the
441
          // main loop
442
          sbi(TIMSK2, T0IE2);
443
     }
444
445
     void loop() {
         if (Config::num_faders > 0) readAndUpdateController<0>();
446
          if (Config::num_faders > 1) readAndUpdateController<1>();
447
          if (Config::num_faders > 2) readAndUpdateController<2>();
448
         if (Config::num_faders > 3) readAndUpdateController<3>();
449
450
     #if WITH_MIDI
451
         updateMIDI();
     #else
452
         if (Config::serial_control) updateSerialIn();
453
     #endif
454
455
     }
456
457
     // ------ Interrupts ----- //
458
459
     // Fires at a constant rate of `interrupt_freq`.
460
     ISR(TIMER2_OVF_vect) {
461
          // We don't have to take all actions at each interupt, so keep a counter to
          // know when to take what actions.
462
463
          static uint8 t counter = 0:
464
465
          adc.update(counter);
466
         touch.update(counter);
467
468
469
          if (counter == Config::interrupt_divisor) counter = 0;
     }
470
471
     // Fires when the ADC measurement is complete. Stores the reading, both before
472
     // and after filtering (for the controller and for user input respectively).
473
```

```
474 | ISR(ADC_vect) { adc.complete(); }
475
476
     // ----- Wire ----- //
477
478
     \ensuremath{//} Send the touch status and filtered fader positions to the master.
479
     void onRequest() {
480
          uint8 t touched = 0;
          for (uint8_t i = 0; i < Config::num_faders; ++i)</pre>
481
              touched |= touch.touched[i] << i;
482
          Wire.write(touched);
483
          for (uint8_t i = 0; i < Config::num_faders; ++i) {</pre>
484
              uint16_t filt_read = adc.readFiltered14ISR(i);
485
              Wire.write(reinterpret_cast<const uint8_t *>(&filt_read), 2);
486
487
488
     }
489
     // Change the setpoint of the given fader based on the value in the message
490
491
     // received from the master.
     void onReceive(int count) {
492
         if (count < 2) return;
if (Wire.available() < 2) return;</pre>
493
494
          uint16_t data = Wire.read();
495
496
          data |= uint16_t(Wire.read()) << 8;</pre>
497
          uint8_t idx = data >> 12;
498
          data &= 0x03FF;
499
          if (idx < Config::num_faders) references[idx].setMasterSetpoint(data);</pre>
     }
500
501
     // ------ Serial ----- //
502
503
     // Read SLIP messages from the serial port that allow dynamically updating the
     // tuning of the controllers. This is used by the Python tuning script.
506
     // Message format: <command> <fader> <value>
507
     // Commands:
508
509
     //
          - p: proportional gain Kp
     //
510
          - i: integral gain Ki
          - d: derivative gain Kd
- c: derivative filter cutoff frequency f_c (Hz)
511
512
          - m: maximum absolute control output
          - s: start an experiment, using getNextExperimentSetpoint
     // Fader index: up to four faders are addressed using the characters '0' - '3'.
515
516
     // Values: values are sent as 32-bit little Endian floating point numbers.
517
     // For example the message c0\x00\x00\x20\x42' sets the derivative filter
518
     // cutoff frequency of the first fader to 40.
519
520
521
     void updateSerialIn() {
         static SLIPParser parser;
static char cmd = '\0';
522
523
          static uint8_t fader_idx = 0;
524
525
          static uint8_t buf[4];
          static_assert(sizeof(buf) == sizeof(float), "");
526
527
          // This function is called if a new byte of the message arrives:
528
          auto on_char_receive = [&](char new_byte, size_t index_in_packet) {
              if (index_in_packet == 0)
  cmd = new_byte;
529
530
              else if (index_in_packet == 1)
531
532
                  fader_idx = new_byte - '0';
533
              else if (index_in_packet < 6)</pre>
                  buf[index_in_packet - 2] = new_byte;
535
          };
// Convert the 4-byte buffer to a float:
536
          auto as_f32 = [&] {
537
538
              float f:
              memcpy(&f, buf, sizeof(float));
539
540
              return f:
541
          // Read and parse incoming packets from Serial:
542
          while (Serial.available() > 0) {
543
544
              uint8_t c = Serial.read();
545
              auto msg_size = parser.parse(c, on_char_receive);
546
              // If a complete message of 6 bytes was received, and if it addresses
              // a valid fader:
547
              if (msg_size == 6 && fader_idx < Config::num_faders) {</pre>
548
                   // Execute the command:
549
                  switch (cmd) {
550
                      case 'p': controllers[fader_idx].setKp(as_f32()); break;
case 'i': controllers[fader_idx].setKi(as_f32()); break;
case 'd': controllers[fader_idx].setKd(as_f32()); break;
551
553
                       case 'c': controllers[fader_idx].setEMACutoff(as_f32()); break;
554
555
                       case 'm': controllers[fader_idx].setMaxOutput(as_f32()); break;
                       case 's':
556
                           references[fader_idx].startExperiment(as_f32());
557
                           controllers[fader_idx].resetIntegral();
558
559
                           break;
                       default: break;
                 }
             }
562
563
         }
564
     }
```

ADC.hpp

```
#pragma once
     #include "Registers.hpp"
     #include <avr/interrupt.h>
 3
     #include <util/atomic.h>
     #include <Arduino_Helpers.h> // EMA.hpp
 8
     #include <AH/Filters/EMA.hpp> // EMA filter
 q
10
     template <class Config>
    struct ADCManager {

/// Evenly distribute the analog readings in the control loop period.
11
12
         constexpr static uint8_t adc_start_count =
   Config::interrupt_divisor / Config::num_faders;
13
14
15
          /// The rate at which we're sampling using the ADC.
         constexpr static float adc_rate = Config::interrupt_freq / adc_start_count;
         // Check that this doesn't take more time than the 13 ADC clock cycles it
17
         // takes to actually do the conversion. Use 14 instead of 13 just to be safe.
static_assert(adc_rate <= Config::adc_clock_freq / 14, "ADC too slow");</pre>
18
19
20
         /// Enable the ADC with Vcc reference, with the given prescaler, auto
21
22
         /// trigger disabled, ADC interrupt enabled.
         /// Called from main program, with interrupts enabled.
23
24
         void begin();
25
26
         /// Start an ADC conversion on the given channel.
27
         /// Called inside an ISR.
28
         void startConversion(uint8_t channel);
29
         /// Start an ADC conversion at the right intervals.
30
         /// @param counter
31
                       Counter that keeps track of how many times the timer interrupt
32
33
                       fired, between 0 and Config::interrupt_divisor - 1.
         /// Called inside an ISR.
34
35
         void update(uint8_t counter);
36
37
         /// Read the latest ADC result.
38
         /// Called inside an ISR.
         void complete();
39
40
         /// Get the latest ADC reading for the given index.
41
         /// Called from main program, with interrupts enabled.
int16_t read(uint8_t idx);
42
43
44
         /// Get the latest filtered ADC reading for the given index.
         /// Called from main program, with interrupts enabled.
45
46
         /// @return (16 - Config::adc_ema_K)-bit filtered ADC value.
         uint16_t readFiltered(uint8_t idx);
/// Get the latest filtered ADC reading for the given index.
47
48
         /// Called from main program, with interrupts enabled.
/// @return 14-bit filtered ADC value.
49
50
         uint16_t readFiltered14(uint8_t idx);
51
         /// Get the latest filtered ADC reading for the given index.
52
53
         /// Called inside an ISR.
54
         /// @return 14-bit filtered ADC value.
55
         uint16_t readFiltered14ISR(uint8_t idx);
56
57
         /// Write the ADC reading for the given index.
58
         /// Called from main program, with interrupts enabled.
         void write(uint8_t idx, int16_t val);
/// Write the filtered ADC reading for the given index.
/// Called only before ADC interrupts are enabled.
59
60
61
62
         /// @param val 10-bit ADC value.
         void writeFiltered(uint8_t idx, uint16_t val);
63
          /// Convert a 10-bit ADC reading to the largest possible range for the given
65
         /// value of Config::adc_ema_K.
66
         uint16_t shiftValue10(uint16_t val);
/// Convert the given shifted filtered value to a 14-bit range.
67
68
69
         uint16_t unShiftValue14(uint16_t val);
70
         /// Convert the channel index between 0 and Config::num faders - 1 to the
71
72
         /// actual ADC multiplexer address.
73
         constexpr static inline uint8_t
74
         channel_index_to_mux_address(uint8_t adc_mux_idx) {
75
              return Config::use_A6_A7
76
                          ? (adc_mux_idx < 2 ? adc_mux_idx : adc_mux_idx + 4)</pre>
77
                           : adc_mux_idx;
78
         }
79
80
         /// Index of the ADC channel currently being read.
         uint8_t channel_index = Config::num_faders;
81
         /// Latest 10-bit ADC reading of each fader (updated in ADC ISR). Used for
82
         /// the control loop.
83
84
         volatile int16_t readings[Config::num_faders];
85
         /// Filters for ADC readings.
         {\tt EMA < Config::adc\_ema\_K, \ uint16\_t > \ filters[Config::num\_faders];}
86
         /// Filtered (shifted) ADC readings. Used to output over MIDI etc. but not
87
         /// for the control loop
88
         volatile uint16_t filtered_readings[Config::num_faders];
90
    };
     template <class Config>
     inline void ADCManager<Config>::begin() {
```

```
94
          constexpr auto prescaler = factorToADCPrescaler(Config::adc_prescaler_fac);
 95
          static_assert(prescaler != ADCPrescaler::Invalid, "Invalid prescaler");
 96
 97
          ATOMIC_BLOCK(ATOMIC_FORCEON) {
 98
              cbi(ADCSRA, ADEN); // Disable ADC
 99
100
              cbi(ADMUX, REFS1); // Vcc reference
              sbi(ADMUX, REFS0); // Vcc reference
101
102
              cbi(ADMUX, ADLAR); // 8 least significant bits in ADCL
103
104
105
              setADCPrescaler(prescaler);
106
              cbi(ADCSRA, ADATE); // Auto trigger disable
107
              sbi(ADCSRA, ADIE); // ADC Interrupt Enable
sbi(ADCSRA, ADEN); // Enable ADC
108
109
110
          }
111
     }
112
      template <class Config>
113
     inline void ADCManager<Config>::update(uint8_t counter) {
   if (Config::num_faders > 0 && counter == 0 * adc_start_count)
114
              startConversion(0);
116
117
          else if (Config::num_faders > 1 && counter == 1 * adc_start_count)
118
              startConversion(1);
119
          else if (Config::num_faders > 2 && counter == 2 * adc_start_count)
          startConversion(2);
else if (Config::num_faders > 3 && counter == 3 * adc_start_count)
120
121
122
              startConversion(3);
123
    }
124
125
      template <class Config>
      inline void ADCManager<Config>::startConversion(uint8_t channel) {
127
          channel_index = channel;
128
          ADMUX &= 0xF0;
129
          ADMUX |= channel_index_to_mux_address(channel);
130
          sbi(ADCSRA, ADSC); // ADC Start Conversion
     }
131
132
      template <class Config>
      inline void ADCManager<Config>::complete() {
135
          if (Config::enable_overrun_indicator && readings[channel_index] >= 0)
136
              sbi(PORTB, 5);
                                 // Set overrun indicator
          uint16_t value = ADC; // Store ADC reading
readings[channel_index] = value;
137
138
139
          // Filter the reading
140
          auto &filter = filters[channel index]:
          filtered_readings[channel_index] = filter(shiftValue10(value));
141
142
143
144
      template <class Config>
145
      inline int16_t ADCManager<Config>::read(uint8_t idx) {
146
          int16_t val;
147
          ATOMIC_BLOCK(ATOMIC_FORCEON) { val = readings[idx]; }
          return val;
148
149
150
151
      template <class Config>
152
     inline void ADCManager<Config>::write(uint8_t idx, int16_t val) {
153
          ATOMIC_BLOCK(ATOMIC_FORCEON) { readings[idx] = val; }
156
      template <class Config>
      inline uint16_t ADCManager<Config>::shiftValue10(uint16_t val) {
157
158
          return val << (6 - Config::adc_ema_K);</pre>
159
160
161
      template <class Config>
      inline uint16_t ADCManager<Config>::unShiftValue14(uint16_t val) {
          const int shift = 6 - Config::adc_ema_K - 4;
          return shift >= 0 ? val >> shift : val << -shift;</pre>
164
165
166
167
      template <class Config>
     inline uint16_t ADCManager<Config>::readFiltered14ISR(uint8_t idx) {
168
          return unShiftValue14(filtered_readings[idx]);
169
170
171
172
      template <class Config>
      inline uint16_t ADCManager<Config>::readFiltered(uint8_t idx) {
173
174
          uint16_t val;
175
          ATOMIC_BLOCK(ATOMIC_FORCEON) { val = filtered_readings[idx]; }
176
          return val;
177
178
      template <class Config>
179
180
     inline uint16_t ADCManager<Config>::readFiltered14(uint8_t idx) {
181
          return unShiftValue14(readFiltered(idx));
183
184
      template <class Config>
      inline void ADCManager<Config>::writeFiltered(uint8_t idx, uint16_t val) {
185
186
          filters[idx].reset(shiftValue10(val));
```

Touch.hpp

```
#pragma once
     #include <avr/interrupt.h>
     #include <avr/io.h>
 3
     #include <util/atomic.h>
 6
     template <class Config>
     struct TouchSense {
 8
 q
          /// The actual threshold as a number of interrupts instead of seconds:
10
          static constexpr uint8_t touch_sense_thres =
          Config::interrupt_freq * Config::touch_rc_time_threshold;
/// Ignore mains noise by making the "touched" status stick for longer than
11
12
          /// the mains period:
13
          static constexpr float period_50Hz = 1. / 50;
15
          /// Keep the "touched" status active for this many periods (see below):
          static constexpr uint8_t touch_sense_stickiness =
          Config::interrupt_freq * period_50Hz * 4 / Config::interrupt_divisor; /// Check that the threshold is smaller than the control loop period:
17
18
19
          static_assert(touch_sense_thres < Config::interrupt_divisor,</pre>
                           "Touch sense threshold too high");
20
21
          /// The combined bit mask for all touch GPIO pins.
22
          static constexpr uint8_t gpio_mask =
23
               (Config::num_faders > 0 ? Config::touch_masks[0] : 0) |
(Config::num_faders > 1 ? Config::touch_masks[1] : 0) |
24
25
26
               (Config::num_faders > 2 ? Config::touch_masks[2] : 0) |
27
               (Config::num_faders > 3 ? Config::touch_masks[3] : 0);
28
29
          /// Initialize the GPIO pins for capacitive sensing.
          \ensuremath{/\!/}\xspace Called from main program, with interrupts enabled.
30
31
          void begin();
32
33
          /// Check which touch sensing knobs are being touched.
          /// @param counter
34
35
                        Counter that keeps track of how many times the timer interrupt
          /// fired, between
                        fired, between 0 and Config::interrupt_divisor - 1.
36
37
38
          void update(uint8_t counter);
39
40
          /// Get the touch status for the given index.
          /// Called from main program, with interrupts enabled.
41
42
          bool read(uint8 t idx);
43
44
          // Timers to take into account the stickiness.
          uint8_t touch_timers[Config::num_faders] {};
45
46
          // Whether the knobs are being touched.
47
          volatile bool touched[Config::num_faders] {};
48
    };
49
     template <class Config>
50
     void TouchSense<Config>::begin() {
51
         ATOMIC_BLOCK(ATOMIC_FORCEON) {
52
              PORTB &= ~gpio_mask; // low
DDRB |= gpio_mask; // output mode
53
54
55
56
    }
57
    // 0. The pin mode is "output", the value is "low".
// 1. Set the pin mode to "input", touch_timer = 0.
// 2. The pin will start charging through the external pull-up resistor.
58
59
60
    // 3. After a fixed amount of time, check whether the pin became "high":
61
62
            if this is the case, the RC-time of the knob/pull-up resistor circuit
            was smaller than the given threshold. Since R is fixed, this can be used
            to infer C, the capacitance of the knob: if the capacitance is lower than
    // the threshold (i.e. RC-time is lower), this means the knob was not touched.
// 5. Set the pin mode to "output", to start discharging the pin to 0V again.
66
67
    \ensuremath{//} 6. Some time later, the pin has discharged, so switch to "input" mode and
    //
            start charging again for the next RC-time measurement.
68
    //
69
    // The "touched" status is sticky: it will remain set for at least
70
     // touch_sense_stickiness ticks. If the pin never resulted in another "touched" // measurement during that period, the "touched" status for that pin is cleared.
71
72
73
74
     template <class Config>
75
     void TouchSense<Config>::update(uint8_t counter) {
76
         if (gpio_mask == 0)
               return;
77
          if (counter == 0) {
78
              DDRB &= ~gpio_mask; // input mode, start charging
79
          } else if (counter == touch_sense_thres) {
80
              uint8_t touched_bits = PINB;
81
              DDRB |= gpio_mask; // output mode, start discharging for (uint8_t i = 0; i < Config::num_faders; ++i) {
83
84
                   if (Config::touch_masks[i] == 0)
                        continue;
85
                   bool touch_i = (touched_bits & Config::touch_masks[i]) == 0;
86
87
                   if (touch_i) {
                        touch_timers[i] = touch_sense_stickiness;
88
                        touched[i] = true;
89
                   } else if (touch_timers[i] > 0) {
                         --touch_timers[i];
                        if (touch_timers[i] == 0) touched[i] = false;
93
```

Controller.hpp

```
#pragma once
 2
        #include <stddef.h>
 3
        #include <stdint.h>
        /// @see @ref horner(float,float,const float(&)[N])
        constexpr inline float horner_impl(float xa, const float *p, size_t count,
 8
                                                                            float t) {
 q
                return count == 0 ? p[count] + xa * t
                                                   : horner_impl(xa, p, count - 1, p[count] + xa * t);
10
11
       }
12
        /// Evaluate a polynomial using
13
        /// [Horner's method](https://en.wikipedia.org/wiki/Horner%27s_method).
        template <size_t N>
        constexpr inline float horner(float x, float a, const float (&p)[N]) {
                return horner_impl(x - a, p, N - 2, p[N - 1]);
17
18
19
       /// Compute the weight factor of a exponential moving average filter
20
        /// with the given cutoff frequency
21
        /// @see https://tttapa.github.io/Pages/Mathematics/Systems-and-Control-Theory/Digital-
22
        filters/Exponential \%20 Moving \%20 Average/Exponential-Moving-Average.html \# cutoff-frequency filters/Exponential \%20 Moving \%20 Average/Exponential \%20 Moving Moving \%20 Moving Moving Moving \%20 Moving Moving
23
                          for the formula.
24
         inline float calcAlphaEMA(float f_n) {
25
                // Taylor coefficients of
                // \alpha(f_n) = \cos(2\pi f_n) - 1 + \sqrt{(\cos(2\pi f_n))^2 - 4\cos(2\pi f_n) + 3)}
26
27
                // at f_n = 0.25
28
                constexpr static float coeff[] {
                       +7.3205080756887730e-01, +9.7201214975728490e-01, -3.7988125051760377e+00, +9.5168450173968860e+00, -2.0829320344443730e+01, +3.0074306603814595e+01, -1.6446172139457754e+01, -8.0756002564633450e+01, +3.2420501524111750e+02, -6.5601870948443250e+02,
29
30
31
32
33
34
                return horner(f_n, 0.25, coeff);
35
       }
36
37
        /// Standard PID (proportional, integral, derivative) controller. Derivative
38
        \ensuremath{/\!/\!/} component is filtered using an exponential moving average filter.
39
        class PID {
40
            public:
41
42
                PID() = default;
43
                /// @param
                                       kp
                                        Proportional gain
44
45
                /// @param
                                       ki
                                        Integral gain
46
                /// @param kd
47
                                       Derivative gain
48
                ///
                /// @param Ts
49
                                       Sampling time (seconds)
                ///
50
                /// @param fc
51
52
                                       Cutoff frequency of derivative EMA filter (Hertz),
53
                                       zero to disable the filter entirely
54
                PID(float kp, float ki, float kd, float Ts, float f_c = 0,
55
                        float maxOutput = 255)
56
                        : Ts(Ts), maxOutput(maxOutput) {
57
                        setKp(kp);
                        setKi(ki);
58
59
                        setKd(kd):
                        setEMACutoff(f_c);
60
61
                }
62
                /// Update the controller: given the current position, compute the control
65
                float update(uint16_t input) {
66
                        // The error is the difference between the reference (setpoint) and the
                        // actual position (input)
67
                        int16_t error = setpoint - input;
// The integral or sum of current and previous errors
68
69
                        int32_t newIntegral = integral + error;
// Compute the difference between the current and the previous input,
70
71
72
                        // but compute a weighted average using a factor \alpha \in (0,1]
73
                        float diff = emaAlpha * (prevInput - input);
74
                        // Update the average
75
                        prevInput -= diff;
76
                        // Check if we can turn off the motor
77
                        if (activityCount >= activityThres && activityThres) {
78
                                float filtError = setpoint - prevInput;
79
                                if (filtError >= -errThres && filtError <= errThres) {</pre>
80
                                        errThres = 2; // hysteresis
82
                                        integral = newIntegral;
83
                                        return 0;
84
                               } else {
85
                                       errThres = 1;
86
                        } else {
87
                                ++activityCount;
88
                               errThres = 1;
89
                        }
                        bool backward = false;
92
```

```
93
               int32 t calcIntegral = backward ? newIntegral : integral;
 94
 95
 96
               float output = kp * error + ki_Ts * calcIntegral + kd_Ts * diff;
 97
 98
               // Clamp and anti-windup
              if (output > maxOutput)
   output = maxOutput;
 99
100
              else if (output < -maxOutput)
  output = -maxOutput;</pre>
101
102
103
               else
                   integral = newIntegral;
104
105
106
              return output;
107
          }
108
          void setKp(float kp) { this->kp = kp; } ///< Proportional gaivoid setKi(float ki) { this->ki_Ts = ki * this->Ts; } ///< Integral gain void setKd(float kd) { this->kd_Ts = kd / this->Ts; } ///< Derivative gain
109
                                                                      ///< Proportional gain
110
111
112
          113
                                                          ///< Proportional gain
114
115
116
          /// Set the cutoff frequency (-3 dB point) of the exponential moving average /// filter that is applied to the input before taking the difference for
117
118
          /// computing the derivative term.
119
          void setEMACutoff(float f_c) {
120
               float f_n = f_c * Ts; // normalized sampling frequency
121
               this->emaAlpha = f_c == 0 ? 1 : calcAlphaEMA(f_n);
122
123
124
          /// Set the reference/target/setpoint of the controller.
125
          void setSetpoint(uint16_t setpoint) {
   if (this->setpoint != setpoint) this->activityCount = 0;
126
127
128
               this->setpoint = setpoint;
129
          /// @see @ref setSetpoint(int16_t)
130
          uint16_t getSetpoint() const { return setpoint; }
131
          /// Set the maximum control output magnitude. Default is 255, which clamps
134
          /// the control output in [-255, +255].
135
          void setMaxOutput(float maxOutput) { this->maxOutput = maxOutput; }
136
          /// @see @ref setMaxOutput(float)
          float getMaxOutput() const { return maxOutput; }
137
138
          /// Reset the activity counter to prevent the motor from turning off.
139
          void resetActivityCounter() { this->activityCount = 0; }
140
          /// Set the number of seconds after which the motor is turned off, zero to
141
          /// keep it on indefinitely.
142
          void setActivityTimeout(float s) {
143
144
              if (s == 0)
145
                   activityThres = 0;
146
               else
                   activityThres = uint16_t(s / Ts) == 0 ? 1 : s / Ts;
147
148
149
150
          /// Reset the sum of the previous errors to zero.
151
          void resetIntegral() { integral = 0; }
152
153
          float Ts = 1;
                                         ///< Sampling time (seconds)
154
155
          float maxOutput = 255;
                                         ///< Maximum control output magnitude
156
          float kp = 1;
                                         ///< Proportional gain
          float ki_Ts = 0;
157
                                         ///< Integral gain times Ts
          float kd_Ts = 0;
                                         ///< Derivative gain divided by Ts
158
                                         ///< Weight factor of derivative EMA filter.
159
          float emaAlpha = 1:
          float prevInput = 0;
                                         ///< (Filtered) previous input for derivative.
          uint16_t activityCount = 0; ///< How many ticks since last setpoint change.</pre>
161
          uint16_t activityThres = 0; ///< Threshold for turning off the output.</pre>
162
                                    ///< Threshold with hysteresis.
163
          uint8_t errThres = 1;
164
          int32_t integral = 0;
                                         ///< Sum of previous errors for integral.
165
          uint16_t setpoint = 0;
                                         ///< Position reference.
     };
166
```

Motor.hpp

```
#pragma once
#include "Registers.hpp"
    #include <avr/interrupt.h>
 3
    #include <util/atomic.h>
 6
    /// Configure Timer0 in either phase correct or fast PWM mode with the given
     /// prescaler, enable output compare B.
 8
    inline void setupMotorTimer0(bool phase_correct, Timer0Prescaler prescaler) {
        ATOMIC_BLOCK(ATOMIC_RESTORESTATE) {
    setTimer0WGMode(phase_correct ? Timer0WGMode::PWM
q
10
11
                                              : TimerOWGMode::FastPWM);
             setTimer0Prescaler(prescaler);
12
             sbi(TCCR0A, COMOB1); // Table 14-6, 14-7 Compare Output Mode sbi(TCCR0A, COMOA1); // Table 14-6, 14-7 Compare Output Mode
13
15
        }
    }
17
    /// Configure Timer2 in either phase correct or fast PWM mode with the given
19
    /// prescaler, enable output compare B.
    inline void setupMotorTimer2(bool phase_correct, Timer2Prescaler prescaler) {
20
        ATOMIC_BLOCK(ATOMIC_RESTORESTATE) {
21
             setTimer2WGMode(phase_correct ? Timer2WGMode::PWM
22
23
                                             : Timer2WGMode::FastPWM);
24
             setTimer2Prescaler(prescaler);
25
             sbi(TCCR2A, COM2B1); // Table 14-6, 14-7 Compare Output Mode
26
             sbi(TCCR2A, COM2A1); // Table 14-6, 14-7 Compare Output Mode
27
         }
28
    }
29
    \ensuremath{///} Configure the timers for the PWM outputs.
30
31
     template <class Config>
32
    inline void setupMotorTimers() {
33
         constexpr auto prescaler0 = factorToTimer0Prescaler(Config::prescaler_fac);
         static_assert(prescaler0 != Timer0Prescaler::Invalid, "Invalid prescaler");
34
35
         constexpr auto prescaler2 = factorToTimer2Prescaler(Config::prescaler_fac);
         static_assert(prescaler2 != Timer2Prescaler::Invalid, "Invalid prescaler");
36
37
38
         if (Config::num_faders > 0)
39
             setupMotorTimer2(Config::phase_correct_pwm, prescaler2);
         if (Config::num_faders > 2)
40
             setupMotorTimer0(Config::phase_correct_pwm, prescaler0);
41
42
    }
43
44
    /// Class for driving up to 4 DC motors using PWM.
45
    template <class Config>
46
    struct Motors {
47
         void begin();
         template <uint8 t Tdx>
48
        void setSpeed(int16_t speed);
49
50
         template <uint8 t Idx>
51
        void setupGPIO();
template <uint8_t Idx>
52
53
54
         void forward(uint8_t speed);
55
         template <uint8_t Idx>
56
         void backward(uint8_t speed);
57
    };
58
     template <class Config>
59
    inline void Motors<Config>::begin() {
60
61
         setupMotorTimers<Config>();
62
63
         if (Config::num_faders > 0) {
             sbi(DDRD, 2);
64
             sbi(DDRD, 3);
65
66
         if (Config::num_faders > 1) {
67
68
             sbi(DDRD, 7);
             sbi(DDRB, 3);
69
70
         if (Config::num_faders > 2) {
71
72
             sbi(DDRD, 4);
73
             sbi(DDRD, 5);
74
75
         if (Config::num_faders > 3) {
76
             if (Config::fader_3_A2)
77
                 sbi(DDRC, 2);
             else
78
79
                 sbi(DDRB, 5);
80
81
             sbi(DDRD, 6);
82
        }
83
    }
84
85
    // Fast PWM (Table 14-6):
          Clear OCOB on Compare Match, set OCOB at BOTTOM (non-inverting mode).
86
    // Phase Correct PWM (Table 14-7):
87
         Clear OCOB on compare match when up-counting. Set OCOB on compare match
88
          when down-counting.
    template <class Config>
     template <uint8_t Idx>
    inline void Motors<Config>::forward(uint8_t speed) {
         if (Idx >= Config::num_faders)
93
```

```
94
               return;
 95
           else if (Idx == 0)
                ATOMIC_BLOCK(ATOMIC_RESTORESTATE) {
 96
                    cbi(TCCR2A, COM2B0);
cbi(PORTD, 2);
 97
 98
 99
                    OCR2B = speed;
100
           else if (Idx == 1)
ATOMIC_BLOCK(ATOMIC_RESTORESTATE) {
    cbi(TCCR2A, COM2A0);
    cbi(PORTD, 7);
101
102
103
104
                     OCR2A = speed;
105
106
107
           else if (Idx == 2)
108
                ATOMIC_BLOCK(ATOMIC_RESTORESTATE) {
                    cbi(TCCR0A, COM0B0);
cbi(PORTD, 4);
109
110
                    OCROB = speed;
111
112
               }
           else if (Idx == 3)
113
                ATOMIC_BLOCK(ATOMIC_RESTORESTATE) {
114
                    cbi(TCCR0A, COM0A0);
if (Config::fader_3_A2)
116
117
                         cbi(PORTC, 2);
118
                        cbi(PORTB, 5);
119
                    OCROA = speed;
120
                }
121
122
      }
123
124
      // Fast PWM (Table 14-6):
            Set OCOB on Compare Match, clear OCOB at BOTTOM (inverting mode).
125
      // Phase Correct PWM (Table 14-7):
127
            Set OCOB on compare match when up-counting. Clear OCOB on compare match
128
            when down-counting.
      template <class Config>
template <uint8_t Idx>
129
130
      inline void Motors<Config>::backward(uint8_t speed) {
   if (Idx >= Config::num_faders)
131
132
                return;
134
           else if (Idx == 0)
135
                ATOMIC_BLOCK(ATOMIC_RESTORESTATE) {
                    sbi(TCCR2A, COM2B0);
sbi(PORTD, 2);
136
137
                    OCR2B = speed;
138
139
                }
           else if (Idx == 1)
140
                ATOMIC_BLOCK(ATOMIC_RESTORESTATE) {
141
                    sbi(TCCR2A, COM2A0);
sbi(PORTD, 7);
142
143
144
                     OCR2A = speed;
145
           else if (Idx == 2)
146
                ATOMIC_BLOCK(ATOMIC_RESTORESTATE) {
147
148
                     sbi(TCCR0A, COM0B0);
                    sbi(PORTD, 4);
OCR0B = speed;
149
150
151
                }
           else if (Idx == 3)
152
153
                ATOMIC_BLOCK(ATOMIC_RESTORESTATE) {
                     sbi(TCCROA, COMOAO);
155
                     if (Config::fader_3_A2)
                         sbi(PORTC, 2);
156
157
                     else
                         sbi(PORTB, 5);
158
                    OCROA = speed;
159
160
                }
161
      template <class Config>
164
      template <uint8_t Idx>
165
      inline void Motors<Config>::setSpeed(int16_t speed) {
           if (speed >= 0)
   forward<Idx>(speed);
166
167
168
           else
                backward<Idx>(-speed);
169
      }
170
```

Reference.hpp

```
#include <avr/pgmspace.h>
#include <stddef.h>
  #include <stdint.h>
  #include <util/atomic.h>
6
  /// Reference signal for testing the controller.
  const uint8_t reference_signal[] PROGMEM = {
     // Ramp up
q
     0, 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20,
10
     21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39,
11
     40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 55, 56, 57, 58,
12
     59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77,
     78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93, 94, 95, 96, 97, 98, 99, 100, 101, 102, 103, 104, 105, 106, 107, 108, 109, 110, 111, 112
13
     113, 114, 115, 116, 117, 118, 119, 120, 121, 122, 123, 124, 125, 126, 127,
     128, 129, 130, 131, 132, 133, 134, 135, 136, 137, 138, 139, 140, 141, 142,
     143, 144, 145, 146, 147, 148, 149, 150, 151, 152, 153, 154, 155, 156, 157,
     158, 159, 160, 161, 162, 163, 164, 165, 166, 167, 168, 169, 170, 171, 172,
19
     173, 174, 175, 176, 177, 178, 179, 180, 181, 182, 183, 184, 185, 186, 187,
     188, 189, 190, 191, 192, 193, 194, 195, 196, 197, 198, 199, 200, 201, 202,
20
21
     203, 204, 205, 206, 207, 208, 209, 210, 211, 212, 213, 214, 215, 216, 217,
     218, 219, 220, 221, 222, 223, 224, 225, 226, 227, 228, 229, 230, 231, 232,
22
     233, 234, 235, 236, 237, 238, 239, 240, 241, 242, 243, 244, 245, 246, 247,
23
     248, 249, 250, 251, 252, 253, 254, 255,
24
25
     // Max
26
     27
     // Ramp down
28
     255, 254, 253, 252, 251, 250, 249, 248, 247, 246, 245, 244, 243, 242, 241,
29
     240, 239, 238, 237, 236, 235, 234, 233, 232, 231, 230, 229, 228, 227, 226,
30
     225, 224, 223, 222, 221, 220, 219, 218, 217, 216, 215, 214, 213, 212, 211,
31
     210, 209, 208, 207, 206, 205, 204, 203, 202, 201, 200, 199, 198, 197,
                                                  196,
32
     195, 194, 193, 192, 191, 190, 189, 188, 187, 186, 185, 184, 183, 182, 181,
33
     180, 179, 178, 177, 176, 175, 174, 173, 172, 171, 170, 169, 168, 167, 166,
     165, 164, 163, 162, 161, 160, 159, 158, 157, 156, 155, 154, 153, 152, 151,
     150, 149, 148, 147, 146, 145, 144, 143, 142, 141, 140, 139, 138, 137, 136,
35
     135, 134, 133, 132, 131, 130, 129, 128, 127,
37
     // Middle
38
     39
     40
41
     127, 127, 127,
42
     // Jump low
43
44
     45
     46
     10, 10, 10, 10, 10, 10, 10, // Jump middle
47
48
49
     50
     51
52
     127, 127,
           127, 127,
53
     // Jump high
54
55
     56
     57
     58
     59
     245, 245, 245, 245,
     // Jump middle
60
     61
62
     63
     66
     67
68
     127, 127, 127, 127, 127, 127, 127, 127,
69
70
     // Ramp down
71
     127, 126, 125, 124, 123, 122, 121, 120, 119, 118, 117, 116, 115, 114, 113,
72
           110, 109, 108, 107, 106, 105, 104, 103, 102, 101, 100, 99, 98, 97,
73
        111,
     96, 95, 94, 93, 92, 91, 90, 89, 88, 87, 86, 85, 84, 83, 82, 81, 80, 79, 78,
74
75
     77, 76, 75, 74, 73, 72, 71, 70, 69, 68, 67, 66, 65, 64, 63, 62, 61, 60,
76
     58, 57, 56, 55, 54, 53, 52, 51, 50, 49, 48, 47, 46, 45, 44, 43, 42, 41, 40,
     39, 38, 37, 36, 35, 34, 33, 32, 31, 30, 29, 28, 27, 26, 25, 24, 23, 22, 21, 20, 19, 18, 17, 16, 15, 14, 13, 12, 11, 10, 9, 8, 7, 6, 5, 4, 3, 2, 1, 0,
77
78
     // Low
79
80
     81
     0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0,
                            0, 0,
                                0, 0, 0, 0, 0, 0, 0, 0,
                        Θ,
             0, 0, 0, 0,
                    Θ, Θ,
                          Θ,
                            Θ,
83
                              Θ,
                                Θ,
                                  0, 0,
                                      Θ,
                                        Θ,
                                          Θ,
84
             0, 0, 0, 0, 0, 0, 0, 0,
                            Θ, Θ,
                                  0, 0,
                                      0, 0,
     Θ,
         0, 0,
                                Θ,
                                          0, 0,
85
     0, 0,
         86
     0, 0,
87
         88
     /// Get the number of elements in the given array.
  template <class T, size_t N>
```

```
94
     constexpr size_t len(const T (&)[N]) {
 95
          return N;
 96
     }
 97
 98
     /// Class that handles the three main references/setpoints:
 99
           1. Sequence programmed in PROGMEM
100
     111
            2. Test sequence for tuning experiments (activated over Serial)
101
     111
            3. Setpoint set by the I<sup>2</sup>C master (for real-world use)
      template <class Config>
102
     class Reference {
103
104
       public:
          /// Called from ISR
105
106
          void setMasterSetpoint(uint16_t setpoint) {
              this->master_setpoint = setpoint;
107
108
109
110
          void startExperiment(float speed_div) {
              this->experiment_speed_div = speed_div;
111
              this->index = 0;
112
              this->seq_idx = 0;
113
114
          }
115
116
          bool experimentInProgress() const { return experiment_speed_div > 0; }
117
118
          uint16_t getNextProgmemSetpoint() {
119
              uint16_t setpoint = pgm_read_byte(reference_signal + index) * 4;
120
              ++seq_idx;
              if (seq_idx >= Config::test_reference_speed_div) {
121
                   seq_idx = 0;
122
123
                   ++index;
124
                   if (index == len(reference_signal)) index = 0;
125
126
              return setpoint;
127
          }
128
129
          uint16_t getNextExperimentSetpoint() {
              constexpr uint16_t RAMPUP = 0xFFFF;
130
              auto rampup = [](uint16_t idx, uint16_t duration) {
   return uint32_t(1024) * idx / duration;
131
132
133
              constexpr uint16_t RAMPDOWN = 0xFFFE;
134
              auto rampdown = [&](uint16_t idx, uint16_t duration) {
   return 1023 - rampup(idx, duration);
135
136
137
              struct TestSeq {
138
                  uint16_t setpoint;
uint16_t duration;
139
140
141
              };
// This array defines the test sequence
              142
143
144
                                                                        {333, 32},
145
                                                          {512, 256},
146
147
148
              static uint8_t seq_index = 0;
149
              static uint16_t index = 0;
uint16_t duration = seqs[seq_index].duration * experiment_speed_div;
150
151
              uint16_t seq_setpoint = seqs[seq_index].setpoint;
152
              uint16_t setpoint;
153
              switch (seq_setpoint) {
                  case RAMPUP: setpoint = rampup(index, duration); break;
                   case RAMPDOWN: setpoint = rampdown(index, duration); break;
155
156
                   default: setpoint = seq_setpoint;
157
              }
158
              ++index:
              if (index == duration) {
159
                   index = 0;
160
161
                   ++seq_index;
                   if (seq_index == len(seqs)) {
162
                       seq_index = 0;
163
164
                       experiment_speed_div = 0;
165
                  }
166
              return setpoint;
167
          }
168
169
          /// Called from main program with interrupts enabled
170
          uint16_t getNextSetpoint() {
171
172
              uint16_t setpoint;
173
              if (Config::serial_control && experiment_speed_div > 0)
174
                   // from the tuning experiment reference
175
                   setpoint = getNextExperimentSetpoint();
176
              else if (Config::test_reference)
                  \ensuremath{\text{//}} from the test reference
177
178
                   setpoint = getNextProgmemSetpoint();
179
180
                   // from the I<sup>2</sup>C master
                   ATOMIC_BLOCK(ATOMIC_FORCEON) { setpoint = master_setpoint; }
181
182
              return setpoint;
183
          }
184
       private:
185
          uint16_t index = 0;
186
187
          uint8_t seq_idx = 0;
188
          float experiment speed div = 0:
```

```
volatile uint16_t master_setpoint = 0;
190 };
```

Registers.hpp

```
#pragma once
    #include <avr/io.h>
3
    #include <avr/sfr_defs.h>
    #include <util/delay.h> // F_CPU
    // ----- Utils ----- //
8
q
    #ifndef ARDUINO // Ensures that my IDE sees the correct frequency
    #undef F CPU
10
    #define F_CPU 16000000UL
11
12
    #endif
13
    #ifndef sbi
14
    /// Set bit in register.
    template <class R>
17
    inline void sbi(R &reg, uint8_t bit) {
       reg |= (1u << bit);
19
    #define sbi sbi
20
21
    #endif
    #ifndef cbi
22
    /// Clear bit in register.
23
    template <class R>
24
25
    inline void cbi(R &reg, uint8_t bit) {
26
        reg &= ~(1u << bit);
27
    #define cbi cbi
28
29
    #endif
    /// Write bit in register.
template <class R>
30
31
    inline void wbi(R &reg, uint8_t bit, bool value) {
32
33
        value ? sbi(reg, bit) : cbi(reg, bit);
34
35
    // ----- Timer0 ----- //
36
37
38
    /// Timer 0 clock select (Table 14-9).
39
    enum class TimerOPrescaler : uint8 t {
        None = 0b000,
40
        S1 = 0b001,
41
        S8 = 0b010,
42
43
        S64 = 0b011
44
        S256 = 0b100
45
        S1024 = 0b101
46
        ExtFall = 0b110,
47
        ExtRise = 0b111,
48
        Invalid = 0 \times FF,
49
    };
50
    /// Timer 0 waveform generation mode (Table 14-8).
51
    enum class TimerOWGMode : uint8_t {
52
        Normal = 0b000,
53
54
        PWM = 0b001,
55
        CTC = 0b010,
56
        FastPWM = 0b011,
57
        PWM_OCRA = 0b101
        FastPWM_OCRA = 0b111,
58
59
   };
60
   // Convert the prescaler factor to the correct bit pattern to write to the
61
62
    // TCCROB register (Table 14-9).
    constexpr inline TimerOPrescaler factorToTimerOPrescaler(uint16_t factor) {
        return factor == 1
                                ? Timer0Prescaler::S1
               : factor == 8 ? TimeroPrescaler::S8 : factor == 64 ? TimeroPrescaler::S64
66
               : factor == 256 ? TimerOPrescaler::S256
67
               : factor == 1024 ? TimerOPrescaler::S1024
68
                                : Timer@Prescaler::Invalid;
69
70
    }
    /// Set the clock source/prescaler of Timer0 (Table 14-9).
73
    inline void setTimer0Prescaler(Timer0Prescaler ps) {
74
        if (ps == Timer@Prescaler::Invalid)
75
            return;
        wbi(TCCR0B, CS02, static_cast<uint8_t>(ps) & (1u << 2));</pre>
76
        wbi(TCCR0B, CS01, static_cast<uint8_t>(ps) & (1u << 1));
wbi(TCCR0B, CS00, static_cast<uint8_t>(ps) & (1u << 0));</pre>
77
78
79
    }
80
81
    /// Set the wavefrom generation mode of Timer0 (Table 14-8).
    inline void setTimerOWGMode(TimerOWGMode mode) {
83
        wbi(TCCR0B, WGM02, static_cast<uint8_t>(mode) & (1u << 2));</pre>
84
        wbi(TCCR0A, WGM01, static_cast<uint8_t>(mode) & (1u << 1));</pre>
85
        wbi(TCCR0A, WGM00, static_cast<uint8_t>(mode) & (1u << 0));</pre>
86
    }
87
    // ----- Timer2 ----- //
88
    /// Timer 0 clock select (Table 17-9).
    enum class Timer2Prescaler : uint8_t {
92
        None = 0b000,
93
        S1 = 0b001,
```

```
94
          S8 = 0b010,
 95
          S32 = 0b011,
          S64 = 0b100,
 96
 97
          S128 = 0b101
 98
          S256 = 0b110,
 99
          S1024 = 0b111
100
          Invalid = 0xFF,
101
     };
102
      /// Timer 0 waveform generation mode (Table 17-8).
103
      enum class Timer2WGMode : uint8_t {
104
          Normal = 0b000,
105
          PWM = 0b001,
106
          CTC = 0b010,
107
108
          FastPWM = 0b011,
          PWM OCRA = 0b101,
109
110
          FastPWM OCRA = 0b111,
111
     };
112
     // Convert the prescaler factor to the correct bit pattern to write to the
113
      // TCCROB register (Table 17-9).
114
      constexpr inline Timer2Prescaler factorToTimer2Prescaler(uint16_t factor) {
115
116
          return factor == 1      ? Timer2Prescaler::S1
                                    ? Timer2Prescaler::S8
117
                 : factor == 8
                  : factor == 32 ? Timer2Prescaler::S32
: factor == 64 ? Timer2Prescaler::S64
118
119
                  : factor == 128 ? Timer2Prescaler::S128
: factor == 256 ? Timer2Prescaler::S256
120
121
                  : factor == 1024 ? Timer2Prescaler::S1024
122
                                    : Timer2Prescaler::Invalid;
123
124
     }
125
      /// Set the clock source/prescaler of Timer2 (Table 17-9).
      inline void setTimer2Prescaler(Timer2Prescaler ps) {
127
128
         if (ps == Timer2Prescaler::Invalid)
              return;
129
          wbi(TCCR2B, CS22, static_cast<uint8_t>(ps) & (1u << 2));
wbi(TCCR2B, CS21, static_cast<uint8_t>(ps) & (1u << 1));
wbi(TCCR2B, CS20, static_cast<uint8_t>(ps) & (1u << 0));</pre>
130
131
132
133
     }
134
135
      /// Set the wavefrom generation mode of Timer2 (Table 17-8).
136
      inline void setTimer2WGMode(Timer2WGMode mode) {
137
          wbi(TCCR2B, WGM22, static_cast<uint8_t>(mode) & (1u << 2));</pre>
          wbi(TCCR2A, WGM21, static_cast<uint8_t>(mode) & (1u << 1));
138
          wbi(TCCR2A, WGM20, static_cast<uint8_t>(mode) & (1u << 0));</pre>
139
     }
140
141
     // ------//
142
143
144
      /// ADC prescaler select (Table 23-5).
145
      enum class ADCPrescaler : uint8_t {
146
          S2 = 0b000,
147
          S2 2 = 0b001
148
          S4 = 0b010,
149
          S8 = 0h011.
          S16 = 0b100
150
          S32 = 0b101,
151
          S64 = 0b110,
152
153
          S128 = 0b111,
          Invalid = 0xFF,
155
     };
156
     // Convert the prescaler factor to the correct bit pattern to write to the
157
158
      // ADCSRA register (Table 23-5).
     constexpr inline ADCPrescaler factorToADCPrescaler(uint8_t factor) {
159
          return factor == 2
                                  ? ADCPrescaler::S2_2
? ADCPrescaler::S4
160
                 : factor == 4
161
                  : factor == 8 ? ADCPrescaler::S8
                  : factor == 16 ? ADCPrescaler::S16
164
                  : factor == 32 ? ADCPrescaler::S32
165
                  : factor == 64 ? ADCPrescaler::S64
166
                  : factor == 128 ? ADCPrescaler::S128
                                   : ADCPrescaler::Invalid;
167
168
169
      /// Set the prescaler of the ADC (Table 23-5).
170
     inline void setADCPrescaler(ADCPrescaler ps) {
171
         if (ps == ADCPrescaler::Invalid)
172
               return;
173
          wbi(ADCSRA, ADPS2, static_cast<uint8_t>(ps) & (1u << 2));</pre>
174
175
          wbi(ADCSRA, ADPS1, static_cast<uint8_t>(ps) & (1u << 1));</pre>
          wbi(ADCSRA, ADPS0, static_cast<uint8_t>(ps) & (1u << 0));</pre>
176
     }
177
```

SerialSLIP.hpp

```
#include <Arduino.h>
 2
    namespace SLIP_Constants {
 3
    const static uint8_t END = 0300;
    const static uint8_t ESC = 0333;
    const static uint8_t ESC_END = 0334;
    const static uint8_t ESC_ESC = 0335;
 8
    } // namespace SLIP_Constants
 q
    /// Parses SLIP packets: https://datatracker.ietf.org/doc/html/rfc1055
10
    class SLIPParser {
11
12
      public:
         template <class Callback>
13
         size_t parse(uint8_t c, Callback callback);
14
15
17
             size = 0;
18
             escape = false;
19
20
      private:
21
         size_t size = 0;
22
         bool escape = false;
23
24
    };
25
26
     template <class Callback>
27
     size_t SLIPParser::parse(uint8_t c, Callback callback) {
28
         using namespace SLIP_Constants;
29
         * handle bytestuffing if necessary
30
31
32
         switch (c) {
33
              * if it's an END character then we're done with
34
              * the packet
35
37
             case END: {
38
                  * a minor optimization: if there is no
39
                  * data in the packet, ignore it. This is
40
                   * meant to avoid bothering IP with all
41
                  * the empty packets generated by the

* duplicate END characters which are in
42
43
44
                  * turn sent to try to detect line noise.
45
46
                  auto packetLen = size;
47
                  reset();
                 if (packetLen) return packetLen;
48
             } break;
49
50
51
              ^{\star} if it's the same code as an ESC character, wait
52
              * and get another character and then figure out
53
54
              * what to store in the packet based on that.
55
56
             case ESC: {
                 escape = true;
57
             } break;
58
59
60
              * here we fall into the default handler and let
61
62
              * it store the character for us
             default: {
64
65
                 if (escape) {
66
                       * if "c" is not one of these two, then we
* have a protocol violation. The best bet
67
68
                         seems to be to leave the byte alone and just stuff it into the packet
69
70
71
72
                      switch (c) {
73
                          case ESC_END: c = END; break;
74
                          case ESC_ESC: c = ESC; break;
75
                          default: break; // LCOV_EXCL_LINE (protocol violation)
76
77
                      escape = false;
78
                 callback(c, size);
79
80
                  ++size;
81
             }
83
         return 0;
84
    }
85
    /// Sends SLIP packets: https://datatracker.ietf.org/doc/html/rfc1055
86
    class SLIPSender {
87
      public:
88
89
         SLIPSender(Stream &stream) : stream(stream) {}
         size_t beginPacket() { return stream.write(SLIP_Constants::END); }
91
92
         size_t endPacket() { return stream.write(SLIP_Constants::END); }
93
```

```
size_t write(const uint8_t *data, size_t len);
size_t writePacket(const uint8_t *data, size_t len) {
 94
 95
 96
              size_t sent = 0;
 97
               sent += beginPacket();
 98
              sent += write(data, len);
 99
              sent += endPacket();
100
              return sent;
          }
101
102
       private:
103
104
          Stream &stream;
105
     };
106
107
      inline size_t SLIPSender::write(const uint8_t *data, size_t len) {
108
          // https://datatracker.ietf.org/doc/html/rfc1055
          using namespace SLIP_Constants;
109
110
          size_t sent = 0;
111
           * for each byte in the packet, send the appropriate character
112
113
          * sequence
114
115
          while (len--) {
116
               switch (*data) {
                  /*

* if it's the same code as an END character, we send a
117
118
                   * special two character code so as not to make the
119
                   * receiver think we sent an END
120
121
122
                   case END:
                       sent += stream.write(ESC);
123
124
                       sent += stream.write(ESC_END);
125
                       break;
                   /*
 * if it's the same code as an ESC character,
127
128
                   * we send a special two character code so as not
129
                    ^{\star} to make the receiver think we sent an ESC
130
131
132
                   case ESC:
133
                       sent += stream.write(ESC);
134
                       sent += stream.write(ESC_ESC);
135
136
                   ^{\prime*} ^{\star} otherwise, we just send the character
137
138
139
                   default: sent += stream.write(*data);
140
141
142
              data++;
143
144
          return sent;
145
     }
```

SMA.hpp

```
#pragma once
    #include <Arduino_Helpers.h>
3
    #include <AH/Math/Divide.hpp>
    #include <AH/STL/algorithm> // std::fill
6
    #include <AH/STL/cstdint>
8
q
     * @brief Simple Moving Average filter.
10
11
       Returns the average of the N most recent input values.
12
13
14
15
       y[n] = \frac{1}{N} \sum_{i=0}^{N-1} x[n-i]
17
18
       @see
                https://tttapa.github.io/Pages/Mathematics/Systems-and-Control-Theory/Digital-
    filters/Simple%20Moving%20Average/Simple-Moving-Average.html
19
       @tparam N
20
                The number of samples to average.
21
22
       @tparam input t
                The type of the input (and output) of the filter.
23
24
       @tparam sum_t
25
                The type to use for the accumulator, must be large enough to fit
26
                N times the maximum input value.
27
    template <uint8_t N, class input_t = uint16_t, class sum_t = uint32_t>
28
    class SMA {
29
30
      public:
        /// Default constructor (initial state is initialized to all zeros).
31
32
        SMA() = default;
33
34
        /// Constructor (initial state is initialized to given value).
        ///
/// @param initialValue
35
36
                    111
37
        ///
38
        ///
39
        SMA(input\_t\ initialValue)\ :\ sum(N\ *\ (sum\_t)initialValue)\ \{
40
            std::fill(std::begin(previousInputs), std::end(previousInputs),
41
42
                      initialValue);
43
44
45
        /// Update the internal state with the new input @f$ x[n] @f$ and return the
46
        /// new output @f$ y[n] @f$.
        111
47
        /// @param input
48
                    The new input @f$ \times [n] @f$.
        ///
49
        /// @return The new output @f$ y[n] @f$.
input_t operator()(input_t input) {
50
51
52
            sum -= previousInputs[index];
53
            sum += input;
54
            previousInputs[index] = input;
55
            if (++index == N) index = 0;
56
            return AH::round_div<N>(sum);
        }
57
58
59
      private:
        uint8_t index = 0;
60
61
        input_t previousInputs[N] {};
        sum_t sum = 0;
    };
```