ETSITS 151 010-4 V4.4.0 (2007-03)

Technical Specification

Digital cellular telecommunications system (Phase 2+);
Mobile Station (MS) conformance specification;
Part 4: Subscriber Identity Module (SIM)
application toolkit conformance test specification
(3GPP TS 51.010-4 version 4.4.0 Release 4)



Reference RTS/TSGC-0651010-4v440 Keywords GSM

ETSI

650 Route des Lucioles F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C Association à but non lucratif enregistrée à la Sous-Préfecture de Grasse (06) N° 7803/88

Important notice

Individual copies of the present document can be downloaded from: <u>http://www.etsi.org</u>

The present document may be made available in more than one electronic version or in print. In any case of existing or perceived difference in contents between such versions, the reference version is the Portable Document Format (PDF). In case of dispute, the reference shall be the printing on ETSI printers of the PDF version kept on a specific network drive within ETSI Secretariat.

Users of the present document should be aware that the document may be subject to revision or change of status.

Information on the current status of this and other ETSI documents is available at

http://portal.etsi.org/tb/status/status.asp

If you find errors in the present document, please send your comment to one of the following services: http://portal.etsi.org/chaircor/ETSI_support.asp

Copyright Notification

No part may be reproduced except as authorized by written permission. The copyright and the foregoing restriction extend to reproduction in all media.

© European Telecommunications Standards Institute 2007.
All rights reserved.

DECTTM, **PLUGTESTS**TM and **UMTS**TM are Trade Marks of ETSI registered for the benefit of its Members. **TIPHON**TM and the **TIPHON logo** are Trade Marks currently being registered by ETSI for the benefit of its Members. **3GPP**TM is a Trade Mark of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners.

Intellectual Property Rights

IPRs essential or potentially essential to the present document may have been declared to ETSI. The information pertaining to these essential IPRs, if any, is publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: "Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards", which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (http://www.etsi.org/legal/home.htm).

Pursuant to the ETSI IPR Policy, no investigation, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Foreword

This Technical Specification (TS) has been produced by the ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities, UMTS identities or GSM identities. These should be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between GSM, UMTS, 3GPP and ETSI identities can be found under http://webapp.etsi.org/key/queryform.asp.

Contents

| Intelle | ectual Property Rights | 2 |
|---------|--|----|
| Forew | vord | 2 |
| Forew | vord | 9 |
| 1 | Scope | 10 |
| 2 | References | 10 |
| 3 | Definitions and abbreviations | 12 |
| 3.1 | Mobile station definition and configurations | |
| 3.2 | Applicability | |
| 3.2.1 | Applicability of the present document | |
| 3.2.2 | Applicability of the individual tests | |
| 3.2.3 | Applicability to terminal equipment | 12 |
| 3.2.4 | Definitions | 12 |
| 3.2.4.1 | Format of the table of optional features | 12 |
| 3.2.4.2 | | |
| 3.2.4.3 | Status and notations | 13 |
| 3.3 | Table of optional features | |
| 3.4 | Applicability table | |
| 3.5 | Conventions for mathematical notations | |
| 3.6 | Conventions on electrical terms | |
| 3.7 | Terms on test conditions | 33 |
| 4 | Test equipment | 33 |
| 5 | Testing methodology in general | 33 |
| 5.1 | Testing of optional functions and procedures | |
| 5.2 | Test interfaces and facilities | |
| 5.3 | Different protocol layers | |
| 5.4 | Information to be provided by the apparatus supplier | |
| 5.5 | Definitions of transmit and receive times | |
| 6 | Reference test methods | |
| 7 | Implicit testing. | |
| | Measurement uncertainty | |
| 8 | • | |
| 9 | Format of tests | 34 |
| 10 | Generic call set up procedures. | 36 |
| 11 | - 26 Not used | 37 |
| 27 | Testing of the SIM/ME interface | 37 |
| | 27.21 Void | |
| 27.22 | SIM Application Toolkit | |
| 27.22. | ** | |
| 27.22. | • • | |
| 27.22. | | |
| | (Profile Download) | 43 |
| 27.22. | | |
| 27.22. | | |
| 27.22. | | |
| 27.22. | | |
| 27.22. | 1.4.1 Initial conditions | 43 |
| 27.22. | | |
| 27.22. | 1 | |
| 27.22. | 2 Contents of the TERMINAL PROFILE command | 45 |

| 27.22.2.1 | Definition and applicability | 45 |
|----------------------------|---|----------------|
| 27.22.2.2 | Conformance requirement | |
| 27.22.2.3 | Test purpose | 46 |
| 27.22.2.4 | Method of test | 46 |
| 27.22.2.4.1 | Initial conditions | 46 |
| 27.22.1.4.2 | Procedure | 46 |
| 27.22.2.5 | Test requirement | 46 |
| 27.22.3 | Servicing of proactive SIM commands | 46 |
| 27.22.3.1 | Definition and applicability | 46 |
| 27.22.3.2 | Conformance requirement | 46 |
| 27.22.3.3 | Test purpose | 46 |
| 27.22.3.4 | Method of test | 47 |
| 27.22.3.4.1 | Initial conditions | 47 |
| 27.22.3.4.2 | Procedure | 47 |
| 27.22.3.5 | Test requirement | 47 |
| 27.22.4 | Proactive SIM commands | 47 |
| 27.22.4.1 | DISPLAY TEXT | |
| 27.22.4.1.1 | DISPLAY TEXT (Normal) | 47 |
| 27.22.4.1.2 | DISPLAY TEXT (Support of "No response from user") | 5 6 |
| 27.22.4.1.3 | DISPLAY TEXT (Display of extension text) | 57 |
| 27.22.4.1.4 | DISPLAY TEXT (Sustained text) | |
| 27.22.4.1.5 | DISPLAY TEXT (Display of icons) | |
| 27.22.4.1.6 | DISPLAY TEXT (UCS2 display supported) | |
| 27.22.4.2 | GET INKEY | |
| 27.22.4.2.1 | GET INKEY(normal) | |
| 27.22.4.2.2 | GET INKEY (No response from User) | |
| 27.22.4.2.3 | GET INKEY (UCS2 format display) | |
| 27.22.4.2.4 | GET INKEY (UCS2 format of entry) | |
| 27.22.4.2.5 | GET INKEY ("Yes/No" Response) | |
| 27.22.4.2.6 | GET INKEY (display of Icon) | |
| 27.22.4.2.7 | GET INKEY (Help Information) | |
| 27.22.4.3. | GET INPUT | |
| 27.22.4.3.1 | GET INPUT (normal) | |
| 27.22.4.3.2 | GET INPUT (No response from User) | |
| 27.22.4.3.3 | GET INPUT (UCS2 format display) | |
| 27.22.4.3.4 | GET INPUT (UCS2 format of entry) | |
| 27.22.4.3.5 | GET INPUT (default text) | |
| 27.22.4.3.6 | GET INPUT (display of Icon) | |
| 27.22.4.3.7 | GET INPUT (Help Information) | |
| 27.22.4.4 | MORE TIME | |
| 27.22.4.4.1 | Definition and applicability | |
| 27.22.4.4.2 | Conformance requirement | |
| 27.22.4.4.3 | Test purpose | |
| 27.22.4.4.4 27.22.4.4.5 | Method of test | |
| 27.22.4.4.5 | PLAY TONE | |
| 27.22.4.5 | Definition and applicability | |
| 27.22.4.5.1 | Conformance requirement | |
| 27.22.4.5.2 | Test purpose | |
| 27.22.4.5.4 | Method of test | |
| 27.22.4.6 | POLL INTERVAL | |
| 27.22.4.6.1 | Definition and applicability | |
| 27.22.4.6.1 | Conformance requirement | |
| 27.22.4.6.3 | Test purpose | |
| 27.22.4.6.4 | Method of test | |
| 27.22.4.6.5 | Test requirement | |
| 27.22.4.7 | REFRESH | |
| 27.22.4.7.1 | REFRESH (normal) | |
| 27.22.4.7.2 | REFRESH (IMSI changing procedure) | |
| 27.22.4.8 | | |
| | | 157 |
| 27.22.4.8.1 | SET UP MENU and ENVELOPE MENU SELECTION | |

| 27.22.4.8.3 | SET UP MENU (next action support) and ENVELOPE MENU SELECTION | 170 |
|----------------------------|--|-----|
| 27.22.4.8.4 | SET UP MENU (display of icons) and ENVELOPE MENU SELECTION | |
| 27.22.4.8.5 | SET UP MENU (soft keys support) and ENVELOPE MENU SELECTION | |
| 27.22.4.9 | SELECT ITEM | |
| 27.22.4.9.1 | SELECT ITEM (mandatory features for ME supporting SELECT ITEM) | |
| 27.22.4.9.2 | SELECT ITEM (next action support) | |
| 27.22.4.9.3 | SELECT ITEM (default item support) | |
| 27.22.4.9.4 | SELECT ITEM (help request support) | |
| 27.22.4.9.5 | SELECT ITEM (icons support) | |
| 27.22.4.9.6 | SELECT ITEM (presentation style) | |
| 27.22.4.9.7 | SELECT ITEM (soft keys support) | |
| 27.22.4.9.8 | SELECT ITEM (Support of "No response from user") | |
| 27.22.4.10 | SEND SHORT MESSAGE | |
| 27.22.4.10.1 | SEND SHORT MESSAGE (normal) | |
| 27.22.4.10.2 | SEND SHORT MESSAGE (UCS2 support) | |
| 27.22.4.10.3 | SEND SHORT MESSAGE (icon support) | |
| 27.22.4.11 | SEND SS | |
| 27.22.4.11.1 | SEND SS (normal) | |
| 27.22.4.11.2 | SEND SS (Icon support) | |
| 27.22.4.11.3 | SEND SS (UCS2 support) | |
| 27.22.4.12 | SEND USSD | |
| 27.22.4.12.1 | SEND USSD (normal) | |
| 27.22.4.12.2 | SEND USSD (Icon support) | |
| 27.22.4.12.3 | SEND USSD (UCS2 support) | |
| 27.22.4.13 | SET UP CALL | |
| 27.22.4.13.1 | SET UP CALL (normal) | |
| 27.22.4.13.2 | SET UP CALL (second alpha identifier) | |
| 27.22.4.13.3 | SET UP CALL (display of icons) | |
| 27.22.4.14 | POLLING OFF | |
| 27.22.4.14.1 | Definition and applicability | |
| 27.22.4.14.2 | Conformance requirement | |
| 27.22.4.14.3 | Test purpose | |
| 27.22.4.14.4 | Method of test | |
| 27.22.4.14.5 27.22.4.15 | Test requirementPROVIDE LOCAL INFORMATION | |
| 27.22.4.15 | Definition and applicability | |
| 27.22.4.15.1 | Conformance requirement | |
| 27.22.4.15.2 | Test purpose | |
| 27.22.4.15.4 | Method of tests | |
| 27.22.4.15.5 | Test requirement. | |
| 27.22.4.16 | SET UP EVENT LIST | |
| 27.22.4.16.1 | SET UP EVENT LIST (normal) | |
| 27.22.4.17 | PERFORM CARD APDU | |
| 27.22.4.17.1 | PERFORM CARD APDU (normal) | |
| 27.22.4.17.2 | PERFORM CARD APDU (detachable card reader) | |
| 27.22.4.18 | POWER OFF CARD | |
| 27.22.4.18.1 | POWER OFF CARD (normal) | |
| 27.22.4.18.2 | POWER OFF CARD (detachable card reader) | |
| 27.22.4.19 | POWER ON CARD | 336 |
| 27.22.4.19.1 | POWER ON CARD (normal) | 336 |
| 27.22.4.19.2 | POWER ON CARD (detachable card reader) | 340 |
| 27.22.4.20 | GET READER STATUS | |
| 27.22.4.20.1 | GET READER STATUS (normal) | |
| 27.22.4.20.2 | GET CARD READER STATUS (detachable card reader) | |
| 27.22.4.21 | TIMER MANAGEMENT and ENVELOPE TIMER EXPIRATION | |
| 27.22.4.21.1 | TIMER MANAGEMENT (normal) | |
| 27.22.4.21.2 | ENVELOPE TIMER EXPIRATION (normal) | |
| 27.22.4.22 | SET UP IDLE MODE TEXT | |
| 27.22.4.22.1 | SET UP IDLE MODE TEXT (normal) | |
| 27.22.4.22.2 | SET UP IDLE MODE TEXT (Icon support) | |
| 27.22.4.22.3 | SET UP IDLE MODE TEXT (UCS2 support) | |
| 27.22.4.23 | RUN AT COMMAND | 411 |

| 27.22.4.23.1 | RUN AT COMMAND (normal) | 411 |
|--------------|---|-----|
| 27.22.4.23.2 | RUN AT COMMAND (Icon support) | |
| 27.22.4.24 | SEND DTMF | |
| 27.22.4.24.1 | SEND DTMF (Normal) | |
| 27.22.4.24.2 | SEND DTMF (Display of icons) | |
| 27.22.4.24.3 | SEND DTMF (UCS2 support) | |
| 27.22.4.25 | LANGUAGE NOTIFICATION | |
| 27.22.4.25.1 | Definition and applicability | |
| 27.22.4.25.1 | Conformance Requirement | |
| | Test purpose | |
| 27.22.4.25.3 | * * | |
| 27.22.4.25.4 | Method of Test | |
| 27.22.4.25.5 | Test requirement | |
| 27.22.4.26 | LAUNCH BROWSER | |
| 27.22.4.26.1 | LAUNCH BROWSER (No session already launched) | |
| 27.22.4.26.2 | LAUNCH BROWSER (Interaction with current session) | |
| 27.22.4.26.3 | LAUNCH BROWSER (UCS2 support) | |
| 27.22.4.26.4 | LAUNCH BROWSER (icons support) | |
| 27.22.4.27 | OPEN CHANNEL | |
| 27.22.4.27.1 | Void | |
| 27.22.4.27.2 | Open Channel (related to GPRS) | |
| 27.22.4.28 | CLOSE CHANNEL | 467 |
| 27.22.4.28.1 | Definition and applicability | 467 |
| 27.22.4.28.2 | Conformance requirements | 467 |
| 27.22.4.28.3 | Test purpose | 467 |
| 27.22.4.28.4 | Method of Test | 467 |
| 27.22.4.29 | RECEIVE DATA | 473 |
| 27.22.4.29.1 | Definition and applicability | 473 |
| 27.22.4.29.2 | Conformance requirements | |
| 27.22.4.29.3 | Test purpose | |
| 27.22.4.29.4 | Method of test | |
| 27.22.4.30 | SEND DATA | |
| 27.22.4.30.1 | Definition and applicability | |
| 27.22.4.30.2 | Conformance requirements | |
| 27.22.4.30.3 | Test purpose | |
| 27.22.4.30.4 | Method of test | |
| 27.22.4.31 | GET CHANNEL STATUS | |
| 27.22.4.31.1 | Definition and applicability | |
| 27.22.4.31.2 | Conformance requirements | |
| 27.22.4.31.3 | Test purpose | |
| 27.22.4.31.4 | Method of test | |
| 27.22.4.31.4 | Data Download to SIM | |
| 27.22.5.1 | SMS-PP Data Download | |
| | | |
| 27.22.5.1.1 | Definition and applicability | |
| 27.22.5.1.2 | Conformance requirement | |
| 27.22.5.1.3 | Test purpose | |
| 27.22.5.1.4 | Method of Test | |
| 27.22.5.1.5 | Test requirement | |
| 27.22.5.2 | SMS-CB Data Download | |
| 27.22.5.2.1 | Definition and applicability | |
| 27.22.5.2.2 | Conformance requirement | |
| 27.22.5.2.3 | Test purpose | |
| 27.22.5.2.4 | Method of Test | |
| 27.22.5.2.5 | Test requirement | 515 |
| 27.22.6 | CALL CONTROL BY SIM | |
| 27.22.6.1 | Procedure for Mobile Originated calls | |
| 27.22.6.1.1 | Definition and applicability | 515 |
| 27.22.6.1.2 | Conformance requirement | 515 |
| 27.22.6.1.3 | Test purpose | 516 |
| 27.22.6.1.4 | Method of tests | 516 |
| 27.22.6.1.5 | Test requirement | 539 |
| 27.22.6.2 | Procedure for Supplementary (SS) Services | |
| 27.22.6.2.1 | Definition and applicability | |

| 27.22.6.2.2 | Conformance requirement | 539 |
|--------------|--|-----|
| 27.22.6.2.3 | Test purpose | 539 |
| 27.22.6.2.4 | Method of tests | 539 |
| 27.22.6.2.5 | Test requirement | 546 |
| 27.22.6.3 | Interaction with Fixed Dialling Number (FDN) | 546 |
| 27.22.6.3.1 | Definition and applicability | 546 |
| 27.22.6.3.2 | Conformance requirement | 546 |
| 27.22.6.3.3 | Test purpose | 546 |
| 27.22.6.3.4 | Method of tests | 546 |
| 27.22.6.3.5 | Test requirement | 553 |
| 27.22.6.4 | Support of Barred Dialling Number (BDN) service | 553 |
| 27.22.6.4.1 | Definition and applicability | |
| 27.22.6.4.2 | Conformance requirement | |
| 27.22.6.4.3 | Test purpose | |
| 27.22.6.4.4 | Method of tests | |
| 27.22.6.4.5 | Test requirement | |
| 27.22.7 | EVENT DOWNLOAD | |
| 27.22.7.1 | MT Call Event | |
| 27.22.7.1.1 | MT Call Event (normal) | |
| 27.22.7.2 | Call Connected Event | |
| 27.22.7.2.1 | Call Connected Event (MT and MO call) | |
| 27.22.7.2.2 | Call Connected Event (ME supporting SET UP CALL) | |
| 27.22.7.3 | Call Disconnected Event | |
| 27.22.7.3.1 | Call Disconnected Event | |
| 27.22.7.4 | Location Status Event | |
| 27.22.7.4.1 | Location Status Event (normal) | |
| 27.22.7.5 | User Activity Event | |
| 27.22.7.5.1 | User Activity Event (normal) | |
| 27.22.7.6 | Idle screen available event | |
| 27.22.7.6.1 | Idle Screen Available (normal) | |
| 27.22.7.7 | Card reader status event | |
| 27.22.7.7 | Card Reader Status (normal) | |
| 27.22.7.7.2 | Card Reader Status (detachable card reader) | |
| 27.22.7.8 | Language selection event | |
| 27.22.7.8.1 | Language selection event (normal) | |
| 27.22.7.9 | Browser termination event | |
| 27.22.7.9.1 | Browser termination (normal) | |
| 27.22.7.10 | Data available event | |
| 27.22.7.10 | Definition and applicability | |
| 27.22.7.10.1 | Conformance requirements | |
| 27.22.7.10.2 | Test purpose | |
| 27.22.7.10.3 | Method of test. | |
| 27.22.7.10.4 | Channel Status event | |
| 27.22.7.11 | Definition and applicability | |
| 27.22.7.11.1 | Conformance requirements. | |
| 27.22.7.11.2 | Test purpose | |
| 27.22.7.11.3 | Method of test. | |
| 27.22.7.11.4 | MO SHORT MESSAGE CONTROL BY SIM | |
| 27.22.8.1 | Definition and applicability | |
| 27.22.8.2 | Conformance requirement | |
| 27.22.8.3 | Test purpose | |
| 27.22.8.4 | Method of tests | |
| 27.22.8.4.1 | Initial conditions | |
| 27.22.8.4.1 | Procedure Procedure | |
| 27.22.8.4.2 | Test requirement | |
| Annex A: | Void | |
| | | |
| Annex B: | Void | |
| Annex C: | Void | 611 |

| Annex D (normative): | Details of Test-SIM (TestSIM) | 612 |
|------------------------|-------------------------------------|-----|
| Annex E (normative): | Details of terminal profile support | 614 |
| Annex F (informative): | Change History | 619 |
| History | | 624 |

Foreword

This Technical Specification has been produced by the 3rd Generation Partnership Project (3GPP).

The contents of the present document are subject to continuing work within the TSG and may change following formal TSG approval. Should the TSG modify the contents of the present document, it will be re-released by the TSG with an identifying change of release date and an increase in version number as follows:

Version x.y.z

where:

- x the first digit:
 - 1 presented to TSG for information;
 - 2 presented to TSG for approval;
 - 3 or greater indicates TSG approved document under change control.
- y the second digit is incremented for all changes of substance, i.e. technical enhancements, corrections, updates, etc.
- z the third digit is incremented when editorial only changes have been incorporated in the document.

1 Scope

The present document describes the technical characteristics and methods of test for testing the SIM Application Toolkit implemented in Mobile Stations (MS) for the Pan European digital cellular communications system and Personal Communication Systems (PCS) operating in the 450 MHz, 480 MHz, 700 MHz, 750 MHz, 850 MHz, 900 MHz, 1 800 MHz and 1 900 MHz frequency band (GSM 400, GSM 700, GSM 750, GSM 850, GSM 900, DCS 1 800 and PCS 1 900) within the European digital cellular telecommunications system, in compliance with the relevant requirements, and in accordance with the relevant guidance given in ISO/IEC 9646-7 [19] and ETS 300 406 [20].

The present document is valid for MS implemented according to GSM Phase2+ R96, or R97, or R98, or R99.

The present document covers the minimum characteristics considered necessary in order to provide sufficient performance for mobile equipment and to prevent interference to other services or to other users, and to the PLMNs.

It does not necessarily include all the characteristics which may be required by a user or subscriber, nor does it necessarily represent the optimum performance achievable.

The present document is part of the GSM-series of technical specifications. The present document neither replaces any of the other GSM technical specifications or GSM related ETSs or ENs, nor is it created to provide full understanding of (or parts of) the GSM 400, GSM 700, GSM 850, GSM 900, DCS1800 and PCS1900 systems . The present document lists the requirements, and provides the methods of test for testing the SIM Application Toolkit implemented in a MS for conformance to the GSM standard.

For a full description of the system, reference should be made to all the GSM technical specifications or GSM related ETSs or ENs. Clause 2 provides a complete list of the GSM technical specifications, GSM related ETSs, ENs, and ETRs, on which this conformance test specifications is based.

If there is a difference between this present conformance document, and any other GSM technical specification or GSM related ETS or EN, or 3GPP TS, then the other GSM technical specification or GSM related ETS or EN or 3GPP TS shall prevail.

2 References

The following documents contain provisions which, through reference in this text, constitute provisions of the present

- References are either specific (identified by date of publication, edition number, version number, etc.) or non-specific.
- For a specific reference, subsequent revisions do not apply.
- For a non-specific reference, the latest version applies. In the case of a reference to a 3GPP document (including a GSM document), a non-specific reference implicitly refers to the latest version of that document *in the relevant Release*.
 - For a GSM Phase 2+ Release 1999 MS, references to GSM documents are to version 8.x.y (for 01.-series to 12.-series) or (3.x.y for 21.-series to 35.-series), when available.
 - For a GSM Phase 2+ Release 1998 MS, references to GSM documents are to version 7.x.y, when available.
 - For a GSM Phase 2+ Release 1997 MS, references to GSM documents are to version 6.x.y, when available.
 - For a GSM Phase 2+ Release 1996 MS, references to GSM documents are to version 5.x.y,. when available.

NOTE: References to 3GPP Technical Specifications and Technical Reports throughout the present document shall be interpreted according to the Release shown in the formal reference in this clause, based upon the Release of the implementation under test.

| EXAMPLE: | References for a R99 MS shall be interpreted as: |
|----------|---|
| | [1] 3GPP TS 21.905 R99 |
| | [2] 3GPP TS 22.001 R99 |
| | etc. |
| [1] | 3GPP TS 01.04 (R96 to R98): "Abbreviations and acronyms". 3GPP TR 21.905 (R99 onwards): "Vocabulary for 3GPP Specifications". |
| [2] | 3GPP TS 02.01 (R96 to R98): "Principles of telecommunication services supported by a GSM Public Land Mobile Network (PLMN)". 3GPP TS 22.001 (R99 onwards): "Principles of circuit telecommunication services supported by a Public Land Mobile Network (PLMN)". |
| [3] | 3GPP TS 02.03 (R96 to R98): "Teleservices supported by a GSM Public Land Mobile Network (PLMN)". 3GPP TS 22.003 (R99 onwards): "Circuit Teleservices supported by a Public Land Mobile Network (PLMN)". |
| [4] | 3GPP TS 02.04 (R96 to R98): "General on supplementary services". 3GPP TS 22.004 (R99 onwards): "General on supplementary services". |
| [5] | 3GPP TS 02.06 (R96 to R98): "Types of Mobile Stations (MS)". |
| [6] | 3GPP TS 02.07 (R96 to R98): "Mobile Station (MS) features". |
| [7] | 3GPP TS 03.38 (R96 to R98): "Alphabets and language-specific information". 3GPP TS 23.038 (R99 onwards): "Alphabets and language-specific information". |
| [8] | 3GPP TS 03.40 (R96 to R98): "Technical realization of the Short Message Service (SMS); Point-to-Point (PP)". 3GPP TS 23.040 (R99 onwards): "Technical realization of the Short Message Service (SMS)". |
| [9] | 3GPP TS 03.41 (R96 to R98): "Technical realization of Cell Broadcast Service (CBS)". 3GPP TS 23.041 (R99 onwards): "Technical realization of Cell Broadcast Service (CBS)". |
| [10] | 3GPP TS 04.08 (R96 to R98): "Mobile radio interface; Layer 3 specification" . 3GPP TS 24.008 (R99 onwards): "Mobile radio interface layer 3 specification; Core network protocols; Stage 3". |
| [11] | 3GPP TS 04.11 (R96 to R98): "Point-to-Point (PP) Short Message Service (SMS) support on mobile radio interface". 3GPP TS 24.011 (R99 onwards): "Point-to-Point (PP) Short Message Service (SMS) Support on mobile radio interface". |
| [12] | 3GPP TS 51.010-1 (Rel-5): "Mobile Station (MS) conformance specification; Part 1: Conformance specification". |
| [13] | 3GPP TS 11.11 (R96 to R99): "Specification of the Subscriber Identity Module - Mobile Equipment (SIM-ME) interface". |
| [14] | 3GPP TS 11.12 (R96): "Specification of the 3 Volt Subscriber Identity Module - Mobile Equipment (SIM-ME) interface". |
| [15] | 3GPP TS 11.14 (R96 to R99): "Specification of the SIM application toolkit for the Subscriber Identity Module - Mobile Equipment (SIM - ME) interface". |
| [16] | Void. |
| [17a] | ISO/IEC 10646-1: "Information technology - Universal Multiple Octet Coded Character Set (UCS) - Part 1: Architecture and Basic Multilingual Plane". |
| [17b] | ISO/IEC 10646-2: "Information technology - Universal Multiple Octet Coded Character Set (UCS) - Part 2: Supplementary Planes". |

| [18] | 3GPP TS 07.07 (R96 to R98): "AT command set for GSM Mobile Equipment (ME)" 3GPP TS 27.007 (R99 onwards): "AT command set for 3G User Equipment (UE)". |
|------|---|
| [19] | ISO/IEC 9646-7 (1995): "Information technology - Open Systems Interconnection - Conformance testing methodology and framework - Part 7: Implementation Conformance Statements". |
| [20] | ETSI ETS 300 406 (1995): "Methods for Testing and Specification (MTS); Protocol and profile conformance testing specifications; Standardization methodology". |
| [21] | 3GPP TS 31.124: "Mobile Equipment (ME) conformance test specification; Universal Subscriber Identity Module Application Toolkit (USAT) conformance test specification". |

3 Definitions and abbreviations

3.1 Mobile station definition and configurations

The mobile station definition and configurations specified in 3GPP TS 51.010-1 [12] clause 3.1 shall apply, unless otherwise specified in the present clause.

3.2 Applicability

3.2.1 Applicability of the present document

The present specification applies to a terminal equipment that supports the SIM Application Toolkit optional feature.

3.2.2 Applicability of the individual tests

Table A.1 lists the optional features for which the supplier of the implementation states the support.

3.2.3 Applicability to terminal equipment

The applicability to terminal equipment specified in 3GPP TS 51.010-1 [12] clause 3.2.3 shall apply, unless otherwise specified in the present clause.

See table B.1.

3.2.4 Definitions

For the purposes of the present document, the terms and definitions given in 3GPP TS 51.010-1 [12], clause 3.3, apply.

3.2.4.1 Format of the table of optional features

Option

The optional feature supported or not by the implementation.

Support Answer notation

The support columns shall be filled in by the supplier of the implementation. The following common notations, defined in ISO/IEC 9646-7 [19], are used for the support column in the tables below.

| Y or y | supported by the implementation |
|--------|-------------------------------------|
| N or n | not supported by the implementation |

N/A, n/a or - no answer required (allowed only if the status is N/A, directly or after evaluation of a conditional status)

Mnemonic column

The Mnemonic column contains mnemonic identifiers for each item.

3.2.4.2 Format of the applicability table

The applicability of every test in table B.1 is formally expressed by the use of Boolean expression defined in the following clause.

The columns in table B.1 have the following meaning:

- In the "Item" column a local entry number for the requirement in the table is given.
- In the "Description" column a short non-exhaustive description of the requirement is found.
- The "Release" column gives the Release applicable and onwards, for the item in the "Description" column
- The "Test Sequence(s)" column gives a reference to the test sequence number(s) detailed in the present document and required to validate the implementation of the corresponding item in the "Description" column.
- For a given Release, the corresponding "Rel 9x ME" column lists the tests required for a Mobile Station to be declared compliant to this Release.
- The "Support" column is blank in the proforma, and shall be completed by the manufacturer in respect of each particular requirement to indicate the choices, which have been made in the implementation.
- The "Terminal Profile" column gives a reference to the corresponding bit that needs to be present in the Terminal Profile.
- The "Recommendation for terminals also supporting USAT" column should be used in conjunction with the entry in the "Rel9x ME" column. The column indicates if the test is applicable or redundant providing that the equivalent USAT test has been performed with the terminal supporting SAT and USAT.

3.2.4.3 Status and notations

The "Release 9x ME" columns shows the status of the entries as follows:

The following notations, defined in ISO/IEC 9646-7 [19], are used for the status column:

M mandatory - the capability is required to be supported.

O optional - the capability may be supported or not.

N/A not applicable - in the given context, it is impossible to use the capability.

X prohibited (excluded) - there is a requirement not to use this capability in the given context.

O.i qualified optional - for mutually exclusive or selectable options from a set. "i" is an integer which identifies an unique group of related optional items and the logic of their selection which is defined immediately following the table.

Ci conditional - the requirement on the capability ("M", "O", "X" or "N/A") depends on the support of other optional or conditional items. "i" is an integer identifying an unique conditional status expression which is defined immediately following the table. For nested conditional expressions, the syntax "IF ... THEN (IF ... THEN ... ELSE...) ELSE ..." shall be used to avoid ambiguities.

The "Recommendation for terminals also supporting USAT" column shows the status of the entries as follows:

A applicable - the test is applicable according to the corresponding entry in the "R9x ME" column

R redundant – the test has to be considered as redundant when the corresponding TS 31.124 [21] test

has been validated and executed. In that case the requirement may be verified by means of TS

31.124 [21].

AERi Additional test Execution Recommendation – with respect to the above listed definitions of ("A")

and ("R") the test is applicable ("A") or redundant ("R") depending on the support of other optional or conditional items. "i" is an integer identifying an unique conditional status expression which is defined immediately following the table. For nested conditional expressions, the syntax

"IF ... THEN (IF ... THEN ... ELSE...) ELSE ..." shall be used to avoid ambiguities.

References to items

For each possible item answer (answer in the support column) there exists a unique reference, used, for example, in the conditional expressions. It is defined as the table identifier, followed by a solidus character "/", followed by the item number in the table. If there is more than one support column in a table, the columns shall be discriminated by letters (a, b, etc.), respectively.

EXAMPLE: A.1/4 is the reference to the answer of item 4 in table A.1.

3.3 Table of optional features

Support of SIM Application Toolkit is optional for Mobile Equipment. However, if an ME states conformance with a specific GSM release, it is mandatory for the ME to support all functions of that release, as stated in table B.1.

The support of letter classes, which specify mainly ME hardware dependent features, is optional for the ME and may supplement the SIM Application Toolkit functionality described in the present document. If an ME states conformance to a letter class, it is mandatory to support all functions within the respective letter class.

The supplier of the implementation shall state the support of possible options in table A.1.

Table A.1: Options

| Item | Option | Status | Support | Mnemonic |
|------|---|--------|---------|----------------------------------|
| 1 | Capability Configuration parameter | 0 | | O_Cap_Conf |
| 2 | Sustained text | 0 | | O_sust_text |
| 3 | UCS2 coding scheme for Entry | 0 | | O_Ucs2_Entry |
| 4 | Extended Text String | 0 | | O_Ext_Str |
| 5 | Help information | 0 | | O_Help |
| 6 | Icons | 0 | | O_lcons |
| 7 | Class A: Dual Slot | 0 | | O_Dual_Slot |
| 8 | Detachable reader | 0 | | O_Detach_Rdr |
| 9 | Class B: RUN AT | 0 | | O_Run_At |
| 10 | Class C: LAUNCH BROWSER | 0 | | O_LB |
| 11 | Class D: Soft keys | 0 | | O_Soft_key |
| 12 | Class E: B.I.P related to CSD | 0 | | O_BIP_CSD |
| 13 | Screen sizing parameters | 0 | | O_Scr_Siz |
| 14 | Screen Resizing | 0 | | O_Scr_Resiz |
| 15 | UCS2 coding scheme for Display | 0 | | O_Ucs2_Disp |
| 16 | Mobile supporting GPRS | 0 | | O_GPRS |
| 17 | Mobile supporting UDP | 0 | | O_UDP |
| 18 | Mobile supporting TCP | 0 | | O_TCP |
| 19 | Redial in Set Up Call | 0 | | O_Redial |
| 20 | Mobile decision to respond with | 0 | | O_D_NoResp |
| | "No response from user" in finite | | | <u> </u> |
| | time | | | |
| 21 | Class E: B.I.P related to GPRS | 0 | | O_BIP_GPRS |
| 22 | Mobile supporting Called Party | 0 | | O_CP_Subaddr |
| | Subaddress | | | |
| 23 | Mobile supporting Fixed Dialling | 0 | | O_FDN |
| | Numbers | | | |
| 24 | Mobile supporting Barred Dialling | 0 | | O_BDN |
| | Numbers | | | |
| 25 | Mobile supporting "+CIMI" in | 0 | | O_+CIMI |
| | combination with Run AT | | | |
| | Command | _ | | |
| 26 | UCS2 in Cyrillic | 0 | | O_UCS2_Cyrillic |
| 27 | Mobile supporting '9EXX' response | 0 | | O_9EXX |
| | code for SIM data download error | | | 2 22 4 5 5 |
| 28 | Mobile supporting Envelope Call | 0 | | O_CC_Auto_Red |
| | Control always sent to the SIM | | | al |
| 20 | during automatic redial mode | 0 | | O_SetUp_Call_Se |
| 29 | Mobile supporting 2nd alpha identifier in SET UP CALL | U | | c Alpha Id |
| 30 | Mobile supporting Open Channel | 0 | | <u> </u> |
| 30 | (GPRS) not containing a Network | | | O_Open_Channe _GPRS_without_I |
| | Access Name TLV when no | | | efaultAPN |
| | default Access Point Name is set | | | Cladititi |
| | in the terminal configuration | | | |
| 31 | Preferred buffer size supported by | 0 | | O_BUFFER_SIZE |
| 0. | the terminal for Open Channel | | | 0_5011211_0121 |
| | command is greater than 0 byte | | | |
| | and less than 65535 bytes | | | |
| 32 | Terminal supports Dual Transfer | 0 | | O_DTM |
| | Mode (allowing GPRS connection | | | _ |
| | and call at the same time) | | | |
| 33 | Terminal supports Long | 0 | | O_longFTN |
| | ForwardToNumber | | | _ |
| 34 | Terminal executes User | 0 | | O_User_Confirm_ |
| | confirmation phase before sending | | | Before_PDP_Con |
| | PDP context activation request | | | ext_Request |
| 35 | Terminal supports SAT and USAT | 0 | | O_SAT_USAT |

3.4 Applicability table

Table B.1: Applicability of tests

| em | Description | Release | Test sequence (s) | Rel 96 ME | Rel 97 ME | Rel 98 ME | Rel 99 ME | Terminal Profile | Support | Recommendation for terminals also supporting USAT |
|----|--|---------|-------------------------|-----------------|-----------------|-----------------|-----------------|-------------------------|---------|---|
| 1 | PROFILE DOWNLOAD | R96 | 1 | М | М | М | M | E.1/1 | | |
| | 27.22.1 | | | | | | | | | |
| 2 | Contents of the TERMINAL PROFILE command 27.22.2 | R96 | | М | М | М | М | E.1/1 | | |
| 3 | Servicing of Proactive SIM Commands | R96 | | М | М | М | М | | | |
| | 27.22.3 | | | | | | | | | |
| 4 | DISPLAY TEXT | | | | | | | | | |
| | 27.22.4.1 | | | | | | | | | |
| | Unpacked | R96 | 1.1 | M | М | М | М | E.1/17 | | AER001 |
| | Screen busy | R96 | 1.2 | М | М | М | М | E.1/17 | | AER001 |
| | high priority | R96 | 1.3 | М | М | М | М | E.1/17 | | AER001 |
| | Packed | R96 | 1.4 | M | M | M | М | E.1/17 | | AER001 |
| | clear after delay | R96 | 1.5 | M | M | M | М | E.1/17 | | AER001 |
| | long text up to 160 bytes | R96 | 1.6 | M | M | M | М | E.1/17 | | AER001 |
| | Backwards move in SIM session | R96 | 1.7 | M | M | M | М | E.1/17 | | AER001 |
| | Session terminated by user | R96 | 1.8 | M | M | M | М | E.1/17 | | AER001 |
| | Command not understood by ME | R96 | 1.9 | M | M | M | М | E.1/17 | | AER001 |
| | no response from user | R96 | 2.1 | C120 | C120 | C120 | C120 | E.1/17 | | AER001 |
| | Extension Text | R98 | 3.1 | | | C106 | C106 | E.1/17 | | AER001 |
| | | | | | | | | AND | | |
| | | | | | | | | E.1/16 | | |
| | sustained text | R98 | 4.1, 4.2, | | | C104 | C104 | E.1/17 | | |
| | | | 4.3, 4.4 | | | | | AND | | |
| | | | | | | | | E.1/65 | | |
| | Icons | R98 | 5.1, 5.2, 5.3 | | | C108 | | E.1/17 | | |
| | UCS2 display | R97 | 6.1 | | C118 | C118 | C118 | E.1/17 AND E.1/15 | | |

| m | Description | Release | Test sequence (s) | Rel 96 ME | Rel 97 ME | Rel 98 ME | Rel 99 ME | Terminal Profile | Support | Recommendation for terminals also supporting USAT |
|---|--|---------|-------------------------|-----------------|-----------------|-----------------|-----------------|---------------------|---------|---|
| | GET INKEY | | | | | | | | | |
| | 27.22.4.2 | | | | | | | | | |
| | prompt unpacked | R96 | 1.1 | М | M | M | M | E.1/18 | | AER001 |
| | prompt packed | R96 | 1.2 | М | M | M | M | E.1/18 | | AER001 |
| | digits only | R96 | 1.1 | М | M | M | M | E.1/18 | | AER001 |
| | Backwards move in SIM session | R96 | 1.3 | М | М | М | M | E.1/18 | | AER001 |
| | Session terminated by user | R96 | 1.4 | М | M | М | M | E.1/18 | | AER001 |
| | SMS alphabet | R96 | 1.5 | М | M | М | M | E.1/18 | | AER001 |
| | Long text up to 160 bytes | R96 | 1.6 | М | М | М | M | E.1/18 | | AER001 |
| | no response from user | R96 | 2.1 | C120 | C120 | C120 | C120 | E.1/18 | | AER001 |
| | UCS2 display | R97 | 3.1 | | C118 | C118 | C118 | E.1/18 | | |
| | | | | | | | | AND | | |
| | | | | | | | | E.1/15 | | |
| | UCS2 display, Long text up to 70 chars | R97 | 3.2 | | C118 | C118 | C118 | E.1/18 | | |
| | | | | | | | | AND | | |
| | | | | | | | | E.1/15 | | |
| | UCS2 format of entry | R97 | 4.1 | | C105 | C105 | C105 | E.1/18 | | |
| | | | | | | | | AND | | |
| | | _ | | | | | | E.1/14 | | |
| | "Yes/No" response | R98 | 5.1 | | | M | M | E.1/18 | | AER001 |
| | | | | | | | | AND | | |
| | | _ | | | | | | E.1/60 | | |
| | Icons | R98 | 6.1, 6.2, | | | C108 | C108 | E.1/18 | | |
| | | | 6.3, 6.4 | | | | | | | |
| | Help information | R97 | 7.1 | | C107 | C107 | C107 | E.1/18 | | AER001 |

| Item | Description | Release | Test sequence (s) | Rel 96 ME | Rel 97 ME | Rel 98 ME | Rel 99 ME | Terminal Profile | Support | Recommendation for terminals also supporting USAT |
|------|---|---------|-----------------------|-----------------|-----------------|-----------------|-----------------|-------------------------|---------|---|
| 6 | GET INPUT | | . , | | | | | | | |
| | 27.22.4.3 | | | | | | | | | |
| | input unpacked | R96 | 1.1 | М | M | М | М | E.1/19 | | AER001 |
| | input packed | R96 | 1.2 | М | M | М | М | E.1/19 | | AER001 |
| | digits only | R96 | 1.1 | М | M | М | М | E.1/19 | | AER001 |
| | SMS alphabet | R96 | 1.3 | М | M | М | М | E.1/19 | | AER001 |
| | hidden input | R96 | 1.4 | М | M | М | М | E.1/19 | | AER001 |
| | min / max acceptable length | R96 | 1.5, 1.9 | М | M | М | М | E.1/19 | | AER001 |
| | Backwards move in SIM session | R96 | 1.6 | М | M | M | M | E.1/19 | | AER001 |
| | Session terminated by user | R96 | 1.7 | М | M | M | M | E.1/19 | | AER001 |
| | Prompt text up to 160 bytes | R96 | 1.8 | М | M | М | М | E.1/19 | | AER001 |
| | SMS default alphabet, ME to echo text, packing not required | R96 | 1.9 | М | М | М | М | E.1/19 | | AER001 |
| | Null length for the text string | R96 | 1.10 | М | M | M | M | E.1/19 | | AER001 |
| | no response from user | R96 | 2.1 | C120 | C120 | C120 | | E.1/19 | | AER001 |
| | UCS2 display | R97 | 3.1, 3.2 | | C118 | C118 | C118 | E.1/19 AND | | |
| | | | | | | | | E.1/15 | | |
| | UCS2 entry | R97 | 4.1, 4.2 | | C105 | C105 | C105 | E.1/19 AND E.1/14 | | |
| | default text for the input | R97 | 5.1, 5.2 | | М | М | М | E.1/19 | | AER001 |
| | icons | R98 | 6.1, 6.2, 6.3, 6.4 | | | C108 | | E.1/19 | | |
| | help information | R97 | 7.1 | | C107 | C107 | C107 | E.1/19 | | |
| 7 | MORE TIME 27.22.4.4 | R96 | 1.1 | М | М | М | М | E.1/20 | | |
| 8 | PLAY TONE | | | | | | | | | |
| | 27.22.4.5 | | | | | | | | | |
| | play all tones | R96 | 1.1 | М | M | M | M | E.1/21 | | |
| | display alpha | R96 | 1.1 | М | M | М | М | E.1/21 | | |
| | user termination | R96 | 1.1 | М | M | М | М | E.1/21 | | |
| | superimpose | R96 | 1.1 | М | M | М | М | E.1/21 | | |
| | UCS2 display | R97 | TBD | | | | | E.1/21 AND E.1/15 | | |
| | icons | R98 | TBD | <u> </u> | | | | E.1/21 | | |
| 9 | POLL INTERVAL | 1.00 | | | | | | , | | |
| | 27.22.4.6 | | | | | | | | | |

| Item | Description | Release | Test | Rel | Rel | Rel | Rel | | Support | Recommendation |
|------|--|---------|----------------------|---------|---------|---------|---------|-----------------|---------|------------------------|
| | | | sequence | 96 | 97 | 98 | 99 | Profile | | for terminals also |
| | duration | R96 | (s) 1.1 | ME M | ME M | ME M | ME M | E.1/22 | | Supporting USAT AER001 |
| 10 | REFRESH | K96 | 1.1 | IVI | IVI | IVI | IVI | E.1/22 | | AERUUT |
| 10 | REFRESH | | | | | | | | | |
| | 27.22.4.7 | | | | | | | | | |
| | SIM initialization, enabling FDN mode | R96 | 1.1 | C125 | C125 | C125 | C125 | E.1/24 | | |
| | file change notification of FDN file | R96 | 1.2 | | | C125 | | E.1/24 | | |
| | SIM initialization and file change | R96 | 1.3 | М | М | М | М | E.1/24 | | |
| | notification of PLMN | | | | | | | | | |
| | SIM initialization and full file change | R96 | 1.4 | C125 | C125 | C125 | C125 | E.1/24 | | |
| | notification, enabling FDN mode | | | | | | | | | |
| | SIM reset | R96 | 1.5 | М | М | М | М | E.1/24 | | |
| | SIM Initialization after SMS-PP data | R96 | 1.6 | 0.405 | C125 | C125 | C125 | E.1/24 | | |
| | download | Doo | 0.4 | C125 | | | | E 4/0.4 | | |
| | IMSI Changing procedure, SIM Initialization and File Change Notification) | R98 | 2.1 | | | M | М | E.1/24 | | |
| | IMSI Changing procedure, SIM Initialization and Full File Change Notification) | R98 | 2.2 | | | М | М | E.1/24 | | |
| | IMSI Changing procedure, SIM Reset | R98 | 2.3 | | | М | М | E.1/24 | | |
| 11 | SET UP MENU | | | | | | | | | |
| | | | | | | | | | | |
| | 27.22.4.8 | | | | | | | | | |
| | Set up, menu selection, replace and | R96 | 1.1 | М | М | М | M | E.1/30 | | AER001 |
| | remove menu | | | | | | | AND | | |
| | Large monu | R96 | 1.2 | М | М | М | М | E.1/4 E.1/30 | | AER001 |
| | Large menu | K96 | 1.2 | IVI | IVI | IVI | IVI | AND | | AERUUT |
| | | | | | | | | E.1/4 | | |
| | help information | R97 | 2.1 | | C107 | C107 | C107 | E.1/30 | | AER001 |
| | | 1.07 | | | 0.0. | 0.0. | 0.0. | AND | | 7.27.001 |
| | | | | | | | | E.1/4 | | |
| | next action indicator | R97 | 3.1 | | М | М | М | E.1/30 | | AER001 |
| | icons | R98 | 4.1, 4.2 | | | C108 | C108 | E.1/30 | | |
| | soft key access | R99 | 5.1 | | | | C112 | E.1/30 | | |
| | | | | | | | | AND | | |
| 40 | OF LEGITLEM | | | | | | | E.1/74 | | |
| 12 | SELECT ITEM | | | | | | | | | |
| | 27.22.4.9 | | | | | | | | | |
| | Mandatory features | R96 | 1.1 | М | М | М | М | E.1/25 | | AER001 |
| | Large menu | R96 | 1.2, 1.3, 1.5,1.6 | М | М | М | М | E.1/25 | | AER001 |
| | Backwards move | R96 | 1.4 | М | М | М | М | E.1/25 | | AER001 |
| | user termination | R96 | 1.5 | М | М | М | М | E.1/25 | | AER001 |

| Item | Description | Release | Test | Rel | Rel | Rel | Rel | Terminal | Support | Recommendation |
|------|---|---------|-----------------------|----------|----------|----------|----------|-------------------------|---------|---------------------------------------|
| | | | sequence (s) | 96 ME | 97 ME | 98 ME | 99 ME | Profile | | for terminals also supporting USAT |
| | next action indicator | R97 | 2.1 | 14.2 | M | M | M | E.1/25 | | capporting conti |
| | default selected item | R97 | 3.1 | | M | M | M | E.1/25 | | AER001 |
| | help information | R97 | 4.1 | | C107 | C107 | C107 | E.1/25 | | 1 |
| | icons | R98 | 5.1, 5.2 | | | C108 | | E.1/25 | | |
| | Presentation style | R98 | 6.1, 6.2 | | | М | М | E.1/25 | | |
| | Soft keys | R99 | 7.1 | | | | C112 | E.1/25 | | |
| | | | | | | | | AND | | |
| | | | | | | | | E.1/73 | | |
| | no response from user | R96 | 8.1 | C120 | C120 | C120 | C120 | E.1/25 | | AER001 |
| 13 | SEND SMS | | | | | | | | | |
| | 27.22.4.10 | | | | | | | | | |
| | Packing not required | R96 | 1.1 | М | М | М | M | E.1/26 | | |
| | Packing required | R96 | 1.2, 1.4 | M | M | M | M | E.1/26 | | AER001 |
| | 8 bit data | R96 | 1.1, 1.2 | М | М | M | M | E.1/26 | | AER001 |
| | SMS default alphabet | R96 | 1.3, 1.4, | M | M | М | M | E.1/26 | | AER001 |
| | | | 1.5 | | | | | | | |
| | 160 bytes length | R96 | 1.4, 1.5 | М | M | М | М | E.1/26 | | AER001 |
| | Alpha identifier | R96 | 1.6, 1.7, 1.8 | М | М | М | М | E.1/26 | | AER001 |
| | UCS2 SMS | R97 | 2.1 | | C118 | C118 | C118 | E.1/26 AND E.1/15 | | |
| | icons | R98 | 3.1, 3.2 | | | C108 | C108 | E.1/26 | | |
| 14 | SEND SS 27.22.4.11 | | | | | | | | | |
| | call forward unconditional, all bearers, successful | R96 | 1.1 | C129 | C129 | C129 | C129 | E.1/27 | | |
| | call forward unconditional, all bearers, Return Error | R96 | 1.2 | М | М | М | М | E.1/27 | | AER001 |
| | call forward unconditional, all bearers, Reject | R96 | 1.3 | М | М | М | М | E.1/27 | | AER001 |
| | call forward unconditional, all bearers, successful, SS request size limit | R96 | 1.4 | C129 | C129 | C129 | C129 | E.1/27 | | AER001 |
| | interrogate CLIR status, successful, alpha identifier limits | R96 | 1.5 | М | М | М | М | E.1/27 | | AER001 |
| | call forward unconditional, all bearers, successful, null data alpha identifier | R96 | 1.6 | C129 | C129 | C129 | C129 | E.1/27 | | AER001 |
| | call forward unconditional, all bearers, successful, icon support | R98 | 2.1, 2.2, 2.3, 2.4 | | | C108 | C108 | E.1/27 | | AER001 |

| Item | Description | Release | Test sequence (s) | Rel 96 ME | Rel 97 ME | Rel 98 ME | Rel 99 ME | Terminal Profile | Support | Recommendation for terminals also supporting USAT |
|------|---|---------|-------------------------|-----------------|-----------------|-----------------|-----------------|-------------------------|---------|---|
| | UCS2 display | R97 | 3.1 | | C118 | C118 | C118 | E.1/27 AND E.1/15 | | |
| 15 | SEND USSD | | | | | | | | | |
| | 27.22.4.12 | | | | | | | | | |
| | 7-bit data, successful | R96 | 1.1 | | | M | М | E.1/28 | | |
| | 8-bit data, successful | R96 | 1.2 | | | М | М | E.1/28 | | AER001 |
| | UCS2 data, successful | R96 | 1.3 | | | M | М | E.1/28 | | AER001 |
| | 7-bit data, unsuccessful | R96 | 1.4 | | | М | М | E.1/28 | | AER001 |
| | 7-bit data, unsuccessful | R96 | 1.5 | | | М | М | E.1/28 | | AER001 |
| | 256 octets, 7-bit data, successful, long alpha identifier | R96 | 1.6 | | | М | М | E.1/28 | | AER001 |
| | 7-bit data, successful, no alpha identifier | R96 | 1.7 | | | М | М | E.1/28 | | AER001 |
| | 7-bit data, successful, null length alpha identifier | R96 | 1.8 | | | М | М | E.1/28 | | AER001 |
| | icons | R98 | 2.1, 2.2, 2.3, 2.4 | | | C108 | C108 | E.1/28 | | |
| | UCS2 | R97 | 3.1 | | | C118 | C118 | E.1/28 AND E.1/15 | | |
| 16 | SET UP CALL 27.22.4.13 | | | | | | | | | |
| | Call confirmed by the user and connected | R96 | 1.1 | М | М | М | М | E.1/29 | | |
| | call rejected by the user | R96 | 1.2 | M | M | M | M | E.1/29 | | AER001 |
| | Void | 1130 | 1.2 | IVI | IVI | IVI | IVI | L. 1/29 | | ALINOUT |
| | putting all other calls on hold, ME busy | R96 | 1.4 | М | М | М | М | E.1/29 | | AER001 |
| | disconnecting all other calls, ME busy | R96 | 1.5 | M | M | M | M | E.1/29 | | AER001 |
| | only if not currently busy on another call, ME busy | R96 | 1.6 | M | M | M | M | E.1/29 | | AER001 |
| | putting all other calls on hold, call hold is not allowed | R96 | 1.7 | М | М | М | М | E.1/29 | | AER001 |
| | Capability configuration | R96 | 1.8 | C101 | C101 | C101 | C101 | E.1/29 | | AER001 |
| | long dialling number string | R96 | 1.9 | М | М | М | М | E.1/29 | | AER001 |
| | long first alpha identifier | R96 | 1.10 | М | М | М | М | E.1/29 | | AER001 |
| | Called party subaddress | R96 | 1.11 | C124 | | C124 | C124 | E.1/29 | | AER001 |
| | maximum duration for the redial mechanism | R96 | 1.12 | | C119 | | C119 | E.1/29 | | AER001 |
| | second alpha identifier | R98 | 2.1 | | | М | М | E.1/29 AND E.1/63 | | |

| Item | Description | Release | Test sequence (s) | Rel 96 ME | Rel 97 ME | Rel 98 ME | Rel 99 ME | Profile | Support | Recommendation for terminals also supporting USAT |
|------|--|---------|----------------------|-----------------|-----------------|-----------------|-----------------|--|---------|---|
| | UCS2 Display | R97 | TBD | | | | | E.1/29 AND E.1/15 | | |
| | icons | R98 | 3.1,3.2, 3.3, 3.4 | | | C108 | C108 | E.1/29 | | |
| 17 | POLLING OFF | R96 | 1.1 | М | М | М | М | E.1/23 | | |
| | 27.22.4.14 | | | | | | | | | |
| 18 | PROVIDE LOCAL INFO | | | | | | | | | |
| | 27.22.4.15 | | | | | | | | | |
| | location information | R96 | 1.1 | M | М | М | M | E.1/31 | | |
| | IMEI | R96 | 1.2 | M | М | М | M | E.1/31 | | AER001 |
| | network measurement results and BCCH channel list | R98 | 1.3 | | | M | M | E.1/32 AND E.1/67 | | AER001 |
| | Date, time and time zone | R98 | 1.4 | | | M | М | E.1/59 | | AER001 |
| | language setting | R99 | 1.5 | | | IVI | M | E.1/68 | | AER001 |
| | Timing advance | R99 | 1.6 | | | | M | E.1/69 | | AER001 |
| 19 | SET ÜP EVENT LIST 27.22.4.16 | | | | | | | | | |
| | Set up call connected event | R97 | 1.1 | | М | М | М | E.1/33 AND E.1/35 | | AER001 |
| | Replace by new event list | R97 | 1.2 | | М | М | M | E.1/33 AND E.1/35 AND E.1/36 | | AER001 |
| | Remove event | R97 | 1.3 | | М | М | М | E.1/33 AND E.1/35 | | AER001 |
| | Remove Event on ME Power Cycle | R97 | 1.4 | | М | М | М | E.1/33 AND E.1/35 | | AER001 |
| 20 | PERFORM CARD APDU | | | | | | | | | |
| | 27.22.4.17 | | | | | | | | | |
| | Additional card inserted, Select MF and Get Response | R98 | 1.1 | | | C109 | C109 | E.1/51 | | |

| Item | Description | Release | Test | Rel | Rel | Rel | Rel | | Support | Recommendation |
|------|--|---------|-----------------|----------|----------|----------|----------|-------------------------|---------|---------------------------------------|
| | | | sequence (s) | 96 ME | 97 ME | 98 ME | 99 ME | Profile | | for terminals also supporting USAT |
| | Additional card inserted, Select DF GSM, | R98 | 1.2 | | | C109 | C109 | E.1/51 | | |
| | Select EF PLMN , Update Binary, Read | | | | | | | | | |
| | Binary on EF PLMN | | | | | | | | | |
| | Additional card inserted, card powered off | R98 | 1.3 | | | | C109 | E.1/51 | | |
| | No card inserted, card powered off | R98 | 1.4 | | | | C109 | E.1/51 | | |
| | Invalid card reader identifier | R98 | 1.5 | | | | C109 | E.1/51 | | |
| | Detachable reader | R98 | 2.1 | | | C116 | C116 | E.1/51 | | |
| 21 | POWER OFF CARD | | | | | | | | | |
| | 27.22.4.18 | | | | | | | | | |
| | Additional card inserted | R98 | 1.1 | | | | C109 | E.1/50 | | |
| | No card inserted | R98 | 1.2 | | | | C109 | E.1/50 | | |
| | Detachable reader | R98 | 2.1 | | | C116 | C116 | E.1/50 | | |
| 22 | POWER ON CARD 27.22.4.19 | | | | | | | | | |
| | Additional card inserted | R98 | 1.1 | | | C109 | C109 | E.1/49 | | |
| | No ATR | R98 | 1.2 | | | | C109 | E.1/49 | | |
| | No card inserted | R98 | 1.3 | | | | C109 | E.1/49 | | |
| | Detachable reader | R98 | 2.1 | | | C116 | C116 | E.1/49 | | |
| 23 | GET READER STATUS | | | | | | | | | |
| | 27.22.4.20 | | | | | | | | | |
| | Additional card inserted, card powered | R98 | 1.1 | | | C109 | C109 | E.1/52 | | |
| | Additional card inserted, card not powered | R98 | 1.2 | | | | C109 | E.1/52 | | |
| | Additional card inserted, card not present | R98 | 1.3 | | | | C109 | E.1/52 | | |
| | Detachable reader | R98 | 2.1 | | | | C116 | E.1/52 | | |
| 24 | TIMER MANAGEMENT | | | | | | | | | |
| | 27.22.4.21.1 | | | | | | | | | |
| | Start timer 1 several times, get the current value of the timer and deactivate the timer successfully | R98 | 1.1 | | | М | М | E.1/57 AND E.1/58 | | AER001 |
| | Start timer 2 several times, get the current value of the timer and deactivate the timer successfully | R98 | 1.2 | | | М | М | E.1/57 AND E.1/58 | | AER001 |
| | Start timer 8 several times, get the current value of the timer and deactivate the timer successfully | R98 | 1.3 | | | М | М | E.1/57 AND E.1/58 | | AER001 |
| | Try to get the current value of a timer which is not started: action in contradiction with the current timer state | R98 | 1.4 | | | М | М | E.1/57 AND E.1/58 | | AER001 |

| Item | Description | Release | Test | Rel 96 | Rel 97 | Rel | Rel 99 | Terminal Profile | Support | Recommendation for terminals also |
|------|--|---------|-----------------|-----------|-----------|----------|-----------|--|---------|-----------------------------------|
| | | | sequence (s) | ME | ME | 98 ME | ME | | | supporting USAT |
| | Try to deactivate a timer which is not started: action in contradiction with the current timer state | R98 | 1.5 | | | М | М | E.1/57 AND E.1/58 | | AER001 |
| | Start 8 timers successfully | R98 | 1.6 | | | М | М | E.1/57 AND E.1/58 | | AER001 |
| 25 | ENVELOPE TIMER EXPIRATION 27.22.4.21.2 | | | | | | | | | |
| | Pending proactive SIM command | R98 | 2.1 | | | М | М | E.1/6 AND E.1/57 | | AER001 |
| | SIM application toolkit busy | R98 | 2.2 | | | M | M | E.1/6 AND E.1/57 AND E.1/20 | | AER001 |
| 26 | SET UP IDLE MODE TEXT 27.22.4.22 | | | | | | | | | |
| | Display idle mode text | R98 | 1.1 | | | M | M | E.1/61 AND E.1/33 AND E.1/39 | | |
| | Replace idle mode text | R98 | 1.2 | | | M | М | E.1/61 AND E.1/33 AND E.1/39 | | |
| | Remove idle mode test | R98 | 1.3 | | | M | M | E.1/61 AND E.1/33 AND E.1/39 | | |
| | Competing information on ME display | R98 | 1.4 | | | M | M | E.1/61 AND E.1/33 AND E.1/39 | | |

| Item | Description | Release | Test | Rel | Rel | Rel | Rel | Terminal | Support | Recommendation |
|------|--------------------------------------|---------|---------------------|-----|-----|------|------|----------|---------|--------------------|
| | 2000 | | sequence | 96 | 97 | 98 | 99 | Profile | Саррон | for terminals also |
| | | | (s) | ME | ME | ME | ME | | | supporting USAT |
| | ME powered cycled | R98 | 1.5 | | | М | М | E.1/61 | | |
| | ' | | | | | | | AND | | |
| | | | | | | | | E.1/33 | | |
| | | | | | | | | AND | | |
| | | | | | | | | E.1/39 | | |
| | Refresh with SIM initialization | R98 | 1.6 | | | M | M | E.1/61 | | |
| | | | | | | | | AND | | |
| | | | | | | | | E.1/24 | | |
| | | | | | | | | AND | | |
| | | | | | | | | E.1/33 | | |
| | | | | | | | | AND | | |
| | | | | | | | | E.1/39 | | |
| | Large text string | R98 | 1.7 | | | M | M | E.1/61 | | |
| | | | | | | | | AND | | |
| | | | | | | | | E.1/33 | | |
| | | | | | | | | AND | | |
| | | | | | | | | E.1/39 | | |
| | icons | R98 | 2.1, 2.2, | | | C108 | C108 | E.1/61 | | |
| | | | 2.3, 2.4 | | | | | AND | | |
| | 11000 11 1 | D00 | 2.4 | | | 0110 | 0440 | E.1/39 | | |
| | UCS2 display | R98 | 3.1 | | | C118 | C118 | E.1/61 | | |
| | | | | | | | | AND | | |
| | | | | | | | | E.1/15 | | |
| | | | | | | | | AND | | |
| 27 | RUN AT COMMAND | | | | | | | E.1/39 | | |
| 21 | RUN AT COMMAND 2 | | | | | | | | | |
| | 7.22.4.23 | | | | | | | | | |
| | No alpha Identifier | R98 | 1.1 | | | C110 | C110 | E.1/62 | | |
| | null data alpha identifier presented | R98 | 1.2 | | | | C110 | E.1/62 | | |
| | alpha identifier presented | R98 | 1.3 | | | | C110 | E.1/62 | | |
| | icons | R98 | 2.1, 2.2, | | | C114 | | E.1/62 | | |
| | ICOIIS | K90 | 2.1, 2.2, 2.3, 2.4, | | | C114 | C114 | E.1/02 | | |
| | | | 2.5, 2.4, | | | | | | | |
| 28 | SEND DTMF | | 2.5 | - | 1 | | | | | |
| 20 | OLIND DIMII | | | | | | | | | |
| | 27.22.4.24 | | | | | | | | | |
| | Normal | R98 | 1.1 | | | М | М | E.1/66 | | AER001 |
| | alpha identifier | R98 | 1.2, 1.3 | | | M | M | E.1/66 | | 7.2.1331 |
| | Mobile is not in a speech call | R98 | 1.4 | | | M | M | E.1/66 | | AER001 |
| | Icons | R98 | 2.1, 2.2, | | 1 | C108 | C108 | E.1/66 | | 7.2 |
| | | | 2.3 | | | | 3.00 | | | |

| Item | Description | Release | Test sequence (s) | Rel 96 ME | Rel 97 ME | Rel 98 ME | Rel 99 ME | Profile | Support | Recommendation for terminals also supporting USAT |
|------|---|---------|-------------------------|-----------------|-----------------|-----------------|-----------------|-------------------------|---------|---|
| | UCS2 display | R98 | 3.1 | | | C118 | C118 | E.1/66 AND E.1/15 | | |
| 29 | LANGUAGE NOTIFICATION | | | | | | | | | |
| | 27.22.4.25 | | | | | | | | | |
| | Specific language notification | R99 | 1.1 | | | | M | E.1/70 | | |
| | Non specific language notification | R99 | 1.2 | | | | M | E.1/70 | | |
| 30 | LAUNCH BROWSER 27.22.4.26 | | | | | | | | | |
| | No session already launched: Connect to the default URL | R99 | 1.1 | | | | C111 | E.1/71 | | |
| | connect to the specified URL, alpha identifier length=0 | R99 | 1.2 | | | | C111 | E.1/71 | | |
| | Browser identity, no alpha identifier | R99 | 1.3 | | | | C111 | E.1/71 | | |
| | one bearer specified and gateway/proxy identity | R99 | 1.4 | | | | C122 | E.1/71 | | |
| | void | R99 | 1.5 | | | | void | void | | |
| | Interaction with current session | R99 | 2.1, 2.2 | | | | C111 | E.1/71 | | |
| | Interaction with current session | R99 | 2.3 | | | | C111 | E.1/71 | | AER001 |
| | UCS2 display | R99 | 3.1 | | | | C117 | E.1/71 AND E.1/15 | | |
| | icons | R99 | 4.1, 4.2 | | | | C115 | E.1/71 | | |
| 31 | OPEN CHANNEL | | | | | | | | | |
| | 27.22.4.27 | | | | | | | | | |
| | Void | R99 | 1.1 - 1.10 | | | | Void | Void | | |
| | immediate link establishment, GPRS, no local address, no alpha identifier, no network access name | R99 | 2.1 | | | | C121 | E.1/89 AND E.1/98 | | |
| | immediate link establishment GPRS, no alpha identifier, with network access name | R99 | 2.2 | | | | C121 | E.1/89 AND E.1/98 | | |
| | immediate link establishment, GPRS, with alpha identifier | R99 | 2.3 | | | | C121 | E.1/89 AND E.1/98 | | |
| | immediate link establishment, GPRS, with null alpha identifier | R99 | 2.4 | | | | C121 | E.1/89 AND E.1/98 | | |

| Item | Description | Release | Test | Rel | Rel | Rel | Rel | Terminal | Support | Recommendation |
|------|---|---------|----------|-----|-----|-----|------|----------|---------|--------------------|
| | | | sequence | 96 | 97 | 98 | 99 | Profile | | for terminals also |
| | | | (s) | ME | ME | ME | ME | | | supporting USAT |
| | immediate link establishment, GPRS, | R99 | 2.5 | | | | C127 | E.1/89 | | |
| | command performed with modifications | | | | | | | AND | | |
| | (buffer size) | | | | | | | E.1/98 | | |
| | Void | Void | 2.6 | | | | Void | Void | | |
| | immediate link establishment, GPRS, open | R99 | 2.7 | | | | C130 | E.1/89 | | |
| | command with alpha identifier, User did not | | | | | | | AND | | |
| | accept the proactive command | | | | | | | E.1/98 | | |
| | GPRS, ME busy on call | R99 | 2.8 | | | | C128 | E.1/89 | | |
| | | | | | | | | AND | | |
| | | | | | | | | E.1/98 | | |
| 32 | CLOSE CHANNEL | | | | | | | | | |
| | | | | | | | | | | |
| | 27.22.4.28 | | | | | | | | | |
| | successful | R99 | 1.1 | | | | C121 | E.1/89 | | |
| | | | | | | | | AND | | |
| | | | | | | | | E.1/90 | | |
| | with an invalid channel identifier | R99 | 1.2 | | | | C121 | E.1/89 | | AER001 |
| | | | | | | | | AND | | |
| | | | | | | | | E.1/90 | | . == |
| | on an already closed channel | R99 | 1.3 | | | | C121 | E.1/90 | | AER001 |
| 33 | RECEIVE DATA | | | | | | | | | |
| | | | | | | | | | | |
| | 27.22.4.29 | | | | | | | | | |
| | already opened channel | R99 | 1.1 | | | | C121 | E.1/89 | | |
| | | | | | | | | AND | | |
| | | | | | | | | E.1/91 | | |
| | | | | | | | | AND | | |
| | | | | | | | | E.1/92 | | |

| Item | Description | Release | Test sequence | Rel 96 | Rel 97 | Rel 98 | Rel 99 | Terminal Profile | Support | Recommendation for terminals also |
|------|-------------------------------------|------------|---------------|-----------|-----------|-----------|-----------|------------------|---------|-----------------------------------|
| | | | (s) | ME | ME | ME | ME | | | supporting USAT |
| 34 | SEND DATA | | | | | | | | | |
| | 07.00.4.00 | | | | | | | | | |
| | 27.22.4.30 | Doo | 4.4 | | | | 0404 | E 4/00 | | |
| | immediate mode | R99 | 1.1 | | | | C121 | E.1/89 AND | | |
| | | | | | | | | E.1/92 | | |
| | Store mode | R99 | 1.2 | | | | C121 | E.1/89 | | AER001 |
| | Store mode | 1133 | 1.2 | | | | 0121 | AND | | ALIXOOT |
| | | | | | | | | E.1/92 | | |
| | Store mode, Tx buffer fully used | R99 | 1.3 | | | | C121 | E.1/89 | | AER001 |
| | Coord mode, in barrer rainy accu | 1.00 | | | | | | AND | | 7.2.100 |
| | | | | | | | | E.1/92 | | |
| | 2 consecutive SEND DATA Store mode | R99 | 1.4 | | | | C121 | E.1/89 | | AER001 |
| | | | | | | | | AND | | |
| | | | | | | | | E.1/92 | | |
| | immediate mode with a bad channel | R99 | 1.5 | | | | C121 | E.1/89 | | AER001 |
| | identifier | | | | | | | AND | | |
| | | | | | | | | E.1/92 | | |
| | Void | Void | 1.6 | | | | Void | Void | | |
| 35 | GET CHANNEL STATUS | | | | | | | | | |
| | 27 22 4 24 | | | | | | | | | |
| | without any BIP channel opened | Doo | 4.4 | | | | C404 | E 4/00 | | AED004 |
| | | R99 R99 | 1.1 | | | | C121 | E.1/93 E.1/89 | | AER001 |
| | with a BIP channel currently opened | K99 | 1.2 | | | | C121 | AND | | |
| | | | | | | | | E.1/93 | | |
| | after a link dropped | R99 | 1.3 | | | | C121 | E.1/89 | | AER001 |
| | alter a link dropped | 1133 | 1.5 | | | | 0121 | AND | | ALIXOOT |
| | | | | | | | | E.1/93 | | |
| 36 | DATA DOWNLOAD TO SIM | | | | | | | | | |
| | | | | | | | | | | |
| | 27.22.5 | | | | | | | | | |
| 37 | SMS-PP DATA DOWNLOAD | | | | | | | | | |
| | | | | | | | | | | |
| | 27.22.5.1 | | | | | | | | | |
| | [void] | | 1.1 | | | | | | | |
| | SIM responds with '91 XX' | R96 | 1.2 | М | М | М | М | E.1/2 | | |
| | More time | R96 | 1.3 | М | М | М | М | E.1/2 | | |
| | 8 bit alphabet | R96 | 1.4 | М | М | M | М | E.1/2 | | |
| | [void] | | 1.5 | ļ | | | | | | |
| | Data coding / message class | R96 | 1.6 | М | М | M | М | E.1/2 | | |

| Item | Description | Release | Test sequence (s) | Rel 96 ME | Rel 97 ME | Rel 98 ME | Rel 99 ME | Terminal Profile | Support | Recommendation for terminals also supporting USAT |
|------|---|---------|-------------------|-----------------|-----------------|-----------------|-----------------|---------------------|---------|---|
| 38 | SMS-CB DATA DOWNLOAD | | | | | | | | | |
| | 27.22.5.2 | | | | | | | | | |
| | ME does not display message | R96 | 1.1 | М | М | М | М | E.1/3 | | |
| | More time | R96 | 1.2 | М | М | М | М | E.1/3 | | |
| | | | | | | | | AND | | |
| | ME displays message | R96 | 1.3 | М | М | M | M | E.1/20 E.1/3 | | |
| 39 | CALL CONTROL BY SIM | 1100 | 1.0 | ivi | 101 | 101 | 171 | 2.170 | | |
| | | | | | | | | | | |
| | 27.22.6 Procedure for MO calls (Cell identity in | R97 | 1.1 to 1.5, | | М | M | M | E.1/10 | | AER001 |
| | envelope call control) | K97 | 1.1 to 1.5, | | IVI | IVI | IVI | AND | | AERUUI |
| | | | 1.14 | | | | | E.1/11 | | |
| | | | | | | | | AND | | |
| | | | | | | | | E.1/13 AND | | |
| | | | | | | | | E.1/29 | | |
| | Procedure for MO calls (Cell identity in | R97 | 1.6, 1.7 | | М | М | М | E.1/10 | | |
| | envelope call control) | | | | | | | AND E.1/11 | | |
| | | | | | | | | AND | | |
| | | | | | | | | E.1/13 | | |
| | | | | | | | | AND | | |
| | Procedure for SS (Cell identity in envelope | R97 | 2.1, 2.2, | | М | М | M | E.1/29 E.1/10 | | |
| | call control) | 11.07 | 2.3, 2.4 | | l IVI | IVI | IVI | AND | | |
| | , | | | | | | | E.1/11 | | |
| | Interaction with FDN (Cell identity in envelope call control) | R97 | 3.1, 3.2, | | C125 | C125 | C125 | E.1/10 | | |
| | lenvelope call control) | | 3.3, 3.4, 3.5 | | | | | | | |
| | Support of BDN service (Cell identity in | R97 | 4.1, 4.2, | | C126 | C126 | C126 | E.1/10 | | |
| | envelope call control) | | 4.3, 4.4 | | | | | | | |
| 40 | EVENT DOWNLOAD | | | | | | | | | |
| | 27.22.7 | | | | | | | | | |
| | 27.22.7.1: MT call event | R97 | 1.1 | | М | М | М | E.1/34 | | AER001 |
| | | | | | | | | AND | | |
| | 27.22.7.2.1: call connected event | R97 | 1.1 | - | М | М | M | E.1/33 E.1/35 | | AER001 |
| | | 1.07 | | | '" | .,, | | AND | | , 1211001 |
| | | | | | 1 | | | E.1/33 | | |

| Item | Description | Release | Test sequence (s) | Rel 96 ME | Rel 97 ME | Rel 98 ME | Rel 99 ME | Terminal S Profile | upport | Recommendation for terminals also supporting USAT |
|------|--|---------|-------------------------|-----------------|-----------------|-----------------|-----------------|--|--------|---|
| | 27.22.7.2.2: ME supporting SET UP CALL | R97 | 2.1 | | М | М | M | E.1/35 AND E.1/29 AND E.1/33 | | |
| | 27.22.7.3: call disconnected event | R97 | 1.1 | | М | М | М | E.1/36 AND E.1/33 | | AER001 |
| | 27.22.7.4: location status event | R97 | 1.1 | | М | М | М | E.1/37 AND E.1/33 | | |
| | 27.22.7.5: user activity event | R97 | 1.1 | | М | М | М | E.1/38 AND E.1/33 | | AER001 |
| | 27.22.7.6: idle screen available event | R97 | 1.1 | | М | М | М | E.1/39 AND E.1/33 | | AER001 |
| | 27.22.7.7.1: Card reader status normal | R98 | 1.1 | | | C109 | C109 | E.1/40 AND E.1/33 | | |
| | 27.22.7.7.2: Detachable card reader | R98 | 2.1 | | | C116 | C116 | E.1/40 AND E.1/33 | | |
| | 27.22.7.8: language selection event | R99 | 1.1 | | | | М | E.1/41 AND E.1/33 | | |
| | 27.22.7.9: Browser termination event | R99 | 1.1 | | | | C111 | E.1/42 AND E.1/33 | | AER001 |
| | 27.22.7.10: Data available event | R99 | 1.1 | | | | C121 | E.1/43 AND E.1/89 AND E.1/33 | | AER001 |
| | 27.22.7.11: Channel status event | R99 | 1.1 | | | | C121 | E.1/44 AND E.1/89 AND E.1/33 | | AER001 |
| 41 | MO SMS Control by SIM 27.22.8 | | | | | 1 | | | | |
| | With proactive command, Allowed, no modification | R98 | 1.1 | | | М | М | E1/12 AND E.1/26 | | |
| | With user SMS, Allowed , no modification | R98 | 1.2 | | | М | М | E1/12 | | |

| Item Description | Release | Test sequence (s) | Rel 96 ME | Rel 97 ME | Rel 98 ME | Rel 99 ME | Terminal Profile | Support | Recommendation for terminals also supporting USAT |
|---|---------|-------------------------|-----------------|-----------------|-----------------|-----------------|------------------------|---------|---|
| With proactive command, Not allowed | R98 | 1.3 | | | M | M | E1/12 AND E.1/26 | | |
| With user SMS, Not allowed | R98 | 1.4 | | | М | М | E1/12 | | |
| With proactive command, Allowed, with modifications | R98 | 1.5 | | | M | M | E1/12 AND E.1/26 | | |
| With user SMS, Allowed, with modifications | R98 | 1.6 | | | М | М | E1/12 | | |
| With Proactive command, the SIM responds with '90 00', Allowed, no modification | R98 | 1.7 | | | M | М | E1/12 AND E.1/26 | | |
| Send Short Message attempt by user, the SIM responds with '90 00', Allowed, no modification | R98 | 1.8 | | | М | М | E1/12 | | |
| Void | | | | | | | | | |

| Item | Description | Release | Test | Rel | Rel | Rel | Rel | Terminal | Support | Recommendation |
|---------------|--|------------|-----------------------------|-----------------|----------|------------|----------|--------------|------------|---------------------------------------|
| | | | sequence (s) | 96 ME | 97 ME | 98 ME | 99 ME | Profile | | for terminals also supporting USAT |
| C101 | IF A.1/1 THEN M ELSE N/A | (| Cap Conf | | | ···- | | L | | loabborning cover |
| C102 | void | | | | | | | | | |
| C103 | void | | | | | | | | | |
| C104 | IF A.1/2 THEN M ELSE N/A | | _Sust_text | | | | | | | |
| C105 | IF A.1/3 AND A.1/26 THEN M ELSE N/A | (| D_Ucs2_Entr | y AND | O_UC | S2_Cyr | illic | | | |
| C106 | IF A.1/4 THEN M ELSE N/A | | D_Ext_Str | | | | | | | |
| C107 | IF A.1/5 THEN M ELSE N/A | |)_Help | | | | | | | |
| C108 | IF A.1/6 THEN (O.1 OR O.2) ELSE N/A | |)_lcons | | | | | | | |
| C109 | IF A.1/7 THEN M ELSE N/A | | D_Dual_Slot | | | | | | | |
| C110 | IF (A.1/9 AND A.1/25) THEN M ELSE N/A | | D_Run_At Al | ND 0_+ | -CIMI | | | | | |
| C111 | IF A.1/10 THEN M ELSE N/A | |)_LB | | | | | | | |
| C112 | IF A.1/11 THEN M ELSE N/A | (| D_Soft_key | | | | | | | |
| C113 | void | | | | | | | | | |
| C114 | IF C110 AND C108 THEN M ELSE N/A | | D_Run_At Al | | | $NNDO_{-}$ | lcons | | | |
| C115 | IF C111 AND C108 THEN M ELSE N/A | | LB AND O | | | | | | | |
| C116 | IF A1/7 AND A.1/8 THEN M ELSE N/A | | D_Dual_Slot | | | | | | | |
| C117 | IF C111 AND C118 THEN M ELSE N/A | | LB AND O | | | | | _Cyrillic | | |
| C118 | IF A.1/15 AND A.1/26 THEN M ELSE N// | |)_Ucs2_Disp | AND | o_ucs | 32_Cyri | llic | | | |
| C119 | IF A.1/19 THEN M ELSE N/A | | D_Redial | | | | | | | |
| C120 | IF A.1/20 THEN M ELSE N/A | | D_D_NoResp | | | _ | | | | |
| C121 | IF A.1/21 AND A.1/17 THEN M ELSE N/A | | BIP_GPR | | | • | | | | |
| C122 | IF C111 AND A.1/16 THEN M ELSE N/A | (| LB AND C |)_GPR | S | | | | | |
| C123 | void | | | | | | _ | | | |
| C124 | IF A.1/22, test x.A M ELSE x.B M (where | | | uence | numbei | r value) | O_ | CP_Subado | dr | |
| C125 | IF A. 1/23 THEN M ELSE N/A | |)_FDN | | | | | | | |
| C126 | IF A. 1/24 THEN M ELSE N/A | |)_BDN | | | | | | | |
| C127 | IF C121 AND A.1/31 THEN M ELSE N/A | |)_BIP_GPR | | | | | | | |
| C128 | IF C121 AND (NOT A.1/32) THEN M ELS | | | S ANL | טט_טט | P AND | (NOT | O_DTM) | | |
| C129 | IF A.1/33 THEN test x.A M ELSE test x.B | | | | | | _ | | | |
| C130 | IF (C121 AND A.1/34) THEN test x.A M E | | | | | P ANI | ر | | | |
| | O_User_Confirm_Before_PDP_Context_ | | | | | | o " | 5. | | |
| | IF (C121 AND NOT A.1/34) test x.B M | | AND O_UDI | AND | NOIC |)_User | _Confiri | m_Betore_I | PDP_Cont | text_Request) |
| O.1 | IF (the ME supports icons as defined in renumber value) | ecord 1 of | EF _(IMG) , test | s x.1A | M ELS | E tests | x.1B M | (where x is | s the expe | cted sequence |
| O.2 | IF the ME supports icons as defined in revalue) | cord 2 of | EF _(IMG) , tests | s x.2A l | M ELSE | E x.2B I | M (wher | e x is the e | xpected s | equence number |
| O.3 AER001 | IF (A.1/21 AND A.1/12) tests (x.A AND x. IF (A.1/35) THEN R ELSE A | | SE IF A.1/12 D_SAT_USA | | IBM (w | here x | is the e | expected se | quence nu | ımber value) |

3.5 Conventions for mathematical notations

The conventions for mathematical notations specified in 3GPP TS 51.010-1 [12] clause 3.4 shall apply, unless otherwise specified in the present clause.

3.6 Conventions on electrical terms

The conventions on electrical terms specified in 3GPP TS 51.010-1 [12] clause 3.5 shall apply, unless otherwise specified in the present clause.

3.7 Terms on test conditions

The terms on test conditions specified in 3GPP TS 51.010-1 [12] clause 3.6 shall apply, unless otherwise specified in the present clause.

4 Test equipment

The test equipment is specified in 3GPP TS 51.010-1 [12] clause 4.

5 Testing methodology in general

5.1 Testing of optional functions and procedures

Any function or procedure which is optional, as indicated in the present document, may be subject to a conformance test if it is implemented in the ME.

5.2 Test interfaces and facilities

The test interfaces and facilities specified in 3GPP TS 51.010-1 [12] clause 5.2 shall apply, unless otherwise specified in the present clause.

The SIM interface provides the main test interface for the purpose of performing conformance tests.

5.3 Different protocol layers

The different protocol layers specified in 3GPP TS 51.010-1 [12] clause 5.3 shall apply, unless otherwise specified in the present clause.

5.4 Information to be provided by the apparatus supplier

The information to be provided by the apparatus supplier specified in 3GPP TS 51.010-1 [12] clause 5.4 shall apply, unless otherwise specified in the present clause.

In addition, the apparatus supplier shall provide the information with respect the Supported Option table A.1 and to ME's default configuration table A.2.

Table A.2: ME"s default configuration

| Item | Description | Value | Status | | | |
|--|--|-------|--------|--|--|--|
| 1 | DISPLAY TEXT: No Response from user timeout interval | | С | | | |
| 2 | GET INKEY: No response from user Timeout interval | | С | | | |
| 3 | 3 GET INPUT: No response from user Timeout interval | | | | | |
| 4 | SELECT ITEM: No response from user Timeout interval | | С | | | |
| 5 | Preferred buffer size supported by the terminal for Open Channel command | | С | | | |
| NOTE: Conditional values shall be provided if the corresponding option is supported in the table A.1 | | | | | | |

5.5 Definitions of transmit and receive times

The definitions of transmit and receive times specified in 3GPP TS 51.010-1 [12] clause 5.5 shall apply, unless otherwise specified in the present clause.

6 Reference test methods

The reference test methods specified in 3GPP TS 51.010-1 [12] clause 6 shall apply, unless otherwise specified.

7 Implicit testing

For some GSM features conformance is not verified explicitly in the present document. This does not imply that correct functioning of these features is not essential, but that these are implicitly tested to a sufficient degree in other tests.

It should be noted that for these features some aspects have to be and are explicitly tested, e.g. the ability to switch between 3v and 5v operation.

Some SIM features will be explicitly tested as result of other tests. These should be identified for the following reason:

- To identify the areas of overlap and thus provide a more efficient testing.

8 Measurement uncertainty

The measured value relating to the corresponding limit shall be used to determine whether or not a terminal equipment meets the requirement. (ETR 028, annex B).

This process is often referred to as "shared risk".

9 Format of tests

In general the following basic format for tests is used:

27.22.X.X. Tested command

27.22.X.X.1 Command tested in «environment #1" (NORMAL, ICONS, UCS2 ...)

27.22.X.X.1.1 Definition and applicability

This clause refers back to clause 3.2.2.

27.22.X.X.1.2 Conformance requirement

Only if required, this clause details the necessary core specification references.

27.22.X.X.1.3 Test purpose

This clause details the purpose of the test.

27.22.X.X.1.4 Method of test

27.22.X.X.1.4.1 Initial conditions

If present this clause defines the initial conditions to be established before running each test sequence.

27.22.X.X.1.4.2 Procedure

This clause details the test procedure. Each test sequence shall be carried out independently unless otherwise stated.

• Sequence 1.1 (further initial conditions, added here)

| Command 1.1.1 |
|-----------------------------------|
| TERMINAL RESPONSE1.1.1A or 1.1.1B |
| Command 1.1.2 |
| TERMINAL RESPONSE1.1.2 |

PROACTIVE COMMAND 1.1.1

TERMINAL RESPONSE 1.1.1A

TERMINAL RESPONSE 1.1.1B

PROACTIVE COMMAND 1.1.2

TERMINAL RESPONSE 1.1.2

• Sequence 1.2

| Command 1.2.1 |
|--|
| TERMINAL RESPONSE 1.2.1 |
| Command 1.2.2 |
| TERMINAL RESPONSE1.2.2 (same as TERMINAL RESPONSE 1.2.1) |
| Command 1.2.3 |
| TERMINAL RESPONSE 1.2.3 |

PROACTIVE COMMAND 1.2.1

PROACTIVE COMMAND 1.2.2

PROACTIVE COMMAND 1.2.3

TERMINAL RESPONSE 1.2.1

TERMINAL RESPONSE 1.2.2

TERMINAL RESPONSE 1.2.3

• Sequence 1.3

Command 1.3.1 TERMINAL RESPONSE1.3.1

PROACTIVE COMMAND 1.3.1

TERMINAL RESPONSE 1.3.1

27.22.X.X.1.5 Test requirement

This clause details the conditions to be met for successful completion of the test.

27.22.X.X.2 Command tested in "environment #2" (NORMAL, ICONS, UCS2 ...)

27.22.X.X. 2.1 Definition and applicability

27.22.X.X. 2.2 Conformance requirement

27.22.X.X. 2.3 Test purpose

27.22.X.X. 2.4 Method of test

27.22.X.X. 2.4.1.1 Initial conditions

27.22.X.X. 2.4.1.2 Procedure

• Sequence 2.1

Command 2.1.1

TERMINAL RESPONSE2.1.1A or 2.1.1B

Command 2.1.2

TERMINAL RESPONSE2.1.2

PROACTIVE COMMAND 2.1.1

TERMINAL RESPONSE 2.1.1A

TERMINAL RESPONSE 2.1.1B

PROACTIVE COMMAND 2.1.2

TERMINAL RESPONSE 2.1.2

• Sequence 2.2

Command 2.2.1

TERMINAL RESPONSE 2.2.1

Command 2.2.2

TERMINAL RESPONSE 2.2.2 (same as TERMINAL RESPONSE 2.2.1)

Command 2.2.3

TERMINAL RESPONSE 2.2.3

PROACTIVE COMMAND 2.2.1

PROACTIVE COMMAND 2.2.2

PROACTIVE COMMAND 2.2.3

Coding TERMINAL RESPONSE 2.2.1

Coding TERMINAL RESPONSE 2.2.2

Coding TERMINAL RESPONSE 2.2.3

27.22.X.X.2.5 Test requirement

10 Generic call set up procedures

The generic call set up procedure specified in 3GPP TS 51.010-1 [12] clause 10 shall apply, unless otherwise specified in the present clause.

11 - 26 Not used

27 Testing of the SIM/ME interface

This clause is an addition to 3GPP TS 51.010-1 [12] clause 27 to confirm the correct interpretation of the SIM Application Toolkit commands and the correct operation of the Toolkit facilities.

The definitions, declarations and default values specified in 3GPP TS 51.010-1 [12] clause 27 shall apply, unless otherwise specified in the present clause.

NOTE: As defined in 3GPP TS 51.010-1 [12] clause 27 the term PCS 1900 defines the tests applicable for GSM 700, GSM 850 and PCS 1900 MS.

A SIM Simulator with the appropriate SIM Application Toolkit functionality will be required. The SIM data defined below shall be used for all test cases unless otherwise specified within the test case.

The comprehension required flags in SIMPLE-TLV objects that are included in a TERMINAL RESPONSE or an ENVELOPE shall be set as described in TS 11.14 [15]. This means that in cases where it is up to the ME to decide if this flag is used or not, the corresponding Tag coding in the TERMINAL RESPONSEs and ENVELOPEs in this document represents only one of the two valid possibilities.

3GPP TS 11.14 [15] defines that in case of the general result "Command performed successfully" some proactive commands require additional information in the command result and in which cases this is mandatory or optional. Thus when additional information bytes are optional in the Result TLV, the additional information bytes of the Result TLVin the Terminal Responses shall be ignored.

27.1 - 27.21 Void

27.22 SIM Application Toolkit

27.22.1A General Test purpose

Testing of functional conformance to SIM Application Toolkit commands, including pro-active SIM commands.

All facilities given by the TERMINAL PROFILE as supported, for which tests exist in the present document, shall be tested.

Many of the proactive SIM commands include an alpha identifier data object. This is intended to be a short one or two word identifier for the ME to optionally display on the screen along with any other indications, at the same time as the ME performs the SIM command.

NOTE: The sequence of SIM Application Toolkit commands are specific to the Toolkit Application being executed within the SIM, hence sequential testing of commands is not possible. The testing will therefore have to be performed on a command by command basis.

27.22.2A Definition of default values for SIM Application Toolkit testing

A SIM containing the following default values is used for all tests of this clause unless otherwise stated.

For each item, the logical default values and the coding within the Elementary Files (EF) of the SIM follow, as defined in:

• 3GPP TS 51. 010-1 [12], clause 27.

NOTE 1: Bx represents byte x of the coding.

NOTE 2: Unless otherwise defined, the coding values in binary.

EFSST (SIM Service Table)

Logically:

| (Service 2) | Abbreviated Dialling Numbers allocated and activated |
|--------------|--|
| (Service 3) | Fixed Dialling Numbers allocated and activated |
| (Service 10) | Extension 1 allocated and activated |
| (Service 11) | Extension 2 allocated and activated |
| (Service 12) | SMS Parameters allocated and activated |
| (Service 14) | Cell Broadcast Message Identifier allocated and activated |
| (Service 25) | Data download via SMS-CB allocated and activated |
| (Service 26) | Data download via SMS-PP allocated and activated |
| (Service 27) | Menu selection allocated and activated |
| (Service 28) | Call control allocated and not activated |
| (Service 29) | Proactive SIM allocated and activated |
| (Service 30) | Cell Broadcast Message Identifier Ranges allocated and activated |
| (Service 31) | Barred Dialling Numbers allocated and not activated |
| (Service 32) | Extension4 allocated and activated |
| (Service 37) | Mobile Originated Short Message control by SIM allocated and not activated |
| (Service 39) | Image (IMG) allocated and activated |
| (Service 41) | USSD string data object supported in Call Control allocated and activated |
| (Service 42) | RUN AT COMMAND command allocated and activated |
| (Service 48) | Extended Capability Configuration Parameters allocated and activated |
| | |

| Coding: | B1 | B2 | B3 | В4 |
|---------|---|----------|------------|------------|
| | xx1111xx | XXXXXXX | 1111111xx | xxxx11xx |
| | | | | |
| | B5 | B6 | B7 | B8 |
| | XXXXXXXX | XXXXXXX | 01111111 | 11011111 |
| | | | | |
| | B9 | B10 | B11 | B12 |
| [| MANAMAN AND AND AND AND AND AND AND AND AND A | vv41vv01 | yyyyy11111 | 11,000,000 |

| | _ | T | T | Τ _ |
|---|---------|----------|----------|----------|
| 1 | B9 | B10 | B11 | B12 |
| İ | xxxxxxx | xx11xx01 | xxxx1111 | 11xxxxxx |

EF_{Phase} (SIM Phase Identification)

Logically: Phase 2+

Coding: '03'

EF_{IMSI} (International Mobile Subscriber Identity)

Logically:

Length: 8 bytes

IMSI: 001 01 0123456789

> Coding: '08 09 10 10 10 32 54 76 98'

EF_{CBMI} (Cell Broadcast Message Identifier)

Logically:

Cell Broadcast Message Identifier 1: '03 E7'

| Coding: | 03 | E7 | FF | FF | | | |
|---------|----|----|----|--------|--|--|--|

EF_{CBMID} (Cell Broadcast Message Identifier for Data Download)

Cell Broadcast Message Identifier 1: '10 01'

| Coding: | 10 | 01 | FF | FF | | | |
|---------|----|----|----|--------|--|--|--|

EF_{FDN} (Fixed Dialling Numbers)

Logically:

At least 10 records

Record 1:

Length of alpha identifier: 32 characters
Alpha identifier: "ABC"
Length of BCD number: "03"

TON and NPI: Telephony and Unknown

Dialled number: 123
CCI: None
Ext2: None

| Coding: | B1 | B2 | B3 | B4 | B32 | B33 | B34 | B35 | B36 | B37 | B46 |
|-----------|----|----|----|----|---------|-----|-----|-----|-----|-----|---------|
| Record 1: | 41 | 42 | 43 | FF | FF | 03 | 81 | 21 | F3 | FF | FF |

Record 2:

Length of alpha identifier: 32 characters
Alpha identifier: "DEF"
Length of BCD number: "04"

TON and NPI: Telephony and Unknown

Dialled number: 9876 CCI: None Ext2: None

| (| Coding: | B1 | B2 | В3 | B4 | B32 | B33 | B34 | B35 | B36 | B37 | B46 | l |
|---|-----------|----|----|----|----|---------|-----|-----|-----|-----|-----|---------|---|
| | Record 1: | 44 | 45 | 46 | FF | FF | 03 | 81 | 89 | 67 | FF | FF | l |

EF_{BDN} (Barred Dialling Numbers)

Logically:

At least 10 records

Record 1:

Length of alpha identifier: 32 characters
Alpha identifier: "CBA"
Length of BCD number: "03"

TON and NPI: Telephony and Unknown

Dialled number: 321
CCI: None
Ext4: None
Comprehension Method Info: None

| Coding: | B1 | B2 | B3 | B4 | B32 | B33 | B34 | B35 | B36 | B37 | B47 |
|-----------|----|----|----|----|---------|-----|-----|-----|-----|-----|---------|
| Record 1: | 43 | 42 | 41 | FF | FF | 03 | 81 | 23 | F1 | FF | FF |

NOTE: EF_{BDN} shall be invalidated unless otherwise stated, i.e. by indicating that Barred Dialling Numbers service is enabled.

EF_{ECC} (Emergency Call Codes)

Emergency Call Code 1: '1020'

| ſ | Coding. | | Λ1 | 02 | FF | | |
|-----|---------|--|----|----|-----|--|--|
| - 1 | County. | | ΟI | 02 | 1.1 | | |

Emergency Call Code 2: '112'

| Coding: | 11 | F2 | FF | | |
|---------|----|----|----|--|--|

EF_{SMSP} (Short message service parameters)

Logically:

Record 1:

Record length: 28 bytes

Parameter Indicators:

TP-Destination Address: Parameter absent TS-Service Centre Address: Parameter present TP-Protocol Identifier: Parameter absent TP-Data Coding Scheme: Parameter absent TP-Validity Period: Parameter absent

TS-Service Centre Address:

TON: International Number

NPI: "ISDN / telephone numbering plan"

Dialled number string: "112233445566778"

| Coding: | B1 | B2 | В3 | B13 | B14 | B15 | B16 | B17 | B18 | B19 | B20 | B21 | B22 | B23 |
|-----------|----|----|----|---------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| Record 1: | FD | FF | FF | FF | 09 | 91 | 11 | 22 | 33 | 44 | 55 | 66 | 77 | F8 |

| | B24 | B25 | B26 | B27 | B28 |
|---|-----|-----|-----|-----|-----|
| ſ | FF | FF | FF | FF | FF |

For the display of icon:

- Under the DF Telecom: creation of DF Graphics (5F50);
- Under the DF 5F50: creation of EF_{Img} (4F20, linear fixed file) and $EF_{Instance}$ (4FXX, transparent file).

EF_{Img} (Image, 4F20)

Record 1:

Logically:

Number of Actual Images Instances: 01 Image Instance Width: 08 Image Instance Height: 08

Image Coding Scheme: 11 (basic image)
Image Instance File Identifier: 4F 04 (EF_{Instance})

Offset into Image Instance File: 00 00 Length of Image Instance Data: 00 0A

Coding:

| Coding: | 01 | 08 | 08 | 11 | 4F | 04 | 00 | 00 | 00 | 0A | FF | FF |
|---------|----|----|----|----|----|----|----|----|----|----|----|----|
| · | FF | | | | |

Record 2:

Number of Actual Images Instances: 01 Image Instance Width: 08 Image Instance Height: 08

Image Coding Scheme:21 (colour image)Image Instance File Identifier: $4F 02(EF_{Instance})$

Offset into Image Instance File: 00 00 Length of Image Instance Data: 00 16

Coding:

| Coding: | 01 | 08 | 80 | 21 | 4F | 02 | 00 | 00 | 00 | 16 | FF | FF |
|---------|----|----|----|----|----|----|----|----|----|----|----|----|
| | FF | | | | |

Record 3:

Logically:

Number of Actual Images Instances: 01 Image Instance Width: 18 Image Instance Height: 10

 $\begin{array}{ll} \text{Image Coding Scheme:} & 11 \text{ (basic image)} \\ \text{Image Instance File Identifier:} & 4F \text{ 03 } \text{(EF}_{\text{Instance}}) \end{array}$

Offset into Image Instance File: 00 00 Length of Image Instance Data: 00 32

Coding:

| Coding: | 01 | 18 | 10 | 11 | 4F | 03 | 00 | 00 | 00 | 32 | FF | FF |
|---------|----|----|----|----|----|----|----|----|----|----|----|----|
| | FF | | | | |

Record 4:

Logically:

Number of Actual Images Instances: 01 Image Instance Width: 2E Image Instance Height: 28

 $\begin{array}{ll} \mbox{Image Coding Scheme:} & \mbox{11 (basic image)} \\ \mbox{Image Instance File Identifier:} & \mbox{4F 01 (EF}_{\mbox{Instance}}) \end{array}$

Offset into Image Instance File: 00 00 Length of Image Instance Data: 00 E8

Coding:

| Coding: | 01 | 2E | 28 | 11 | 4F | 01 | 00 | 00 | 00 | E8 | FF | FF | |
|---------|----|----|----|----|----|----|----|----|----|----|----|----|--|
| • | FF | | | | | |

Record 5:

Logically:

Number of Actual Images Instances: 01 Image Instance Width: 05 Image Instance Height: 05

Image Coding Scheme: 11 (basic image)
Image Instance File Identifier: 4F 05 (EF_{Instance})

Offset into Image Instance File: 00 00 Length of Image Instance Data: 00 08

| Coding: | 01 | 05 | 05 | 11 | 4F | 05 | 00 | 00 | 00 | 08 | FF | FF |
|---------|----|----|----|----|----|----|----|----|----|----|----|----|
| | FF | FF | FF | FF | FF | FF | | | | | | |

EF_{Instance} (4F01)

Logically:

Image Instance Data: see below

Coding:

| Coding: | 2E | 28 | 00 | 00 | 00 | 00 | 00 | 00 | 00 | 01 | FF | 80 |
|---------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | 00 | 00 | 0F | FF | 00 | 00 | 00 | 00 | 77 | FE | 00 |
| | 00 | 00 | 01 | BF | F8 | 00 | 00 | 00 | 06 | FF | E0 | 00 |
| | 00 | 00 | 1A | 03 | 80 | 00 | 00 | 00 | 6B | F6 | BC | 00 |
| | 00 | 01 | AF | D8 | 38 | 00 | 00 | 06 | BF | 60 | 20 | 00 |
| | 00 | 1A | FD | 80 | 40 | 00 | 00 | 6B | F6 | 00 | 80 | 00 |
| | 01 | A0 | 1F | 02 | 00 | 00 | 06 | FF | E4 | 04 | 00 | 00 |
| | 1B | FF | 90 | 10 | 00 | 00 | 6D | EE | 40 | 40 | 00 | 01 |
| | BF | F9 | 01 | 00 | 00 | 6F | FF | E4 | 04 | 00 | 00 | 1B |
| | FF | 90 | 10 | 00 | 00 | 6F | FE | 40 | 40 | 00 | 01 | BF |
| | F9 | 01 | 00 | 00 | 06 | FF | E6 | 04 | 00 | 00 | 1B | FF |
| | 88 | 10 | 00 | 00 | 6F | FE | 20 | 40 | 00 | 01 | BF | F8 |
| | 66 | 00 | 00 | 06 | FF | E0 | F0 | 00 | 00 | 1B | FF | 80 |
| | 80 | 00 | 00 | 7F | FE | 00 | 00 | 00 | 03 | 00 | 0C | 00 |
| | 00 | 00 | 1F | FF | F8 | 00 | 00 | 00 | 00 | 00 | 00 | 00 |
| | 00 | 00 | 00 | 00 | 00 | 00 | 00 | 00 | 00 | 00 | 00 | 00 |
| | 1C | 21 | 08 | 44 | EE | 00 | 48 | C4 | 31 | 92 | 20 | 01 |
| | 25 | 11 | 45 | 50 | 80 | 07 | 14 | 45 | 15 | 43 | 80 | 12 |
| | 71 | 1C | 4D | 08 | 00 | 4A | 24 | 89 | 32 | 20 | 01 | C8 |
| | 9E | 24 | 4E | E0 | | | | | | | | |

EF_{Instance} (4F02)

Logically:

Image Instance Data:

Image width:08Image length:08Bits per raster image point:02Number of CLUT entries:03Location of CLUT:00 16Image body:see below

Coding:

| Coding: | 08 | 08 | 02 | 03 | 00 | 16 | AA | AA | 80 | 02 | 85 | 42 |
|---------|----|----|----|----|----|----|----|----|----|----|----|----|
| _ | 81 | 42 | 81 | 42 | 81 | 52 | 80 | 02 | AA | AA | FF | 00 |
| | 00 | 00 | FF | 00 | 00 | 00 | FF | | | | | |

EF_{Instance} (4F03)

Logically:

Image Instance Data: see below

| Coding: | 18 | 10 | FF | FF | FF | 80 | 00 | 01 | 80 | 00 | 01 | 80 |
|---------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | 01 | 8F | 3C | F1 | 89 | 20 | 81 | 89 | 20 | 81 | 89 |
| | 20 | F1 | 89 | 20 | 11 | 89 | 20 | 11 | 89 | 20 | 11 | 8F |
| | 3C | F1 | 80 | 00 | 01 | 80 | 00 | 01 | 80 | 00 | 01 | FF |
| | FF | FF | | | | | | | | | | |

EF_{Instance} (4F04)

Logically:

Image Instance Data: see below

Coding:

| Coding: | 80 | 80 | FF | 03 | A5 | 99 | 99 | A5 | C3 | FF |
|---------|----|----|----|----|----|----|----|----|----|----|
|---------|----|----|----|----|----|----|----|----|----|----|

EF_{Instance} (4F05)

Logically:

Image Instance Data: see below

Coding:

| Coding: | 05 | 05 | FE | EB | BF | FF | FF | FF |
|---------|----|----|----|----|----|----|----|----|
| | | | | | | | | |

27.22.1 Initialization of SIM Application Toolkit Enabled SIM by SIM Application Toolkit Enabled ME (Profile Download)

27.22.1.1 Definition and applicability

See clause 3.2.2.

27.22.1.2 Conformance requirement

The ME shall support the PROFILE DOWNLOAD command as defined in:

• 3GPP TS 11.14 [15] clause 5.2.

27.22.1.3 Test purpose

To verify that the ME sends a TERMINAL PROFILE command in accordance with the above requirements.

27.22.1.4 Method of test

27.22.1.4.1 Initial conditions

The ME is connected to the SIM Simulator. All elementary files are coded as the default Toolkit personalization, with the CHV1 enabled.

27.22.1.4.2 Procedure

Expected Sequence 1 (PROFILE DOWNLOAD)

| Step | Direction | Message / Action | Comments |
|------------|---|---|---|
| 1 | $USER \to ME$ | Power on ME | |
| 2 | $ME \to USER$ | PIN entry request | |
| 3 | $USER \to ME$ | Enter "1111" | |
| 4 5 | $\begin{array}{c} ME \to SIM \\ SIM \to ME \end{array}$ | VERIFY CHV1 1.1A VERIFY CHV ATTEMPT UNSUCCESSFUL 1.1A | [CHV1 code: "1111"] |
| 6 7 | $\begin{array}{c} ME \to USER \\ USER \to ME \end{array}$ | PIN entry request Enter "1234" | |
| 8 | $ME \to SIM$ | VERIFY CHV1 1.1B | [CHV1 code: "1234"] |
| 9 | $SIM \rightarrow ME$ | NORMAL ENDING OF COMMAND 1.1A | |
| 10 | $ME \to SIM$ | TERMINAL PROFILE 1.4 | The ME shall have read EF PHASE prior to the Profile Download |
| 11 | $SIM \to ME$ | NORMAL ENDING OF COMMAND 1.1A | |
| 12 | $ME \to SIM$ | SELECT EF IMSI 1.5 | |
| | | SELECT EF LOCI 1.6 | |

VERIFY CHV1: 1.1A

Logically:

Coding:

| APD | U: | CLA=A0 | INS=2 | 20 P1= | =00 P | 2=01 | P3=08 | |
|----------|----|--------|-------|--------|-------|------|-------|----|
| | | | | | | | | |
| DATA IN: | 31 | 31 | 31 | 31 | FF | FF | FF | FF |

VERIFY CHV1 ATTEMPT UNSUCCESSFUL: 1.1A

Logically:

Coding:

SW1=98 SW2=04

VERIFY CHV1: 1.1B

Logically:

Coding:

| APD | U: | CLA=A0 INS=20 | | 20 P1= | =00 I | P2=01 | P3=08 | |
|----------|----|---------------|----|--------|-------|-------|-------|----|
| | | | | | | | | |
| DATA IN: | 31 | 32 | 33 | 34 | FF | FF | FF | FF |

NORMAL ENDING OF COMMAND: 1.1A

Coding:

| SW1=90 | SW2=00 |
|--------|--------|
| | |

45

TERMINAL PROFILE: 1.4

Logically:

Coding:

| APDU: | CLA=A0 | INS=10 | P1=00 | P2=00 | P3=XX |
|-------|----------|--------|-------|-------|-------|
| _ | | | | | |
| | DATA IN: | YY | ZZ | | |

With XX representing the length of the following DATA IN depending on the SIM Toolkit commands supported by the ME, and with YY, ZZ, ... representing here the bytes of the TERMINAL PROFILE data, as specified in 3GPP TS 11.14 [15], clause 5.2.

SELECT EF IMSI: 1.5

Logically:

Coding:

| APDU: | CLA=A0 | INS=A4 | | P1=00 | | P2=00 |) | P3=02 |
|-------|---------|--------|----|-------|----|-------|---|-------|
| | DATA IN | l: | 6F | = | 07 | | | |

SELECT EF LOCI: 1.6

Logically:

Coding:

| APDU: | CLA=A0 | INS=A4 | | P1=00 | | P2=00 | P3=02 |
|-------|---------|----------|--|-------|--|-------|-------|
| | | | | | | | _ |
| | DATA IN | DATA IN: | | 6F | | | |

27.22.1.5 Test requirement

The ME shall operate in the manner defined in expected sequence 1.

27.22.2 Contents of the TERMINAL PROFILE command

27.22.2.1 Definition and applicability

See table E.1.

27.22.2.2 Conformance requirement

The ME shall support the PROFILE DOWNLOAD command as defined in:

• 3GPP TS 11.14 [15] clause 5.2.

27.22.2.3 Test purpose

- 1. Verify that the TERMINAL PROFILE indicates that Profile Download facility is supported.
- 2. Record which SIM Application Toolkit facilities are supported by the ME, to determine which subsequent tests are required.

27.22.2.4 Method of test

27.22.2.4.1 Initial conditions

The ME is connected to the SIM Simulator. All elementary files are coded as the default SIM Application Toolkit personalization.

27.22.1.4.2 Procedure

- a) The ME is powered on.
- b) After the ME sends the TERMINAL PROFILE command to the SIM Simulator, the SIM Simulator shall record the content of the TERMINAL PROFILE.
- c) The SIM Simulator shall return SW1 / SW2 of '90 00'.
- d) The contents of the TERMINAL PROFILE is recorded and compared to the corresponding table E.1 "status" column.

The test is terminated upon the ME sending the TERMINAL PROFILE command to the SIM Simulator.

27.22.2.5 Test requirement

- 1) After step a) the ME shall send the TERMINAL PROFILE command to the SIM Simulator with bit 1 of the first byte set to 1 (facility supported by ME).
- 2) In table E.1 for the corresponding ME Sim Toolkit Release and Options, The TERMINAL PROFILE information "support" recorded must be in accordance with the "Status" column. Support of features defined only in releases later than present release shall be ignored.

27.22.3 Servicing of proactive SIM commands

27.22.3.1 Definition and applicability

See clause 3.2.2.

27.22.3.2 Conformance requirement

On detection of a pending SIM Application Toolkit command from the SIM the ME shall perform the FETCH command to retrieve the proactive SIM command. The result of the executed command shall be transmitted from the ME to the SIM within a TERMINAL RESPONSE command.

The MORE TIME proactive command is used in this test. The ME shall have knowledge of this command, but may not support this SIM Application Toolkit facility.

• 3GPP TS 11.14 [15] clause 6.3.

27.22.3.3 Test purpose

To verify that the ME uses the FETCH command to obtain the proactive SIM command, after detection of a pending proactive SIM command. The pending proactive SIM command is indicated by the response parameters '91 xx' from the SIM.

To verify that the ME transmits the result of execution of the proactive SIM command to the SIM in the TERMINAL RESPONSE command.

27.22.3.4 Method of test

27.22.3.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as the SIM Application Toolkit default.

The SIM Simulator is configured to indicate that a proactive SIM command is pending.

The SIM Simulator is configured to monitor the SIM - ME interface.

27.22.3.4.2 Procedure

- a) The ME is powered on.
- b) After the ME has performed the PROFILE DOWNLOAD procedure, the SIM Simulator indicates that a Proactive SIM Command is pending with SW1 / SW2 of '91 0B'.
- c) After the ME sends the FETCH command to the SIM Simulator, the SIM Simulator returns Proactive SIM Command 2.1: MORE TIME.

27.22.3.5 Test requirement

- 1) After step b) the ME shall send the FETCH command to the SIM.
- 2) After step c) the ME shall send the TERMINAL REPONSE command with command number "01", type of command "02" and command qualifier "00".

27.22.4 Proactive SIM commands

27.22.4.1 DISPLAY TEXT

27.22.4.1.1 DISPLAY TEXT (Normal)

27.22.4.1.1.1 Definition and applicability

See clause 3.2.2.

27.22.4.1.1.2 Conformance requirements

The ME shall support the DISPLAY TEXT command as defined in the following technical specifications:

3GPP TS 11.14 [15], clause 5.2, clause 6.4.1, clause 6.5.4, clause 6.6.1, clause 6.8, clause 6.11, clause 12.6, clause 12.15, clause 12.15.1, clause 12.15.2, clause 12.15.3 and clause 12.31.

27.22.4.1.1.3 Test purpose

To verify that the ME displays the text contained in the DISPLAY TEXT proactive SIM command, and returns a successful result in the TERMINAL RESPONSE command send to the SIM.

27.22.4.1.1.4 Method of test

27.22.4.1.1.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

27.22.4.1.1.4.2 Procedure

Expected Sequence 1.1 (DISPLAY TEXT normal priority, Unpacked 8 bit data for Text String, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|-----------------------------|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: DISPLAY TEXT 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | [Normal priority, wait for user to clear |
| | | DISPLAY TEXT 1.1.1 | message, unpacked, 8 bit data] |
| 4 | $ME \to USER$ | Display "Toolkit Test 1" | |
| 5 | $USER \to ME$ | Clear Message | |
| 6 | $ME \to SIM$ | TERMINAL RESPONSE: | [Command performed successfully] |
| | | DISPLAY TEXT 1.1.1 | |
| 7 | $SIM \to ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |

PROACTIVE COMMAND: DISPLAY TEXT 1.1.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text String

Data coding scheme: unpacked, 8 bit data
Text: "Toolkit Test 1"

Coding:

| BER-TLV: | D0 | 1A | 81 | 03 | 01 | 21 | 80 | 82 | 02 | 81 | 02 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| - | 0F | 04 | 54 | 6F | 6F | 6C | 6B | 69 | 74 | 20 | 54 | 65 |
| | 73 | 74 | 20 | 31 | | | | | | | | |

TERMINAL RESPONSE: DISPLAY TEXT 1.1.1

Logically:

Command details

Command number:

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Expected Sequence 1.2 (DISPLAY TEXT normal priority, Unpacked 8 bit data for Text String, screen busy)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|----------------------------------|---|
| 1 | $USER \to ME$ | Set the ME screen to a display | The ME will be set to a mode so that normal |
| | | mode other than the normal | priority text commands shall be rejected. |
| | | stand-by display | |
| 2 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: DISPLAY TEXT 1.2.1 | |
| 3 | $ME \rightarrow SIM$ | FETCH | |
| 4 | $SIM \to ME$ | PROACTIVE COMMAND: | [Normal priority] |
| | | DISPLAY TEXT 1.2.1 | |
| 5 | $ME \rightarrow USER$ | No change of the currently being | |
| | | used display. | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: | [ME currently unable to process command - |
| | | DISPLAY TEXT 1.2.1 | screen busy] |
| 7 | $SIM \to ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |

PROACTIVE COMMAND: DISPLAY TEXT 1.2.1: same as 1.1.1

TERMINAL RESPONSE: DISPLAY TEXT 1.2.1

Logically:

Command details

Command number:

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME
Destination device: SIM

Result

General Result: ME currently unable to process command

Additional information: Screen is busy

Coding:

| BER-TLV: | 81 | 03 | 01 | 21 | 80 | 82 | 02 | 82 | 81 | 83 | 02 | 20 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | | | | | | | | | | | |

Expected Sequence 1.3 (DISPLAY TEXT, high priority, Unpacked 8 bit data for Text String, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|---------------|----------------------------------|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | The ME screen is in a mode other than the |
| | | PENDING: DISPLAY TEXT 1.3.1 | normal stand by display. |
| 2 | $ME \to SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | [High priority] |
| | | DISPLAY TEXT 1.3.1 | |
| 4 | $ME \to USER$ | Display "Toolkit Test 2" | |
| 5 | $USER \to ME$ | Clear Message | |
| 6 | $ME \to SIM$ | TERMINAL RESPONSE: | |
| | | DISPLAY TEXT 1.3.1 | |
| 7 | $SIM \to ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |
| 8 | $USER \to ME$ | Set the ME screen back to normal | |
| | | stand-by display | |

PROACTIVE COMMAND: DISPLAY TEXT 1.3.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: high priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text String

Data coding scheme: unpacked, 8 bit data Text: "Toolkit Test 2"

Coding:

| BER-TLV: | D0 | 1A | 81 | 03 | 01 | 21 | 81 | 82 | 02 | 81 | 02 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| • | 0F | 04 | 54 | 6F | 6F | 6C | 6B | 69 | 74 | 20 | 54 | 65 |
| | 73 | 74 | 20 | 32 | | | | | | | | |

TERMINAL RESPONSE: DISPLAY TEXT 1.3.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: high priority, wait for user to clear message

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 21 | 81 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
|----------|----|----|----|----|----|----|----|----|----|----|----|----|

Expected Sequence 1.4 (DISPLAY TEXT, Packed, SMS default alphabet, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-----------------------------|----------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: DISPLAY TEXT 1.4.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | [Packed, SMS default alphabet] |
| | | DISPLAY TEXT 1.4.1 | |
| 4 | $ME \rightarrow USER$ | Display "Toolkit Test 3" | |
| 5 | $USER \to ME$ | Clear Message | |
| 6 | $ME \to SIM$ | TERMINAL RESPONSE: | [Command performed successfully] |
| | | DISPLAY TEXT 1.4.1 | |

PROACTIVE COMMAND: DISPLAY TEXT 1.4.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text string

Data coding scheme: packed, SMS default alphabet

Text: "Toolkit Test 3"

Coding:

| BER-TLV: | D0 | 19 | 81 | 03 | 01 | 21 | 80 | 82 | 02 | 81 | 02 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0E | 00 | D4 | F7 | 9B | BD | 4E | D3 | 41 | D4 | F2 | 9C |
| | 0E | 9A | 01 | | | | | | | | | |

TERMINAL RESPONSE: DISPLAY TEXT 1.4.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 21 | 80 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | | | | | | | | | | | | |

Expected Sequence 1.5 (DISPLAY TEXT, Clear message after delay, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|------------------------------------|----------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: DISPLAY TEXT 1.5.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | [Clear message after a delay] |
| | | DISPLAY TEXT 1.5.1 | |
| 4 | ME 	o | Display "Toolkit Test 4" and clear | |
| | USER | this message after a short delay | |
| 5 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: | [Command performed successfully] |
| | | DISPLAY TEXT 1.5.1 | |
| 6 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |

PROACTIVE COMMAND: DISPLAY TEXT 1.5.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, clear message after a delay

Device identities

Source device: SIM
Destination device: Display

Text string

Data coding scheme: unpacked, 8 bit data
Text: "Toolkit Test 4"

| BER-TLV: | D0 | 1A | 81 | 03 | 01 | 21 | 00 | 82 | 02 | 81 | 02 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| · | 0F | 04 | 54 | 6F | 6F | 6C | 6B | 69 | 74 | 20 | 54 | 65 |
| | 73 | 74 | 20 | 34 | | | | | | | | |

TERMINAL RESPONSE: DISPLAY TEXT 1.5.1

Logically:

Command details

Command number:

Command type: DISPLAY TEXT

1

Command qualifier: normal priority, clear message after a delay

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TL | V: | 81 | 03 | 01 | 21 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|--------|----|----|----|----|----|----|----|----|----|----|----|----|----|

Expected Sequence 1.6 (DISPLAY TEXT, Text string with 160 bytes, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-----------------------------------|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: DISPLAY TEXT 1.6.1 | |
| 2 | $ME \to SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | [Text string with 160 bytes - maximum for non |
| | | DISPLAY TEXT 1.6.1 | extension text] |
| 4 | $ME \rightarrow USER$ | Display "This command instructs | |
| | | the ME to display a text message. | |
| | | It allows the SIM to define the | |
| | | priority of that message, and the | |
| | | text string format. Two types of | |
| | | prio" | |
| 5 | | Clear Message | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: | Command performed successfully |
| | | DISPLAY TEXT 1.6.1 | |

PROACTIVE COMMAND: DISPLAY TEXT 1.6.1

Logically:

Command details

Command number:

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text String

Data coding scheme: unpacked, 8 bit data

Text: "This command instructs the ME to display a text message. It allows the SIM to

define the priority of that message, and the text string format. Two types of prio"

| BER-TLV: | D0 | 81 | AD | 81 | 03 | 01 | 21 | 80 | 82 | 02 | 81 | 02 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 81 | A1 | 04 | 54 | 68 | 69 | 73 | 20 | 63 | 6F | 6D |
| | 6D | 61 | 6E | 64 | 20 | 69 | 6E | 73 | 74 | 72 | 75 | 63 |

| 74 | 73 | 20 | 74 | 68 | 65 | 20 | 4D | 45 | 20 | 74 | 6F |
|----|----|----|----|----|----|----|----|----|----|----|----|
| 20 | 64 | 69 | 73 | 70 | 6C | 61 | 79 | 20 | 61 | 20 | 74 |
| 65 | 78 | 74 | 20 | 6D | 65 | 73 | 73 | 61 | 67 | 65 | 2E |
| 20 | 49 | 74 | 20 | 61 | 6C | 6C | 6F | 77 | 73 | 20 | 74 |
| 68 | 65 | 20 | 53 | 49 | 4D | 20 | 74 | 6F | 20 | 64 | 65 |
| 66 | 69 | 6E | 65 | 20 | 74 | 68 | 65 | 20 | 70 | 72 | 69 |
| 6F | 72 | 69 | 74 | 79 | 20 | 6F | 66 | 20 | 74 | 68 | 61 |
| 74 | 20 | 6D | 65 | 73 | 73 | 61 | 67 | 65 | 2C | 20 | 61 |
| 6E | 64 | 20 | 74 | 68 | 65 | 20 | 74 | 65 | 78 | 74 | 20 |
| 73 | 74 | 72 | 69 | 6E | 67 | 20 | 66 | 6F | 72 | 6D | 61 |
| 74 | 2E | 20 | 54 | 77 | 6F | 20 | 74 | 79 | 70 | 65 | 73 |
| 20 | 6F | 66 | 20 | 70 | 72 | 69 | 6F | | | | |

TERMINAL RESPONSE: DISPLAY TEXT 1.6.1

Logically:

Command details

Command number:

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 21 | 80 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|

Expected Sequence 1.7 (DISPLAY TEXT, Backward move in SIM session, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--|---|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: DISPLAY TEXT 1.7.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | |
| | | DISPLAY TEXT 1.7.1 | |
| 4 | $ME \rightarrow USER$ | Display " <go-backwards>"</go-backwards> | |
| 5 | $USER \to ME$ | Indicate the need to go backwards | |
| | | in the proactive SIM application | |
| | | session | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: | [Backward move in the proactive SIM session |
| | | DISPLAY TEXT 1.7.1 | requested by the user] |

PROACTIVE COMMAND: DISPLAY TEXT 1.7.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text string

Data coding scheme: unpacked, 8 bit data
Text: "<GO-BACKWARDS>"

Coding:

| BER-TLV: | D0 | 1A | 81 | 03 | 01 | 21 | 80 | 82 | 02 | 81 | 02 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0F | 04 | 3C | 47 | 4F | 2D | 42 | 41 | 43 | 4B | 57 | 41 |
| | 52 | 44 | 53 | 3E | | | | | | | | |

TERMINAL RESPONSE: DISPLAY TEXT 1.7.1

Logically:

Command details

Command number:

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME Destination device: SIM

Result

General Result: Backward move in the proactive SIM session requested by the user

Coding:

BER-TLV: 81 03 01 21 80 82 02 82 81 83 01 11

Expected Sequence 1.8 (DISPLAY TEXT, session terminated by user)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-----------------------------------|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: DISPLAY TEXT 1.8.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | |
| | | DISPLAY TEXT 1.8.1 | |
| 4 | $ME \rightarrow USER$ | Display " <abort>"</abort> | |
| 5 | $USER \rightarrow ME$ | Indicate the need to end the | |
| | | proactive SIM application session | |
| 6 | $ME \to SIM$ | TERMINAL RESPONSE: | [Proactive SIM session terminated by the |
| | | DISPLAY TEXT 1.8.1 | user] |
| 7 | $SIM \to ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |

PROACTIVE COMMAND: DISPLAY TEXT 1.8.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text string

Data coding scheme: unpacked, 8 bit data Text: "<ABORT>"

| BER-TLV: | D0 | 13 | 81 | 03 | 01 | 21 | 80 | 82 | 02 | 81 | 02 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| _ | 08 | 04 | 3C | 41 | 42 | 4F | 52 | 54 | 3E | | | |

TERMINAL RESPONSE: DISPLAY TEXT 1.8.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME Destination device: SIM

Result

General Result: Proactive SIM session terminated by the user

Coding:

| BER-TLV: | 81 | 03 | 01 | 21 | 80 | 82 | 02 | 82 | 81 | 83 | 01 | 10 | l |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|---|
|----------|----|----|----|----|----|----|----|----|----|----|----|----|---|

Expected Sequence 1.9 (DISPLAY TEXT, icon and text to be displayed, no text string given, not understood by ME)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|-----------------------------|---|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: DISPLAY TEXT 1.9.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: | Including icon identifier, icon shall be |
| | | | displayed together with the alpha text string, but no text string given |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: | [Command data not understood by ME |
| | | DISPLAY TEXT 1.9.1 | (clause 6.5.4)] |
| 5 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |

PROACTIVE COMMAND: DISPLAY TEXT 1.9.1

Logically:

Command details

Command number:

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text string

Contents: null data object

Icon Identifier:

Icon qualifier: icon is self-explanatory Icon Identifier: record 1 in $EF_{(IMG)}$

Coding:

| BER-TLV: | D0 | 0F | 81 | 03 | 01 | 21 | 80 | 82 | 02 | 81 | 02 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | 9E | 02 | 00 | 01 | | | | | | | |

TERMINAL RESPONSE: DISPLAY TEXT 1.9.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command data not understood by ME

Coding:

| BER-TLV: 81 | 1 03 | 01 | 21 | 80 | 82 | 02 | 82 | 81 | 83 | 01 | 32 | 1 |
|-------------|------|----|----|----|----|----|----|----|----|----|----|---|
|-------------|------|----|----|----|----|----|----|----|----|----|----|---|

27.22.4.1.1.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.9.

27.22.4.1.2 DISPLAY TEXT (Support of "No response from user")

27.22.4.1.2.1 Definition and applicability

See clause 3.2.2.

27.22.4.1.2.2 Conformance requirement

The ME shall support the DISPLAY TEXT command as defined in the following technical specifications:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.1, clause 6.6.1, clause 6.8, clause 6.11, clause 12.6, clause 12.15, clause 12.15.1, clause 12.15.2 and clause 12.15.3.

27.22.4.1.2.3 Test purpose

To verify that the ME displays the text contained in the DISPLAY TEXT proactive SIM command, and returns a "No response from user" result value in the TERMINAL RESPONSE command send to the SIM.

27.22.4.1.2.4 Method of test

27.22.4.1.2.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

ME Manufacturers shall set the "no response from user" period of time.

The SIM simulator shall be set to that period of time.

27.22.4.1.2.4.2 Procedure

Expected Sequence 2.1 (DISPLAY TEXT, no response from user)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|----------------------------------|--|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: DISPLAY TEXT 2.1.1 | |
| 2 | $ME \to SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: | [Normal priority, wait for user to clear |
| | | DISPLAY TEXT 2.1.1 | message, unpacked, 8 bit data] |
| 4 | $ME \rightarrow USER$ | Display " <time-out>"</time-out> | |

| 6 | $ME \to SIM$ | TERMINAL RESPONSE: | [No response from user] within 5 s after the |
|---|--------------|-----------------------|--|
| | | DISPLAY TEXT 2.1.1 | end of that defined period of time |
| 7 | $SIM \to ME$ | PROACTIVE SIM SESSION | · |
| | | ENDED | |

PROACTIVE COMMAND: DISPLAY TEXT 2.1.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text string

Data coding scheme: unpacked, 8 bit data
Text: "<TIME-OUT>"

Coding:

| BER-TLV: | D0 | 16 | 81 | 03 | 01 | 21 | 80 | 82 | 02 | 81 | 02 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0B | 04 | 3C | 54 | 49 | 4D | 45 | 2D | 4F | 55 | 54 | 3E |

TERMINAL RESPONSE: DISPLAY TEXT 2.1.1

Logically:

Command details

Command number:

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME Destination device: SIM

Result

General Result: No response from user

Coding:

| BER-TLV: | 81 | 03 | 01 | 21 | 80 | 82 | 02 | 82 | 81 | 83 | 01 | 12 |
|-----------|----|----|----|----------|----|----|----|----|----|----|----|----|
| DLIX-ILV. | 01 | 03 | Οī | <u> </u> | 00 | 02 | 02 | 02 | 01 | 03 | UI | 14 |

27.22.4.1.2.5 Test requirement

The ME shall operate in the manner defined in expected sequence 2.1.

27.22.4.1.3 DISPLAY TEXT (Display of extension text)

27.22.4.1.3.1 Definition and applicability

See clause 3.2.2.

27.22.4.1.3.2 Conformance requirement

The ME shall support the DISPLAY TEXT command as defined in the following technical specifications:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.1, clause 6.6.1, clause 6.8, clause 6.11, clause 12.6, clause 12.15, clause 12.15.1, clause 12.15.2 and clause 12.15.3.

27.22.4.1.3.3 Test purpose

To verify that the ME displays the extension text contained in the DISPLAY TEXT proactive SIM command, and returns a successful result in the TERMINAL RESPONSE command send to the SIM.

27.22.4.1.3.4 Method of test

27.22.4.1.3.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

27.22.4.1.3.4.2 Procedure

Expected Sequence 3.1 (DISPLAY TEXT, display of the extension text)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|------------------------------------|---|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: DISPLAY TEXT 3.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: | [Text string with the maximum of 240 bytes] |
| | | DISPLAY TEXT 3.1.1 | |
| 4 | $ME \rightarrow USER$ | Display "This command instructs | |
| | | the ME to display a text message, | |
| | | and/or an icon (see clause 6.5.4). | |
| | | It allows the SIM to define the | |
| | | priority of that message, and the | |
| | | text string format. Two types of | |
| | | priority are defined:- display | |
| _ | | normal priority text and/" | |
| 5 | | Clear Message | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: | [Command performed successfully] |
| | | DISPLAY TEXT 3.1.1 | |
| 7 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |

PROACTIVE COMMAND: DISPLAY TEXT 3.1.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text String

Data coding scheme: unpacked, 8 bit data

Text: "This command instructs the ME to display a text message and/or an icon (see

clause 6.5.4). It allows the SIM to define the priority of that message, and the text string format. Two types of priority are defined:- display normal priority text and/"

| BER-TLV: | D0 | 81 | FD | 81 | 03 | 01 | 21 | 80 | 82 | 02 | 81 | 02 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 81 | F1 | 04 | 54 | 68 | 69 | 73 | 20 | 63 | 6F | 6D |
| | 6D | 61 | 6E | 64 | 20 | 69 | 6E | 73 | 74 | 72 | 75 | 63 |

| 74 | 73 | 20 | 74 | 68 | 65 | 20 | 4D | 45 | 20 | 74 | 6F |
|----|----|----|----|----|----|----|----|----|----|----|----|
| 20 | 64 | 69 | 73 | 70 | 6C | 61 | 79 | 20 | 61 | 20 | 74 |
| 65 | 78 | 74 | 20 | 6D | 65 | 73 | 73 | 61 | 67 | 65 | 2C |
| 20 | 61 | 6E | 64 | 2F | 6F | 72 | 20 | 61 | 6E | 20 | 69 |
| 63 | 6F | 6E | 20 | 28 | 73 | 65 | 65 | 20 | 36 | 2E | 35 |
| 2E | 34 | 29 | 2E | 20 | 49 | 74 | 20 | 61 | 6C | 6C | 6F |
| 77 | 73 | 20 | 74 | 68 | 65 | 20 | 53 | 49 | 4D | 20 | 74 |
| 6F | 20 | 64 | 65 | 66 | 69 | 6E | 65 | 20 | 74 | 68 | 65 |
| 20 | 70 | 72 | 69 | 6f | 72 | 69 | 74 | 79 | 20 | 6F | 66 |
| 20 | 74 | 68 | 61 | 74 | 20 | 6D | 65 | 73 | 73 | 61 | 67 |
| 65 | 2C | 20 | 61 | 6E | 64 | 20 | 74 | 68 | 65 | 20 | 74 |
| 65 | 78 | 74 | 20 | 73 | 74 | 72 | 69 | 6E | 67 | 20 | 66 |
| 6F | 72 | 6D | 61 | 74 | 2E | 20 | 54 | 77 | 6F | 20 | 74 |
| 79 | 70 | 65 | 73 | 20 | 6F | 66 | 20 | 70 | 72 | 69 | 6F |
| 72 | 69 | 74 | 79 | 20 | 61 | 72 | 65 | 20 | 64 | 65 | 66 |
| 69 | 6E | 65 | 64 | 3A | 2D | 20 | 64 | 69 | 73 | 70 | 6C |
| 61 | 79 | 20 | 6E | 6F | 72 | 6D | 61 | 6C | 20 | 70 | 72 |
| 69 | 6F | 72 | 69 | 74 | 79 | 20 | 74 | 65 | 78 | 74 | 20 |
| 61 | 6E | 64 | 2F | | | | | | | | |

TERMINAL RESPONSE: DISPLAY TEXT 3.1.1

Logically:

Command details

Command number:

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 21 | 80 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |] |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|---|
|----------|----|----|----|----|----|----|----|----|----|----|----|----|---|

27.22.4.1.3.5 Test requirement

The ME shall operate in the manner defined in expected sequence 3.1.

27.22.4.1.4 DISPLAY TEXT (Sustained text)

27.22.4.1.4.1 Definition and applicability

See clause 3.2.2.

27.22.4.1.4.2 Conformance requirement

The ME shall support the DISPLAY TEXT command as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.1, clause 6.6.1, clause 6.8, clause 6.11, clause 12.6, clause 12.15, clause 12.15.1, clause 12.15.2, clause 12.15.3 and clause 12.43.

27.22.4.1.4.3 Test purpose

To verify that the ME displays the text contained in the DISPLAY TEXT proactive SIM command, returns a successful result in the TERMINAL RESPONSE command send to the SIM and sustain the display beyond sending the TERMINAL response.

27.22.4.1.4.4 Method of test

27.22.4.1.4.4.1 Initial conditions

The ME is connected to the SIM Simulator and only connected to the System Simulator if the System Simulator is mentioned in the sequence table. The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

27.22.4.1.4.4.2 Procedure

Expected Sequence 4.1 (DISPLAY TEXT, sustained text, unpacked data 8 bits, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-----------------------------------|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: DISPLAY TEXT 4.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | [Normal priority, wait for user to clear |
| | | DISPLAY TEXT 4.1.1 | message, unpacked, 8 bit data] |
| 4 | $ME \rightarrow USER$ | Display "Toolkit Test 1" | |
| 6 | $ME \to SIM$ | TERMINAL RESPONSE: | [Command performed successfully] |
| | | DISPLAY TEXT 4.1.1 | |
| 7 | $SIM \to ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |
| 8 | $ME \rightarrow USER$ | Display of "Toolkit Test 1" shall | Text shall sustain until - a subsequent |
| | | sustain | proactive command is received containing |
| | | | display data. |

PROACTIVE COMMAND: DISPLAY TEXT 4.1.1

Logically:

Command details

Command number:

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text String

Data coding scheme: unpacked, 8 bit data
Text: "Toolkit Test 1"

Immediate Response

Coding:

| BER-TLV: | D0 | 1C | 81 | 03 | 01 | 21 | 80 | 82 | 02 | 81 | 02 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| _ | 0F | 04 | 54 | 6F | 6F | 6C | 6B | 69 | 74 | 20 | 54 | 65 |
| | 73 | 74 | 20 | 31 | AB | 00 | | | | | | |

TERMINAL RESPONSE: DISPLAY TEXT 4.1.1

Logically:

Command details

Command number:

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 21 | 80 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|-----------|----|----|----|------------|----|----|----|----|----|----|----|----|
| DLIX ILV. | 01 | 03 | 01 | ~ ! | 00 | 02 | 02 | 02 | 01 | 00 | 01 | 00 |

Expected Sequence 4.2 (DISPLAY TEXT, sustained text, clear message after delay, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-----------------------------|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: DISPLAY TEXT 4.2.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | [Clear message after a delay] |
| | | DISPLAY TEXT 4.2.1 | |
| 4 | $ME \rightarrow USER$ | Display "Toolkit Test 2" | |
| 5 | $ME \to SIM$ | TERMINAL RESPONSE: | [Command performed successfully] |
| | | DISPLAY TEXT 4.2.1 | |
| 6 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |
| 7 | $ME \rightarrow USER$ | Display "Toolkit Test 2" | Text shall sustain until - the expiration of a |
| | | | short delay. |

PROACTIVE COMMAND: DISPLAY TEXT 4.2.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, clear message after a delay

Device identities

Source device: SIM
Destination device: Display

Text String

Data coding scheme: unpacked, 8 bit data
Text: "Toolkit Test 2"

Immediate Response

Coding:

| BER-TLV: | D0 | 1C | 81 | 03 | 01 | 21 | 00 | 82 | 02 | 81 | 02 | 8D | |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|--|
| | 0F | 04 | 54 | 6F | 6F | 6C | 6B | 69 | 74 | 20 | 54 | 65 | |
| | 73 | 74 | 20 | 32 | AB | 00 | , | | | | | | |

TERMINAL RESPONSE: DISPLAY TEXT 4.2.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, clear message after a delay

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | l 81 | 03 | 01 | 21 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|------|----|----------|----|----|----|----|----|----|----|----------|----|
| D | | | . | | 00 | | V- | U_ | 01 | | . | |

Expected Sequence 4.3 (DISPLAY TEXT, sustained text, wait for user MMI to clear, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-----------------------------|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: DISPLAY TEXT 4.3.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | [wait for user to clear message] |
| | | DISPLAY TEXT 4.3.1 | |
| 4 | $ME \rightarrow USER$ | Display "Toolkit Test 3" | |
| 5 | $ME \to SIM$ | TERMINAL RESPONSE: | [Command performed successfully] |
| | | DISPLAY TEXT 4.3.1 | |
| 6 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |
| 7 | $ME \rightarrow USER$ | Display of "Toolkit Test 3" | Text shall sustain until - a user MMI action. |
| 8 | $USER \to ME$ | Clear message | |

PROACTIVE COMMAND: DISPLAY TEXT 4.3.1

Logically:

Command details

Command number:

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text String

Data coding scheme: unpacked, 8 bit data
Text: "Toolkit Test 3"

Immediate Response

Coding:

| BER-TLV: | D0 | 1C | 81 | 03 | 01 | 21 | 80 | 82 | 02 | 81 | 02 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0F | 04 | 54 | 6F | 6F | 6C | 6B | 69 | 74 | 20 | 54 | 65 |
| | 73 | 74 | 20 | 33 | AB | 00 | | | | | | |

TERMINAL RESPONSE: DISPLAY TEXT 4.3.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

| BER-TLV: | 81 | 03 | 01 | 21 | 80 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|

Expected Sequence 4.4 (DISPLAY TEXT, sustained text, wait for high priority event to clear, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-----------------------------|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: DISPLAY TEXT 4.4.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | [wait for user to clear message] |
| | | DISPLAY TEXT 4.4.1 | |
| 4 | $ME \rightarrow USER$ | Display "Toolkit Test 4" | |
| 5 | $ME \to SIM$ | TERMINAL RESPONSE: | [Command performed successfully] |
| | | DISPLAY TEXT 4.4.1 | |
| 6 | $SIM \to ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |
| 7 | $ME \rightarrow USER$ | Display of "Toolkit Test 4" | Text shall sustain until - a higher priority event |
| | | | occurs. |
| 8 | $SS \to ME$ | INCOMING MOBILE | |
| | | TERMINATED CALL | |

PROACTIVE COMMAND: DISPLAY TEXT 4.4.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text String

Data coding scheme: unpacked, 8 bit data
Text: "Toolkit Test 4"

Immediate Response

Coding:

| BER-TLV: | D0 | 1C | 81 | 03 | 01 | 21 | 80 | 82 | 02 | 81 | 02 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| · | 0F | 04 | 54 | 6F | 6F | 6C | 6B | 69 | 74 | 20 | 54 | 65 |
| | 73 | 74 | 20 | 34 | AB | 00 | | | | | | |

TERMINAL RESPONSE: DISPLAY TEXT 4.4.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

| BER-T | .V: | 81 | 03 | 01 | 21 | 80 | 82 | 02 | 82 | 81 | 83 | 01 | 00 | |
|-------|-----|----|----|----|----|----|----|----|----|----|----|----|----|--|
|-------|-----|----|----|----|----|----|----|----|----|----|----|----|----|--|

27.22.4.1.4.5 Test requirement

The ME shall operate in the manner defined in expected sequences 4.1 to 4.4.

27.22.4.1.5 DISPLAY TEXT (Display of icons)

27.22.4.1.5.1 Definition and applicability

See clause 3.2.2.

27.22.4.1.5.2 Conformance requirement

The ME shall support the DISPLAY TEXT command as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.1, clause 6.5.4, clause 6.6.1, clause 6.8, clause 6.11, clause 12.6, clause 12.15, clause 12.15.1, clause 12.15.2, clause 12.15.3 and clause 12.31.

27.22.4.1.5.3 Test purpose

To verify that the ME displays the icons which are referred to in the contents of the DISPLAY TEXT proactive SIM command, and returns a successful result in the TERMINAL RESPONSE command send to the SIM.

27.22.4.1.5.4 Method of test

27.22.4.1.5.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

The ME screen shall be in its normal stand-by display.

27.22.4.1.5.4.2 Procedure

Expected Sequence 5.1A (DISPLAY TEXT, display of basic icon, self-explanatory, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-----------------------------|----------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: DISPLAY TEXT 5.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | [BASIC-ICON, self-explanatory] |
| | | DISPLAY TEXT 5.1.1 | |
| 4 | $ME \rightarrow USER$ | Display the BASIC-ICON | |
| 5 | $USER \to ME$ | Clear Message | |
| 6 | $ME \to SIM$ | TERMINAL RESPONSE: | [Command performed successfully] |
| | | DISPLAY TEXT 5.1.1A | |

PROACTIVE COMMAND: DISPLAY TEXT 5.1.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text String

Data coding scheme: unpacked, 8 bit data
Text: "Basic Icon"

Icon Identifier:

 $\begin{array}{ll} \mbox{Icon qualifier:} & \mbox{icon is self-explanatory} \\ \mbox{Icon Identifier:} & \mbox{record 1 in } EF_{(IMG)} \\ \end{array}$

Coding:

| BER-TLV: | D0 | 1A | 81 | 03 | 01 | 21 | 80 | 82 | 02 | 81 | 02 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| _ | 0B | 04 | 42 | 61 | 73 | 69 | 63 | 20 | 49 | 63 | 6F | 6E |
| | 9E | 02 | 00 | 01 | | | | | | | | |

TERMINAL RESPONSE: DISPLAY TEXT 5.1.1A

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 21 80 82 02 82 81 83 01 00

Expected Sequence 5.1B (DISPLAY TEXT, display of basic icon, self-explanatory, requested icon could not be displayed)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-----------------------------------|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: DISPLAY TEXT 5.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | [BASIC-ICON, self-explanatory] |
| | | DISPLAY TEXT 5.1.1 | |
| 4 | $ME \rightarrow USER$ | Display "Basic Icon" without icon | |
| 5 | $USER \to ME$ | Clear Message | |
| 6 | $ME \to SIM$ | TERMINAL RESPONSE: | [Command performed successfully, but |
| | | DISPLAY TEXT 5.1.1B | requested icon could not be displayed] |

TERMINAL RESPONSE: DISPLAY TEXT 5.1.1B

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be displayed

| | | 00 | | | | 0.0 | | 0.0 | | 0.2 | | |
|----------|----|--------|------|------|------|-----|---------|------|------|------|-------|------|
| | 01 | 1 11/2 | Ι Λ1 | 1 21 | PΩΛ | | 1 (1/2) | | 1 01 | 02 | l ()1 | ()4 |
| BER-TLV: | | บอ | 1 01 | 1 21 | I OU | OZ. | 1 02 | 1 02 | | 1 00 | 1 01 | 1 04 |

Expected Sequence 5.2A (DISPLAY TEXT, display of colour icon, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-----------------------------|----------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: DISPLAY TEXT 5.2.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | [COLOUR-ICON] |
| | | DISPLAY TEXT 5.2.1 | |
| 4 | $ME \rightarrow USER$ | Display the COLOUR-ICON | |
| 5 | $USER \to ME$ | Clear Message | |
| 6 | $ME \to SIM$ | TERMINAL RESPONSE: | [Command performed successfully] |
| | | DISPLAY TEXT 5.2.1A | |

PROACTIVE COMMAND: DISPLAY TEXT 5.2.1

Logically:

Command details

Command number:

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text String

Data coding scheme: unpacked, 8 bit data
Text: "Colour Icon"

Icon Identifier:

Icon qualifier: icon is self-explanatory Icon Identifier: record 2 in $EF_{(IMG)}$

Coding:

| BER-TLV: | D0 | 1B | 81 | 03 | 01 | 21 | 80 | 82 | 02 | 81 | 02 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0C | 04 | 43 | 6F | 6C | 6F | 75 | 72 | 20 | 49 | 63 | 6F |
| | 6E | 9E | 02 | 00 | 02 | | | | | | | |

TERMINAL RESPONSE: DISPLAY TEXT 5.2.1A

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Expected Sequence 5.2B (DISPLAY TEXT, display of colour icon, requested icon could not be displayed)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-----------------------------------|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: DISPLAY TEXT 5.2.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | [COLOUR-ICON] |
| | | DISPLAY TEXT 5.2.1 | |
| 4 | $ME \rightarrow USER$ | Display "Colour Icon" without the | |
| | | icon | |
| 5 | $USER \to ME$ | Clear Message | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: | [Command performed successfully, but |
| | | | requested icon could not be displayed] |
| | | | |

TERMINAL RESPONSE: DISPLAY TEXT 5.2.1B

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be displayed

Coding:

| BER-TLV: | 81 | 03 | 01 | 21 | 80 | 82 | 02 | 82 | 81 | 83 | 01 | 04 | |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|--|
|----------|----|----|----|----|----|----|----|----|----|----|----|----|--|

Expected Sequence 5.3A (DISPLAY TEXT, display of basic icon, not self explanatory, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-----------------------------|------------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: DISPLAY TEXT 5.3.1 | |
| 2 | $ME \to SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | [BASIC-ICON, not self-explanatory] |
| | | DISPLAY TEXT 5.3.1 | |
| 4 | $ME \rightarrow USER$ | Display the BASIC-ICON | |
| | | And | |
| | | Display "Basic Icon" | |
| 5 | $USER \rightarrow ME$ | Clear Message | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: | [Command performed successfully] |
| | | DISPLAY TEXT 5.3.1A | |
| | | | |
| 7 | $SIM \to ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |

PROACTIVE COMMAND: DISPLAY TEXT 5.3.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text String

Data coding scheme: unpacked, 8 bit data
Text: "Basic Icon"

Icon Identifier:

Icon qualifier: icon is not self-explanatory

Icon Identifier: record 1 in $EF_{(IMG)}$

Coding:

| BER-TLV: | D0 | 1A | 81 | 03 | 01 | 21 | 80 | 82 | 02 | 81 | 02 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0B | 04 | 42 | 61 | 73 | 69 | 63 | 20 | 49 | 63 | 6F | 6E |
| | 9E | 02 | 01 | 01 | | | | | | | | |

TERMINAL RESPONSE: DISPLAY TEXT 5.3.1A

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 21 | 80 | 82 | 02 | 82 | 81 | 83 | 01 | 00 | |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|--|
|----------|----|----|----|----|----|----|----|----|----|----|----|----|--|

Expected Sequence 5.3B (DISPLAY TEXT, display of basic icon, not self explanatory, requested icon could not be displayed)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|----------------------------------|--|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: DISPLAY TEXT 5.3.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | [BASIC-ICON, not self-explanatory] |
| | | DISPLAY TEXT 5.3.1 | |
| 4 | $ME \rightarrow USER$ | Display "Basic Icon" without the | |
| | | icon | |
| 5 | $USER \to ME$ | Clear Message | |
| 6 | $ME \to SIM$ | TERMINAL RESPONSE: | [Command performed successfully, but |
| | | DISPLAY TEXT 5.3.1B | requested icon could not be displayed] |
| | | | |
| | | | |
| 7 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |

TERMINAL RESPONSE: DISPLAY TEXT 5.3.1B

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be displayed

Coding:

| | BER-TLV: | 81 | 03 | 01 | 21 | 80 | 82 | 02 | 82 | 81 | 83 | 01 | 04 |
|--|----------|----|----|----|----|----|----|----|----|----|----|----|----|
|--|----------|----|----|----|----|----|----|----|----|----|----|----|----|

27.22.4.1.5.5 Test requirement

The ME shall operate in the manner defined in expected sequences 5.1A to 5.3B.

27.22.4.1.6 DISPLAY TEXT (UCS2 display supported)

27.22.4.1.6.1 Definition and applicability

See clause 3.2.2.

27.22.4.1.6.2 Conformance requirement

The ME shall support the DISPLAY TEXT command as defined in the following technical specifications:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.1, clause 6.5.4, clause 6.6.1, clause 6.8, clause 6.11, clause 12.6, clause 12.15, clause 12.15.1, clause 12.15.2, clause 12.15.3 and clause 12.31.

The ME shall support the UCS2 alphabet for the coding of the Cyrillic alphabet, as defined in the following technical specification: ISO/IEC 10646 [17].

27.22.4.1.6.3 Test purpose

To verify that the ME displays the text contained in the DISPLAY TEXT proactive SIM command, and returns a successful result in the TERMINAL RESPONSE command send to the SIM.

27.22.4.1.6.4 Method of test

27.22.4.1.6.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

27.22.4.1.6.4.2 Procedure

Expected Sequence 6.1 (DISPLAY TEXT, UCS2 coded)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|-----------------------------|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: DISPLAY TEXT 6.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | [Normal priority, wait for user to clear |
| | | DISPLAY TEXT 6.1.1 | message, UCS2 coded] |
| 4 | $ME \to USER$ | | ["Hello" in Russian] |
| | | Display " ЗДРАВСТВУЙТЕ " | |
| 5 | $USER \to ME$ | Clear message | |
| 6 | $ME \to SIM$ | TERMINAL RESPONSE: | |
| | | DISPLAY TEXT 6.1.1 | |

PROACTIVE COMMAND: DISPLAY TEXT 6.1.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text String

Data coding scheme: UCS2 (16bit)

Text: "ЗДРАВСТВУЙТЕ"

Coding:

| BER-TLV: | D0 | 24 | 81 | 03 | 01 | 21 | 80 | 82 | 02 | 81 | 02 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 19 | 08 | 04 | 17 | 04 | 14 | 04 | 20 | 04 | 10 | 04 | 12 |
| | 04 | 21 | 04 | 22 | 04 | 12 | 04 | 23 | 04 | 19 | 04 | 22 |
| | 04 | 15 | | | | | | | | | | |

TERMINAL RESPONSE: DISPLAY TEXT 6.1.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

27.22.4.1.6.5 Test requirement

The ME shall operate in the manner defined in expected sequence 6.1.

27.22.4.2 GET INKEY

27.22.4.2.1 GET INKEY(normal)

27.22.4.2.1.1 Definition and applicability

See clause 3.2.2.

27.22.4.2.1.2 Conformance Requirement

The ME shall support the GET INKEY command as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.2, clause 6.6.2, clause 6.8, clause 6.11, clause 12.6, clause 12.15, clause 12.15.1, clause 12.15.2 and clause 12.15.3.

27.22.4.2.1.3 Test purpose

To verify that the ME displays the text contained in the GET INKEY proactive SIM command, and returns the single character entered in the TERMINAL RESPONSE command sent to the SIM.

27.22.4.2.1.4 Method of test

27.22.4.2.1.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be set to a display other than the idle display.

27.22.4.2.1.4.2 Procedure

Expected Sequence 1.1 (GET INKEY, digits only for character, Unpacked 8 bit data for Text String, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--------------------------|---------------------------------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INKEY 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: GET | [digits only, no help info available] |
| | | INKEY 1.1.1 | |
| 4 | $ME \rightarrow USER$ | Display "Enter "+"" | |
| | | | Text string coding in unpacked format |
| 5 | $USER \to ME$ | Enter the input "+" and | |
| | | completion | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: GET | [command performed successfully] |
| | | INKEY 1.1.1 | |

PROACTIVE COMMAND: GET INKEY 1.1.1

Logically:

Command details

Command number:

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: SIM
Destination device: ME

Text String

Data coding scheme: unpacked, 8 bit data Text: "Enter "+" "

Coding:

| BER-TLV: | D0 | 15 | 81 | 03 | 01 | 22 | 00 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0A | 04 | 45 | 6E | 74 | 65 | 72 | 20 | 22 | 2B | 22 | |

TERMINAL RESPONSE: GET INKEY 1.1.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text String

Data coding scheme: unpacked, 8 bit data

Text: "+"

Coding:

| BER-TLV: | 81 | 03 | 01 | 22 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 02 | 04 | 2B | | | | | | | | |

Expected Sequence 1.2 (GET INKEY, digits only for character set, SMS default Alphabet for Text String, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--------------------------|---------------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INKEY 1.2.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: GET | [digits only, no help info available] |
| | | INKEY 1.2.1 | |
| 4 | $ME \rightarrow USER$ | Display "Enter "0"" | |
| | | | Text string coding in packed format |
| 5 | $USER \to ME$ | Enter the input "0" and | |
| | | completion | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: | [command performed successfully] |
| | | GET INKEY 1.2.1 | |

PROACTIVE COMMAND: GET INKEY 1.2.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: SIM
Destination device: ME

Text String

Data coding scheme: SMS default alphabet

Text: "Enter "0""

Coding:

| BER-TLV: | D0 | 14 | 81 | 03 | 01 | 22 | 00 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 09 | 00 | 45 | 37 | BD | 2C | 07 | 89 | 60 | 22 | | |

TERMINAL RESPONSE: GET INKEY 1.2.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text String

Data coding scheme: unpacked, 8 bit data

Text: "0"

Coding:

| BER-TLV: | 81 | 03 | 01 | 22 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 02 | 04 | 30 | | | | | | | | |

Expected Sequence 1.3 (GET INKEY, backward move)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INKEY 1.3.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: GET | [digits only, no help information available] |
| | | INKEY 1.3.1 | |
| 4 | $ME \rightarrow USER$ | Display " <go-backwards>"</go-backwards> | |
| | | | Text string coding in unpacked format |
| 5 | $USER \to ME$ | Backwards move MMI action | |
| 6 | $ME \rightarrow SIM$ | | [backward move in the proactive SIM session |
| | | INKEY 1.3.1 | requested by the user] |

PROACTIVE COMMAND: GET INKEY 1.3.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: SIM
Destination device: ME

Text String

Data coding scheme: unpacked, 8 bit data
Text: "<GO-BACKWARDS>"

| BER-TLV: | D0 | 1A | 81 | 03 | 01 | 22 | 00 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| _ | 0F | 04 | 3C | 47 | 4F | 2D | 42 | 41 | 43 | 4B | 57 | 41 |
| | 52 | 44 | 53 | 3E | | | | | | | | |

TERMINAL RESPONSE: GET INKEY 1.3.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: backward move in the proactive SIM session requested by the user

Coding:

| | BE | R-TLV: | 81 | 03 | 01 | 22 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 11 |
|--|----|--------|----|----|----|----|----|----|----|----|----|----|----|----|
|--|----|--------|----|----|----|----|----|----|----|----|----|----|----|----|

Expected Sequence 1.4 (GET INKEY, abort)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-----------------------------|--|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INKEY 1.4.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: GET | [digits only, no help information available] |
| | | INKEY 1.4.1 | |
| 4 | $ME \rightarrow USER$ | Display " <abort>"</abort> | Text string coding in unpacked format |
| 5 | $USER \to ME$ | Terminate the Proactive SIM | |
| | | session MMI action | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: GET | [Proactive SIM session terminated by the |
| | | INKEY 1.4.1 | user] |

PROACTIVE COMMAND: GET INKEY 1.4.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: SIM
Destination device: ME

Text String

Data coding scheme: unpacked, 8 bit data
Text: "<ABORT>"

Coding:

| BER-TLV: | D0 | 13 | 81 | 03 | 01 | 22 | 00 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 80 | 04 | 3C | 41 | 42 | 4F | 52 | 54 | 3E | | | |

TERMINAL RESPONSE: GET INKEY 1.4.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Proactive SIM session terminated by the user

Coding:

| BER-TLV: 81 | 03 01 | 22 00 | 82 02 | 82 8 | 81 83 | 01 | 10 |
|-------------|-------|-------|-------|------|-------|----|----|
|-------------|-------|-------|-------|------|-------|----|----|

Expected Sequence 1.5 (GET INKEY, SMS default alphabet for character set, Unpacked 8 bit data for Text String, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--------------------------|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INKEY 1.5.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: GET | [characters from SMS default alphabet, no |
| | | INKEY 1.5.1 | help info available] |
| 4 | $ME \rightarrow USER$ | Display "Enter "q"" | Text string coding in unpacked format |
| 5 | $USER \to ME$ | Enter the input "q" and | |
| | | completion | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: GET | [command performed successfully] |
| | | INKEY 1.5.1 | |

PROACTIVE COMMAND: GET INKEY 1.5.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: SMS default alphabet, no help information available

Device identities

Source device: SIM
Destination device: ME

Text String

Data coding scheme: unpacked, 8 bit data

Text: "Enter "q""

Coding:

| BER-TLV: | D0 | 15 | 81 | 03 | 01 | 22 | 01 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0A | 04 | 45 | 6E | 74 | 65 | 72 | 20 | 22 | 71 | 22 | |

TERMINAL RESPONSE: GET INKEY 1.5.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: SMS default alphabet, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text String

Data coding scheme: unpacked, 8 bit data

Text: "q"

Coding:

| BER-TLV: | 81 | 03 | 01 | 22 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 02 | 04 | 71 | | | | | | | | |

Expected Sequence 1.6 (GET INKEY, Max length for the Text String, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-----------------------------------|---------------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INKEY 1.6.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: GET | [digits only, no help info available] |
| | | INKEY 1.6.1 | |
| 4 | $ME \rightarrow USER$ | Display "Enter "x". This | |
| | | command instructs the ME to | 160 characters Text string coding in |
| | | display text, and to expect the | unpacked format |
| | | user to enter a single character. | |
| | | Any response entered by the | |
| | | user shall be passed t" | |
| 5 | $USER \to ME$ | Enter the input "x" and | |
| | | completion | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: GET | [command performed successfully] |
| | | INKEY 1.6.1 | |

PROACTIVE COMMAND: GET INKEY 1.6.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: SMS default alphabet, no help information available

Device identities

Source device: SIM
Destination device: ME

Text String

Data coding scheme: unpacked, 8 bit data

Text: "Enter "x". This command instructs the ME to display text, and to expect the user to

enter a single character. Any response entered by the user shall be passed t"

| BER-TLV: | D0 | 81 | AD | 81 | 03 | 01 | 22 | 01 | 82 | 02 | 81 | 82 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 81 | A1 | 04 | 45 | 6E | 74 | 65 | 72 | 20 | 22 | 78 |
| | 22 | 2E | 20 | 54 | 68 | 69 | 73 | 20 | 63 | 6F | 6D | 6D |
| | 61 | 6E | 64 | 20 | 69 | 6E | 73 | 74 | 72 | 75 | 63 | 74 |
| | 73 | 20 | 74 | 68 | 65 | 20 | 4D | 45 | 20 | 74 | 6F | 20 |
| | 64 | 69 | 73 | 70 | 6C | 61 | 79 | 20 | 74 | 65 | 78 | 74 |
| | 2C | 20 | 61 | 6E | 64 | 20 | 74 | 6F | 20 | 65 | 78 | 70 |
| | 65 | 63 | 74 | 20 | 74 | 68 | 65 | 20 | 75 | 73 | 65 | 72 |
| | 20 | 74 | 6F | 20 | 65 | 6E | 74 | 65 | 72 | 20 | 61 | 20 |
| | 73 | 69 | 6E | 67 | 6C | 65 | 20 | 63 | 68 | 61 | 72 | 61 |
| | 63 | 74 | 65 | 72 | 2E | 20 | 41 | 6E | 79 | 20 | 72 | 65 |
| | 73 | 70 | 6F | 6E | 73 | 65 | 20 | 65 | 6E | 74 | 65 | 72 |
| | 65 | 64 | 20 | 62 | 79 | 20 | 74 | 68 | 65 | 20 | 75 | 73 |
| | 65 | 72 | 20 | 73 | 68 | 61 | 6C | 6C | 20 | 62 | 65 | 20 |
| | 70 | 61 | 73 | 73 | 65 | 64 | 20 | 74 | | | | |

TERMINAL RESPONSE: GET INKEY 1.6.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: SMS default alphabet, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text String

Data coding scheme: unpacked, 8 bit data

Text: "x'

Coding:

| BER-TLV: | 81 | 03 | 01 | 22 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 02 | 04 | 78 | | | | | | | | |

27.22.4.2.1.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.6.

27.22.4.2.2 GET INKEY (No response from User)

27.22.4.2.2.1 Definition and applicability

See clause 3.2.2.

27.22.4.2.2.2 Conformance requirement

The ME shall support the GET INKEY command as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.2, clause 6.6.2, clause 6.8, clause 6.11, clause 12.6, clause 12.15, clause 12.15.1, clause 12.15.2 and clause 12.15.3.

27.22.4.2.2.3 Test purpose

To verify that the ME displays the text contained in the GET INKEY proactive SIM command, and returns a "No response from user" result value in the TERMINAL RESPONSE command send to the SIM.

27.22.4.2.2.4 Method of test

27.22.4.2.2.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

ME Manufacturers shall set the "no response from user" period of time.

The SIM simulator shall be set to that period of time.

27.22.4.2.2.4.2 Procedure

Expected Sequence 2.1 (GET INKEY, no response from the user)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|----------------------------------|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INKEY 2.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: GET | [digits only, no help information available] |
| | | INKEY 2.1.1 | |
| 4 | $ME \rightarrow USER$ | Display " <time-out>"</time-out> | Text string coding in unpacked format |
| 5 | USER | Waiting and no completion | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: GET | [No response from user] within 5 s after the |
| | | INKEY 2.1.1 | end of that defined period of time |
| 7 | USER | Check the delay of TERMINAL | |
| | | RESPONSE is reasonable or not | |

PROACTIVE COMMAND: GET INKEY 2.1.1

Logically:

Command details

Command number:

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: SIM
Destination device: ME

Text String

Data coding scheme: unpacked, 8 bit data

Text: "<TIME-OUT>"

Coding:

| BER-TLV: | D0 | 16 | 81 | 03 | 01 | 22 | 00 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0B | 04 | 3C | 54 | 49 | 4D | 45 | 2D | 4F | 55 | 54 | 3E |

TERMINAL RESPONSE: GET INKEY 2.1.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: No response from user

Coding:

| BER-TLV: | 81 | 03 | 01 | 22 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 12 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|

27.22.4.2.2.5 Test requirement

The ME shall operate in the manner defined in expected sequence 2.1.

27.22.4.2.3 GET INKEY (UCS2 format display)

27.22.4.2.3.1 Definition and applicability

See clause 3.2.2.

27.22.4.2.3.2 Conformance requirement

The ME shall support the GET INKEY command as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.2, clause 6.6.2, clause 6.8, clause 6.11, clause 12.6, clause 12.15, clause 12.15.1, clause 12.15.2 and clause 12.15.3.

Additionally, the ME shall support the UCS2 facility for the coding of the Cyrillic alphabet, as defined in the following technical specifications: ISO/IEC 10646 [17].

27.22.4.2.3.3 Test purpose

To verify that the ME displays the text contained in the GET INKEY proactive SIM command, and returns the text string entered in the TERMINAL RESPONSE command sent to the SIM.

27.22.4.2.3.4 Method of test

27.22.4.2.3.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

27.22.4.2.3.4.2 Procedure

Expected Sequence 3.1 (GET INKEY, Text String coding in UCS2 Alphabet, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--------------------------|--|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INKEY 3.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: GET | [Digits only, no help information available] |
| | | INKEY 3.1.1 | |
| 4 | $ME \rightarrow USER$ | Display " ЗДРАВСТВУЙТЕ " | Text string "Hello" in Russian coding in 16 bits |
| | | | UCS2 alphabet format |
| 5 | $USER \to ME$ | Enter the input "+" and | |
| | | completion | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: GET | [command performed successfully] |
| | | INKEY 3.1.1 | |

PROACTIVE COMMAND: GET INKEY 3.1.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: SIM
Destination device: ME

Text String

Data coding scheme: 16 bit data UCS2 alphabet format

Техt: "ЗДРАВСТВУЙТЕ "

Coding:

| BER-TLV: | D0 | 24 | 81 | 03 | 01 | 22 | 00 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 19 | 80 | 04 | 17 | 04 | 14 | 04 | 20 | 04 | 10 | 04 | 12 |
| | 04 | 21 | 04 | 22 | 04 | 12 | 04 | 23 | 04 | 19 | 04 | 22 |
| | 04 | 15 | | | | | | | | | | |

TERMINAL RESPONSE: GET INKEY 3.1.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text String:

Data coding scheme: unpacked, 8 bit data

Text: "+"

Coding:

| BER-TLV: | 81 | 03 | 01 | 22 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 02 | 04 | 2B | | | | | | | | |

Expected Sequence 3.2 (GET INKEY, max length for the Text String coding in UCS2 Alphabet, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--------------------------|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INKEY 3.2.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: GET | [digits only, no help information available] |
| | | INKEY 3.2.1 | |
| 4 | $ME \rightarrow USER$ | Display | |
| | | "ЗДРАВСТВУЙТЕЗДРАВСТВУ | Text string length 70 characters, coding in 16 |
| | | | bits UCS2 alphabet format |
| | | ВУЙТЕЗДРАВСТВУЙТЕЗДРАВ | |
| | | СТВУЙ" | |
| 5 | $USER \to ME$ | Enter the input "+" and | |
| | | completion | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: GET | [command performed successfully] |
| | | INKEY 3.2.1 | |

PROACTIVE COMMAND: GET INKEY 3.2.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: SIM

Destination device: ME

Text String

Data coding scheme:16 bit data UCS2 alphabet formatText:"ЗДРАВСТВУЙТЕЗДРАВСТВУЙТЕ

ЗДРАВСТВУЙТЕЗДРАВСТВУЙТЕ ЗДРАВСТВУЙТЕЗДРАВСТВУЙ"

Coding:

| BER-TLV: | D0 | 81 | 99 | 81 | 03 | 01 | 22 | 00 | 82 | 02 | 81 | 82 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 81 | 8D | 08 | 04 | 17 | 04 | 14 | 04 | 20 | 04 | 10 |
| | 04 | 12 | 04 | 21 | 04 | 22 | 04 | 12 | 04 | 23 | 04 | 19 |
| | 04 | 22 | 04 | 15 | 04 | 17 | 04 | 14 | 04 | 20 | 04 | 10 |
| | 04 | 12 | 04 | 21 | 04 | 22 | 04 | 12 | 04 | 23 | 04 | 19 |
| | 04 | 22 | 04 | 15 | 04 | 17 | 04 | 14 | 04 | 20 | 04 | 10 |
| | 04 | 12 | 04 | 21 | 04 | 22 | 04 | 12 | 04 | 23 | 04 | 19 |
| | 04 | 22 | 04 | 15 | 04 | 17 | 04 | 14 | 04 | 20 | 04 | 10 |
| | 04 | 12 | 04 | 21 | 04 | 22 | 04 | 12 | 04 | 23 | 04 | 19 |
| | 04 | 22 | 04 | 15 | 04 | 17 | 04 | 14 | 04 | 20 | 04 | 10 |
| | 04 | 12 | 04 | 21 | 04 | 22 | 04 | 12 | 04 | 23 | 04 | 19 |
| | 04 | 22 | 04 | 15 | 04 | 17 | 04 | 14 | 04 | 20 | 04 | 10 |
| | 04 | 12 | 04 | 21 | 04 | 22 | 04 | 12 | 04 | 23 | 04 | 19 |

TERMINAL RESPONSE: GET INKEY 3.2.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text String:

Data coding scheme: unpacked, 8 bit data

Text: "+"

Coding:

| BER-TLV: | 81 | 03 | 01 | 22 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 02 | 04 | 2B | | | | | | | | |

27.22.4.2.3.5 Test requirement

The ME shall operate in the manner defined in expected sequence 3.1 to 3.2.

27.22.4.2.4 GET INKEY (UCS2 format of entry)

27.22.4.2.4.1 Definition and applicability

See clause 3.2.2.

27.22.4.2.4.2 Conformance requirement

The ME shall support the GET INKEY command as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.2, clause 6.6.2, clause 6.8, clause 6.11, clause 12.6, clause 12.15, clause 12.15.1, clause 12.15.2 and clause 12.15.3.

Additionally, the ME shall support the UCS2 facility for the coding of the Cyrillic alphabet, as defined in the following technical specifications: ISO/IEC 10646 [17].

27.22.4.2.4.3 Test purpose

To verify that the ME displays the text contained in the GET INKEY proactive SIM command, and returns the text string entered in the TERMINAL RESPONSE command sent to the SIM.

27.22.4.2.4.4 Method of test

27.22.4.2.4.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

27.22.4.2.4.4.2 Procedure

Expected Sequence 4.1 (GET INKEY, characters from UCS2 alphabet, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--------------------------|--|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INKEY 4.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: GET | [characters from UCS2 alphabet, no help |
| | | INKEY 4.1.1 | information available] |
| 4 | $ME \rightarrow USER$ | Display "Enter" | Text string coding in unpacked format |
| 5 | $USER \to ME$ | Enter the input "Д" | Russian character, coding in UCS2 format |
| | | and completion | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: GET | [command performed successfully] |
| | | INKEY 4.1.1 | |

PROACTIVE COMMAND: GET INKEY 4.1.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: characters from UCS2 alphabet, no help information available

Device identities

Source device: SIM
Destination device: ME

Text String

Data coding scheme: unpacked, 8 bit data

Text: "Enter"

| BER-TLV: | D0 | 11 | 81 | 03 | 01 | 22 | 03 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 06 | 04 | 45 | 6F | 74 | 65 | 72 | | | | | |

TERMINAL RESPONSE: GET INKEY 4.1.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: characters from UCS2 alphabet, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text String:

Data coding scheme: 16 bit data UCS2 alphabet format

Text: "Д

Coding:

| BER-TLV: | 81 | 03 | 01 | 22 | 03 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| _ | 8D | 03 | 08 | 04 | 14 | | | | | | | |

27.22.4.2.4.5 Test requirement

The ME shall operate in the manner defined in expected sequence 4.1.

27.22.4.2.5 GET INKEY ("Yes/No" Response)

27.22.4.2.5.1 Definition and applicability

See clause 3.2.2.

27.22.4.2.5.2 Conformance requirement

The ME shall support the GET INKEY command as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.2, clause 6.6.2, clause 6.8, clause 6.11, clause 12.6, clause 12.15, clause 12.15.1, clause 12.15.2 and clause 12.15.3.

27.22.4.2.5.3 Test purpose

To verify that the ME displays the text contained in the GET INKEY proactive SIM command, and returns the text string entered in the TERMINAL RESPONSE command sent to the SIM.

27.22.4.2.5.4 Method of test

27.22.4.2.5.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

27.22.4.2.5.4.2 Procedure

Expected Sequence 5.1(GET INKEY, "Yes/No" Response for the input, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-----------------------------|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INKEY 5.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: GET | ["Yes/No" Response, no help information |
| | | INKEY 5.1.1 | available] |
| 4 | $ME \rightarrow USER$ | Display "Enter YES " | Text string coding in unpacked format |
| 5 | $USER \to ME$ | Choice "Yes" and Completion | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: GET | [command performed successfully] |
| | | INKEY 5.1.1 | Check if it is in accordance with the user |
| | | | choice (value '01' in the Text String data |
| | | | object) |
| 7 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INKEY 5.1.2 | |
| 8 | $ME \rightarrow SIM$ | FETCH | |
| 9 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: GET | ["Yes/No" Response, no help information |
| | | INKEY 5.1.2 | available] |
| 10 | $ME \rightarrow USER$ | Display "Enter NO:" | Text string coding in unpacked format |
| 11 | $USER \to ME$ | Choice "No" and Completion | |
| 12 | $ME \to SIM$ | TERMINAL RESPONSE: GET | [command performed successfully] |
| | | INKEY 5.1.2 | Check if it is in accordance with the user |
| | | | choice (value '00' in the Text String data |
| | | | object) |

PROACTIVE COMMAND: GET INKEY 5.1.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: "Yes/No" Response, no help information available

Device identities

Source device: SIM
Destination device: ME

Text String

Data coding scheme: unpacked, 8 bit data
Text: "Enter YES"

Coding:

| BER-TLV: | D0 | 15 | 81 | 03 | 01 | 22 | 04 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0A | 04 | 45 | 6E | 74 | 65 | 72 | 20 | 59 | 45 | 53 | |

TERMINAL RESPONSE: GET INKEY 5.1.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: "Yes/No" Response, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text String:

Data coding scheme: unpacked, 8 bit data

Text: 01 (hex)

Coding:

| BER-TLV: | 81 | 03 | 01 | 22 | 04 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 02 | 04 | 01 | | | | | | | | |

PROACTIVE COMMAND: GET INKEY 5.1.2:

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: "Yes/No" Response, no help information available

Device identities

Source device: SIM
Destination device: ME

Text String

Data coding scheme: unpacked, 8 bit data

Text: "Enter NO"

Coding:

| BER-TLV: | D0 | 14 | 81 | 03 | 01 | 22 | 04 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 09 | 04 | 45 | 6E | 74 | 65 | 72 | 20 | 4E | 4F | | |

TERMINAL RESPONSE: GET INKEY 5.1.2

Logically:

Command details

Command number:

Command type: GET INKEY

Command qualifier: "Yes/No" Response, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text String:

Data coding scheme: unpacked, 8 bit data

Text: 00 (hex)

Coding:

| BER-TLV: | 81 | 03 | 01 | 22 | 04 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| _ | 8D | 02 | 04 | 00 | | | | | | | | |

27.22.4.2.5.5 Test requirement

The ME shall operate in the manner defined in expected sequence 5.1.

27.22.4.2.6 GET INKEY (display of Icon)

27.22.4.2.6.1 Definition and applicability

See clause 3.2.2.

27.22.4.2.6.2 Conformance requirement

The ME shall support the GET INKEY command as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.2, clause 6.5.4, clause 6.6.2, clause 6.8, clause 6.11, clause 12.6, clause 12.15, clause 12.15.1, clause 12.15.2, clause 12.15.3 and clause 12.31.

27.22.4.2.6.3 Test purpose

To verify that the ME displays the Icon contained in the GET INKEY proactive SIM command, and returns the text string entered in the TERMINAL RESPONSE command sent to the SIM.

27.22.4.2.6.4 Method of test

27.22.4.2.6.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

The ME screen shall be in its normal stand-by display.

27.22.4.2.6.4.2 Procedure

Expected Sequence 6.1A (GET INKEY, Basic icon, self-explanatory, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--------------------------------|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INKEY 6.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: GET | [BASIC-ICON self-explanatory for the Text |
| | | INKEY 6.1.1 | string] |
| 4 | $ME \rightarrow USER$ | Display the BASIC-ICON for the | Text string coding in unpacked format |
| | | prompt | |
| 5 | $USER \to ME$ | Enter "+" and completion | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: GET | Command performed successfully] |
| | | INKEY 6.1.1A | |
| | | | |

PROACTIVE COMMAND: GET INKEY 6.1.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: SIM
Destination device: ME

Text String

Data coding scheme: unpacked, 8 bit data
Text: "<NO-ICON>"

Icon Identifier

Icon qualifier: self-explanatory

Icon identifier: 1 (number of record in EF_{Img})

| BER-TLV: | D0 | 19 | 81 | 03 | 01 | 22 | 00 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| _ | 0A | 04 | 3C | 4E | 4F | 2D | 49 | 43 | 4F | 4E | 3E | 1E |
| | 02 | 00 | 01 | | | | | | | | | |

TERMINAL RESPONSE: GET INKEY 6.1.1A

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text String

Data coding scheme: unpacked, 8 bit data

Text: "+"

Coding:

| BER-TLV: | 81 | 03 | 01 | 22 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 02 | 04 | 2B | | | | | | | | |

Expected Sequence 6.1B (GET INKEY, Basic icon, self-explanatory, requested icon could not be displayed)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INKEY 6.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: GET | [BASIC-ICON self-explanatory for the Text |
| | | INKEY 6.1.1 | string] |
| 4 | $ME \rightarrow USER$ | Display " <no-icon>" for the</no-icon> | Text string coding in unpacked format |
| | | prompt without the icon | |
| 5 | $USER \rightarrow ME$ | Enter "+" and completion | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: GET | [Command performed successfully, but |
| | | INKEY 6.1.1B | requested icon could not be displayed] |

TERMINAL RESPONSE: GET INKEY 6.1.1B

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully but requested icon could not be displayed

Text String:

Data coding scheme: unpacked, 8 bit data

Text: "+"

| BER-TLV: | 81 | 03 | 01 | 22 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 04 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 02 | 04 | 2B | | | | | | | | |

Expected Sequence 6.2A (GET INKEY, Basic icon, non self-explanatory, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INKEY 6.2.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: GET | [BASIC-ICON non self-explanatory for the |
| | | INKEY 6.2.1 | Text string] |
| 4 | $ME \rightarrow USER$ | Display " <basic-icon>" and</basic-icon> | Text string coding in unpacked format |
| | | Display the BASIC-ICON for the | |
| | | prompt | |
| 5 | $USER \to ME$ | Enter the input "+" and | |
| | | completion | |
| 6 | $ME \rightarrow SIM$ | | [Command performed successfully] |
| | | INKEY 6.2.1A | |

PROACTIVE COMMAND: GET INKEY 6.2.1

Logically:

Command details

Command number:

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: SIM
Destination device: ME

Text String

Data coding scheme: unpacked, 8 bit data
Text: "<BASIC-ICON>"

Icon Identifier

Icon qualifier: not self-explanatory

Icon identifier: 1 (number of record in EF_{Img})

Coding:

| BER-TLV: | D0 | 1C | 81 | 03 | 01 | 22 | 00 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0D | 04 | 3C | 42 | 41 | 53 | 49 | 43 | 2D | 49 | 43 | 4F |
| | 4E | 3E | 1E | 02 | 01 | 01 | | | | | | |

TERMINAL RESPONSE: GET INKEY 6.2.1A

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text String:

Data coding scheme: unpacked, 8 bit data

Text: "+"

| BER-TLV: | 81 | 03 | 01 | 22 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 02 | 04 | 2B | | | | | | | | |

Expected Sequence 6.2B (GET INKEY, Basic icon, non self-explanatory, requested icon could not be displayed)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INKEY 6.2.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: GET | [BASIC-ICON non self-explanatory for the |
| | | INKEY 6.2.1 | Text string] |
| 4 | $ME \rightarrow USER$ | Display " <basic-icon>" for the</basic-icon> | Text string coding in unpacked format |
| | | prompt without the icon | |
| 5 | $USER \to ME$ | Enter the input "+" and | |
| | | completion | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: GET | [Command performed successfully, but |
| | | INKEY 6.2.1B | requested icon could not be displayed] |

TERMINAL RESPONSE: GET INKEY 6.2.1B

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully but requested icon could not be displayed

Text String:

Data coding scheme: unpacked, 8 bit data

Text: "+"

Coding:

| | BER-TLV: | 81 | 03 | 01 | 22 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 04 |
|---|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| I | | 8D | 02 | 04 | 2B | | | | | | | | |

Expected Sequence 6.3A (GET INKEY, Colour icon, self-explanatory, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-----------------------------|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INKEY 6.3.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: GET | [COLOUR-ICON self-explanatory for the Text |
| | | INKEY 6.3.1 | string] |
| 4 | $ME \rightarrow USER$ | Display the COLOUR-ICON for | Text string coding in unpacked format |
| | | the prompt | |
| 5 | $USER \to ME$ | Enter the input "+" and | |
| | | completion | |
| 6 | | | [Command performed successfully] |
| | | INKEY 6.3.1A | |

PROACTIVE COMMAND: GET INKEY 6.3.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: SIM
Destination device: ME

Text String

Data coding scheme: unpacked, 8 bit data Text: "<NO-ICON>"

Icon Identifier

Icon qualifier: self-explanatory

Icon identifier: 2 (number of record in EF_{Img})

Coding:

| BER-TLV: | D0 | 19 | 81 | 03 | 01 | 22 | 00 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0A | 04 | 3C | 4E | 4F | 2D | 49 | 43 | 4F | 4E | 3E | 1E |
| | 02 | 00 | 02 | | | | | | | | | |

TERMINAL RESPONSE: GET INKEY 6.3.1A

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text String:

Data coding scheme: unpacked, 8 bit data

Text: "+"

Coding:

| BER-TLV: | 81 | 03 | 01 | 22 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 02 | 04 | 2B | | | | | | | | |

Expected Sequence 6.3B (GET INKEY, Colour icon, self-explanatory, requested icon could not be displayed)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|---------------------------------------|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INKEY 6.3.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: GET | [COLOUR-ICON self-explanatory for the Text |
| | | | string] |
| 4 | $ME \rightarrow USER$ | Display " <no-icon>"for the</no-icon> | Text string coding in unpacked format |
| | | prompt without the icon | |
| 5 | $USER \to ME$ | Enter the input "+" and | |
| | | completion | |
| 6 | $ME \rightarrow SIM$ | | [Command performed successfully, but |
| | | INKEY 6.3.1B | requested icon could not be displayed] |

TERMINAL RESPONSE: GET INKEY 6.3.1B

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully but requested icon could not be displayed

Text String:

Data coding scheme: unpacked, 8 bit data

Text: "+"

Coding:

| BER-TLV: | 81 | 03 | 01 | 22 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 04 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 02 | 04 | 2B | | | | | | | | |

Expected Sequence 6.4A (GET INKEY, Colour icon, non self-explanatory, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INKEY 6.4.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: GET | [COLOUR-ICON non self-explanatory for the |
| | | INKEY 6.4.1 | Text string] |
| 4 | $ME \rightarrow USER$ | Display " <colour-icon>" and</colour-icon> | Text string coding in unpacked format |
| | | Display the COLOUR-ICON for | |
| | | the prompt | |
| 5 | $USER \to ME$ | Enter the input "+" and | |
| | | completion | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: GET | [Command performed successfully] |
| | | INKEY 6.4.1A | |

PROACTIVE COMMAND: GET INKEY 6.4.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: SIM Destination device: ME

Text String

Data coding scheme: unpacked, 8 bit data
Text: "<COLOUR-ICON>"

Icon Identifier

Icon qualifier: not self-explanatory

Icon identifier: 2 (number of record in EF_{Img})

Coding:

| BER-TLV: | D0 | 1D | 81 | 03 | 01 | 22 | 00 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0E | 04 | 3C | 43 | 4F | 4C | 4F | 55 | 52 | 2D | 49 | 43 |
| | 4F | 4E | 3E | 1E | 02 | 01 | 02 | | | | | |

TERMINAL RESPONSE: GET INKEY 6.4.1A

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text String:

Data coding scheme: unpacked, 8 bit data

Text: "+"

Coding:

| BER-TLV: | 81 | 03 | 01 | 22 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| · | 8D | 02 | 04 | 2B | | | | | | | | |

Expected Sequence 6.4B (GET INKEY, Colour icon, non self-explanatory, requested icon could not be displayed)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INKEY 6.4.1 | |
| 2 | $ME \to SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: GET | [COLOUR-ICON non self-explanatory for the |
| | | INKEY 6.4.1 | Text string] |
| 4 | $ME \rightarrow USER$ | Display " <colour-icon>" for</colour-icon> | Text string coding in unpacked format |
| | | the prompt without the icon | |
| 5 | $USER \to ME$ | Enter the input "+" and | |
| | | completion | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: GET | [Command performed successfully, but |
| | | INKEY 6.4.1B | requested icon could not be displayed] |

TERMINAL RESPONSE: GET INKEY 6.4.1B

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully but requested icon could not be displayed

Text String:

Data coding scheme: unpacked, 8 bit data

Text: "+"

Coding:

| BER-TLV: | 81 | 03 | 01 | 22 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 04 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 02 | 04 | 2B | | | | | | | | |

27.22.4.2.6.5 Test requirement

The ME shall operate in the manner defined in expected sequence 6.1A to 6.4B.

27.22.4.2.7 GET INKEY (Help Information)

27.22.4.2.7.1 Definition and applicability

See clause 3.2.2.

27.22.4.2.7.2 Conformance requirement

The ME shall support the GET INKEY command as defined in the following technical specifications:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.2, clause 6.5.4, clause 6.6.2, clause 6.8, clause 6.11, clause 12.6, clause 12.15, clause 12.15.1, clause 12.15.2, clause 12.15.3 and clause 12.31.

27.22.4.2.7.3 Test purpose

To verify that the ME displays the text contained in the GET INKEY proactive SIM command, and returns the text string entered in the TERMINAL RESPONSE command sent to the SIM.

27.22.4.2.7.4 Method of test

27.22.4.2.7.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.2.7.4.2 Procedure

Expected Sequence 7.1 (GET INKEY, help information available)

| Step | Direction | MESSAGE / Action | Comments |
|--------|-----------------------|--|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INKEY 7.1.1 | |
| 2 | $ME \to SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: GET | [digits only, help information available] |
| | | INKEY 7.1.1 | |
| 4 | | Display "Enter "+"" | Text string coding in unpacked format |
| 5 | | Press "help" key | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: GET | [help info required] |
| _ | | INKEY 7.1.1 | |
| 7 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | ME CIM | PENDING: DISPLAY TEXT 7.1.1 | |
| 8 9 | , | FETCH | |
| 9 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: DISPLAY TEXT 7.1.1 | |
| 10 | ME LICED | Display 'Help information' | Text string coded in unpacked format |
| 11 | | Clear Message | Text String coded in unpacked format |
| 12 | | TERMINAL RESPONSE: | |
| 12 | IVIE -> SIIVI | DISPLAY TEXT 7.1.1 | |
| 13 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | Olivi / IVIL | PENDING: GET INKEY 7.1.2 | |
| 14 | $ME \rightarrow SIM$ | FETCH | |
| 15 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: GET | [digits only, help information available] |
| | J 7 | INKEY 7.1.2 | |
| 16 | $ME \rightarrow USER$ | Display "Enter "+"" | Repetition of get inkey |
| 17 | $USER \to ME$ | Enter the input "+" and | |
| | | completion | |
| 18 | $ME \to SIM$ | TERMINAL RESPONSE: GET | [Command performed successfully] |
| | | INKEY 7.1.2 | |

PROACTIVE COMMAND: GET INKEY 7.1.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, help information available

Device identities

Source device: SIM
Destination device: ME

Text String

Data coding scheme: unpacked, 8 bit data

Text: "Enter "+""

Coding:

| BER-TLV: | D0 | 15 | 81 | 03 | 01 | 22 | 80 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| · | 0A | 04 | 45 | 6E | 74 | 65 | 72 | 20 | 22 | 2B | 22 | |

TERMINAL RESPONSE: GET INKEY 7.1.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Help information required by the user

Coding:

| BER-TLV: | 81 | 03 | 01 | 22 | 80 | 82 | 02 | 82 | 81 | 83 | 01 | 13 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|

PROACTIVE COMMAND: DISPLAY TEXT 7.1.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text String

Data coding scheme: unpacked, 8 bit data
Text: "Help information"

| BER-TLV: | D0 | 1C | 81 | 03 | 01 | 21 | 80 | 82 | 02 | 81 | 02 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 11 | 04 | 48 | 65 | 6C | 70 | 20 | 69 | 6E | 66 | 6F | 72 |
| | 6D | 61 | 74 | 69 | 6F | 6E | | | | | | |

TERMINAL RESPONSE: DISPLAY TEXT 7.1.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 21 | 80 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|-----|----|-----|----|----|----|-----|----|----|----|----|----|
| D | U . | 00 | U . | | 00 | U- | U — | U- | | 00 | 0. | 00 |

PROACTIVE COMMAND: GET INKEY 7.1.2

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, help information available

Device identities

Source device: SIM
Destination device: ME

Text String

Data coding scheme: unpacked, 8 bit data

Text: "Enter "+""

Coding:

| BER-TLV: | D0 | 15 | 81 | 03 | 01 | 22 | 80 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0A | 04 | 45 | 6F | 74 | 65 | 72 | 20 | 22 | 2B | 22 | |

TERMINAL RESPONSE: GET INKEY 7.1.2

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text String:

Data coding scheme: unpacked, 8 bit data

Text: "+"

| BER-TLV: | 81 | 03 | 01 | 22 | 80 | 82 | 02 | 82 | 81 | 83 | 01 | 00 | |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|--|
| | 8D | 02 | 04 | 2B | | | | | | | | | |

27.22.4.2.7.5 Test requirement

The ME shall operate in the manner defined in expected sequence 7.1.

27.22.4.3. GET INPUT

27.22.4.3.1 GET INPUT (normal)

27.22.4.3.1.1 Definition and applicability

See clause 3.2.2.

27.22.4.3.1.2 Conformance requirement

The ME shall support the GET INPUT command as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.3, clause 6.6.3, clause 6.8, clause 6.11, clause 12.6, clause 12.15, clause 12.15.1, clause 12.15.2, clause 12.15.3 and clause 12.13.

27.22.4.3.1.3 Test purpose

To verify that the ME displays the text contained in the GET INPUT proactive SIM command, and returns the text string entered in the TERMINAL RESPONSE command sent to the SIM.

27.22.4.3.1.4 Method of test

27.22.4.3.1.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.3.1.4.2 Procedure

Expected Sequence 1.1 (GET INPUT, digits only, SMS default alphabet, ME to echo text, ME supporting 8 bit data Message)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-----------------------------|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INPUT 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: GET | [digits only, SMS default alphabet, ME to echo |
| | | INPUT 1.1.1 | text, packing not required, no help info |
| | | | available] |
| 4 | $ME \rightarrow USER$ | Display "Enter 12345" | Range of expected length is 5-5 |
| | | | Text string coding in unpacked format |
| 5 | $USER \to ME$ | Enter the input "12345" and | |
| | | completion | |
| 6 | $ME \to SIM$ | TERMINAL RESPONSE: GET | [command performed successfully] |
| | | INPUT 1.1.1 | |

PROACTIVE COMMAND: GET INPUT 1.1.1

Logically:

Command details

Command number:

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, no help information available

Device identities

Source device: SIM
Destination device: ME

Text String

Data coding scheme: unpacked, 8 bit data
Text: "Enter 12345"

Response length

Minimum length: 5 Maximum length: 5

Coding:

| BER-TLV: | D0 | 1B | 81 | 03 | 01 | 23 | 00 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0C | 04 | 45 | 6E | 74 | 65 | 72 | 20 | 31 | 32 | 33 | 34 |
| | 35 | 91 | 02 | 05 | 05 | | | | | | | |

TERMINAL RESPONSE: GET INPUT 1.1.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data

Text: "12345"

Coding:

| BER-TLV: | 81 | 03 | 01 | 23 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 06 | 04 | 31 | 32 | 33 | 34 | 35 | | | | |

Expected Sequence 1.2 (GET INPUT, digits only, SMS default alphabet, ME to echo text, packing SMS Point-to-point required by ME)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|--|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INPUT 1.2.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: GET INPUT 1.2.1 | [digits only, SMS default alphabet, ME to echo text, packing required, no help information available] |
| 4 | $ME \to USER$ | Display "Enter 67*#+" | Range of expected length is 5-5 Text string coding in packed format |
| 5 | $USER \to ME$ | Enter the input "67*#+" and completion | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: GET INPUT 1.2.1 | [command performed successfully] |

PROACTIVE COMMAND: GET INPUT 1.2.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in packed SMS format, ME

to echo text, no help information available

Device identities

Source device: SIM
Destination device: ME

Text String

Data coding scheme: SMS default alphabet

Text: "Enter 67*#+"

Response length

Minimum length: 5 Maximum length: 5

Coding:

| BER-TLV: | D0 | 1A | 81 | 03 | 01 | 23 | 08 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0B | 00 | 45 | 37 | BD | 2C | 07 | D9 | 6E | AA | D1 | 0A |
| | 91 | 02 | 05 | 05 | | | | | | | | |

TERMINAL RESPONSE: GET INPUT 1.2.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in packed SMS format, ME

to echo text, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: packed SMS format

Text: "67*#+"

| BER-TLV: | 81 | 03 | 01 | 23 | 80 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 06 | 00 | B6 | 9B | 6A | B4 | 02 | | | | |

Expected Sequence 1.3 (GET INPUT, character set, SMS Default Alphabet, ME to echo text, ME supporting 8 bit data Message)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-----------------------------|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INPUT 1.3.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: GET | [character set, SMS default alphabet, ME to |
| | | INPUT 1.3.1 | echo text, packing not required, no help |
| | | | information available] |
| 4 | $ME \rightarrow USER$ | Display "Enter AbCdE" | Range of expected length is 5-5 |
| | | | Text string coding in unpacked format |
| 5 | $USER \to ME$ | Enter the input "AbCdE" and | The ME may echo the input |
| | | completion | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: GET | [command performed successfully] |
| | | INPUT 1.3.1 | |

PROACTIVE COMMAND: GET INPUT 1.3.1

Logically:

Command details

Command number:

Command type: GET INPUT

Command qualifier: Character set, SMS default alphabet, input in unpacked format, ME to echo text, no

help information available

Device identities

Source device: SIM
Destination device: ME

Text String

Data coding scheme: unpacked, 8 bit data
Text: "Enter AbCdE"

Response length

Minimum length: 5 Maximum length: 5

Coding:

| BER-TLV: | D0 | 1B | 81 | 03 | 01 | 23 | 01 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| - | 0C | 04 | 45 | 6E | 74 | 65 | 72 | 20 | 41 | 62 | 43 | 64 |
| | 45 | 91 | 02 | 05 | 05 | | | | | | | |

TERMINAL RESPONSE: GET INPUT 1.3.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: Character set, SMS default alphabet, input in unpacked format, ME to echo text, no

help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data

Text: "AbCdE"

Coding:

| BER-TLV: | 81 | 03 | 01 | 23 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 06 | 04 | 41 | 62 | 43 | 64 | 45 | | | | |

Expected Sequence 1.4 (GET INPUT, digits only, SMS default alphabet, ME to hide text, ME supporting 8 bit data Message)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--|--|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INPUT 1.4.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: GET | [digits only, SMS default alphabet, ME to hide |
| | | INPUT 1.4.1 | text, packing not required, no help information |
| | ME HOED | Diamless | available] |
| 4 | $ME \rightarrow USER$ | וטואסומן "Password 1 <send>2345678"</send> | Range of expected length is 4-8 |
| _ | | | Text string coding in unpacked format |
| 5 | USER → ME | Enter the input "2345678" and | User"s input not to be revealed at any time, |
| | | completion | optionally indication of key entries such as by displaying "*" |
| 6 | $ME \rightarrow USER$ | Input not revealed | optionally indication of key entries such as by |
| | | | displaying "*" |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: GET | [command performed successfully] |
| | | INPUT 1.4.1 | |

PROACTIVE COMMAND: GET INPUT 1.4.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked format, ME to

hide text, no help information available

Device identities

Source device: SIM
Destination device: ME

Text String

Data coding scheme: unpacked, 8 bit data

Text: "Password 1<SEND>2345678"

Response length

Minimum length: 4
Maximum length: 8

Coding:

| BER-TLV: | D0 | 27 | 81 | 03 | 01 | 23 | 04 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 18 | 04 | 50 | 61 | 73 | 73 | 77 | 6F | 72 | 64 | 20 | 31 |
| | 3C | 53 | 45 | 4E | 44 | 3E | 32 | 33 | 34 | 35 | 36 | 37 |
| | 38 | 91 | 02 | 04 | 08 | | | | | | | |

TERMINAL RESPONSE: GET INPUT 1.4.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked format, ME to

hide text, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data

Text: "2345678"

Coding:

| BER-TLV: | 81 | 03 | 01 | 23 | 04 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 08 | 04 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | | |

Expected Sequence 1.5 (GET INPUT, digits only, SMS default alphabet, ME to echo text, ME supporting 8 bit data Message)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|---|---|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INPUT 1.5.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | | [digits only, SMS default alphabet, ME to echo text, packing not required, no help information available] |
| 4 | $ME \rightarrow USER$ | Display "Enter 19,09,0(1)" | Range of expected length is 1-20 Text string coding in unpacked format |
| 5 | $USER \rightarrow ME$ | Completion without input | |
| 6 | $ME \rightarrow USER$ | The ME MMI takes action to manage the entry of correct numbers of characters. | |
| 7 | $USER \to ME$ | Enter "12345678901234567890" and completion | |
| 8 | $ME \rightarrow SIM$ | • | [command performed successfully] |

PROACTIVE COMMAND: GET INPUT 1.5.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, no help information available

Device identities

Source device: SIM
Destination device: ME

Text String

Data coding scheme: unpacked, 8 bit data
Text: "Enter 1..9,0..9,0(1)"

Response length

Minimum length: 1 Maximum length: 20

| BER-TLV: | D0 | 24 | 81 | 03 | 01 | 23 | 00 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| · | 15 | 04 | 45 | 6E | 74 | 65 | 72 | 20 | 31 | 2E | 2E | 39 |
| | 2C | 30 | 2E | 2E | 39 | 2C | 30 | 28 | 31 | 29 | 91 | 02 |
| | 01 | 14 | | | | | | | | | | |

TERMINAL RESPONSE: GET INPUT 1.5.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data
Text: "12345678901234567890"

Coding:

| BER-TLV: | 81 | 03 | 01 | 23 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 15 | 04 | 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 |
| | 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 30 | |

Expected Sequence 1.6 (GET INPUT, backwards move)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INPUT 1.6.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: GET | [digits only, SMS default alphabet, ME to echo |
| | | INPUT 1.6.1 | text, packing not required, no help information |
| | | | available] |
| 4 | $ME \rightarrow USER$ | Display " <go-backwards>"</go-backwards> | Range of expected length is 0-8 |
| | | | Text string coding in unpacked format |
| 5 | $USER \to ME$ | Backwards move MMI action | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: GET | [backward move in the proactive SIM session |
| | | INPUT 1.6.1 | requested by the user] |

PROACTIVE COMMAND: GET INPUT 1.6.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, no help information available

Device identities

Source device: SIM Destination device: ME

Text string

Data coding scheme: unpacked, 8 bit data
Text: "<GO-BACKWARDS>"

Response length

Minimum length: 0 Maximum length: 8

Coding:

| BER-TLV: | D0 | 1E | 81 | 03 | 01 | 23 | 00 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0F | 04 | 3C | 47 | 4F | 2D | 42 | 41 | 43 | 4B | 57 | 41 |
| | 52 | 44 | 53 | 3E | 91 | 02 | 00 | 80 | | | | |

TERMINAL RESPONSE: GET INPUT 1.6.1

Logically:

Command details

Command number:

Command type: GET INPUT

1

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: backward move in the proactive SIM session requested by the user

Coding:

| BER-TLV: | 81 | 03 | 01 | 23 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 11 | |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|--|
|----------|----|----|----|----|----|----|----|----|----|----|----|----|--|

Expected Sequence 1.7 (GET INPUT, abort)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INPUT 1.7.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: GET INPUT 1.7.1 | [digits only, SMS default alphabet, ME to echo text, packing not required, no help information available] |
| 4 | $ME \rightarrow USER$ | Display " <abort>"</abort> | Range if expected length is 0-8 Text string coding in unpacked format |
| 5 | $USER \to ME$ | Terminate the Proactive SIM session MMI action | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: GET INPUT 1.7.1 | [Proactive SIM session terminated by the user] |

PROACTIVE COMMAND: GET INPUT 1.7.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, no help information available

Device identities

Source device: SIM
Destination device: ME

Text string

Data coding scheme: unpacked, 8 bit data

Text: "<ABORT>"

Response length

Minimum length: 0 Maximum length: 8

Coding:

| BER-TLV: | D0 | 17 | 81 | 03 | 01 | 23 | 00 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 08 | 04 | 3C | 41 | 42 | 4F | 52 | 54 | 3E | 91 | 02 | 00 |
| | 08 | | | | | | | | | | | |

TERMINAL RESPONSE: GET INPUT 1.7.1

Logically:

Command details

Command number:

Command type: GET INPUT

1

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Proactive SIM session terminated by the user

Coding:

| BE | R-TLV: | 81 | 03 | 01 | 23 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 10 | |
|----|--------|----|----|----|----|----|----|----|----|----|----|----|----|--|
|----|--------|----|----|----|----|----|----|----|----|----|----|----|----|--|

Expected Sequence 1.8 (GET INPUT, digits only, SMS default alphabet, ME to echo text, ME supporting 8 bit data Message)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INPUT 1.8.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: GET | [digits only, SMS default alphabet, ME to echo |
| | | INPUT 1.8.1 | text, packing not required, no help information |
| | | | available] |
| 4 | $ME \rightarrow USER$ | , , | Range of length expected is 160-160 |
| | | "***111111111###***2222222 | Text string coding in unpacked format |
| | | 222###***333333333###***44 | |
| | | 4444444###***555555555## | |
| | | #***6666666666###***7777777 | |
| | | 777###***88888888###***99 | |
| | | 9999999###***000000000## | |
| 5 | LIGED ME | #" | |
| 5 | USER → ME | Enter the input | |
| | | "***111111111###***2222222 222###***333333333###***44 | |
| | | 4444444###***555555555## | |
| | | #***6666666666###***7777777 | |
| | | 777###***88888888###***99 | |
| | | 9999999###***000000000## | |
| | | #" | |
| | | and completion | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: GET | [command performed successfully] |
| | | INPUT 1.8.1 | |

PROACTIVE COMMAND: GET INPUT 1.8.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked format, ME

to echo text, no help information available

Device identities

Source device: SIM
Destination device: ME

Text string

Data coding scheme: unpacked, 8 bit data

Text: "***111111111###***222222222###***33333333###***44444444###***

55555555###***666666666###***77777777###***888888888###***9999

99999###***000000000###"

Response length

Minimum length: 160 Maximum length: 160

Coding:

| BER-TLV: | D0 | 81 | B1 | 81 | 03 | 01 | 23 | 00 | 82 | 02 | 81 | 82 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 81 | A1 | 04 | 2A | 2A | 2A | 31 | 31 | 31 | 31 | 31 |
| | 31 | 31 | 31 | 31 | 31 | 23 | 23 | 23 | 2A | 2A | 2A | 32 |
| | 32 | 32 | 32 | 32 | 32 | 32 | 32 | 32 | 32 | 23 | 23 | 23 |
| | 2A | 2A | 2A | 33 | 33 | 33 | 33 | 33 | 33 | 33 | 33 | 33 |
| | 33 | 23 | 23 | 23 | 2A | 2A | 2A | 34 | 34 | 34 | 34 | 34 |
| | 34 | 34 | 34 | 34 | 34 | 23 | 23 | 23 | 2A | 2A | 2A | 35 |
| | 35 | 35 | 35 | 35 | 35 | 35 | 35 | 35 | 35 | 23 | 23 | 23 |
| | 2A | 2A | 2A | 36 | 36 | 36 | 36 | 36 | 36 | 36 | 36 | 36 |
| | 36 | 23 | 23 | 23 | 2A | 2A | 2A | 37 | 37 | 37 | 37 | 37 |
| | 37 | 37 | 37 | 37 | 37 | 23 | 23 | 23 | 2A | 2A | 2A | 38 |
| | 38 | 38 | 38 | 38 | 38 | 38 | 38 | 38 | 38 | 23 | 23 | 23 |
| | 2A | 2A | 2A | 39 | 39 | 39 | 39 | 39 | 39 | 39 | 39 | 39 |
| | 39 | 23 | 23 | 23 | 2A | 2A | 2A | 30 | 30 | 30 | 30 | 30 |
| | 30 | 30 | 30 | 30 | 30 | 23 | 23 | 23 | 91 | 02 | A0 | A0 |

TERMINAL RESPONSE: GET INPUT 1.8.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data

Text: "***111111111###***222222222###***

33333333###***4444444### ***5555555555###***666666666### ***77777777###***88888888### ***999999999###***0000000000###"

Coding:

| BER-TLV: | 81 | 03 | 01 | 23 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 81 | A1 | 04 | 2A | 2A | 2A | 31 | 31 | 31 | 31 | 31 |
| | 31 | 31 | 31 | 31 | 31 | 23 | 23 | 23 | 2A | 2A | 2A | 32 |
| | 32 | 32 | 32 | 32 | 32 | 32 | 32 | 32 | 32 | 23 | 23 | 23 |
| | 2A | 2A | 2A | 33 | 33 | 33 | 33 | 33 | 33 | 33 | 33 | 33 |
| | 33 | 23 | 23 | 23 | 2A | 2A | 2A | 34 | 34 | 34 | 34 | 34 |
| | 34 | 34 | 34 | 34 | 34 | 23 | 23 | 23 | 2A | 2A | 2A | 35 |
| | 35 | 35 | 35 | 35 | 35 | 35 | 35 | 35 | 35 | 23 | 23 | 23 |
| | 2A | 2A | 2A | 36 | 36 | 36 | 36 | 36 | 36 | 36 | 36 | 36 |
| | 36 | 23 | 23 | 23 | 2A | 2A | 2A | 37 | 37 | 37 | 37 | 37 |
| | 37 | 37 | 37 | 37 | 37 | 23 | 23 | 23 | 2A | 2A | 2A | 38 |
| | 38 | 38 | 38 | 38 | 38 | 38 | 38 | 38 | 38 | 23 | 23 | 23 |
| | 2A | 2A | 2A | 39 | 39 | 39 | 39 | 39 | 39 | 39 | 39 | 39 |
| | 39 | 23 | 23 | 23 | 2A | 2A | 2A | 30 | 30 | 30 | 30 | 30 |
| | 30 | 30 | 30 | 30 | 30 | 23 | 23 | 23 | | | | |

Expected Sequence 1.9 (GET INPUT, digits only, SMS default alphabet, ME to echo text, ME supporting 8 bit data Message)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INPUT 1.9.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: GET INPUT 1.9.1 | [digits only, SMS default alphabet, ME to echo text, packing not required, no help information available] |
| 4 | $ME \rightarrow USER$ | Display " <send>"</send> | Range of expected length is 0-1 Text string coding in unpacked format |
| 5 | $USER \rightarrow ME$ | Completion | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: GET INPUT 1.9.1A Or TERMINAL RESPONSE: GET INPUT 1.9.1B | [command performed successfully] |

PROACTIVE COMMAND: GET INPUT 1.9.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, no help information available

Device identities

Source device: SIM Destination device: ME

Text string

Data coding scheme: unpacked, 8 bit data

Text: "<SEND>"

Response length

Minimum length: 0 Maximum length: 1

| BER-TLV: | D0 | 16 | 81 | 03 | 01 | 23 | 00 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| · | 07 | 04 | 3C | 53 | 45 | 4E | 44 | 3E | 91 | 02 | 00 | 01 |

TERMINAL RESPONSE: GET INPUT 1.9.1A

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data empty string

Coding:

| BER-TLV: | 81 | 03 | 01 | 23 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 01 | 04 | | | | | | | | | |

TERMINAL RESPONSE: GET INPUT 1.9.1B

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text string

Contents: Null data object

Coding:

| BER-TLV: | 81 | 03 | 01 | 23 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 00 | | | | | | | | | | |

Expected Sequence 1.10 (GET INPUT, null length for the text string, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-----------------------------|--|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INPUT 1.10.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: GET | [digits only, SMS default alphabet, ME to echo |
| | | INPUT 1.10.1 | text, packing not required, no help info |
| | | | available] |
| 4 | $ME \rightarrow USER$ | Request for input | Range of expected length is 1-5 |
| | | | Null Text string |
| 5 | $USER \to ME$ | Enter the input "12345" and | |
| | | completion | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: GET | [command performed successfully] |
| | | INPUT 1.10.1 | |

PROACTIVE COMMAND: GET INPUT 1.10.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, no help information available

Device identities

Source device: SIM Destination device: ME

Text string

Text: length null (00).

Response length

Minimum length: 1 Maximum length: 5

Coding:

| BER-TLV: | D0 | 0F | 81 | 03 | 01 | 23 | 00 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | 91 | 02 | 01 | 05 | | | | | | | |

TERMINAL RESPONSE: GET INPUT 1.10.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data

Text: "12345"

Coding:

| BER-TLV: | 81 | 03 | 01 | 23 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 06 | 04 | 31 | 32 | 33 | 34 | 35 | | | | |

27.22.4.3.1.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.10.

27.22.4.3.2 GET INPUT (No response from User)

27.22.4.3.2.1 Definition and applicability

See clause 3.2.2.

27.22.4.3.2.2 Conformance requirement

The ME shall support the GET INPUT command as defined in the following technical specifications:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.3, clause 6.6.3, clause 6.8, clause 6.11, clause 12.6, clause 12.15, clause 12.15.1, clause 12.15.2, clause 12.15.3 and clause 12.13.

27.22.4.3.2.3 Test purpose

To verify that the ME displays the text contained in the GET INPUT proactive SIM command, and returns a "No response from user" result value in the TERMINAL RESPONSE command send to the SIM.

27.22.4.3.2.4 Method of test

27.22.4.3.2.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

ME Manufacturers shall set the "no response from user" period of time.

The SIM simulator shall be set to that period of time.

27.22.4.3.2.4.2 Procedure

Expected Sequence 2.1 (GET INPUT, no response from the user)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|---------------------------|--|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INPUT 2.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: GET | [digits only, SMS default alphabet |
| | | INPUT 2.1.1 | ME to echo text, packing not required, no help |
| | | | information available] |
| 4 | $ME \rightarrow USER$ | | Range of expected length is 0-10 |
| | | | Text string coding in unpacked format |
| 5 | USER | Waiting and no completion | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: GET | [No response from user] within 5 s after the |
| | | INPUT 2.1.1 | end of that defined period of time |

PROACTIVE COMMAND: GET INPUT 2.1.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, no help information available

Device identities

Source device: SIM Destination device: ME

Text String

Data coding scheme: unpacked, 8 bit data
Text: "<TIME-OUT>"

Response length

Minimum length: 0 Maximum length: 10

| BER-TLV: | D0 | 1A | 81 | 03 | 01 | 23 | 00 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0B | 04 | 3C | 54 | 49 | 4D | 45 | 2D | 4F | 55 | 54 | 3E |
| | 91 | 02 | 00 | 0A | | | | | | | | |

TERMINAL RESPONSE: GET INPUT 2.1.1

Logically:

Command details

Command number:

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: No response from user

1

Coding:

| BER-TLV: | Q1 | Λ3 | 01 | 23 | 00 | 82 | 02 | 82 | Ω1 | 83 | Ω1 | 12 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| DER-ILV. | 01 | 03 | UI | 23 | 00 | 02 | 02 | 02 | 01 | ೦೦ | υı | 12 |

27.22.4.3.2.5 Test requirement

The ME shall operate in the manner defined in expected sequence 2.1.

27.22.4.3.3 GET INPUT (UCS2 format display)

27.22.4.3.3.1 Definition and applicability

See clause 3.2.2.

27.22.4.3.3.2 Conformance requirement

The ME shall support the GET INPUT command as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.3, clause 6.6.3, clause 6.8, clause 6.11, clause 12.6, clause 12.15, clause 12.15.1, clause 12.15.2, clause 12.15.3 and clause 12.13.

Additionally the ME shall support the UCS2 facility for the coding of the Cyrillic alphabet, as defined in the following technical specifications: ISO/IEC 10646 [17].

27.22.4.3.3.3 Test purpose

To verify that the ME displays the text contained in the GET INPUT proactive SIM command, and returns the text string entered in the TERMINAL RESPONSE command sent to the SIM.

27.22.4.3.3.4 Method of test

27.22.4.3.3.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

27.22.4.3.3.4.2 Procedure

Expected Sequence 3.1 (GET INPUT, text string coding in UCS2, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|--|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INPUT 3.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: GET INPUT 3.1 | [digits only, SMS default alphabet, ME to echo text, packing not required, no help information available] |
| 4 | $ME \to USER$ | Display " ЗДРАВСТВУЙТЕ " | Range of expected length is 5-5 Text string "Hello" in Russian coding in 16 bits UCS2 alphabet format |
| 5 | $USER \to ME$ | Enter the input "HELLO" and completion | · |
| 6 | $ME \to SIM$ | TERMINAL RESPONSE: GET INPUT 3.1.1 | [command performed successfully] |

PROACTIVE COMMAND: GET INPUT 3.1.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: alphabet set, SMS default alphabet, input in unpacked format, ME to echo text, no

help information available

Device identities

Source device: SIM
Destination device: ME

Text String

Data coding scheme: 16 bit data UCS2 alphabet format

Text: "ЗДРАВСТВУЙТЕ "

Response length

Minimum length: 5 Maximum length: 5

Coding:

| BER-TLV: | D0 | 28 | 81 | 03 | 01 | 23 | 01 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 19 | 08 | 04 | 17 | 04 | 14 | 04 | 20 | 04 | 10 | 04 | 12 |
| | 04 | 21 | 04 | 22 | 04 | 12 | 04 | 23 | 04 | 19 | 04 | 22 |
| | 04 | 15 | 91 | 02 | 05 | 05 | | | | | | |

TERMINAL RESPONSE: GET INPUT 3.1.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: alphabet set, SMS default alphabet, input in unpacked format, ME to echo text, no

help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data

Text: "HELLO"

Coding:

| BER-TLV: | 81 | 03 | 01 | 23 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 06 | 04 | 48 | 45 | 4C | 4C | 4F | | | | |

Expected Sequence 3.2 (GET INPUT, max length for the text string coding in UCS2, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|---|---|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INPUT 3.2.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: GET INPUT 3.2.1 | [digits only, SMS default alphabet, ME to echo text, packing not required, no help information available] |
| 4 | $ME \rightarrow USER$ | Display | Range of expected length is 5-5 |
| | | "ЗДРАВСТВУЙТЕЗДРАВСТВ УЙТЕ ЗДРАВСТВУЙТЕЗДРАВСТВ УЙТЕ ЗДРАВСТВУЙТЕЗДРАВСТВУЙ | Text string length 70 characters, coding in 16 bits UCS2 alphabet format |
| _ | | <u>"</u> | |
| 5 | USER → ME | Enter the input "HELLO" and completion | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: GET INPUT 3.2.1 | [command performed successfully] |

PROACTIVE COMMAND: GET INPUT 3.2.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: alphabet set, SMS default alphabet, input in unpacked format, ME to echo text, no

help information available

Device identities

Source device: SIM Destination device: ME

Text String

Data coding scheme: 16 bit data UCS2 alphabet format Text: "ЗДРАВСТВУЙТЕЗДРАВСТВУЙТЕ

ЗДРАВСТВУЙТЕЗДРАВСТВУЙТЕ ЗДРАВСТВУЙТЕЗДРАВСТВУЙТ ЗДРАВСТВУЙТЕЗДРАВСТВУЙ"

Response length

Minimum length: 5 Maximum length: 5

| BER-TLV: | D0 | 81 | 9D | 81 | 03 | 01 | 23 | 01 | 82 | 02 | 81 | 82 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 81 | 8D | 08 | 04 | 17 | 04 | 14 | 04 | 20 | 04 | 10 |
| | 04 | 12 | 04 | 21 | 04 | 22 | 04 | 12 | 04 | 23 | 04 | 19 |
| | 04 | 22 | 04 | 15 | 04 | 17 | 04 | 14 | 04 | 20 | 04 | 10 |
| | 04 | 12 | 04 | 21 | 04 | 22 | 04 | 12 | 04 | 23 | 04 | 19 |
| | 04 | 22 | 04 | 15 | 04 | 17 | 04 | 14 | 04 | 20 | 04 | 10 |
| | 04 | 12 | 04 | 21 | 04 | 22 | 04 | 12 | 04 | 23 | 04 | 19 |
| | 04 | 22 | 04 | 15 | 04 | 17 | 04 | 14 | 04 | 20 | 04 | 10 |
| | 04 | 12 | 04 | 21 | 04 | 22 | 04 | 12 | 04 | 23 | 04 | 19 |
| | 04 | 22 | 04 | 15 | 04 | 17 | 04 | 14 | 04 | 20 | 04 | 10 |
| | 04 | 12 | 04 | 21 | 04 | 22 | 04 | 12 | 04 | 23 | 04 | 19 |
| | 04 | 22 | 04 | 15 | 04 | 17 | 04 | 14 | 04 | 20 | 04 | 10 |
| | 04 | 12 | 04 | 21 | 04 | 22 | 04 | 12 | 04 | 23 | 04 | 19 |

| 91 | 02 | 05 | 05 | | | | |
|----|----|----|----|--|--|--|--|

TERMINAL RESPONSE: GET INPUT 3.2.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: alphabet set, SMS default alphabet, input in unpacked format, ME to echo text, no

help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data

Text: "HELLO"

Coding:

| BER-TLV: | 81 | 03 | 01 | 23 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 06 | 04 | 48 | 45 | 4C | 4C | 4F | | | | |

27.22.4.3.3.5 Test requirement

The ME shall operate in the manner defined in expected sequences 3.1 to 3.2.

27.22.4.3.4 GET INPUT (UCS2 format of entry)

27.22.4.3.4.1 Definition and applicability

See clause 3.2.2.

27.22.4.3.4.2 Conformance requirement

The ME shall support the GET INPUT command as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.3, clause 6.6.3, clause 6.8, clause 6.11, clause 12.6, clause 12.15, clause 12.15.1, clause 12.15.2, clause 12.15.3 and clause 12.13.

Additionally the ME shall support the UCS2 facility for the coding of the Cyrillic alphabet, as defined in ISO/IEC 10646 [17].

27.22.4.3.4.3 Test purpose

To verify that the ME displays the text contained in the GET INPUT proactive SIM command, and returns the text string entered in the TERMINAL RESPONSE command sent to the SIM.

27.22.4.3.4.4 Method of test

27.22.4.3.4.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

27.22.4.3.4.4.2 Procedure

Expected Sequence 4.1 (GET INPUT, character set from UCS2 alphabet, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INPUT 4.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: GET INPUT 4.1.1 | [character set, UCS2 alphabet, ME to echo text, packing not required, no help information available] |
| 4 | $ME \rightarrow USER$ | Display "Enter Hello" | Range of expected length is 12-12 Text string coding in unpacked format |
| 5 | USER → ME | Enter the input "ЗДРАВСТВУЙТЕ " and completion | "Hello" in Russian, coding in UCS2 format |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: GET | [command performed successfully] |

PROACTIVE COMMAND: GET INPUT 4.1.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: character set, UCS2 alphabet, input in unpacked format, ME to echo text, no help

information available

Device identities

Source device: SIM Destination device: ME

Text String

Data coding scheme: unpacked, 8 bit data
Text: "Enter Hello"

Response length

Minimum length: 12 Maximum length: 12

Coding:

| BER-TLV: | D0 | 1B | 81 | 03 | 01 | 23 | 03 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0C | 04 | 45 | 6E | 74 | 65 | 72 | 20 | 48 | 65 | 6C | 6C |
| | 6F | 91 | 02 | 0C | 0C | | | | | | | |

TERMINAL RESPONSE: GET INPUT 4.1.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: character set, UCS2 alphabet, input in unpacked format, ME to echo text, no help

information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: UCS2

Техт: "ЗДРАВСТВУЙТЕ"

Coding:

| BER-TLV: | 81 | 03 | 01 | 23 | 03 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 19 | 80 | 04 | 17 | 04 | 14 | 04 | 20 | 04 | 10 | 04 |
| | 12 | 04 | 21 | 04 | 22 | 04 | 12 | 04 | 23 | 04 | 19 | 04 |
| | 22 | 04 | 15 | | | | | | | | | |

Expected Sequence 4.2 (GET INPUT, character set from UCS2 alphabet, Max length for the input, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--------------------------|--|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INPUT 4.2.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: GET | [character set, UCS2 alphabet, ME to echo |
| | | INPUT 4.2.1 | text, packing not required, no help information available] |
| 4 | ME LICED | Display | - |
| 4 | $ME \rightarrow USER$ | l"Enter Hello" | Range of expected length is no limit Text string coding in unpacked format |
| 5 | LICED VME | Enter the input | Input length 70 characters, coding in UCS2 |
| | USEN → IVIE | 1 | format |
| | | уйте | iomat |
| | | ЗДРАВСТВУЙТЕЗДРАВСТВ | |
| | | УЙТЕ | |
| | | ЗДРАВСТВУЙТЕЗДРАВСТВУЙ | |
| | | and completion | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: GET | [command performed successfully] |
| | | INPUT 4.2.1 | |

PROACTIVE COMMAND: GET INPUT 4.2.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: character set, UCS2 alphabet, input in unpacked format, ME to echo text, no help

information available

Device identities

Source device: SIM Destination device: ME

Text String

Data coding scheme: unpacked, 8 bit data
Text: "Enter Hello"

Response length

Minimum length: 5

Maximum length: No maximum length requirement

| BER-TLV: | D0 | 1B | 81 | 03 | 01 | 23 | 03 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0C | 04 | 45 | 6E | 74 | 65 | 72 | 20 | 48 | 65 | 6C | 6C |
| | 6F | 91 | 02 | 05 | FF | | | | | | | |

TERMINAL RESPONSE: GET INPUT 4.2.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: character set, UCS2 alphabet, input in unpacked format, ME to echo text, no help

information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Data coding scheme: UCS2

Техt: "ЗДРАВСТВУЙТЕ...ЗДРАВСТВУЙ" (70 chars)

Coding:

| BER-TLV: | 81 | 03 | 01 | 23 | 03 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 81 | 8D | 08 | 04 | 17 | 04 | 14 | 04 | 20 | 04 | 10 |
| | 04 | 12 | 04 | 21 | 04 | 22 | 04 | 12 | 04 | 23 | 04 | 19 |
| | 04 | 22 | 04 | 15 | 04 | 17 | 04 | 14 | 04 | 20 | 04 | 10 |
| | 04 | 12 | 04 | 21 | 04 | 22 | 04 | 12 | 04 | 23 | 04 | 19 |
| | 04 | 22 | 04 | 15 | 04 | 17 | 04 | 14 | 04 | 20 | 04 | 10 |
| | 04 | 12 | 04 | 21 | 04 | 22 | 04 | 12 | 04 | 23 | 04 | 19 |
| | 04 | 22 | 04 | 15 | 04 | 17 | 04 | 14 | 04 | 20 | 04 | 10 |
| | 04 | 12 | 04 | 21 | 04 | 22 | 04 | 12 | 04 | 23 | 04 | 19 |
| | 04 | 22 | 04 | 15 | 04 | 17 | 04 | 14 | 04 | 20 | 04 | 10 |
| | 04 | 12 | 04 | 21 | 04 | 22 | 04 | 12 | 04 | 23 | 04 | 19 |
| | 04 | 22 | 04 | 15 | 04 | 17 | 04 | 14 | 04 | 20 | 04 | 10 |
| | 04 | 12 | 04 | 21 | 04 | 22 | 04 | 12 | 04 | 23 | 04 | 19 |

27.22.4.3.4.5 Test requirement

The ME shall operate in the manner defined in expected sequences 4.1 to 4.2.

27.22.4.3.5 GET INPUT (default text)

27.22.4.3.5.1 Definition and applicability

See clause 3.2.2.

27.22.4.3.5.2 Conformance requirement

The ME shall support the GET INPUT command as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.3, clause 6.6.3, clause 6.8, clause 6.11, clause 12.6, clause 12.15, clause 12.15.1, clause 12.15.2, clause 12.15.3 and clause 12.13.

27.22.4.3.5.3 Test purpose

To verify that the ME displays the text contained in the GET INPUT proactive SIM command, and returns the text string entered in the TERMINAL RESPONSE command sent to the SIM.

27.22.4.3.5.4 Method of test

27.22.4.3.5.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

27.22.4.3.5.4.2 Procedure

Expected Sequence 5.1(GET INPUT, default text for the input, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--------------------------|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INPUT 5.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: GET | [digits only, SMS default alphabet, ME to echo |
| | | INPUT 5.1.1 | text, packing not required, no help |
| | | | information available] |
| 4 | $ME \rightarrow USER$ | Display "Enter 12345" | Range of expected length is 5-5 |
| | | Display "12345" | Text string coding in unpacked format |
| | | | Default text coding in unpacked format |
| 5 | $USER \to ME$ | Completion | |
| 6 | $ME \to SIM$ | TERMINAL RESPONSE: GET | [command performed successfully] |
| | | INPUT 5.1.1 | |

PROACTIVE COMMAND: GET INPUT 5.1.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, no help information available

Device identities

Source device: SIM
Destination device: ME

Text String

Data coding scheme: unpacked, 8 bit data Text: "Enter 12345"

Response length

Minimum length: 5 Maximum length: 5

Default Text

Data coding scheme: unpacked, 8 bit data

Text: "12345"

Coding:

| BER-TLV: | D0 | 23 | 81 | 03 | 01 | 23 | 00 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0C | 04 | 45 | 6E | 74 | 65 | 72 | 20 | 31 | 32 | 33 | 34 |
| | 35 | 91 | 02 | 05 | 05 | 17 | 06 | 04 | 31 | 32 | 33 | 34 |
| | 35 | | | | | | | | | | | |

TERMINAL RESPONSE: GET INPUT 5.1.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data

Text: "12345"

Coding:

| BER-TLV: | 81 | 03 | 01 | 23 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 06 | 04 | 31 | 32 | 33 | 34 | 35 | | | | |

Expected Sequence 5.2 (GET INPUT, default text for the input with max length, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-----------------------------|--|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INPUT 5.2.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: GET | [digits only, SMS default alphabet, ME to echo |
| | | INPUT 5.2.1 | text, packing not required, no help |
| | | | information available] |
| 4 | $ME \rightarrow USER$ | Display "Enter:" | Range of expected length is 160-160 |
| | | Display default text input: | Text string coding in unpacked format |
| | | "***111111111###***22222222 | Default text length 160 bytes coding in |
| | | 22###***33333333###***4444 | unpacked format |
| | | 444444###***555555555###*** | |
| | | 666666666###***777777777 | |
| | | ##***888888888###***999999 | |
| | | 999###***000000000###" | |
| 5 | $USER \to ME$ | Completion | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: GET | [command performed successfully] |
| | | INPUT 5.2.1 | |

PROACTIVE COMMAND: GET INPUT 5.2.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, no help information available

Device identities

Source device: SIM
Destination device: ME

Text String

Data coding scheme: unpacked, 8 bit data

Text: "Enter:"

Response length

Minimum length: 160 Maximum length: 160

Default Text

Data coding scheme: unpacked, 8 bit data

Text: "***111111111###***222222222###***33333333###***44444444###***

55555555###***6666666666###***77777777###***888888888###***9999

99999###***0000000000###"

Coding:

| BER-TLV: | D0 | 81 | BA | 81 | 03 | 01 | 23 | 00 | 82 | 02 | 81 | 82 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 07 | 04 | 45 | 6E | 74 | 65 | 72 | 3A | 91 | 02 | A0 |
| | A0 | 17 | 81 | A1 | 04 | 2A | 2A | 2A | 31 | 31 | 31 | 31 |
| | 31 | 31 | 31 | 31 | 31 | 31 | 23 | 23 | 23 | 2A | 2A | 2A |
| | 32 | 32 | 32 | 32 | 32 | 32 | 32 | 32 | 32 | 32 | 23 | 23 |
| | 23 | 2A | 2A | 2A | 33 | 33 | 33 | 33 | 33 | 33 | 33 | 33 |
| | 33 | 33 | 23 | 23 | 23 | 2A | 2A | 2A | 34 | 34 | 34 | 34 |
| | 34 | 34 | 34 | 34 | 34 | 34 | 23 | 23 | 23 | 2A | 2A | 2A |
| | 35 | 35 | 35 | 35 | 35 | 35 | 35 | 35 | 35 | 35 | 23 | 23 |
| | 23 | 2A | 2A | 2A | 36 | 36 | 36 | 36 | 36 | 36 | 36 | 36 |
| | 36 | 36 | 23 | 23 | 23 | 2A | 2A | 2A | 37 | 37 | 37 | 37 |
| | 37 | 37 | 37 | 37 | 37 | 37 | 23 | 23 | 23 | 2A | 2A | 2A |
| | 38 | 38 | 38 | 38 | 38 | 38 | 38 | 38 | 38 | 38 | 23 | 23 |
| | 23 | 2A | 2A | 2A | 39 | 39 | 39 | 39 | 39 | 39 | 39 | 39 |
| | 39 | 39 | 23 | 23 | 23 | 2A | 2A | 2A | 30 | 30 | 30 | 30 |
| | 30 | 30 | 30 | 30 | 30 | 30 | 23 | 23 | 23 | | | |

TERMINAL RESPONSE: GET INPUT 5.2.1

Logically:

Command details

Command number:

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text String

Data coding scheme: unpacked, 8 bit data

Text: "***111111111###***22222222###***333333333###***444444444###***

5555555555###***666666666###***777777777###***888888888###***9999

99999###***000000000###"

Coding:

| BER-TLV: | 81 | 03 | 01 | 23 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 81 | A1 | 04 | 2A | 2A | 2A | 31 | 31 | 31 | 31 | 31 |
| | 31 | 31 | 31 | 31 | 31 | 23 | 23 | 23 | 2A | 2A | 2A | 32 |
| | 32 | 32 | 32 | 32 | 32 | 32 | 32 | 32 | 32 | 23 | 23 | 23 |
| | 2A | 2A | 2A | 33 | 33 | 33 | 33 | 33 | 33 | 33 | 33 | 33 |
| | 33 | 23 | 23 | 23 | 2A | 2A | 2A | 34 | 34 | 34 | 34 | 34 |
| | 34 | 34 | 34 | 34 | 34 | 23 | 23 | 23 | 2A | 2A | 2A | 35 |
| | 35 | 35 | 35 | 35 | 35 | 35 | 35 | 35 | 35 | 23 | 23 | 23 |
| | 2A | 2A | 2A | 36 | 36 | 36 | 36 | 36 | 36 | 36 | 36 | 36 |
| | 36 | 23 | 23 | 23 | 2A | 2A | 2A | 37 | 37 | 37 | 37 | 37 |
| | 37 | 37 | 37 | 37 | 37 | 23 | 23 | 23 | 2A | 2A | 2A | 38 |
| | 38 | 38 | 38 | 38 | 38 | 38 | 38 | 38 | 38 | 23 | 23 | 23 |
| | 2A | 2A | 2A | 39 | 39 | 39 | 39 | 39 | 39 | 39 | 39 | 39 |
| | 39 | 23 | 23 | 23 | 2A | 2A | 2A | 30 | 30 | 30 | 30 | 30 |
| | 30 | 30 | 30 | 30 | 30 | 23 | 23 | 23 | | | | |

27.22.4.3.5.5 Test requirement

The ME shall operate in the manner defined in expected sequences 5.1 to 5.2.

27.22.4.3.6 GET INPUT (display of Icon)

27.22.4.3.6.1 Definition and applicability

See clause 3.2.2.

27.22.4.3.6.2 Conformance requirement

The ME shall support the GET INPUT command as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.3, clause 6.5.4, clause 6.6.3, clause 6.8, clause 6.11, clause 12.6, clause 12.15, clause 12.15.1, clause 12.15.2, clause 12.15.3, clause 12.13 and clause 12.31.

27.22.4.3.6.3 Test purpose

To verify that the ME displays the Icon contained in the GET INPUT proactive SIM command, and returns the text string entered in the TERMINAL RESPONSE command sent to the SIM.

27.22.4.3.6.4 Method of test

27.22.4.3.6.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

The ME screen shall be in its normal stand-by display.

27.22.4.3.6.4.2 Procedure

Expected Sequence 6.1A (GET INPUT, Basic icon, self-explanatory, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INPUT 6.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: GET | [BASIC-ICON self-explanatory for the Text |
| | | INPUT 6.1.1 | string] |
| 4 | $ME \rightarrow USER$ | Display " <no-icon>" for the</no-icon> | |
| | | prompt without the icon | Text string coding in unpacked format |
| 5 | $USER \to ME$ | Enter "+" and completion | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: GET | Command performed successfully] |
| | | INPUT 6.1.1A | |

PROACTIVE COMMAND: GET INPUT 6.1.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: SIM
Destination device: ME

Text String

Data coding scheme: unpacked, 8 bit data Text: "<NO-ICON>"

Response length

Minimum length: 0 Maximum length: 10

Icon Identifier

Icon qualifier: self-explanatory

Icon identifier: 1 (number of record in EF_{Img})

Coding:

| BER-TLV: | D0 | 1D | 81 | 03 | 01 | 23 | 00 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0A | 04 | 3C | 4E | 4F | 2D | 49 | 43 | 4F | 4E | 3E | 91 |
| | 02 | 00 | 0A | 1E | 02 | 00 | 01 | | | | | |

TERMINAL RESPONSE: GET INPUT 6.1.1A

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data

Text: "+"

Coding:

| BER-TLV: | 81 | 03 | 01 | 23 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| · | 8D | 02 | 04 | 2B | | | | | | | | |

Expected Sequence 6.1B (GET INPUT, Basic icon, self-explanatory, requested icon could not be displayed)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INPUT 6.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: GET INPUT 6.1.1 | [BASIC-ICON self-explanatory for the Text string] |
| 4 | $ME \rightarrow USER$ | Display " <no-icon>" for the prompt without the icon</no-icon> | |
| | | | Text string coding in unpacked format |
| 5 | $USER \rightarrow ME$ | Enter "+" and completion | |
| 6 | ME → SIM | TERMINAL RESPONSE: GET INPUT 6.1.1B | [Command performed successfully, but requested icon could not be displayed] |

TERMINAL RESPONSE: GET INPUT 6.1.1B

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully but requested icon could not be

displayed

Text string

unpacked, 8 bit data "+" Data coding scheme:

Coding:

| BER-TLV: | 81 | 03 | 01 | 23 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 04 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| · | 8D | 02 | 04 | 2B | | | | | | | | |

Expected Sequence 6.2A (GET INPUT, Basic icon, non self-explanatory, successful)

| Direction | MESSAGE / Action | Comments |
|-----------------------|---|---|
| $SIM \to ME$ | PROACTIVE COMMAND | |
| | PENDING: GET INPUT 6.2.1 | |
| $ME \to SIM$ | FETCH | |
| $SIM \to ME$ | PROACTIVE COMMAND: GET | [BASIC-ICON non self-explanatory for the |
| | INPUT 6.2.1 | Text string] |
| $ME \rightarrow USER$ | 1 | |
| | , , | |
| | prompt | |
| | | Text string coding in unpacked format |
| | | |
| | | |
| | l • | [Command performed augeocafully] |
| IVIE → SIIVI | | [Command performed successfully] |
| | | |
| | $\begin{array}{c} \text{SIM} \rightarrow \text{ME} \\ \text{ME} \rightarrow \text{SIM} \\ \text{SIM} \rightarrow \text{ME} \\ \\ \text{ME} \rightarrow \text{USER} \\ \\ \\ \text{USER} \rightarrow \text{ME} \\ \end{array}$ | SIM → ME PROACTIVE COMMAND PENDING: GET INPUT 6.2.1 ME → SIM SIM → ME PROACTIVE COMMAND: GET INPUT 6.2.1 ME → USER Display " <basic-icon>" and Display the BASIC-ICON for the prompt USER → ME Enter the input "+" and completion</basic-icon> |

PROACTIVE COMMAND: GET INPUT 6.2.1

Logically:

Command details

Command number: 1

GET INPUT Command type:

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

SIM Source device: Destination device: ME

Text String

Data coding scheme: unpacked, 8 bit data Text: "<BASIC-ICON>"

Response length

Minimum length: 0 Maximum length: 10

Icon Identifier

Icon qualifier: not self-explanatory

Icon identifier: 1 (number of record in EF_{Img})

| BER-TLV: | D0 | 20 | 81 | 03 | 01 | 23 | 00 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0D | 04 | 3C | 42 | 41 | 53 | 49 | 43 | 2D | 49 | 43 | 4F |
| | 4E | 3E | 91 | 02 | 00 | 0A | 1E | 02 | 01 | 01 | | |

TERMINAL RESPONSE: GET INPUT 6.2.1A

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data

Text: "+"

Coding:

| BER-TLV: | 81 | 03 | 01 | 23 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 02 | 04 | 2B | | | | | | | | |

Expected Sequence 6.2B (GET INPUT, Basic icon, non self-explanatory, requested icon could not be displayed)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INPUT 6.2.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: GET | [BASIC-ICON non self-explanatory for the |
| | | INPUT 6.2.1 | Text string] |
| 4 | $ME \rightarrow USER$ | Display " <basic-icon>" for the</basic-icon> | |
| | | prompt without the icon | |
| | | | Toyt atring adding in uppacked format |
| | | | Text string coding in unpacked format |
| 5 | $USER \to ME$ | Enter the input "+" and | |
| | OOLIN - IVIL | completion | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: GET | [Command performed successfully, but |
| | | INPUT 6.2.1B | requested icon could not be displayed] |
| | | | |
| | | | |

TERMINAL RESPONSE: GET INPUT 6.2.1B

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully but requested icon could not be displayed

Text string

Data coding scheme: unpacked, 8 bit data

Text: "+"

Coding:

| BER-TLV: | 81 | 03 | 01 | 23 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 04 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 02 | 04 | 2B | | | | | | | | |

Expected Sequence 6.3A (GET INPUT, Colour icon, self-explanatory, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|-----------------------------|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INPUT 6.3.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: GET | [COLOUR-ICON self-explanatory for the Text |
| | | INPUT 6.3.1 | string] |
| 4 | $ME \to USER$ | Display the COLOUR-ICON for | |
| | | the prompt | |
| | | | Text string coding in unpacked format |
| | | | Tox offing obtains in dispusited format |
| 5 | $USER \to ME$ | Enter the input "+" and | |
| | | completion | |
| 6 | $ME \to SIM$ | TERMINAL RESPONSE: GET | [Command performed successfully] |
| | | INPUT 6.3.1A | |
| | | | |

PROACTIVE COMMAND: GET INPUT 6.3.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: SIM Destination device: ME

Text String

Data coding scheme: unpacked, 8 bit data Text: "<NO-ICON>"

Response length

Minimum length: 0 Maximum length: 10

Icon Identifier

Icon qualifier: self-explanatory

Icon identifier: 2 (number of record in EF_{Img})

Coding:

| BER-TLV: | D0 | 1D | 81 | 03 | 01 | 23 | 00 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| _ | 0A | 04 | 3C | 4E | 4F | 2D | 49 | 43 | 4F | 4E | 3E | 91 |
| | 02 | 00 | 0A | 1E | 02 | 00 | 02 | | | | | |

TERMINAL RESPONSE: GET INPUT 6.3.1A

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data

Text: "+"

Coding:

| BER-TLV: | 81 | 03 | 01 | 23 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 02 | 04 | 2B | | | | | | | | |

Expected Sequence 6.3B (GET INPUT, Colour icon, self-explanatory, requested icon could not be displayed)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|--|--|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INPUT 6.3.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: GET | [COLOUR-ICON self-explanatory for the Text |
| | | INPUT 6.3.1 | string] |
| 4 | | Display " <no-icon>" for the</no-icon> | |
| | | prompt without the icon | Text string coding in unpacked format |
| 5 | $USER \to ME$ | Enter the input "+" and | |
| _ | | completion | |
| 6 | $ME \rightarrow SIM$ | | [Command performed successfully, but |
| | | INPUT 6.3.1B | requested icon could not be displayed] |
| | | | |
| | | | |

TERMINAL RESPONSE: GET INPUT 6.3.1B

Logically:

Command details

Command number:

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully but requested icon could not be displayed

Text string

Data coding scheme: unpacked, 8 bit data

Text: "+"

| BER-TLV: | 81 | 03 | 01 | 23 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 04 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 02 | 04 | 2B | | | | | | | | |

Expected Sequence 6.4A (GET INPUT, Colour icon, non self-explanatory, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|---|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| 2 | $ME \rightarrow SIM$ | PENDING: GET INPUT 6.4.1 | |
| 3 | $SIM \rightarrow ME$ | | [COLOUR-ICON non self-explanatory for the |
| 4 | ME → USER | INPUT 6.4.1 Display " <colour-icon>" and Display the COLOUR-ICON for the prompt</colour-icon> | Text string] |
| | | | Text string coding in unpacked format |
| 5 | $USER \to ME$ | Enter the input "+" and completion | |
| 6 | $ME \rightarrow SIM$ | • | [Command performed successfully] |

PROACTIVE COMMAND: GET INPUT 6.4.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: SIM
Destination device: ME

Text String

Data coding scheme: unpacked, 8 bit data
Text: "<COLOUR-ICON>"

Response length

Minimum length: 0 Maximum length: 10

Icon Identifier

Icon qualifier: not self-explanatory

Icon identifier: 2 (number of record in EF_{Img})

Coding:

| BER-TLV: | D0 | 21 | 81 | 03 | 01 | 23 | 00 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0E | 04 | 3C | 43 | 4F | 4C | 4F | 55 | 52 | 2D | 49 | 43 |
| | 4F | 4E | 3E | 91 | 02 | 00 | 0A | 1E | 02 | 01 | 02 | |

TERMINAL RESPONSE: GET INPUT 6.4.1A

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data

Text: "+"

Coding:

| BER-TLV: | 81 | 03 | 01 | 23 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 02 | 04 | 2B | | | | | | | | |

Expected Sequence 6.4B (GET INPUT, Colour icon, non self-explanatory, requested icon could not be displayed)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|--|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| 2 | 145 0114 | PENDING: GET INPUT 6.4.1 | |
| _ | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: GET | [COLOUR-ICON non self-explanatory for the |
| 4 | ME LICED | INPUT 6.4.1 | Text string] |
| 4 | IVIE → USER | Display " <colour-icon>" for the prompt without the icon</colour-icon> | |
| | | line prompt without the icon | |
| | | | |
| | | | Text string coding in unpacked format |
| 5 | $USER \to ME$ | Enter the input "+" and | |
| | | completion | |
| 6 | $ME \rightarrow SIM$ | | [Command performed successfully, but |
| | | INPUT 6.4.1B | requested icon could not be displayed] |
| | | | |
| | | | |
| | | | |

TERMINAL RESPONSE: GET INPUT 6.4.1B

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully but requested icon could not be

displayed

Text string

Data coding scheme: unpacked, 8 bit data

Text: "+"

Coding:

| BER-TLV: | 81 | 03 | 01 | 23 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 04 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 02 | 04 | 2B | | | | | | | | |

27.22.4.3.6.5 Test Requirement

The ME shall operate in the manner defined in expected sequences 6.1A to 6.4B.

27.22.4.3.7 GET INPUT (Help Information)

27.22.4.3.7.1 Definition and applicability

See clause 3.2.2.

27.22.4.3.7.2 Conformance requirement

The ME shall support the GET INPUT command as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.3, clause 6.6.3, clause 6.8, clause 6.11, clause 12.6, clause 12.15, clause 12.15.1, clause 12.15.2, clause 12.15.3 and clause 12.13.

27.22.4.3.7.3 Test purpose

To verify that the ME displays the text contained in the GET INPUT proactive SIM command, and returns a 'help information required by the user' result value in the TERMINAL RESPONSE command sent to the SIM if the user has indicated the need to get help information.

27.22.4.3.7.4 Method of test

27.22.4.3.7.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.3.7.4.2 Procedure

Expected Sequence 7.1 (GET INPUT, digits only, ME to echo text, ME supporting 8 bit data Message, help information available)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--------------------------|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET INPUT 7.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: GET | [digits only, SMS default alphabet, ME to echo |
| | | INPUT 7.1.1 | text, packing not required, help information |
| | | | available] |
| 4 | $ME \rightarrow USER$ | Display "Enter 12345" | Range of expected length is 5-5 |
| | | | Text string coding in unpacked format |
| 5 | $USER \to ME$ | Press "help" | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: GET | [command performed, help information |
| | | INPUT 7.1.1 | required by user] |

PROACTIVE COMMAND: GET INPUT 7.1.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, help information available

Device identities

Source device: SIM
Destination device: ME

Text String

Data coding scheme: unpacked, 8 bit data
Text: "Enter 12345"

Response length

Minimum length: 5 Maximum length: 5

Coding:

| BER-TLV: | D0 | 1B | 81 | 03 | 01 | 23 | 80 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0C | 04 | 45 | 6E | 74 | 65 | 72 | 20 | 31 | 32 | 33 | 34 |
| | 35 | 91 | 02 | 05 | 05 | | | | | | | |

TERMINAL RESPONSE: GET INPUT 7.1.1

Logically:

Command details

Command number:

Command type: GET INPUT

1

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Help information required by the user

Coding:

| BER-TLV: 81 03 | 01 23 | 80 82 02 | 82 81 | 83 01 13 | 3 |
|----------------|-------|----------|-------|----------|---|
|----------------|-------|----------|-------|----------|---|

27.22.4.3.7.5 Test requirement

The ME shall operate in the manner defined in expected sequence 7.1.

27.22.4.4 MORE TIME

27.22.4.4.1 Definition and applicability

See clause 3.2.2.

27.22.4.4.2 Conformance requirement

The ME shall support the MORE TIME command as defined in:

• 3GPP TS 11.14 [15] clause 6.4.4, clause 6.6.4, clause 5.2, clause 12.6 and clause 12.7.

27.22.4.4.3 Test purpose

To verify that the ME shall send a TERMINAL RESPONSE (OK) to the SIM after the ME receives the MORE TIME proactive SIM command.

27.22.4.4.4 Method of test

27.22.4.4.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.4.4.2 Procedure

Expected Sequence 1.1 (MORE TIME)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|--------------------------|----------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: MORE TIME 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: MORE | |
| | | TIME 1.1.1 | |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: MORE | [Command performed successfully] |
| | | TIME 1.1.1 | |
| 5 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |

PROACTIVE COMMAND: MORE TIME 1.1.1

Logically:

Command details

Command number: 1

Command type: MORE TIME

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Coding:

| BER-TLV: | D0 | 09 | 81 | 03 | 01 | 02 | 00 | 82 | 02 | 81 | 82 |
|----------|----|----|----|----|----|----|----|----|----|----|----|

TERMINAL RESPONSE: MORE TIME 1.1.1

Logically:

Command details

Command number: 1

Command type: MORE TIME

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 02 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|-----------------|------|----|----|----|----|----------------|------------|----|----------|----|----------|----|
| D = 1 \ 1 = \ 1 | , o. | 00 | 0. | | 00 | _ _ | ~ <u>~</u> | | . | | . | |

27.22.4.4.5 Test requirement

The ME shall operate in the manner defined in expected sequence 1.1.

27.22.4.5 PLAY TONE

27.22.4.5.1 Definition and applicability

See clause 3.2.2.

27.22.4.5.2 Conformance requirement

The ME shall support the PLAY TONE command as defined in:

• 3GPP TS 11.14 [15] clause 6.1, clause 6.4.5, clause 6.6.5, clause 5.2, clause 12.6, clause 12.7, clause 12.2, clause 12.16 and clause 12.8.

27.22.4.5.3 Test purpose

To verify that the ME plays an audio tone of a type and duration contained in the PLAY TONE proactive SIM command, and returns a successful response in the TERMINAL RESPONSE command sent to the SIM.

To verify that the ME plays the requested audio tone through the external ringer whilst not in call and shall superimpose the tone on top of the downlink audio whilst in call.

To verify that the ME displays the text contained in the PLAY TONE proactive SIM command.

27.22.4.5.4 Method of test

27.22.4.5.4.1 Initial conditions

The ME is connected to the SIM Simulator and only connected to the System Simulator if the System Simulator is mentioned in the sequence table. The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

27.22.4.5.4.2 Procedure

Expected Sequence 1.1 (PLAY TONE)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--------------------------------------|----------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: PLAY TONE 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: PLAY | |
| | | TONE 1.1.1 | |
| 4 | $ME \rightarrow USER$ | Display "Dial Tone" | |
| | | Play a standard supervisory dial | |
| | | tone through the external ringer for | |
| | | a duration of 5 s | |
| 5 | $ME \to SIM$ | TERMINAL RESPONSE: PLAY | [Command performed successfully] |
| | | TONE 1.1.1 | |
| 6 | $SIM \to ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |
| 7 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| 8 | $ME \rightarrow SIM$ | PENDING: PLAY TONE 1.1.2 FETCH | |
| 9 | SIM → ME | PROACTIVE COMMAND: PLAY | |
| 9 | SIIVI → IVI⊑ | TONE 1.1.2 | |
| 10 | $ME \rightarrow USER$ | Display "Sub. Busy" | |
| | / COLIK | | |
| | | Play a standard supervisory called | |
| | | subscriber busy tone for a duration | |
| | | of 5 s | |
| 11 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: PLAY | [Command performed successfully] |
| 40 | 0184 845 | TONE 1.1.2 | |
| 12 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION | |
| 13 | $SIM \to ME$ | PROACTIVE COMMAND | |
| 15 | Olivi — IVIE | PENDING: PLAY TONE 1.1.3 | |

| Step | Direction | MESSAGE / Action | Comments |
|----------|---|--|----------------------------------|
| 14 | $ME \rightarrow SIM$ | FETCH | |
| 15 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: PLAY TONE 1.1.3 | |
| 16 | $ME \to USER$ | Display "Congestion" | |
| | | Play a standard supervisory congestion tone for a duration of 5 s | |
| 17 | $ME \to SIM$ | TERMINAL RESPONSE: PLAY | [Command performed successfully] |
| 18 | $SIM \to ME$ | PROACTIVE SIM SESSION ENDED | |
| 19 | $SIM \to ME$ | PROACTIVE COMMAND PENDING: PLAY TONE 1.1.4 | |
| 20 21 | $\begin{array}{c} ME \to SIM \\ SIM \to ME \end{array}$ | FETCH PROACTIVE COMMAND: PLAY | |
| 22 | $ME \rightarrow USER$ | TONE 1.1.4 Display "RP Ack" | |
| | | Play a standard supervisory radio | |
| 23 | ME 	o SIM | path acknowledgement tone TERMINAL RESPONSE: PLAY | [Command performed successfully] |
| 24 | SIM → ME | TONE 1.1.4 PROACTIVE SIM SESSION | |
| 25 | $SIM \rightarrow ME$ | ENDED PROACTIVE COMMAND | |
| 26 | ME 	o SIM | PENDING: PLAY TONE 1.1.5 FETCH | |
| 27 | SIM → ME | PROACTIVE COMMAND: PLAY | |
| 28 | $ME \to USER$ | Display "No RP" | |
| | | Play a standard supervisory radio path not available / call dropped | |
| 29 | ME 	o SIM | tone for a duration of 5 s TERMINAL RESPONSE: PLAY | [Command performed successfully] |
| 30 | $SIM \rightarrow ME$ | TONE 1.1.5 PROACTIVE SIM SESSION | |
| 31 | $SIM \rightarrow ME$ | ENDED PROACTIVE COMMAND | |
| 22 | NAT CUNA | PENDING: PLAY TONE 1.1.6 | |
| 32 33 | $\begin{array}{c} ME \to SIM \\ SIM \to ME \end{array}$ | PROACTIVE COMMAND: PLAY | |
| 34 | $ME \to USER$ | TONE 1.1.6 Display "Spec Info" | |
| | | Play a standard supervisory error / special information tone for a duration of 5 s | |
| 35 | $ME \to SIM$ | TERMINAL RESPONSE: PLAY | [Command performed successfully] |
| 36 | $SIM \to ME$ | PROACTIVE SIM SESSION ENDED | |
| 37 | $SIM \to ME$ | PROACTIVE COMMAND PENDING: PLAY TONE 1.1.7 | |
| 38 | $ME \rightarrow SIM$ | FETCH | |
| 39 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: PLAY TONE 1.1.7 | |
| 40 | $ME \rightarrow USER$ | Display "Call Wait" | |
| | | Play a standard supervisory call waiting tone for a duration of 5 s | |
| 41 | $ME \to SIM$ | TERMINAL RESPONSE: PLAY | [Command performed successfully] |
| 42 | $SIM \to ME$ | PROACTIVE SIM SESSION ENDED | |
| I | | 1 | 1 |

| Step | Direction | MESSAGE / Action | Comments |
|----------|-----------------------|---|--|
| 43 | $SIM \to ME$ | PROACTIVE COMMAND | |
| 44 | NAT CINA | PENDING: PLAY TONE 1.1.8 FETCH | |
| 44 45 | ME 	o SIM $SIM 	o ME$ | PROACTIVE COMMAND: PLAY | |
| 70 | Olivi — IVIE | TONE 1.1.8 | |
| 46 | $ME \to USER$ | Display "Ring Tone" | |
| | | Play a standard supervisory | |
| | | ringing tone for duration of 5 s | |
| 47 | $ME \to SIM$ | TERMINAL RESPONSE: PLAY | [Command performed successfully] |
| 40 | 0114 145 | TONE 1.1.8 | |
| 48 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION ENDED | |
| 49 | $USER \to ME$ | Set up a voice call | User dials 123456789 to connect to the |
| | | | network manually] |
| 50 | $ME \rightarrow SS$ | Establish voice call | [Voice call is established] |
| 51 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: PLAY TONE 1.1.9 | |
| 52 | $ME \rightarrow SIM$ | FETCH | |
| 53 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: PLAY | |
| F.4 | ME LIGES | TONE 1.1.9 | |
| 54 | $ME \rightarrow USER$ | Display "Dial Tone" | |
| | | Superimpose the standard | |
| | | supervisory dial tone on the audio | |
| | NAT 0184 | downlink for the duration of 5 s | |
| 55 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: PLAY TONE 1.1.9 | [Command performed successfully] |
| 56 | $SIM \to ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |
| 57 59 | USER → ME | The user ends the call | |
| 58 | $SIM \to ME$ | PROACTIVE COMMAND PENDING: PLAY TONE 1.1.10 | |
| 59 | $ME \to SIM$ | FETCH | |
| 60 | $SIM \to ME$ | PROACTIVE COMMAND: PLAY | |
| 61 | $ME \to USER$ | TONE 1.1.10 Display "This command instructs | |
| 01 | IVIE → USEK | the ME to play an audio tone. | |
| | | Upon receiving this command, the | |
| | | ME shall check if it is currently in, | |
| | | or in the process of setting up (SET-UP message sent to the | |
| | | network, see GSM"04.08"(8)), a | |
| | | speech call If the ME I" | |
| | | Play a general beep | |
| 62 | $ME \to SIM$ | TERMINAL RESPONSE: PLAY | [Command performed successfully] |
| | ···- / •···· | TONE 1.1.10a | |
| | | OF | or |
| | | TERMINAL RESPONSE: PLAY TONE 1.1.10b | [Command beyond ME's capabilities] |
| 63 | $SIM \to ME$ | PROACTIVE SIM SESSION | |
| 0.4 | 0114 | ENDED | |
| 64 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: PLAY TONE 1.1.11 | |
| 65 | $ME \rightarrow SIM$ | FETCH | |
| 66 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: PLAY | |
| 67 | ME LIGER | TONE 1.1.11 | |
| 67 | $ME \rightarrow USER$ | Display "Beep" | |
| | | Play a ME proprietary general | |
| 00 | ME 6 | beep | [Commond norformed access ()] |
| 68 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: PLAY TONE 1.1.11a | [Command performed successfully] |
| | | Or | or |
| | | TERMINAL RESPONSE: PLAY | [Command beyond ME's capabilities] |
| | | TONE 1.1.11b | |

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|---|--|
| 69 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION | |
| 70 | SIM 	o ME | PROACTIVE COMMAND | |
| / 0 | SIIVI → IVIE | PENDING: PLAY TONE 1.1.12 | |
| 71 | $ME \to SIM$ | FETCH | |
| 72 | $SIM \to ME$ | PROACTIVE COMMAND: PLAY | |
| 73 | ME 	o USER | TONE 1.1.12 Display "Positive" | |
| " | IVIL -> OOLIK | Biopiay 1 conivo | |
| | | Play a ME proprietary positive | |
| 74 | ME 	o SIM | acknowledgement tone TERMINAL RESPONSE: PLAY | [Command performed successfully] |
| | IVIL -> OIIVI | TONE 1.1.12a | [command ponomica adocedarany] |
| | | or | or |
| | | TERMINAL RESPONSE: PLAY TONE 1.1.12b | [Command beyond ME's capabilities] |
| 75 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |
| 76 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: PLAY TONE 1.1.13 | |
| 77 | $ME \rightarrow SIM$ | FETCH | |
| 78 | $SIM \to ME$ | PROACTIVE COMMAND: PLAY | |
| 79 | ME 	o USER | TONE 1.1.13 Display "Negative" | |
| 79 | IVIE → USER | Display Negative | |
| | | Play a ME proprietary negative | |
| 80 | $ME \rightarrow SIM$ | acknowledgement tone TERMINAL RESPONSE: PLAY | [Command performed successfully] |
| | IVIL -> SIIVI | TONE 1.1.13a | [command performed successibility] |
| | | or | or |
| | | TERMINAL RESPONSE: PLAY TONE 1.1.13b | [Command beyond ME's capabilities] |
| 81 | $SIM \to ME$ | PROACTIVE SIM SESSION | |
| 00 | | ENDED | |
| 82 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: PLAY TONE 1.1.14 | |
| 83 | $ME \to SIM$ | FETCH | |
| 84 | $SIM \to ME$ | PROACTIVE COMMAND: PLAY | |
| 85 | ME 	o USER | TONE 1.1.14 Display "Quick" | |
| 00 | WIE 7 OOEIK | Biopiay Quien | |
| | | Play a ME proprietary general | |
| 86 | $ME \rightarrow SIM$ | beep TERMINAL RESPONSE: PLAY | [Command performed successfully] |
| | WIE 7 OHVI | TONE 1.1.14a | [Command ponomica cacceciany] |
| | | or TERMINAL RESPONSE: PLAY | or [Command beyond ME's capabilities] |
| | | TONE 1.1.14b | [Command beyond ME's capabilities] |
| 87 | $SIM \to ME$ | PROACTIVE SIM SESSION | |
| 88 | SIM 	o ME | PROACTIVE COMMAND | |
| 00 | Olivi → IVIE | PENDING: PLAY TONE 1.1.15 | |
| 89 | $ME \rightarrow SIM$ | FETCH | |
| 90 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: PLAY TONE 1.1.15 | |
| 91 | $ME \to USER$ | Display " <abort>"</abort> | |
| | | | |
| | | Play an ME Error / Special information tone until user aborts | |
| | | this command (the command shall | |
| | | be aborted by the user within 1 | |
| 92 | $ME \to SIM$ | minute) TERMINAL RESPONSE: PLAY | [Proactive SIM session terminated by the |
| | | TONE 1.1.15 | user] |
| 93 | $SIM \to ME$ | PROACTIVE SIM SESSION ENDED | |
| I | | IEINDED | I |

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--|---|
| 94 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: PLAY TONE 1.1.16 | |
| 95 | $ME \to SIM$ | FETCH | |
| 96 | $SIM \to ME$ | PROACTIVE COMMAND: PLAY TONE 1.1.16 | [No alpha identifier, no tone tag, no duration tag] |
| 97 | $ME \rightarrow User$ | ME plays general beep, or if not | [ME uses default duration defined by |
| | | supported any (defined by ME- manufacturer) other supported tone | ME-manufacturer] |
| 98 | $ME \to SIM$ | | [Command performed successfully], [ME uses general beep, or if not supported any (defined by ME-manufacturer) other supported tone, uses default duration defined by ME-manufacturer] |
| 99 | $SIM \to ME$ | PROACTIVE SIM SESSION ENDED | |

PROACTIVE COMMAND: PLAY TONE 1.1.1

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Earpiece
Alpha identifier: "Dial Tone"

Tone: Standard supervisory tones: dial tone

Duration

Time unit: Seconds
Time interval: 5

Coding:

| BER-TLV: | D0 | 1B | 81 | 03 | 01 | 20 | 00 | 82 | 02 | 81 | 03 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 09 | 44 | 69 | 61 | 6C | 20 | 54 | 6F | 6E | 65 | 8E | 01 |
| | 01 | 84 | 02 | 01 | 05 | | | | | | | |

PROACTIVE COMMAND: PLAY TONE 1.1.2

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Earpiece
Alpha identifier: "Sub. Busy"

Tone: Standard supervisory tones: called subscriber busy

Duration

Time unit: Seconds
Time interval: 5

| BER-TLV: | D0 | 1B | 81 | 03 | 01 | 20 | 00 | 82 | 02 | 81 | 03 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| · | 09 | 53 | 75 | 62 | 2E | 20 | 42 | 75 | 73 | 79 | 8E | 01 |
| | 02 | 84 | 02 | 01 | 05 | | | | | | | |

PROACTIVE COMMAND: PLAY TONE 1.1.3

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Earpiece
Alpha identifier: "Congestion"

Tone: Standard supervisory tones: congestion

Duration

Time unit: Seconds
Time interval: 5

Coding:

| BER-TLV: | D0 | 1C | 81 | 03 | 01 | 20 | 00 | 82 | 02 | 81 | 03 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0A | 43 | 6F | 6E | 67 | 65 | 73 | 74 | 69 | 6F | 6E | 8E |
| | 01 | 03 | 84 | 02 | 01 | 05 | | | | | | |

PROACTIVE COMMAND: PLAY TONE 1.1.4

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Earpiece
Alpha identifier: "RP Ack"

Tone: Standard supervisory tones: radio path acknowledge

Duration

Time unit: Seconds
Time interval: 5

Coding:

| BER-TLV: | D0 | 18 | 81 | 03 | 01 | 20 | 00 | 82 | 02 | 81 | 03 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| • | 06 | 52 | 50 | 20 | 41 | 63 | 6B | 8E | 01 | 04 | 84 | 02 |
| | 01 | 05 | | | | | | | | | | |

PROACTIVE COMMAND: PLAY TONE 1.1.5

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Earpiece Alpha identifier: "No RP"

Tone: Standard supervisory tones: radio path not available

Duration

Time unit: Seconds
Time interval: 5

Coding:

| BER-TLV: | D0 | 17 | 81 | 03 | 01 | 20 | 00 | 82 | 02 | 81 | 03 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 05 | 4E | 6F | 20 | 52 | 50 | 8E | 01 | 05 | 84 | 02 | 01 |
| | 05 | | | | | | | | | | | |

PROACTIVE COMMAND: PLAY TONE 1.1.6

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Earpiece

Alpha identifier: "Spec Info"

Tone: Standard supervisory tones: Error/ special information

Duration

Time unit: Seconds
Time interval: 5

Coding:

| BER-TLV: | D0 | 1B | 81 | 03 | 01 | 20 | 00 | 82 | 02 | 81 | 03 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 09 | 53 | 70 | 65 | 63 | 20 | 49 | 6E | 66 | 6F | 8E | 01 |
| | 06 | 84 | 02 | 01 | 05 | | | | | | | |

PROACTIVE COMMAND: PLAY TONE 1.1.7

Logically:

Command details

Command number:

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Earpiece

Alpha identifier: "Call Wait"

Tone: Standard supervisory tones: call waiting tone

Duration

Time unit: Seconds
Time interval: 5

| BER-TLV: | D0 | 1B | 81 | 03 | 01 | 20 | 00 | 82 | 02 | 81 | 03 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 09 | 43 | 61 | 6C | 6C | 20 | 57 | 61 | 69 | 74 | 8E | 01 |
| | 07 | 84 | 02 | 01 | 05 | | | | | | | |

PROACTIVE COMMAND: PLAY TONE 1.1.8

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Earpiece
Alpha identifier: "Ring Tone"

Tone: Standard supervisory tones: ringing tone

Duration

Time unit: Seconds
Time interval: 5

Coding:

| BER-TLV: | D0 | 1B | 81 | 03 | 01 | 20 | 00 | 82 | 02 | 81 | 03 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 09 | 52 | 69 | 6E | 67 | 20 | 54 | 6F | 6E | 65 | 8E | 01 |
| | 08 | 84 | 02 | 01 | 05 | | | | | | | |

PROACTIVE COMMAND: PLAY TONE 1.1.9

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Earpiece

Alpha identifier: "Dial Tone"

Tone: Standard supervisory tones: dial tone

Duration

Time unit: Seconds
Time interval: 5

Coding:

| BER-TLV: | D0 | 1B | 81 | 03 | 01 | 20 | 00 | 82 | 02 | 81 | 03 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| _ | 09 | 44 | 69 | 61 | 6C | 20 | 54 | 6F | 6E | 65 | 8E | 01 |
| | 01 | 84 | 02 | 01 | 05 | | | | | | | |

PROACTIVE COMMAND: PLAY TONE 1.1.10

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Earpiece

Alpha identifier: "This command instructs the ME to play an audio tone. Upon receiving this

command, the ME shall check if it is currently in, or in the process of setting up (SET-UP message sent to the network, see GSM"04.08"(8)), a speech call. - If the

ME I"

Coding:

| BER-TLV: | D0 | 81 | FD | 81 | 03 | 01 | 20 | 00 | 82 | 02 | 81 | 03 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 85 | 81 | F1 | 54 | 68 | 69 | 73 | 20 | 63 | 6F | 6D | 6D |
| | 61 | 6E | 64 | 20 | 69 | 6E | 73 | 74 | 72 | 75 | 63 | 74 |
| | 73 | 20 | 74 | 68 | 65 | 20 | 4D | 45 | 20 | 74 | 6F | 20 |
| | 70 | 6C | 61 | 79 | 20 | 61 | 6E | 20 | 61 | 75 | 64 | 69 |
| | 6F | 20 | 74 | 6F | 6E | 65 | 2E | 20 | 55 | 70 | 6F | 6E |
| | 20 | 72 | 65 | 63 | 65 | 69 | 76 | 69 | 6E | 67 | 20 | 74 |
| | 68 | 69 | 73 | 20 | 63 | 6F | 6D | 6D | 61 | 6E | 64 | 2C |
| | 20 | 74 | 68 | 65 | 20 | 4D | 45 | 20 | 73 | 68 | 61 | 6C |
| | 6C | 20 | 63 | 68 | 65 | 63 | 6B | 20 | 69 | 66 | 20 | 69 |
| | 74 | 20 | 69 | 73 | 20 | 63 | 75 | 72 | 72 | 65 | 6E | 74 |
| | 6C | 79 | 20 | 69 | 6E | 2C | 20 | 6F | 72 | 20 | 69 | 6E |
| | 20 | 74 | 68 | 65 | 20 | 70 | 72 | 6F | 63 | 65 | 73 | 73 |
| | 20 | 6F | 66 | 20 | 73 | 65 | 74 | 74 | 69 | 6E | 67 | 20 |
| | 75 | 70 | 20 | 28 | 53 | 45 | 54 | 2D | 55 | 50 | 20 | 6D |
| | 65 | 73 | 73 | 61 | 67 | 65 | 20 | 73 | 65 | 6E | 74 | 20 |
| | 74 | 6F | 20 | 74 | 68 | 65 | 20 | 6E | 65 | 74 | 77 | 6F |
| | 72 | 6B | 2C | 20 | 73 | 65 | 65 | 20 | 47 | 53 | 4D | 22 |
| | 30 | 34 | 2E | 30 | 38 | 22 | 28 | 38 | 29 | 29 | 2C | 20 |
| | 61 | 20 | 73 | 70 | 65 | 65 | 63 | 68 | 20 | 63 | 61 | 6C |
| | 6C | 2E | 20 | 2D | 20 | 49 | 66 | 20 | 74 | 68 | 65 | 20 |
| | 4D | 45 | 20 | 49 | | | | | | | | |

PROACTIVE COMMAND: PLAY TONE 1.1.11

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Earpiece
Alpha identifier: "Beep"

Tone: ME proprietary tones: general beep

Duration

Time unit: Seconds
Time interval: 1

Coding:

| BER-TLV: | D0 | 16 | 81 | 03 | 01 | 20 | 00 | 82 | 02 | 81 | 03 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 04 | 42 | 65 | 65 | 70 | 8E | 01 | 10 | 84 | 02 | 01 | 01 |

PROACTIVE COMMAND: PLAY TONE 1.1.12

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Earpiece
Alpha identifier: "Positive"

Tone: ME proprietary tones: positive acknowledgement tone

Duration

Time unit: Seconds
Time interval: 1

Coding:

| BER-TLV: | D0 | 1A | 81 | 03 | 01 | 20 | 00 | 82 | 02 | 81 | 03 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 80 | 50 | 6F | 73 | 69 | 74 | 69 | 76 | 65 | 8E | 01 | 11 |
| | 84 | 02 | 01 | 01 | | | | | | | | |

PROACTIVE COMMAND: PLAY TONE 1.1.13

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Earpiece
Alpha identifier: "Negative"

Tone: ME proprietary tones: negative acknowledgement tone

Duration

Time unit: Seconds
Time interval: 1

Coding:

| BER-TLV: | D0 | 1A | 81 | 03 | 01 | 20 | 00 | 82 | 02 | 81 | 03 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| · | 80 | 4E | 65 | 67 | 61 | 74 | 69 | 76 | 65 | 8E | 01 | 12 |
| | 84 | 02 | 01 | 01 | | | | | | | | |

PROACTIVE COMMAND: PLAY TONE 1.1.14

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Earpiece
Alpha identifier: "Quick"

Tone: ME proprietary tones: general beep

Duration

Time unit: Tenths of seconds

Time interval: 2

| BER-TLV: | D0 | 17 | 81 | 03 | 01 | 20 | 00 | 82 | 02 | 81 | 03 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 05 | 51 | 75 | 69 | 63 | 6B | 8E | 01 | 10 | 84 | 02 | 02 |
| | 02 | | | | | | | | | | | |

PROACTIVE COMMAND: PLAY TONE 1.1.15

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Earpiece
Alpha identifier: "<ABORT>"

Tone: Standard supervisory tones: Error / Special information

Duration

Time unit: Minutes
Time interval: 1

Coding:

| BER-TLV: | D0 | 19 | 81 | 03 | 01 | 20 | 00 | 82 | 02 | 81 | 03 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| - | 07 | 3C | 41 | 42 | 4F | 52 | 54 | 3E | 8E | 01 | 06 | 84 |
| | 02 | 00 | 01 | | | | | | | | | |

PROACTIVE COMMAND: PLAY TONE 1.1.16

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Earpiece

Coding:

| BER-TLV: | D0 | 09 | 81 | 03 | 01 | 20 | 00 | 82 | 02 | 81 | 03 | |
|----------|----|----|----|----|----|----|----|----|----|----|----|--|
| · | | | | | | | | | | | | |

TERMINAL RESPONSE: PLAY TONE 1.1.1 ... 1.1.9, 1.1.16

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

| | | | | | | | 00 | | | | | |
|----------|------|----|------|----|----|----|----|----|----|----|------|----|
| BER-TLV: | l 81 | 03 | l 01 | 20 | 00 | 82 | 02 | 82 | 81 | 83 | l 01 | 00 |

TERMINAL RESPONSE: PLAY TONE 1.1.10a ... 1.1.14a

Logically:

Command details

Command number:

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 20 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
|----------|----|----|----|----|----|----|----|----|----|----|----|----|

TERMINAL RESPONSE: PLAY TONE 1.1.10b ..1.1.14b

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command beyond ME's capabilities

Coding:

| BER-TLV: 81 | 03 | 01 | 20 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 30 | l |
|-------------|----|----|----|----|----|----|----|----|----|----|----|---|
|-------------|----|----|----|----|----|----|----|----|----|----|----|---|

TERMINAL RESPONSE: PLAY TONE 1.1.15

Logically:

Command details

Command number:

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Proactive SIM session terminated by user

Coding:

| E | BER-TLV: | 81 | 03 | 01 | 20 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 10 | l |
|---|----------|----|----|----|----|----|----|----|----|----|----|----|----|---|
|---|----------|----|----|----|----|----|----|----|----|----|----|----|----|---|

27.22.4.5.5 Test requirement

The ME shall operate in the manner defined in expected sequence 1.1.

27.22.4.6 POLL INTERVAL

27.22.4.6.1 Definition and applicability

See clause 3.2.2.

27.22.4.6.2 Conformance requirement

The ME shall support the POLL INTERVAL command as defined in:

• 3GPP TS 11.14 [15] clause 6.1, clause 6.4.6, clause 6.6.6, clause 5.2, clause 12.6, clause 12.7 and clause 12.8.

27.22.4.6.3 Test purpose

To verify that the ME shall send a TERMINAL RESPONSE (OK) to the SIM after the ME receives the POLL INTERVAL proactive SIM command.

To verify that the ME gives a valid response to the polling interval requested by the SIM.

To verify that the ME sends STATUS commands to the SIM at an interval no longer than the interval negotiated by the SIM.

27.22.4.6.4 Method of test

27.22.4.6.4.1 Initial conditions

The ME is connected to the SIM Simulator.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.6.4.2 Procedure

Expected Sequence 1.1 (POLL INTERVAL, Seconds)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|------------------------------------|---|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: POLL INTERVAL 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: POLL | [Duration: 20 seconds] |
| | | INTERVAL 1.1.1 | |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: POLL | [Command performed successfully, duration |
| | | INTERVAL 1.1.1 | depends on the ME"s capabilities] |
| 5 | $ME \rightarrow SIM$ | ME polls in intervals as stated in | |
| | | the duration TLV of TERMINAL | |
| | | RESPONSE: POLL INTERVAL | |
| | | 1.1.1 | |

PROACTIVE COMMAND: POLL INTERVAL 1.1.1

Logically:

Command details

Command number:

Command type: POLL INTERVAL

Command qualifier: "00"

Device identities

Source device: SIM Destination device: ME

Duration

Time unit: Seconds
Time interval: 20

Coding:

| BER-TLV: | D0 | 0D | 81 | 03 | 01 | 03 | 00 | 82 | 02 | 81 | 82 | 84 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 02 | 01 | 14 | | | | | | | | | |

TERMINAL RESPONSE: POLL INTERVAL 1.1.1

Logically:

Command details

Command number:

Command type: POLL INTERVAL

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Duration

Time unit: Seconds
Time interval: 20

Coding:

| BER-TLV: | 81 | 03 | 01 | 03 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| · | 84 | 02 | 01 | 14 | | | | | | | | |

NOTE: If the requested poll interval is not supported by the ME, the ME is allowed to use a different one as stated in 3GPP TS 11.14 [13], subclause 6.4.6.

27.22.4.6.5 Test requirement

The ME shall operate in the manner defined in expected sequence 1.1.

27.22.4.7 REFRESH

27.22.4.7.1 REFRESH (normal)

27.22.4.7.1.1 Definition and applicability

See clause 3.2.2.

27.22.4.7.1.2 Conformance requirement

The ME shall support the REFRESH command as defined in:

• 3GPP TS 11.14 [15] clause 6.1, clause 6.4.7, clause 6.6.13, clause 5.2, clause 12.6, clause 12.7 and clause 12.18.

27.22.4.7.1.3 Test purpose

To verify that the ME performs the SIM initialization and / or re-reads the contents and structure of the EFs on the SIM that have been changed and / or restarts the card session by resetting the ME, and successfully returns the result of the execution of the command in the TERMINAL RESPONSE command send to the SIM.

27.22.4.7.1.4 Method of test

27.22.4.7.1.4.1 Initial conditions

The ME is connected to the SIM Simulator and only connected to the System Simulator if the System Simulator is mentioned in the sequence table. The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

Prior to the execution of expected sequence 1.2 the FDN service shall be enabled.

27.22.4.7.1.4.2 Procedure

Expected Sequence 1.1 (REFRESH, SIM Initialization)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--|--|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: REFRESH 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: | |
| | | REFRESH 1.1.1 | |
| 4 | SIM | Invalidate EF IMSI, EF LOCI and EF ADN | [Restricted dialling feature is enabled] |
| 5 | $ME \rightarrow SIM$ | SIM Initialization | [ME performs SIM initialization] |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: | |
| | | REFRESH 1.1.1A | |
| | | Or | |
| | | TERMINAL RESPONSE: | [additional EFs read] |
| | | REFRESH 1.1.1B | |
| 7 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION | |
| _ | | ENDED | |
| 8 | $USER \to ME$ | Call setup to "321" | |
| 9 | $ME \rightarrow USER$ | Call set up not allowed | |
| 10 | $USER \to ME$ | Call setup to "123" | |
| 11 | $ME \rightarrow SS$ | Setup | Called party BCD number shall be "123" |

PROACTIVE COMMAND: REFRESH 1.1.1

Logically:

Command details

Command number:

Command type: REFRESH
Command qualifier: SIM Initialization

Device identities

Source device: SIM
Destination device: ME

Coding:

| BER-TLV: | D0 | 09 | 81 | 03 | 01 | 01 | 03 | 82 | 02 | 81 | 82 | |
|----------|----|----|----|----|----|----|----|----|----|----|----|--|

TERMINAL RESPONSE: REFRESH 1.1.1A

Logically:

Command details

Command number: 1

Command type: REFRESH
Command qualifier: SIM Initialization

Device identities

Source device: ME

Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 01 03 82 02 82 81 83 01 00

TERMINAL RESPONSE: REFRESH 1.1.1B

Logically:

Command details

Command number: 1

Command type: REFRESH
Command qualifier: SIM Initialization

Device identities

Source device: ME Destination device: SIM

Result

General Result: REFRESH performed with additional EFs read

Coding:

BER-TLV: 81 03 01 01 03 82 02 82 81 83 01 03

Expected Sequence 1.2 (REFRESH, File Change Notification)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|----------------------------|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: REFRESH 1.2.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | |
| | | REFRESH 1.2.1 | |
| 4 | SIM | Update EF FDN RECORD 1 | [EF FDN record 1 updated to contain the |
| | | | dialling string "0123456789"] |
| 5 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: | [normal ending] |
| | | REFRESH 1.2.1A | |
| | | Or | |
| | | TERMINAL RESPONSE: | [additional EFs read] |
| | | REFRESH 1.2.1B | |
| 6 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION | |
| 7 | LICED ME | ENDED | |
| 7 | | Call setup to "123" | |
| 8 | | Call set up not allowed | |
| 9 | $USER \to ME$ | Call setup to "0123456789" | |
| 10 | $ME \to SS$ | Setup | Called party BCD number shall be |
| | | | "0123456789" |

PROACTIVE COMMAND: REFRESH 1.2.1

Logically:

Command details

Command number: 1

Command type: REFRESH

Command qualifier: File Change Notification

Device identities

Source device: SIM
Destination device: ME
File List: EF FDN

Coding:

| BER-TLV: | D0 | 12 | 81 | 03 | 01 | 01 | 01 | 82 | 02 | 81 | 82 | 92 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 07 | 01 | 3F | 00 | 7F | 10 | 6F | 3B | | | | |

TERMINAL RESPONSE: REFRESH 1.2.1A

Logically:

Command details

Command number: 1

Command type: REFRESH

Command qualifier: File Change Notification

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: |
|----------|
|----------|

TERMINAL RESPONSE: REFRESH 1.2.1B

Logically:

Command details

Command number: 1

Command type: REFRESH

Command qualifier: File Change Notification

Device identities

Source device: ME Destination device: SIM

Result

General Result: REFRESH performed with additional EFs read

Coding:

| BER-TLV: | 81 | 03 | 01 | 01 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 03 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|

Expected Sequence 1.3 (REFRESH, SIM Initialization and File Change Notification)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|-----------------------------|---|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: REFRESH 1.3.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: | |
| | | REFRESH 1.3.1 | |
| 4 | SIM | Update EF PLMN | [EF PLMN to contain the PLMN code "98798" |
| | | | as the first PLMN code] |
| 5 | $ME \rightarrow SIM$ | SIM initialization and READ | |
| | | BINARY: EF PLMN | |
| 6 | $ME \rightarrow SIM$ | | [normal ending] |
| | | REFRESH 1.3.1A | |
| | | Or | |
| | | TERMINAL RESPONSE: | [additional EFs read] |
| | | REFRESH 1.3.1B | |
| 7 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |

PROACTIVE COMMAND: REFRESH 1.3.1

Logically:

Command details

Command number: 1

Command type: REFRESH

Command qualifier: SIM Initialization and File Change Notification

Device identities

Source device: SIM
Destination device: ME
File List: EF PLMN

Coding:

| BER-TLV: | D0 | 12 | 81 | 03 | 01 | 01 | 02 | 82 | 02 | 81 | 82 | 92 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| · | 07 | 01 | 3F | 00 | 7F | 20 | 6F | 30 | | | | |

TERMINAL RESPONSE: REFRESH 1.3.1A

Logically:

Command details

Command number: 1

Command type: REFRESH

Command qualifier: SIM Initialization and File Change Notification

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 01 | 03 | 01 | 01 | 02 | 92 | 02 | 92 | 01 | 92 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| DEK-ILV. | 01 | 03 | UI | UI | 02 | 02 | 02 | 02 | 01 | ಂ | UI | 00 |

TERMINAL RESPONSE: REFRESH 1.3.1B

Logically:

Command details

Command number: 1

Command type: REFRESH

Command qualifier: SIM Initialization and File Change Notification

Device identities

Source device: ME Destination device: SIM

Result

General Result: REFRESH performed with additional EFs read

| BER | -TLV: | 81 | 03 | 01 | 01 | 02 | 82 | 02 | 82 | 81 | 83 | 01 | 03 | l |
|-----|-------|----|----|----|----|----|----|----|----|----|----|----|----|---|
|-----|-------|----|----|----|----|----|----|----|----|----|----|----|----|---|

Expected Sequence 1.4 (REFRESH, SIM Initialization and Full File Change Notification)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|---|---|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: REFRESH 1.4.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: REFRESH 1.4.1 | |
| 4 | SIM | Invalidate EF IMSI, EF LOCI and EF ADN | [Restricted dialling feature is enabled] |
| 5 | SIM | Update EF FDN | [EF FDN record 1 updated to contain the dialling string "0123456789"] |
| 6 | $ME \to SIM$ | SIM Initialization | [ME performs SIM initialization] |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: REFRESH 1.4.1A Or | |
| | | TERMINAL RESPONSE: REFRESH 1.4.1B | [additional EFs read] |
| 8 | $SIM \to ME$ | PROACTIVE SIM SESSION ENDED | |
| 9 | $USER \to ME$ | Call setup to "321" | |
| 10 | $ME \rightarrow USER$ | Call set up not allowed | |
| 11 | $USER \to ME$ | Call setup to "0123456789" | |
| 12 | $ME \rightarrow SS$ | Setup | Called party BCD number shall be "0123456789" |

PROACTIVE COMMAND: REFRESH 1.4.1

Logically:

Command details

Command number:

Command type: REFRESH

Command qualifier: SIM Initialization and Full File Change Notification

Device identities

Source device: SIM
Destination device: ME

Coding:

| BER-TLV: | D0 | 09 | 81 | 03 | 01 | 01 | 00 | 82 | 02 | 81 | 82 | | |
|----------|----|----|----|----|----|----|----|----|----|----|----|--|--|
|----------|----|----|----|----|----|----|----|----|----|----|----|--|--|

TERMINAL RESPONSE: REFRESH 1.4.1A

Logically:

Command details

Command number: 1

Command type: REFRESH

Command qualifier: SIM Initialization and Full File Change Notification

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

| BER-TI V· | 81 | 03 | 01 | 01 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|-----------|----|----|----|----|----|----|----|----|----|----|----|----|

TERMINAL RESPONSE: REFRESH 1.4.1B

Logically:

Command details

Command number: 1

Command type: REFRESH

Command qualifier: SIM Initialization and Full File Change Notification

Device identities

Source device: ME Destination device: SIM

Result

General Result: REFRESH performed with additional EFs read

Coding:

| BER-TLV: | 81 | 03 | 01 | 01 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 03 |
|----------|----|----|----|-----|----|----|----|----|----|----|----|----|
| DER-ILV. | 01 | 03 | 01 | O I | 00 | 02 | 02 | 02 | 01 | 03 | 01 | 03 |

Expected Sequence 1.5 (REFRESH, SIM Reset)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|---------------------------|------------------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: REFRESH 1.5.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: | |
| | | REFRESH 1.5.1 | |
| 4 | $ME \rightarrow SIM$ | GSM Termination Procedure | |
| 5 | $ME \rightarrow SIM$ | GSM Activation Procedure | |
| 6 | $ME \rightarrow SIM$ | SIM Initialization | |
| 7 | $ME \rightarrow SIM$ | | [NO TERMINAL RESPONSE] |

PROACTIVE COMMAND: REFRESH 1.5.1

Logically:

Command details

Command number: 1

Command type: REFRESH Command qualifier: SIM Reset

Device identities

Source device: SIM
Destination device: ME

| RFR-TI V· | DO | 09 | 81 | 03 | 01 | 01 | 04 | 82 | 02 | 81 | 82 | |
|-----------|----|----|----|----|----|----|----|----|----|----|----|--|

Expected Sequence 1.6 (REFRESH, SIM Initialization after SMS-PP data download)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|---|--|
| 1 | ME | The ME shall be in its normal idle mode | [Start a sequence to verify that the ME returns the RP-ACK message back to the system Simulator, if the SIM responds with '90 00'] |
| 2 | $SS \to ME$ | SMS-PP Data Download Message 1.6.1 | |
| 3 | $ME \to USER$ | The ME shall not display the message or alert the user of a short message waiting | |
| 4 | $ME \to SIM$ | ENVELOPE: SMS-PP DOWNLOAD 1.6.1 | |
| 5 | $SIM \to ME$ | PROACTIVE COMMAND PENDING: REFRESH 1.1.1 | |
| 6 | $ME \to SS$ | RP-ACK | |
| 7 | $ME \to SIM$ | FETCH | |
| 8 | $SIM \to ME$ | PROACTIVE COMMAND: REFRESH 1.1.1 | |
| 9 | SIM | Invalidate EF IMSI, EF LOCI and EF ADN | [Restricted dialling feature is enabled] |
| 10 | $ME \to SIM$ | SIM Initialization | [ME performs SIM initialization] |
| 11 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: REFRESH 1.1.1A Or | |
| | | TERMINAL RESPONSE: | [additional EFs read] |
| 12 | $SIM \to ME$ | REFRESH 1.1.1B PROACTIVE SIM SESSION ENDED | |
| 13 | $USER \to ME$ | Call setup to "321" | |
| 14 | $ME \to USER$ | Call set up not allowed | |
| 15 | $USER \to ME$ | Call setup to "123" | |
| 16 | $ME \to SS$ | Setup | Called party BCD number shall be "123" |

SMS-PP (Data Download) Message 1.6.1

Logically:

SMS TPDU

TP-MTI SMS-DELIVER

TP-MMS No more messages waiting for the MS in this SC
TP-RP TP-Reply-Path is not set in this SMS-DELIVER
TP-UDHI TP-UD field contains only the short message
TP-SRI A status report will not be returned to the SME

TP-OA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "1234"

TP-PID SIM Data download

TP-DCS

Coding Group General Data Coding Compression Text is uncompressed

Message Class Class 2 SIM Specific Message

Alphabet 8 bit data

TP-SCTS: 01/01/98 00:00:00 +0

TP-UDL 13

TP-UD "Short Message"

| Coding | 04 | 04 | 91 | 21 | 43 | 7F | 16 | 89 | 10 | 10 | 00 | 00 |
|--------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | 00 | 0D | 53 | 68 | 6F | 72 | 74 | 20 | 4D | 65 | 73 |
| | 73 | 61 | 67 | 65 | | | | | | | | |

ENVELOPE: SMS-PP DOWNLOAD 1.6.1

Logically:

SMS-PP Download

Device identities

Source device: Network
Destination device: SIM

Address

TON International number

NPI "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

SMS TPDU

TP-MTI SMS-DELIVER

TP-MMS No more messages waiting for the MS in this SC
TP-RP TP-Reply-Path is not set in this SMS-DELIVER
TP-UDHI TP-UD field contains only the short message
TP-SRI A status report will not be returned to the SME

TP-OA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "1234"

TP-PID SIM Data download

TP-DCS

Coding Group
Compression

Compr

Message Class Class 2 SIM Specific Message

Alphabet 8 bit data

TP-SCTS: 01/01/98 00:00:00 +0

TP-UDL 13

TP-UD "Short Message"

Coding:

| BER-TLV: | D1 | 2D | 82 | 02 | 83 | 81 | 06 | 09 | 91 | 11 | 22 | 33 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 44 | 55 | 66 | 77 | F8 | 8B | 1C | 04 | 04 | 91 | 21 | 43 |
| | 7F | 16 | 89 | 10 | 10 | 00 | 00 | 00 | 00 | 0D | 53 | 68 |
| | 6F | 72 | 74 | 20 | 4D | 65 | 73 | 73 | 61 | 67 | 65 | |

27.22.4.7.1.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.6.

27.22.4.7.2 REFRESH (IMSI changing procedure)

27.22.4.7.2.1 Definition and applicability

See clause 3.2.2.

27.22.4.7.2.2 Conformance requirement

The ME shall support the REFRESH command as defined in:

• 3GPP TS 11.14 [15] clause 6.1, clause 6.4.7, clause 6.6.13, clause 5.2, clause 12.6, clause 12.7 and clause 12.18.

Additionally the ME shall support the SIM Initialization procedure as defined in:

• 3GPP TS 11.11 [13] clause 12.2.1.

27.22.4.7.2.3 Test purpose

To verify that the ME performs the SIM initialization and / or re-reads the contents and structure of the EFs on the SIM that have been changed and / or restarts the card session by resetting the ME, and successfully returns the result of the execution of the command in the TERMINAL RESPONSE command send to the SIM.

27.22.4.7.2.4 Method of test

27.22.4.7.2.4.1 Initial conditions

The ME is connected to the SIM Simulator and only connected to the System Simulator if the System Simulator is mentioned in the sequence table. The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ATT flag broadcast in the L3-RR SYSTEM INFORMATION TYPE 3 message on the BCCH is set to "MSs shall apply IMSI attach and detach procedure" for Expected Sequences 2.2 and 2.3.

27.22.4.7.2.4.2 Procedure

Expected Sequence 2.1 (REFRESH, SIM Initialization and File Change Notification)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|---|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND PENDING: REFRESH 2.1.1 | |
| 2 | $ME \to SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: REFRESH 2.1.1 | |
| 4 | ME | Invoke MM Restart Procedure | |
| 5 | | SIM INITIALIZATION and the SIM will update EF IMSI, EF LOCI and EF KC after phase request TERMINAL RESPONSE: | [Update the contents of EF IMSI to "001010123456788", set the update status inside EF LOCI to not updated, Temporary Mobile Subscriber Identity (TMSI) in EF LOCI to "FF FF FF FF" and EF KC to not valid, ME performs SIM initialization; including reading EF IMSI, EF LOCI and EF KC] [normal] |
| | | REFRESH 2.1.1A Or TERMINAL RESPONSE: REFRESH 2.1.1B | [additional EFs read] |
| 7 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION ENDED | |
| 8 | $ME \to SS$ | Location updating request (type "normal location updating") | [Send IMSI of "001010123456788" to System Simulator] |

PROACTIVE COMMAND: REFRESH 2.1.1

Logically:

Command details

Command number:

Command type: REFRESH

Command qualifier: SIM Initialization and File Change Notification

Device identities

Source device: SIM Destination device: ME

File List

File 1: EF IMSI

File 2: EF LOCI File 3: EF KC

Coding:

| BER-TLV: | D0 | 1E | 81 | 03 | 01 | 01 | 02 | 82 | 02 | 81 | 82 | 92 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 13 | 03 | 3F | 00 | 7F | 20 | 6F | 07 | 3F | 00 | 7F | 20 |
| | 6F | 7E | 3F | 00 | 7F | 20 | 6F | 20 | | | | |

TERMINAL RESPONSE: REFRESH 2.1.1A

Logically:

Command details

Command number:

Command type: REFRESH

Command qualifier: SIM Initialization and File Change Notification

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 01 02 82 02 82 81 83 01 00

TERMINAL RESPONSE: REFRESH 2.1.1B

Logically:

Command details

Command number: 1

Command type: REFRESH

Command qualifier: SIM Initialization and File Change Notification

Device identities

Source device: ME Destination device: SIM

Result

General Result: REFRESH performed with additional EFs read

Coding:

BER-TLV: 81 03 01 01 02 82 02 82 81 83 01 03

Expected Sequence 2.2 (REFRESH, SIM Initialization and Full File Change Notification)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|--|--|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: REFRESH 2.2.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: REFRESH 2.2.1 | |
| 4 | ME | Invoke MM Restart Procedure | [including IMSI DETACH] |
| 5 | $ME \rightarrow SIM$ | SIM INITIALIZATION and the SIM will update EF IMSI and EF LOCI after phase request | [Update the contents of EF IMSI to "001010123456787", Temporary Mobile Subscriber Identity (TMSI) in EF LOCI be set to "FF FF FF"; ME performs SIM initialization; including reading EF IMSI, EF LOCI and EF KC] |
| 6 | ME → SIM | TERMINAL RESPONSE: REFRESH 2.2.1A Or TERMINAL RESPONSE: REFRESH 2.2.1B | [normal] [additional EFs read] |
| 7 | $SIM \to ME$ | PROACTIVE SIM SESSION ENDED | |
| 8 | $ME \rightarrow SS$ | IMSI ATTACH | [Send IMSI of "001010123456787" to System Simulator] |

PROACTIVE COMMAND: REFRESH 2.2.1

Logically:

Command details

Command number: 1

Command type: REFRESH

Command qualifier: SIM Initialization and Full File Change Notification

Device identities

Source device: SIM
Destination device: ME

Coding:

| BER-TLV: D | 00 09 | 81 | 03 | 01 | 01 | 00 | 82 | 02 | 81 | 82 |
|------------|-------|----|----|----|----|----|----|----|----|----|
|------------|-------|----|----|----|----|----|----|----|----|----|

TERMINAL RESPONSE: REFRESH 2.2.1A

Logically:

Command details

Command number: 1

Command type: REFRESH

Command qualifier: SIM Initialization and File Change Notification

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

| BER-TLV: | 81 | 03 | 01 | 01 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 | ı |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|---|
|----------|----|----|----|----|----|----|----|----|----|----|----|----|---|

TERMINAL RESPONSE: REFRESH 2.2.1B

Logically:

Command details

Command number: 1

Command type: REFRESH

Command qualifier: SIM Initialization and File Change Notification

Device identities

Source device: ME Destination device: SIM

Result

General Result: REFRESH performed with additional EFs read

Coding:

| BER-TLV: | 81 | 03 | 01 | 01 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 03 |
|-----------|----|----|----|-----|----|----|----|----|----|----|----|----|
| DEIX-IEV. | 01 | 03 | 01 | O I | 00 | 02 | 02 | 02 | 01 | 00 | 01 | 03 |

Expected Sequence 2.3 (REFRESH, SIM Reset)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|-------------------------------------|---|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: REFRESH 2.3.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: | |
| | | REFRESH 2.3.1 | |
| 4 | $ME \rightarrow SIM$ | GSM Session Termination | |
| | | Procedure | |
| 5 | $ME \rightarrow SS$ | IMSI DETACH | |
| 6 | $ME \rightarrow SIM$ | SIM Initialization and the SIM will | [Update the contents of EF IMSI to |
| | | update EF IMSI and EF LOCI after | "001010123456786', Temporary Mobile |
| | | phase request | Subscriber Identity (TMSI) in EF LOCI be set |
| | | | to "FF FF FF"; ME performs SIM |
| | | | initialization; including reading EF IMSI, EF |
| | | | LOCI and EF KC] |
| 7 | $ME \rightarrow SS$ | IMSI ATTACH | [Send IMSI of "001010123456786" to System |
| | | | Simulator] |

PROACTIVE COMMAND: REFRESH 2.3.1

Logically:

Command details

Command number: 1

Command type: REFRESH Command qualifier: SIM Reset

Device identities

Source device: SIM
Destination device: ME

Coding:

| BER-TLV: | D0 | 09 | 81 | 03 | 01 | 01 | 04 | 82 | 02 | 81 | 82 |
|----------|----|----|----|----|----|----|----|----|----|----|----|

27.22.4.7.2.5 Test requirement

The ME shall operate in the manner defined in expected sequences 2.1 to 2.3.

27.22.4.8 SET UP MENU and ENVELOPE MENU SELECTION

27.22.4.8.1 SET UP MENU (normal) and ENVELOPE MENU SELECTION

27.22.4.8.1.1 Definition and applicability

See clause 3.2.2.

27.22.4.8.1.2 Conformance requirement

The ME shall support the SET UP MENU command as defined in:

• 3GPP TS 11.14 clause 5, clause 6.4.8, clause 6.6.7, clause 6.8, clause 6.11, clause 12.6, clause 12.9 and clause 13.4.

The ME shall support MENU SELECTION as defined in:

• 3GPP TS 11.14 [15] clause 4.4, clause 5.2, clause 6.4.8, clause 6.9, clause 8, clause 12.7 and clause 12.10.

27.22.4.8.1.3 Test purpose

To verify that the ME correctly integrates the menu items contained in the SET UP MENU proactive SIM command, and returns a successful response in the TERMINAL RESPONSE command sent to the SIM.

To verify that the ME replaces the current list of menu items with the list of menu items contained in the SET UP MENU command.

To verify that the ME removes the current list of menu items following receipt of a SET UP MENU command with no items.

To verify that the ME correctly passes the identifier of the selected menu item to the SIM using the ENVELOPE (MENU SELECTION) command.

To verify that when the help is available for the command and the user gas indicated the need to get help information on one of the items, the ME informs properly the SIM about an HELP REQUEST, using the MENU SELECTION mechanism.

27.22.4.8.1.4 Method of test

27.22.4.8.1.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

The ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

27.22.4.8.1.4.2 Procedure

Expected Sequence 1.1 (SET UP MENU and MENU SELECTION, without Help Request, Replace and Remove a Toolkit Menu)

| Step | Direction | MESSAGE / Action | Comments |
|------|--|---|--|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | [First Set Up Menu] |
| | | PENDING: SET UP MENU 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND SET UP | |
| 4 | ME LICED | MENU 1.1.1 | |
| 4 | $ME \rightarrow USER$ | Integrate the menu header of "Toolkit Menu" into its menu | |
| | | system and have the menu items | |
| | | of "Item 1", "Item 2", "Item 3" and | |
| | | "Item 4" under this header. | |
| 5 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP | [Command Performed Successfully] |
| | | MENU 1.1.1 | |
| 6 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION | |
| | $USER \to ME$ | ENDED Select the Toolkit Menu "Toolkit | |
| 7 | USER → IVIE | Menu" | |
| | $ME \to USER$ | Display "Item 1", "Item 2", "Item 3", | |
| 8 | | "Item 4" | |
| 9 | $USER \to ME$ | Select the "Item 2" Menu entry | |
| | $ME \rightarrow SIM$ | Send the ENVELOPE 1.1.1: | |
| 10 | | MENU SELECTION | |
| 14 | OIM ME | (Identifier of item: 2) PROACTIVE COMMAND | [Cocond Cot In Many DEDI ACE Old Many] |
| 11 | $SIM \rightarrow ME$ | PENDING: SET UP MENU 1.1.2 | [Second Set Up Menu, REPLACE Old Menu] |
| 12 | $ME \to SIM$ | FETCH | |
| 13 | $SIM \rightarrow ME$ | PROACTIVE COMMAND SET UP | |
| | J 7 | MENU 1.1.2 | |
| 14 | $ME \rightarrow USER$ | Integrate the new menu header of | |
| | | "Toolkit Menu" into its menu | |
| | | system and have the menu items | |
| | | of "One" and "Two" under this header. | |
| 15 | $ME \to SIM$ | TERMINAL RESPONSE: SET UP | [Command Performed Successfully] |
| | WIE 7 ONVI | MENU 1.1.2 | [command renormed edecectally] |
| 16 | $SIM \to ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |
| 17 | $USER \to ME$ | Select the Toolkit Menu "Toolkit | |
| | ME LIGED | Menu" | |
| 18 | ME → USER | Display "One", "Two" | |
| 19 | $\begin{array}{c} USER \to ME \\ ME \to SIM \end{array}$ | Select the "Two" menu entry Send the ENVELOPE 1.1.2: | |
| 20 | IVIL -> SIIVI | MENU SELECTION | |
| _, | | (Identifier of item: 12) | |
| 21 | $SIM \to ME$ | PROACTIVE COMMAND | [Third Set Up Menu, REMOVE Toolkit Menu] |
| 1 | | PENDING: SET UP MENU 1.1.3 | |
| 00 | NAE 0 | with SW1 / SW2 of '91 0F'. | |
| 22 | $ME \rightarrow SIM$ | FETCH | |
| 23 | $SIM \rightarrow ME$ | PROACTIVE COMMAND SET UP MENU 1.1.3 | |
| 24 | ME → USER | Remove the menu "Toolkit Menu" | |
| | WIL / OOLIK | from its menu system. | |
| 25 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP | [Command Performed Successfully] |
| | | MENU 1.1.3 | |
| 26 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION | |
| 0.7 | | ENDED | |
| 27 | $USER \to ME$ | Has to unsuccessfully find the Toolkit Menu | |
| L | | I DOINIL MEHU | |

PROACTIVE COMMAND: SET UP MENU 1.1.1

Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: "00"

Device identities

Source device: SIM Destination device: ME

Alpha identifier: "Toolkit Menu"

Item

Identifier of item: 1

Text string of item: "Item 1"

Item

Identifier of item: 2

Text string of item: "Item 2"

Item

Identifier of item: 3

Text string of item: "Item 3"

Item

Identifier of item: 4

Text string of item: "Item 4"

Coding:

| BER-TLV: | D0 | 3B | 81 | 03 | 01 | 25 | 00 | 82 | 02 | 81 | 82 | 85 |
|------------|----|----|----|----|----|----|----|----|----|----|----|----|
| \ <u>-</u> | 0C | 54 | 6F | 6F | 6C | 6B | 69 | 74 | 20 | 4D | 65 | 6E |
| | 75 | 8F | 07 | 01 | 49 | 74 | 65 | 6D | 20 | 31 | 8F | 07 |
| | 02 | 49 | 74 | 65 | 6D | 20 | 32 | 8F | 07 | 03 | 49 | 74 |
| | 65 | 6D | 20 | 33 | 8F | 07 | 04 | 49 | 74 | 65 | 6D | 20 |
| | 34 | | | | | | | | | | | |

PROACTIVE COMMAND: SET UP MENU 1.1.2

Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha identifier: "Toolkit Menu"

Item

Identifier of item: "11"

Text string of item: "One"

Item

Identifier of item: "12" Text string of item: "Two"

| BER-TLV: | D0 | 23 | 81 | 03 | 01 | 25 | 00 | 82 | 02 | 81 | 82 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0C | 54 | 6F | 6F | 6C | 6B | 69 | 74 | 20 | 4D | 65 | 6E |
| | 75 | 8F | 04 | 11 | 4F | 6E | 65 | 8F | 04 | 12 | 54 | 77 |
| | 6F | | | | | | | | | | | |

PROACTIVE COMMAND: SET UP MENU 1.1.3

Logically:

Command details

Command number:

Command type: SET UP MENU

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME
Item: Empty

Coding:

| BER-TLV: | D0 | 0D | 81 | 03 | 01 | 25 | 00 | 82 | 02 | 81 | 82 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | 8F | 00 | | | | | | | | | |

TERMINAL RESPONSE: SET UP MENU 1.1.1, 1.1.2 and 1.1.3

Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: "no help information available"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| DED TIV | 0.4 | 00 | 0.4 | 25 | 00 | 0.0 | 00 | 0.0 | 0.4 | 0.2 | Ω1 | 00 |
|----------|-----|----|-----|----|----|-----|----|-----|-----|-----|----|----|
| BER-TLV: | 81 | 03 | 01 | 25 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |

ENVELOPE 1.1.1: MENU SELECTION

Logically:

Menu selection

Device identities

Source device: Keypad Destination device: SIM Item identifier 02

Coding:

| BER-TLV: | D3 | 07 | 82 | 02 | 01 | 81 | 90 | 01 | 02 | |
|----------|----|----|----|----|----|----|----|----|----|--|
|----------|----|----|----|----|----|----|----|----|----|--|

ENVELOPE 1.1.2: MENU SELECTION

Logically:

Menu selection

Device identities

Source device: Keypad Destination device: SIM Item identifier 12 Coding:

| BER-TLV: | D3 | 07 | 82 | 02 | 01 | 81 | 90 | 01 | 12 |
|----------|----|----|----|----|----|----|----|----|----|

Expected Sequence 1.2 (SET UP MENU, Large Menu with many items or with large items or with Large Alpha Identifier)

| 1 | 0184 845 | | Comments |
|----|---------------------------|---|--|
| | $SIM \rightarrow ME$ | PROACTIVE COMMAND | [First Large Menu with many items, Fetch of |
| | ME CIM | PENDING: SET UP MENU 1.2.1 FETCH | FF bytes] |
| 3 | $ME \to SIM$ $SIM \to ME$ | PROACTIVE COMMAND SET UP | |
| | Olivi -> IVIL | MENU 1.2.1 | |
| 4 | $ME \to USER$ | Integrate the new menu header of | |
| | | "LargeMenu1" into its menu | |
| | | system and have the menu items | |
| | | of "Zero", "One", "Two", Three", "Four", "Five", "Six", "Seven", | |
| | | "Eight", "Nine", "Alpha", "Bravo", | |
| | | "Charlie", "Delta", "Echo", "Fox- | |
| | | trot", "Black", "Brown", "Red", | |
| | | "Orange", "Yellow", "Green", | |
| | | "Blue", "Violet", "Grey", "White", "milli", "micro", "nano" and "pico" | |
| | | under this header. | |
| 5 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP | [Command Performed Successfully] |
| | | MENU 1.2.1 | |
| 6 | $SIM \to ME$ | PROACTIVE SIM SESSION ENDED | |
| 7 | $USER \to ME$ | Select the Toolkit "LargeMenu1" | |
| 8 | $ME \rightarrow USER$ | Display "Zero", "One", "Two" | |
| | WE 7 COLIC | "pico" | |
| 9 | $USER \to ME$ | Select the "Orange" menu entry | |
| 10 | $ME \to SIM$ | Send the ENVELOPE 1.2.1: | |
| | | MENU SELECTION | |
| 11 | $SIM \to ME$ | (Identifier of item: 0x3D) PROACTIVE COMMAND | [Second Large Menu with large items, Fetch |
| | OIM / ME | PENDING: SET UP MENU 1.2.2 | of F6 bytes] |
| 12 | $ME \to SIM$ | FETCH | |
| 13 | $SIM \to ME$ | PROACTIVE COMMAND SET UP | |
| 14 | $ME \to USER$ | MENU 1.2.2 Integrate the new menu header of | |
| 14 | WIL -> OOLK | "LargeMenu2" into its menu | |
| | | system and have the menu items | |
| | | of "1 Call Forward Unconditional", | |
| | | "2 Call Forward On User Busy", "3 Call Forward On No Reply", "4 Call | |
| | | Forward On User Not Reachable", | |
| | | "5 Barring Of All Outgoing Calls", | |
| | | "6 Barring Of All Outgoing Int | |
| | | Calls" and "7 CLI Presentation" | |
| 15 | $ME \rightarrow SIM$ | under this header. TERMINAL RESPONSE: SET UP | [Command Performed Successfully] |
| '` | IVIL -> OIIVI | MENU 1.2.2 | Learning is a second of the se |
| 16 | $SIM \to ME$ | PROACTIVE SIM SESSION | |
| 47 | LICED ME | ENDED | |
| 17 | $USER \to ME$ | Select the Toolkit Menu "LargeMenu2" | |
| 18 | $ME \rightarrow USER$ | Display "1 Call Forward | |
| | | Unconditional", "2 Call Forward On | |
| | | User Busy", "3 Call Forward On No | |
| | | Reply", "4 Call Forward On User Not Reachable", "5 Barring Of All | |
| | | Outgoing Calls", "6 Barring Of All | |
| | | Outgoing Int Calls", "7 CLI | |
| | | Presentation" | |

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|--|--|
| 19 | $USER \to ME$ | Select the "5 Barring Of All | |
| | | Outgoing Calls" menu entry | |
| 20 | $ME \to SIM$ | Send the ENVELOPE 1.2.2: | |
| | | MENU SELECTION | |
| 21 | CIM . ME | (Identifier of item: 0xFB) PROACTIVE COMMAND | [Third Lorge Many with a Lorge Alpha |
| 21 | $SIM \rightarrow ME$ | PENDING: SET UP MENU 1.2.3 | [Third Large Menu with a Large Alpha Identifier and only one Short Item, Fetch of FF |
| | | LINDING. SET OF MENO 1.2.3 | bytes] |
| 22 | $ME \to SIM$ | FETCH | sytooj |
| 23 | $SIM \rightarrow ME$ | PROACTIVE COMMAND SET UP | |
| | O 7 | MENU 1.2.3 | |
| 24 | $ME \to USER$ | Integrate the new menu header of | |
| | | " The SIM shall supply a set of | |
| | | menu items, which shall be | |
| | | integrated with the menu system | |
| | | (or other MMI facility) in order to | |
| | | give the user the opportunity to | |
| | | choose one of these menu items at | |
| | | his own discretion. Each item | |
| | | comprises a sh" into it's menu system and have a menu item of | |
| | | "Y" under this header. | |
| 25 | $ME \to SIM$ | TERMINAL RESPONSE: SET UP | [Command Performed Successfully] |
| | IVIL / OIIVI | MENU 1.2.3 | [Command Ferromina Cassessiany] |
| 26 | $SIM \to ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |
| 27 | $USER \to ME$ | Select the Toolkit Menu "The SIM | |
| | | shall supply a set of menu items, | |
| | | which shall be integrated with the | |
| | | menu system (or other MMI | |
| | | facility) in order to give the user the | |
| | | opportunity to choose one of these menu items at his own discretion. | |
| | | Each item comprises a sh". | |
| 28 | $ME \to USER$ | Display "Y" | |
| 29 | USER → ME | Select the item "Y" | |
| 30 | $ME \rightarrow SIM$ | Send the ENVELOPE 1.2.3: | |
| | IVIL -> OIIVI | MENU SELECTION | |
| | | (Identifier of item: 1) | |

PROACTIVE COMMAND: SET UP MENU 1.2.1

Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: "00"

Device identities

Source device: SIM Destination device: ME

Alpha Identifier: "LargeMenu1"

Item

Identifier of item: "50" Text string of item: "Zero"

Item

Identifier of item: "4F"
Text string of item: "One"

Item

Identifier of item: "4E" Text string of item: "Two"

| Item | | |
|------|---|--------------------|
| | Identifier of item: Text string of item: | "4D" "Three" |
| Item | Identifier of item: Text string of item: | "4C" "Four" |
| Item | Identifier of item: Text string of item: | "4B" "Five" |
| Item | Identifier of item: Text string of item: | "4A" "Six" |
| Item | Identifier of item: | "49" |
| Item | Text string of item: Identifier of item: | "Seven" "48" |
| Item | Text string of item: Identifier of item: | "Eight" "47" |
| Item | Text string of item: Identifier of item: | "Nine" "46" |
| Item | Text string of item: | "Alpha" |
| Item | Identifier of item: Text string of item: | "45" "Bravo" |
| Item | Identifier of item: Text string of item: | "44" "Charlie" |
| Item | Identifier of item: Text string of item: | "43" "Delta" |
| _ | Identifier of item: Text string of item: | "42" "Echo" |
| Item | Identifier of item: Text string of item: | "41" "Fox-trot" |
| Item | Identifier of item: Text string of item: | "40" "Black" |
| Item | Identifier of item: | "3F" |
| Item | Text string of item: Identifier of item: | "Brown" "3E" |
| Item | Text string of item: Identifier of item: | "Red" "3D" |
| Item | Text string of item: Identifier of item: | "Orange" "3C" |
| Item | Text string of item: Identifier of item: | "Yellow" "3B" |
| Item | Text string of item: | "Green" |
| | Identifier of item: Text string of item: | "3A" "Blue" |

Item

"39" Identifier of item: "Violet"

Text string of item:

Item

"38" Identifier of item:

Text string of item: "Grey"

Item

Identifier of item: "37"

"White" Text string of item:

Item

Identifier of item: "36" Text string of item: "milli"

Item

"35" Identifier of item:

Text string of item: "micro"

Item

"34" Identifier of item:

Text string of item: "nano"

Item

"33" Identifier of item: "pico" Text string of item:

Coding:

| BER-TLV: | D0 | 81 | FC | 81 | 03 | 01 | 25 | 00 | 82 | 02 | 81 | 82 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 85 | 0A | 4C | 61 | 72 | 67 | 65 | 4D | 65 | 6E | 75 | 31 |
| | 8F | 05 | 50 | 5A | 65 | 72 | 6F | 8F | 04 | 4F | 4F | 6E |
| | 65 | 8F | 04 | 4E | 54 | 77 | 6F | 8F | 06 | 4D | 54 | 68 |
| | 72 | 65 | 65 | 8F | 05 | 4C | 46 | 6F | 75 | 72 | 8F | 05 |
| | 4B | 46 | 69 | 76 | 65 | 8F | 04 | 4A | 53 | 69 | 78 | 8F |
| | 06 | 49 | 53 | 65 | 76 | 65 | 6E | 8F | 06 | 48 | 45 | 69 |
| | 67 | 68 | 74 | 8F | 05 | 47 | 4E | 69 | 6E | 65 | 8F | 06 |
| | 46 | 41 | 6C | 70 | 68 | 61 | 8F | 06 | 45 | 42 | 72 | 61 |
| | 76 | 6F | 8F | 08 | 44 | 43 | 68 | 61 | 72 | 6C | 69 | 65 |
| | 8F | 06 | 43 | 44 | 65 | 6C | 74 | 61 | 8F | 05 | 42 | 45 |
| | 63 | 68 | 6F | 8F | 09 | 41 | 46 | 6F | 78 | 2D | 74 | 72 |
| | 6F | 74 | 8F | 06 | 40 | 42 | 6C | 61 | 63 | 6B | 8F | 06 |
| | 3F | 42 | 72 | 6F | 77 | 6E | 8F | 04 | 3E | 52 | 65 | 64 |
| | 8F | 07 | 3D | 4F | 72 | 61 | 6E | 67 | 65 | 8F | 07 | 3C |
| | 59 | 65 | 6C | 6C | 6F | 77 | 8F | 06 | 3B | 47 | 72 | 65 |
| | 65 | 6E | 8F | 05 | 3A | 42 | 6C | 75 | 65 | 8F | 07 | 39 |
| | 56 | 69 | 6F | 6C | 65 | 74 | 8F | 05 | 38 | 47 | 72 | 65 |
| | 79 | 8F | 06 | 37 | 57 | 68 | 69 | 74 | 65 | 8F | 06 | 36 |
| | 6D | 69 | 6C | 6C | 69 | 8F | 06 | 35 | 6D | 69 | 63 | 72 |
| | 6F | 8F | 05 | 34 | 6E | 61 | 6E | 6F | 8F | 05 | 33 | 70 |
| | 69 | 63 | 6F | | | | | | | | | |

PROACTIVE COMMAND: SET UP MENU 1.2.2

Logically:

Command details

Command number:

SET UP MENU Command type:

Command qualifier: "00"

Device identities

SIM Source device: Destination device: ME

Alpha Identifier: "LargeMenu2"

Item

Identifier of item:

Text string of item: "1 Call Forward Unconditional" Item

Identifier of item: "FE"

Text string of item: "2 Call Forward On User Busy"

Item

Identifier of item: "FD"

Text string of item: "3 Call Forward On No Reply"

Item

Identifier of item: "FC"

Text string of item: "4 Call Forward On User Not Reachable"

Item

Identifier of item: "FB"

Text string of item: "5 Barring Of All Outgoing Calls"

Item

Identifier of item: "FA"

Text string of item: "6 Barring Of All Outgoing Int Calls"

Item

Identifier of item: "F9"

Text string of item: "7 CLI Presentation"

Coding:

| DED TIVE | Ι ΒΛ | 0.4 | ГΩ | 0.4 | 00 | 04 | 25 | 00 | 00 | 00 | 0.4 | 00 |
|----------|------|-----|----|-----|----|----|----|----|----|----|-----|----|
| BER-TLV: | D0 | 81 | F3 | 81 | 03 | 01 | 25 | 00 | 82 | 02 | 81 | 82 |
| | 85 | 0A | 4C | 61 | 72 | 67 | 65 | 4D | 65 | 6E | 75 | 32 |
| | 8F | 1D | FF | 31 | 20 | 43 | 61 | 6C | 6C | 20 | 46 | 6F |
| | 72 | 77 | 61 | 72 | 64 | 20 | 55 | 6E | 63 | 6F | 6E | 64 |
| | 69 | 74 | 69 | 6F | 6E | 61 | 6C | 8F | 1C | FE | 32 | 20 |
| | 43 | 61 | 6C | 6C | 20 | 46 | 6F | 72 | 77 | 61 | 72 | 64 |
| | 20 | 4F | 6E | 20 | 55 | 73 | 65 | 72 | 20 | 42 | 75 | 73 |
| | 79 | 8F | 1B | FD | 33 | 20 | 43 | 61 | 6C | 6C | 20 | 46 |
| | 6F | 72 | 77 | 61 | 72 | 64 | 20 | 4F | 6E | 20 | 4E | 6F |
| | 20 | 52 | 65 | 70 | 6C | 79 | 8F | 25 | FC | 34 | 20 | 43 |
| | 61 | 6C | 6C | 20 | 46 | 6F | 72 | 77 | 61 | 72 | 64 | 20 |
| | 4F | 6E | 20 | 55 | 73 | 65 | 72 | 20 | 4E | 6F | 74 | 20 |
| | 52 | 65 | 61 | 63 | 68 | 61 | 62 | 6C | 65 | 8F | 20 | FB |
| | 35 | 20 | 42 | 61 | 72 | 72 | 69 | 6E | 67 | 20 | 4F | 66 |
| | 20 | 41 | 6C | 6C | 20 | 4F | 75 | 74 | 67 | 6F | 69 | 6E |
| | 67 | 20 | 43 | 61 | 6C | 6C | 73 | 8F | 24 | FA | 36 | 20 |
| | 42 | 61 | 72 | 72 | 69 | 6E | 67 | 20 | 4F | 66 | 20 | 41 |
| | 6C | 6C | 20 | 4F | 75 | 74 | 67 | 6F | 69 | 6E | 67 | 20 |
| | 49 | 6E | 74 | 20 | 43 | 61 | 6C | 6C | 73 | 8F | 13 | F9 |
| | 37 | 20 | 43 | 4C | 49 | 20 | 50 | 72 | 65 | 73 | 65 | 6E |
| | 74 | 61 | 74 | 69 | 6F | 6E | | | | | | |

PROACTIVE COMMAND: SET UP MENU 1.2.3

Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: "00"

Device identities

Source device: SIM Destination device: ME

Alpha Identifier: "The SIM shall supply a set of menu items, which shall be integrated with the menu

system (or other MMI facility) in order to give the user the opportunity to choose

one of these menu items at his own discretion. Each item comprises a sh"

Item

Identifier of item: "01" Text string of item: "Y"

Coding:

| | 1 | | | | | | | | | | | |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| BER-TLV: | D0 | 81 | FC | 81 | 03 | 01 | 25 | 00 | 82 | 02 | 81 | 82 |
| | 85 | 81 | EC | 54 | 68 | 65 | 20 | 53 | 49 | 4D | 20 | 73 |
| | 68 | 61 | 6C | 6C | 20 | 73 | 75 | 70 | 70 | 6C | 79 | 20 |
| | 61 | 20 | 73 | 65 | 74 | 20 | 6F | 66 | 20 | 6D | 65 | 6E |
| | 75 | 20 | 69 | 74 | 65 | 6D | 73 | 2C | 20 | 77 | 68 | 69 |
| | 63 | 68 | 20 | 73 | 68 | 61 | 6C | 6C | 20 | 62 | 65 | 20 |
| | 69 | 6E | 74 | 65 | 67 | 72 | 61 | 74 | 65 | 64 | 20 | 77 |
| | 69 | 74 | 68 | 20 | 74 | 68 | 65 | 20 | 6D | 65 | 6E | 75 |
| | 20 | 73 | 79 | 73 | 74 | 65 | 6D | 20 | 28 | 6F | 72 | 20 |
| | 6F | 74 | 68 | 65 | 72 | 20 | 4D | 4D | 49 | 20 | 66 | 61 |
| | 63 | 69 | 6C | 69 | 74 | 79 | 29 | 20 | 69 | 6E | 20 | 6F |
| | 72 | 64 | 65 | 72 | 20 | 74 | 6F | 20 | 67 | 69 | 76 | 65 |
| | 20 | 74 | 68 | 65 | 20 | 75 | 73 | 65 | 72 | 20 | 74 | 68 |
| | 65 | 20 | 6F | 70 | 70 | 6F | 72 | 74 | 75 | 6E | 69 | 74 |
| | 79 | 20 | 74 | 6F | 20 | 63 | 68 | 6F | 6F | 73 | 65 | 20 |
| | 6F | 6E | 65 | 20 | 6F | 66 | 20 | 74 | 68 | 65 | 73 | 65 |
| | 20 | 6D | 65 | 6E | 75 | 20 | 69 | 74 | 65 | 6D | 73 | 20 |
| | 61 | 74 | 20 | 68 | 69 | 73 | 20 | 6F | 77 | 6E | 20 | 64 |
| | 69 | 73 | 63 | 72 | 65 | 74 | 69 | 6F | 6E | 2E | 20 | 45 |
| | 61 | 63 | 68 | 20 | 69 | 74 | 65 | 6D | 20 | 63 | 6F | 6D |
| | 70 | 72 | 69 | 73 | 65 | 73 | 20 | 61 | 20 | 73 | 68 | 8F |
| | 02 | 01 | 59 | | | | | | | | | |
| | | | | | | | | | | | | • |

TERMINAL RESPONSE: SET UP MENU 1.2.1, 1.2.2 and 1.2.3

Logically:

Command details

Command number:

Command type: SET UP MENU

Command qualifier: "no help information available"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 25 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|

ENVELOPE 1.2.1: MENU SELECTION

Logically:

Menu selection

Device identities

Source device: Keypad Destination device: SIM Item identifier 3D

| BFR-TLV: | D3 | 07 | 92 | 02 | Ω1 | 81 | 90 | 01 | ЗD |
|-----------|-------|----|------|------|----|----|----|----|-----|
| IDENTILV. | 1.1.3 | | 1 02 | l UZ | | | 90 | | เอย |

ENVELOPE 1.2.2: MENU SELECTION

Logically:

Menu selection

Device identities

Source device: Keypad
Destination device: SIM
Item identifier FB

Coding:

| BER-TLV: | D3 | 07 | 82 | 02 | 01 | 81 | 90 | 01 | FB |
|----------|----|----|----|----|----|----|----|----|----|

ENVELOPE 1.2.3: MENU SELECTION

Logically:

Menu selection

Device identities

Source device: Keypad
Destination device: SIM
Item identifier 01

Coding:

| BER-TLV: | D3 | 07 | 82 | 02 | 01 | 81 | 90 | 01 | 01 |
|----------|----|----|----|----|----|----|----|----|----|

The following table details the test requirements with relation to the tested features:

| | Proactive S | IM Command | Facilities |
|------------------------------|----------------------------|-----------------|------------------------|
| Proactive SIM Command Number | Alpha Identifier Length | Number of items | Maximum length of item |
| 1.1.1 | 12 | 4 | 6 |
| 1.1.2 | 12 | 2 | 3 |
| 1.1.3 | 10 | 0 | - |
| 1.2.1 | 10 | 30 | 8 |
| 1.2.2 | 10 | 7 | 37 |
| 1.2.3 | 235 | 1 | 1 |

27.22.4.8.1.5 Test requirement

The ME shall operate in the manner defined in expected sequence 1.1 and in expected sequence 1.2.

27.22.4.8.2 SET UP MENU (help request support) and ENVELOPE MENU SELECTION

27.22.4.8.2.1 Definition and applicability

See clause 3.2.2.

27.22.4.8.2.2 Conformance requirement

Requirements are the same as in clause 27.22.4.8.1.1, with an additional one:

• 3GPP TS 11.14 [15] clause 12.21.

27.22.4.8.2.3 Test purpose

To verify that the ME correctly integrates the menu items contained in the SET UP MENU proactive SIM command, and returns a successful response in the TERMINAL RESPONSE command sent to the SIM.

To verify that when the help is available for the command and the user has indicated the need to get help information on one of the items, the ME informs properly the SIM about an HELP REQUEST, using the MENU SELECTION mechanism.

To verify that the ME correctly passes the identifier of the selected menu item to the SIM using the ENVELOPE (MENU SELECTION) command.

27.22.4.8.2.4 Method of test

27.22.4.8.2.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

The ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

27.22.4.8.2.4.2 Procedure

Expected Sequence 2.1 (SET UP MENU and MENU SELECTION, with Help Request, Replace and Remove a Toolkit Menu)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|---|---------------------------------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | [First Set Up Menu] |
| | | PENDING: SET UP MENU 2.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND SET UP | |
| | | MENU 2.1.1 | |
| 4 | $ME \rightarrow USER$ | Integrate the menu header of | |
| | | "Toolkit Menu" into its menu | |
| | | system and have the menu items | |
| | | of "Item 1", "Item 2", "Item 3" and "Item 4" under this header. | |
| 5 | $ME \rightarrow SIM$ | | [Command Performed Successfully] |
| | | MENU 2.1.1 | [Continuation enormed Successibility] |
| 6 | | PROACTIVE SIM SESSION | |
| | J | ENDED | |
| 7 | $USER \to ME$ | Select the Toolkit Menu "Toolkit | |
| | | Menu" | |
| 8 | $ME \rightarrow USER$ | | |
| _ | | "Item 4" | |
| 9 | $USER \to ME$ | Select the Help Request on | |
| 40 | | "Item 2" Menu entry | |
| 10 | $ME \rightarrow SIM$ | Send the ENVELOPE 2.1.1: | |
| | | MENU SELECTION | |
| | | (Identifier of item: 2) | |

PROACTIVE COMMAND: SET UP MENU 2.1.1

Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: "80"

Device identities

Source device: SIM
Destination device: ME

Alpha identifier: "Toolkit Menu"

Item

Identifier of item: 1

Text string of item: "Item 1"

Item

Identifier of item: 2

Text string of item: "Item 2"

Item

Identifier of item: 3

Text string of item: "Item 3"

Item

Identifier of item:4

Text string of item: "Item 4"

Coding:

| BER-TLV: | D0 | 3B | 81 | 03 | 01 | 25 | 80 | 82 | 02 | 81 | 82 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0C | 54 | 6F | 6F | 6C | 6B | 69 | 74 | 20 | 4D | 65 | 6E |
| | 75 | 8F | 07 | 01 | 49 | 74 | 65 | 6D | 20 | 31 | 8F | 07 |
| | 02 | 49 | 74 | 65 | 6D | 20 | 32 | 8F | 07 | 03 | 49 | 74 |
| | 65 | 6D | 20 | 33 | 8F | 07 | 04 | 49 | 74 | 65 | 6D | 20 |
| | 34 | | | | | | | | | | | |

TERMINAL RESPONSE: SET UP MENU 2.1.1

Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: "help information available"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 25 | 80 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|------------|------------|----|----|----|----|----|----|----|----|----|----|----|
| D=:: := v: | O . | 00 | | | | U_ | V- | | | | | |

ENVELOPE 2.1.1: MENU SELECTION

Logically:

Menu selection

Device identities

Source device: Keypad
Destination device: SIM
Item identifier 02

Help request tag

Coding:

| | 82 02 01 | 81 90 | 01 02 | 15 00 |
|--|----------|-------|-------|-------|
|--|----------|-------|-------|-------|

27.22.4.8.2.5 Test requirement

The ME shall operate in the manner defined in expected sequence 2.1.

27.22.4.8.3 SET UP MENU (next action support) and ENVELOPE MENU SELECTION

27.22.4.8.3.1 Definition and applicability

See clause 3.2.2.

If the SIM provides an Items Next Action Indicator data object, the comprehension required flag shall be set to '0'.

27.22.4.8.3.2 Conformance requirement

Requirements are the same as in clause 27.22.4.8.1.1, with an additional one:

• 3GPP TS 11.14 [15] clause 12.24.

27.22.4.8.3.3 Test purpose

To verify that the ME correctly integrates the menu items contained in the SET UP MENU proactive SIM command, and returns a successful response in the TERMINAL RESPONSE command sent to the SIM.

To verify that the next action indicator is supported.

To verify that the ME correctly passes the identifier of the selected menu item to the SIM using the ENVELOPE (MENU SELECTION) command.

27.22.4.8.3.4 Method of test

27.22.4.8.3.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

The ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

27.22.4.8.3.4.2 Procedure

Expected Sequence 3.1 (SET UP MENU, next action indicator "Send SM", "Set Up Call", "Launch Browser", "Provide Local Information", successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|---------------------------------------|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | [First Set Up Menu] |
| | | PENDING: SET UP MENU 3.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND SET UP | |
| | | MENU 3.1.1 | |
| 4 | $ME \rightarrow USER$ | Integrate the menu header of | |
| | | "Toolkit Menu" into its menu | |
| | | system and have the menu items | |
| | | of "Item 1", "Item 2", "Item 3" and | |
| _ | | "Item 4" under this header. | [Oanna and Danfa and all Oanna and all all |
| 5 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP | [Command Performed Successfully] |
| 6 | OIM ME | MENU 3.1.1 PROACTIVE SIM SESSION | |
| 0 | $SIM \rightarrow ME$ | ENDED | |
| 7 | $USER \to ME$ | Select the Toolkit Menu "Toolkit | |
| _ ′ | USEK → IVIE | Menu" | |
| 8 | $ME \rightarrow USER$ | Display "Item 1", "Item 2", "Item 3", | The ME may indicate to the user the |
| | WL 700LK | "Item 4" | consequences of performing the selection of |
| | | No. I | an item. |
| 9 | $USER \rightarrow ME$ | Navigate in the items, then select | The ME may indicate to the user the |
| | | "Item 2". | consequences of performing the selection of |
| | | | an item. |
| 10 | $ME \to SIM$ | Send the ENVELOPE 3.1.1: | |
| | | MENU SELECTION | |
| | | (Identifier of item: 2) | |

ENVELOPE 3.1.1: MENU SELECTION

Logically:

Menu selection

Device identities

Source device: Keypad
Destination device: SIM
Item identifier 02

Coding:

| BER-TLV: D3 07 82 02 01 81 90 01 02 | |
|-------------------------------------|--|
|-------------------------------------|--|

PROACTIVE COMMAND: SET UP MENU 3.1.1

Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha identifier: "Toolkit Menu"

Item

Identifier of item: 1

Text string of item: "Item 1"

Item

Identifier of item: 2

Text string of item: "Item 2"

Item

Identifier of item: 3

Text string of item: "Item 3"

Item

Identifier of item: 4

Text string of item: "Item 4"

Items next action indicator list

List: "Send SM", "Set Up Call", "Launch Browser", "Provide Local Information"

Coding:

| BER-TLV: | D0 | 41 | 81 | 03 | 01 | 25 | 00 | 82 | 02 | 81 | 82 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0C | 54 | 6F | 6F | 6C | 6B | 69 | 74 | 20 | 4D | 65 | 6E |
| | 75 | 8F | 07 | 01 | 49 | 74 | 65 | 6D | 20 | 31 | 8F | 07 |
| | 02 | 49 | 74 | 65 | 6D | 20 | 32 | 8F | 07 | 03 | 49 | 74 |
| | 65 | 6D | 20 | 33 | 8F | 07 | 04 | 49 | 74 | 65 | 6D | 20 |
| | 34 | 18 | 04 | 13 | 10 | 15 | 26 | | | | | |

TERMINAL RESPONSE: SET UP MENU 3.1.1

Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: "no help information available"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| В | BER-TLV: | 81 | 03 | 01 | 25 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|---|----------|----|----|----|----|----|----|----|----|----|----|----|----|

27.22.4.8.3.5 Test requirement

The ME shall operate in the manner defined in expected sequence 3.1.

27.22.4.8.4 SET UP MENU (display of icons) and ENVELOPE MENU SELECTION

27.22.4.8.4.1 Definition and applicability

See clause 3.2.2.

27.22.4.8.4.2 Conformance requirement

Requirements are the same as in clause 27.22.4.8.1.1, with an additional one:

• GSM 11.14 clause 6.5.4, 12.31 and 12.32.

27.22.4.8.4.3 Test purpose

To verify that the ME correctly integrates the menu items contained in the SET UP MENU proactive SIM command, and returns a successful response in the TERMINAL RESPONSE command sent to the SIM.

To verify that icons are displayed with the command Set Up Menu in the Alpha Identifier and Items Data Objects. To verify that the ME correctly passes the identifier of the selected menu item to the SIM using the ENVELOPE (MENU SELECTION) command.

27.22.4.8.4.4 Method of test

27.22.4.8.4.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

The ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

27.22.4.8.4.4.2 Procedure

Expected Sequence 4.1A (SET UP MENU, BASIC ICON NOT SELF EXPLANATORY in ALPHA ID and ITEMS DATA OBJECTS, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|---|---|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | [First Set Up Menu] |
| | | PENDING: SET UP MENU 4.1.1 | |
| 2 | $ME \to SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND SET UP MENU 4.1.1 | |
| 4 | ME → USER | Integrate the menu header of "Toolkit Menu" into its menu system and have the menu items of "Item 1", "Item 2", "Item 3" under this header. | |
| 5 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP MENU 4.1.1A | [Command Performed Successfully] |
| 6 | $SIM \to ME$ | PROACTIVE SIM SESSION ENDED | |
| 7 | $USER \to ME$ | Select the Toolkit Menu "Toolkit Menu" | Verify the icon is displayed with alpha id. |
| 8 | $ME \rightarrow USER$ | Display "Item 1", "Item 2", "Item 3". | |
| 9 | $USER \to ME$ | Navigate in the items, then select "Item 2". | Verify icons are displayed for each item. |
| 10 | $ME \rightarrow SIM$ | Send the ENVELOPE 3.1.1: MENU SELECTION (Identifier of item: 2) | |

PROACTIVE COMMAND: SET UP MENU 4.1.1

Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: "00"

Device identities

Source device: SIM Destination device: ME

Alpha identifier: "Toolkit Menu"

Item

Identifier of item: 1

Text string of item: "Item 1"

Item

Identifier of item: 2

Text string of item: "Item 2"

Item

Identifier of item: 3
Text string of item: "Item 3"

Icon identifier

Icon qualifier: icon is not self explanatory

Icon identifier: record 1 EF (IMG)

Item icon identifier list

Icon qualifier: icon is not self explanatory

Icon identifier list: record 5 EF (IMG), record 5 EF (IMG), record 5 EF (IMG)

Coding:

| BER-TLV: | D0 | 3C | 81 | 03 | 01 | 25 | 00 | 82 | 02 | 81 | 82 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0C | 54 | 6F | 6F | 6C | 6B | 69 | 74 | 20 | 4D | 65 | 6E |
| | 75 | 8F | 07 | 01 | 49 | 74 | 65 | 6D | 20 | 31 | 8F | 07 |
| | 02 | 49 | 74 | 65 | 6D | 20 | 32 | 8F | 07 | 03 | 49 | 74 |
| | 65 | 6D | 20 | 33 | 9E | 02 | 01 | 01 | 9F | 04 | 01 | 05 |
| | 05 | 05 | | | | | | | | | | |

TERMINAL RESPONSE: SET UP MENU 4.1.1A

Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: "no help information available"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

| BER-TLV: | | 00 |
|----------|--|----|
|----------|--|----|

Expected Sequence 4.1B (SET UP MENU, BASIC ICON NOT SELF EXPLANATORY in ALPHA ID and ITEMS DATA OBJECTS, requested icon could not be displayed)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------------|---|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND PENDING: SET UP MENU 4.1.1 | [First Set Up Menu] |
| 2 | $ME \to SIM$ | FETCH | |
| 3 | | PROACTIVE COMMAND SET UP | |
| _ | | MENU 4.1.1 | |
| 4 | $ME \rightarrow USER$ | Integrate the menu header of "Toolkit Menu" into its menu | |
| | | system and have the menu items | |
| | | of "Item 1", "Item 2", "Item 3" under | |
| _ | | this header. | [O |
| 5 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP IMENU 4.1.1B | [Command performed successfully, but requested icon could not be displayed] |
| | | WENG IIIIB | requested foot oddid flot se displayed; |
| | | | |
| 6 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION | |
| _ | $USER \to ME$ | Select the Toolkit Menu "Toolkit | |
| 7 | | Menu" | |
| 8 | $ME \to USER$ | Display "Item 1", "Item 2", "Item 3" | Verify that either for the header or for each of |
| | $USER \to ME$ | under the header 'Toolkit Menu'. Navigate in the items, then select | the items no icon is displayed |
| 9 | OOLIN - IVIL | "Item 2". | |
| 10 | $\text{ME} \to \text{SIM}$ | Send the ENVELOPE 3.1.1: | |
| | | MENU SELECTION | |
| | | (Identifier of item: 2) | |

TERMINAL RESPONSE: SET UP MENU 4.1.1B

Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: "no help information available"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully but requested icon could not be displayed

| RFR-TI V∕· | 04 02 | 0.4 | 25 | ~~ | 0.0 | 00 | 0.0 | 0.4 | 0.2 | 0.4 | - 4 |
|-------------|---------|-------|-----|----|-----|------|------|------|------|-------|-------|
| IBER-ILV: I | 81 03 | 1 ()1 | レンケ | 00 | 82 | 1 02 | 1 82 | I 81 | 1 83 | 1 ()7 | 1 ()4 |

Expected Sequence 4.2A (SET UP MENU, BASIC ICON SELF EXPLANATORY in ALPHA ID and ITEMS DATA OBJECTS, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|---------------------------------------|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | [First Set Up Menu] |
| _ | | PENDING: SET UP MENU 4.2.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND SET UP | |
| | | MENU 4.2.1 | |
| 4 | $ME \rightarrow USER$ | Integrate the menu header of | |
| | | "Toolkit Menu" into its menu | |
| | | system and have the menu items | |
| | | of "Item 1", "Item 2", "Item 3" under | |
| _ | | this header. | 10 10 (10 |
| 5 | $ME \to SIM$ | TERMINAL RESPONSE: SET UP | [Command Performed Successfully] |
| | | MENU 4.2.1A | |
| 6 | CIM . ME | PROACTIVE SIM SESSION | |
| 0 | $SIM \rightarrow ME$ | FNDFD | |
| | $USER \to ME$ | Select the Toolkit Menu "Toolkit | Verify the icon is displayed in alpha id. |
| 7 | USER → IVIE | Menu" | |
| 8 | ME LISED | Display "Item 1", "Item 2", "Item 3". | |
| 0 | | Navigate in the items, then select | Verify icons are displayed for each item. |
| 9 | OSLIN - IVIL | "Item 2". | verify loons are displayed for each item. |
| 10 | $ME \rightarrow SIM$ | Send the ENVELOPE 3.1.1: | |
| | IVIL 7 OIIVI | MENU SELECTION | |
| | | (Identifier of item: 2) | |

PROACTIVE COMMAND: SET UP MENU 4.2.1

Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: "00"

Device identities

Source device: SIM Destination device: ME

Alpha identifier: "Toolkit Menu"

Item

Identifier of item:

Text string of item: "Item 1"

Item

Identifier of item: 2

Text string of item: "Item 2"

Item

Identifier of item: 3

Text string of item: "Item 3"

Icon identifier

Icon qualifier: icon is self explanatory
Icon identifier: record 1 EF (IMG)

Item icon identifier list

Icon qualifier: icon is self explanatory

Icon identifier list: record 5 EF (IMG), record 5 EF (IMG), record 5 EF (IMG)

| BER-TLV: | D0 | 3C | 81 | 03 | 01 | 25 | 00 | 82 | 02 | 81 | 82 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0C | 54 | 6F | 6F | 6C | 6B | 69 | 74 | 20 | 4D | 65 | 6E |
| | 75 | 8F | 07 | 01 | 49 | 74 | 65 | 6D | 20 | 31 | 8F | 07 |
| | 02 | 49 | 74 | 65 | 6D | 20 | 32 | 8F | 07 | 03 | 49 | 74 |
| | 65 | 6D | 20 | 33 | 9E | 02 | 00 | 01 | 9F | 04 | 00 | 05 |
| | 05 | 05 | | | | | | | | | | 1 |

TERMINAL RESPONSE: SET UP MENU 4.2.1A

Logically:

Command details

Command number:

Command type: SET UP MENU

Command qualifier: "no help information available"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| DED TIVE | 0.4 | 00 | 0.4 | 25 | 00 | 0.2 | 00 | 0.0 | 0.4 | 0.2 | 01 | 00 |
|----------|-----|----|-----|----|----|-----|----|-----|-----|-----|----|----|
| BER-TLV: | 81 | 03 | 01 | 25 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |

Expected Sequence 4.2B (SET UP MENU, BASIC ICON SELF EXPLANATORY in ALPHA ID and ITEMS DATA OBJECTS, requested icon could not be displayed)

| Step | Direction | MESSAGE / Action | Comments |
|------|---|---|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND PENDING: SET UP MENU 4.2.1 | [First Set Up Menu] |
| 2 | $ME \to SIM$ | FETCH | |
| 3 | • · · · · · · · · · · · · · · · · · · · | PROACTIVE COMMAND SET UP MENU 4.2.1 | |
| 4 | $ME \to USER$ | Integrate the menu header of "Toolkit Menu" into its menu system and have the menu items of "Item 1", "Item 2", "Item 3" under this header. | |
| 5 | | | [Command Performed Successfully] |
| 6 | $SIM \to ME$ | PROACTIVE SIM SESSION ENDED | |
| 7 | | Select the Toolkit Menu "Toolkit Menu" | |
| 8 | $ME \to USER$ | Display "Item 1", "Item 2", "Item 3" under the header 'Tookit Menu'. | Verify that either for the header or for each of the items no icon is displayed |
| 9 | $USER \to ME$ | Navigate in the items, then select "Item 2". | |
| 10 | $ME \rightarrow SIM$ | Send the ENVELOPE 3.1.1: MENU SELECTION (Identifier of item: 2) | |

TERMINAL RESPONSE: SET UP MENU 4.2.1B

Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: "no help information available"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully but requested icon could not be displayed

Coding:

BER-TLV: 81 03 01 25 00 82 02 82 81 83 01 04

27.22.4.8.4.5 Test requirement

The ME shall operate in the manner defined in expected sequences 4.1A to 4.2B.

27.22.4.8.5 SET UP MENU (soft keys support) and ENVELOPE MENU SELECTION

27.22.4.8.5.1 Definition and applicability

See clause 3.2.2.

27.22.4.8.5.2 Conformance requirement

Requirements are the same as in clause 27.22.4.8.1.1.

27.22.4.8.5.3 Test purpose

To verify that the ME correctly integrates the menu items contained in the SET UP MENU proactive SIM command, and returns a successful response in the TERMINAL RESPONSE command sent to the SIM.

To verify that if soft key preferred is indicated in the command details and soft key for SET UP MENU is supported by the ME and the number of icon items does not exceed the number of soft keys available, then the ME displays those icons as soft key.

To verify that the ME correctly passes the identifier of the selected menu item to the SIM using the ENVELOPE (MENU SELECTION) command.

27.22.4.8.5.4 Method of test

27.22.4.8.5.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

The ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

27.22.4.8.5.4.2 Procedure

Expected Sequence 5.1 (SET UP MENU, SOFT KEY PREFERRED, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|---|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND PENDING: SET UP MENU 5.1.1 | [First Set Up Menu] |
| 2 | $ME \to SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND SET UP MENU 5.1.1 | |
| 4 | $ME \to USER$ | Integrate the menu header of "Toolkit Menu" into its menu system and have the menu items of "Item 1", "Item 2" under this header. | |
| 5 | $ME \to SIM$ | TERMINAL RESPONSE: SET UP | [Command Performed Successfully] |
| 6 | $SIM \to ME$ | PROACTIVE SIM SESSION ENDED | |
| 7 | $USER \to ME$ | Select the Toolkit Menu "Toolkit Menu" | |
| 8 | $ME \to USER$ | Display "Item 1", "Item 2" | |
| 9 | $USER \to ME$ | Navigate in the items, then select "Item 2". | Verify we can select items through soft keys |
| 10 | $ME \rightarrow SIM$ | Send the ENVELOPE 3.1.1: MENU SELECTION (Identifier of item: 2) | |

PROACTIVE COMMAND: SET UP MENU 5.1.1

Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: '01' (selection using soft key preferred)

Device identities

Source device: SIM Destination device: ME

Alpha identifier: "Toolkit Menu"

Item

Identifier of item:

Text string of item: "Item 1"

Item

Identifier of item: 2
Text string of item: "Item 2"

Coding:

| BER-TLV: | D0 | 29 | 81 | 03 | 01 | 25 | 01 | 82 | 02 | 81 | 82 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0C | 54 | 6F | 6F | 6C | 6B | 69 | 74 | 20 | 4D | 65 | 6E |
| | 75 | 8F | 07 | 01 | 49 | 74 | 65 | 6D | 20 | 31 | 8F | 07 |
| | 02 | 49 | 74 | 65 | 6D | 20 | 32 | | | | | |

TERMINAL RESPONSE: SET UP MENU 5.1.1

Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: '01' (selection using soft key preferred)

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TI | _V: | 81 | 03 | 01 | 25 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|--------|-----|----|----|----|----|----|----|----|----|----|----|----|----|

27.22.4.8.5.5 Test requirement

The ME shall operate in the manner defined in expected sequence 5.1.

27.22.4.9 SELECT ITEM

27.22.4.9.1 SELECT ITEM (mandatory features for ME supporting SELECT ITEM)

27.22.4.9.1.1 Definition and applicability

See clause 3.2.2.

27.22.4.9.1.2 Conformance requirement

The ME shall support the Proactive SIM: Select Item facility as defined in the following technical specifications:

• 3GPP TS 11.14 [15] clause 5, clause 6.4.9, clause 6.6.8, clause 6.8, clause 12.6, clause 13.4 and clause 14.

27.22.4.9.1.3 Test purpose

To verify that the ME correctly presents the set of items contained in the SELECT ITEM proactive SIM command, and returns a TERMINAL RESPONSE command to the SIM with the identifier of the item chosen.

To verify that the ME allows a SELECT ITEM proactive SIM command within the maximum 255 byte BER-TLV boundary.

To verify that the ME returns a TERMINAL RESPONSE with "Proactive SIM application session terminated by the user", if the user has indicated the need to end the proactive SIM session.

To verify that the ME returns a TERMINAL RESPONSE with "Backwards move in the proactive SIM application session requested by the user", if the user has indicated the need to go backwards in the proactive SIM application session.

27.22.4.9.1.4 Method of test

27.22.4.9.1.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.9.1.4.2 Procedure

Expected Sequence 1.1 (SELECT ITEM, mandatory features, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--------------------------------------|--------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SELECT ITEM 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | |
| | | SELECT ITEM 1.1.1 | |
| 4 | $ME \rightarrow USER$ | Display items of "Item 1", "Item 2", | |
| | | "Item 3" and "Item 4" under the | |
| | | header of "Toolkit Select". | |
| 5 | $USER \to ME$ | Select "Item 2". | |
| 6 | $ME \to SIM$ | TERMINAL RESPONSE: SELECT | Command performed successfully |
| | | ITEM 1.1.1 | |

PROACTIVE COMMAND: SELECT ITEM 1.1.1

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: SIM Destination device: ME

Alpha identifier: "Toolkit Select"

Item

Identifier of item: 1

Text string of item: "Item 1"

Item

Identifier of item: 2

Text string of item: "Item 2"

Item

Identifier of item: 3

Text string of item: "Item 3"

Item

Identifier of item: 4

Text string of item: "Item 4"

Coding:

| BER-TLV: | D0 | 3D | 81 | 03 | 01 | 24 | 00 | 82 | 02 | 81 | 82 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0E | 54 | 6F | 6F | 6C | 6B | 69 | 74 | 20 | 53 | 65 | 6C |
| | 65 | 63 | 74 | 8F | 07 | 01 | 49 | 74 | 65 | 6D | 20 | 31 |
| | 8F | 07 | 02 | 49 | 74 | 65 | 6D | 20 | 32 | 8F | 07 | 03 |
| | 49 | 74 | 65 | 6D | 20 | 33 | 8F | 07 | 04 | 49 | 74 | 65 |
| | 6D | 20 | 34 | | | | | | | | | |

TERMINAL RESPONSE: SELECT ITEM 1.1.1

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME

Destination device: SIM

Result

General Result: Command performed successfully

Item identifier

Identifier of item chosen: 02

Coding:

| BER-TLV: | 81 | 03 | 01 | 24 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 90 | 01 | 02 | | | | | | | | | |

Expected Sequence 1.2 (SELECT ITEM, large menu, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|---------------------------------------|--------------------------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: SELECT ITEM 1.2.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | |
| | | SELECT ITEM 1.2.1 | |
| 4 | $ME \rightarrow USER$ | Present the items of "Zero", "One", | |
| | | "Two", Three", "Four", "Five", "Six", | |
| | | "Seven", "Eight", "Nine", "Alpha", | |
| | | "Bravo", "Charlie", "Delta", "Echo", | |
| | | "Fox-trot", "Black", "Brown", "Red", | |
| | | "Orange", "Yellow", "Green", | |
| | | "Blue", "Violet", "Grey", "White", | |
| | | "milli", "micro", "nano" and "pico" | |
| _ | | under the header of "LargeMenu1" | |
| 5 | | Select item "Orange". | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SELECT | Command performed successfully |
| | | ITEM 1.2.1 | |

PROACTIVE COMMAND: SELECT ITEM 1.2.1

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha identifier: "LargeMenu1"

Item

Identifier of item: "50" Text string of item: "Zero"

Item

Identifier of item: "4F"
Text string of item: "One"

Item

Identifier of item: "4E" Text string of item: "Two"

Item

Identifier of item: "4D"
Text string of item: "Three"

Item

Identifier of item: "4C"
Text string of item: "Four"

Item

Identifier of item: "4B" Text string of item: "Five"

| Item | Identifier of item: | "4A" |
|--------|---|--------------------|
| Item | Text string of item: | "Six" |
| 100111 | Identifier of item: Text string of item: | "49" "Seven" |
| Item | Identifier of item: | "48" |
| Item | Text string of item: Identifier of item: | "Eight" "47" |
| Item | Text string of item: | "Nine" |
| Item | Identifier of item: Text string of item: | "46" "Alpha" |
| Hein | Identifier of item: Text string of item: | "45" "Bravo" |
| Item | Identifier of item: | "44" |
| Item | Text string of item: Identifier of item: | "Charlie" "43" |
| Item | Text string of item: | "Delta" |
| Item | Identifier of item: Text string of item: | "42" "Echo" |
| T4 | Identifier of item: Text string of item: | "41" "Fox-trot" |
| Item | Identifier of item: Text string of item: | "40" "Black" |
| Item | Identifier of item: Text string of item: | "3F" "Brown" |
| Item | Identifier of item: | "3E" |
| Item | Text string of item: | "Red" "3D" |
| Item | Identifier of item: Text string of item: | "Orange" |
| Ψ. | Identifier of item: Text string of item: | "3C" "Yellow" |
| Item | Identifier of item: Text string of item: | "3B" "Green" |
| Item | Identifier of item: | "3A" |
| Item | Text string of item: Identifier of item: | "Blue" "39" |
| Item | Text string of item: | "Violet" |
| Item | Identifier of item: Text string of item: | "38" "Grey" |
| 10111 | Identifier of item: Text string of item: | "37" "White" |
| Item | Identifier of item: | "36" |

Text string of item: "milli"

Item

Identifier of item: "35"
Text string of item: "micro"

Item

Identifier of item: "34"

Text string of item: "nano"

Item

Identifier of item: "33"
Text string of item: "pico"

Coding:

| BER-TLV: | D0 | 81 | FC | 81 | 03 | 01 | 24 | 00 | 82 | 02 | 81 | 82 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 85 | 0A | 4C | 61 | 72 | 67 | 65 | 4D | 65 | 6E | 75 | 31 |
| | 8F | 05 | 50 | 5A | 65 | 72 | 6F | 8F | 04 | 4F | 4F | 6E |
| | 65 | 8F | 04 | 4E | 54 | 77 | 6F | 8F | 06 | 4D | 54 | 68 |
| | 72 | 65 | 65 | 8F | 05 | 4C | 46 | 6F | 75 | 72 | 8F | 05 |
| | 4B | 46 | 69 | 76 | 65 | 8F | 04 | 4A | 53 | 69 | 78 | 8F |
| | 06 | 49 | 53 | 65 | 76 | 65 | 6E | 8F | 06 | 48 | 45 | 69 |
| | 67 | 68 | 74 | 8F | 05 | 47 | 4E | 69 | 6E | 65 | 8F | 06 |
| | 46 | 41 | 6C | 70 | 68 | 61 | 8F | 06 | 45 | 42 | 72 | 61 |
| | 76 | 6F | 8F | 80 | 44 | 43 | 68 | 61 | 72 | 6C | 69 | 65 |
| | 8F | 06 | 43 | 44 | 65 | 6C | 74 | 61 | 8F | 05 | 42 | 45 |
| | 63 | 68 | 6F | 8F | 09 | 41 | 46 | 6F | 78 | 2D | 74 | 72 |
| | 6F | 74 | 8F | 06 | 40 | 42 | 6C | 61 | 63 | 6B | 8F | 06 |
| | 3F | 42 | 72 | 6F | 77 | 6E | 8F | 04 | 3E | 52 | 65 | 64 |
| | 8F | 07 | 3D | 4F | 72 | 61 | 6E | 67 | 65 | 8F | 07 | 3C |
| | 59 | 65 | 6C | 6C | 6F | 77 | 8F | 06 | 3B | 47 | 72 | 65 |
| | 65 | 6E | 8F | 05 | 3A | 42 | 6C | 75 | 65 | 8F | 07 | 39 |
| | 56 | 69 | 6F | 6C | 65 | 74 | 8F | 05 | 38 | 47 | 72 | 65 |
| | 79 | 8F | 06 | 37 | 57 | 68 | 69 | 74 | 65 | 8F | 06 | 36 |
| | 6D | 69 | 6C | 6C | 69 | 8F | 06 | 35 | 6D | 69 | 63 | 72 |
| | 6F | 8F | 05 | 34 | 6E | 61 | 6E | 6F | 8F | 05 | 33 | 70 |
| | 69 | 63 | 6F | | | | | | | | | |

TERMINAL RESPONSE: SELECT ITEM 1.2.1

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Item identifier

Identifier of item chosen: 3D

| BER-TLV: | 81 | 03 | 01 | 24 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 90 | 01 | 3D | | | | | | | | | |

Expected Sequence 1.3 (SELECT ITEM, call options, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|---|--------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND PENDING: SELECT ITEM 1.3.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SELECT ITEM 1.3.1 | |
| 4 | ME → USER | Present the items of " Call Forwarding Unconditional", "Call Forwarding On User Busy", "Call Forwarding On No Reply", "Call Forwarding On User Not Reachable", "Barring Of All Outgoing Calls", "Barring Of All Outgoing International Calls" and "CLI Presentation" under the header of " LargeMenu2 | |
| 5 | $USER \to ME$ | Select item "Barring Of All Outgoing Calls". | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SELECT | Command performed successfully |
| 7 | $SIM \to ME$ | PROACTIVE SIM SESSION ENDED | |

PROACTIVE COMMAND: SELECT ITEM 1.3.1

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: SIM Destination device: ME

Alpha identifier: "LargeMenu2"

Item

Identifier of item: "FF"

Text string of item: "Call Forwarding Unconditional"

Item

Identifier of item: "FE"

Text string of item: "Call Forwarding On User Busy"

Item

Identifier of item: "FD"

Text string of item: "Call Forwarding On No Reply"

Item

Identifier of item: "FC"

Text string of item: "Call Forwarding On User Not Reachable"

Item

Identifier of item: "FB"

Text string of item: "Barring Of All Outgoing Calls"

Item

Identifier of item: "FA"

Text string of item: "Barring Of All Outgoing International Calls"

Item

Identifier of item: "F9"

Text string of item: "CLI Presentation"

Coding:

| BER-TLV: | D0 | 81 | FB | 81 | 03 | 01 | 24 | 00 | 82 | 02 | 81 | 82 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 85 | 0A | 4C | 61 | 72 | 67 | 65 | 4D | 65 | 6E | 75 | 32 |
| | 8F | 1E | FF | 43 | 61 | 6C | 6C | 20 | 46 | 6F | 72 | 77 |
| | 61 | 72 | 64 | 69 | 6E | 67 | 20 | 55 | 6E | 63 | 6F | 6E |
| | 64 | 69 | 74 | 69 | 6F | 6E | 61 | 6C | 8F | 1D | FE | 43 |
| | 61 | 6C | 6C | 20 | 46 | 6F | 72 | 77 | 61 | 72 | 64 | 69 |
| | 6E | 67 | 20 | 4F | 6E | 20 | 55 | 73 | 65 | 72 | 20 | 42 |
| | 75 | 73 | 79 | 8F | 1C | FD | 43 | 61 | 6C | 6C | 20 | 46 |
| | 6F | 72 | 77 | 61 | 72 | 64 | 69 | 6E | 67 | 20 | 4F | 6E |
| | 20 | 4E | 6F | 20 | 52 | 65 | 70 | 6C | 79 | 8F | 26 | FC |
| | 43 | 61 | 6C | 6C | 20 | 46 | 6F | 72 | 77 | 61 | 72 | 64 |
| | 69 | 6E | 67 | 20 | 4F | 6E | 20 | 55 | 73 | 65 | 72 | 20 |
| | 4E | 6F | 74 | 20 | 52 | 65 | 61 | 63 | 68 | 61 | 62 | 6C |
| | 65 | 8F | 1E | FB | 42 | 61 | 72 | 72 | 69 | 6E | 67 | 20 |
| | 4F | 66 | 20 | 41 | 6C | 6C | 20 | 4F | 75 | 74 | 67 | 6F |
| | 69 | 6E | 67 | 20 | 43 | 61 | 6C | 6C | 73 | 8F | 2C | FA |
| | 42 | 61 | 72 | 72 | 69 | 6E | 67 | 20 | 4F | 66 | 20 | 41 |
| | 6C | 6C | 20 | 4F | 75 | 74 | 67 | 6F | 69 | 6E | 67 | 20 |
| | 49 | 6E | 74 | 65 | 72 | 6E | 61 | 74 | 69 | 6F | 6E | 61 |
| | 6C | 20 | 43 | 61 | 6C | 6C | 73 | 8F | 11 | F9 | 43 | 4C |
| | 49 | 20 | 50 | 72 | 65 | 73 | 65 | 6E | 74 | 61 | 74 | 69 |
| | 6F | 6E | | | | | | | | | | |

TERMINAL RESPONSE: SELECT ITEM 1.3.1

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Item identifier

Identifier of item chosen: FB

| BER-TLV: | 81 | 03 | 01 | 24 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| · | 90 | 01 | FB | | | | | | | | | |

Expected Sequence 1.4 (SELECT ITEM, backward move by user, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--|---|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | [|
| | | PENDING: SELECT ITEM 1.4.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: | |
| | | SELECT ITEM 1.4.1 | |
| 4 | $ME \rightarrow USER$ | Present the items of "One" and | |
| | | "Two" under the header of "Select | |
| 5 | LICED ME | Item". | |
| 5 | USER → ME | Indicate to go backwards in the proactive SIM application session. | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SELECT | Backward move in the proactive SIM |
| | IVIL / OIIVI | ITEM 1.4.1A | application session requested by user |
| | | or | approduction requestion by user |
| | | TERMINAL RESPONSE: SELECT | |
| | | ITEM 1.4.1B | |
| 7 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SELECT ITEM 1.4.2 | |
| 8 | / 0 | FETCH | |
| 9 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: | |
| 40 | | SELECT ITEM 1.4.2 | |
| 10 | $ME \rightarrow USER$ | | |
| | | "Two" under the header of "Select ltem". | |
| 11 | USER → ME | Indicate to end the proactive SIM | |
| '' | OSLIN - IVIL | application and return the ME to | |
| | | normal operation. | |
| 12 | $ME \rightarrow SIM$ | | Proactive SIM application terminated by the |
| | | ITEM 1.4.2A | user |
| | | or | |
| | | TERMINAL RESPONSE: SELECT | |
| | | ITEM 1.4.2B | |
| 13 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |

PROACTIVE COMMAND: SELECT ITEM 1.4.1 and 1.4.2

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: SIM Destination device: ME

Alpha identifier: "Select Item"

Item

Identifier of item: "11"
Text string of item: "One"

Item

Identifier of item: "12" Text string of item: "Two"

| BER-TLV: | D0 | 22 | 81 | 03 | 01 | 24 | 00 | 82 | 02 | 81 | 82 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| · | 0B | 53 | 65 | 6C | 65 | 63 | 74 | 20 | 49 | 74 | 65 | 6D |
| | 8F | 04 | 11 | 4F | 6E | 65 | 8F | 04 | 12 | 54 | 77 | 6F |

TERMINAL RESPONSE: SELECT ITEM 1.4.1A

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: backward move in the proactive SIM session requested by the user

Coding:

BER-TLV: 81 03 01 24 00 82 02 82 81 83 01 11

TERMINAL RESPONSE: SELECT ITEM 1.4.1B

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: backward move in the proactive SIM session requested by the user

Item identifier

Identifier of item chosen: XX

Coding:

| BER-TLV: | 81 | 03 | 01 | 24 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 11 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 90 | 01 | XX | | | | | | | | | |

TERMINAL RESPONSE: SELECT ITEM 1.4.2A

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: proactive SIM session terminated by the user

Coding:

BER-TLV: 81 03 01 24 00 82 02 82 81 83 01 10

TERMINAL RESPONSE: SELECT ITEM 1.4.2B

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: proactive SIM session terminated by the user

Item identifier

Identifier of item chosen: XX

Coding:

| BER-TLV: | 81 | 03 | 01 | 24 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 10 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 90 | 01 | XX | | | | | | | | | |

Expected Sequence 1.5 (SELECT ITEM, "Y", successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|---------------------------------------|--------------------------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: SELECT ITEM 1.5.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: | |
| | | SELECT ITEM 1.5.1 | |
| 4 | | Present the items of "Y" under the | |
| | | header of "The SIM shall supply a | |
| | | set of items from which the user | |
| | | may choose one. Each item | |
| | | comprises a short identifier (used | |
| | | to indicate the selection) and a text | |
| | | string. Optionally the SIM may | |
| | | include an alpha identifier. The | |
| 5 | LICED ME | alpha identifier i". | |
| _ | | Select item "Y" | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SELECT | Command performed successfully |
| _ | | ITEM 1.5.1 | |
| 7 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |

PROACTIVE COMMAND: SELECT ITEM 1.5.1

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha identifier: "The SIM shall supply a set of items from which the user may choose one. Each

item comprises a short identifier (used to indicate the selection) and a text string. Optionally the SIM may include an alpha identifier. The alpha identifier i"

Item

Identifier of item: "01" Text string of item: "Y"

| BER-TLV: | D0 | 81 | FD | 81 | 03 | 01 | 24 | 00 | 82 | 02 | 81 | 82 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| DEN-TEV. | | | | | | | | | | | _ | |
| | 85 | 81 | ED | 54 | 68 | 65 | 20 | 53 | 49 | 4D | 20 | 73 |
| | 68 | 61 | 6C | 6C | 20 | 73 | 75 | 70 | 70 | 6C | 79 | 20 |
| | 61 | 20 | 73 | 65 | 74 | 20 | 6F | 66 | 20 | 69 | 74 | 65 |
| | 6D | 73 | 20 | 66 | 72 | 6F | 6D | 20 | 77 | 68 | 69 | 63 |
| | 68 | 20 | 74 | 68 | 65 | 20 | 75 | 73 | 65 | 72 | 20 | 6D |
| | 61 | 79 | 20 | 63 | 68 | 6F | 6F | 73 | 65 | 20 | 6F | 6E |
| | 65 | 2E | 20 | 45 | 61 | 63 | 68 | 20 | 69 | 74 | 65 | 6D |
| | 20 | 63 | 6F | 6D | 70 | 72 | 69 | 73 | 65 | 73 | 20 | 61 |
| | 20 | 73 | 68 | 6F | 72 | 74 | 20 | 69 | 64 | 65 | 6E | 74 |
| | 69 | 66 | 69 | 65 | 72 | 20 | 28 | 75 | 73 | 65 | 64 | 20 |
| | 74 | 6F | 20 | 69 | 6E | 64 | 69 | 63 | 61 | 74 | 65 | 20 |
| | 74 | 68 | 65 | 20 | 73 | 65 | 6C | 65 | 63 | 74 | 69 | 6F |
| | 6E | 29 | 20 | 61 | 6E | 64 | 20 | 61 | 20 | 74 | 65 | 78 |
| | 74 | 20 | 73 | 74 | 72 | 69 | 6E | 67 | 2E | 20 | 4F | 70 |
| | 74 | 69 | 6F | 6E | 61 | 6C | 6C | 79 | 20 | 74 | 68 | 65 |
| | 20 | 53 | 49 | 4D | 20 | 6D | 61 | 79 | 20 | 69 | 6E | 63 |
| | 6C | 75 | 64 | 65 | 20 | 61 | 6E | 20 | 61 | 6C | 70 | 68 |
| | 61 | 20 | 69 | 64 | 65 | 6E | 74 | 69 | 66 | 69 | 65 | 72 |
| | 2E | 20 | 54 | 68 | 65 | 20 | 61 | 6C | 70 | 68 | 61 | 20 |
| | 69 | 64 | 65 | 6E | 74 | 69 | 66 | 69 | 65 | 72 | 20 | |
| | 69 | 8F | 02 | 01 | 59 | | | | | | | |

TERMINAL RESPONSE: SELECT ITEM 1.5.1

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Item identifier

Identifier of item chosen: 01

| BER-TLV: | 81 | 03 | 01 | 24 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| · | 90 | 01 | 01 | | | | | | | | | |

Expected Sequence 1.6 (SELECT ITEM, Large menu, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|------------------------------------|--------------------------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: SELECT ITEM 1.6.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | |
| | | SELECT ITEM 1.6.1 | |
| 4 | $ME \rightarrow USER$ | Present the items of "1 Call | |
| | | Forward Unconditional", "2 Call | |
| | | Forward On User Busy", "3 Call | |
| | | Forward On No Reply", "4 Call | |
| | | Forward On User Not Reachable", | |
| | | "5 Barring Of All Outgoing Calls", | |
| | | "6 Barring Of All Outgoing Int | |
| | | Calls" and "7 CLI Presentation" | |
| | | under the header of | |
| | | "0LargeMenu". | |
| 5 | $USER \to ME$ | Select item "5 Barring Of All | |
| | | Outgoing Calls". | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SELECT | Command performed successfully |
| | | ITEM 1.6.1 | |

PROACTIVE COMMAND: SELECT ITEM 1.6.1

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha identifier: "0LargeMenu"

Item

Identifier of item: "FF"

Text string of item: "1 Call Forward Unconditional"

Item

Identifier of item: "FE"

Text string of item: "2 Call Forward On User Busy"

Item

Identifier of item: "FD"

Text string of item: "3 Call Forward On No Reply"

Item

Identifier of item: "FC"

Text string of item: "4 Call Forward On User Not Reachable"

Item

Identifier of item: "FB"

Text string of item: "5 Barring Of All Outgoing Calls"

Item

Identifier of item: "FA"

Text string of item: "6 Barring Of All Outgoing Int Calls"

Item

Identifier of item: "F9"

Text string of item: "7 CLI Presentation"

| D0 | 81 | F3 | 81 | 03 | 01 | 24 | 00 | 82 | 02 | 81 | 82 |
|----|--|---|----|---|--|---|---|--|---|--|---|
| 85 | 0A | 30 | 4C | 61 | 72 | 67 | 65 | 4D | 65 | 6E | 75 |
| 8F | 1D | FF | 31 | 20 | 43 | 61 | 6C | 6C | 20 | 46 | 6F |
| 72 | 77 | 61 | 72 | 64 | 20 | 55 | 6E | 63 | 6F | 6E | 64 |
| 69 | 74 | 69 | 6F | 6E | 61 | 6C | 8F | 1C | FE | 32 | 20 |
| 43 | 61 | 6C | 6C | 20 | 46 | 6F | 72 | 77 | 61 | 72 | 64 |
| 20 | 4F | 6E | 20 | 55 | 73 | 65 | 72 | 20 | 42 | 75 | 73 |
| 79 | 8F | 1B | FD | 33 | 20 | 43 | 61 | 6C | 6C | 20 | 46 |
| 6F | 72 | 77 | 61 | 72 | 64 | 20 | 4F | 6E | 20 | 4E | 6F |
| 20 | 52 | 65 | 70 | 6C | 79 | 8F | 25 | FC | 34 | 20 | 43 |
| 61 | 6C | 6C | 20 | 46 | 6F | 72 | 77 | 61 | 72 | 64 | 20 |
| 4F | 6E | 20 | 55 | 73 | 65 | 72 | 20 | 4E | 6F | 74 | 20 |
| 52 | 65 | 61 | 63 | 68 | 61 | 62 | 6C | 65 | 8F | 20 | FB |
| 35 | 20 | 42 | 61 | 72 | 72 | 69 | 6E | 67 | 20 | 4F | 66 |
| 20 | 41 | 6C | 6C | 20 | 4F | 75 | 74 | 67 | 6F | 69 | 6E |
| 67 | 20 | 43 | 61 | 6C | 6C | 73 | 8F | 24 | FA | 36 | 20 |
| 42 | 61 | 72 | 72 | 69 | 6E | 67 | 20 | 4F | 66 | 20 | 41 |
| 6C | 6C | 20 | 4F | 75 | 74 | 67 | 6F | 69 | 6E | 67 | 20 |
| 49 | 6E | 74 | 20 | 43 | 61 | 6C | 6C | 73 | 8F | 13 | F9 |
| 37 | 20 | 43 | 4C | 49 | 20 | 50 | 72 | 65 | 73 | 65 | 6E |
| 74 | 61 | 74 | 69 | 6F | 6E | | | | | | |
| | 85 8F 72 69 43 20 79 6F 20 61 4F 52 35 20 67 42 6C 49 | 85 0A 8F 1D 72 77 69 74 43 61 20 4F 79 8F 6F 72 20 52 61 6C 4F 6E 52 65 35 20 20 41 67 20 42 61 6C 6C 49 6E 37 20 | 85 | 85 0A 30 4C 8F 1D FF 31 72 77 61 72 69 74 69 6F 43 61 6C 6C 20 4F 6E 20 79 8F 1B FD 6F 72 77 61 20 52 65 70 61 6C 6C 20 4F 6E 20 55 52 65 61 63 35 20 42 61 20 41 6C 6C 67 20 43 61 42 61 72 72 6C 6C 20 4F 49 6E 74 20 37 20 43 4C | 85 0A 30 4C 61 8F 1D FF 31 20 72 77 61 72 64 69 74 69 6F 6E 43 61 6C 6C 20 20 4F 6E 20 55 79 8F 1B FD 33 6F 72 77 61 72 20 52 65 70 6C 61 6C 6C 20 46 4F 6E 20 55 73 52 65 61 63 68 35 20 42 61 72 20 41 6C 6C 20 67 20 43 61 6C 42 61 72 72 69 6C 6C 20 4F 75 | 85 0A 30 4C 61 72 8F 1D FF 31 20 43 72 77 61 72 64 20 69 74 69 6F 6E 61 43 61 6C 6C 20 46 20 4F 6E 20 55 73 79 8F 1B FD 33 20 6F 72 77 61 72 64 20 52 65 70 6C 79 61 6C 6C 20 46 6F 4F 6E 20 55 73 65 52 65 61 63 68 61 35 20 42 61 72 72 20 41 6C 6C 20 4F 67 20 43 61 < | 85 0A 30 4C 61 72 67 8F 1D FF 31 20 43 61 72 77 61 72 64 20 55 69 74 69 6F 6E 61 6C 43 61 6C 6C 20 46 6F 20 4F 6E 20 55 73 65 79 8F 1B FD 33 20 43 6F 72 77 61 72 64 20 20 52 65 70 6C 79 8F 61 6C 6C 20 46 6F 72 4F 6E 20 55 73 65 72 4F 6E 20 55 73 65 72 52 65 61 63 68 61 | 85 0A 30 4C 61 72 67 65 8F 1D FF 31 20 43 61 6C 72 77 61 72 64 20 55 6E 69 74 69 6F 6E 61 6C 8F 43 61 6C 6C 20 46 6F 72 20 4F 6E 20 55 73 65 72 79 8F 1B FD 33 20 43 61 6F 72 77 61 72 64 20 4F 20 52 65 70 6C 79 8F 25 61 6C 6C 20 46 6F 72 77 4F 6E 20 55 73 65 72 20 52 65 61 | 85 0A 30 4C 61 72 67 65 4D 8F 1D FF 31 20 43 61 6C 6C 72 77 61 72 64 20 55 6E 63 69 74 69 6F 6E 61 6C 8F 1C 43 61 6C 6C 20 46 6F 72 77 20 4F 6E 20 55 73 65 72 20 79 8F 1B FD 33 20 43 61 6C 6F 72 77 61 72 64 20 4F 6E 20 52 65 70 6C 79 8F 25 FC 61 6C 6C 20 46 6F 72 77 61 4F 6E | 85 0A 30 4C 61 72 67 65 4D 65 8F 1D FF 31 20 43 61 6C 6C 20 72 77 61 72 64 20 55 6E 63 6F 69 74 69 6F 6E 61 6C 8F 1C FE 43 61 6C 6C 20 46 6F 72 77 61 20 4F 6E 20 55 73 65 72 20 42 79 8F 1B FD 33 20 43 61 6C 6C 6F 72 77 61 72 64 20 4F 6E 20 20 52 65 70 6C 79 8F 25 FC 34 61 6C 6C | 85 0A 30 4C 61 72 67 65 4D 65 6E 8F 1D FF 31 20 43 61 6C 6C 20 46 72 77 61 72 64 20 55 6E 63 6F 6E 69 74 69 6F 6E 61 6C 8F 1C FE 32 43 61 6C 6C 20 46 6F 72 77 61 72 20 4F 6E 20 55 73 65 72 20 42 75 79 8F 1B FD 33 20 43 61 6C 6C 20 4E 20 52 65 70 6C 79 8F 25 FC 34 20 61 6C 6C 20 46 |

TERMINAL RESPONSE: SELECT ITEM 1.6.1

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Item identifier

Identifier of item chosen: FB

Coding:

| BER-TLV: | 81 | 03 | 01 | 24 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 90 | 01 | FB | | | | | | | | | |

The following table details the test commands with relation to the tested features:

| | Proactive SI | M Command | Facilities |
|--|----------------------------|-----------------|------------------------|
| Proactive SIM Command SELECT ITEM Number | Alpha Identifier Length | Number of items | Maximum length of item |
| 1.1 | 14 | 4 | 6 |
| 1.2 | 10 | 30 | 8 |
| 1.3 | 10 | 7 | 43 |
| 1.4 | 11 | 2 | 3 |
| 1.5 | 236 | 1 | 1 |
| 1.6 | 10 | 7 | 37 |

27.22.4.9.1.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1, 1.2, 1.3, 1.4, 1.5 and 1.6 (SELECT ITEM, mandatory features).

27.22.4.9.2 SELECT ITEM (next action support)

27.22.4.9.2.1 Definition and applicability

See clause 3.2.2.

27.22.4.9.2.2 Conformance Requirement

Same as clause 27.22.4.9.1.2.

27.22.4.9.2.3 Test purpose

To verify that the mobile supports next action indicator mode.

27.22.4.9.2.4 Method of test

27.22.4.9.2.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.9.2.4.2 Procedure

Expected Sequence 2.1 (SELECT ITEM, next action indicator, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-------------------------------------|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SELECT ITEM 2.1.1 | |
| 2 | $ME \to SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | |
| | | SELECT ITEM 2.1.1 | |
| 4 | $ME \rightarrow USER$ | Display items of "Item 1", "Item 2" | The ME may indicate to the user the |
| | | and "Item 3" under the header of | consequences of performing the selection of |
| | | "Toolkit Select". | an item. |
| 5 | $USER \to ME$ | Navigate in the items, then select | The ME may indicate to the user the |
| | | "Item 2". | consequences of performing the selection of |
| | | | an item. |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SELECT | Command performed successfully |
| | | ITEM 2.1.1 | |

PROACTIVE COMMAND: SELECT ITEM 2.1.1

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha identifier: "Toolkit Select"

Item

Identifier of item: 1

Text string of item: "Item 1"

Item

Identifier of item: 2

Text string of item: "Item 2"

Item

Identifier of item: 3

Text string of item: "Item 3"

Items next action indicator

Items list "Send SM", "Set Up Call", "Provide Local Info."

Coding:

| BER-TLV: | D0 | 39 | 81 | 03 | 01 | 24 | 00 | 82 | 02 | 81 | 82 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0E | 54 | 6F | 6F | 6C | 6B | 69 | 74 | 20 | 53 | 65 | 6C |
| | 65 | 63 | 74 | 8F | 07 | 01 | 49 | 74 | 65 | 6D | 20 | 31 |
| | 8F | 07 | 02 | 49 | 74 | 65 | 6D | 20 | 32 | 8F | 07 | 03 |
| | 49 | 74 | 65 | 6D | 20 | 33 | 18 | 03 | 13 | 10 | 26 | |

TERMINAL RESPONSE: SELECT ITEM 2.1.1

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Item identifier

Identifier of item chosen: 02

Coding:

| BER-TLV: | 81 | 03 | 01 | 24 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 90 | 01 | 02 | | | | | | | | | |

27.22.4.9.2.5 Test requirement

The ME shall operate in the manner defined in expected sequence 2.1

27.22.4.9.3 SELECT ITEM (default item support)

27.22.4.9.3.1 Definition and applicability

See clause 3.2.2.

27.22.4.9.3.2 Conformance requirement

Same as clause 27.22.4.9.1.2.

27.22.4.9.3.3 Test purpose

To verify that the mobile supports "default item" mode.

27.22.4.9.3.4 Method of test

27.22.4.9.3.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.9.3.4.2 Procedure

Expected Sequence 3.1 (SELECT ITEM, default item, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|-------------------------------------|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SELECT ITEM 3.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | |
| | | SELECT ITEM 3.1.1 | |
| 4 | $ME \to USER$ | Display items of "Item 1", "Item 2" | Check that "Item 2" is selected by default. |
| | | and "Item 3" under the header of | |
| | | "Toolkit Select". | |
| 5 | $USER \to ME$ | Navigate in the items, then select | |
| | | "Item 3". | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SELECT | Command performed successfully |
| | | ITEM 3.1.1 | |

PROACTIVE COMMAND: SELECT ITEM 3.1.1

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha identifier: "Toolkit Select"

Item

Identifier of item: 01
Text string of item: "Item 1"

Item

Identifier of item: 02

Text string of item: "Item 2"

Item

Identifier of item: 03
Text string of item: "Item 3"

Item identifier

Identifier of item chosen 02

Coding:

| BER-TLV: | D0 | 37 | 81 | 03 | 01 | 24 | 00 | 82 | 02 | 81 | 82 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0E | 54 | 6F | 6F | 6C | 6B | 69 | 74 | 20 | 53 | 65 | 6C |
| | 65 | 63 | 74 | 8F | 07 | 01 | 49 | 74 | 65 | 6D | 20 | 31 |
| | 8F | 07 | 02 | 49 | 74 | 65 | 6D | 20 | 32 | 8F | 07 | 03 |
| | 49 | 74 | 65 | 6D | 20 | 33 | 90 | 01 | 02 | | | |

TERMINAL RESPONSE: SELECT ITEM 3.1.1

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device:

ME

Destination device: SIM

Result

General Result: Command performed successfully

Item identifier

Identifier of item chosen: 03

Coding:

| BER-TLV: | 81 | 03 | 01 | 24 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 90 | 01 | 03 | | | | | | | | | |

27.22.4.9.3.5 Test requirement

The ME shall operate in the manner defined in expected sequence 3.1

27.22.4.9.4 SELECT ITEM (help request support)

27.22.4.9.4.1 Definition and applicability

See clause 3.2.2.

27.22.4.9.4.2 Conformance requirement

Same as clause 27.22.4.9.1.2.

27.22.4.9.4.3 Test purpose

To verify that the mobile supports "help request" for the command Select Item.

27.22.4.9.4.4 Method of test

27.22.4.9.4.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.9.4.4.2 Procedure

Expected Sequence 4.1 (SELECT ITEM, help request, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|---------------------------------------|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SELECT ITEM 4.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | [Help information available] |
| | | SELECT ITEM 4.1.1 | |
| 4 | $ME \rightarrow USER$ | Display items of "Item 1", "Item 2" | |
| | | and "Item 3" under the header of | |
| | | "Toolkit Select". | |
| 5 | $USER \to ME$ | Navigate in the items until "Item 1". | |
| 6 | $USER \to ME$ | Select the Help Request on "Item | |
| | | 1" Menu entry | |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SELECT | [Help information required by the user] |
| | | ITEM 4.1.1 | |

PROACTIVE COMMAND: SELECT ITEM 4.1.1

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "80" help information available

Device identities

Source device: SIM Destination device: ME

Alpha identifier: "Toolkit Select"

Item

Identifier of item: 01 Text string of item:

Item

"Item 1"

Identifier of item: 02 Text string of item: "Item 2"

Item

Identifier of item: 03 Text string of item: "Item 3"

Coding:

| BER-TLV: | D0 | 34 | 81 | 03 | 01 | 24 | 80 | 82 | 02 | 81 | 82 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0E | 54 | 6F | 6F | 6C | 6B | 69 | 74 | 20 | 53 | 65 | 6C |
| | 65 | 63 | 74 | 8F | 07 | 01 | 49 | 74 | 65 | 6D | 20 | 31 |
| | 8F | 07 | 02 | 49 | 74 | 65 | 6D | 20 | 32 | 8F | 07 | 03 |
| | 49 | 74 | 65 | 6D | 20 | 33 | | | | | | |

TERMINAL RESPONSE: SELECT ITEM 4.1.1

Logically:

Command details

Command number:

SELECT ITEM Command type:

Command qualifier: "80"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Help information required by the user Item identifier

Identifier of item chosen: 01

Coding:

| BER-TLV: | 81 | 03 | 01 | 24 | 80 | 82 | 02 | 82 | 81 | 83 | 01 | 13 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 90 | 01 | 01 | | | | | | | | | |

27.22.4.9.4.5 Test requirement

The ME shall operate in the manner defined in expected sequence 4.1

27.22.4.9.5 SELECT ITEM (icons support)

27.22.4.9.5.1 Definition and applicability

See clause 3.2.2.

27.22.4.9.5.2 Conformance requirement

Same as clause 27.22.4.9.1.2 and 3GPP TS 11.14 [15] clause 12.31 and clause 12.32.

27.22.4.9.5.3 Test purpose

To verify that the mobile displays icons with the command Select Item.

27.22.4.9.5.4 Method of test

27.22.4.9.5.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.9.5.4.2 Procedure

Expected Sequence 5.1A (SELECT ITEM, BASIC ICON NOT SELF EXPLANATORY, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-------------------------------------|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SELECT ITEM 5.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | |
| | | SELECT ITEM 5.1.1 | |
| 4 | $ME \rightarrow USER$ | Display items of "Item 1", "Item 2" | Verify icons are displayed in the alpha |
| | | and "Item 3" under the header of | identifier and in the 3 items. |
| | | "Toolkit Select". | |
| 5 | $USER \to ME$ | Navigate in the items, then select | |
| | | "Item 1". | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SELECT | [command performed successfully] |
| | | ITEM 5.1.1 A | |

PROACTIVE COMMAND: SELECT ITEM 5.1.1

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: SIM Destination device: ME

Alpha identifier: "Toolkit Select"

Item

Identifier of item: 01
Text string of item: "Item 1"

Item

Identifier of item: 02
Text string of item: "Item 2"

Item

Identifier of item: 03
Text string of item: "Item 3"

Icon Identifier:

Icon qualifier: "01" (icon is not self-explanatory)

Icon Identifier: record 1 in $EF_{(IMG)}$

Item icon identifier list:

Icon qualifier: "01" (icon is not self-explanatory)

Icon Identifier: record 5 in $EF_{(IMG)}$, record 5 in $EF_{(IMG)}$, record 5 in $EF_{(IMG)}$

Coding:

| BER-TLV: | D0 | 3E | 81 | 03 | 01 | 24 | 00 | 82 | 02 | 81 | 82 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0E | 54 | 6F | 6F | 6C | 6B | 69 | 74 | 20 | 53 | 65 | 6C |
| | 65 | 63 | 74 | 8F | 07 | 01 | 49 | 74 | 65 | 6D | 20 | 31 |
| | 8F | 07 | 02 | 49 | 74 | 65 | 6D | 20 | 32 | 8F | 07 | 03 |
| | 49 | 74 | 65 | 6D | 20 | 33 | 9E | 02 | 01 | 01 | 9F | 04 |
| | 01 | 05 | 05 | 05 | | | | | | | | |

TERMINAL RESPONSE: SELECT ITEM 5.1.1A

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Item identifier

Identifier of item chosen: 01

| BER-TLV: | 81 | 03 | 01 | 24 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| ' | 90 | 01 | 01 | | | | | | | | | |

Expected Sequence 5.1B (SELECT ITEM, BASIC ICON NOT SELF EXPLANATORY, requested icon could not be displayed)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-------------------------------------|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SELECT ITEM 5.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | |
| | | SELECT ITEM 5.1.1 | |
| 4 | $ME \rightarrow USER$ | Display items of "Item 1", "Item 2" | Verify that either for the header or for each of |
| | | and "Item 3" under the header of | the items no icon is displayed |
| | | "Toolkit Select". | |
| 5 | $USER \to ME$ | Navigate in the items, then select | |
| | | "Item 1" under the header 'Toolkit | |
| | | Select'. | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SELECT | [Command performed successfully, but |
| | | ITEM 5.1.1 B | requested icon could not be displayed] |

TERMINAL RESPONSE: SELECT ITEM 5.1.1B

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully but requested icon could not be displayed

Item identifier

Identifier of item chosen: 01

Coding:

| BER-TLV: | 81 | 03 | 01 | 24 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 04 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 90 | 01 | 01 | | | | | | | | | |

Expected Sequence 5.2A (SELECT ITEM, BASIC ICON SELF EXPLANATORY, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-------------------------------------|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SELECT ITEM 5.2.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | |
| | | SELECT ITEM 5.2.1 | |
| 4 | $ME \rightarrow USER$ | Display items of "Item 1", "Item 2" | Verify icons are displayed without text as |
| | | and "Item 3" under the header of | alpha id and for the all 3 items. |
| | | "Toolkit Select". | |
| 5 | $USER \to ME$ | Navigate in the items, then select | |
| | | "Item 1". | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SELECT | [command performed successfully] |
| 1 | | ITEM 5.2.1 A | |

PROACTIVE COMMAND: SELECT ITEM 5.2.1

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha identifier: "Toolkit Select"

Item

Identifier of item: 01

Text string of item: "Item 1"

Item

Identifier of item: 02
Text string of item: "Item 2"

Item

Identifier of item: 03
Text string of item: "Item 3"

Icon Identifier:

Icon qualifier: "00" (icon is self-explanatory)

Icon Identifier: record 1 in $EF_{(IMG)}$

Item icon identifier list:

Icon qualifier: "00" (icon is self-explanatory)

Icon Identifier: record 5 in $EF_{(IMG)}$, record 5 in $EF_{(IMG)}$, record 5 in $EF_{(IMG)}$

Coding:

| BER-TLV: | D0 | 3E | 81 | 03 | 01 | 24 | 00 | 82 | 02 | 81 | 82 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| • | 0E | 54 | 6F | 6F | 6C | 6B | 69 | 74 | 20 | 53 | 65 | 6C |
| | 65 | 63 | 74 | 8F | 07 | 01 | 49 | 74 | 65 | 6D | 20 | 31 |
| | 8F | 07 | 02 | 49 | 74 | 65 | 6D | 20 | 32 | 8F | 07 | 03 |
| | 49 | 74 | 65 | 6D | 20 | 33 | 9E | 02 | 00 | 01 | 9F | 04 |
| | 00 | 05 | 05 | 05 | | | | | | | | |

TERMINAL RESPONSE: SELECT ITEM 5.2.1A

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Item identifier

Identifier of item chosen: 01

| BER-TLV: | 81 | 03 | 01 | 24 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 90 | 01 | 01 | | | | | | | | | |

Expected Sequence 5.2B (SELECT ITEM, BASIC ICON SELF EXPLANATORY, requested icon could not be displayed)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-------------------------------------|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SELECT ITEM 5.2.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | |
| | | SELECT ITEM 5.2.1 | |
| 4 | $ME \rightarrow USER$ | Display items of "Item 1", "Item 2" | Verify that either for the header or for each of |
| | | and "Item 3" under the header of | the items no icon is displayed. |
| | | "Toolkit Select". | |
| 5 | $USER \to ME$ | Navigate in the items, then select | |
| | | "Item 1" under the header "Toolkit | |
| | | Select". | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SELECT | [command performed successfully but |
| | | ITEM 5.2.1B | requested icon could not be displayed] |

TERMINAL RESPONSE: SELECT ITEM 5.2.1B

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully but requested icon could not be displayed

Item identifier

Identifier of item chosen: 01

Coding:

| BER-TLV: | 81 | 03 | 01 | 24 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 04 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 90 | 01 | 01 | | | | | | | | | |

27.22.4.9.5.5 Test requirement

The ME shall operate in the manner defined in expected sequences 5.1A to 5.2B.

27.22.4.9.6 SELECT ITEM (presentation style)

27.22.4.9.6.1 Definition and applicability

See clause 3.2.2.

27.22.4.9.6.2 Conformance requirement

Same as clause 27.22.4.9.1.2.

27.22.4.9.6.3 Test purpose

To verify that the mobile supports the "presentation style" with the command Select Item.

27.22.4.9.6.4 Method of test

27.22.4.9.6.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.9.6.4.2 Procedure

Expected Sequence 6.1 (SELECT ITEM, PRESENTATION AS A CHOICE OF NAVIGATION OPTIONS, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|-------------------------------------|---------------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SELECT ITEM 6.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | |
| | | SELECT ITEM 6.1.1 | |
| 4 | $ME \to USER$ | Display items of "Item 1", "Item 2" | Verify if presentation style appears. |
| | | and "Item 3" under the header of | |
| | | "Toolkit Select". | |
| 5 | $USER \to ME$ | Navigate in the items, then select | |
| | | "Item 1". | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SELECT | [command performed successfully] |
| | | ITEM 6.1.1 | |

PROACTIVE COMMAND: SELECT ITEM 6.1.1

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "03" (presentation as a choice of navigation options)

Device identities

Source device: SIM
Destination device: ME

Alpha identifier: "Toolkit Select"

Item

Identifier of item: 01
Text string of item: "Item 1"

Item

Identifier of item: 02
Text string of item: "Item 2"

Item

Identifier of item: 03
Text string of item: "Item 3"

| BER-TLV: | D0 | 34 | 81 | 03 | 01 | 24 | 03 | 82 | 02 | 81 | 82 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0E | 54 | 6F | 6F | 6C | 6B | 69 | 74 | 20 | 53 | 65 | 6C |
| | 65 | 63 | 74 | 8F | 07 | 01 | 49 | 74 | 65 | 6D | 20 | 31 |
| | 8F | 07 | 02 | 49 | 74 | 65 | 6D | 20 | 32 | 8F | 07 | 03 |
| | 49 | 74 | 65 | 6D | 20 | 33 | | | | | | |

TERMINAL RESPONSE: SELECT ITEM 6.1.1

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "03" (presentation as a choice of navigation options)

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Item identifier

Identifier of item chosen: 01

Coding:

| BER-TLV: | 81 | 03 | 01 | 24 | 03 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 90 | 01 | 01 | | | | | | | | | |

Expected Sequence 6.2 (SELECT ITEM, PRESENTATION AS A CHOICE OF DATA VALUES, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-------------------------------------|--------------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SELECT ITEM 6.2.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | |
| | | SELECT ITEM 6.2.1 | |
| 4 | $ME \rightarrow USER$ | Display items of "Item 1", "Item 2" | Verify if presentation style appears |
| | | and "Item 3" under the header of | |
| | | "Toolkit Select". | |
| 5 | $USER \to ME$ | Navigate in the items, then select | |
| | | "Item 1". | |
| 6 | $ME \to SIM$ | TERMINAL RESPONSE: SELECT | [command performed successfully] |
| | | ITEM 6.2.1 | |

PROACTIVE COMMAND: SELECT ITEM 6.2.1

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "01" (presentation as a choice of data values)

Device identities

Source device: SIM Destination device: ME

Alpha identifier: "Toolkit Select"

Item

Identifier of item: 01
Text string of item: "Item 1"

Item

Identifier of item: 02
Text string of item: "Item 2"

Item

Identifier of item: 03
Text string of item: "Item 3"

Coding:

| BER-TLV: | D0 | 34 | 81 | 03 | 01 | 24 | 01 | 82 | 02 | 81 | 82 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0E | 54 | 6F | 6F | 6C | 6B | 69 | 74 | 20 | 53 | 65 | 6C |
| | 65 | 63 | 74 | 8F | 07 | 01 | 49 | 74 | 65 | 6D | 20 | 31 |
| | 8F | 07 | 02 | 49 | 74 | 65 | 6D | 20 | 32 | 8F | 07 | 03 |
| | 49 | 74 | 65 | 6D | 20 | 33 | | | | | | |

TERMINAL RESPONSE: SELECT ITEM 6.2.1

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "01"(presentation as a choice of data values)

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Item identifier

Identifier of item chosen: 01

Coding:

| BER-TLV: | 81 | 03 | 01 | 24 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 90 | 01 | 01 | | | | | | | | | |

27.22.4.9.6.5 Test requirement

The ME shall operate in the manner defined in expected sequences 6.1 and 6.2.

27.22.4.9.7 SELECT ITEM (soft keys support)

27.22.4.9.7.1 Definition and applicability

See clause 3.2.2.

27.22.4.9.7.2 Conformance requirement

Same as clause 27.22.4.9.1.2.

27.22.4.9.7.3 Test purpose

To verify that the mobile supports the "soft keys" with the command Select Item.

27.22.4.9.7.4 Method of test

27.22.4.9.7.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.9.7.4.2 Procedure

Expected Sequence 7.1 (SELECT ITEM, SELECTING USING SOFT KEYS PREFERRED, successful, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-------------------------------------|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SELECT ITEM 7.1.1 | |
| 2 | $ME \to SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | |
| | | SELECT ITEM 7.1.1 | |
| 4 | $ME \rightarrow USER$ | Display items of "Item 1", "Item 2" | |
| | | under the header of "Toolkit | |
| | | Select". | |
| 5 | $USER \to ME$ | Navigate in the items, then select | Verify that we can choose an item through |
| | | "Item 1". | soft keys |
| 6 | $ME \to SIM$ | TERMINAL RESPONSE: SELECT | [command performed successfully] |
| | | ITEM 7.1.1 | |

PROACTIVE COMMAND: SELECT ITEM 7.1.1

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "04" (selection using soft keys preferred)

Device identities

Source device: SIM
Destination device: ME

Alpha identifier: "Toolkit Select"

Item

Identifier of item: 01
Text string of item: "Item 1"

Item

Identifier of item: 02
Text string of item: "Item 2"

Coding:

| BER-TLV: | D0 | 2B | 81 | 03 | 01 | 24 | 04 | 82 | 02 | 81 | 82 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| - | 0E | 54 | 6F | 6F | 6C | 6B | 69 | 74 | 20 | 53 | 65 | 6C |
| | 65 | 63 | 74 | 8F | 07 | 01 | 49 | 74 | 65 | 6D | 20 | 31 |
| | 8F | 07 | 02 | 49 | 74 | 65 | 6D | 20 | 32 | | | |

TERMINAL RESPONSE: SELECT ITEM 7.1.1

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "04" (selection using soft keys preferred)

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Item identifier

Identifier of item chosen: 01

207

Coding:

| BER-TLV: | 81 | 03 | 01 | 24 | 04 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 90 | 01 | 01 | | | | | | | | | |

27.22.4.9.7.5 Test requirement

The ME shall operate in the manner defined in expected sequence 7.1.

27.22.4.9.8 SELECT ITEM (Support of "No response from user")

27.22.4.9.8.1 Definition and applicability

See clause 3.2.2.

27.22.4.9.8.2 Conformance requirement

Same as clause 27.22.4.9.1.2.

27.22.4.9.8.3 Test purpose

To verify that after a period of user inactivity the ME returns a "No response from user" result value in the TERMINAL RESPONSE command sent to the SIM.

27.22.4.9.8.4 Method of test

27.22.4.9.8.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME Manufacturer shall have defined the "no response from user" period of time.

The SIM simulator shall be set to that period of time.

27.22.4.9.8.4.2 Procedure

Expected Sequence 8.1 (SELECT ITEM, no response from user)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-------------------------------------|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SELECT ITEM 8.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | |
| | | SELECT ITEM 8.1.1 | |
| 4 | $ME \rightarrow USER$ | Display items of "Item 1", "Item 2" | |
| | | and "Item 3" under the header of | |
| | | " <time-out>".</time-out> | |
| 5 | USER | Waiting and no completion | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SELECT | [No response from user] within 5 s after the |
| | | ITEM 8.1.1 | end of that defined period of time |
| 7 | USER | Check if the delay of TERMINAL | |
| | | RESPONSE is reasonable or not | |

PROACTIVE COMMAND: SELECT ITEM 8.1.1

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha identifier: "<TIME-OUT>"

Item

Identifier of item: 01

Text string of item: "Item 1"

Item

Identifier of item: 02
Text string of item: "Item 2"

Item

Identifier of item: 03
Text string of item: "Item 3"

Coding:

| BER-TLV: | D0 | 30 | 81 | 03 | 01 | 24 | 00 | 82 | 02 | 81 | 82 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0A | 3C | 54 | 49 | 4D | 45 | 2D | 4F | 55 | 54 | 3E | 8F |
| | 07 | 01 | 49 | 74 | 65 | 6D | 20 | 31 | 8F | 07 | 02 | 49 |
| | 74 | 65 | 6D | 20 | 32 | 8F | 07 | 03 | 49 | 74 | 65 | 6D |
| | 20 | 33 | | | | | | | | | | |

TERMINAL RESPONSE: SELECT ITEM 8.1.1

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: No response from user

Coding:

BER-TLV: 81 03 01 24 00 82 02 82 81 83 01 12

27.22.4.9.8.5 Test requirement

The ME shall operate in the manner defined in expected sequence 8.1.

27.22.4.10 SEND SHORT MESSAGE

27.22.4.10.1 SEND SHORT MESSAGE (normal)

27.22.4.10.1.1 Definition and applicability

See clause 3.2.2.

27.22.4.10.1.2 Conformance requirement

The ME shall support the Proactive SIM: SEND SHORT MESSAGE facility as defined in:

• 3GPP TS 11.14 [15] clause 6.1, clause 6.4.10, clause 6.6.9, clause 12.6, clause 12.7, clause 12.2, clause 12.1, clause 12.13, clause 12.31 and clause 5.2.

27.22.4.10.1.3 Test purpose

To verify that the ME correctly formats and sends a short message to the network (System Simulator) as indicated in the SEND SHORT MESSAGE proactive SIM command, and returns a TERMINAL RESPONSE command to the SIM indicating the status of the transmission of the Short Message.

27.22.4.10.1.4 Method of test

27.22.4.10.1.4.1 Initial conditions

The ME is connected to the SIM Simulator and only connected to the System Simulator if the System Simulator is mentioned in the sequence table. Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.10.1.4.2 Procedure

Expected Sequence 1.1(SEND SHORT MESSAGE, packing not required, 8-bit data, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-------------------------|------------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SEND SHORT | |
| | | MESSAGE 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SEND | [packing not required, 8-bit data] |
| | | SHORT MESSAGE 1.1.1 | - |
| 4 | $ME \rightarrow USER$ | Display "Send SM" | [Alpha Identifier] |
| 5 | $ME \to SS$ | Send SMS-PP (SEND SHORT | |
| | | MESSAGE) Message 1.1 | |
| 6 | $SS \to ME$ | SMS RP-ACK | |
| 7 | $ME \to SIM$ | TERMINAL RESPONSE: SEND | [Command performed successfully] |
| | | SHORT MESSAGE 1.1.1 | |

PROACTIVE COMMAND: SEND SHORT MESSAGE 1.1.1

Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE packing not required

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "Send SM"

Address

TON: International number

NPI: "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding 8-bit data
Message class class 0
TP-UDL 12

TP-UD "Test Message"

Coding:

| BER-TLV: | D0 | 37 | 81 | 03 | 01 | 13 | 00 | 82 | 02 | 81 | 83 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 07 | 53 | 65 | 6E | 64 | 20 | 53 | 4D | 86 | 09 | 91 | 11 |
| | 22 | 33 | 44 | 55 | 66 | 77 | F8 | 8B | 18 | 01 | 00 | 09 |
| | 91 | 10 | 32 | 54 | 76 | F8 | 40 | F4 | 0C | 54 | 65 | 73 |
| | 74 | 20 | 4D | 65 | 73 | 73 | 61 | 67 | 65 | | | |

SMS-PP (SEND SHORT MESSAGE) Message 1.1

Logically:

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "01"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding 8-bit data
Message class class 0
TP-UDL 12

TP-UD "Test Message"

Coding:

| Coding | 01 | 01 | 09 | 91 | 10 | 32 | 54 | 76 | F8 | 40 | F4 | 0C |
|--------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 54 | 65 | 73 | 74 | 20 | 4D | 65 | 73 | 73 | 61 | 67 | 65 |

TERMINAL RESPONSE: SEND SHORT MESSAGE 1.1.1

Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE packing not required

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: 81 03 01 | 13 0 | 82 | 02 | 82 | 81 | 83 | 01 | 00 | ĺ |
|-------------------|------|----|----|----|----|----|----|----|---|
|-------------------|------|----|----|----|----|----|----|----|---|

Expected Sequence 1.2 (SEND SHORT MESSAGE, packing required, 8-bit data, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|-------------------------|----------------------------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: SEND SHORT | |
| | | MESSAGE 1.2.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SEND | [packing required, 8-bit data] |
| | | SHORT MESSAGE 1.2.1 | |
| 4 | | Display "Send SM" | [Alpha Identifier] |
| 5 | $ME \to SS$ | Send SMS-PP (SEND SHORT | |
| | | MESSAGE) Message 1.2 | |
| 6 | $SS \to ME$ | SMS RP-ACK | |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND | [Command performed successfully] |
| | | SHORT MESSAGE 1.2.1 | |

PROACTIVE COMMAND: SEND SHORT MESSAGE 1.2.1

Logically:

Command details

Command number:

Command type: SEND SHORT MESSAGE

Command qualifier: packing required

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "Send SM"

Address

TON: International number

NPI: "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI The TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding 8-bit data
Message class class 0
TP-UDL 7

TP-UD "Send SM"

Coding:

| BER-TLV: | D0 | 32 | 81 | 03 | 01 | 13 | 01 | 82 | 02 | 81 | 83 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 07 | 53 | 65 | 6E | 64 | 20 | 53 | 4D | 86 | 09 | 91 | 11 |
| | 22 | 33 | 44 | 55 | 66 | 77 | F8 | 8B | 13 | 01 | 00 | 09 |
| | 91 | 10 | 32 | 54 | 76 | F8 | 40 | F4 | 07 | 53 | 65 | 6E |
| | 64 | 20 | 53 | 4D | | | | | | | | |

SMS-PP (SEND SHORT MESSAGE) Message 1.2

Logically:

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "01"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding SMS default alphabet

Message class 0 TP-UDL 7

TP-UD "Send SM"

Coding:

| Coding | 01 | 01 | 09 | 91 | 10 | 32 | 54 | 76 | F8 | 40 | F0 | 07 |
|--------|----|----|----|----|----|----|----|----|----|----|----|----|
| | D3 | B2 | 9B | 0C | 9A | 36 | 01 | | | | | |

TERMINAL RESPONSE: SEND SHORT MESSAGE 1.2.1

Logically:

Command details

Command number:

Command type: SEND SHORT MESSAGE

Command qualifier: packing required

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

| BER-TLV: | 81 | 03 | 01 | 13 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
|----------|----|----|----|----|----|----|----|----|----|----|----|----|

Expected Sequence 1.3 (SEND SHORT MESSAGE, packing not required, SMS default alphabet, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-------------------------|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SEND SHORT | |
| | | MESSAGE 1.3.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SEND | [packing not required, SMS default alphabet] |
| | | SHORT MESSAGE 1.3.1 | |
| 4 | $ME \rightarrow USER$ | Display "Short Message" | [Alpha Identifier] |
| 5 | $ME \to SS$ | Send SMS-PP (SEND SHORT | |
| | | MESSAGE) Message 1.3 | |
| 6 | $SS \to ME$ | SMS RP-ACK | |
| 7 | $ME \to SIM$ | TERMINAL RESPONSE: SEND | [Command performed successfully] |
| | | SHORT MESSAGE 1.3.1 | |

PROACTIVE COMMAND: SEND SHORT MESSAGE 1.3.1

Logically:

Command details

Command number:

Command type: SEND SHORT MESSAGE packing not required

Command qualifier:

Device identities

Source device: SIM Destination device: Network Alpha identifier: "Short Message"

Address

TON: International number

NPI: "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

SMS TPDU

TP-MTI **SMS-SUBMIT**

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI The TP-UD field contains only the short message

TP-SRR A status report is not requested

"00" TP-MR

TP-DA

TON International number

"ISDN / telephone numbering plan" NPI

"012345678" Address value

TP-PID Short message type 0

TP-DCS

Message coding SMS default alphabet

Message class class 0 TP-UDL 13

TP-UD "Short Message"

| BER-TLV: | D0 | 3D | 81 | 03 | 01 | 13 | 00 | 82 | 02 | 81 | 83 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0D | 53 | 68 | 6F | 72 | 74 | 20 | 4D | 65 | 73 | 73 | 61 |
| | 67 | 65 | 86 | 09 | 91 | 11 | 22 | 33 | 44 | 55 | 66 | 77 |
| | F8 | 8B | 18 | 01 | 00 | 09 | 91 | 10 | 32 | 54 | 76 | F8 |
| | 40 | F0 | 0D | 53 | F4 | 5B | 4E | 07 | 35 | CB | F3 | 79 |
| | F8 | 5C | 06 | | | | | | | | | |

SMS-PP (SEND SHORT MESSAGE) Message 1.3

Logically:

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "01"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding SMS default alphabet

Message class 0 TP-UDL 13

TP-UD "Short Message"

Coding:

| Coding | 01 | 01 | 09 | 91 | 10 | 32 | 54 | 76 | F8 | 40 | F0 | 0D |
|--------|----|----|----|----|----|----|----|----|----|----|----|----|
| · | 53 | F4 | 5B | 4E | 07 | 35 | CB | F3 | 79 | F8 | 5C | 06 |

TERMINAL RESPONSE: SEND SHORT MESSAGE 1.3.1

Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE

Command qualifier: packing not required

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

| DE | R-TLV: | 01 | 03 | 01 | 12 | 00 | 92 | 02 | 92 | 01 | 92 | 01 | 00 |
|----|--------|----|----|----|----|----|----|----|----|----|----|----|----|
| | K-ILV. | 01 | 03 | 01 | 13 | UU | 02 | 02 | 82 | 01 | ೦೦ | UI | UU |

Expected Sequence 1.4 (SEND SHORT MESSAGE, packing required, 8 bit data, message of 160 characters user data, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|----------------------------------|----------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SEND SHORT | |
| | | MESSAGE 1.4. 1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SEND | [packing required, 8 bit data] |
| | | SHORT MESSAGE 1.4.1 | |
| 4 | $ME \rightarrow USER$ | Display "The address data object | [Alpha Identifier] |
| | | holds the RP_Destination_Address | |
| | | " | |
| 5 | $ME \to SS$ | ` | [message of 140 bytes user data] |
| | | MESSAGE) Message 1.4 | |
| 6 | $SS \to ME$ | SMS RP-ACK | |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND | [Command performed successfully] |
| | | SHORT MESSAGE 1.4.1 | |

PROACTIVE COMMAND: SEND SHORT MESSAGE 1.4.1

Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE

Command qualifier: packing required

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "The address data object holds the RP_Destination_Address"

Address

TON: International number

NPI: "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding 8 bit data Message class class 0 TP-UDL 160

TP-UD "Two types are defined: - A short message to be sent to the network in an

SMS-SUBMIT message, or an SMS-COMMAND message, where the user data can

be passed transp"

Coding:

| | 1 | | | | | | | | | | | |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| BER-TLV: | D0 | 81 | FD | 81 | 03 | 01 | 13 | 01 | 82 | 02 | 81 | 83 |
| | 85 | 38 | 54 | 68 | 65 | 20 | 61 | 64 | 64 | 72 | 65 | 73 |
| | 73 | 20 | 64 | 61 | 74 | 61 | 20 | 6F | 62 | 6A | 65 | 63 |
| | 74 | 20 | 68 | 6F | 6C | 64 | 73 | 20 | 74 | 68 | 65 | 20 |
| | 52 | 50 | 11 | 44 | 65 | 73 | 74 | 69 | 6E | 61 | 74 | 69 |
| | 6F | 6E | 11 | 41 | 64 | 64 | 72 | 65 | 73 | 73 | 86 | 09 |
| | 91 | 11 | 22 | 33 | 44 | 55 | 66 | 77 | F8 | 8B | 81 | AC |
| | 01 | 00 | 09 | 91 | 10 | 32 | 54 | 76 | F8 | 40 | F4 | A0 |
| | 54 | 77 | 6F | 20 | 74 | 79 | 70 | 65 | 73 | 20 | 61 | 72 |
| | 65 | 20 | 64 | 65 | 66 | 69 | 6E | 65 | 64 | 3A | 20 | 2D |
| | 20 | 41 | 20 | 73 | 68 | 6F | 72 | 74 | 20 | 6D | 65 | 73 |
| | 73 | 61 | 67 | 65 | 20 | 74 | 6F | 20 | 62 | 65 | 20 | 73 |
| | 65 | 6E | 74 | 20 | 74 | 6F | 20 | 74 | 68 | 65 | 20 | 6E |
| | 65 | 74 | 77 | 6F | 72 | 6B | 20 | 69 | 6E | 20 | 61 | 6E |
| | 20 | 53 | 4D | 53 | 2D | 53 | 55 | 42 | 4D | 49 | 54 | 20 |
| | 6D | 65 | 73 | 73 | 61 | 67 | 65 | 2C | 20 | 6F | 72 | 20 |
| | 61 | 6E | 20 | 53 | 4D | 53 | 2D | 43 | 4F | 4D | 4D | 41 |
| | 4E | 44 | 20 | 6D | 65 | 73 | 73 | 61 | 67 | 65 | 2C | 20 |
| | 77 | 68 | 65 | 72 | 65 | 20 | 74 | 68 | 65 | 20 | 75 | 73 |
| | 65 | 72 | 20 | 64 | 61 | 74 | 61 | 20 | 63 | 61 | 6E | 20 |
| | 62 | 65 | 20 | 70 | 61 | 73 | 73 | 65 | 64 | 20 | 74 | 72 |
| | 61 | 6E | 73 | 70 | | | | | | | | |

SMS-PP (SEND SHORT MESSAGE) Message 1.4

Logically:

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI The TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "01"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding SMS default alphabet

Message class 0 TP-UDL 160

TP-UD "Two types are defined: - A short message to be sent to the network in an

SMS-SUBMIT message, or an SMS-COMMAND message, where the user data can

be passed transp"

Coding:

| Coding | | 01 | 01 | 09 | 91 | 10 | 32 | 54 | 76 | F8 | 40 | F0 |
|--------|----|----|----|----|----|----|----|----|----|----|----|----|
| | A0 | D4 | FB | 1B | 44 | CF | C3 | CB | 73 | 50 | 58 | 5E |
| | 06 | 91 | СВ | E6 | B4 | BB | 4C | D6 | 81 | 5A | A0 | 20 |
| | 68 | 8E | 7E | СВ | E9 | A0 | 76 | 79 | 3E | 0F | 9F | CB |
| | 20 | FA | 1B | 24 | 2E | 83 | E6 | 65 | 37 | 1D | 44 | 7F |
| | 83 | E8 | E8 | 32 | C8 | 5D | A6 | DF | DF | F2 | 35 | 28 |
| | ED | 06 | 85 | DD | A0 | 69 | 73 | DA | 9A | 56 | 85 | CD |
| | 24 | 15 | D4 | 2E | CF | E7 | E1 | 73 | 99 | 05 | 7A | CB |
| | 41 | 61 | 37 | 68 | DA | 9C | B6 | 86 | CF | 66 | 33 | E8 |
| | 24 | 82 | DA | E5 | F9 | 3C | 7C | 2E | В3 | 40 | 77 | 74 |
| | 59 | 5E | 06 | D1 | D1 | 65 | 50 | 7D | 5E | 96 | 83 | C8 |
| | 61 | 7A | 18 | 34 | 0E | BB | 41 | E2 | 32 | 08 | 1E | 9E |
| | CF | СВ | 64 | 10 | 5D | 1E | 76 | CF | E1 | | | |

TERMINAL RESPONSE: SEND SHORT MESSAGE 1.4.1

Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE

Command qualifier: packing required

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: 81 03 01 13 | 01 82 02 | 82 81 83 | 01 00 |
|----------------------|----------|----------|-------|
|----------------------|----------|----------|-------|

Expected Sequence 1.5 (SEND SHORT MESSAGE, packing not required, SMS default alphabet, message of 160 characters user data, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|------------------------------------|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SEND SHORT | |
| | | MESSAGE 1.5.1 | |
| 2 | $ME \to SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SEND | [packing not required, SMS default alphabet] |
| | | SHORT MESSAGE 1.5.1 | |
| 4 | $ME \rightarrow USER$ | Display "The address data object | [Alpha Identifier] |
| | | holds the RP Destination Address " | |
| 5 | $ME \to SS$ | Send SMS-PP (SEND SHORT | [message of 140 bytes user data] |
| | | MESSAGE) Message 1.5 | |
| 6 | $SS \to ME$ | SMS RP-ACK | |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND | [Command performed successfully] |
| | | SHORT MESSAGE 1.5.1 | |

PROACTIVE COMMAND: SEND SHORT MESSAGE 1.5.1

Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE packing not required

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "The address data object holds the RP Destination Address"

Address

TON: International number

NPI: "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI The TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding SMS default alphabet

Message class 0 TP-UDL 160

TP-UD "Two types are defined: - A short message to be sent to the network in an

SMS-SUBMIT message, or an SMS-COMMAND message, where the user data can

be passed transp"

Coding:

| BER-TLV: | D0 | 81 | E9 | 81 | 03 | 01 | 13 | 00 | 82 | 02 | 81 | 83 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 85 | 38 | 54 | 68 | 65 | 20 | 61 | 64 | 64 | 72 | 65 | 73 |
| | 73 | 20 | 64 | 61 | 74 | 61 | 20 | 6F | 62 | 6A | 65 | 63 |
| | 74 | 20 | 68 | 6F | 6C | 64 | 73 | 20 | 74 | 68 | 65 | 20 |
| | 52 | 50 | 20 | 44 | 65 | 73 | 74 | 69 | 6E | 61 | 74 | 69 |
| | 6F | 6E | 20 | 41 | 64 | 64 | 72 | 65 | 73 | 73 | 86 | 09 |
| | 91 | 11 | 22 | 33 | 44 | 55 | 66 | 77 | F8 | 8B | 81 | 98 |
| | 01 | 00 | 09 | 91 | 10 | 32 | 54 | 76 | F8 | 40 | F0 | A0 |
| | D4 | FB | 1B | 44 | CF | C3 | CB | 73 | 50 | 58 | 5E | 06 |
| | 91 | CB | E6 | B4 | BB | 4C | D6 | 81 | 5A | A0 | 20 | 68 |
| | 8E | 7E | CB | E9 | A0 | 76 | 79 | 3E | 0F | 9F | CB | 20 |
| | FA | 1B | 24 | 2E | 83 | E6 | 65 | 37 | 1D | 44 | 7F | 83 |
| | E8 | E8 | 32 | C8 | 5D | A6 | DF | DF | F2 | 35 | 28 | ED |
| | 06 | 85 | DD | A0 | 69 | 73 | DA | 9A | 56 | 85 | CD | 24 |
| | 15 | D4 | 2E | CF | E7 | E1 | 73 | 99 | 05 | 7A | CB | 41 |
| | 61 | 37 | 68 | DA | 9C | B6 | 86 | CF | 66 | 33 | E8 | 24 |
| | 82 | DA | E5 | F9 | 3C | 7C | 2E | В3 | 40 | 77 | 74 | 59 |
| | 5E | 06 | D1 | D1 | 65 | 50 | 7D | 5E | 96 | 83 | C8 | 61 |
| | 7A | 18 | 34 | 0E | BB | 41 | E2 | 32 | 08 | 1E | 9E | CF |
| | CB | 64 | 10 | 5D | 1E | 76 | CF | E1 | | | | |
| | | | | | | | | | | | | |

SMS-PP (SEND SHORT MESSAGE) Message 1.5

Logically:

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI The TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "01"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding SMS default alphabet

Message class 0 TP-UDL 160

TP-UD "Two types are defined: - A short message to be sent to the network in an SMS-

SUBMIT message, or an SMS-COMMAND message, where the user data can be

passed transp"

Coding:

| Coding | 01 | 01 | 09 | 91 | 10 | 32 | 54 | 76 | F8 | 40 | F0 | A0 |
|--------|----|----|----|----|----|----|----|----|----|----|----|----|
| | D4 | FB | 1B | 44 | CF | C3 | CB | 73 | 50 | 58 | 5E | 06 |
| | 91 | CB | E6 | B4 | BB | 4C | D6 | 81 | 5A | A0 | 20 | 68 |
| | 8E | 7E | СВ | E9 | A0 | 76 | 79 | 3E | 0F | 9F | CB | 20 |
| | FA | 1B | 24 | 2E | 83 | E6 | 65 | 37 | 1D | 44 | 7F | 83 |
| | E8 | E8 | 32 | C8 | 5D | A6 | DF | DF | F2 | 35 | 28 | ED |
| | 06 | 85 | DD | A0 | 69 | 73 | DA | 9A | 56 | 85 | CD | 24 |
| | 15 | D4 | 2E | CF | E7 | E1 | 73 | 99 | 05 | 7A | CB | 41 |
| | 61 | 37 | 68 | DA | 9C | B6 | 86 | CF | 66 | 33 | E8 | 24 |
| | 82 | DA | E5 | F9 | 3C | 7C | 2E | В3 | 40 | 77 | 74 | 59 |
| | 5E | 06 | D1 | D1 | 65 | 50 | 7D | 5E | 96 | 83 | C8 | 61 |
| | 7A | 18 | 34 | 0E | BB | 41 | E2 | 32 | 80 | 1E | 9E | CF |
| | CB | 64 | 10 | 5D | 1E | 76 | CF | E1 | | | | |

TERMINAL RESPONSE: SEND SHORT MESSAGE 1.5.1

Logically:

Command details

Command number:

Command type: SEND SHORT MESSAGE

Command qualifier: packing not required

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

| DED TIV | 0.4 | 02 | 01 | 40 | 00 | 0.0 | 00 | 0.0 | 0.4 | 0.2 | 01 | 00 |
|---------|-----|--------|----|-----|--------|-----|-------|-----|-----|-------|----|--------|
| DEK-IIV | | 1 ().5 | | 1.5 | 1 ()() | 0/ | 1 11/ | 0/ | | 1 0.3 | | 1 ()() |

Expected Sequence 1.6 (SEND SHORT MESSAGE, alpha identifier 160 bytes long, SMS default alphabet, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-------------------------------------|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SEND SHORT | |
| | | MESSAGE 1.6.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SEND | [packing not required, SMS default alphabet] |
| | | SHORT MESSAGE 1.6.1 | |
| 4 | $ME \rightarrow USER$ | Display "Two types are defined: - A | [Alpha Identifier of 160 bytes] |
| | | short message to be sent to the | |
| | | network in an SMS-SUBMIT | |
| | | message, or an SMS-COMMAND | |
| | | message, where the user data can | |
| | | be passed transparently; - A short | |
| | | message to be sent to the network | |
| | | in an SMS-SUBMIT " | |
| 5 | $ME \rightarrow SS$ | Send SMS-PP (SEND SHORT | |
| | | MESSAGE) Message 1.6 | |
| 6 | $SS \rightarrow ME$ | SMS RP-ACK | |
| 7 | $ME \rightarrow SIM$ | | [Command performed successfully] |
| | | SHORT MESSAGE 1.6.1 | |

PROACTIVE COMMAND: SEND SHORT MESSAGE 1.6.1

Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE packing not required

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "Two types are defined: - A short message to be sent to the network in an

SMS-SUBMIT message, or an SMS-COMMAND message, where the user data can

be passed transparently; - A short message to be sent to the network in an

SMS-SUBMIT"

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI The TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "01"

TP-PID Short message type 0

TP-DCS

Message coding SMS default alphabet

Message class 0
TP-UDL 1
TP-UD " "

Coding:

| D0 | 81 | FD | 81 | 03 | 01 | 13 | 00 | 82 | 02 | 81 | 83 |
|----|--|--|---|---|--|---|---|--|---|--|---|
| 85 | 81 | E6 | 54 | 77 | 6F | 20 | 74 | 79 | 70 | 65 | 73 |
| 20 | 61 | 72 | 65 | 20 | 64 | 65 | 66 | 69 | 6E | 65 | 64 |
| 3A | 20 | 2D | 20 | 41 | 20 | 73 | 68 | 6F | 72 | 74 | 20 |
| 6D | 65 | 73 | 73 | 61 | 67 | 65 | 20 | 74 | 6F | 20 | 62 |
| 65 | 20 | 73 | 65 | 6E | 74 | 20 | 74 | 6F | 20 | 74 | 68 |
| 65 | 20 | 6E | 65 | 74 | 77 | 6F | 72 | 6B | 20 | 69 | 6E |
| 20 | 61 | 6E | 20 | 53 | 4D | 53 | 2D | 53 | 55 | 42 | 4D |
| 49 | 54 | 20 | 6D | 65 | 73 | 73 | 61 | 67 | 65 | 2C | 20 |
| 6F | 72 | 20 | 61 | 6E | 20 | 53 | 4D | 53 | 2D | 43 | 4F |
| 4D | 4D | 41 | 4E | 44 | 20 | 6D | 65 | 73 | 73 | 61 | 67 |
| 65 | 2C | 20 | 77 | 68 | 65 | 72 | 65 | 20 | 74 | 68 | 65 |
| 20 | 75 | 73 | 65 | 72 | 20 | 64 | 61 | 74 | 61 | 20 | 63 |
| 61 | 6E | 20 | 62 | 65 | 20 | 70 | 61 | 73 | 73 | 65 | 64 |
| 20 | 74 | 72 | 61 | 6E | 73 | 70 | 61 | 72 | 65 | 6E | 74 |
| 6C | 79 | 3B | 20 | 2D | 20 | 41 | 20 | 73 | 68 | 6F | 72 |
| 74 | 20 | 6D | 65 | 73 | 73 | 61 | 67 | 65 | 20 | 74 | 6F |
| 20 | 62 | 65 | 20 | 73 | 65 | 6E | 74 | 20 | 74 | 6F | 20 |
| 74 | 68 | 65 | 20 | 6E | 65 | 74 | 77 | 6F | 72 | 6B | 20 |
| 69 | 6E | 20 | 61 | 6E | 20 | 53 | 4D | 53 | 2D | 53 | 55 |
| 42 | 4D | 49 | 54 | 20 | 8B | 09 | 01 | 00 | 02 | 91 | 10 |
| 40 | F0 | 01 | 20 | | _ | | _ | | | _ | |
| | 85 20 3A 6D 65 65 20 49 6F 4D 65 20 61 20 67 74 20 74 69 42 | 85 81 20 61 3A 20 6D 65 65 20 65 20 20 61 49 54 6F 72 4D 4D 65 2C 20 75 61 6E 20 74 6C 79 74 20 20 62 74 68 69 6E 42 4D | 85 81 E6 20 61 72 3A 20 2D 6D 65 73 65 20 6E 20 61 6E 20 61 6E 49 54 20 6F 72 20 4D 4D 41 65 2C 20 20 75 73 61 6E 20 20 74 72 6C 79 3B 74 20 6D 20 62 65 74 68 65 69 6E 20 42 4D 49 | 85 81 E6 54 20 61 72 65 3A 20 2D 20 6D 65 73 73 65 20 73 65 65 20 6E 65 20 61 6E 20 49 54 20 6D 6F 72 20 61 4D 4D 41 4E 65 2C 20 77 20 75 73 65 61 6E 20 62 20 74 72 61 6C 79 3B 20 74 20 6D 65 20 62 65 20 74 68 65 20 69 6E 20 61 42 4D 49 54 | 85 81 E6 54 77 20 61 72 65 20 3A 20 2D 20 41 6D 65 73 73 61 65 20 6E 65 74 20 61 6E 20 53 49 54 20 6D 65 6F 72 20 61 6E 4D 4D 41 4E 44 65 2C 20 77 68 20 75 73 65 72 61 6E 20 62 65 20 74 72 61 6E 6C 79 3B 20 2D 74 20 6D 65 73 20 62 65 20 73 74 68 65 20 73 | 85 81 E6 54 77 6F 20 61 72 65 20 64 3A 20 2D 20 41 20 6D 65 73 73 61 67 65 20 73 65 6E 74 65 20 6E 65 74 77 20 61 6E 20 53 4D 49 54 20 6D 65 73 6F 72 20 61 6E 20 4D 4D 41 4E 44 20 65 2C 20 77 68 65 20 75 73 65 72 20 61 6E 20 62 65 20 20 74 72 61 6E 73 6C 79 3B 20 < | 85 81 E6 54 77 6F 20 20 61 72 65 20 64 65 3A 20 2D 20 41 20 73 6D 65 73 73 61 67 65 65 20 73 65 6E 74 20 65 20 6E 65 74 77 6F 20 61 6E 20 53 4D 53 49 54 20 6D 65 73 73 6F 72 20 61 6E 20 53 4D 4D 41 4E 44 20 6D 65 2C 20 77 68 65 72 20 75 73 65 72 20 64 61 6E 20 62 65 20 | 85 81 E6 54 77 6F 20 74 20 61 72 65 20 64 65 66 3A 20 2D 20 41 20 73 68 6D 65 73 73 61 67 65 20 65 20 73 65 6E 74 20 74 65 20 6E 65 74 77 6F 72 20 61 6E 20 53 4D 53 2D 49 54 20 6D 65 73 73 61 6F 72 20 61 6E 20 53 4D 4D 4D 41 4E 44 20 6D 65 65 2C 20 77 68 65 72 65 20 75 73 | 85 81 E6 54 77 6F 20 74 79 20 61 72 65 20 64 65 66 69 3A 20 2D 20 41 20 73 68 6F 6D 65 73 73 61 67 65 20 74 65 20 73 65 6E 74 20 74 6F 65 20 6E 65 74 77 6F 72 6B 20 61 6E 20 53 4D 53 2D 53 49 54 20 6D 65 73 73 61 67 6F 72 20 61 6E 20 53 4D 53 4D 4D 41 4E 44 20 6D 65 73 65 2C | 85 81 E6 54 77 6F 20 74 79 70 20 61 72 65 20 64 65 66 69 6E 3A 20 2D 20 41 20 73 68 6F 72 6D 65 73 73 61 67 65 20 74 6F 65 20 73 65 6E 74 20 74 6F 20 65 20 6E 65 74 77 6F 72 6B 20 20 61 6E 20 53 4D 53 2D 53 55 49 54 20 6D 65 73 73 61 67 65 6F 72 20 61 6E 20 53 4D 53 2D 4D 4D 41 | 85 81 E6 54 77 6F 20 74 79 70 65 20 61 72 65 20 64 65 66 69 6E 65 3A 20 2D 20 41 20 73 68 6F 72 74 6D 65 73 73 61 67 65 20 74 6F 20 65 20 73 65 6E 74 20 74 6F 20 74 65 20 6E 65 74 77 6F 72 6B 20 69 20 61 6E 20 53 4D 53 2D 53 55 42 49 54 20 6D 65 73 73 61 67 65 2C 6F 72 20 61 6E 20 |

SMS-PP (SEND SHORT MESSAGE) Message 1.6

Logically:

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI The TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "01"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "01"

TP-PID Short message type 0

TP-DCS

Message coding SMS default alphabet

Message class 0
TP-UDL 1
TP-UD " "

Coding:

| Coding 01 01 02 91 10 40 F0 01 20 |
|-----------------------------------|
|-----------------------------------|

TERMINAL RESPONSE: SEND SHORT MESSAGE 1.6.1

Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE Command qualifier: packing not required

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TL' | /: 8 | 31 | 03 | 01 | 13 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 | l |
|---------|------|----|----|----|----|----|----|----|----|----|----|----|----|---|
|---------|------|----|----|----|----|----|----|----|----|----|----|----|----|---|

Expected Sequence 1.7(SEND SHORT MESSAGE, alpha identifier length '00', packing not required, 8-bit data, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|-------------------------|------------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SEND SHORT | |
| | | MESSAGE 1.7.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SEND | [packing not required, 8-bit data] |
| | | SHORT MESSAGE 1.7.1 | |
| 4 | ME | No information to user | [Alpha identifier length '00'] |
| 5 | $ME \rightarrow SS$ | Send SMS-PP (SEND SHORT | |
| | | MESSAGE) Message 1.7 | |
| 6 | $SS \rightarrow ME$ | SMS RP-ACK | |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND | [Command performed successfully] |
| | | SHORT MESSAGE 1.7.1 | |

PROACTIVE COMMAND: SEND SHORT MESSAGE 1.7.1

Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE packing not required

Device identities

Source device: SIM
Destination device: Network

Alpha identifier:

Address

TON: International number

NPI: "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT
TP-UDHI TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding 8-bit data Message class class 0 TP-UDL 12

TP-UD "Test Message"

Coding:

| BER-TLV: | D0 | 30 | 81 | 03 | 01 | 13 | 00 | 82 | 02 | 81 | 83 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | 86 | 09 | 91 | 11 | 22 | 33 | 44 | 55 | 66 | 77 | F8 |
| | 8B | 18 | 01 | 00 | 09 | 91 | 10 | 32 | 54 | 76 | F8 | 40 |
| | F4 | 0C | 54 | 65 | 73 | 74 | 20 | 4D | 65 | 73 | 73 | 61 |
| | 67 | 65 | | | | | | | | | | |

SMS-PP (SEND SHORT MESSAGE) Message 1.7

Logically:

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI The TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "01"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding 8-bit data
Message class class 0
TP-UDL 12

TP-UD "Test Message"

Coding:

| Coding | 01 | 01 | 09 | 91 | 10 | 32 | 54 | 76 | F8 | 40 | F4 | 0C | |
|--------|----|----|----|----|----|----|----|----|----|----|----|----|---|
| | 54 | 65 | 73 | 74 | 20 | 4D | 65 | 73 | 73 | 61 | 67 | 65 | l |

TERMINAL RESPONSE: SEND SHORT MESSAGE 1.7.1

Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE packing not required

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

| BER-TLV: | 81 | 03 | 01 | 13 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 | l |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|---|
| | | | | | | | | | | | | | |

Expected Sequence 1.8 (SEND SHORT MESSAGE, packing not required, 8-bit data, no alpha identifier, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|------------------------------|------------------------------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: SEND SHORT | |
| | | MESSAGE 1.8.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SEND | [packing not required, 8-bit data] |
| | | SHORT MESSAGE 1.8.1 | |
| 4 | $ME \rightarrow USER$ | May give information to user | [No Alpha Identifier] |
| | | concerning what is happening | |
| 5 | $ME \to SS$ | Send SMS-PP (SEND SHORT | |
| | | MESSAGE) Message 1.8 | |
| 6 | $SS \rightarrow ME$ | SMS RP-ACK | |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND | [Command performed successfully] |
| | | SHORT MESSAGE 1.8.1 | |

PROACTIVE COMMAND: SEND SHORT MESSAGE 1.8.1

Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE packing not required

Device identities

Source device: SIM
Destination device: Network

Address

TON: International number

NPI: "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding 8-bit data Message class class 0 TP-UDL 12

TP-UD "Test Message"

| BER-TLV: | D0 | 2E | 81 | 03 | 01 | 13 | 00 | 82 | 02 | 81 | 83 | 86 | l |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|---|
| | 09 | 91 | 11 | 22 | 33 | 44 | 55 | 66 | 77 | F8 | 8B | 18 | l |
| | 01 | 00 | 09 | 91 | 10 | 32 | 54 | 76 | F8 | 40 | F4 | 0C | l |
| | 54 | 65 | 73 | 74 | 20 | 4D | 65 | 73 | 73 | 61 | 67 | 65 | ı |

SMS-PP (SEND SHORT MESSAGE) Message 1.8

Logically:

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI The TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "01"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding 8-bit data
Message class class 0
TP-UDL 12

TP-UD "Test Message"

Coding:

| Coding | 01 | 01 | 09 | 91 | 10 | 32 | 54 | 76 | F8 | 40 | F4 | 0C |
|--------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 54 | 65 | 73 | 74 | 20 | 4D | 65 | 73 | 73 | 61 | 67 | 65 |

TERMINAL RESPONSE: SEND SHORT MESSAGE 1.8.1

Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE packing not required

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 01 | 03 | Ω1 | 12 | 00 | 92 | 02 | 92 | 01 | 0.2 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|-----|----|----|
| DEK-ILV. | 01 | US | UI | 13 | UU | 02 | 02 | 02 | 01 | ၀၁ | UI | UU |

27.22.4.10.1.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.8.

27.22.4.10.2 SEND SHORT MESSAGE (UCS2 support)

27.22.4.10.2.1 Definition and applicability

See clause 3.2.2.

27.22.4.10.2.2 Conformance requirement

The ME shall support the Proactive SIM: SEND SHORT MESSAGE facility as defined in:

• 3GPP TS 11.14 [15] clause 6.1, clause 6.4.10, clause 6.6.9, clause 12.6, clause 12.7, clause 12.2, clause 12.1, clause 12.13, clause 12.31 and clause 5.2.

Additionally, the ME shall support the UCS2 facility for the coding of the Cyrillic alphabet, as defined in the following technical specifications: ISO/IEC 10646 [17].

27.22.4.10.2.3 Test purpose

To verify that the ME correctly formats and sends a short message to the network (System Simulator) as indicated in the SEND SHORT MESSAGE proactive SIM command, and returns a TERMINAL RESPONSE command to the SIM indicating the status of the transmission of the Short Message.

27.22.4.10.2.4 Method of test

27.22.4.10.2.4.1 Initial conditions

The ME is connected to the SIM Simulator and only connected to the System Simulator if the System Simulator is mentioned in the sequence table. Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.10.2.4.2 Procedure

Expected Sequence 2.1 (SEND SHORT MESSAGE, packing not required, UCS2 (16-bit data))

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|-------------------------|---------------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SEND SHORT | |
| | | MESSAGE 2.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SEND | [packing not required, 16-bit data] |
| | | SHORT MESSAGE 2.1.1 | |
| 4 | $ME \to USER$ | Display "Send SM" | [Alpha Identifier] |
| 5 | ME 	o SS | Send SMS-PP (SEND SHORT | ["ЗДРАВСТВУЙТЕ" = "Hello" in Russian] |
| | | MESSAGE) Message 2.1 | |
| 6 | $SS \to ME$ | SMS RP-ACK | |
| 7 | $ME \to SIM$ | TERMINAL RESPONSE: SEND | [Command performed successfully] |
| | | SHORT MESSAGE 2.1.1 | j- |

PROACTIVE COMMAND: SEND SHORT MESSAGE: 2.1.1

Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE packing not required

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "Send SM"

Address

TON: International number

NPI: "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding 16-bit data Message class class 0 TP-UDL 24

ТР-UD "ЗДРАВСТВУЙТЕ"

Coding:

| BER-TLV: | D0 | 43 | 81 | 03 | 01 | 13 | 00 | 82 | 02 | 81 | 83 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 07 | 53 | 65 | 6E | 64 | 20 | 53 | 4D | 86 | 09 | 91 | 11 |
| | 22 | 33 | 44 | 55 | 66 | 77 | F8 | 8B | 24 | 01 | 00 | 09 |
| | 91 | 10 | 32 | 54 | 76 | F8 | 40 | 08 | 18 | 04 | 17 | 04 |
| | 14 | 04 | 20 | 04 | 10 | 04 | 12 | 04 | 21 | 04 | 22 | 04 |
| | 12 | 04 | 23 | 04 | 19 | 04 | 22 | 04 | 15 | | | |

SMS-PP (SEND SHORT MESSAGE) Message 2.1

Logically:

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "01"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding UCS2 (16-bit data)

Message class 0 TP-UDL 24

ТР-UD "ЗДРАВСТВУЙТЕ"

Coding:

| Coding | 01 | 01 | 09 | 91 | 10 | 32 | 54 | 76 | F8 | 40 | 80 | 18 |
|--------|----|----|----|----|----|----|----|----|----|----|----|----|
| _ | 04 | 17 | 04 | 14 | 04 | 20 | 04 | 10 | 04 | 12 | 04 | 21 |
| | 04 | 22 | 04 | 12 | 04 | 23 | 04 | 19 | 04 | 22 | 04 | 15 |

TERMINAL RESPONSE: SEND SHORT MESSAGE 2.1.1

Logically:

Command details

Command number:

Command type: SEND SHORT MESSAGE

Command qualifier: packing not required

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 13 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|

27.22.4.10.2.5 Test requirement

The ME shall operate in the manner defined in expected sequence 2.1.

27.22.4.10.3 SEND SHORT MESSAGE (icon support)

27.22.4.10.3.1 Definition and applicability

See clause 3.2.2.

27.22.4.10.3.2 Conformance requirement

27.22.4.10.3.3 Test purpose

To verify that the ME correctly formats and sends a short message to the network (System Simulator) as indicated in the SEND SHORT MESSAGE proactive SIM command, and returns a TERMINAL RESPONSE command to the SIM indicating the status of the transmission of the Short Message.

27.22.4.10.3.4 Method of test

27.22.4.10.3.4.1 Initial conditions

The ME is connected to the SIM Simulator and only connected to the System Simulator if the System Simulator is mentioned in the sequence table. The elementary files are coded as Toolkit default.

The ME screen shall be in its normal stand-by display.

27.22.4.10.3.4.2 Procedure

Expected Sequence 3.1A (SEND SHORT MESSAGE, basic icon self-explanatory, packing not required, 8-bit data, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-------------------------------|------------------------------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: SEND SHORT | |
| | | MESSAGE 3.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SEND | [packing not required, 8-bit data] |
| | | SHORT MESSAGE 3.1.1 | |
| 4 | $ME \rightarrow USER$ | Displays the icon and not the | [basic icon self-explanatory] |
| | | alpha identifier | |
| 5 | $ME \rightarrow SS$ | Send SMS-PP (SEND SHORT | |
| | | MESSAGE) Message 3.1 | |
| 6 | $SS \rightarrow ME$ | SMS RP-ACK | |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND | [Command performed successfully] |
| | | SHORT MESSAGE 3.1.1A | |

PROACTIVE COMMAND: SEND SHORT MESSAGE 3.1.1

Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE packing not required

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "NO ICON"

Address

TON: International number

NPI: "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding 8bit-data Message class 0 TP-UDL 12

TP-UD "Test Message"

Icon Identifier

Icon Qualifier self-explanatory

Icon Identifier 1 (number of record in EF IMG)

Coding:

| BER-TLV: | D0 | 3B | 81 | 03 | 01 | 13 | 00 | 82 | 02 | 81 | 83 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 07 | 4E | 4F | 20 | 49 | 43 | 4F | 4E | 86 | 09 | 91 | 11 |
| | 22 | 33 | 44 | 55 | 66 | 77 | F8 | 8B | 18 | 01 | 00 | 09 |
| | 91 | 10 | 32 | 54 | 76 | F8 | 40 | F4 | 0C | 54 | 65 | 73 |
| | 74 | 20 | 4D | 65 | 73 | 73 | 61 | 67 | 65 | 9E | 02 | 00 |
| | 01 | | | | | | | | | | | |

SMS-PP (SEND SHORT MESSAGE) Message 3.1

Logically:

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "01"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

"012345678" Address value

TP-PID Short message type 0

TP-DCS

8-bit data Message coding Message class class 0 TP-UDL 12

"Test Message" TP-UD

Coding:

| Coding | 01 | 01 | 09 | 91 | 10 | 32 | 54 | 76 | F8 | 40 | F4 | 0C |
|--------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 54 | 65 | 73 | 74 | 20 | 4D | 65 | 73 | 73 | 61 | 67 | 65 |

TERMINAL RESPONSE: SEND SHORT MESSAGE 3.1.1A

Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE

Command qualifier: packing not required

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BEK-ILV: | 81 | 03 | 01 | 13 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | | | | | | | | | | | | |

Expected Sequence 3.1B (SEND SHORT MESSAGE, basic icon self-explanatory, packing not required, 8-bit data, requested icon could not be displayed)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-------------------------------|---|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: SEND SHORT | |
| | | MESSAGE 3.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SEND | [packing not required, 8-bit data, basic icon |
| | | SHORT MESSAGE 3.1.1 | self-explanatory]] |
| 4 | $ME \rightarrow USER$ | Displays the alpha identifier | · |
| | | without the icon | |
| 5 | $ME \to SS$ | Send SMS-PP (SEND SHORT | |
| | | MESSAGE) Message 3.1 | |
| 6 | $SS \to ME$ | SMS RP-ACK | |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND | [Command performed successfully, but |
| | | SHORT MESSAGE 3.1.1B | requested icon could not be displayed] |

TERMINAL RESPONSE: SEND SHORT MESSAGE 3.1.1B

Logically:

Command details

Command number:

SEND SHORT MESSAGE Command type: packing not required

Command qualifier:

Device identities

Source device: ME Destination device:

SIM

Result

General Result: Command performed successfully, but requested icon could not be displayed

Coding:

| BER-TLV: | 81 | 03 | 01 | 13 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 04 | 1 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|---|
|----------|----|----|----|----|----|----|----|----|----|----|----|----|---|

Expected Sequence 3.2A (SEND SHORT MESSAGE, basic icon non-self-explanatory, packing not required, 8-bit data, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--------------------------------|------------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SEND SHORT | |
| | | MESSAGE 3.2.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SEND | [packing not required, 8-bit data] |
| | | SHORT MESSAGE 3.2.1 | |
| 4 | $ME \rightarrow USER$ | display the icon and "Send SM" | [basic icon non-self-explanatory] |
| 5 | $ME \to SS$ | Send SMS-PP (SEND SHORT | |
| | | MESSAGE) Message 3.2 | |
| 6 | $SS \to ME$ | SMS RP-ACK | |
| 7 | $ME \to SIM$ | TERMINAL RESPONSE: SEND | [Command performed successfully] |
| | | SHORT MESSAGE 3.2.1A | |

PROACTIVE COMMAND: SEND SHORT MESSAGE 3.2.1

Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE packing not required

Device identities

Source device: SIM
Destination device: Network
Alpha Identifier "Send SM"

Address

TON: International number

NPI: "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI The TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding 8bit-data
Message class class 0
TP-UDL 12

TP-UD "Test Message"

Icon Identifier

Icon Qualifier non-self-explanatory

Icon Identifier 1 (number of record in EF IMG)

Coding:

| BER-TLV: | D0 | 3B | 81 | 03 | 01 | 13 | 00 | 82 | 02 | 81 | 83 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 07 | 53 | 65 | 6E | 64 | 20 | 53 | 4D | 86 | 09 | 91 | 11 |
| | 22 | 33 | 44 | 55 | 66 | 77 | F8 | 8B | 18 | 01 | 00 | 09 |
| | 91 | 10 | 32 | 54 | 76 | F8 | 40 | F4 | 0C | 54 | 65 | 73 |
| | 74 | 20 | 4D | 65 | 73 | 73 | 61 | 67 | 65 | 1E | 02 | 01 |
| | 01 | | | | | | | | | | | |

SMS-PP (SEND SHORT MESSAGE) Message 3.2

Logically:

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "01"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding 8-bit data
Message class class 0
TP-UDL 12

TP-UD "Test Message"

Coding:

| Coding | 01 | 01 | 09 | 91 | 10 | 32 | 54 | 76 | F8 | 40 | F4 | 0C |
|--------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 54 | 65 | 73 | 74 | 20 | 4D | 65 | 73 | 73 | 61 | 67 | 65 |

TERMINAL RESPONSE: SEND SHORT MESSAGE 3.2.1A

Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE

Command qualifier: packing not required

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

| | | | | | | | 0 | | | - | | |
|----------|------|------------|------|------|------|----|------|----|-----|------|----|------|
| BER-TLV: | Ι Ω1 | ∩ 3 | Ι Λ1 | 1 12 | 00 | 22 | | 82 | Ω1 | 83 | ∩1 | 00 |
| | 1 01 | 1 03 | | 1 13 | 1 00 | 02 | 1 02 | 02 | 101 | 1 00 | | 1 00 |

Expected Sequence 3.2B (SEND SHORT MESSAGE, basic icon non-self-explanatory, packing not required, 8-bit data, requested icon could not be displayed)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|------------------------------------|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SEND SHORT | |
| | | MESSAGE 3.2.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SEND | [packing not required, 8-bit data, basic icon |
| | | SHORT MESSAGE 3.2.1 | non-self-explanatory] |
| 4 | $ME \rightarrow USER$ | display "Send SM" without the icon | |
| 5 | $ME \to SS$ | Send SMS-PP (SEND SHORT | |
| | | MESSAGE) Message 3.2 | |
| 6 | $SS \to ME$ | SMS RP-ACK | |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND | [Command performed successfully, but |
| | | SHORT MESSAGE 3.2.1B | requested icon could not be displayed] |

TERMINAL RESPONSE: SEND SHORT MESSAGE 3.2.1B

Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE packing not required

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be displayed;

Coding:

| E |
|---|
|---|

27.22.4.10.3.5 Test requirement

The ME shall operate in the manner defined in expected sequences 3.1A to 3.2B.

27.22.4.11 SEND SS

27.22.4.11.1 SEND SS (normal)

27.22.4.11.1.1 Definition and applicability

See clause 3.2.2.

27.22.4.11.1.2 Conformance requirement

The ME shall support the Proactive SIM: Send SS facility as defined in:

• 3GPP TS 11.14 [15] clause 6.1, clause 6.4.11, clause 6.6.10, clause 12.12.1, clause 5.2, clause 12.6, clause 12.7, clause 12.2, clause 12.14, clause 12.31 and clause 6.5.4.

27.22.4.11.1.3 Test purpose

To verify that the ME correctly translates and sends the supplementary service request indicated in the SEND SS proactive SIM command to the system Simulator.

To verify that the ME returns a TERMINAL RESPONSE command to the SIM indicating the status of the transmission of the SS and any contents of the SS result as additional data.

27.22.4.11.1.4 Method of test

27.22.4.11.1.4.1 Initial conditions

The ME is connected to the SIM Simulator and only connected to the System Simulator if the System Simulator is mentioned in the sequence table.

The elementary files are coded as SIM Application Toolkit default. Prior to this test the ME shall have been powered on, performed the PROFILE DOWNLOAD procedure and be in updated idle mode on the System Simulator.

27.22.4.11.1.4.2 Procedure

Expected Sequence 1.1A (SEND SS, call forward unconditional, all bearers, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-------------------------|--------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: SEND SS 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SEND | |
| | | SS 1.1.1 | |
| 4 | $ME \rightarrow USER$ | Display "Call Forward" | |
| 5 | $ME \to SS$ | REGISTER 1.1A | |
| 6 | $SS \to ME$ | RELEASE COMPLETE (SS | [Successful] |
| | | RETURN RESULT) 1.1A | |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND | |
| | | SS 1.1.1A | |

Expected Sequence 1.1B (SEND SS, call forward unconditional, all bearers, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-------------------------|--------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SEND SS 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SEND | |
| | | SS 1.1.1 | |
| 4 | $ME \rightarrow USER$ | Display "Call Forward" | |
| 5 | $ME \to SS$ | REGISTER 1.1B | |
| 6 | $SS \to ME$ | RELEASE COMPLETE (SS | [Successful] |
| | | RETURN RESULT) 1.1B | |
| 7 | $ME \to SIM$ | TERMINAL RESPONSE: SEND | |
| | | SS 1.1.1B | |

PROACTIVE COMMAND: SEND SS 1.1.1

Logically:

Command details

Command number: 1

Command type: SEND SS Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "Call Forward"

SS String

TON: International

NPI: "ISDN / telephone numbering plan" SS string: "**21*01234567890123456789*10#"

Coding:

| BER-TLV: | D0 | 29 | 81 | 03 | 01 | 11 | 00 | 82 | 02 | 81 | 83 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0C | 43 | 61 | 6C | 6C | 20 | 46 | 6F | 72 | 77 | 61 | 72 |
| | 64 | 89 | 10 | 91 | AA | 12 | 0A | 21 | 43 | 65 | 87 | 09 |
| | 21 | 43 | 65 | 87 | A9 | 01 | FB | | | | | |

REGISTER 1.1A

Logically (only SS argument):

REGISTER SS ARGUMENT

SS-Code:

- Call Forwarding Unconditional

TeleserviceCode

- All Tele Services

Forwarded To Number

- nature of address ind.: international

numbering plan ind.: ISDN/Telephony (E.164)
 TBCD String: 01234567890123456789

- longFTN-Supported

Coding:

| Coding | 30 | 15 | 04 | 01 | 21 | 83 | 01 | 00 | 84 | 0B | 91 | 10 |
|--------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 32 | 54 | 76 | 98 | 10 | 32 | 54 | 76 | 98 | 89 | 00 | |

REGISTER 1.1B

Logically (only SS argument):

REGISTER SS ARGUMENT

SS-Code:

- Call Forwarding Unconditional

TeleserviceCode

- All Tele Services

ForwardedToNumber

- nature of address ind.: international

numbering plan ind.: ISDN/Telephony (E.164)
 TBCD String: 01234567890123456789

Coding:

| Coding | 30 | 13 | 04 | 01 | 21 | 83 | 01 | 00 | 84 | 0B | 91 | 10 |
|--------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 32 | 54 | 76 | 98 | 10 | 32 | 54 | 76 | 98 | | | |

RELEASE COMPLETE (SS RETURN RESULT) 1.1A

Logically (only from operation code):

REGISTER SS RETURN RESULT

ForwardingInfo

SS-Code

- Call Forwarding Unconditional

Forward Feature List

ForwardingFeature

TeleserviceCode

- All Tele Services

SS-Status

- state ind.: operative

provision ind.: provisionedregistration ind.: registeredactive

Forwarded To Number

- nature of address ind.: international

- numbering plan ind.: ISDN/Telephony (E.164)- TBCD String: 01234567890123456789

Coding:

| Coding | 0A | A0 | 1A | 04 | 01 | 21 | 30 | 15 | 30 | 13 | 83 | 01 |
|--------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | 84 | 01 | 07 | 89 | 0B | 91 | 10 | 32 | 54 | 76 | 98 |
| | 10 | 32 | 54 | 76 | 98 | | | | | | | |

RELEASE COMPLETE (SS RETURN RESULT) 1.1B

Logically (only from operation code):

REGISTER SS RETURN RESULT

Forwarding Info

SS-Code

- Call Forwarding Unconditional

ForwardFeatureList

ForwardingFeature

TeleserviceCode

- All Tele Services

SS-Status

- state ind .: operative

provision ind.: provisionedregistration ind.: registeredactive

Coding:

| Coding | 0A | A0 | 0D | 04 | 01 | 21 | 30 | 80 | 30 | 06 | 83 | 01 |
|--------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | 84 | 01 | 07 | | | | | | | | |

TERMINAL RESPONSE: SEND SS 1.1.1A

Logically:

Command details

Command number: 1

Command type: SEND SS Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully Additional information: Operation Code and SS Parameters

| BER-TLV: | 81 | 03 | 01 | 11 | 00 | 82 | 02 | 82 | 81 | 03 | 1E |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| - | 00 | 0A | A0 | 1A | 04 | 01 | 21 | 30 | 15 | 30 | 13 |
| | 83 | 01 | 00 | 84 | 01 | 07 | 89 | 0B | 91 | 10 | 32 |
| | 54 | 76 | 98 | 10 | 32 | 54 | 76 | 98 | | | |

TERMINAL RESPONSE: SEND SS 1.1.1B

Logically:

Command details

Command number: 1

Command type: SEND SS
Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully Additional information: Operation Code and SS Parameters

Coding:

| BER-TLV: | 81 | 03 | 01 | 11 | 00 | 82 | 02 | 82 | 81 | 03 | 11 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| • | 00 | 0A | A0 | 0D | 04 | 01 | 21 | 30 | 80 | 30 | 06 |
| | 83 | 01 | 00 | 84 | 01 | 07 | | | | | |

Expected Sequence 1.2 (SEND SS, call forward unconditional, all bearers, Return Error)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--|----------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: SEND SS 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SEND SS 1.1.1 | |
| 4 | $ME \rightarrow USER$ | Display "Call Forward" | |
| 5 | $ME \to SS$ | REGISTER 1.1A | |
| | | Or | |
| | | REGISTER 1.1B | |
| 6 | | | [Return Error] |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND SS 1.2.1 | |

RELEASE COMPLETE (SS RETURN ERROR) 1.1

Logically (only from error code):

Error Code: Facility not supported

Coding:

Coding 02 01 15

TERMINAL RESPONSE: SEND SS 1.2.1

Logically:

Command details

Command number: 1

Command type: SEND SS Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: SS Return Error Additional information: Error Code

| BER-TLV: | 81 | 03 | 01 | 11 | 00 | 82 | 02 | 82 | 81 | 03 | 02 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 34 | 15 | | | | | | | | | |

Expected Sequence 1.3 (SEND SS, call forward unconditional, all bearers, Reject)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--|----------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: SEND SS 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SEND SS 1.1.1 | |
| 4 | $ME \rightarrow USER$ | Display "Call Forward" | |
| 5 | $ME \to SS$ | REGISTER 1.1A | |
| | | Or | |
| | | REGISTER 1.1B | |
| 6 | $SS \rightarrow ME$ | RELEASE COMPLETE (SS REJECT) 1.1. | [Reject] |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND SS 1.3.1 | |

RELEASE COMPLETE (SS REJECT) 1.1

Logically (only from problem code):

Problem Code:

- General problem
- Unrecognized component

Coding:

TERMINAL RESPONSE: SEND SS 1.3.1

Logically:

Command details

Command number: 1

Command type: SEND SS Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: SS Return Error

Additional information: No specific cause can be given

| BER-TLV: | 81 | 03 | 01 | 11 | 00 | 82 | 02 | 82 | 81 | 03 | 02 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 34 | OΩ | | | | | | | | | |

Expected Sequence 1.4A (SEND SS, call forward unconditional, all bearers, successful, SS request size limit)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--|--------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: SEND SS 1.4.1 | |
| 2 | $ME \to SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SEND SS 1.4.1 | |
| 4 | $ME \rightarrow USER$ | Display "Call Forward" | |
| 5 | $ME \to SS$ | REGISTER 1.2A | |
| 6 | $SS \to ME$ | RELEASE COMPLETE (SS RETURN RESULT) 1.2A | [Successful] |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND SS 1.4.1A | |

Expected Sequence 1.4B (SEND SS, call forward unconditional, all bearers, successful, SS request size limit)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--|--------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: SEND SS 1.4.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SEND SS 1.4.1 | |
| 4 | $ME \rightarrow USER$ | Display "Call Forward" | |
| 5 | $ME \to SS$ | REGISTER 1.2B | |
| 6 | $SS \rightarrow ME$ | RELEASE COMPLETE (SS RETURN RESULT) 1.2B | [Successful] |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND SS 1.4.1B | |

PROACTIVE COMMAND: SEND SS 1.4.1

Logically:

Command details

Command number: 1

Command type: SEND SS Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "Call Forward"

SS String

TON: International

NPI: "ISDN / telephone numbering plan"

SS string: "**21*0123456789012345678901234567*11#"

Coding:

| BER-TLV: | D0 | 2D | 81 | 03 | 01 | 11 | 00 | 82 | 02 | 81 | 83 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0C | 43 | 61 | 6C | 6C | 20 | 46 | 6F | 72 | 77 | 61 | 72 |
| | 64 | 89 | 14 | 91 | AA | 12 | 0A | 21 | 43 | 65 | 87 | 09 |
| | 21 | 43 | 65 | 87 | 09 | 21 | 43 | 65 | A7 | 11 | FB | |
| | | | | | | | | | | | | |

REGISTER 1.2A

Logically (only SS argument):

REGISTER SS ARGUMENT

RegisterSSArg

SS-Code

Call Forwarding Unconditional

TeleserviceCode

See Note 1

Forwarded To Number

nature of address ind.: international

numbering plan ind.: ISDN/Telephony (E.164)

TBCD String: 0123456789012345678901234567

longFTN-Supported

Coding:

| Coding | 30 | 19 | 04 | 01 | 21 | 83 | 01 | Note 1 | 84 | 0F | 91 | 10 |
|--------|----|----|----|----|----|----|----|--------|----|----|----|----|
| | 32 | 54 | 76 | 98 | 10 | 32 | 54 | 76 | 98 | 10 | 32 | 54 |
| | 76 | 89 | 00 | | | | | | | | | |

Note 1: TeleserviceCode is '11' for "Telephony" or is '10' for "allSpeechTransmissionServices"

REGISTER 1.2B

Logically (only SS argument):

REGISTER SS ARGUMENT

RegisterSSArg

SS-Code

Call Forwarding Unconditional

TeleserviceCode

See Note 1

ForwardedToNumber

nature of address ind.: international

numbering plan ind.: ISDN/Telephony (E.164)

TBCD String: 0123456789012345678901234567

longFTN-Supported

Coding:

| Coding | 30 | 17 | 04 | 01 | 21 | 83 | 01 | Note 1 | 84 | 0F | 91 | 10 |
|--------|----|----|----|----|----|----|----|--------|----|----|----|----|
| | 32 | 54 | 76 | 98 | 10 | 32 | 54 | 76 | 98 | 10 | 32 | 54 |
| | 76 | | | | | | | | | | | |

Note 1: TeleserviceCode is '11' for "Telephony" or is '10' for "allSpeechTransmissionServices"

RELEASE COMPLETE (SS RETURN RESULT) 1.2A

Logically (only from operation code):

REGISTER SS RETURN RESULT

ForwardingInfo

SS-Code

- Call Forwarding Unconditional

Forward Feature List

ForwardingFeature

TeleserviceCode

- See Note 1

SS-Status

- state ind .: operative

- provision ind.: provisioned

- registration ind.: registered

- activation ind .: active

longForwardedToNumber

- nature of address ind.: international

- numbering plan ind.: ISDN/Telephony (E.164)

- TBCD String: 0123456789012345678901234567

| BER-TLV | 0A | A0 | 1E | 04 | 01 | 21 | 30 | 19 | 30 | 17 | 83 | 01 |
|---------|--------|----|----|----|----|----|----|----|----|----|----|----|
| | Note 1 | 84 | 01 | 07 | 89 | 0F | 91 | 10 | 32 | 54 | 76 | 98 |
| | 10 | 32 | 54 | 76 | 98 | 10 | 32 | 54 | 76 | | | |
| | | | | | | | | | | | | |

Note 1: TeleserviceCode is '11' for "Telephony" or is '10' for "allSpeechTransmissionServices"

RELEASE COMPLETE (SS RETURN RESULT) 1.2B

Logically (only from operation code):

REGISTER SS RETURN RESULT

ForwardingInfo

SS-Code

- Call Forwarding Unconditional

ForwardFeatureList

ForwardingFeature

TeleserviceCode

See Note 1

SS-Status

- state ind .: operative

- provision ind.: provisioned

- registration ind.: registered - activation ind.: active

Coding:

| BER-TLV | 0A | A0 | 0D | 04 | 01 | 21 | 30 | 08 | 30 | 06 | 83 | 01 |
|---------|--------|----|----|----|----|----|----|----|----|----|----|----|
| | Note 1 | 84 | 01 | 07 | | | | | | | | |

Note 1: TeleserviceCode is '11' for "Telephony" or is '10' for "allSpeechTransmissionServices"

TERMINAL RESPONSE: SEND SS 1.4.1A

Logically:

Command details

Command number:

Command type: SEND SS Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully Additional information: Operation Code and SS Parameters

| BER-TLV: | 81 | 03 | 01 | 11 | 00 | 82 | 02 | 82 | 81 | 03 | 22 |
|----------|----|----|--------|----|----|----|----|----|----|----|----|
| | 00 | 0A | A0 | 1E | 04 | 01 | 21 | 30 | 19 | 30 | 17 |
| | 83 | 01 | Note 1 | 84 | 01 | 07 | 89 | 0F | 91 | 10 | 32 |
| | 54 | 76 | 98 | 10 | 32 | 54 | 76 | 98 | 10 | 32 | 54 |
| | 76 | | | | | | | | | | |

Note 1: TeleserviceCode is '11' for "Telephony" or is '10' for "allSpeechTransmissionServices"

TERMINAL RESPONSE: SEND SS 1.4.1B

Logically:

Command details

Command number: 1

Command type: SEND SS Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully Additional information: Operation Code and SS Parameters

Coding:

| BER-TLV: | 81 | 03 | 01 | 11 | 00 | 82 | 02 | 82 | 81 | 03 | 11 |
|----------|----|----|--------|----|----|----|----|----|----|----|----|
| | 00 | 0A | A0 | 0D | 04 | 01 | 21 | 30 | 80 | 30 | 06 |
| | 83 | 01 | Note 1 | 84 | 01 | 07 | | | | | |

Note 1: TeleserviceCode is '11' for "Telephony" or is '10' for "allSpeechTransmissionServices"

Expected Sequence 1.5 (SEND SS, interrogate CLIR status, successful, alpha identifier limits)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|---|--------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: SEND SS 1.5.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SEND SS 1.5.1 | |
| 4 | | Display "Even if the Fixed Dialling Number service is enabled, the supplementary service control string included in the SEND SS proactive command shall not be checked against those of the FDN list. Upon receiving this command, the ME shall deci" | |
| 5 | $ME \to SS$ | REGISTER 1.3 | |
| 6 | $SS \rightarrow ME$ | RELEASE COMPLETE (SS RETURN RESULT) 1.3 | [Successful] |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND SS 1.5.1 | |

PROACTIVE COMMAND: SEND SS 1.5.1

Logically:

Command details

Command number: 1

Command type: SEND SS Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "Even if the Fixed Dialling Number service is enabled, the supplementary service

control string included in the SEND SS proactive command shall not be checked against those of the FDN list. Upon receiving this command, the ME shall deci"

SS String

TON: Undefined NPI: Undefined SS string: "*#31#"

Coding:

| BER-TLV: | D0 | 81 | FD | 81 | 03 | 01 | 11 | 00 | 82 | 02 | 81 | 83 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 85 | 81 | EB | 45 | 76 | 65 | 6E | 20 | 69 | 66 | 20 | 74 |
| | 68 | 65 | 20 | 46 | 69 | 78 | 65 | 64 | 20 | 44 | 69 | 61 |
| | 6C | 6C | 69 | 6E | 67 | 20 | 4E | 75 | 6D | 62 | 65 | 72 |
| | 20 | 73 | 65 | 72 | 76 | 69 | 63 | 65 | 20 | 69 | 73 | 20 |
| | 65 | 6E | 61 | 62 | 6C | 65 | 64 | 2C | 20 | 74 | 68 | 65 |
| | 20 | 73 | 75 | 70 | 70 | 6C | 65 | 6D | 65 | 6E | 74 | 61 |
| | 72 | 79 | 20 | 73 | 65 | 72 | 76 | 69 | 63 | 65 | 20 | 63 |
| | 6F | 6E | 74 | 72 | 6F | 6C | 20 | 73 | 74 | 72 | 69 | 6E |
| | 67 | 20 | 69 | 6E | 63 | 6C | 75 | 64 | 65 | 64 | 20 | 69 |
| | 6E | 20 | 74 | 68 | 65 | 20 | 53 | 45 | 4E | 44 | 20 | 53 |
| | 53 | 20 | 70 | 72 | 6F | 61 | 63 | 74 | 69 | 76 | 65 | 20 |
| | 63 | 6F | 6D | 6D | 61 | 6E | 64 | 20 | 73 | 68 | 61 | 6C |
| | 6C | 20 | 6E | 6F | 74 | 20 | 62 | 65 | 20 | 63 | 68 | 65 |
| | 63 | 6B | 65 | 64 | 20 | 61 | 67 | 61 | 69 | 6E | 73 | 74 |
| | 20 | 74 | 68 | 6F | 73 | 65 | 20 | 6F | 66 | 20 | 74 | 68 |
| | 65 | 20 | 46 | 44 | 4E | 20 | 6C | 69 | 73 | 74 | 2E | 20 |
| | 55 | 70 | 6F | 6E | 20 | 72 | 65 | 63 | 65 | 69 | 76 | 69 |
| | 6E | 67 | 20 | 74 | 68 | 69 | 73 | 20 | 63 | 6F | 6D | 6D |
| | 61 | 6E | 64 | 2C | 20 | 74 | 68 | 65 | 20 | 4D | 45 | 20 |
| | 73 | 68 | 61 | 6C | 6C | 20 | 64 | 65 | 63 | 69 | 89 | 04 |
| | FF | BA | 13 | FB | | | | | | | | |
| | | | | | | | | | | | | |

REGISTER 1.3

Logically (only SS argument):

INTERROGATE SS ARGUMENT

SS-Code

- Calling Line Id Restriction

Coding:

| Coding | 30 | 03 | 04 | 01 | 12 |
|--------|----|----|----|----|----|

RELEASE COMPLETE (SS RETURN RESULT) 1.3

Logically (only from operation code):

INTERROGATE SS RESULT

CliRestrictionInfo

SS-Status

- state ind.: operative

provision ind.: provisionedregistration ind.: registeredactivation ind.: not active

CliRestrictionOption

- Temporary Def Allowed

| Coding | 0E A4 | 06 | 04 | 01 | 06 | 0A | 01 | 02 |
|--------|-------|----|----|----|----|----|----|----|
|--------|-------|----|----|----|----|----|----|----|

TERMINAL RESPONSE: SEND SS 1.5.1

Logically:

Command details

Command number:

Command type: SEND SS
Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Additional information

Operation Code: SS Code

Parameters: SS Return Result

Coding:

| BER-TLV: | 81 | 03 | 01 | 11 | 00 | 82 | 02 | 82 | 81 | 03 | 0A |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | 0E | A4 | 06 | 04 | 01 | 06 | 0A | 01 | 02 | |

Expected Sequence 1.6A (SEND SS, call forward unconditional, all bearers, successful, null data alpha identifier)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|--|--------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: SEND SS 1.6.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SEND SS 1.6.1 | |
| 4 | | Should not give any information to the user on the fact that the ME is sending an SS request | |
| 5 | $ME \to SS$ | REGISTER 1.1A | |
| 6 | $SS \to ME$ | RELEASE COMPLETE (SS RETURN RESULT) 1.1A | [Successful] |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND SS 1.1.1A | |

Expected Sequence 1.6B (SEND SS, call forward unconditional, all bearers, successful, null data alpha identifier)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|--|--------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND PENDING: SEND SS | |
| | | 1.6.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SEND SS 1.6.1 | |
| 4 | ME | Should not give any information to the user on the | |
| | | fact that the ME is sending an SS request | |
| 5 | $ME \rightarrow SS$ | REGISTER 1.1B | |
| 6 | $SS \rightarrow ME$ | RELEASE COMPLETE (SS RETURN RESULT) | [Successful] |
| | | 1.1B | |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND SS 1.1.1B | |

PROACTIVE COMMAND: SEND SS 1.6.1

Logically:

Command details

Command number: 1

Command type: SEND SS Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: null data object

SS String

TON: International

NPI: "ISDN / telephone numbering plan" SS string: "**21*01234567890123456789*10#"

Coding:

| BER-TLV: | D0 | 1D | 81 | 03 | 01 | 11 | 00 | 82 | 02 | 81 | 83 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| · | 00 | 89 | 10 | 91 | AA | 12 | 0A | 21 | 43 | 65 | 87 | 09 |
| | 21 | 43 | 65 | 87 | A9 | 01 | FB | | | | | |

27.22.4.11.1.5 Test requirement

The ME shall operate in the manner defined in expected sequence 1.1 to 1.6.

27.22.4.11.2 SEND SS (Icon support)

27.22.4.11.2.1 Definition and applicability

See clause 3.2.2.

27.22.4.11.2.2 Conformance requirement

27.22.4.11.2.3 Test purpose

To verify that the ME displays the text contained in the SEND SS proactive SIM command, and returns a successful result in the TERMINAL RESPONSE command send to the SIM.

In addition to verify that if an icon is provided by the SIM, the icon indicated in the command may be used by the ME to inform the user, in addition to, or instead of the alpha identifier, as indicated with the icon qualifier.

27.22.4.11.2.4 Method of test

27.22.4.11.2.4.1 Initial conditions

The ME is connected to the SIM Simulator and only connected to the System Simulator if the System Simulator is mentioned in the sequence table.

Prior to this test the ME shall have been powered on, performed the PROFILE DOWNLOAD procedure and be in updated idle mode on the System Simulator.

The elementary files are coded as Toolkit default.

27.22.4.11.2.4.2 Procedure

Expected Sequence 2.1A (SEND SS, call forward unconditional, all bearers, successful, basic icon self explanatory, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--|------------------------------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: SEND | |
| | | SS 2.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SEND SS 2.1.1 | [BASIC-ICON, self-explanatory] |
| 4 | $ME \rightarrow USER$ | Display the basic icon without the alpha | |
| | | identifier | |
| 5 | $ME \rightarrow SS$ | REGISTER 1.1A | Option A applies if A.1/33 is |
| | | Or | supported, |
| | | REGISTER 1.1B | Option B applies if A.1/33 is not |
| | | | supported |
| 6 | $SS \rightarrow ME$ | RELEASE COMPLETE (SS RETURN | [Successful] |
| | | RESULT) 1.1A or | Option A applies if A.1/33 is |
| | | RELEASE COMPLETE (SS RETURN | supported, |
| | | RESULT) 1.1B | Option B applies if A.1/33 is not |
| | | | supported |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND SS 2.1.1AA | [Command performed successfully] |
| | | or | Option AA applies if A.1/33 is |
| | | TERMINAL RESPONSE: SEND SS 2.1.1AB | supported, |
| | | | Option AB applies if A.1/33 is not |
| | | | supported |

PROACTIVE COMMAND: SEND SS 2.1.1

Logically:

Command details

Command number: 1

Command type: SEND SS Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Network

Alpha identifier: "Basic Icon"

SS String

TON: International

NPI: "ISDN / telephone numbering plan" SS string: "**21*01234567890123456789*10#"

Icon Identifier:

Icon qualifier: icon is self-explanatory Icon Identifier: record 1 in $EF_{(IMG)}$

Coding:

| BER-TLV: | D0 | 2B | 81 | 03 | 01 | 11 | 00 | 82 | 02 | 81 | 83 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0A | 42 | 61 | 73 | 69 | 63 | 20 | 49 | 63 | 6F | 6E | 89 |
| | 10 | 91 | AA | 12 | 0A | 21 | 43 | 65 | 87 | 09 | 21 | 43 |
| | 65 | 87 | A9 | 01 | FB | 9E | 02 | 00 | 01 | | | |

TERMINAL RESPONSE: SEND SS 2.1.1AA

Logically:

Command details

Command number: 1

Command type: SEND SS Command qualifier: "00" Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully Additional information: Operation Code and SS Parameters

Coding:

| BER-TLV: | 81 | 03 | 01 | 11 | 00 | 82 | 02 | 82 | 81 | 03 | 1E |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | 0A | A0 | 1A | 04 | 01 | 21 | 30 | 15 | 30 | 13 |
| | 83 | 01 | 00 | 84 | 01 | 07 | 89 | 0B | 91 | 10 | 32 |
| | 54 | 76 | 98 | 10 | 32 | 54 | 76 | 98 | | | |

TERMINAL RESPONSE: SEND SS 2.1.1AB

Logically:

Command details

Command number: 1

Command type: SEND SS

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully Additional information: Operation Code and SS Parameters

Coding:

| BER-TLV: | 81 | 03 | 01 | 11 | 00 | 82 | 02 | 82 | 81 | 03 | 11 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | 0A | A0 | 0D | 04 | 01 | 21 | 30 | 08 | 30 | 06 |
| | 83 | 01 | 00 | 84 | 01 | 07 | | | | | |

Expected Sequence 2.1B (SEND SS, call forward unconditional, all bearers, successful, basic icon self explanatory, requested icon could not be displayed)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|----------------------------------|--|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: SEND SS 2.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SEND | [BASIC-ICON, self-explanatory] |
| | | SS 2.1.1 | |
| 4 | $ME \rightarrow USER$ | Display "Basic Icon" without the | |
| | | icon | |
| 5 | $ME \rightarrow SS$ | REGISTER 1.1A | |
| | | Or | |
| | | REGISTER 1.1B | |
| 6 | $SS \rightarrow ME$ | RELEASE COMPLETE (SS | [Successful] |
| | | RETURN RESULT) 1.1A or | Option A applies if A.1/33 is supported, |
| | | RELEASE COMPLETE (SS | Option B applies if A.1/33 is not supported |
| | | RETURN RESULT) 1.1B | |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND | [Command performed successfully, but |
| | | SS 2.1.1BA or | requested icon could not be displayed] |
| | | TERMINAL RESPONSE: SEND | Option BA applies if A.1/33 is supported, |
| | | SS 2.1.1BB | Option BB applies if A.1/33 is not supported |

TERMINAL RESPONSE: SEND SS 2.1.1BA

Logically:

Command details

Command number: 1

Command type: SEND SS
Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be displayed

Additional information: Operation Code and SS Parameters

Coding:

BER-TLV:

| 81 | 03 | 01 | 11 | 00 | 82 | 02 | 82 | 81 | 03 | 1E |
|----|----|----|----|----|----|----|----|----|----|----|
| 04 | 0A | A0 | 1A | 04 | 01 | 21 | 30 | 15 | 30 | 13 |
| 83 | 01 | 00 | 84 | 01 | 07 | 89 | 0B | 91 | 10 | 32 |
| 54 | 76 | 98 | 10 | 32 | 54 | 76 | 98 | | | |

TERMINAL RESPONSE: SEND SS 2.1.1BB

Logically:

Command details

Command number: 1

Command type: SEND SS Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be displayed

Additional information: Operation Code and SS Parameters

Coding:

BER-TLV:

| Ī | 81 | 03 | 01 | 11 | 00 | 82 | 02 | 82 | 81 | 03 | 11 |
|---|----|----|----|----|----|----|----|----|----|----|----|
| ſ | 04 | 0A | A0 | 0D | 04 | 01 | 21 | 30 | 80 | 30 | 06 |
| Γ | 83 | 01 | 00 | 84 | 01 | 07 | | | | | |

Expected Sequence 2.2A (SEND SS, call forward unconditional, all bearers, successful, colour icon self explanatory, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-------------------------------------|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SEND SS 2.2.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SEND | [COLOUR-ICON, self-explanatory] |
| | | SS 2.2.1 | |
| 4 | $ME \rightarrow USER$ | Display the colour icon without the | |
| | | alpha identifier | |
| 5 | $ME \to SS$ | REGISTER 1.1A | |
| | | Or | |
| _ | | REGISTER 1.1B | |
| 6 | $SS \rightarrow ME$ | RELEASE COMPLETE (SS | [Successful] |
| | | RETURN RESULT) 1.1 | Option A applies if A.1/33 is supported, |
| | | | Option B applies if A.1/33 is not supported |
| 7 | $ME \to SIM$ | | [Command performed successfully] |
| | | SS 2.1.1AA or | Option AA applies if A.1/33 is supported, |
| | | TERMINAL RESPONSE: SEND | Option AB applies if A.1/33 is not supported |
| | | SS 2.1.1AB | |

PROACTIVE COMMAND: SEND SS 2.2.1

Logically:

Command details

Command number: 1

Command type: SEND SS Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Network

Alpha identifier: "Colour Icon"

SS String

TON: International

NPI: "ISDN / telephone numbering plan" SS string: "**21*01234567890123456789*10#"

Icon Identifier:

Icon qualifier: icon is self-explanatory Icon Identifier: record 2 in $EF_{(IMG)}$

| BER-TLV: | D0 | 2C | 81 | 03 | 01 | 11 | 00 | 82 | 02 | 81 | 83 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0B | 43 | 6F | 6C | 6F | 75 | 72 | 20 | 49 | 63 | 6F | 6E |
| | 89 | 10 | 91 | AA | 12 | 0A | 21 | 43 | 65 | 87 | 09 | 21 |
| | 43 | 65 | 87 | A9 | 01 | FB | 9E | 02 | 00 | 02 | | |

Expected Sequence 2.2B (SEND SS, call forward unconditional, all bearers, successful, colour icon self explanatory, requested icon could not be displayed)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-----------------------------------|--|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: SEND SS 2.2.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SEND | [COLOUR-ICON, self-explanatory] |
| | | SS 2.2.1 | |
| 4 | $ME \rightarrow USER$ | Display "Colour Icon" without the | |
| | | icon | |
| 5 | $ME \rightarrow SS$ | REGISTER 1.1A | |
| | | Or | |
| | | REGISTER 1.1B | |
| 6 | $SS \rightarrow ME$ | RELEASE COMPLETE (SS | [Successful] |
| | | RETURN RESULT) 1.1A or | Option A applies if A.1/33 is supported, |
| | | RELEASE COMPLETE (SS | Option B applies if A.1/33 is not supported |
| _ | | RETURN RESULT) 1.1B | |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND | [Command performed but requested icon |
| | | SS 2.1.1BA or | could not be displayed] |
| | | TERMINAL RESPONSE: SEND | Option BA applies if A.1/33 is supported, |
| | | SS 2.1.1BB | Option BB applies if A.1/33 is not supported |

Expected Sequence 2.3A (SEND SS, call forward unconditional, all bearers, successful, basic icon non self-explanatory, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|------------------------------------|--|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: SEND SS 2.3.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SEND | [BASIC-ICON, non self-explanatory] |
| | | SS 2.3.1 | |
| 4 | $ME \rightarrow USER$ | Display "Basic Icon" and the basic | |
| | | icon | |
| 5 | $ME \rightarrow SS$ | REGISTER 1.1A | |
| | | Or | |
| | | REGISTER 1.1B | |
| 6 | $SS \to ME$ | RELEASE COMPLETE (SS | [Successful] |
| | | RETURN RESULT) 1.1A or | Option A applies if A.1/33 is supported, |
| | | RELEASE COMPLETE (SS | Option B applies if A.1/33 is not supported |
| | | RETURN RESULT) 1.1B | |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND | [Command performed successfully] |
| | | SS 2.1.1AA or | Option AA applies if A.1/33 is supported, |
| | | TERMINAL RESPONSE: SEND | Option AB applies if A.1/33 is not supported |
| | | SS 2.1.1AB | |

PROACTIVE COMMAND: SEND SS 2.3.1

Logically:

Command details

Command number: 1

Command type: SEND SS Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network

Alpha Identifier

Text: "Basic Icon"

SS String

TON: International

NPI: "ISDN / telephone numbering plan" SS string: "**21*01234567890123456789*10#"

Icon Identifier

Icon qualifier: icon is non self-explanatory

Icon Identifier: record 1 in $EF_{(IMG)}$

Coding:

| BER-TLV: | D0 | 2B | 81 | 03 | 01 | 11 | 00 | 82 | 02 | 81 | 83 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0A | 42 | 61 | 73 | 69 | 63 | 20 | 49 | 63 | 6F | 6E | 89 |
| | 10 | 91 | AA | 12 | 0A | 21 | 43 | 65 | 87 | 09 | 21 | 43 |
| | 65 | 87 | A9 | 01 | FB | 9E | 02 | 01 | 01 | | | |

Expected Sequence 2.3B (SEND SS, call forward unconditional, all bearers, successful, basic icon non self-explanatory)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|----------------------------------|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SEND SS 2.3.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SEND | [BASIC-ICON, non self-explanatory] |
| | | SS 2.3.1 | |
| 4 | $ME \rightarrow USER$ | Display "Basic Icon" without the | |
| | | icon | |
| 5 | $ME \to SS$ | REGISTER 1.1A | |
| | | Or | |
| | | REGISTER 1.1B | |
| 6 | $SS \to ME$ | RELEASE COMPLETE (SS | [Successful] |
| | | RETURN RESULT) 1.1A or | Option A applies if A.1/33 is supported, |
| | | RELEASE COMPLETE (SS | Option B applies if A.1/33 is not supported |
| _ | | RETURN RESULT) 1.1B | |
| 7 | $ME \rightarrow SIM$ | | [Command performed but requested icon |
| | | SS 2.1.1BA or | could not be displayed] |
| | | TERMINAL RESPONSE: SEND | Option BA applies if A.1/33 is supported, |
| | | SS 2.1.1BB | Option BB applies if A.1/33 is not supported |

Expected Sequence 2.4 (SEND SS, call forward unconditional, all bearers, successful, basic icon non self-explanatory, no alpha identifier presented)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|----------------------------------|-------------------------------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: | |
| | | SEND SS 2.4.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SEND SS 2.4.1 | [BASIC-ICON, non self-explanatory] |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND SS 2.4.1 | [Command data not understood by ME] |

PROACTIVE COMMAND: SEND SS 2.4.1

Logically:

Command details

Command number: 1

Command type: SEND SS Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network

SS String

TON: International

NPI: "ISDN / telephone numbering plan" SS string: "**21*01234567890123456789#"

Icon Identifier

Icon qualifier: icon is non self-explanatory

252

Icon Identifier: record 1 in $EF_{(IMG)}$

Coding:

| BER-TLV: | D0 | 1D | 81 | 03 | 01 | 11 | 00 | 82 | 02 | 81 | 83 | 89 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0E | 91 | AA | 12 | 0A | 21 | 43 | 65 | 87 | 09 | 21 | 43 |
| | 65 | 87 | B9 | 9E | 02 | 01 | 01 | | | | | |

TERMINAL RESPONSE: SEND SS 2.4.1

Logically:

Command details

Command number: 1

Command type: SEND SS
Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command data not understood by ME

Coding:

| BER-TLV: | 81 | 03 | 01 | 11 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 32 |
|----------|----------|----|----------|----|----|----------|----|----|----------|----|----------|----|
| D | <u> </u> | 00 | . | | | <u> </u> | V- | U_ | . | | . | |

27.22.4.11.2.5 Test requirement

The ME shall operate in the manner defined in expected sequences 2.1A to 2.4.

27.22.4.11.3 SEND SS (UCS2 support)

27.22.4.11.3.1 Definition and applicability

See clause 3.2.2.

27.22.4.11.3.2 Conformance requirement

The ME shall support the UCS2 facility for the coding of the Cyrillic alphabet, as defined in: ISO/IEC 10646 [17].

27.22.4.11.3.3 Test purpose

To verify that the ME displays the UCS2 text contained in the SEND SS proactive SIM command, and returns a successful result in the TERMINAL RESPONSE command send to the SIM.

27.22.4.11.3.4 Method of test

27.22.4.11.3.4.1 Initial conditions

The ME is connected to the SIM Simulator and only connected to the System Simulator if the System Simulator is mentioned in the sequence table.

The elementary files are coded as SIM Application Toolkit default. Prior to this test the ME shall have been powered on, performed the PROFILE DOWNLOAD procedure and be in updated idle mode on the System Simulator.

27.22.4.11.3.4.2 Procedure

Expected Sequence 3.1 (SEND SS, call forward unconditional, all bearers, successful, UCS2 text)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-------------------------|---|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: SEND SS 3.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SEND | |
| | | SS 3.1.1 | |
| 4 | $ME \rightarrow USER$ | Display "ЗДРАВСТВУЙТЕ" | ["Hello" in Russian] |
| 5 | $ME \to SS$ | REGISTER 1.1A | |
| | | Or | |
| | | REGISTER 1.1B | |
| 6 | $SS \to ME$ | RELEASE COMPLETE (SS | [Successful] |
| | | RETURN RESULT) 1.1A or | Option A applies if A.1/33 is supported, |
| | | RELEASE COMPLETE (SS | Option B applies if A.1/33 is not supported |
| | | RETURN RESULT) 1.1B | |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND | [Command performed successfully] |
| | | SS 1.1.1A or | Option A applies if A.1/33 is supported, |
| | | TERMINAL RESPONSE: SEND | Option B applies if A.1/33 is not supported |
| | | SS 1.1.1B | |

PROACTIVE COMMAND: SEND SS 3.1.1

Logically:

Command details

Command number: 1

Command type: SEND SS Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network

Alpha Identifier

Data coding scheme: UCS2 (16bit) Text: "ЗДРАВСТВУЙТЕ"

SS String

TON: International

NPI: "ISDN / telephone numbering plan" SS string: "**21*01234567890123456789*10#"

Coding:

| BER-TLV: | D0 | 36 | 81 | 03 | 01 | 11 | 00 | 82 | 02 | 81 | 83 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 19 | 80 | 04 | 17 | 04 | 14 | 04 | 20 | 04 | 10 | 04 | 12 |
| | 04 | 21 | 04 | 22 | 04 | 12 | 04 | 23 | 04 | 19 | 04 | 22 |
| | 04 | 15 | 89 | 10 | 91 | AA | 12 | 0A | 21 | 43 | 65 | 87 |
| | 09 | 21 | 43 | 65 | 87 | A9 | 01 | FB | | | | |

27.22.4.11.3.5 Test requirement

The ME shall operate in the manner defined in expected sequence 3.1.

27.22.4.12 SEND USSD

27.22.4.12.1 SEND USSD (normal)

27.22.4.12.1.1 Definition and applicability

See clause 3.2.2.

27.22.4.12.1.2 Conformance requirement

The ME shall support the Proactive SIM: Send USSD facility as defined in:

- 3GPP TS 11.14 [15] clause 6.1, clause 6.4.12, clause 6.6.11, clause 12.12.7, clause 5.2, clause 12.6, clause 12.7, clause 12.2, clause 12.17, clause 12.31 and clause 6.5.4.
- 3GPP TS 03.38 [7] clause 5.

Additionally the ME shall support the UCS2 facility for the coding of the Cyrillic alphabet, as defined in: ISO/IEC 10646 [17].

27.22.4.12.1.3 Test purpose

To verify that the ME correctly translates and sends the unstructured supplementary service request indicated in the SEND USSD proactive SIM command to the system Simulator.

To verify that the ME returns a TERMINAL RESPONSE command to the SIM indicating the status of the transmission of the USSD request and including a USSD result as a text string in the TERMINAL RESPONSE.

27.22.4.12.1.4 Method of test

27.22.4.12.1.4.1 Initial conditions

The ME is connected to the SIM Simulator and only connected to the System Simulator if the System Simulator is mentioned in the sequence table.

The elementary files are coded as SIM Application Toolkit default. Prior to this test the ME shall have been powered on, performed the PROFILE DOWNLOAD procedure and be in updated idle mode on the System Simulator.

27.22.4.12.1.4.2 Procedure

Expected Sequence 1.1 (SEND USSD, 7-bit data, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--------------------------|----------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SEND USSD 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SEND | |
| | | USSD 1.1.1 | |
| 4 | $ME \rightarrow USER$ | Display "7-bit USSD" | |
| 5 | $ME \to SS$ | REGISTER 1.1 | |
| 6 | $SS \to ME$ | RELEASE COMPLETE (SS | ["USSD string received from SS"] |
| | | RETURN RESULT) 1.1 | |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND | |
| | | USSD 1.1.1 | |

PROACTIVE COMMAND: SEND USSD 1.1.1

Logically:

Command details

Command number:

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "7-bit USSD"

USSD String

Data coding scheme: 7-bit default, no message class

USSD string: "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-

1234567890"

Coding:

| BER-TLV: | D0 | 50 | 81 | 03 | 01 | 12 | 00 | 82 | 02 | 81 | 83 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0A | 37 | 2D | 62 | 69 | 74 | 20 | 55 | 53 | 53 | 44 | 8A |
| | 39 | F0 | 41 | E1 | 90 | 58 | 34 | 1E | 91 | 49 | E5 | 92 |
| | D9 | 74 | 3E | A1 | 51 | E9 | 94 | 5A | B5 | 5E | B1 | 59 |
| | 6D | 2B | 2C | 1E | 93 | CB | E6 | 33 | 3A | AD | 5E | В3 |
| | DB | EE | 37 | 3C | 2E | 9F | D3 | EB | F6 | 3B | 3E | AF |
| | 6F | C5 | 64 | 33 | 5A | CD | 76 | C3 | E5 | 60 | | |

REGISTER 1.1

Logically (only USSD argument)

ProcessUnstructuredSS-Request ARGUMENT

USSD-DataCodingScheme:

- 7-bit default, no message class

USSD string:

- "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-1234567890"

Coding:

| Coding | 30 | 3D | 04 | 01 | F0 | 04 | 38 | 41 | E1 | 90 | 58 | 34 |
|--------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 1E | 91 | 49 | E5 | 92 | D9 | 74 | 3E | A1 | 51 | E9 | 94 |
| | 5A | B5 | 5E | B1 | 59 | 6D | 2B | 2C | 1E | 93 | CB | E6 |
| | 33 | 3A | AD | 5E | В3 | DB | EE | 37 | 3C | 2E | 9F | D3 |
| | EB | F6 | 3B | 3E | AF | 6F | C5 | 64 | 33 | 5A | CD | 76 |
| | C3 | E5 | 60 | | | | | | | | | |

RELEASE COMPLETE (SS RETURN RESULT) 1.1

Logically (only from USSD result):

ProcessUnstructuredSS-Request RETURN RESULT

USSD-Data Coding Scheme:

- 7-bit default, no message class

USSD string:

- "USSD string received from SS"

Coding:

| Coding | 30 | 1E | 04 | 01 | F0 | 04 | 19 | D5 | E9 | 94 | 08 | 9A |
|--------|----|----|----|----|----|----|----|----|----|----|----|----|
| | D3 | E5 | 69 | F7 | 19 | 24 | 2F | 8F | CB | 69 | 7B | 99 |
| | 0C | 32 | CB | DF | 6D | D0 | 74 | 0A | | | | |

TERMINAL RESPONSE: SEND USSD 1.1.1

Logically:

Command details

Command number: 1

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text String

Data coding scheme: 7-bit default, no message class String: "USSD string received from SS"

Coding:

| BER-TLV: | 81 | 03 | 01 | 12 | 00 | 82 | 02 | 82 | 81 | 83 | 01 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | 8D | 1A | 00 | D5 | E9 | 94 | 80 | 9A | D3 | E5 |
| | 69 | F7 | 19 | 24 | 2F | 8F | СВ | 69 | 7B | 99 | 0C |
| | 32 | СВ | DF | 6D | D0 | 74 | 0A | | | | |

Expected Sequence 1.2 (SEND USSD, 8-bit data, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--------------------------|----------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SEND USSD 1.2.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SEND | |
| | | USSD 1.2.1 | |
| 4 | $ME \rightarrow USER$ | Display "8-bit USSD" | |
| 5 | $ME \to SS$ | REGISTER 1.2 | |
| 6 | $SS \to ME$ | RELEASE COMPLETE (SS | ["USSD string received from SS"] |
| | | RETURN RESULT) 1.2 | |
| 7 | $ME \to SIM$ | TERMINAL RESPONSE: SEND | |
| | | USSD 1.2.1 | |

PROACTIVE COMMAND: SEND USSD 1.2.1

Logically:

Command details

Command number: 1

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "8-bit USSD"

USSD String

Data coding scheme: Uncompressed, no message class meaning, 8-bit data

USSD string: "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-

1234567890"

Coding:

| BER-TLV: | D0 | 58 | 81 | 03 | 01 | 12 | 00 | 82 | 02 | 81 | 83 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| • | 0A | 38 | 2D | 62 | 69 | 74 | 20 | 55 | 53 | 53 | 44 | 8A |
| | 41 | 44 | 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 | 49 | 4A |
| | 4B | 4C | 4D | 4E | 4F | 50 | 51 | 52 | 53 | 54 | 55 | 56 |
| | 57 | 58 | 59 | 5A | 2D | 61 | 62 | 63 | 64 | 65 | 66 | 67 |
| | 68 | 69 | 6A | 6B | 6C | 6D | 6E | 6F | 70 | 71 | 72 | 73 |
| | 74 | 75 | 76 | 77 | 78 | 79 | 7A | 2D | 31 | 32 | 33 | 34 |
| | 35 | 36 | 37 | 38 | 39 | 30 | | | | | | |

REGISTER 1.2

Logically (only USSD argument):

ProcessUnstructuredSS-Request ARGUMENT

USSD-DataCodingScheme:

- Uncompressed, no message class meaning, 8-bit data

USSD string:

- "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-1234567890"

Coding:

| Coding | 30 | 45 | 04 | 01 | 44 | 04 | 40 | 41 | 42 | 43 | 44 | 45 |
|--------|----|----|----|----|----|----|----|----|----|----|----|----|
| - | 46 | 47 | 48 | 49 | 4A | 4B | 4C | 4D | 4E | 4F | 50 | 51 |
| | 52 | 53 | 54 | 55 | 56 | 57 | 58 | 59 | 5A | 2D | 61 | 62 |
| | 63 | 64 | 65 | 66 | 67 | 68 | 69 | 6A | 6B | 6C | 6D | 6E |
| | 6F | 70 | 71 | 72 | 73 | 74 | 75 | 76 | 77 | 78 | 79 | 7A |
| | 2D | 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 30 | |

RELEASE COMPLETE (SS RETURN RESULT) 1.2

Logically (only from USSD result):

ProcessUnstructuredSS-Request RETURN RESULT

USSD-DataCodingScheme:

- Uncompressed, no message class meaning, 8-bit data

USSD string:

- "USSD string received from SS"

Coding:

| Coding | 30 | 21 | 04 | 01 | 44 | 04 | 1C | 55 | 53 | 53 | 44 | 20 |
|--------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 73 | 74 | 72 | 69 | 6E | 67 | 20 | 72 | 65 | 63 | 65 | 69 |
| | 76 | 65 | 64 | 20 | 66 | 72 | 6F | 6D | 20 | 53 | 53 | |

TERMINAL RESPONSE: SEND USSD 1.2.1

Logically:

Command details

Command number: 1

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text String

Data coding scheme: Uncompressed, no message class meaning, 8-bit data

String: "USSD string received from SS"

| BER-TLV: | 81 | 03 | 01 | 12 | 00 | 82 | 02 | 82 | 81 | 83 | 01 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | 8D | 1D | 04 | 55 | 53 | 53 | 44 | 20 | 73 | 74 |
| | 72 | 69 | 6E | 67 | 20 | 72 | 65 | 63 | 65 | 69 | 76 |
| | 65 | 64 | 20 | 66 | 72 | 6F | 6D | 20 | 53 | 53 | |

Expected Sequence 1.3 (SEND USSD, UCS2 data, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-------------------------------------|----------------------------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: SEND | |
| | | USSD 1.3.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SEND USSD 1.3.1 | |
| 4 | $ME \rightarrow USER$ | Display "UCS2 USSD" | |
| 5 | $ME \to SS$ | REGISTER 1.3 | |
| 6 | $SS \to ME$ | RELEASE COMPLETE (SS RETURN RESULT) | ["USSD string received from SS"] |
| | | 1.3 | - |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND USSD 1.3.1 | |

PROACTIVE COMMAND: SEND USSD 1.3.1

Logically:

Command details

Command number: 1

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "UCS2 USSD"

USSD String

Data coding scheme: Uncompressed, no message class meaning, UCS2 (16 bit)

USSD string: "ЗДРАВСТВУЙТЕ" ("Hello" in Russian)

Coding:

| BER-TLV: | D0 | 2F | 81 | 03 | 01 | 12 | 00 | 82 | 02 | 81 | 83 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 09 | 55 | 43 | 53 | 32 | 20 | 55 | 53 | 53 | 44 | 8A | 19 |
| | 48 | 04 | 17 | 04 | 14 | 04 | 20 | 04 | 10 | 04 | 12 | 04 |
| | 21 | 04 | 22 | 04 | 12 | 04 | 23 | 04 | 19 | 04 | 22 | 04 |
| | 15 | | | | | | | | | | | |

REGISTER 1.3

Logically (only USSD argument):

ProcessUnstructuredSS-Request ARGUMENT

USSD-DataCodingScheme:

- Uncompressed, no message class meaning, UCS2 (16 bit)

USSD string:

- "ЗДРАВСТВУЙТЕ" ("Hello" in Russian)

Coding:

| Coding | 30 | 1D | 04 | 01 | 48 | 04 | 18 | 04 | 17 | 04 | 14 | 04 |
|--------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 20 | 04 | 10 | 04 | 12 | 04 | 21 | 04 | 22 | 04 | 12 | 04 |
| | 23 | 04 | 19 | 04 | 22 | 04 | 15 | | | | | |

RELEASE COMPLETE (SS RETURN RESULT) 1.3

Logically (only from USSD result):

ProcessUnstructuredSS-Request RETURN RESULT

USSD-DataCodingScheme:

- Uncompressed, no message class meaning, UCS2 (16 bit)

USSD string:

- "USSD string received from SS"

Coding:

| Coding | 30 | 3D | 04 | 01 | 48 | 04 | 38 | 00 | 55 | 00 | 53 | 00 |
|--------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 53 | 00 | 44 | 00 | 20 | 00 | 73 | 00 | 74 | 00 | 72 | 00 |
| | 69 | 00 | 6E | 00 | 67 | 00 | 20 | 00 | 72 | 00 | 65 | 00 |
| | 63 | 00 | 65 | 00 | 69 | 00 | 76 | 00 | 65 | 00 | 64 | 00 |
| | 20 | 00 | 66 | 00 | 72 | 00 | 6F | 00 | 6D | 00 | 20 | 00 |
| | 53 | 00 | 53 | | | | | | | | | |

TERMINAL RESPONSE: SEND USSD 1.3.1

Logically:

Command details

Command number: 1

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text String

Data coding scheme: Uncompressed, no message class meaning, UCS2 (16 bit)

String: "USSD string received from SS"

Coding:

| BER-TLV: | 81 | 03 | 01 | 12 | 00 | 82 | 02 | 82 | 81 | 83 | 01 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | 8D | 39 | 08 | 00 | 55 | 00 | 53 | 00 | 53 | 00 |
| | 44 | 00 | 20 | 00 | 73 | 00 | 74 | 00 | 72 | 00 | 69 |
| | 00 | 6E | 00 | 67 | 00 | 20 | 00 | 72 | 00 | 65 | 00 |
| | 63 | 00 | 65 | 00 | 69 | 00 | 76 | 00 | 65 | 00 | 64 |
| | 00 | 20 | 00 | 66 | 00 | 72 | 00 | 6F | 00 | 6D | 00 |
| | 20 | 00 | 53 | 00 | 53 | | | | | | |

Expected Sequence 1.4 (SEND USSD, 7-bit data, unsuccessful (Return Error))

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--|--------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: SEND USSD 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SEND USSD 1.1.1 | |
| 4 | $ME \rightarrow USER$ | Display "7-bit USSD" | |
| 5 | $ME \to SS$ | REGISTER 1.1 | |
| 6 | $SS \to ME$ | RELEASE COMPLETE (SS RETURN ERROR) 1.1 | Return Error |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND USSD 1.4.1 | |

RELEASE COMPLETE (SS RETURN ERROR) 1.1

Logically (only from Return Error code):

ProcessUnstructuredSS-Request RETURN ERROR

Return Error code:

- Unknown alphabet

Coding:

| Coding | 02 | 01 | 47 |
|--------|----|----|----|
| County | 02 | 01 | 71 |

TERMINAL RESPONSE: SEND USSD 1.4.1

Logically:

Command details

Command number:

Command type: SEND USSD

Command qualifier:

"00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: USSD Return Error Additional information: "Unknown alphabet"

Coding:

| BER-TLV: | 81 | 03 | 01 | 12 | 00 | 82 | 02 | 82 | 81 | 83 | 02 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 37 | 47 | | | | | | | | | |

Expected Sequence 1.5 (SEND USSD, 7-bit data, unsuccessful (Reject))

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--|----------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: SEND USSD 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SEND USSD 1.1.1 | |
| 4 | $ME \rightarrow USER$ | Display "7-bit USSD" | |
| 5 | $ME \to SS$ | REGISTER 1.1 | |
| 6 | $SS \to ME$ | RELEASE COMPLETE (SS REJECT) 1.1 | Reject |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND USSD 1.5.1 | |

RELEASE COMPLETE (SS REJECT) 1.1

Logically (only from Problem code):

ProcessUnstructuredSS-Request REJECT

Invoke Problem code:

- Mistyped parameter

Coding:

| Codina | 81 | 01 | 02 |
|--------|----|----|----|

TERMINAL RESPONSE: SEND <u>U</u>SSD 1.5.1

Logically:

Command details

Command number:

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM Result

General Result: USSD Return Error

Additional information: "No specific cause can be given"

Coding:

| BER-TLV: | 81 | 03 | 01 | 12 | 00 | 82 | 02 | 82 | 81 | 83 | 02 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 37 | 00 | | | | | | | | | |

Expected Sequence 1.6 (SEND USSD, 256 octets, 7-bit data, successful, long alpha identifier)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|---|----------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND PENDING: SEND | |
| | | USSD 1.6.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SEND USSD 1.6.1 | |
| 4 | $ME \to USER$ | Display "once a RELEASE COMPLETE | |
| | | message containing the USSD Return Result | |
| | | message not containing an error has been | |
| | | received from the network, the ME shall | |
| | | inform the SIM that the command has" | |
| 5 | $ME \to SS$ | REGISTER 1.1 | |
| 6 | $SS \to ME$ | RELEASE COMPLETE (SS RETURN | ["USSD string received from SS"] |
| | | RESULT) 1.1 | |
| 7 | $ME \to SIM$ | TERMINAL RESPONSE: SEND USSD 1.1.1 | |

PROACTIVE COMMAND: SEND USSD 1.6.1

Logically:

Command details

Command number: 1

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "once a RELEASE COMPLETE message containing the USSD Return Result

message not containing an error has been received from the network, the ME shall

inform the SIM that the command has"

USSD String

Data coding scheme: 7-bit default, no message class

USSD string: "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-

1234567890"

Coding:

| BER-TLV: | D0 | 81 | FD | 81 | 03 | 01 | 12 | 00 | 82 | 02 | 81 | 83 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 85 | 81 | В6 | 6F | 6E | 63 | 65 | 20 | 61 | 20 | 52 | 45 |
| | 4C | 45 | 41 | 53 | 45 | 20 | 43 | 4F | 4D | 50 | 4C | 45 |
| | 54 | 45 | 20 | 6D | 65 | 73 | 73 | 61 | 67 | 65 | 20 | 63 |
| | 6F | 6E | 74 | 61 | 69 | 6E | 69 | 6E | 67 | 20 | 74 | 68 |
| | 65 | 20 | 55 | 53 | 53 | 44 | 20 | 52 | 65 | 74 | 75 | 72 |
| | 6E | 20 | 52 | 65 | 73 | 75 | 6C | 74 | 20 | 6D | 65 | 73 |
| | 73 | 61 | 67 | 65 | 20 | 6E | 6F | 74 | 20 | 63 | 6F | 6E |
| | 74 | 61 | 69 | 6E | 69 | 6E | 67 | 20 | 61 | 6E | 20 | 65 |
| | 72 | 72 | 6F | 72 | 20 | 68 | 61 | 73 | 20 | 62 | 65 | 65 |
| | 6E | 20 | 72 | 65 | 63 | 65 | 69 | 76 | 65 | 64 | 20 | 66 |
| | 72 | 6F | 6D | 20 | 74 | 68 | 65 | 20 | 6E | 65 | 74 | 77 |
| | 6F | 72 | 6B | 2C | 20 | 74 | 68 | 65 | 20 | 4D | 45 | 20 |
| | 73 | 68 | 61 | 6C | 6C | 20 | 69 | 6E | 66 | 6F | 72 | 6D |
| | 20 | 74 | 68 | 65 | 20 | 53 | 49 | 4D | 20 | 74 | 68 | 61 |
| | 74 | 20 | 74 | 68 | 65 | 20 | 63 | 6F | 6D | 6D | 61 | 6E |
| | 64 | 20 | 68 | 61 | 73 | 8A | 39 | F0 | 41 | E1 | 90 | 58 |
| | 34 | 1E | 91 | 49 | E5 | 92 | D9 | 74 | 3E | A1 | 51 | E9 |
| | 94 | 5A | B5 | 5E | B1 | 59 | 6D | 2B | 2C | 1E | 93 | CB |
| | E6 | 33 | 3A | AD | 5E | B3 | DB | EE | 37 | 3C | 2E | 9F |
| | D3 | EB | F6 | 3B | 3E | AF | 6F | C5 | 64 | 33 | 5A | CD |
| | 76 | C3 | E5 | 60 | | | | | | | | |

Expected Sequence 1.7 (SEND USSD, 7-bit data, successful, no alpha identifier)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|---|----------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND PENDING: SEND | |
| | | USSD 1.7.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SEND USSD 1.7.1 | |
| 4 | $ME \rightarrow USER$ | Optionally display an informative message | |
| 5 | $ME \to SS$ | REGISTER 1.1 | |
| 6 | $SS \to ME$ | RELEASE COMPLETE (SS RETURN RESULT) | ["USSD string received from SS"] |
| | | 1.1 | |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND USSD 1.1.1 | |

PROACTIVE COMMAND: SEND USSD 1.7.1

Logically:

Command details

Command number: 1

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network

USSD String

Data coding scheme: 7-bit default, no message class

USSD string: "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-

1234567890"

Coding:

| BER-TLV: | D0 | 44 | 81 | 03 | 01 | 12 | 00 | 82 | 02 | 81 | 83 | 8A |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 39 | F0 | 41 | E1 | 90 | 58 | 34 | 1E | 91 | 49 | E5 | 92 |
| | D9 | 74 | 3E | A1 | 51 | E9 | 94 | 5A | B5 | 5E | B1 | 59 |
| | 6D | 2B | 2C | 1E | 93 | CB | E6 | 33 | 3A | AD | 5E | B3 |
| | DB | EE | 37 | 3C | 2E | 9F | D3 | EB | F6 | 3B | 3E | AF |
| | 6F | C5 | 64 | 33 | 5A | CD | 76 | C3 | E5 | 60 | | |

Expected Sequence 1.8 (SEND USSD, 7-bit data, successful, null length alpha identifier)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--|----------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND PENDING: SEND | |
| | | USSD 1.8.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SEND USSD 1.8.1 | |
| 4 | $ME \rightarrow USER$ | the ME should not give any information to the | |
| | | user on the fact that the ME is sending a USSD | |
| | | request | |
| 5 | $ME \rightarrow SS$ | REGISTER 1.1 | |
| 6 | $SS \to ME$ | RELEASE COMPLETE (SS RETURN RESULT) | ["USSD string received from SS"] |
| | | 1.1 | |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND USSD 1.1.1 | |

PROACTIVE COMMAND: SEND USSD 1.8.1

Logically:

Command details

Command number: 1

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: ""

USSD String

Data coding scheme: 7-bit default, no message class

USSD string: "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-

1234567890"

Coding:

| BER-TLV: | D0 | 46 | 81 | 03 | 01 | 12 | 00 | 82 | 02 | 81 | 83 | 85 |
|------------|----|----|----|----|----|----|----|----|----|----|----|----|
| \ <u>-</u> | 00 | 8A | 39 | F0 | 41 | E1 | 90 | 58 | 34 | 1E | 91 | 49 |
| | E5 | 92 | D9 | 74 | 3E | A1 | 51 | E9 | 94 | 5A | B5 | 5E |
| | B1 | 59 | 6D | 2B | 2C | 1E | 93 | CB | E6 | 33 | 3A | AD |
| | 5E | В3 | DB | EE | 37 | 3C | 2E | 9F | D3 | EB | F6 | 3B |
| | 3E | AF | 6F | C5 | 64 | 33 | 5A | CD | 76 | C3 | E5 | 60 |

27.22.4.12.1.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 - 1.8.

27.22.4.12.2 SEND USSD (Icon support)

27.22.4.12.2.1 Definition and applicability

See clause 3.2.2.

27.22.4.12.2.2 Conformance requirement

27.22.4.12.2.3 Test purpose

To verify that the ME displays the text contained in the SEND USSD proactive SIM command, and returns a successful result in the TERMINAL RESPONSE command send to the SIM.

In addition to verify that if an icon is provided by the SIM, the icon indicated in the command may be used by the ME to inform the user, in addition to, or instead of the alpha identifier, as indicated with the icon qualifier.

27.22.4.12.2.4 Method of test

27.22.4.12.2.4.1 Initial conditions

The ME is connected to the SIM Simulator and only connected to the System Simulator if the System Simulator is mentioned in the sequence table. Prior to this test the ME shall have been powered on, performed the PROFILE DOWNLOAD procedure and be in updated idle mode on the System Simulator

The elementary files are coded as Toolkit default.

27.22.4.12.2.4.2 Procedure

Expected Sequence 2.1A (SEND USSD, 7-bit data, successful, basic icon self explanatory, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|---------------|-------------------------------------|----------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND PENDING: SEND | |
| | | USSD 2.1.1 | |
| 2 | $ME \to SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SEND USSD 2.1.1 | [BASIC-ICON, self-explanatory] |
| 4 | $ME \to USER$ | Display BASIC ICON | |
| 5 | $ME \to SS$ | REGISTER 2.1 | |
| 6 | $SS \to ME$ | RELEASE COMPLETE (SS RETURN | ["USSD string received from SS"] |
| | | RESULT) 2.1 | |
| 7 | $ME \to SIM$ | TERMINAL RESPONSE: SEND USSD 2.1.1A | [Command performed successfully] |

PROACTIVE COMMAND: SEND USSD 2.1.1

Logically:

Command details

Command number: 1

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Network

Alpha identifier: "Basic Icon"

USSD String

Data coding scheme: 7-bit default, no message class

USSD string: "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-

1234567890"

Icon Identifier:

Icon qualifier: icon is self-explanatory Icon Identifier: record 1 in $EF_{(IMG)}$

Coding:

| BER-TLV: | D0 | 54 | 81 | 03 | 01 | 12 | 00 | 82 | 02 | 81 | 83 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| _ | 0A | 42 | 61 | 73 | 69 | 63 | 20 | 49 | 63 | 6F | 6E | 8A |
| | 39 | F0 | 41 | E1 | 90 | 58 | 34 | 1E | 91 | 49 | E5 | 92 |
| | D9 | 74 | 3E | A1 | 51 | E9 | 94 | 5A | B5 | 5E | B1 | 59 |
| | 6D | 2B | 2C | 1E | 93 | CB | E6 | 33 | 3A | AD | 5E | В3 |
| | DB | EE | 37 | 3C | 2E | 9F | D3 | EB | F6 | 3B | 3E | AF |
| | 6F | C5 | 64 | 33 | 5A | CD | 76 | C3 | E5 | 60 | 9E | 02 |
| | 00 | 01 | | | | | | | | | | |

REGISTER 2.1

Logically (only USSD argument)

ProcessUnstructuredSS-Request ARGUMENT

USSD-DataCodingScheme:

- 7-bit default, no message class

USSD string:

- "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-1234567890"

Coding:

| Coding | 30 | 3D | 04 | 01 | F0 | 04 | 38 | 41 | E1 | 90 | 58 | 34 |
|--------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 1E | 91 | 49 | E5 | 92 | D9 | 74 | 3E | A1 | 51 | E9 | 94 |
| | 5A | B5 | 5E | B1 | 59 | 6D | 2B | 2C | 1E | 93 | CB | E6 |
| | 33 | 3A | AD | 5E | B3 | DB | EE | 37 | 3C | 2E | 9F | D3 |
| | EB | F6 | 3B | 3E | AF | 6F | C5 | 64 | 33 | 5A | CD | 76 |
| | C3 | E5 | 60 | | | | | | | | | |

RELEASE COMPLETE (SS RETURN RESULT) 2.1

Logically (only from USSD result):

ProcessUnstructuredSS-Request RETURN RESULT

USSD-DataCodingScheme:

- 7-bit default, no message class

USSD string:

- "USSD string received from SS"

Coding:

| Coding | 30 | 1E | 04 | 01 | F0 | 04 | 19 | D5 | E9 | 94 | 08 | 9A |
|--------|----|----|----|----|----|----|----|----|----|----|----|----|
| | D3 | E5 | 69 | F7 | 19 | 24 | 2F | 8F | CB | 69 | 7B | 99 |
| | 0C | 32 | CB | DF | 6D | D0 | 74 | 0A | | | | |

TERMINAL RESPONSE: SEND USSD 2.1.1A

Logically:

Command details

Command number: 1

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text String

Data coding scheme: 7-bit default, no message class String: "USSD string received from SS"

Coding:

| BER-TLV: | 81 | 03 | 01 | 12 | 00 | 82 | 02 | 82 | 81 | 83 | 01 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | 8D | 1A | 00 | D5 | E9 | 94 | 80 | 9A | D3 | E5 |
| | 69 | F7 | 19 | 24 | 2F | 8F | CB | 69 | 7B | 99 | 0C |
| | 32 | CB | DF | 6D | D0 | 74 | 0A | | | | |

Expected Sequence 2.1B (SEND USSD, 7-bit data, successful, basic icon self explanatory, requested icon could not be displayed)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|----------------------------------|---------------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SEND USSD 2.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SEND | [BASIC-ICON, self-explanatory] |
| | | USSD 2.1.1 | |
| 4 | $ME \rightarrow USER$ | Display "Basic Icon" without the | |
| | | icon | |
| 5 | $ME \to SS$ | REGISTER 2.1 | |
| 6 | $SS \to ME$ | RELEASE COMPLETE (SS | ["USSD string received from SS"] |
| | | RETURN RESULT) 2.1 | |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND | [Command performed but requested icon |
| | | USSD 2.1.1B | could not be displayed] |

TERMINAL RESPONSE: SEND USSD 2.1.1B

Logically:

Command details

Command number: 1

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be displayed

Text String

Data coding scheme: 7-bit default, no message class String: "USSD string received from SS"

| BER-TLV: | 81 | 03 | 01 | 12 | 00 | 82 | 02 | 82 | 81 | 83 | 01 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 04 | 8D | 1A | 00 | D5 | E9 | 94 | 80 | 9A | D3 | E5 |
| | 69 | F7 | 19 | 24 | 2F | 8F | CB | 69 | 7B | 99 | 0C |
| | 32 | СВ | DF | 6D | D0 | 74 | 0A | | | | |

Expected Sequence 2.2 (SEND USSD, 7-bit data, successful, colour icon self explanatory)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|------------------------------|---------------------------------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: SEND USSD 2.2.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SEND | [COLOUR-ICON, self-explanatory] |
| | | USSD 2.2.1 | |
| 4 | $ME \rightarrow USER$ | Display COLOUR-ICON | |
| | | or | |
| | | May give information to user | |
| | | concerning what is happening | |
| 5 | / 00 | REGISTER 2.1 | |
| 6 | $SS \to ME$ | RELEASE COMPLETE (SS | ["USSD string received from SS"] |
| | | RETURN RESULT) 2.1 | |
| 7 | $ME \rightarrow SIM$ | | [Command performed successfully] |
| | | USSD 2.1.1A | or |
| | | | [Command performed but requested icon |
| | | TERMINAL RESPONSE: SEND | could not be displayed] |
| | | USSD 2.1.1B | |

PROACTIVE COMMAND: SEND USSD 2.2.1

Logically:

Command details

Command number: 1

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "Color Icon"

USSD String

Data coding scheme: 7-bit default, no message class

USSD string: "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-

1234567890"

Icon Identifier:

Icon qualifier: icon is self-explanatory Icon Identifier: record 2 in $EF_{(IMG)}$

| BER-TLV: | D0 | 54 | 81 | 03 | 01 | 12 | 00 | 82 | 02 | 81 | 83 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0A | 43 | 6F | 6C | 6F | 72 | 20 | 49 | 63 | 6F | 6E | 8A |
| | 39 | F0 | 41 | E1 | 90 | 58 | 34 | 1E | 91 | 49 | E5 | 92 |
| | D9 | 74 | 3E | A1 | 51 | E9 | 94 | 5A | B5 | 5E | B1 | 59 |
| | 6D | 2B | 2C | 1E | 93 | CB | E6 | 33 | 3A | AD | 5E | В3 |
| | DB | EE | 37 | 3C | 2E | 9F | D3 | EB | F6 | 3B | 3E | AF |
| | 6F | C5 | 64 | 33 | 5A | CD | 76 | C3 | E5 | 60 | 9E | 02 |
| | 00 | 02 | | | | | | | | | | |

Expected Sequence 2.3A (SEND USSD, 7-bit data, successful, basic icon non self-explanatory, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|---------------------------------|------------------------------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: SEND USSD 2.3.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SEND | [BASIC-ICON, non self-explanatory] |
| | | USSD 2.3.1 | |
| 4 | $ME \rightarrow USER$ | Display "Basic Icon" and BASIC- | |
| | | ICON | |
| _ | | DEGLOTED & 4 | |
| 5 | $ME \to SS$ | REGISTER 2.1 | |
| 6 | $SS \rightarrow ME$ | RELEASE COMPLETE (SS | ["USSD string received from SS"] |
| | | RETURN RESULT) 2.1 | |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND | [Command performed successfully] |
| | | USSD 2.1.1A | |

PROACTIVE COMMAND: SEND USSD 2.3.1

Logically:

Command details

Command number: 1

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Network

Alpha identifier: "Basic Icon"

USSD String

Data coding scheme: 7-bit default, no message class

USSD string: "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-

1234567890"

Icon Identifier

Icon qualifier: icon is non self-explanatory

Icon Identifier: record 1 in $EF_{(IMG)}$

| BER-TLV: | D0 | 54 | 81 | 03 | 01 | 12 | 00 | 82 | 02 | 81 | 83 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0A | 42 | 61 | 73 | 69 | 63 | 20 | 49 | 63 | 6F | 6E | 8A |
| | 39 | F0 | 41 | E1 | 90 | 58 | 34 | 1E | 91 | 49 | E5 | 92 |
| | D9 | 74 | 3E | A1 | 51 | E9 | 94 | 5A | B5 | 5E | B1 | 59 |
| | 6D | 2B | 2C | 1E | 93 | CB | E6 | 33 | 3A | AD | 5E | В3 |
| | DB | EE | 37 | 3C | 2E | 9F | D3 | EB | F6 | 3B | 3E | AF |
| | 6F | C5 | 64 | 33 | 5A | CD | 76 | C3 | E5 | 60 | 9E | 02 |
| | 01 | 01 | | | | | | | | | | |

Expected Sequence 2.3B (SEND USSD, 7-bit data, successful, basic icon non self-explanatory, requested icon could not be displayed)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|----------------------------------|---------------------------------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: SEND USSD 2.3.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SEND | [BASIC-ICON, non self-explanatory] |
| | | USSD 2.3.1 | |
| 4 | ME 	o | Display "Basic Icon" without the | |
| | USER | icon | |
| 5 | $ME \rightarrow SS$ | REGISTER 2.1 | |
| 6 | $SS \rightarrow ME$ | RELEASE COMPLETE (SS | ["USSD string received from SS"] |
| | | RETURN RESULT) 2.1 | |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND | [Command performed but requested icon |
| | | USSD 2.1.1B | could not be displayed] |

Expected Sequence 2.4 (SEND USSD, 7-bit data, basic icon non self-explanatory, no alpha identifier presented)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|--------------------------|-------------------------------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: SEND USSD 2.4.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SEND | [BASIC-ICON, non self-explanatory] |
| | | USSD 2.4.1 | · |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND | [Command data not understood by ME] |
| | | USSD 2.4.1 | |

PROACTIVE COMMAND: SEND USSD 2.4.1

Logically:

Command details

Command number: 1

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network

USSD String

Data coding scheme: 7-bit default, no message class

USSD string: "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-

Icon Identifier

Icon qualifier: icon is non self-explanatory

Icon Identifier: record 1 in $EF_{(IMG)}$

| BER-TLV: | D0 | 48 | 81 | 03 | 01 | 12 | 00 | 82 | 02 | 81 | 83 | 8A |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 39 | F0 | 41 | E1 | 90 | 58 | 34 | 1E | 91 | 49 | E5 | 92 |
| | D9 | 74 | 3E | A1 | 51 | E9 | 94 | 5A | B5 | 5E | B1 | 59 |
| | 6D | 2B | 2C | 1E | 93 | CB | E6 | 33 | 3A | AD | 5E | B3 |
| | DB | EE | 37 | 3C | 2E | 9F | D3 | EB | F6 | 3B | 3E | AF |
| | 6F | C5 | 64 | 33 | 5A | CD | 76 | C3 | E5 | 60 | 9E | 02 |
| | 01 | 01 | | | | | | | | | | |

270

TERMINAL RESPONSE: SEND USSD 2.4.1

Logically:

Command details

Command number:

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command data not understood by ME

Coding:

| BER-TLV: | 81 | 03 | 01 | 12 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 32 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | | | | | | | | | | | | |

27.22.4.12.2.5 Test requirement

The ME shall operate in the manner defined in expected sequences 2.1 - 2.4.

27.22.4.12.3 SEND USSD (UCS2 support)

27.22.4.12.3.1 Definition and applicability

See clause 3.2.2.

27.22.4.12.3.2 Conformance requirement

The ME shall support the UCS2 facility for the coding of the Cyrillic alphabet, as defined in:

• ISO/IEC 10646 [17].

27.22.4.12.3.3 Test purpose

To verify that the ME displays the UCS2 text contained in the SEND USSD proactive SIM command, and returns a successful result in the TERMINAL RESPONSE command send to the SIM.

27.22.4.12.3.4 Method of test

27.22.4.12.3.4.1 Initial conditions

The ME is connected to the SIM Simulator and only connected to the System Simulator if the System Simulator is mentioned in the sequence table. The elementary files are coded as SIM Application Toolkit default. Prior to this test the ME shall have been powered on, performed the PROFILE DOWNLOAD procedure and be in updated idle mode on the System Simulator.

27.22.4.12.3.4.2 Procedure

Expected Sequence 3.1 (SEND USSD, 7-bit data, successful, UCS2 text)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|------------------------------------|----------------------------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: SEND | |
| | | USSD 3.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SEND USSD 3.1.1 | |
| 4 | $ME \rightarrow USER$ | Display "ЗДРАВСТВУЙТЕ" | ["Hello" in Russian] |
| 5 | $ME \to SS$ | REGISTER 3.1 | |
| 6 | $SS \to ME$ | RELEASE COMPLETE (SS RETURN | [Successful] |
| | | RESULT) 3.1 | |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND USSD 3.1.1 | [Command performed successfully] |

PROACTIVE COMMAND: SEND USSD 3.1.1

Logically:

Command details

Command number:

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network

Alpha Identifier

Data coding scheme: UCS2 (16bit)

Text: "ЗДРАВСТВУЙТЕ"

USSD String

Data coding scheme: 7-bit default, no message class

USSD String: "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-

Coding:

| BER-TLV: | D0 | 5F | 81 | 03 | 01 | 12 | 00 | 82 | 02 | 81 | 83 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 19 | 80 | 04 | 17 | 04 | 14 | 04 | 20 | 04 | 10 | 04 | 12 |
| | 04 | 21 | 04 | 22 | 04 | 12 | 04 | 23 | 04 | 19 | 04 | 22 |
| | 04 | 15 | 8A | 39 | F0 | 41 | E1 | 90 | 58 | 34 | 1E | 91 |
| | 49 | E5 | 92 | D9 | 74 | 3E | A1 | 51 | E9 | 94 | 5A | B5 |
| | 5E | B1 | 59 | 6D | 2B | 2C | 1E | 93 | CB | E6 | 33 | 3A |
| | AD | 5E | В3 | DB | EE | 37 | 3C | 2E | 9F | D3 | EB | F6 |
| | 3B | 3E | AF | 6F | C5 | 64 | 33 | 5A | CD | 76 | C3 | E5 |
| | 60 | | | | | | | | | | | |

REGISTER 3.1

Logically (only USSD argument)

ProcessUnstructuredSS-Request ARGUMENT

USSD-DataCodingScheme:

- 7-bit default, no message class

USSD String:

- "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-1234567890"

Coding:

| Coding | 30 | 3D | 04 | 01 | F0 | 04 | 38 | 41 | E1 | 90 | 58 | 34 |
|--------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 1E | 91 | 49 | E5 | 92 | D9 | 74 | 3E | A1 | 51 | E9 | 94 |
| | 5A | B5 | 5E | B1 | 59 | 6D | 2B | 2C | 1E | 93 | CB | E6 |
| | 33 | 3A | AD | 5E | B3 | DB | EE | 37 | 3C | 2E | 9F | D3 |
| | EB | F6 | 3B | 3E | AF | 6F | C5 | 64 | 33 | 5A | CD | 76 |
| | C3 | E5 | 60 | | | | | | | | | |

RELEASE COMPLETE (SS RETURN RESULT) 3.1

Logically (only from USSD result):

ProcessUnstructuredSS-Request RETURN RESULT

USSD-DataCodingScheme:

- 7-bit default, no message class

USSD String:

- "USSD string received from SS"

Coding:

| Coding | 30 | 1E | 04 | 01 | F0 | 04 | 19 | D5 | E9 | 94 | 08 | 9A |
|--------|----|----|----|----|----|----|----|----|----|----|----|----|
| | D3 | E5 | 69 | F7 | 19 | 24 | 2F | 8F | CB | 69 | 7B | 99 |
| | 0C | 32 | CB | DF | 6D | D0 | 74 | 0A | | | | |

TERMINAL RESPONSE: SEND USSD 3.1.1

Logically:

Command details

Command number: 1

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text String

Data coding scheme: 7-bit default, no message class String: "USSD string received from SS"

Coding:

| BER-TLV: | 81 | 03 | 01 | 12 | 00 | 82 | 02 | 82 | 81 | 83 | 01 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | 8D | 1A | 00 | D5 | E9 | 94 | 80 | 9A | D3 | E5 |
| | 69 | F7 | 19 | 24 | 2F | 8F | CB | 69 | 7B | 99 | 0C |
| | 32 | СВ | DF | 6D | D0 | 74 | 0A | | | | |

27.22.4.12.3.5 Test requirement

The ME shall operate in the manner defined in expected sequence 3.1.

27.22.4.13 SET UP CALL

27.22.4.13.1 SET UP CALL (normal)

27.22.4.13.1.1 Definition and applicability

See clause 3.2.2.

27.22.4.13.1.2 Conformance requirement

The ME shall support the Proactive SIM: Set Up Call facility as defined in:

• 3GPP TS 11.14 [15] clause 6.1, clause 6.4.13, clause 6.6.12, clause 12.6, clause 12.7, clause 12.12, clause 12.12.3 and clause 5.2.

27.22.4.13.1.3 Test purpose

To verify that the ME accepts the Proactive Command - Set Up Call, displays the alpha identifier to the user, attempts to set up a call to the address and returns the result in the TERMINAL RESPONSE.

27.22.4.13.1.4 Method of test

27.22.4.13.1.4.1 Initial conditions

The ME is connected to both the SIM Simulator and the System Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on, performed the PROFILE DOWNLOAD procedure and be in updated idle mode on the system simulator.

27.22.4.13.1.4.2 Procedure

Expected Sequence 1.1 (SET UP CALL, call confirmed by the user and connected)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|---|---|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: SET | |
| | | UP CALL 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SET UP CALL 1.1.1 | |
| 4 | $ME \rightarrow USER$ | ME displays "Not busy" during user confirmation phase. | |
| 5 | $USER \to ME$ | The user confirms the call set up | [user confirmation] |
| 6 | $ME \rightarrow SS$ | The ME attempts to set up a call to "+012340123456" | |
| 7 | $SS \rightarrow ME$ | The ME receives the CONNECT message from the system simulator. | [The SS also has to handle the START DTMF and STOP DTMF messages sent by the ME in an appropriate way] |
| 8 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP CALL 1.1.1 The ME shall not update EF LND with the | [Command performed successfully] |
| 9 | $USER \to ME$ | called party address. The user ends the call after 10 s. The ME returns to idle mode. | |

PROACTIVE COMMAND: SET UP CALL 1.1.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "Not busy"

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string "012340123456p1p2"

Coding:

| BER-TLV: | D0 | 1E | 81 | 03 | 01 | 10 | 00 | 82 | 02 | 81 | 83 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 80 | 4E | 6F | 74 | 20 | 62 | 75 | 73 | 79 | 86 | 09 | 91 |
| | 10 | 32 | 04 | 21 | 43 | 65 | 1C | 2C | | | | |

TERMINAL RESPONSE: SET UP CALL 1.1.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BEF | :-TLV: | 81 | 03 | 01 | 10 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 | |
|-----|--------|----|----|----|----|----|----|----|----|----|----|----|----|--|
|-----|--------|----|----|----|----|----|----|----|----|----|----|----|----|--|

Expected Sequence 1.2 (SET UP CALL, call rejected by the user)

| Step | Direction | MESSAGE / Action | Comments |
|------|---------------|-----------------------------------|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SET UP CALL 1.1.1 | |
| 2 | $ME \to SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SET UP | |
| | | CALL 1.1.1 | |
| 4 | $ME \to USER$ | ME displays "Not busy" during the | |
| | | user confirmation phase | |
| 5 | $USER \to ME$ | The user rejects the set up call | [user rejects the call] |
| 6 | $ME \to SIM$ | TERMINAL RESPONSE: SET UP | [User did not accept call set-up request] |
| | | CALL 1.2.1 | |
| 7 | $ME \to USER$ | The ME returns in idle mode. | |

TERMINAL RESPONSE: SET UP CALL 1.2.1

Logically:

Command details

Command number:

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: ME

Destination device: SIM

Result

General Result: User did not accept the proactive command

Coding:

| BER-TLV: | 81 | 03 | 01 | 10 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 22 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|

Expected Sequence 1.3 Void

Expected Sequence 1.4 (SET UP CALL, putting all other calls on hold, ME busy)

ME is busy on a call

| Step | Direction | MESSAGE / Action | Comments |
|------|---------------|---|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND PENDING: SET | |
| | | UP CALL 1.4.1 | |
| 2 | $ME \to SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SET UP CALL 1.4.1 | [putting all other calls on hold] |
| 4 | $ME \to USER$ | ME displays "On hold" during the user confirmation phase | |
| 5 | $USER \to ME$ | The user confirms the set up call | [user confirms the call] |
| 6 | $ME \to SS$ | The active call is put on hold | |
| 7 | ME→SS | The ME attempts to set up a call to "+012340123456" | |
| 8 | $SS \to ME$ | The ME receives the CONNECT message from the system simulator. | [The SS also has to handle the START DTMF and STOP DTMF messages sent by the ME in an appropriate way] |
| 9 | $ME \to SIM$ | TERMINAL RESPONSE: SET UP CALL 1.4.1 | [Command performed successfully] |
| 10 | $USER \to ME$ | The user ends the call after 10 s. The ME retrieves the previous call automatically or on request of the user | |

PROACTIVE COMMAND: SET UP CALL 1.4.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: putting all other calls on hold

Device identities

Source device: SIM

Destination device: Network

Alpha identifier: "On hold"

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string "012340123456p1p2"

Coding:

| BER-TLV: | D0 | 1D | 81 | 03 | 01 | 10 | 02 | 82 | 02 | 81 | 83 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 07 | 4F | 6E | 20 | 68 | 6F | 6C | 64 | 86 | 09 | 91 | 10 |
| | 32 | 04 | 21 | 43 | 65 | 1C | 2C | | | | | |

TERMINAL RESPONSE: SET UP CALL 1.4.1

Logically:

Command details

Command number:

Command type: SET UP CALL

Command qualifier: putting all other calls on hold

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 10 | 02 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|-----------|-----|----|----|----|----|----|----|----|-----|----|-----|----|
| DLIX ILV. | 0 1 | 00 | 01 | 10 | 02 | 02 | 02 | 02 | O I | 00 | 0 1 | 00 |

Expected Sequence 1.5 (SET UP CALL, disconnecting all other calls, ME busy)

ME is busy on a call

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--|---|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: SET | |
| | | UP CALL 1.5.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SET UP CALL 1.5.1 | [disconnecting all other calls] |
| 4 | $ME \rightarrow USER$ | ME displays "Disconnect" during the user confirmation phase | |
| 5 | $USER \to ME$ | The user confirms the set up call | [user confirms the call] |
| 6 | $ME \to SS$ | The ME disconnects the active call | |
| 7 | ME→SS | The ME attempts to set up a call to "+012340123456" | |
| 8 | $SS \to ME$ | The ME receives the CONNECT message from the system simulator. | [The SS also has to handle the START DTMF and STOP DTMF messages sent by the ME in an appropriate way] |
| 9 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP CALL 1.5.1 | [Command performed successfully] |
| 10 | $USER \to ME$ | The user ends the call after 10 s. | |

PROACTIVE COMMAND: SET UP CALL 1.5.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: disconnecting all other calls

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "Disconnect"

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string "012340123456p1p2"

| BER-TLV: | D0 | 20 | 81 | 03 | 01 | 10 | 04 | 82 | 02 | 81 | 83 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0A | 44 | 69 | 73 | 63 | 6F | 6E | 6E | 65 | 63 | 74 | 86 |
| | 09 | 91 | 10 | 32 | 04 | 21 | 43 | 65 | 1C | 2C | | |

TERMINAL RESPONSE: SET UP CALL 1.5.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: putting all other calls on hold

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 10 | 04 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|-----------|----|----|-----|----|-----------------|----|----|----|----|----|-----|----|
| DLIX-ILV. | 01 | 03 | O I | 10 | U -1 | 02 | 02 | 02 | 01 | 00 | O I | 00 |

Expected Sequence 1.6 (SET UP CALL, only if not currently busy on another call, ME busy)

ME is busy on a call

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|----------------------------|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SET UP CALL 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SET UP | [only if not currently busy on another call] |
| | | CALL 1.1.1 | |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP | [ME currently unable to process command] |
| | | CALL 1.6.1 | |

TERMINAL RESPONSE: SET UP CALL 1.6.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: ME
Destination device: SIM

Result

General Result: ME currently unable to process command

Additional Information: ME currently busy on call

Coding:

| BER-TLV: | 81 | 03 | 01 | 10 | 00 | 82 | 02 | 82 | 81 | 83 | 02 | 20 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| ' | 02 | | | | | | | | | | | |

Expected Sequence 1.7 (SET UP CALL, putting all other calls on hold, call hold is not allowed)

ME is busy on a call. The system simulator shall be configured to not allow Call Hold.

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|---|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SET UP CALL 1.4.1 | |
| 2 | $ME \to SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SET UP CALL 1.4.1 | [putting all other calls on hold] |
| 4 | $ME \to USER$ | ME displays "On hold" during the user confirmation phase | |
| 5 | $USER \to ME$ | The user confirms the set up call | [user confirms the call] |
| 6 | $ME \to SS$ | The ME attempts to put the active call on hold | |
| 7 | SS->ME | The ME receives the HOLD REJECT message from the system simulator | [SS sends "Facility Rejected" as cause value] |
| 8 | $ME \rightarrow SIM$ | CALL 1.7.1A OR | [Network currently unable to process command] |
| | | TERMINAL RESPONSE: SET UP CALL 1.7.1B | |

TERMINAL RESPONSE: SET UP CALL 1.7.1A

Logically:

Command details

Command number:

Command type: SET UP CALL

Command qualifier: putting all other calls on hold

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Network currently unable to process command

Additional Information: No specific cause can be given

Coding:

| BER-TLV: | 81 | 03 | 01 | 10 | 02 | 82 | 02 | 82 | 81 | 83 | 02 | 21 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | | | | | | | | | | | |

TERMINAL RESPONSE: SET UP CALL 1.7.1B

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: putting all other calls on hold

Device identities

Source device: ME Destination device: SIM

Result

General Result: Network currently unable to process command

Additional Information: Facility Rejected

| BER-TLV: | 81 | 03 | 01 | 10 | 02 | 82 | 02 | 82 | 81 | 83 | 02 | 21 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| • | 9D | | | | | | | | | | | |

Expected Sequence 1.8 (SET UP CALL, Capability configuration)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|-------------------------------------|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SET UP CALL 1.8.1 | |
| 2 | $ME \to SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SET UP | [Capability configuration parameters: full rate |
| | | CALL 1.8.1 | support] |
| 4 | $ME \to USER$ | ME displays "Capability config" | |
| | | during the user confirmation phase | |
| 5 | $USER \to ME$ | The user confirms the set up call | [user confirmation] |
| 6 | $ME \to SS$ | The ME attempts to set up a call to | |
| | | "+012340123456" using the | |
| | | capability configuration parameters | |
| | | supplied by SIM | |
| 7 | $SS \to ME$ | The ME receives the CONNECT | [The SS also has to handle the START DTMF |
| | | message from the system | and STOP DTMF messages sent by the ME |
| | | simulator. | in an appropriate way] |
| 8 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP | [Command performed successfully] |
| | LIGED ME | CALL 1.8.1 | |
| 9 | $USER \to ME$ | The user ends the call after 10 s. | |
| | | The ME returns in idle mode. | |

PROACTIVE COMMAND: SET UP CALL 1.8.1

Logically:

Command details

Command number:

Command type: SET UP CALL

Command qualifier: if not busy on another call

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "Capability config"

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string "012340123456p1p2"

Capability configuration parameters

Information transfer cap: full rate support only MS

Coding:

| BER-TLV: | D0 | 2B | 81 | 03 | 01 | 10 | 00 | 82 | 02 | 81 | 83 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 11 | 43 | 61 | 70 | 61 | 62 | 69 | 6C | 69 | 74 | 79 | 20 |
| | 63 | 6F | 6E | 66 | 69 | 67 | 86 | 09 | 91 | 10 | 32 | 04 |
| | 21 | 43 | 65 | 1C | 2C | 87 | 02 | 01 | Α0 | | | |

TERMINAL RESPONSE: SET UP CALL 1.8.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: if not busy on another call

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 10 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|

Expected Sequence 1.9 (SET UP CALL, max dialling number string, no alpha identifier)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-------------------------------------|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SET UP CALL 1.9.1 | |
| 2 | $ME \to SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND SET UP | [dialling number string, no alpha identifier] |
| | | CALL 1.9.1 | |
| 4 | $USER \to ME$ | The user confirms the set up call | [user confirmation] |
| 5 | $ME \rightarrow SS$ | The ME attempts to set up a call to | |
| | | "012345678901234567890123456 | |
| | | 78901" | |
| 6 | $SS \to ME$ | The ME receives the CONNECT | |
| | | message from the system | |
| | | simulator. | |
| 7 | $ME \to SIM$ | | [Command performed successfully] |
| | | CALL 1.9.1 | |
| 8 | USER \rightarrow ME | The user ends the call | |
| | | The ME returns in idle mode. | |

PROACTIVE COMMAND: SET UP CALL 1.9.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call with redial

Device identities

Source device: SIM
Destination device: Network

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string: "01234567890123456789012345678901"

Coding:

| BER-TLV: | D0 | 1C | 81 | 03 | 01 | 10 | 01 | 82 | 02 | 81 | 83 | 86 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 11 | 91 | 10 | 32 | 54 | 76 | 98 | 10 | 32 | 54 | 76 | 98 |
| | 10 | 32 | 54 | 76 | 98 | 10 | | | | | | |

Note: The maximum BCD number length is limited as dependencies of the lower-layer type of access, e.g. PCS

1900, GSM 900, GSM 850, UMTS FDD shall be taken into account.

TERMINAL RESPONSE: SET UP CALL 1.9.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call with redial

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 10 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 00 | l |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|---|
|----------|----|----|----|----|----|----|----|----|----|----|----|----|---|

Expected Sequence 1.10 (SET UP CALL,256 octets length, long first alpha identifier)

| Step | Direction | MESSAGE / Action | Comments |
|----------|-----------------------|---|----------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND PENDING: SET UP | |
| | | CALL 1.10.1 | |
| 2 | $ME \to SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SET UP CALL | [alpha identifier] |
| | | 1.10.1 | |
| 4 | $ME \to USER$ | ME displays "Three types are defined: - set up | |
| | | a call, but only if not currently busy on another | |
| | | call; - set up a call, putting all other calls (if any) | |
| | | on hold; - set up a call, disconnecting all other | |
| | | calls (if any) first. For each of these types, " | |
| 5 | HOED ME | during the user confirmation phase. | [uaar aanfirmatian] |
| _ | | • | [user confirmation] |
| 6 | ME→SS | The ME attempts to set up a call to "+01" | |
| 7 | $SS \to ME$ | The ME receives the CONNECT message from | |
| | | the system simulator. | ro |
| 8 | | TERMINAL RESPONSE: SET UP CALL 1.10.1 | [Command performed successfully] |
| 9 | USER \rightarrow ME | The user ends the call | |
| <u> </u> | | The ME returns in idle mode. | |

PROACTIVE COMMAND: SET UP CALL 1.10.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call with redial

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "Three types are defined: - set up a call, but only if not currently busy on another

call; - set up a call, putting all other calls (if any) on hold; - set up a call, disconnecting all other calls (if any) first. For each of these types, "

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string: "01"

| DED TIV | DO | 0.4 | ГD | 0.4 | 00 | 04 | 40 | 04 | 00 | 00 | 04 | 00 |
|----------|----|-----|----|-----|----|----|----|----|----|----|----|----|
| BER-TLV: | D0 | 81 | FD | 81 | 03 | 01 | 10 | 01 | 82 | 02 | 81 | 83 |
| | 85 | 81 | ED | 54 | 68 | 72 | 65 | 65 | 20 | 74 | 79 | 70 |
| | 65 | 73 | 20 | 61 | 72 | 65 | 20 | 64 | 65 | 66 | 69 | 6E |
| | 65 | 64 | 3A | 20 | 2D | 20 | 73 | 65 | 74 | 20 | 75 | 70 |
| | 20 | 61 | 20 | 63 | 61 | 6C | 6C | 2C | 20 | 62 | 75 | 74 |
| | 20 | 6F | 6E | 6C | 79 | 20 | 69 | 66 | 20 | 6E | 6F | 74 |
| | 20 | 63 | 75 | 72 | 72 | 65 | 6E | 74 | 6C | 79 | 20 | 62 |
| | 75 | 73 | 79 | 20 | 6F | 6E | 20 | 61 | 6E | 6F | 74 | 68 |
| | 65 | 72 | 20 | 63 | 61 | 6C | 6C | 3B | 20 | 2D | 20 | 73 |
| | 65 | 74 | 20 | 75 | 70 | 20 | 61 | 20 | 63 | 61 | 6C | 6C |
| | 2C | 20 | 70 | 75 | 74 | 74 | 69 | 6E | 67 | 20 | 61 | 6C |
| | 6C | 20 | 6F | 74 | 68 | 65 | 72 | 20 | 63 | 61 | 6C | 6C |
| | 73 | 20 | 28 | 69 | 66 | 20 | 61 | 6E | 79 | 29 | 20 | 6F |
| | 6E | 20 | 68 | 6F | 6C | 64 | 3B | 20 | 2D | 20 | 73 | 65 |
| | 74 | 20 | 75 | 70 | 20 | 61 | 20 | 63 | 61 | 6C | 6C | 2C |
| | 20 | 64 | 69 | 73 | 63 | 6F | 6E | 6E | 65 | 63 | 74 | 69 |
| | 6E | 67 | 20 | 61 | 6C | 6C | 20 | 6F | 74 | 68 | 65 | 72 |
| | 20 | 63 | 61 | 6C | 6C | 73 | 20 | 28 | 69 | 66 | 20 | 61 |
| | 6E | 79 | 29 | 20 | 66 | 69 | 72 | 73 | 74 | 2E | 20 | 46 |
| | 6F | 72 | 20 | 65 | 61 | 63 | 68 | 20 | 6F | 66 | 20 | 74 |
| | 68 | 65 | 73 | 65 | 20 | 74 | 79 | 70 | 65 | 73 | 2C | 20 |
| | 86 | 02 | 91 | 10 | | | | | | | | |

TERMINAL RESPONSE: SET UP CALL 1.10.1

Logically:

Command details

Command number:

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call with redial

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

| BFR-TI V | . 81 | 03 | 01 | 10 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|------|----|----|----|----|----|----|----|----|----|----|----|

Expected Sequence 1.11A (SET UP CALL, Called party subaddress, command performed successfully)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-------------------------------------|--|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: SET UP CALL 1.11.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SET UP | [set up a call with called party subaddress] |
| | | CALL 1.11.1 | |
| 4 | $ME \rightarrow USER$ | ME displays "Called party" during | |
| | | the user confirmation phase | |
| 5 | $USER \to ME$ | • | [user confirmation] |
| 6 | $ME \rightarrow SS$ | The ME attempts to set up a call to | |
| | | "+012340123456" with the called | |
| _ | | party subaddress information | |
| 7 | $SS \rightarrow ME$ | The ME receives the CONNECT | [The SS also has to handle the START DTMF |
| | | message from the system | and STOP DTMF messages sent by the ME |
| 8 | ME OIM | simulator. | in an appropriate way] |
| 0 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP | [Command performed successfully] |
| 9 | LICED ME | The user ends the call after 10 s. | |
| 9 | USEK → ME | The ME returns in idle mode. | |
| | | THE ME TELUITIS III IUIE IIIUUE. | |

Expected Sequence 1.11B (SET UP CALL, Called party subaddress, ME not supporting the called party subaddress)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|-----------------------------|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SET UP CALL 1.11.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SET UP | [set up a call with called party subaddress] |
| | | CALL 1.11.1 | |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP | [beyond ME's capabilities] |
| | | CALL 1.11.1B | |

PROACTIVE COMMAND: SET UP CALL 1.11.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: if not busy on another call

Device identities

Source device: SIM

Destination device: Network

Alpha identifier: "Called party"

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string: "012340123456p1p2"

Called party subaddress

Type of subaddress: NSAP (X.213 / ISO 8348 AD2) Odd / even indicator: even number of address signals Subaddress information: AFI, 95, 95, 95, 95, 95

| BER-TLV: | D0 | 2B | 81 | 03 | 01 | 10 | 00 | 82 | 02 | 81 | 83 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| • | 0C | 43 | 61 | 6C | 6C | 65 | 64 | 20 | 70 | 61 | 72 | 74 |
| | 79 | 86 | 09 | 91 | 10 | 32 | 04 | 21 | 43 | 65 | 1C | 2C |
| | 88 | 07 | 80 | 50 | 95 | 95 | 95 | 95 | 95 | | | |

TERMINAL RESPONSE: SET UP CALL 1.11.1A

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: if not busy on another call

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 10 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|------|----|----|----|----|-----|------------|----|----------|----|----------|----|
| D_:: v . | , o. | 00 | 0. | | 00 | - C | ~ <u>~</u> | | . | 00 | . | |

TERMINAL RESPONSE: SET UP CALL 1.11.1B

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: if not busy on another call

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Beyond ME's capabilities

Coding:

| BER-TLV: | 81 | 03 | 01 | 10 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 30 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|

Expected Sequence 1.12 (SET UP CALL, maximum duration for the redial mechanism)

The system simulator shall be configured such that call set up requests will be rejected with cause "User Busy".

| Step | Direction | MESSAGE / Action | Comments |
|------|---------------|-----------------------------------|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SET UP CALL 1.12.1 | |
| 2 | $ME \to SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SET UP | [only if not currently busy on another call with |
| | | CALL 1.12.1 | redial] |
| 4 | $ME \to USER$ | ME displays "Duration" during the | |
| | | user confirmation phase | |
| 5 | $USER \to ME$ | The user confirms the set up call | [user confirms the call] |
| 6 | $ME \to SS$ | ME attempts to set up a call to | [redial mechanism with maximum duration of |
| | | "+012340123456" . It stops its | 10 seconds]] |
| | | attempts after 10 seconds. | |
| 7 | $ME \to SIM$ | TERMINAL RESPONSE: SET UP | [network currently unable to process |
| | | CALL 1.12.1 | command] |
| 8 | $ME \to USER$ | The ME returns in idle mode. | |

PROACTIVE COMMAND: SET UP CALL 1.12.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call with redial

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "Duration"

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string: "012340123456p1p2"

Duration

Unit: Seconds Interval: 10

Coding:

| BER-TLV: | D0 | 22 | 81 | 03 | 01 | 10 | 01 | 82 | 02 | 81 | 83 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 80 | 44 | 75 | 72 | 61 | 74 | 69 | 6F | 6E | 86 | 09 | 91 |
| | 10 | 32 | 04 | 21 | 43 | 65 | 1C | 2C | 84 | 02 | 01 | 0A |

TERMINAL RESPONSE: SET UP CALL 1.12.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call with redial

Device identities

Source device: ME Destination device: SIM

Result

General Result: network currently unable to process command

Additional Information: User Busy

Coding:

| BER-TLV: | 81 | 03 | 01 | 10 | 01 | 82 | 02 | 82 | 81 | 83 | 02 | 21 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 91 | | | | | | | | | | | |

27.22.4.13.1.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.12.

27.22.4.13.2 SET UP CALL (second alpha identifier)

27.22.4.13.2.1 Definition and applicability

See clause 3.2.2.

27.22.4.13.2.2 Conformance requirement

Same as clause 27.22.4.13.2.1.

27.22.4.13.2.3 Test purpose

To verify that the ME accepts a Proactive Command - Set Up Call, displays the alpha identifiers to the user, attempts to set up a call to the address and returns the result in the TERMINAL RESPONSE.

27.22.4.13.2.4 Method of test

27.22.4.13.2.4.1 Initial conditions

The ME is connected to both the SIM Simulator and the System Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on, performed the PROFILE DOWNLOAD procedure and is in updated idle mode on the system simulator.

27.22.4.13.2.4.2 Procedure

Expected Sequence 2.1 (SET UP CALL, two alpha identifiers)

| Step | Direction | MESSAGE / Action | Comments | | | | |
|------|-----------------------|--|--------------------------------------|--|--|--|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND PENDING: | | | | | |
| | | SET UP CALL 2.1.1 | | | | | |
| 2 | $ME \rightarrow SIM$ | FETCH | | | | | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SET UP | | | | | |
| | | CALL 2.1.1 | | | | | |
| 4 | $ME \rightarrow USER$ | ME displays "CONFIRMATION" during | | | | | |
| | | the user confirmation phase | | | | | |
| 5 | $USER \to ME$ | The user confirms the set up call | [user confirmation] | | | | |
| 6 | $ME \rightarrow SS$ | The ME attempts to set up a call to | [second alpha identifier] | | | | |
| | | "+012340123456". | | | | | |
| | | The ME displays "CALL" if the ME | | | | | |
| | | supports 2 nd alpha identifier or otherwise | | | | | |
| | | the ME may display "CONFIRMATION" | | | | | |
| 7 | $SS \to ME$ | The ME receives the CONNECT | [The SS also has to handle the START | | | | |
| | | message from the system simulator. | DTMF and STOP DTMF messages sent | | | | |
| | | | by the ME in an appropriate way] | | | | |
| 8 | $ME \rightarrow SIM$ | | [Command performed successfully] | | | | |
| | | 2.1.1 | | | | | |
| | | The ME shall not update EF LND with | | | | | |
| | | the called party address. | | | | | |
| 9 | USER \rightarrow ME | The user ends the call after 10 s. | | | | | |
| | | The ME returns in idle mode. | | | | | |

PROACTIVE COMMAND: SET UP CALL 2.1.1

Logically:

Command details

Command number:

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "CONFIRMATION"

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string "012340123456p1p2"

Alpha Identifier (call set up phase): "CALL"

| BER-TLV: | D0 | 28 | 81 | 03 | 01 | 10 | 00 | 82 | 02 | 81 | 83 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0C | 43 | 4F | 4E | 46 | 49 | 52 | 4D | 41 | 54 | 49 | 4F |
| | 4E | 86 | 09 | 91 | 10 | 32 | 04 | 21 | 43 | 65 | 1C | 2C |
| | 85 | 04 | 43 | 41 | 4C | 4C | | | | | | |

TERMINAL RESPONSE: SET UP CALL 2.1.1

Logically:

Command details

Command number:

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: 81 | 1 03 | 01 | 10 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 | I |
|-------------|------|----|----|----|----|----|----|----|----|----|----|---|
|-------------|------|----|----|----|----|----|----|----|----|----|----|---|

27.22.4.13.2.5 Test requirement

The ME shall operate in the manner defined in expected sequence 2.1.

27.22.4.13.3 SET UP CALL (display of icons)

27.22.4.13.3.1 Definition and applicability

See clause 3.2.2.

27.22.4.13.3.2 Conformance requirement

27.22.4.13.3.3 Test purpose

To verify that the ME accepts a Proactive Set Up Call, displays the message or icon to the user, attempts to set up a call to the address, returns the result in the TERMINAL response.

27.22.4.13.3.4 Method of test

27.22.4.13.3.4.1 Initial conditions

The ME is connected to both the SIM Simulator and the System Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on, performed the PROFILE DOWNLOAD procedure and is in updated idle mode on the system simulator.

27.22.4.13.3.4.2 Procedure

Expected Sequence 3.1A (SET UP CALL, display of basic icon during confirmation phase, not self-explanatory, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|---|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SET UP CALL 3.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SET UP CALL 3.1.1 | Including icon identifier, icon shall be displayed in addition of the first alpha identifier |
| 4 | ME → USER | ME displays "Set up call Icon 3.1.1" and the basic icon during a user confirmation phase. | |
| 5 | $USER \to ME$ | The user confirms the set up call | [user confirmation] |
| 6 | ME→SS | The ME attempts to set up a call to "+012340123456" | |
| 7 | $SS \to ME$ | message from the system | [The SS also has to handle the START DTMF and STOP DTMF messages sent by the ME in an appropriate way] |
| 8 | $ME \to SIM$ | | [Command performed successfully] |
| 9 | $USER \to ME$ | The user ends the call after 10 s. The ME returns in idle mode. | |

PROACTIVE COMMAND: SET UP CALL 3.1.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "Set up call Icon 3.1.1"

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string "012340123456p1p2"

Icon identifier

Icon qualifier: icon is not self-explanatory
Icon identifier: <record 1 in EF IMG>

Coding:

| BER-TLV: | D0 | 30 | 81 | 03 | 01 | 10 | 00 | 82 | 02 | 81 | 83 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 16 | 53 | 65 | 74 | 20 | 75 | 70 | 20 | 63 | 61 | 6C | 6C |
| | 20 | 49 | 63 | 6F | 6E | 20 | 33 | 2E | 31 | 2E | 31 | 86 |
| | 09 | 91 | 10 | 32 | 04 | 21 | 43 | 65 | 1C | 2C | 9E | 02 |
| | 01 | 01 | | | | | | | | | | |

TERMINAL RESPONSE: SET UP CALL 3.1.1A

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 10 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----------|----|----|----------------|----|----|------|----|----|----|
| D_:: v . | | 00 | . | | 00 | _ _ | | | , o. | | | |

Expected Sequence 3.1B (SET UP CALL, display of basic icon during confirmation phase, not self-explanatory, requested icon could not be displayed)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|---|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SET UP CALL 3.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SET UP | Including icon identifier, icon shall be |
| | | | displayed in addition of the first alpha identifier |
| 4 | ME → USER | ME displays "Set up call Icon 3.1.1" without the basic icon during a user confirmation phase. | |
| 5 | $USER \rightarrow ME$ | The user confirms the set up call | [user confirmation] |
| 6 | ME→SS | The ME attempts to set up a call to "+012340123456" | |
| 7 | $SS \to ME$ | The ME receives the CONNECT message from the system simulator. | [The SS also has to handle the START DTMF and STOP DTMF messages sent by the ME in an appropriate way] |
| 8 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP CALL 3.1.1B | [Command performed successfully, but requested icon could not be displayed]. |
| 9 | USER → ME | The user ends the call after 10 s. The ME returns in idle mode. | |

TERMINAL RESPONSE: SET UP CALL 3.1.1B

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be displayed

| BER-TLV: | 81 | 03 | 01 | 10 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 04 | l |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|---|
|----------|----|----|----|----|----|----|----|----|----|----|----|----|---|

Expected Sequence 3.2A (SET UP CALL, display of basic icon during confirmation phase, self-explanatory, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|-------------------------------------|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SET UP CALL 3.2.1 | |
| 2 | $ME \to SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SET UP | Including icon identifier, icon shall be |
| | | CALL 3.2.1 | displayed instead of the first alpha identifier |
| 4 | $ME \to USER$ | ME displays the basic icon during | |
| | | a user confirmation phase. | |
| 5 | $USER \to ME$ | The user confirms the set up call | [user confirmation] |
| 6 | $ME \to SS$ | The ME attempts to set up a call to | |
| | | "+012340123456" | |
| 7 | $SS \to ME$ | The ME receives the CONNECT | [The SS also has to handle the START DTMF |
| | | message from the system | and STOP DTMF messages sent by the ME |
| | | simulator. | in an appropriate way] |
| 8 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP | [Command performed successfully] |
| | | CALL 3.2.1A | |
| 9 | $USER \to ME$ | The user ends the call after 10 s. | |
| | | The ME returns in idle mode. | |

PROACTIVE COMMAND: SET UP CALL 3.2.1

Logically:

Command details

Command number:

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "Set up call Icon 3.2.1"

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string "012340123456p1p2"

Icon identifier

Icon qualifier: icon is self-explanatory
Icon identifier: <record 1 in EF IMG>

Coding:

| BER-TLV: | D0 | 30 | 81 | 03 | 01 | 10 | 00 | 82 | 02 | 81 | 83 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 16 | 53 | 65 | 74 | 20 | 75 | 70 | 20 | 63 | 61 | 6C | 6C |
| | 20 | 49 | 63 | 6F | 6E | 20 | 33 | 2E | 32 | 2E | 31 | 86 |
| | 09 | 91 | 10 | 32 | 04 | 21 | 43 | 65 | 1C | 2C | 9E | 02 |
| | 00 | 01 | | | | | | | | | | |

TERMINAL RESPONSE: SET UP CALL 3.2.1A

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 10 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 | |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|--|
|----------|----|----|----|----|----|----|----|----|----|----|----|----|--|

Expected Sequence 3.2B (SET UP CALL, display of basic icon during confirmation phase, self-explanatory, requested icon could not be displayed)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|---|---|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: SET UP CALL 3.2.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SET UP | Including icon identifier, icon shall be |
| | | CALL 3.2.1 | displayed instead of the first alpha identifier |
| 4 | $ME \rightarrow USER$ | ME display "Set up call Icon 3.2.1" | |
| | | without the icon | |
| 5 | $USER \to ME$ | • | [user confirmation] |
| 6 | ME→SS | The ME attempts to set up a call to | |
| _ | | "+012340123456" | |
| 7 | $SS \rightarrow ME$ | The ME receives the CONNECT | [The SS also has to handle the START DTMF |
| | | message from the system | and STOP DTMF messages sent by the ME |
| 8 | 145 0114 | simulator. | in an appropriate way] |
| 0 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP ICALL 3.2.1B | [Command performed successfully, but |
| | | CALL 3.2.1D | requested icon could not be displayed]. |
| 9 | USER → ME | The user ends the call after 10 s. | |
| | JOSEIN / IVIE | The ME returns in idle mode. | |

TERMINAL RESPONSE: SET UP CALL 3.2.1B

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be displayed

| BER-TLV: | | 03 | 01 | 10 | 00 | 82 | 02 | 82 | 21 | 83 | Λ1 | 04 |
|----------|----|----|----|----|------|----|------|----|----|----|----|------------------|
| DEK-ILV. | 01 | 03 | 01 | 10 | 1 00 | 02 | 1 02 | 02 | 01 | 03 | 01 | 1 U 1 |

Expected Sequence 3.3A (SET UP CALL, display of colour icon during confirmation phase, not self-explanatory, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-------------------------------------|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SET UP CALL 3.3.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SET UP | Including icon identifier, icon shall be displayed in |
| | | CALL 3.3.1 | addition of the first alpha identifier |
| 4 | $ME \to USER$ | ME displays "Set up call Icon | |
| | | 3.3.1" and the colour icon during a | |
| | | user confirmation phase. | |
| 5 | $USER \to ME$ | The user confirms the set up call | [user confirmation] |
| 6 | $ME \rightarrow SS$ | The ME attempts to set up a call to | |
| | | "+012340123456" | |
| 7 | $SS \rightarrow ME$ | | [The SS also has to handle the START DTMF and |
| | | message from the system | STOP DTMF messages sent by the ME in an |
| | | simulator. | appropriate way] |
| 8 | $ME \rightarrow SIM$ | | [Command performed successfully] |
| | | CALL 3.3.1A | |
| 9 | USER \rightarrow ME | The user ends the call after 10 s. | |
| | | The ME returns in idle mode. | |

PROACTIVE COMMAND: SET UP CALL 3.3.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "Set up call Icon 3.3.1"

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string "012340123456p1p2"

Icon identifier

Icon qualifier: icon is not self-explanatory
Icon identifier: <record 2 in EF IMG>

Coding:

| BER-TLV: | D0 | 30 | 81 | 03 | 01 | 10 | 00 | 82 | 02 | 81 | 83 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 16 | 53 | 65 | 74 | 20 | 75 | 70 | 20 | 63 | 61 | 6C | 6C |
| | 20 | 49 | 63 | 6F | 6E | 20 | 33 | 2E | 33 | 2E | 31 | 86 |
| | 09 | 91 | 10 | 32 | 04 | 21 | 43 | 65 | 1C | 2C | 9E | 02 |
| | 01 | 02 | | | | | | | | | | |

TERMINAL RESPONSE: SET UP CALL 3.3.1A

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TL' | /: 8 [^] | 1 03 | 3 0 | 1 | 10 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 | l |
|---------|-------------------|------|-----|---|----|----|----|----|----|----|----|----|----|---|
|---------|-------------------|------|-----|---|----|----|----|----|----|----|----|----|----|---|

Expected Sequence 3.3B (SET UP CALL, display of colour icon during confirmation phase, not self-explanatory, requested icon could not be displayed)

| Step | Direction | MESSAGE / Action | Comments |
|------|---------------|--|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SET UP CALL 3.3.1 | |
| 2 | $ME \to SIM$ | FETCH | |
| 3 | $SIM \to ME$ | | Including icon identifier, icon shall be |
| | | CALL 3.3.1 | displayed in addition of the first alpha identifier |
| 4 | $ME \to USER$ | ME only display alpha string: " Set up call Icon 3.3.1" | |
| 5 | $USER \to ME$ | The user confirms the set up call | [user confirmation] |
| 6 | $ME \to SS$ | The ME attempts to set up a call to "+012340123456" | |
| 7 | $SS \to ME$ | The ME receives the CONNECT message from the system simulator. | [The SS also has to handle the START DTMF and STOP DTMF messages sent by the ME in an appropriate way] |
| 8 | $ME \to SIM$ | TERMINAL RESPONSE: SET UP CALL 3.3.1B | [Command performed successfully, but requested icon could not be displayed]. |
| 9 | $USER \to ME$ | The user ends the call after 10 s. | |
| | | The ME returns in idle mode. | |

TERMINAL RESPONSE: SET UP CALL 3.3.1B

Logically:

Command details

Command number:

Command type: SET UP CALL

1

Command qualifier: only if not currently busy on another call

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be displayed

| RED_TI \/· | 01 | 03 | Ω1 | 10 | 00 | 82 | 02 | 82 | 01 | 93 | Ω1 | 04 |
|------------|----|----|----|----|----|----|----|----|----|----|----|----|

Expected Sequence 3.4A (SET UP CALL, display of self explanatory basic icon during set up call, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|-------------------------------------|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SET UP CALL 3.4.1 | |
| 2 | $ME \to SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SET UP | Including a second alpha identifier and two |
| | | CALL 3.4.1 | icons |
| 4 | $ME \to USER$ | ME displays the basic icon during | |
| | | a user confirmation phase. | |
| 5 | $USER \to ME$ | The user confirms the set up call | [user confirmation] |
| 6 | $ME \rightarrow SS$ | The ME attempts to set up a call to | |
| | | "+012340123456". The ME | |
| | | displays the basic icon without the | |
| | | text during the set up call. | |
| 7 | $SS \to ME$ | The ME receives the CONNECT | [The SS also has to handle the START DTMF |
| | | message from the system | and STOP DTMF messages sent by the ME |
| | | simulator. | in an appropriate way] |
| 8 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP | [Command performed successfully] |
| | | CALL 3.4.1A | |
| 9 | $USER \to ME$ | The user ends the call after 10 s. | |
| | | The ME returns in idle mode. | |

PROACTIVE COMMAND: SET UP CALL 3.4.1

Logically:

Command details

Command number:

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "Set up call Icon 3.4.1"

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string "012340123456p1p2"

Icon identifier

Icon qualifier: icon is self-explanatory
Icon identifier: <record 1 in EF IMG>
Alpha identifier: "Set up call Icon 3.4.2"

Icon identifier

Icon qualifier: icon is self-explanatory
Icon identifier: <record 1 in EF IMG>

| BER-TLV: | D0 | 4C | 81 | 03 | 01 | 10 | 00 | 82 | 02 | 81 | 83 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 16 | 53 | 65 | 74 | 20 | 75 | 70 | 20 | 63 | 61 | 6C | 6C |
| | 20 | 49 | 63 | 6F | 6E | 20 | 33 | 2E | 34 | 2E | 31 | 86 |
| | 09 | 91 | 10 | 32 | 04 | 21 | 43 | 65 | 1C | 2C | 9E | 02 |
| | 00 | 01 | 85 | 16 | 53 | 65 | 74 | 20 | 75 | 70 | 20 | 63 |
| | 61 | 6C | 6C | 20 | 49 | 63 | 6F | 6E | 20 | 33 | 2E | 34 |
| | 2F | 32 | 9F | 02 | 00 | 01 | | | | | | |

TERMINAL RESPONSE: SET UP CALL 3.4.1A

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 10 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 | ĺ |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|---|
|----------|----|----|----|----|----|----|----|----|----|----|----|----|---|

Expected Sequence 3.4B (SET UP CALL, display of self explanatory basic icon during set up call, requested icon could not be displayed)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|-------------------------------------|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SET UP CALL 3.4.1 | |
| 2 | $ME \to SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SET UP | Including a second alpha identifier and two |
| | | CALL 3.4.1 | icons |
| 4 | $ME \to USER$ | ME displays "Set up call Icon | |
| | | 3.4.1" without the icon | |
| 5 | $USER \to ME$ | The user confirms the set up call | [user confirmation] |
| 6 | $ME \to SS$ | The ME attempts to set up a call to | |
| | | "+012340123456". The ME | |
| | | displays "Set up call Icon 3.4.2" | |
| | | without the icon during the set up | |
| _ | | call. | |
| 7 | $SS \to ME$ | The ME receives the CONNECT | [The SS also has to handle the START DTMF |
| | | message from the system | and STOP DTMF messages sent by the ME |
| | | simulator. | in an appropriate way] |
| 8 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP | [Command performed successfully, but |
| | LIGED A | CALL 3.4.1B | requested icon could not be displayed]. |
| 9 | $USER \to ME$ | The user ends the call after 10 s. | |
| | | The ME returns in idle mode. | |

TERMINAL RESPONSE: SET UP CALL 3.4.1B

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be displayed

| BER-TLV: 81 | 03 | 01 | 10 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 04 |
|-------------|----|----|----|----|----|----|----|----|----|----|----|

27.22.4.13.3.5 Test requirement

The ME shall operate in the manner defined in expected sequences 3.1A to 3.4B.

27.22.4.14 POLLING OFF

27.22.4.14.1 Definition and applicability

See clause 3.2.2.

27.22.4.14.2 Conformance requirement

The ME shall support the POLLING OFF as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.14, clause 6.6.14, clause 6.8, clause 6.11, clause 12.6 and clause 12.7.

27.22.4.14.3 Test purpose

To verify that the ME cancels the effect of any previous POLL INTERVAL commands and does not effect SIM presence detection.

27.22.4.14.4 Method of test

27.22.4.14.4.1 Initial conditions

The ME is connected to the SIM Simulator.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.14.4.2 Procedure

Expected Sequence 1.1 (POLLING OFF)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|------------------------------|---|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: POLL INTERVAL | |
| | | 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: | Interval = 1 min |
| | | POLL INTERVAL 1.1.1 | |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: POLL | [command performed successfully, duration |
| | | INTERVAL 1.1.1 A or | depends on the ME"s capabilities] |
| | | TERMINAL RESPONSE: POLL | |
| | | INTERVAL 1.1.1B | |
| 5 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: POLLING OFF | |
| | | 1.1.2 | |
| 6 | $ME \rightarrow SIM$ | FETCH | |
| 7 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: | |
| _ | | POLLING OFF 1.1.2 | |
| 8 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: | [command performed successfully] |
| | | POLLING OFF 1.1.2 | |
| 9 | $USER \to SIM$ | • | |
| 10 | $ME \rightarrow SIM$ | Periods of inactivity on the | |
| | | SIM-ME interfaceshall not | |
| | | exceed 30 seconds | |
| 11 | $USER \to SIM$ | | |
| | | after call setup | |

PROACTIVE COMMAND: POLL INTERVAL 1.1.1

Logically:

Command details

Command number:

Command type: POLL INTERVAL

Command qualifier: "00"

Device identities

Source device: SIM Destination device: ME

Duration

Time unit: Minutes
Time interval: 1

Coding:

| BER-TLV: | D0 | 0D | 81 | 03 | 01 | 03 | 00 | 82 | 02 | 81 | 82 | 84 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| • | 02 | 00 | 01 | | | | | | | | | |

TERMINAL RESPONSE: POLL INTERVAL 1.1.1A

Logically:

Command details

Command number: 1

Command type: POLL INTERVAL

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Duration

Time unit: Minutes
Time interval: 1

Coding:

| BER-TLV: | 81 | 03 | 01 | 03 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 84 | 02 | 00 | 01 | | | | | | | | |

TERMINAL RESPONSE: POLL INTERVAL 1.1.1B

Logically:

Command details

Command number: 1

Command type: POLL INTERVAL

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Duration

Time unit: Seconds
Time interval: 60

| 84 | 02 | 01 | 3C | | | | |
|----|----|----|----|--|--|--|--|

NOTE: If the requested poll interval is not supported by the ME, the ME is allowed to use a different one as stated in 3GPP TS 11.14 [13], subclause 6.4.6.

PROACTIVE COMMAND: POLLING OFF 1.1.2

Logically:

Command details

Command number: 1

Command type: POLLING OFF

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Coding:

| BER-TLV: | D0 | 09 | 81 | 03 | 01 | 04 | 00 | 82 | 02 | 81 | 82 |
|-----------|----|----|----|----|----|-----|----|----|----|----|----|
| DEIX IEV. | | 00 | 0. | 00 | 0. | 0 1 | 00 | 02 | 02 | 0. | 02 |

TERMINAL RESPONSE: POLLING OFF 1.1.2

Logically:

Command details

Command number:

Command type: POLLING OFF

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

27.22.4.14.5 Test requirement

The ME shall operate in the manner defined in expected sequence 1.1.

27.22.4.15 PROVIDE LOCAL INFORMATION

27.22.4.15.1 Definition and applicability

See clause 3.2.2.

27.22.4.15.2 Conformance requirement

The ME shall support the PROVIDE LOCAL INFORMATION facility as defined in:

• 3GPP TS 11.14 [15] clause 6.4.15.

27.22.4.15.3 Test purpose

To verify that the ME returns the following requested local information within a TERMINAL RESPONSE:

- location information:
 - Mobile Country Code (MCC);
 - Mobile Network Code (MNC);
 - Location Area Code (LAC); and
 - cell ID of the current serving cell;
- the IMEI of the ME;
- the Network Measurement Results and the BCCH channel list;
- the current date, time and time zone;
- the current ME language setting;
- the Timing Advance;

if the local information is stored in the ME; otherwise, sends the correct error code to the SIM in the TERMINAL RESPONSE.

27.22.4.15.4 Method of tests

27.22.4.15.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The ME is connected to the System Simulator and has performed the location update procedure.

The GSM parameters of the system simulator are:

- Mobile Country Code (MCC) = 001;
- Mobile Network Code (MNC) = 01;
- Location Area Code (LAC) = 0001;
- Cell Identity value = 0001;
- Timing advance = 0;
- Neighbour allocations = 561, 565, 568, 569, 573, 575, 577, 581, 582 and 585.

The PCS 1900 parameters of the system simulator are:

- Mobile Country Code (MCC) = 001;
- Mobile Network Code (MNC) = 011;
- Location Area Code (LAC) = 0001;
- Cell Identity value = 0001;
- Timing advance = 0;
- Neighbour allocations = 561, 565, 568, 569, 573, 575, 577, 581, 582 and 585.

The elementary files are coded as the SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.15.4.2 Procedure

Expected Sequence 1.1 (PROVIDE LOCAL INFORMATION, Local Info (MCC, MNC, LAC & Cell ID))

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|----------------------------|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND PENDING | |
| | | PROVIDE LOCAL INFORMATION | |
| | | 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: PROVIDE | |
| | | LOCAL INFORMATION 1.1.1 | |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: PROVIDE | [Command performed successfully, MCC MNC LAC |
| | | LOCAL INFORMATION 1.1.1A | and Cell Identity as system simulator, option A shall |
| | | | apply for GSM parameters] |
| | | or | |
| | | TERMINAL RESPONSE: PROVIDE | [Command performed successfully, MCC MNC LAC |
| | | LOCAL INFORMATION 1.1.1B | and Cell Identity as system simulator, option B shall |
| | | | apply for PCS1900 parameters] |
| | | | |

PROACTIVE COMMAND: PROVIDE LOCAL INFORMATION 1.1.1

Logically:

Command details

Command number:

Command type: PROVIDE LOCAL INFORMATION

Qualifier: "00" Location information (MCC MNC LAC and Cell Identity)

Device identities

Source device: SIM Destination device: ME

Coding:

| BER-TLV: | D0 | 09 | 81 | 03 | 01 | 26 | 00 | 82 | 02 | 81 | 82 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
|----------|----|----|----|----|----|----|----|----|----|----|----|

TERMINAL RESPONSE: PROVIDE LOCAL INFORMATION 1.1.1A

Logically:

Command details

Command number: 1

Command type: PROVIDE LOCAL INFORMATION

Qualifier: "00" Location information (MCC MNC LAC and Cell Identity)

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Location Information

MCC & MNC: MCC = 001, MNC = 01

Location Area Code: 0001 Cell Identity Value: 0001

| BER-TLV: | 81 | 03 | 01 | 26 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 93 | 07 | 00 | F1 | 10 | 00 | 01 | 00 | 01 | | | |

TERMINAL RESPONSE: PROVIDE LOCAL INFORMATION 1.1.1B

Logically:

Command details

Command number:

Command type: PROVIDE LOCAL INFORMATION

Qualifier: "00" Location information (MCC MNC LAC and Cell Identity)

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Location Information

MCC & MNC: MCC = 001, MNC = 011

Location Area Code: 0001 Cell Identity Value: 0001

Coding:

| BER-TLV: | 81 | 03 | 01 | 26 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 93 | 07 | 00 | 11 | 10 | 00 | 01 | 00 | 01 | | | |

Expected Sequence 1.2 (PROVIDE LOCAL INFORMATION, IMEI of the ME)

| Ste | p Direction | MESSAGE / Action | Comments |
|-----|----------------------|----------------------------|--|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING | |
| | | PROVIDE LOCAL INFORMATION | |
| | | 1.2.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: PROVIDE | |
| | | LOCAL INFORMATION 1.2.1 | |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: PROVIDE | [Command performed successfully, IMEI |
| | | LOCAL INFORMATION 1.2.1 | as system simulator, but spare digit shall |
| | | | be zero when transmitted by the ME] |

PROACTIVE COMMAND: PROVIDE LOCAL INFORMATION 1.2.1

Logically:

Command details

Command number:

Command type: PROVIDE LOCAL INFORMATION

Qualifier: "01" IMEI of the ME

Device identities

Source device: SIM
Destination device: ME

Coding:

| BER-TLV: | D0 | 09 | 81 | 03 | 01 | 26 | 01 | 82 | 02 | 81 | 82 |
|----------|----|----|----|----|----|----|----|----|----|----|----|

TERMINAL RESPONSE: PROVIDE LOCAL INFORMATION 1.2.1

Logically:

Command details

Command number: 1

Command type: PROVIDE LOCAL INFORMATION

Qualifier: "01" IMEI of the ME

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

IMEI

IMEI of the ME: The IMEI of the ME

The result coding depends on the Mobile IMEI value.

Coding:

| BER-TLV: | 81 | 03 | 01 | 26 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 94 | 80 | XX | | |

Expected Sequence 1.3 (PROVIDE LOCAL INFORMATION, Network Measurement Results (NMR))

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|----------------------------|----------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND PENDING | |
| | | PROVIDE LOCAL INFORMATION | |
| | | 1.3.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: PROVIDE | |
| | | LOCAL INFORMATION 1.3.1 | |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: PROVIDE | [Command performed successfully, |
| | | LOCAL INFORMATION 1.3.1 | NMR as system simulator] |

PROACTIVE COMMAND: PROVIDE LOCAL INFORMATION 1.3.1

Logically:

Command details

Command number: 1

Command type: PROVIDE LOCAL INFORMATION
Qualifier: "02" Network Measurement Results

Device identities

Source device: SIM
Destination device: ME

Coding:

| BER-TLV: | D0 | 09 | 81 | 03 | 01 | 26 | 02 | 82 | 02 | 81 | 82 |
|----------|----|----|----|----|----|----|----|----|----|----|----|

TERMINAL RESPONSE: PROVIDE LOCAL INFORMATION 1.3.1

The actual values of the measurements are not tested.

Logically:

Command details

Command number:

Command type: PROVIDE LOCAL INFORMATION
Qualifier: "02" Network Measurement Results

Device identities

Source device: ME

Destination device: SIM

Result

General Result: Command performed successfully

Network Measurement Results RXLEV-FULL-SERVING-CELL=52, BA not used, DTX not used, as

an example in the BER-TLV)

BCCH channel list 561, 565, 568, 569, 573, 575, 577, 581, 582 and 585

Coding:

| BER-TLV: | 81 | 03 | 01 | 26 | 02 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 96 | 10 | 34 | 34 | 00 | 00 | 00 | 00 | 00 | 00 | 00 | 00 |
| | 00 | 00 | 00 | 00 | 00 | 00 | 9D | 0D | 8C | 63 | 58 | E2 |
| | 39 | 8F | 63 | F9 | 06 | 45 | 91 | A4 | 90 | | | |

Expected Sequence 1.4 (PROVIDE LOCAL INFORMATION, Date, Time, Time Zone)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|---------------------------------|----------------------------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING | |
| | | PROVIDE LOCAL INFORMATION 1.4.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: PROVIDE | |
| | | LOCAL INFORMATION 1.4.1 | |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: PROVIDE | [Command performed successfully] |
| | | LOCAL INFORMATION 1.4.1 | |

PROACTIVE COMMAND: PROVIDE LOCAL INFORMATION 1.4.1

Logically:

Command details

Command number:

Command type: PROVIDE LOCAL INFORMATION
Qualifier: "03" Date Time and Time Zone

Device identities

Source device: SIM Destination device: ME

Coding:

| BER-TLV: | D0 | 09 | 81 | 03 | 01 | 26 | 03 | 82 | 02 | 81 | 82 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
|----------|----|----|----|----|----|----|----|----|----|----|----|

TERMINAL RESPONSE: PROVIDE LOCAL INFORMATION 1.4.1

Logically:

Command details

Command number: 1

Command type: PROVIDE LOCAL INFORMATION
Qualifier: "03" Date Time and Time Zone

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Date-Time and Time Zone date an time set by the user: 7th May 2002, 14h 08mn 17s, no time zone

information, as an example in TLV

| BER-TLV: | 81 | 03 | 01 | 26 | 03 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | A6 | 07 | 20 | 50 | 70 | 41 | 80 | 71 | FF | | | |

Expected Sequence 1.5 (PROVIDE LOCAL INFORMATION, Language setting)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|----------------------------|----------------------------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING | |
| | | PROVIDE LOCAL INFORMATION | |
| | | 1.5.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: PROVIDE | |
| | | LOCAL INFORMATION 1.5.1 | |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: PROVIDE | [Command performed successfully] |
| | | LOCAL INFORMATION 1.5.1 | - |

PROACTIVE COMMAND: PROVIDE LOCAL INFORMATION 1.5.1

Logically:

Command details

Command number:

Command type: PROVIDE LOCAL INFORMATION

Qualifier: "04" Language setting

Device identities

Source device: SIM Destination device: ME

Coding:

| BER-TLV: | D0 | 09 | 81 | 03 | 01 | 26 | 04 | 82 | 02 | 81 | 82 |
|----------|----|----|----|----|----|----|----|----|----|----|----|

TERMINAL RESPONSE: PROVIDE LOCAL INFORMATION 1.5.1

Logically:

Command details

Command number:

Command type: PROVIDE LOCAL INFORMATION

Qualifier: "04" Language setting

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully
Language English ("en") as an example for TLV

Coding:

| BER-TLV: | 81 | 03 | 01 | 26 | 04 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | AD | 02 | 65 | 6E | | | | | | | | |

Expected Sequence 1.6 (PROVIDE LOCAL INFORMATION, Timing advance)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|---------------------------------|----------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND PENDING | |
| | | PROVIDE LOCAL INFORMATION 1.6.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: PROVIDE | |
| | | LOCAL INFORMATION 1.6.1 | |

4 ME → SIM TERMINAL RESPONSE: PROVIDE [Command performed successfully] LOCAL INFORMATION 1.6.1

PROACTIVE COMMAND: PROVIDE LOCAL INFORMATION 1.6.1

Logically:

Command details

Command number: 1

Command type: PROVIDE LOCAL INFORMATION

Qualifier: "05" Timing Advance

Device identities

Source device: SIM Destination device: ME

Coding:

| BER-TLV: | D0 | nα | 81 | Ω 3 | Ω1 | 26 | 05 | 82 | 02 | 21 | 82 |
|----------|----|----|----|------------|----|----|----|----|----|----|----|
| DER-ILV. | טט | 09 | 01 | 03 | UI | 20 | 05 | 02 | 02 | 01 | 02 |

TERMINAL RESPONSE: PROVIDE LOCAL INFORMATION 1.6.1

Logically:

Command details

Command number: 1

Command type: PROVIDE LOCAL INFORMATION

Qualifier: "05" Timing Advance

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Timing Advance 2 bytes

ME status: "00" ME is in idle state Idle State

Timing Advance: 0

Coding:

| BER-TLV: | 81 | 03 | 01 | 26 | 05 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | AE | 02 | 00 | 00 | | | | | | | | |

27.22.4.15.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.6.

27.22.4.16 SET UP EVENT LIST

27.22.4.16.1 SET UP EVENT LIST (normal)

27.22.4.16.1.1 Definition and applicability

See clause 3.2.2.

27.22.4.16.1.2 Conformance requirement

The ME shall support the Proactive SIM: Set Up Event List facility as defined in:

• 3GPP TS 11.14 [15] clause 6.4.16 and clause 6.6.16.

Additionally the ME shall support the Event Download: Call Connect and the Event Download: Call Disconnected mechanism as defined in:

• 3GPP TS 11.14 [15] clause 11.2, clause 11.2.1, clause 11.2.2, clause 11.3, clause 11.3.1 and clause 11.3.2.

27.22.4.16.1.3 Test purpose

To verify that the ME accepts a list of events that it shall monitor the current list of events supplied by the SIM, is able to have this current list of events replaced and is able to have the list of events removed.

To verify that when the ME has successfully accepted or removed the list of events, it shall send TERMINAL RESPONSE (OK) to the SIM and when the ME is not able to successfully accept or remove the list of events, it shall send TERMINAL RESPONSE (Command beyond ME's capabilities).

27.22.4.16.1.4 Method of test

27.22.4.16.1.4.1 Initial conditions

The ME is connected to both the SIM Simulator and the System Simulator.

The elementary files are coded as SIM Application Toolkit default with the following exceptions.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.16.1.4.2 Procedure

Expected Sequence 1.1 (SET UP EVENT LIST, Set Up Call Connect Event)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|-------------------------------------|------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND PENDING: SET UP | |
| | | EVENT LIST 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SET UP EVENT | |
| | | LIST 1.1.1 | |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP EVENT | |
| | | LIST 1.1.1 | |
| 5 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION ENDED | |
| 6 | $SS \to ME$ | SETUP 1.1.1 | [Incoming call alert] |
| 7 | $USER \to ME$ | User shall accept the incoming call | |
| 8 | $ME \to SS$ | CONNECT 1.1.1 | |
| 9 | $ME \to SIM$ | ENVELOPE: EVENT DOWNLOAD CALL | [Call Connected Event] |
| | | CONNECTED 1.1.1 | - |
| 10 | $SIM \to ME$ | PROACTIVE SIM SESSION ENDED | |

PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00

Device identities

Source device: SIM
Destination device: ME

Event list

Event 1: Call Connected

| BER-TLV: | D0 | 0C | 81 | 03 | 01 | 05 | 00 | 82 | 02 | 81 | 82 | 99 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | 01 | | | | | | | | | | |

TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-T | _V: 8′ | 1 03 | 01 | 05 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 | l |
|-------|--------|------|----|----|----|----|----|----|----|----|----|----|---|
|-------|--------|------|----|----|----|----|----|----|----|----|----|----|---|

SET UP 1.1.1

Logically:

Transaction identifier

Ti value: 0 (bit 5-7)

Address

TON: "Unknown"

NPI: "ISDN/ telephone numbering plan"

Dialling number string: "9876"

CONNECT 1.1.1

Logically:

Transaction identifier

Ti value: 0 (bit 5-7) Ti flag: 1 (bit 8)

ENVELOPE: EVENT DOWNLOAD CALL CONNECTED 1.1.1

Logically

Event list

Event 1: Call Connected

Device identities

Source device: ME
Destination device: SIM

Transaction identifier

Ti value: 0 (bit 5-7) Ti flag: 1 (bit 8)

| BER-TLV: | D6 | 0A | 99 | 01 | 01 | 82 | 02 | 82 | 81 | 9C | 01 | 80 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|

Expected Sequence 1.2 (SET UP EVENT LIST, Replace Event)

| Step | Direction | MESSAGE / Action | Comments |
|------|---------------------------------------|---|---------------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SET UP EVENT LIST | |
| | | 1.2.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | | [Call Connected and Call Disconnected |
| | | EVENT LIST 1.2.1 | Events] |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP | |
| 5 | | EVENT LIST 1.2.1 PROACTIVE COMMAND | |
| 5 | $SIM \rightarrow ME$ | PENDING: SET UP EVENT LIST | |
| | | 1.2.2 | |
| 6 | $ME \to SIM$ | FETCH | |
| 7 | / | PROACTIVE COMMAND: SET UP | [Call Disconnected Event] |
| | · · · · · · · · · · · · · · · · · · · | EVENT LIST 1.2.2 | [] |
| 8 | $ME \to SIM$ | TERMINAL RESPONSE: SET UP | |
| | | EVENT LIST 1.2.2 | |
| 9 | $SIM \to ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |
| 10 | $SS \to ME$ | SETUP 1.2.2 | [Incoming call alert] |
| 11 | | User shall accept the incoming call | |
| 12 | $ME \rightarrow SS$ | CONNECT 1.2.2 | |
| 13 | $SS \to ME$ | DISCONNECT 1.2.2 | |
| 14 | $ME \rightarrow SIM$ | ENVELOPE: EVENT DOWNLOAD | [Call Disconnect Event] |
| | | CALL DISCONNECT 1.2.2A | |
| | | Of | |
| | | ENVELOPE: EVENT DOWNLOAD CALL DISCONNECT 1.2.2B | |
| 15 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION | |
| 13 | SIIVI → IVIE | ENDED | |
| | | LINDLD | |

PROACTIVE COMMAND: SET UP EVENT LIST 1.2.1

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM
Destination device: ME

Event list

Event 1: Call Connected Event 2: Call Disconnected

Coding:

| BER-TLV: | D0 | 0D | 81 | 03 | 01 | 05 | 00 | 82 | 02 | 81 | 82 | 99 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 02 | 01 | 02 | | | | | | | | | |

TERMINAL RESPONSE: SET UP EVENT LIST 1.2.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME

Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 05 00 82 02 82 81 83 01 00

PROACTIVE COMMAND: SET UP EVENT LIST 1.2.2

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM
Destination device: ME

Event list

Event 1: Call Disconnected

Coding:

| BER-TLV: | D0 | 0C | 81 | 03 | 01 | 05 | 00 | 82 | 02 | 81 | 82 | 99 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | 02 | | | | | | | | | | |

TERMINAL RESPONSE: SET UP EVENT LIST 1.2.2

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 05 00 82 02 82 81 83 01 00

SET UP 1.2.2

Logically:

Transaction identifier

Ti value: 0 (bit 5-7)
Ti flag: 0 (bit 8)

Address

TON: "Unknown"

NPI: "ISDN/ telephone numbering plan"

Dialling number string: "9876"

CONNECT 1.2.2

Logically:

Transaction identifier

Ti value: 0 (bit 5-7) Ti flag: 1 (bit 8)

DISCONNECT 1.2.2

Logically:

Transaction identifier

Ti value: 0 (bit 5-7)
Ti flag: 0 (bit 8)

Cause

Value: Normal call clearing

ENVELOPE: EVENT DOWNLOAD CALL DISCONNECTED 1.2.2A

Logically:

Event list

Event 1: Call Disconnected

Device identities

Source device: Network
Destination device: SIM

Transaction identifier

Ti value: 0 (bit 5-7)
Ti flag: 0 (bit 8)

Cause

Value: Normal call clearing

Coding:

| BER-TLV: | D6 | 0E | 99 | 01 | 02 | 82 | 02 | 83 | 81 | 9C | 01 | 00 | |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|--|
| | 9A | 02 | 60 | 90 | | | | | | | | | |

ENVELOPE: EVENT DOWNLOAD CALL DISCONNECTED 1.2.2B

Logically:

Event list

Event 1: Call Disconnected

Device identities

Source device: Network
Destination device: SIM

Transaction identifier

Ti value: 0 (bit 5-7) Ti flag: 0 (bit 8)

Cause

Value: Normal call clearing

| BER-TLV: | D6 | 0E | 99 | 01 | 02 | 82 | 02 | 83 | 81 | 9C | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| _ | 9A | 02 | E0 | 90 | | | | | | | | |

Expected Sequence 1.3 (SET UP EVENT LIST, Remove Event)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|-------------------------------------|------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SET UP EVENT LIST | |
| | | 1.3.1 | |
| 2 | | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SET UP | [Call Connected Event] |
| | | EVENT LIST 1.3.1 | |
| | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP | |
| | | EVENT LIST 1.3.1 | |
| 4 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: SET UP EVENT LIST | |
| _ | | 1.3.2 | |
| 5 | , | FETCH | · |
| 6 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SET UP | [Remove Event] |
| _ | | EVENT LIST 1.3.2 | |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP | |
| 8 | CIM . ME | PROACTIVE SIM SESSION | |
| 0 | $SIM \rightarrow ME$ | ENDED | |
| 10 | $SS \rightarrow ME$ | SETUP 1.3.2 | [Incoming call alert] |
| 11 | USER → ME | User shall accept the incoming call | [mooning dan dient] |
| 12 | | CONNECT 1.3.2 | |
| 13 | $ME \rightarrow SS$ | No ENVELOPE: EVENT | |
| 13 | IVIE → SIIVI | DOWNLOAD (call connected) sent | |
| 1 44 | 00 145 | , | |
| 14 | $SS \to ME$ | DISCONNECT 1.3.2 | |

PROACTIVE COMMAND: SET UP EVENT LIST 1.3.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM Destination device: ME

Event list

Event 1: Call Connected

Coding:

| BER-TLV: | D0 | 0C | 81 | 03 | 01 | 05 | 00 | 82 | 02 | 81 | 82 | 99 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| · | 01 | 01 | | | | | | | | | | |

TERMINAL RESPONSE: SET UP EVENT LIST 1.3.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

| BER-TLV: | 81 | 03 | 01 | 05 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|

PROACTIVE COMMAND: SET UP EVENT LIST 1.3.2

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM
Destination device: ME
Event list: Empty

Coding:

| BER-TLV: | D0 | 0B | 81 | 03 | 01 | 05 | 00 | 82 | 02 | 81 | 82 | 99 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| • | 00 | | | | | | | | | | | |

TERMINAL RESPONSE: SET UP EVENT LIST 1.3.2

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 05 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|-----|----|----|----|----|----|----------|----|-----|----|
| | | | · · | | | | | | <u> </u> | | · · | |

SET UP 1.3.2

Logically:

Transaction identifier

Ti value: 0 (bit 5-7) Ti flag: 0 (bit 8)

Address

TON: "Unknown"

NPI: "ISDN/ telephone numbering plan"

Dialling number string: "9876"

CONNECT 1.3.2

Logically:

Transaction identifier

Ti value: 0 (bit 5-7)

Ti flag: 1 (bit 8)

DISCONNECT 1.3.2

Logically:

Transaction identifier

Ti value: 0 (bit 5-7) Ti flag: 0 (bit 8)

Cause

Value: Normal call clearing

Expected Sequence 1.4 (SET UP EVENT LIST, Remove Event on ME Power Cycle)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|-------------------------------------|------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SET UP EVENT LIST | |
| | | 1.4.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SET UP | [Call Connected Event] |
| | | EVENT LIST 1.4.1 | |
| | $ME \to SIM$ | TERMINAL RESPONSE: SET UP | |
| | | EVENT LIST 1.4.1 | |
| 4 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION | |
| _ | | ENDED | |
| 5 | 000i / iiiL | Power off ME | |
| 6 | 000. / <u> </u> | Power on ME | |
| 7 | 00 / | SETUP 1.4.1 | [Incoming call alert] |
| 8 | $USER \to ME$ | User shall accept the incoming call | |
| 9 | $ME \to SS$ | CONNECT 1.4.1 | |
| 10 | $ME \to SIM$ | No ENVELOPE: EVENT | |
| | | DOWNLOAD (call connected) sent | |
| 11 | $SS \to ME$ | DISCONNECT 1.4.1 | |

PROACTIVE COMMAND: SET UP EVENT LIST 1.4.1

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM
Destination device: ME

Event list

Event 1: Call Connected

Coding:

| BER-TLV: | D0 | 0C | 81 | 03 | 01 | 05 | 00 | 82 | 02 | 81 | 82 | 99 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | 01 | | | | | | | | | | |

TERMINAL RESPONSE: SET UP EVENT LIST 1.4.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME

Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 05 00 82 02 82 81 83 01 00

SET UP 1.4.1

Logically:

Transaction identifier

Ti value: 0 (bit 5-7) Ti flag: 0 (bit 8)

Address

TON: "Unknown"

NPI: "ISDN/ telephone numbering plan"

Dialling number string: "9876"

CONNECT 1.4.1

Logically:

Transaction identifier

Ti value: 0 (bit 5-7) Ti flag: 1 (bit 8)

DISCONNECT 1.4.1

Logically:

Transaction identifier

Ti value: 0 (bit 5-7) Ti flag: 0 (bit 8)

Cause

Value: Normal call clearing

27.22.4.16.1.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.4.

27.22.4.17 PERFORM CARD APDU

27.22.4.17.1 PERFORM CARD APDU (normal)

27.22.4.17.1.1 Definition and applicability

See clause 3.2.2.

27.22.4.17.1.2 Conformance requirement

The ME shall support the Proactive SIM: Perform Card APDU facility as defined in:

• 3GPP TS 11.14 [15] clause 6.1, clause 5.2, clause 6.4.17, clause 6.6.17, clause 6.8, clause 12.6, clause 12.7, clause 12.35, clause 12.36 and clause 12.12.9.

Additionally the ME shall support multiple card operation as defined in:

• 3GPP TS 11.14 [15] clause 6.4.19, clause 6.6.19, clause 6.4.18 and clause 6.6.18.

27.22.4.17.1.3 Test purpose

To verify that the ME sends an APDU command to the additional card identified in the PERFORM CARD APDU proactive SIM command, and successfully returns the result of the execution of the command in the TERMINAL RESPONSE command send to the SIM.

The ME-Manufacturer can assign the card reader identifier from 0 to 7.

This test applies for MEs with only one additional card reader.

In this particular case the card reader identifier 1 is chosen.

In this particular case a special Test-SIM (TestSIM) with T=0 protocol is chosen as additional card for the additional ME card reader (for coding of the TestSIM see annex D).

27.22.4.17.1.4 Method of test

27.22.4.17.1.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The TestSIM is inserted in the additional ME card reader.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

If the ME supports a detachable card reader, the card reader shall be attached to the ME.

The elementary files of the TestSIM are coded as defined in annex D. Another card with different parameters may be used as TestSIM to execute these tests. In this case the SIM Simulator shall take into account the corresponding response data.

27.22.4.17.1.4.2 Procedure

Expected Sequence 1.1 (PERFORM CARD APDU, card reader 1, additional card inserted, Select MF and Get Response)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|---|--|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: POWER ON CARD | |
| | | 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: | [Power on card reader 1] |
| | | POWER ON CARD 1.1.1 | |
| 4 | | RESET CARD | [Perform electrical initialization] |
| 5 | | ANSWER TO RESET 1.1 | [ATR] |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: POWER | [ATR] |
| | | ON CARD 1.1.1 | |
| 7 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: PERFORM CARD | |
| | 145 0114 | APDU 1.1.1 | |
| 8 | $ME \rightarrow SIM$ | FETCH | [Oalast Mastarfile] |
| 9 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: PERFORM CARD APDU 1.1.1 | [Select Masterfile] |
| 10 | ME SIMO | C-APDU: SELECT 1.1 | [Select Masterfile] |
| 11 | | R-APDU: SELECT 1.1 | [Command performed successfully - length |
| '' | SIIVIZ -> IVIE | R-APDO. SELECT 1.1 | 1B' of response data |
| 12 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: | The of response dataj |
| 12 | IVIL / OIIVI | PERFORM CARD APDU 1.1.1 | |
| 13 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | O 7 | PENDING: PERFORM CARD | |
| | | APDU 1.1.2 | |
| 14 | $ME \rightarrow SIM$ | FETCH | |
| 15 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: | [Get Response with length '1B'] |
| | | PERFORM CARD APDU 1.1.2 | |
| 16 | $ME \rightarrow SIM2$ | C-APDU: GET RESPONSE 1.1 | [Get Response with length '1B'] |
| 17 | $SIM2 \rightarrow ME$ | R-APDU: GET RESPONSE 1.1 | [Response data with length '1B'] |
| 18 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: | [Response data with length '1B'] |
| | | PERFORM CARD APDU 1.1.2 | |

PROACTIVE COMMAND POWER ON CARD 1.1.1

Logically:

Command details

Command number:

Command type: POWER ON CARD

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card reader 1

Coding:

| | | | | 00 | | | | 0.0 | 00 | | |
|----------|----|----|----|----|----|----|----|-----|----|----|----|
| BER-TLV: | D0 | 09 | 81 | 03 | 01 | 31 | 00 | 82 | 02 | 81 | 11 |

ANSWER TO RESET 1.1

Logically:

TS (Initial character): '3B'

T0 (Format character): '86' (Following interface characters: TD(1), number of historical characters: 6)

TD1: '00' (Following interface characters: none, Transfer protocol: T=0)

T1: 91 T2: 99 T3: 00 T4: 12 T5: C1 T6: 00

Coding:

| Coding: | 3B | 86 | 00 | 91 | 99 | 00 | 12 | C1 | 00 |
|---------|----|----|----|----|----|----|----|----|----|

TERMINAL RESPONSE: POWER ON CARD 1.1.1

Logically:

Command details

Command number: 1

Command type: POWER ON CARD

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Card ATR

TS (Initial character): '3B'

T0 (Format character): '86' (Following interface characters: TD(1), number of historical characters: 6)

TD1: '00' (Following interface characters: none, Transfer protocol: T=0)

T1: 91
T2: 99
T3: 00
T4: 12
T5: C1
T6: 00

Coding:

| BER-TLV: | 81 | 03 | 01 | 31 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | A1 | 09 | 3B | 86 | 00 | 91 | 99 | 00 | 12 | C1 | 00 | |

PROACTIVE COMMAND PERFORM CARD APDU 1.1.1

Logically:

Command details

Command number: 1

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card Reader 1

C-APDU

Class: 'A0'
Instruction: SELECT
P1 parameter: '00'
P2 parameter: '00'
Lc: '02'

Data: Master File

Coding:

| BER-TLV: | D0 | 12 | 81 | 03 | 01 | 30 | 00 | 82 | 02 | 81 | 11 | A2 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 07 | A0 | A4 | 00 | 00 | 02 | 3F | 00 | | | | |

C-APDU: SELECT 1.1

Logically:

C-APDU

Class: 'A0'
Instruction: SELECT
P1 parameter: '00'
P2 parameter: '00'
Lc: '02'
Data: Master File

Coding:

Coding: A0 A4 00 00 02 3F 00

R-APDU: SELECT 1.1

Logically:

Status Words

SW1 / SW2: Command performed successfully - length '1B' of response data

Coding:

Coding: 9F 1B

TERMINAL RESPONSE: PERFORM CARD APDU 1.1.1

Logically:

Command details

Command number: 1

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

R-APDU

Status Words

SW1 / SW2: Command performed successfully - length '1B' of response data

| BER-TLV: | 81 | 03 | 01 | 30 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | Α3 | 02 | ٩F | 1B | | | | | | | | |

PROACTIVE COMMAND PERFORM CARD APDU 1.1.2

Logically:

Command details

Command number: 1

Command type: PERFORM CARD APDU

Command qualifier: '00'

Device identities

Source device: SIM

Destination device: Card Reader 1

C-APDU

Class: 'A0'

Instruction: GET RESPONSE

P1 parameter: '00' P2 parameter: '00' Le: '1B'

Coding:

| BER-TLV: | D0 | 10 | 81 | 03 | 01 | 30 | 00 | 82 | 02 | 81 | 11 | A2 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 05 | A0 | C0 | 00 | 00 | 1B | | | | | | |

C-APDU: GET RESPONSE 1.1

Logically:

C-APDU

Class: 'A0'

Instruction: GET RESPONSE

P1 parameter: '00' P2 parameter: '00' Le: '1B'

Coding:

| Codina: | A0 | C0 | 00 | 00 | 1B |
|---------|----|----|----|----|----|

R-APDU: GET RESPONSE 1.1

Logically:

R-APDU data

RFU: '00 00'
Not allocated memory: '653 bytes'
File ID: Master File

Type of file: MF

RFU: 00 00 22 FF 01' Length of following data: 14 bytes'

File characteristics:

Clock Stop: Not allowed Min. frequence for GSM algorithm: 13/8 MHz

Technology identification: 3V Technology SIM

CHV1: disabled DFs in current directory: 2

EFs in current directory: 8
Number of CHV and admin. Codes: 3
RFU byte 18: 00

CHV1 status:

False representations remaining: 3 RFU-bits 7-5: 000

Secret code: Initialized

Unlock CHV1 status:

False representations remaining: 10
RFU-bits 7-5: 000
Secret code: Initialized

CHV2 status:

False representations remaining: 3
RFU-bits 7-5: 000
Secret code: Initialized

Unlock CHV2 status:

False representations remaining: 10
RFU-bits 7-5: 000
Secret code: Initialized
RFU bytes 23: 00

Reserved for admin. management: 00 83 00 FF

Status Words

SW1 / SW2: Normal ending of command

Coding:

| Coding: | 00 | 00 | 02 | 8D | 3F | 00 | 01 | 00 | 00 | 22 | FF | 01 | |
|---------|----|----|----|----|----|----|----|----|----|----|----|----|---|
| | 0E | 9B | 02 | 08 | 03 | 00 | 83 | 8A | 83 | 8A | 00 | 00 | l |
| | 83 | 00 | FF | 90 | 00 | | | | | | | | l |

TERMINAL RESPONSE: PERFORM CARD APDU 1.1.2

Logically:

Command details

Command number:

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

R-APDU data

RFU: '00 00'

Not allocated memory: '653 bytes'

File ID: Master File

Type of file: MF

RFU: 00 00 22 FF 01' Length of following data: 14 bytes'

File characteristics:

Clock Stop: Not allowed Min. frequence for GSM algorithm: 13/8 MHz

Technology identification: 3V Technology SIM

CHV1: disabled

DFs in current directory: 2

EFs in current directory:

Number of CHV and admin. Codes: 3 RFU byte 18: 00

CHV1 status:

False representations remaining: 3
RFU-bits 7-5: 000
Secret code: Initialized

Unlock CHV1 status:

False representations remaining: 10
RFU-bits 7-5: 000
Secret code: Initialized

CHV2 status:

False representations remaining: 3
RFU-bits 7-5: 000
Secret code: Initialized

Unlock CHV2 status:

False representations remaining: 10
RFU-bits 7-5: 000
Secret code: Initialized
RFU bytes 23: 00

Reserved for admin. management: 00 83 00 FF

Statu Words

SW1 / SW2: Normal ending of command

Coding:

| BER-TLV: | 81 | 03 | 01 | 30 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| · | A3 | 0F | 00 | 00 | 02 | 8D | 3F | 00 | 01 | 00 | 00 | 22 |
| | FF | 01 | 0E | 90 | 00 | | | | | | | |

Expected Sequence 1.2 (PERFORM CARD APDU, card reader 1, additional card inserted, Select DF GSM, Select EF PLMN, Update Binary, Read Binary on EF PLMN)

| Step | Direction | MESSAGE / Action | Comments |
|------|---------------------------------------|---|-------------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: POWER ON CARD | |
| | | 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | [Power on card reader 1] |
| | | POWER ON CARD 1.1.1 | |
| 4 | | RESET CARD | [Perform electrical initialization] |
| 5 | · · · · · · · · · · · · · · · · · · · | ANSWER TO RESET 1.1 | [ATR] |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: POWER | [ATR] |
| _ | | ON CARD 1.1.1 | |
| 7 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: PERFORM CARD | |
| 0 | ME CIM | APDU 1.2.1 | |
| 8 | $ME \rightarrow SIM$ | FETCH | ICalast COM |
| 9 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: PERFORM CARD APDU 1.2.1 | [Select GSM] |
| 10 | ME → SIM2 | C-APDU: SELECT 1.2a | [Select GSM] |
| 11 | | R-APDU: SELECT 1.2a | [Select Golvi] |
| 12 | ME → SIM | TERMINAL RESPONSE: | |
| 12 | IVIE -> SIIVI | PERFORM CARD APDU 1.2.1 | |
| 13 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| 10 | Olivi / WIL | PENDING: PERFORM CARD | |
| | | APDU 1.2.2 | |
| 14 | $ME \rightarrow SIM$ | FETCH | |
| 15 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: | [Select PLMN] |
| | | PERFORM CARD APDU 1.2.2 | , |
| 16 | $ME \rightarrow SIM2$ | C-APDU: SELECT 1.2b | [Select PLMN] |
| 17 | $SIM2 \rightarrow ME$ | R-APDU: SELECT 1.2b | |
| 18 | $ME \to SIM$ | TERMINAL RESPONSE: | |
| | | PERFORM CARD APDU 1.2.2 | |
| 19 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: PERFORM CARD | |
| | | APDU 1.2.3 | |
| 20 | $ME \rightarrow SIM$ | FETCH | |
| 21 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: | [Update Binary] |
| | | PERFORM CARD APDU 1.2.3 | |
| 22 | | C-APDU: UPDATE BINARY 1.2 | [Update Binary] |
| 23 | | R-APDU: UPDATE BINARY 1.2 | |
| 24 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: | |
| | | PERFORM CARD APDU 1.2.3 | l l |

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|----------------------------|-----------------|
| 25 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: PERFORM CARD | |
| | | APDU 1.2.4 | |
| 26 | $ME \rightarrow SIM$ | FETCH | |
| 27 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: | [Read Binary] |
| | | PERFORM CARD APDU 1.2.4 | |
| 28 | $ME \rightarrow SIM2$ | C-APDU: READ BINARY 1.2 | [Read Binary] |
| 29 | $SIM2 \rightarrow ME$ | R-APDU: READ BINARY 1.2 | |
| 30 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: | |
| | | PERFORM CARD APDU 1.2.4 | |
| 31 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: PERFORM CARD | |
| | | APDU 1.2.5 | |
| 32 | $ME \rightarrow SIM$ | FETCH | |
| 33 | $SIM \to ME$ | PROACTIVE COMMAND: | [Update Binary] |
| | | PERFORM CARD APDU 1.2.5 | |
| 34 | $ME \rightarrow SIM2$ | C-APDU: UPDATE BINARY 1.2a | [Update Binary] |
| 35 | $SIM2 \rightarrow ME$ | R-APDU: UPDATE BINARY 1.2 | |
| 36 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: | |
| | | PERFORM CARD APDU 1.2.3 | |

PROACTIVE COMMAND PERFORM CARD APDU 1.2.1

Logically:

Command details

Command number:

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card Reader 1

C-APDU

Class: 'A0'
Instruction: SELECT
P1 parameter: '00'
P2 parameter: '00'
Lc: '02'
Data: DF GSM

Coding:

| BER-TLV: | D0 | 12 | 81 | 03 | 01 | 30 | 00 | 82 | 02 | 81 | 11 | A2 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 07 | A0 | A4 | 00 | 00 | 02 | 7F | 20 | | | | |

PROACTIVE COMMAND: PERFORM CARD APDU 1.2.2

Logically:

Command details

Command number: 1

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card Reader 1

C-APDU

Class: 'A0'
Instruction: SELECT
P1 parameter: '00'
P2 parameter: '00'

Lc: '02'

Data: EF PLMN

Coding:

| BER-TLV: | D0 | 12 | 81 | 03 | 01 | 30 | 00 | 82 | 02 | 81 | 11 | A2 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 07 | A0 | A4 | 00 | 00 | 02 | 6F | 30 | | | | |

PROACTIVE COMMAND: PERFORM CARD APDU 1.2.3

Logically:

Command details

Command number: 1

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card Reader 1

C-APDU

Class: 'A0'

Instruction: UPDATE BINARY

P1 parameter: '00' P2 parameter: '00' Lc: '18'

Data: '00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0B 0E 0F 10 11 12 13 14 15 16 17'

Coding:

| BER-TLV: | D0 | 28 | 81 | 03 | 01 | 30 | 00 | 82 | 02 | 81 | 11 | A2 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 1D | A0 | D6 | 00 | 00 | 18 | 00 | 01 | 02 | 03 | 04 | 05 |
| | 06 | 07 | 08 | 09 | 0A | 0B | 0C | 0D | 0E | 0F | 10 | 11 |
| | 12 | 13 | 14 | 15 | 16 | 17 | | | | | | |

PROACTIVE COMMAND: PERFORM CARD APDU 1.2.4

Logically:

Command details

Command number: 1

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card Reader 1

C-APDU

Class: 'A0'

Instruction: READ BINARY

P1 parameter: '00' P2 parameter: '00' Le: '18'

| BER-TLV: | D0 | 10 | 81 | 03 | 01 | 30 | 00 | 82 | 02 | 81 | 11 | A2 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 05 | A0 | B0 | 00 | 00 | 18 | | | | | | |

PROACTIVE COMMAND: PERFORM CARD APDU 1.2.5

Logically:

Command details

Command number: 1

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card Reader 1

C-APDU

Class: 'A0'

Instruction: UPDATE BINARY

P1 parameter: '00' P2 parameter: '00' Lc: '18'

Coding:

| BER-TLV: | D0 | 28 | 81 | 03 | 01 | 30 | 00 | 82 | 02 | 81 | 11 | A2 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 1D | A0 | D6 | 00 | 00 | 18 | FF | FF | FF | FF | FF | FF |
| | FF |
| | FF | FF | FF | FF | FF | FF | | | | | | |

C-APDU: SELECT 1.2a

Logically:

C-APDU

Class: 'A0'
Instruction: SELECT
P1 parameter: '00'
P2 parameter: '00'
Lc: '02'
Data: DF GSM

Coding:

| Coding: A0 A4 00 00 02 7 | 7F | l 20 |
|--------------------------|----|------|
|--------------------------|----|------|

C-APDU: SELECT 1.2b

Logically:

C-APDU

Class: 'A0'
Instruction: SELECT
P1 parameter: '00'
P2 parameter: '00'
Lc: '02'
Data: EF PLMN

| Coding: A0 A4 00 00 02 6F 3 | 30 | 30 | | | 02 | 00 | 00 | A4 | A0 | Coding: |
|---|----|----|--|--|----|----|----|----|----|---------|
|---|----|----|--|--|----|----|----|----|----|---------|

C-APDU: UPDATE BINARY 1.2

Logically:

C-APDU

Class: 'A0'

Instruction: UPDATE BINARY

P1 parameter: '00' P2 parameter: '00' Lc: '18'

Data: '00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0B 0E 0F 10 11 12 13 14 15 16 17'

Coding:

| Coding: | A0 | D6 | 00 | 00 | 18 | 00 | 01 | 02 | 03 | 04 | 05 | 06 |
|---------|----|----|----|----|----|----|----|----|----|----|----|----|
| · | 07 | 08 | 09 | 0A | 0B | 0C | 0D | 0E | 0F | 10 | 11 | 12 |
| | 13 | 14 | 15 | 16 | 17 | | | | | | | |

C-APDU: READ BINARY 1.2

Logically:

C-APDU

Class: 'A0'

Instruction: READ BINARY

P1 parameter: '00' P2 parameter: '00' Le: '18'

Coding:

Coding: A0 B0 00 00 18

C-APDU: UPDATE BINARY 1.2a

Logically:

C-APDU

Class: 'A0'

Instruction: UPDATE BINARY

P1 parameter: '00' P2 parameter: '00' Lc: '18'

Coding:

| Coding: | A0 | D6 | 00 | 00 | 18 | FF |
|---------|----|----|----|----|----|----|----|----|----|----|----|----|
| | FF |
| | FF | FF | FF | FF | FF | | | | | | | |

R-APDU: SELECT 1.2a

Logically:

Status Words

SW1 / SW2: Normal ending of command - length '1B' of response data

Coding:

Coding: 9F 1B

R-APDU: SELECT 1.2b

Logically:

Status Words

SW1 / SW2: Normal ending of command - length '0F' of response data

Coding:

Coding: 9F 0F

R-APDU: UPDATE BINARY 1.2

Logically:

Status Words

SW1 / SW2: Normal ending of command

Coding:

Coding: 90 00

R-APDU: READ BINARY 1.2

Logically:

R-APDU data

Data: '00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0B 0E 0F 10 11 12 13 14 15 16 17'

Status Words

SW1 / SW2: Normal ending of command

Coding:

| Coding: | 00 | 01 | 02 | 03 | 04 | 05 | 06 | 07 | 08 | 09 | 0A | 0B |
|---------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0C | 0D | 0E | 0F | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |
| | 90 | 00 | | | | | | | | | | |

TERMINAL RESPONSE: PERFORM CARD APDU 1.2.1

Logically:

Command details

Command number: 1

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

R-APDU

Status Words

SW1 / SW2: Command performed successfully - length 1B of response data

Coding:

| BER-TLV: | 81 | 03 | 01 | 30 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | А3 | 02 | 9F | 1B | | | | | | | | |

TERMINAL RESPONSE: PERFORM CARD APDU 1.2.2

Logically:

Command details

Command number:

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

R-APDU

Status Words

SW1 / SW2: Command performed successfully - length 0F of response data

Coding:

| BER-TLV: | 81 | 03 | 01 | 30 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | А3 | 02 | 9F | 0F | | | | | | | | |

TERMINAL RESPONSE: PERFORM CARD APDU 1.2.3

Logically:

Command details

Command number: 1

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

R-APDU

Status Words

SW1 / SW2: Normal ending of command

Coding:

| BER-TLV: | 81 | 03 | 01 | 30 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | А3 | 02 | 90 | 00 | | | | | | | | |

TERMINAL RESPONSE: PERFORM CARD APDU 1.2.4

Logically:

Command details

Command number: 1

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM Result

General Result: Command performed successfully

R-APDU

R-APDU data

Data: '00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0B 0E 0F 10 11 12 13 14 15 16 17'

Status Words

SW1 / SW2: Normal ending of command

Coding:

| BER-TLV: | 81 | 03 | 01 | 30 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | А3 | 1A | 00 | 01 | 02 | 03 | 04 | 05 | 06 | 07 | 80 | 09 |
| | 0A | 0B | 0C | 0D | 0E | 0F | 10 | 11 | 12 | 13 | 14 | 15 |
| | 16 | 17 | 90 | 00 | | | | | | | | |

Expected Sequence 1.3 (PERFORM CARD APDU, card reader 1, card inserted, card powered off)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|----------------------------------|---------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: POWER OFF CARD | |
| | | 1.3.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: | [Power off card reader 1] |
| | | POWER OFF CARD 1.3.1 | |
| 4 | $ME \rightarrow SIM2$ | POWER OFF CARD | [Power off card reader 1] |
| 5 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: POWER | [Successful] |
| | | OFF CARD 1.3.1 | |
| 6 | ME | SIM2 is powered off from ME card | |
| | | reader | |
| 7 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: PEFORM CARD APDU | |
| | | 1.1.1 | |
| 8 | $ME \rightarrow SIM$ | FETCH | |
| 9 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: | [Select Master File] |
| | | PERFORM CARD APDU 1.1.1 | |
| 10 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: | [Card powered off] |
| | | PERFORM CARD APDU 1.3.1 | |

PROACTIVE COMMAND: POWER OFF CARD 1.3.1

Logically:

Command details

Command number: 1

Command type: POWER OFF CARD

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card reader 1

Coding:

BER-TLV: D0 09 81 03 01 32 00 82 02 81 11

TERMINAL RESPONSE: POWER OFF CARD 1.3.1

Logically:

Command details

Command number: 1

Command type: POWER OFF CARD

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 32 | 00 | 82 | 02 | 82 | 81 | 83 | 01 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | | | | | | | | | | |

TERMINAL RESPONSE: PERFORM CARD APDU 1.3.1

Logically:

Command details

Command number: 1

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: MultipleCard commands error

Additional Information: Card powered off

Coding:

| BER-TLV: | 81 | 03 | 01 | 30 | 00 | 82 | 02 | 82 | 81 | 83 | 02 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 38 | 04 | | | | | | | | | |

Expected Sequence 1.4 (PERFORM CARD APDU, card reader 1, no card inserted)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|------------------------------|----------------------|
| 1 | ME | SIM2 is removed from ME card | |
| | | reader | |
| 2 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: PEFORM CARD APDU | |
| | | 1.1.1 | |
| 3 | $ME \rightarrow SIM$ | FETCH | |
| 4 | $SIM \to ME$ | PROACTIVE COMMAND: | [Select Master File] |
| | | PERFORM CARD APDU 1.1.1 | |
| 5 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: | [No card inserted] |
| | | PERFORM CARD APDU 1.4.1 | - |

TERMINAL RESPONSE: PERFORM CARD APDU 1.4.1

Logically:

Command details

Command number: 1

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: MultipleCard commands error Additional Information: Card removed or not present

Coding:

| BER-TLV: | 81 | 03 | 01 | 30 | 00 | 82 | 02 | 82 | 81 | 83 | 02 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 38 | 02 | | | | | | | | | |

Expected Sequence 1.5 (PERFORM CARD APDU, card reader 7 (which is not the valid card reader identifier of the additional ME card reader))

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|---------------------------|------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | [invalid card reader ID] |
| | | PENDING: PEFORM CARD APDU | |
| | | 1.5.1 | |
| 3 | $ME \rightarrow SIM$ | FETCH | |
| 4 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: | [Select Master File] |
| | | PERFORM CARD APDU 1.5.1 | |
| 5 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: | [Specified reader not valid] |
| | | PERFORM CARD APDU 1.5.1 | |

PROACTIVE COMMAND: PERFORM CARD APDU 1.5.1

Logically:

Command details

Command number: 1

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card Reader 7

C-APDU

Class: 'A0'
Instruction: SELECT
P1 parameter: '00'
P2 parameter: '00'
Lc: '02'

Data: Master File

Coding:

| BER-TLV: | D0 | 12 | 81 | 03 | 01 | 30 | 00 | 82 | 02 | 81 | 17 | A2 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 07 | A0 | A4 | 00 | 00 | 02 | 3F | 00 | | | | |

C-APDU: SELECT 1.1

Logically:

C-APDU

Class: 'A0'
Instruction: SELECT
P1 parameter: '00'
P2 parameter: '00'
Lc: '02'

Data: Master File

| Coding: | A0 | A4 | 00 | 00 | 02 | 3F | 00 |
|---------|----|----|----|----|----|----|----|
| | | | | | | | |

TERMINAL RESPONSE: PERFORM CARD APDU 1.5.1

Logically:

Command details

Command number: 1

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: MultipleCard commands error Additional Information: Specified reader not valid

Coding:

| BER-TLV: | 81 | 03 | 01 | 30 | 00 | 82 | 02 | 82 | 81 | 83 | 02 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 38 | 09 | | | | | | | | | |

27.22.4.17.1.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.5.

27.22.4.17.2 PERFORM CARD APDU (detachable card reader)

27.22.4.17.2.1 Definition and applicability

See clause 3.2.2.

27.22.4.17.2.2 Conformance requirement

27.22.4.17.2.3 Test purpose

To verify that the ME sends an APDU command to the additional card identified in the PERFORM CARD APDU proactive SIM command, and successfully returns the result of the execution of the command in the TERMINAL RESPONSE command send to the SIM.

27.22.4.17.2.4 Method of test

27.22.4.17.2.4.1 Initial conditions

The ME is connected to the SIM Simulator.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The card reader shall be detached from the ME.

27.22.4.17.2.4.2 Procedure

Expected Sequence 2.1 (PERFORM CARD APDU, card reader 1, card reader detached)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|---------------------------|------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: PEFORM CARD APDU | |
| | | 2.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | [Select Master File] |
| | | PERFORM CARD APDU 2.1.1 | - |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: | [Card reader detached] |
| | | PERFORM CARD APDU 2.1.1 | - |

PROACTIVE COMMAND: PERFORM CARD APDU 2.1.1

Logically:

Command details

Command number:

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card Reader 1

C-APDU

Class: 'A0'
Instruction: SELECT
P1 parameter: '00'
P2 parameter: '00'
Lc: '02'
Data: Master File

Coding:

| BER-TLV: | D0 | 12 | 81 | 03 | 01 | 30 | 00 | 82 | 02 | 81 | 11 | A2 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 07 | A0 | A4 | 00 | 00 | 02 | 3F | 00 | | | | |

TERMINAL RESPONSE: PERFORM CARD APDU 2.1.1

Logically:

Command details

Command number: 1

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: MultipleCard commands error Additional Information: Card reader removed or not present

| BER-TLV: | 81 | 03 | 01 | 30 | 00 | 82 | 02 | 82 | 81 | 83 | 02 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 38 | 01 | | | | | | | | | |

27.22.4.17.2.5 Test requirement

The ME shall operate in the manner defined in expected sequence 2.1.

27.22.4.18 POWER OFF CARD

27.22.4.18.1 POWER OFF CARD (normal)

27.22.4.18.1.1 Definition and applicability

See clause 3.2.2.

27.22.4.18.1.2 Conformance requirement

The ME shall support the Proactive SIM: Power Off Card facility as defined in:

• 3GPP TS 11.14 [15] clause 6.1, clause 6.4.18, clause 6.6.18, clause 12.6, clause 12.7, clause 12.12, clause 12.12.9, clause 5.2 and annex H.

27.22.4.18.1.3 Test purpose

To verify that the ME closes a session with the additional card identified in the POWER OFF CARD proactive SIM command, and successfully returns result in the TERMINAL RESPONSE command send to the SIM.

The ME-Manufacturer can assign the card reader identifier from 0 to 7.

This test applies for MEs with only one additional card reader.

In this particular case the card reader identifier 1 is chosen.

27.22.4.18.1.4 Method of test

27.22.4.18.1.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The ME card reader is connected to the second SIM Simulator (SIM2). Instead of the second SIM Simulator a card with different parameters may be used as SIM2 to execute these tests. In this case the SIM Simulator shall take into account the corresponding response data.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

If the ME supports a detachable card reader, the card reader shall be attached to the ME.

Prior to this test the ME shall have powered on the second SIM Simulator (SIM2).

27.22.4.18.1.4.2 Procedure

Expected Sequence 1.1 (POWER OFF CARD, card reader 1)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|------------------------------|---------------------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: | |
| | | POWER OFF CARD 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: POWER OFF | [Power off card reader 1] |
| | | CARD 1.1.1 | |
| 4 | $ME \rightarrow SIM2$ | POWER OFF CARD | [Power off card reader 1] |
| 5 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: POWER OFF | [Successful] |
| | | CARD 1.1.1 | - |

PROACTIVE COMMAND: POWER OFF CARD 1.1.1

Logically:

Command details

Command number: 1

Command type: POWER OFF CARD

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card reader 1

Coding:

| BER-TLV: | D0 | 09 | 81 | 03 | 01 | 32 | 00 | 82 | 02 | 81 | 11 |
|-----------|----|-----|----|----|-----|----|----|----|----|----|-----|
| DEIX-IEV. | | 0.0 | 01 | 00 | O I | 32 | 00 | 02 | 02 | 01 | 1.1 |

TERMINAL RESPONSE: POWER OFF CARD 1.1.1

Logically:

Command details

Command number:

Command type: POWER OFF CARD

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 32 | 00 | 82 | 02 | 82 | 81 | 83 | 01 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | | | | | | | | | | |

Expected Sequence 1.2 (POWER OFF CARD, card reader 1, no card inserted)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|-------------------------------------|---------------------------|
| 1 | SIM2 | SIM2 is removed from ME card reader | |
| 2 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: POWER | |
| | | OFF CARD 1.1.1 | |
| 3 | $ME \rightarrow SIM$ | FETCH | |
| 4 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: POWER OFF CARD | [Power off card reader 1] |
| | | 1.1.1 | |
| 5 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: POWER OFF CARD | [No card inserted] |
| | | 1.2.1 | |

TERMINAL RESPONSE: POWER OFF CARD 1.2.1

Logically:

Command details

Command number: 1

Command type: POWER OFF CARD

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: MultipleCard commands error Additional Information: Card removed or not present

335

Coding:

| BER-TLV: | 81 | 03 | 01 | 32 | 00 | 82 | 02 | 82 | 81 | 83 | 02 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 38 | 02 | | | | | | | | | |

27.22.4.18.1.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.2.

27.22.4.18.2 POWER OFF CARD (detachable card reader)

27.22.4.18.2.1 Definition and applicability

See clause 3.2.2.

27.22.4.18.2.2 Conformance requirement

Void.

27.22.4.18.2.3 Test purpose

To verify that the ME closes a session with the additional card identified in the POWER OFF CARD proactive SIM command, and successfully returns result in the TERMINAL RESPONSE command send to the SIM.

27.22.4.18.2.4 Method of test

27.22.4.18.2.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The ME card reader is connected to the second SIM Simulator (SIM2).

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

Prior to this test the ME shall have powered on the second SIM Simulator (SIM2).

The card reader shall be detached from the ME.

27.22.4.18.2.4.2 Procedure

Expected Sequence 2.1 (POWER OFF CARD, card reader 1, no card reader attached)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|------------------------------|--------------------------------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: | |
| | | POWER OFF CARD 2.1.1 | |
| 2 | $ME \rightarrow SIM$ | | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: POWER | [Power off card reader 1] |
| | | OFF CARD 2.1.1 | |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: POWER OFF | [Card reader removed or not present] |
| | | CARD 2.1.1 | |

PROACTIVE COMMAND: POWER OFF CARD 2.1.1

Logically:

Command details

Command number:

Command type: POWER OFF CARD

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card reader 1

Coding:

| BER-TLV: | D0 | 09 | 81 | 03 | 01 | 32 | 00 | 82 | 02 | 81 | 11 |
|----------|----|----|----|----|----|----|----|----|----|----|----|

TERMINAL RESPONSE: POWER OFF CARD 2.1.1

Logically:

Command details

Command number: 1

Command type: POWER OFF CARD

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: MultipleCard commands error Additional Information: Card reader removed or not present

Coding:

| BER-TLV: | 81 | 03 | 01 | 32 | 00 | 82 | 02 | 82 | 81 | 83 | 02 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 38 | 01 | | | | | | | | | |

27.22.4.18.2.5 Test requirement

The ME shall operate in the manner defined in expected sequence 2.1.

27.22.4.19 POWER ON CARD

27.22.4.19.1 POWER ON CARD (normal)

27.22.4.19.1.1 Definition and applicability

See clause 3.2.2.

27.22.4.19.1.2 Conformance requirement

The ME shall support the Proactive SIM: Power On Card facility as defined in:

- 3GPP TS 11.14 [15] clause 6.1, clause 6.4.19, clause 6.6.19, clause 12.6, clause 12.7, clause 12.12, clause 12.12.9, clause 12.34, clause 5.2 and annex H.
- ISO /IEC 7816-3 [21].

27.22.4.19.1.3 Test purpose

To verify that the ME starts a session with the additional card identified in the POWER ON CARD proactive SIM command, and successfully returns the Answer To Reset within the TERMINAL RESPONSE command send to the SIM.

The ME-Manufacturer can assign the card reader identifier from 0 to 7.

This test applies for MEs with only one additional card reader.

In this particular case the card reader identifier 1 is chosen.

27.22.4.19.1.4 Method of test

27.22.4.19.1.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The ME card reader is connected to the second SIM Simulator (SIM2). Instead of the second SIM Simulator a card with different parameters may be used as SIM2 to execute these tests. In this case the SIM Simulator shall take into account the corresponding response data.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

If the ME supports a detachable card reader, the card reader shall be attached to the ME.

27.22.4.19.1.4.2 Procedure

Expected Sequence 1.1 (POWER ON CARD, card reader 1)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-----------------------------|-------------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND PENDING: | |
| | | POWER ON CARD 1.1.1 | |
| 2 | $ME \to SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: POWER ON | [Power on card reader 1] |
| | | CARD 1.1.1 | |
| 4 | $ME \rightarrow SIM2$ | RESET CARD | [Perform electrical initialization] |
| 5 | $SIM2 \rightarrow ME$ | ANSWER TO RESET 1.1.1 | [ATR] |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: POWER ON | [ATR] |
| | | CARD 1.1.1 | - - |

PROACTIVE COMMAND: POWER ON CARD 1.1.1

Logically:

Command details

Command number:

Command type: POWER ON CARD

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card reader 1

Coding:

| BER-TLV: | D0 | 09 | 81 | በ3 | 01 | 31 | 00 | 82 | 02 | 81 | 11 1 |
|-----------|----|----|-----|----|-----|----|----|----|----|----|------|
| DEIX IEV. | | 00 | O I | 03 | O I | 01 | 00 | 02 | 02 | 01 | |

ANSWER TO RESET 1.1.1

Logically:

| TS (Initial character): | '3B |
|-----------------------------|-----|
| T0 (Format character): | 0F |
| T1 (Historical character): | 'P' |
| T2 (Historical character): | 'o' |
| T3 (Historical character): | 'w' |
| T4 (Historical character): | 'e' |
| T5 (Historical character): | 'r' |
| T6 (Historical character): | 'O' |
| T7 (Historical character): | 'n' |
| T8 (Historical character): | 'C' |
| T9 (Historical character): | 'a' |
| T10 (Historical character): | 'r' |
| | |

T11 (Historical character): 'd'
T12 (Historical character): 'T'
T13 (Historical character): 'e'
T14 (Historical character): 's'
T15 (Historical character): 't'

Coding:

| Coding | 3B | 0F | 50 | 6F | 77 | 65 | 72 | 4F | 6E | 43 | 61 | 72 |
|--------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 64 | 54 | 65 | 74 | 75 | | | | | | | |

TERMINAL RESPONSE: POWER ON CARD 1.1.1

Logically:

Command details

Command number:

Command type: POWER ON CARD

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Card ATR

TS (Initial character): '3B' 0F T0 (Format character): 'P' T1 (Historical character): T2 (Historical character): 'o' T3 (Historical character): 'w' T4 (Historical character): 'e' 'r' T5 (Historical character): T6 (Historical character): 'O' T7 (Historical character): 'n' T8 (Historical character): 'C' T9 (Historical character): 'a' T10 (Historical character): 'r' T11 (Historical character): 'd' T12 (Historical character): 'T' 'e' T13 (Historical character): T14 (Historical character): 's' 't' T15 (Historical character):

| BER-TLV: | 81 | 03 | 01 | 31 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | A1 | 11 | 3B | 0F | 50 | 6F | 77 | 65 | 72 | 4F | 6E | 43 |
| | 61 | 72 | 64 | 54 | 65 | 74 | 75 | | | | | |

Expected Sequence 1.2 (POWER ON CARD, card reader 1, no ATR)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--------------------------|-------------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: POWER ON CARD | |
| | | 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | [Power on card reader 1] |
| | | POWER ON CARD 1.1.1 | |
| 4 | $ME \rightarrow SIM2$ | RESET CARD | [Perform electrical initialization] |
| 5 | $SIM2 \rightarrow ME$ | NO ATR | [No ATR] |
| 6 | $ME \to SIM$ | TERMINAL RESPONSE: POWER | [No ATR] |
| | | ON CARD 1.2.1 | |

TERMINAL RESPONSE: POWER ON CARD 1.2.1

Logically:

Command details

Command number:

Command type: POWER ON CARD

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: MultipleCard commands error

Additional Information: Card mute

Coding:

| BER-TLV: | 81 | 03 | 01 | 31 | 00 | 82 | 02 | 82 | 81 | 83 | 02 | 38 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 06 | | | | | | | | | | | |

Expected Sequence 1.3 (POWER ON CARD, card reader 1, no card inserted)

| Step | Direction | MESSAGE / Action | Comments |
|------|--------------|------------------------------|-------------------------------|
| 1 | SIM2 | SIM2 is removed from ME card | |
| 2 | $SIM \to ME$ | reader PROACTIVE COMMAND | |
| | | PENDING: POWER ON CARD | |
| | | 1.1.1 | |
| 3 | $ME \to SIM$ | FETCH | |
| 4 | $SIM \to ME$ | PROACTIVE COMMAND: | [Power on card reader 1] |
| | | POWER ON CARD 1.1.1 | |
| 5 | $ME \to SIM$ | TERMINAL RESPONSE: POWER | [Card removed or not present] |
| | | ON CARD 1.3.1 | |

TERMINAL RESPONSE: POWER ON CARD 1.3.1

Logically:

Command details

Command number: 1

Command type: POWER ON CARD

Command qualifier: "00"

Device identities

Source device: Card reader 0

Destination device: SIM

Result

General Result: MultipleCard commands error

Additional Information: Card removed or not present

Coding:

| BER-TLV: | 81 | 03 | 01 | 31 | 00 | 82 | 02 | 82 | 81 | 83 | 02 | 38 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 02 | | | | | | | | | | | |

27.22.4.19.1.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.3.

27.22.4.19.2 POWER ON CARD (detachable card reader)

27.22.4.19.2.1 Definition and applicability

See clause 3.2.2.

27.22.4.19.2.2 Conformance requirement

27.22.4.19.2.3 Test purpose

To verify that the ME starts a session with the additional card identified in the POWER ON CARD proactive SIM command, and successfully returns the Answer To Reset within the TERMINAL RESPONSE command send to the SIM.

27.22.4.19.2.4 Method of test

27.22.4.19.2.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The card reader shall be detached from the ME.

27.22.4.19.2.4.2 Procedure

Expected Sequence 2.1 (POWER ON CARD, card reader 1, no card reader attached)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|--------------------------|--------------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: POWER ON CARD | |
| | | 2.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | [Power on card reader 1] |
| | | POWER ON CARD 2.1.1 | |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: POWER | [Card reader removed or not present] |
| | | ON CARD 2.1.1 | |

PROACTIVE COMMAND: POWER ON CARD 2.1.1

Logically:

Command details

Command number:

Command type: POWER ON CARD

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card reader 1

Coding:

| BER-TLV: | D0 | 09 | 81 | 03 | 01 | 31 | 00 | 82 | 02 | 81 | 11 | |
|----------|----|----|----|----|----|----|----|----|----|----|----|--|
|----------|----|----|----|----|----|----|----|----|----|----|----|--|

TERMINAL RESPONSE: POWER ON CARD 2.1.1

Logically:

Command details

Command number: 1

Command type: POWER ON CARD

Command qualifier: "00"

Device identities

Source device: Card reader 0

Destination device: SIM

Result

General Result: MultipleCard commands error Additional Information: Card reader removed or not present

Coding:

| BER-TLV: | 81 | 03 | 01 | 31 | 00 | 82 | 02 | 82 | 81 | 83 | 02 | 38 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | | | | | | | | | | | |

27.22.4.19.2.5 Test requirement

The ME shall operate in the manner defined in expected sequence 2.1.

27.22.4.20 GET READER STATUS

27.22.4.20.1 GET READER STATUS (normal)

27.22.4.20.1.1 Definition and applicability

See clause 3.2.2.

27.22.4.20.1.2 Conformance requirement

The ME shall support the Proactive SIM: Get Card Reader Status facility as defined in:

• 3GPP TS 11.14 [15] clause 6.1, clause 5.2, clause 6.4.20, clause 6.6.20, clause 6.8, clause 12.6, clause 12.7, clause 12.33, clause 12.57 and annex H.

Additionally the ME shall support multiple card operation as defined in:

• 3GPP TS 11.14 [15] clause 6.4.19, clause 6.6.19, clause 6.4.18 and clause 6.6.18.

27.22.4.20.1.3 Test purpose

To verify that the ME sends starts a session with the additional card identified in the GET CARD READER STATUS proactive SIM command, and successfully returns information about all interfaces to additional card reader(s) in the TERMINAL RESPONSE command send to the SIM.

The ME-Manufacturer can assign the card reader identifier from 0 to 7.

This test applies for MEs with only one additional card reader.

In this particular case the card reader identifier 1 is chosen.

In this test case the second SIM-Simulator (SIM2) shall response with the ATR "3B 00".

27.22.4.20.1.4 Method of test

27.22.4.20.1.4.1 Initial conditions

The ME shall support the Proactive SIM: Get Card Reader Status (Card Reader Status) facility. The ME is connected to the SIM Simulator.

The ME card reader is connected to the second SIM Simulator (SIM2). Instead of the second SIM Simulator a card with different parameters may be used as SIM2 to execute these tests. In this case the SIM Simulator shall take into account the corresponding response data.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

If the ME supports a detachable card reader, the card reader shall be attached to the ME.

Prior to this test the ME shall have powered on the second SIM Simulator (SIM2).

27.22.4.20.1.4.2 Procedure

Expected Sequence 1.1 (GET CARD READER STATUS, card reader 1, card inserted, card powered)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|---|-------------------------------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: | |
| | | POWER ON CARD 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: POWER ON | [Power on card reader 1] |
| | | CARD 1.1.1 | |
| 4 | | RESET CARD | [Perform electrical initialization] |
| 5 | | ANSWER TO RESET 1.1.1 | [ATR] |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: POWER ON CARD 1.1.1 | [ATR] |
| 7 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: GET CARD READER STATUS 1.1.1 | |
| 8 | $ME \rightarrow SIM$ | FETCH | |
| 9 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: GET CARD READER STATUS 1.1.1 | [Get Card Reader Status] |
| 10 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: GET CARD READER STATUS 1.1.1a Or | [Successful] |
| | | TERMINAL RESPONSE: GET CARD READER STATUS 1.1.1b or | [Successful] |
| | | TERMINAL RESPONSE: GET CARD READER STATUS 1.1.1c | [Successful] |
| | | or TERMINAL RESPONSE: GET CARD READER STATUS 1.1.1d | [Successful] |

PROACTIVE COMMAND: POWER ON CARD 1.1.1

Logically:

Command details

Command number: 1

Command type: POWER ON CARD

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card reader 1

Coding:

| BER-TLV: | D0 | 09 | 81 | 03 | 01 | 31 | 00 | 82 | 02 | 81 | 11 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | | | | | | | | | | | |

ANSWER TO RESET 1.1.1

Logically:

TS (Initial character): '3B' TO (Format character): '00'

Coding:

Coding: 3B 00

TERMINAL RESPONSE: POWER ON CARD 1.1.1

Logically:

Command details

Command number: 1

Command type: POWER ON CARD

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Card ATR

TS (Initial character): '3B' T0 (Format character): '00'

Coding:

| BER-TLV: | 81 | 03 | 01 | 31 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | A1 | 02 | 3B | 00 | | | | | | | | |

PROACTIVE COMMAND: GET CARD READER STATUS 1.1.1

Logically:

Command details

Command number: 1

Command type: GET CARD READER STATUS

Command qualifier: Card reader status

Device identities

Source device: SIM
Destination device: ME

Coding:

| BER-TLV: | D0 | 09 | 81 | 03 | 01 | 33 | 00 | 82 | 02 | 81 | 82 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
|----------|----|----|----|----|----|----|----|----|----|----|----|

TERMINAL RESPONSE: GET CARD READER STATUS 1.1.1a

Logically:

Command details

Command number: 1

Command type: GET CARD READER STATUS

Command qualifier: Card reader status

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Card reader status

Identity of card reader: '01'
Card reader removable: 'No'
Card reader present: Yes
Card reader ID-1 size: 'Yes'
Card present in reader: Yes
Card powered: Yes

Coding:

| BER-TLV: | 81 | 03 | 01 | 33 | 00 | 82 | 02 | 82 | 81 | 83 | 01 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | A0 | 01 | F1 | | | | | | | |

TERMINAL RESPONSE: GET CARD READER STATUS 1.1.1b

Logically:

Command details

Command number: 1

Command type: GET CARD READER STATUS

Command qualifier: Card reader status

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Card reader status

Identity of card reader: '01'
Card reader removable: 'No'
Card reader present: Yes
Card reader ID-1 size: 'No'
Card present in reader: Yes
Card powered: Yes

Coding:

| BER-TLV: | 81 | 03 | 01 | 33 | 00 | 82 | 02 | 82 | 81 | 83 | 01 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | A0 | 01 | D1 | | | | | | | |

TERMINAL RESPONSE: GET CARD READER STATUS 1.1.1c

Logically:

Command details

Command number: 1

Command type: GET CARD READER STATUS

Command qualifier: Card reader status

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Card reader status

Identity of card reader: '01' Card reader removable: 'Yes' Card reader present: Yes
Card reader ID-1 size: 'Yes'
Card present in reader: Yes
Card powered: Yes

Coding:

| BER-TLV: | 81 | 03 | 01 | 33 | 00 | 82 | 02 | 82 | 81 | 83 | 01 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | A0 | 01 | F9 | | | | | | | |

TERMINAL RESPONSE: GET CARD READER STATUS 1.1.1d

Logically:

Command details

Command number: 1

Command type: GET CARD READER STATUS

Command qualifier: Card reader status

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Card reader status

Identity of card reader: '01'
Card reader removable: 'Yes'
Card reader present: Yes
Card reader ID-1 size: 'No'
Card present in reader: Yes
Card powered: Yes

| BER-TLV: | 81 | 03 | 01 | 33 | 00 | 82 | 02 | 82 | 81 | 83 | 01 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | A0 | 01 | D9 | | | | | | | |

Expected Sequence 1.2 (GET CARD READER STATUS, card reader 1, card inserted, card not powered)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|---|---------------------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: POWER OFF CARD 1.2.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: POWER OFF CARD 1.2.1 | [Power off card reader 1] |
| 4 | $ME \rightarrow SIM2$ | POWER OFF CARD | [Power off card reader 1] |
| 5 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: POWER OFF CARD 1.2.1 | [Successful] |
| 6 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: GET CARD READER STATUS 1.1.1 | |
| 7 | $ME \rightarrow SIM$ | FETCH | |
| 8 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: GET CARD READER STATUS 1.1.1 | [Get Card Reader Status] |
| 9 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: GET CARD READER STATUS 1.2.1a Or | [Successful] |
| | | TERMINAL RESPONSE: GET CARD READER STATUS 1.2.1b or | [Successful] |
| | | TERMINAL RESPONSE: GET CARD READER STATUS 1.2.1c Or | [Successful] |
| | | TERMINAL RESPONSE: GET CARD READER STATUS 1.2.1d | [Successful] |

PROACTIVE COMMAND: POWER OFF CARD 1.2.1

Logically:

Command details

Command number: 1

Command type: POWER OFF CARD

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card reader 1

Coding:

| BER-TLV: | D0 | 09 | 81 | 03 | 01 | 32 | 00 | 82 | 02 | 81 | 11 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
|----------|----|----|----|----|----|----|----|----|----|----|----|

TERMINAL RESPONSE: POWER OFF CARD 1.2.1

Logically:

Command details

Command number: 1

Command type: POWER OFF CARD

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 32 | 00 | 82 | 02 | 82 | 81 | 83 | 01 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | | | | | | | | | | |

TERMINAL RESPONSE: GET CARD READER STATUS 1.2.1a

Logically:

Command details

Command number:

Command type: GET CARD READER STATUS

Command qualifier: Card reader status

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Card reader status

Identity of card reader: '01'
Card reader removable: 'No'
Card reader present: Yes
Card reader ID-1 size: 'Yes'
Card present in reader: Yes
Card powered: No

Coding:

| BER-TLV: | 81 | 03 | 01 | 33 | 00 | 82 | 02 | 82 | 81 | 83 | 01 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | A0 | 01 | 71 | | | | | | | |

TERMINAL RESPONSE: GET CARD READER STATUS 1.2.1b

Logically:

Command details

Command number: 1

Command type: GET CARD READER STATUS

Command qualifier: Card reader status

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Card reader status

Identity of card reader: '01'
Card reader removable: 'No'
Card reader present: Yes
Card reader ID-1 size: 'No'
Card present in reader: Yes
Card powered: No

Coding:

| BER-TLV: | 81 | 03 | 01 | 33 | 00 | 82 | 02 | 82 | 81 | 83 | 01 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | A0 | 01 | 51 | | | | | | | |

TERMINAL RESPONSE: GET CARD READER STATUS 1.2.1c

Logically:

Command details

Command number:

Command type: GET CARD READER STATUS

Command qualifier: Card reader status

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Card reader status

Identity of card reader: '01'
Card reader removable: 'Yes'
Card reader present: Yes
Card reader ID-1 size: 'Yes'
Card present in reader: Yes
Card powered: No

Coding:

| BER-TLV: | 81 | 03 | 01 | 33 | 00 | 82 | 02 | 82 | 81 | 83 | 01 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | A0 | 01 | 79 | | | | | | | |

TERMINAL RESPONSE: GET CARD READER STATUS 1.2.1d

Logically:

Command details

Command number: 1

Command type: GET CARD READER STATUS

Command qualifier: Card reader status

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Card reader status

Identity of card reader: '01'
Card reader removable: 'Yes'
Card reader present: Yes
Card reader ID-1 size: 'No'
Card present in reader: Yes
Card powered: No

| BER-TLV: | 81 | 03 | 01 | 33 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | ĺ |
|----------|----|----|----|----|----|----|----|----|----|----|----|---|
| | 00 | A0 | 01 | 59 | | | | | | | | l |

Expected Sequence 1.3 (GET CARD READER STATUS, card reader 1, card not present)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|-------------------------------------|--------------------------|
| 1 | SIM2 | SIM2 is removed from ME card reader | |
| 2 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: | |
| | | GET CARD READER STATUS 1.1.1 | |
| 3 | $ME \rightarrow SIM$ | FETCH | |
| 4 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: GET CARD | [Get Card Reader Status] |
| | | READER STATUS 1.1.1 | |
| 5 | | TERMINAL RESPONSE: GET CARD | [Successful] |
| | | READER STATUS 1.3.1a | |
| | | or | |
| | | TERMINAL RESPONSE: GET CARD | [Successful] |
| | | READER STATUS 1.3.1b | |
| | | or | |
| | | TERMINAL RESPONSE: GET CARD | [Successful] |
| | | READER STATUS 1.3.1c | |
| | | or | |
| | | TERMINAL RESPONSE: GET CARD | |
| | | READER STATUS 1.3.1d | [Successful] |

TERMINAL RESPONSE: GET CARD READER STATUS 1.3.1a

Logically:

Command details

Command number:

Command type: GET CARD READER STATUS

Command qualifier: Card reader status

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Card reader status

Identity of card reader: '1'
Card reader removable: 'No'
Card reader present: Yes
Card reader ID-1 size: 'Yes'
Card present in reader: No
Card powered: No

Coding:

| BER-TLV: | 81 | 03 | 01 | 33 | 00 | 82 | 02 | 82 | 81 | 83 | 01 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | A0 | 01 | 31 | | | | | | | |

TERMINAL RESPONSE: GET CARD READER STATUS 1.3.1b

Logically:

Command details

Command number: 1

Command type: GET CARD READER STATUS

Command qualifier: card reader status

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Card reader status

Identity of card reader: '1'

Card reader removable: 'No'
Card reader present: Yes
Card reader ID-1 size: 'No'
Card present in reader: No
Card powered: No

Coding:

| BER-TLV: | 81 | 03 | 01 | 33 | 00 | 82 | 02 | 82 | 81 | 83 | 01 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | A0 | 01 | 11 | | | | | | | |

TERMINAL RESPONSE: GET CARD READER STATUS 1.3.1c

Logically:

Command details

Command number: 1

Command type: GET CARD READER STATUS

Command qualifier: card reader status

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Card reader status

Identity of card reader: '1'
Card reader removable: 'Yes'
Card reader present: Yes
Card reader ID-1 size: 'Yes'
Card present in reader: No
Card powered: No

Coding:

| BER-TLV: | 81 | 03 | 01 | 33 | 00 | 82 | 02 | 82 | 81 | 83 | 01 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | A0 | 01 | 39 | | | | | | | |

TERMINAL RESPONSE: GET CARD READER STATUS 1.3.1d

Logically:

Command details

Command number: 1

Command type: GET CARD READER STATUS

Command qualifier: Card reader status

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Card reader status

Identity of card reader: '1'
Card reader removable: 'Yes'
Card reader present: Yes
Card reader ID-1 size: 'No'
Card present in reader: No
Card powered: No

Coding:

| BER-TLV: | 81 | 03 | 01 | 33 | 00 | 82 | 02 | 82 | 81 | 83 | 01 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | A0 | 01 | 19 | | | | | | | |

27.22.4.20.1.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.3.

27.22.4.20.2 GET CARD READER STATUS (detachable card reader)

27.22.4.20.2.1 Definition and applicability

See clause 3.2.2.

27.22.4.20.2.2 Conformance requirement

Void.

27.22.4.20.2.3 Test purpose

To verify that the ME closes a session with the additional card identified in the GET CARD READER STATUS proactive SIM command, and successfully returns result in the TERMINAL RESPONSE command send to the SIM.

27.22.4.20.2.4 Method of test

27.22.4.20.2.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

Prior to this test the ME shall have powered on the second SIM Simulator (SIM2).

The card reader shall be detached from the ME.

27.22.4.20.2.4.2 Procedure

Expected Sequence 2.1 (GET CARD READER STATUS, no card reader attached)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|-------------------------------------|--------------------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: GET CARD | |
| | | READER STATUS 2.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: GET CARD READER | [Get Card Reader Status] |
| | | STATUS 2.1.1 | |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: GET CARD READER | [Successful] |
| | | STATUS 2.1.1a | |
| | | or | |
| | | TERMINAL RESPONSE: GET CARD READER | [Successful] |
| | | STATUS 2.1.1b | |

PROACTIVE COMMAND: GET CARD READER STATUS 2.1.1

Logically:

Command details

Command number: 1

Command type: GET CARD READER STATUS

Command qualifier: Card Reader Status

Device identities

Source device: SIM
Destination device: ME

Coding:

BER-TLV: D0 09 81 03 01 33 00 82 02 81 82

TERMINAL RESPONSE: GET CARD READER STATUS 2.1.1a

Logically:

Command details

Command number: 1

Command type: GET CARD READER STATUS

Command qualifier: Card reader status

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Card reader status

Identity of card reader: 01
Card reader removable: Yes
Card reader present: No
Card reader ID-1 size: Yes
Card present in reader: No
Card powered: No

Coding:

| BER-TLV: | 81 | 03 | 01 | 33 | 00 | 82 | 02 | 82 | 81 | 83 | 01 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | A0 | 01 | 29 | | | | | | | |

TERMINAL RESPONSE: GET CARD READER STATUS 2.1.1b

Logically:

Command details

Command number: 1

Command type: GET CARD READER STATUS

Command qualifier: Card reader status

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Card reader status

Identity of card reader: 01
Card reader removable: Yes
Card reader present: No
Card reader ID-1 size: No
Card present in reader: No
Card powered: No

| BER-TLV: | 81 | 03 | 01 | 33 | 00 | 82 | 02 | 82 | 81 | 83 | 01 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | A0 | 01 | 09 | | | | | | | |

27.22.4.20.2.5 Test requirement

The ME shall operate in the manner defined in expected sequence 2.1.

27.22.4.21 TIMER MANAGEMENT and ENVELOPE TIMER EXPIRATION

27.22.4.21.1 TIMER MANAGEMENT (normal)

27.22.4.21.1.1 Definition and applicability

See clause 3.2.2.

27.22.4.21.1.2 Conformance Requirement

The ME shall support the TIMER MANAGEMENT as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.21, clause 6.8, clause 12.6, clause 12.7, clause 12.37 and clause 12.38.

27.22.4.21.1.3 Test purpose

To verify that the ME manages correctly its internal timers, start a timer, deactivate a timer or return the current value of a timer according to the Timer Identifier defined in the TIMER MANAGEMENT proactive SIM command.

27.22.4.21.1.4 Method of Test

27.22.4.21.1.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

27.22.4.21.1.4.2 Procedure

Expected Sequence 1.1 (TIMER MANAGEMENT, start timer 1 several times, get the current value of the timer and deactivate the timer successfully)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|--|--|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: TIMER | |
| | | MANAGEMENT 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | | PROACTIVE COMMAND: | [start timer 1] |
| | | TIMER MANAGEMENT 1.1.1 | |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: TIMER | [command performed successfully] |
| _ | | MANAGEMENT 1.1.1 | |
| 5 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | After 1 minute following reception of Terminal |
| | | PENDING: TIMER | Response |
| | NAT 0184 | MANAGEMENT 1.1.2 | |
| 6 | $ME \rightarrow SIM$ | FETCH | factorial of the and 1 |
| 7 | | PROACTIVE COMMAND: | [ask value of timer 1] |
| 8 | NAT OINA | TIMER MANAGEMENT 1.1.2 TERMINAL RESPONSE: TIMER | [sammand parformed suppositully] |
| 0 | $ME \rightarrow SIM$ | MANAGEMENT 1.1.2 | [command performed successfully] |
| 9 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | Before timer expires! |
| 9 | SIIVI - IVIE | PENDING: TIMER | Delote titlet expires: |
| | | MANAGEMENT 1.1.3 | |
| 10 | $ME \rightarrow SIM$ | FETCH | |
| 11 | IVIL 7 OIIVI | PROACTIVE COMMAND: | [reinitialize timer 1] |
| 1 | | TIMER MANAGEMENT 1.1.3 | |
| 12 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: TIMER | [command performed successfully] |
| | | MANAGEMENT 1.1.3 | , |
| 13 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | After 30 s following reception of the Terminal |
| | | PENDING: TIMER | Response |
| | | MANAGEMENT 1.1.4 | |
| 14 | $ME \rightarrow SIM$ | FETCH | |
| 15 | | PROACTIVE COMMAND: | [deactivate timer 1] |
| | | TIMER MANAGEMENT 1.1.4 | |
| 16 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: TIMER | [command performed successfully] |
| | | MANAGEMENT 1.1.4 | |

PROACTIVE COMMAND: TIMER MANAGEMENT 1.1.1

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 1

Timer value

Value of timer: 5 min

| BER-TLV: | D0 | 11 | 81 | 03 | 01 | 27 | 00 | 82 | 02 | 81 | 82 | A4 | |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|--|
| | 01 | 01 | A5 | 03 | 00 | 50 | 00 | | | | | | |

PROACTIVE COMMAND: TIMER MANAGEMENT 1.1.2

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get the current value of the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 1

Coding:

| BER-TLV: | D0 | 0C | 81 | 03 | 01 | 27 | 02 | 82 | 02 | 81 | 82 | A4 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | 01 | | | | | | | | | | |

PROACTIVE COMMAND: TIMER MANAGEMENT 1.1.3

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 1

Timer value

Value of timer: 1min 30s

Coding:

| BER-TLV: | D0 | 11 | 81 | 03 | 01 | 27 | 00 | 82 | 02 | 81 | 82 | A4 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | 01 | A5 | 03 | 00 | 10 | 03 | | | | | |

PROACTIVE COMMAND: TIMER MANAGEMENT 1.1.4

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT deactivate the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 1

| BER-TLV: | D0 | 0C | 81 | 03 | 01 | 27 | 01 | 82 | 02 | 81 | 82 | A4 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| ' | 01 | 01 | | | | | | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.1.1 and 1.1.3

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier

Identifier of timer: 1

Coding::

| BER-TLV: | 81 | 03 | 01 | 27 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | A4 | 01 | 01 | | | | | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.1.2

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get the current value of the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier

Identifier of timer: 1

Timer value

Value of timer: value < to the timer value of command 1.1.1

Coding:

| BER-TLV: | 81 | 03 | 01 | 27 | 02 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | A4 | 01 | 01 | A5 | 03 | XX | XX | XX | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.1.4

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT Command qualifier: deactivate the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier

Identifier of timer: 1

Timer value

Value of timer: value < to the timer value of command 1.1.3

Coding:

| BER-TLV: | 81 | 03 | 01 | 27 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | A4 | 01 | 01 | A5 | 03 | XX | XX | XX | | | | |

Expected Sequence 1.2 (TIMER MANAGEMENT, start timer 2 several times, get the current value of the timer and deactivate the timer successfully)

| Step | Direction | MESSAGE / Action | Comments |
|------|---|---------------------------------------|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: TIMER | |
| | | MANAGEMENT 1.2.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | | PROACTIVE COMMAND: | [start timer 2] |
| | | TIMER MANAGEMENT 1.2.1 | |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: TIMER | [command performed successfully] |
| | | MANAGEMENT 1.2.1 | |
| 5 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | After 1 minute following reception of Terminal |
| | | PENDING: TIMER | Response |
| | | MANAGEMENT 1.2.2 | |
| 6 | $ME \to SIM$ | | |
| 7 | | PROACTIVE COMMAND: | [ask value of timer 2] |
| | 145 0114 | TIMER MANAGEMENT 1.2.2 | [some seed to see for war and some seeffully 1] |
| 8 | ME → SIM | TERMINAL RESPONSE: TIMER | [command performed successfully] |
| 9 | CIM . ME | MANAGEMENT 1.2.2 PROACTIVE COMMAND | Before timer expires! |
| 9 | SIIVI → IVIE | PENDING: TIMER | Delote titlet expires: |
| | | MANAGEMENT 1.2.3 | |
| 10 | $ME \rightarrow SIM$ | | |
| 11 | IVIL 7 OIIVI | PROACTIVE COMMAND: | [reinitialize timer 2] |
| | | TIMER MANAGEMENT 1.2.3 | |
| 12 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: TIMER | [command performed successfully] |
| | , | MANAGEMENT 1.2.3 | [,] |
| 13 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | After 10 seconds following reception of |
| | | PENDING: TIMER | Terminal Response |
| | | MANAGEMENT 1.2.4 | |
| 14 | $ME \to SIM$ | | |
| 15 | | PROACTIVE COMMAND: | [deactivate timer 2] |
| | | TIMER MANAGEMENT 1.2.4 | |
| 16 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: TIMER | [command performed successfully] |
| | | MANAGEMENT 1.2.4 | |

PROACTIVE COMMAND: TIMER MANAGEMENT 1.2.1

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 2

Timer value

Value of timer: 23 h 59 min 59 s

| BER-TLV: | D0 | 11 | 81 | 03 | 01 | 27 | 00 | 82 | 02 | 81 | 82 | A4 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | 02 | Α5 | 03 | 32 | 95 | 95 | | | | | |

PROACTIVE COMMAND: TIMER MANAGEMENT 1.2.2

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get the current value of the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 2

Coding:

| BER-TLV: | D0 | 0C | 81 | 03 | 01 | 27 | 02 | 82 | 02 | 81 | 82 | A4 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | 02 | | | | | | | | | | |

PROACTIVE COMMAND: TIMER MANAGEMENT 1.2.3

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 2

Timer value

Value of timer: 1 min 10 s

Coding:

| BER-TLV: | D0 | 11 | 81 | 03 | 01 | 27 | 00 | 82 | 02 | 81 | 82 | A4 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | 02 | A5 | 03 | 00 | 10 | 01 | | | | | |

PROACTIVE COMMAND: TIMER MANAGEMENT 1.2.4

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT deactivate the Timer

Device identities

Source device: SIM Destination device: ME

Timer identifier

Identifier of timer: 2

| BER-TLV: | D0 | 0C | 81 | 03 | 01 | 27 | 01 | 82 | 02 | 81 | 82 | A4 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | 02 | | | | | | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.2.1 and 1.2.3

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier

Identifier of timer: 2

Coding:

| BER-TLV: | 81 | 03 | 01 | 27 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | A4 | 01 | 02 | | | | | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.2.2

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get the current value of the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier

Identifier of timer: 2

Timer value

Value of timer: value < to the timer value of command 1.2.1

Coding:

| BER-TLV: | 81 | 03 | 01 | 27 | 02 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | A4 | 01 | 02 | A5 | 03 | XX | XX | XX | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.2.4

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT Command qualifier: deactivate the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier

Identifier of timer: 2

Timer value

Value of timer: value < to the timer value of command 1.2.3

Coding:

| BER-TLV: | 81 | 03 | 01 | 27 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | A4 | 01 | 02 | A5 | 03 | XX | XX | XX | | | | |

Expected Sequence 1.3 (TIMER MANAGEMENT, start timer 8 several times, get the current value of the timer and deactivate the timer successfully)

| Step | Direction | MESSAGE / Action | Comments |
|------|---|---|--|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: TIMER | |
| | | MANAGEMENT 1.3.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | | PROACTIVE COMMAND: | [start timer 8] |
| | | TIMER MANAGEMENT 1.3.1 | |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: TIMER | [command performed successfully] |
| _ | | MANAGEMENT 1.3.1 | |
| 5 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | After 1 minute following reception of Terminal |
| | | PENDING: TIMER | Response |
| | | MANAGEMENT 1.3.2 | |
| 6 | $ME \rightarrow SIM$ | FETCH | |
| 7 | | PROACTIVE COMMAND: | [ask value of timer 8] |
| 8 | NAT OINA | TIMER MANAGEMENT 1.3.2 | [command parformed augeografully] |
| 0 | INE → SIM | TERMINAL RESPONSE: TIMER MANAGEMENT 1.3.2 | [command performed successfully] |
| 9 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | Before timer expires! |
| 3 | SIIVI - IVIE | PENDING: TIMER | Delote titlet expires: |
| | | MANAGEMENT 1.3.3 | |
| 10 | $ME \rightarrow SIM$ | FETCH | |
| 11 | IVIL 7 OIIVI | PROACTIVE COMMAND: | [reinitialize timer 8] |
| 1 | | TIMER MANAGEMENT 1.3.3 | |
| 12 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: TIMER | [command performed successfully] |
| | , | MANAGEMENT 1.3.3 | [,] |
| 13 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | After 30 seconds following reception of |
| | | PENDING: TIMER | Terminal Response |
| | | MANAGEMENT 1.3.4 | |
| 14 | $ME \rightarrow SIM$ | FETCH | |
| 15 | | PROACTIVE COMMAND: | [deactivate timer 8] |
| | | TIMER MANAGEMENT 1.3.4 | |
| 16 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: TIMER | [command performed successfully] |
| | | MANAGEMENT 1.3.4 | |

PROACTIVE COMMAND: TIMER MANAGEMENT 1.3.1

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 8

Timer value

Value of timer: 20min

| BER-TLV: | D0 | 11 | 81 | 03 | 01 | 27 | 00 | 82 | 02 | 81 | 82 | A4 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | 08 | A5 | 03 | 00 | 02 | 00 | | | | | |

PROACTIVE COMMAND: TIMER MANAGEMENT 1.3.2

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get the current value of the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 8

Coding:

| BER-TLV: | D0 | 0C | 81 | 03 | 01 | 27 | 02 | 82 | 02 | 81 | 82 | A4 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| · | 01 | 08 | | | | | | | | | | |

PROACTIVE COMMAND: TIMER MANAGEMENT 1.3.3

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM Destination device: ME

Timer identifier

Identifier of timer: 8

Timer value

Value of timer: 01 h 00 min 00 s

Coding:

| BER-TLV: | D0 | 11 | 81 | 03 | 01 | 27 | 00 | 82 | 02 | 81 | 82 | A4 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | 08 | A5 | 03 | 10 | 00 | 00 | | | | | |

PROACTIVE COMMAND: TIMER MANAGEMENT 1.3.4

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT deactivate the Timer

Device identities

Source device: SIM Destination device: ME

Timer identifier

Identifier of timer: 8

| BER-TLV: | D0 | 0C | 81 | 03 | 01 | 27 | 01 | 82 | 02 | 81 | 82 | A4 | |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|--|
| | 01 | 08 | | | | | | | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.3.1 and 1.3.3

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier

Identifier of timer: 8

Coding:

| BER-TLV: | 81 | 03 | 01 | 27 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | A4 | 01 | 80 | | | | | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.3.2

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get the current value of the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

8

Timer identifier

Identifier of timer:

Timer value

Value of timer: value < to the timer value of command 1.3.1

Coding:

| BER-TLV: | 81 | 03 | 01 | 27 | 02 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | A4 | 01 | 80 | A5 | 03 | XX | XX | XX | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.3.4

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT Command qualifier: deactivate the Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier

Identifier of timer: 8

Timer value

Value of timer: value < to the timer value of command 1.3.3

Coding:

| BER-TLV: | 81 | 03 | 01 | 27 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | A4 | 01 | 08 | A5 | 03 | XX | XX | XX | | | | |

Expected Sequence1.4 (TIMER MANAGEMENT, try to get the current value of a timer which is not started: action in contradiction with the current timer state)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|--|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: TIMER | |
| 2 | $ME \rightarrow SIM$ | MANAGEMENT 1.4.1 | |
| 3 | IVI⊏ → OIIVI | PROACTIVE COMMAND: | [get current value from timer 1] |
| | | TIMER MANAGEMENT 1.4.1 | iger can sin value from anion ij |
| 4 | $ME \to SIM$ | TERMINAL RESPONSE: TIMER | [action in contradiction with the current timer |
| | | MANAGEMENT 1.4.1A | state] |
| | | Or TERMINIAL RESPONSE: TIMER | |
| | | TERMINAL RESPONSE: TIMER MANAGEMENT 1.4.1B | |
| 5 | $SIM \to MF$ | PROACTIVE COMMAND | |
| | | PENDING: TIMER | |
| | | MANAGEMENT 1.4.2 | |
| 6 | $ME \rightarrow SIM$ | FETCH | [not ourront value from times 0] |
| 7 | | PROACTIVE COMMAND: TIMER MANAGEMENT 1.4.2 | [get current value from timer 2] |
| 8 | $ME \to SIM$ | TERMINAL RESPONSE: TIMER | [action in contradiction with the current timer |
| | , 31111 | MANAGEMENT 1.4.2A | state] |
| | | or | |
| | | TERMINAL RESPONSE: TIMER MANAGEMENT 1.4.2B | |
| 9 | $SIM \to ME$ | | |
| - | / IVIL | PENDING: TIMER | |
| | | MANAGEMENT 1.4.3 | |
| 10 | $ME \to SIM$ | FETCH | [got ourrent value from the Co |
| 11 | | PROACTIVE COMMAND: TIMER MANAGEMENT 1.4.3 | [get current value from timer 3] |
| 12 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: TIMER | [action in contradiction with the current timer |
| | _ / 51101 | MANAGEMENT 1.4.3A | state] |
| | | or | |
| | | TERMINAL RESPONSE: TIMER | |
| 13 | $SIM \to ME$ | MANAGEMENT 1.4.3B PROACTIVE COMMAND | |
| . | / IVI⊑ | PENDING: TIMER | |
| | | MANAGEMENT 1.4.4 | |
| 14 | $ME \to SIM$ | FETCH | Front ourment value from C |
| 15 | | PROACTIVE COMMAND: TIMER MANAGEMENT 1.4.4 | [get current value from timer 4] |
| 16 | $ME \to SIM$ | TERMINAL RESPONSE: TIMER | [action in contradiction with the current timer |
| - | , 51111 | MANAGEMENT 1.4.4A | state] |
| | | or | |
| | | TERMINAL RESPONSE: TIMER MANAGEMENT 1.4.4B | |
| 17 | $SIM \to ME$ | PROACTIVE COMMAND | |
| '' | J.WI 7 IVIE | PENDING: TIMER | |
| | | MANAGEMENT 1.4.5 | |
| 18 | $ME \to SIM$ | FETCH | Front ourment vieles (, , , , , , , , , , , , , , , , , , |
| 19 | | PROACTIVE COMMAND: TIMER MANAGEMENT 1.4.5 | [get current value from timer 5] |
| 20 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: TIMER | [action in contradiction with the current timer |
| | / 51111 | MANAGEMENT 1.4.5A | state] |
| | | or | |
|] | | TERMINAL RESPONSE: TIMER | |
| 1 | | MANAGEMENT 1.4.5B | ı |

| Step | Direction | MESSAGE / Action | Comments |
|----------|----------------------|--|---|
| 21 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: TIMER | |
| | | MANAGEMENT 1.4.6 | |
| 22 | $ME \rightarrow SIM$ | FETCH | |
| 23 | | PROACTIVE COMMAND: | [get current value from timer 6] |
| | | TIMER MANAGEMENT 1.4.6 | |
| 24 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: TIMER | [action in contradiction with the current timer |
| | | MANAGEMENT 1.4.6A | state] |
| | | OF | |
| | | TERMINAL RESPONSE: TIMER MANAGEMENT 1.4.6B | |
| 25 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| 23 | SIIVI - IVIE | PENDING: TIMER | |
| | | MANAGEMENT 1.4.7 | |
| 26 | $ME \rightarrow SIM$ | FETCH | |
| 27 | 1012 / 01101 | PROACTIVE COMMAND: | [get current value from timer 7] |
| | | TIMER MANAGEMENT 1.4.7 | |
| 28 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: TIMER | [action in contradiction with the current timer |
| | | MANAGEMENT 1.4.7A | state] |
| | | or | |
| | | TERMINAL RESPONSE: TIMER | |
| | | MANAGEMENT 1.4.7B | |
| 29 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: TIMER | |
| 20 | NAT 0184 | MANAGEMENT 1.4.8 | |
| 30 31 | $ME \rightarrow SIM$ | FETCH PROACTIVE COMMAND: | [got ourrent value from timer 0] |
| 31 | | TIMER MANAGEMENT 1.4.8 | [get current value from timer 8] |
| 32 | ME → SIM | TERMINAL RESPONSE: TIMER | [action in contradiction with the current timer |
| 02 | IVIL -> SIIVI | MANAGEMENT 1.4.8A | state |
| | | or | |
| | | TERMINAL RESPONSE: TIMER | |
| | | MANAGEMENT 1.4.8B | |

PROACTIVE COMMAND: TIMER MANAGEMENT 1.4.1

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get the current value of the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 1

Coding:

| BER-TLV: | D0 | 0C | 81 | 03 | 01 | 27 | 02 | 82 | 02 | 81 | 82 | A4 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | 01 | | | | | | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.4.1A

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT
Command qualifier: get current value from the Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier

Identifier of timer: 1

Coding:

| BER-TLV: | 81 | 03 | 01 | 27 | 02 | 82 | 02 | 82 | 81 | 83 | 01 | 24 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | A4 | 01 | 01 | | | | | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.4.1B

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get current value from the Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Coding:

| BER-TLV: 8 | 81 03 | 01 | 27 | 02 | 82 | 02 | 82 | 81 | 83 | 01 | 24 |
|------------|-------|----|----|----|----|----|----|----|----|----|----|
|------------|-------|----|----|----|----|----|----|----|----|----|----|

PROACTIVE COMMAND: TIMER MANAGEMENT 1.4.2

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get the current value of the Timer

Device identities

Source device: SIM Destination device: ME

Timer identifier

Identifier of timer: 2

Coding:

| BER-TLV: | D0 | 0C | 81 | 03 | 01 | 27 | 02 | 82 | 02 | 81 | 82 | A4 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | 02 | | | | | | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.4.2A

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get current value from the Timer

Device identities

Source device: ME

Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier

Identifier of timer: 2

Coding:

| BER-TLV: | 81 | 03 | 01 | 27 | 02 | 82 | 02 | 82 | 81 | 83 | 01 | 24 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | A4 | 01 | 02 | | | | | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.4.2B

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get current value from the Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Coding:

| BER-TLV: | 81 | 03 | 01 | 27 | 02 | 82 | 02 | 82 | 81 | 83 | 01 | 24 | l |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|---|
|----------|----|----|----|----|----|----|----|----|----|----|----|----|---|

PROACTIVE COMMAND: TIMER MANAGEMENT 1.4.3

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get the current value of the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 3

Coding:

| BER-TLV: | D0 | 0C | 81 | 03 | 01 | 27 | 02 | 82 | 02 | 81 | 82 | A4 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | 03 | | | | | | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.4.3A

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get current value from the Timer

Device identities

Source device: ME Destination device: SIM Result

General Result: Action in contradiction with the current timer state

Timer identifier

Identifier of timer: 3

Coding:

| BER-TLV: | 81 | 03 | 01 | 27 | 02 | 82 | 02 | 82 | 81 | 83 | 01 | 24 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | A4 | 01 | 03 | | | | | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.4.3B

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get current value from the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Coding:

| BER-TI | .V: 81 | 03 | 01 | 27 | 02 | 82 | 02 | 82 | 81 | 83 | 01 | 24 | l |
|--------|--------|----|----|----|----|----|----|----|----|----|----|----|---|
|--------|--------|----|----|----|----|----|----|----|----|----|----|----|---|

PROACTIVE COMMAND: TIMER MANAGEMENT 1.4.4

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get the current value of the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 4

Coding:

| BER-TLV: | D0 | 0C | 81 | 03 | 01 | 27 | 02 | 82 | 02 | 81 | 82 | A4 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | 04 | | | | | | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.4.4A

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get current value from the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier

Identifier of timer: 4

Coding:

| BER-TLV: | 81 | 03 | 01 | 27 | 02 | 82 | 02 | 82 | 81 | 83 | 01 | 24 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| · | A4 | 01 | 04 | | | | | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.4.4B

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get current value from the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Coding:

| Е | BER-TLV: | 81 | 03 | 01 | 27 | 02 | 82 | 02 | 82 | 81 | 83 | 01 | 24 | l |
|---|----------|----|----|----|----|----|----|----|----|----|----|----|----|---|
|---|----------|----|----|----|----|----|----|----|----|----|----|----|----|---|

PROACTIVE COMMAND: TIMER MANAGEMENT 1.4.5

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get the current value of the Timer

Device identities

Source device: SIM Destination device: ME

Timer identifier

Identifier of timer: 5

Coding:

| BER-TLV: | D0 | 0C | 81 | 03 | 01 | 27 | 02 | 82 | 02 | 81 | 82 | A4 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | 05 | | | | | | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.4.5A

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get current value from the Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier

Identifier of timer: 5

Coding:

| BER-TLV: | 81 | 03 | 01 | 27 | 02 | 82 | 02 | 82 | 81 | 83 | 01 | 24 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | A4 | 01 | 05 | | | | | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.4.5B

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get current value from the Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Coding:

| BER-TLV: | 81 | 03 | 01 | 27 | 02 | 82 | 02 | 82 | 81 | 83 | 01 | 24 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|

PROACTIVE COMMAND: TIMER MANAGEMENT 1.4.6

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get the current value of the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 6

Coding:

| BER-TLV: | D0 | 0C | 81 | 03 | 01 | 27 | 02 | 82 | 02 | 81 | 82 | A4 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | 06 | | | | | | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.4.6A

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get current value from the Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier

Identifier of timer: 6

Coding:

| BER-TLV: | 81 | 03 | 01 | 27 | 02 | 82 | 02 | 82 | 81 | 83 | 01 | 24 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | A4 | 01 | 06 | | | | | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.4.6B

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get current value from the Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Coding:

| В | BER-TLV: | 81 | 03 | 01 | 27 | 02 | 82 | 02 | 82 | 81 | 83 | 01 | 24 | |
|---|----------|----|----|----|----|----|----|----|----|----|----|----|----|--|
|---|----------|----|----|----|----|----|----|----|----|----|----|----|----|--|

PROACTIVE COMMAND: TIMER MANAGEMENT 1.4.7

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get the current value of the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 7

Coding:

| BER-TLV: | D0 | 0C | 81 | 03 | 01 | 27 | 02 | 82 | 02 | 81 | 82 | A4 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | 07 | | | | | | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.4.7A

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get current value from the Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier

Identifier of timer: 7

Coding:

| BER-TLV: | 81 | 03 | 01 | 27 | 02 | 82 | 02 | 82 | 81 | 83 | 01 | 24 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | A4 | 01 | 07 | | | | | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.4.7B

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get current value from the Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Coding:

| BER-TLV: | 81 | 03 | 01 | 27 | 02 | 82 | 02 | 82 | 81 | 83 | 01 | 24 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | | | | | | | | | | | | |

PROACTIVE COMMAND: TIMER MANAGEMENT 1.4.8

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get the current value of the Timer

Device identities

Source device: SIM Destination device: ME

Timer identifier

Identifier of timer: 8

Coding:

| BER-TLV: | D0 | 0C | 81 | 03 | 01 | 27 | 02 | 82 | 02 | 81 | 82 | A4 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | 80 | | | | | | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.4.8A

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get current value from the Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier

Identifier of timer: 8

| BER-TLV: | 81 | 03 | 01 | 27 | 02 | 82 | 02 | 82 | 81 | 83 | 01 | 24 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | A4 | 01 | 08 | | | | | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.4.8B

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get current value from the Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Coding:

| BER-TLV: | 81 | 03 | 01 | 27 | 02 | 82 | 02 | 82 | 81 | 83 | 01 | 24 | l |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|---|
|----------|----|----|----|----|----|----|----|----|----|----|----|----|---|

Expected Sequence1.5 (TIMER MANAGEMENT, try to deactivate a timer which is not started: action in contradiction with the current timer state)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|---|---|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: TIMER | |
| | | MANAGEMENT 1.5.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | | PROACTIVE COMMAND: | [deactivate timer 1] |
| | | TIMER MANAGEMENT 1.5.1 | |
| 4 | $ME \rightarrow SIM$ | | [action in contradiction with the current timer |
| | | MANAGEMENT 1.5.1A | state] |
| | | or ITERMINAL RESPONSE: TIMER | |
| | | MANAGEMENT 1.5.1B | |
| 5 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | OIIVI 7 IVIE | PENDING: TIMER | |
| | | MANAGEMENT 1.5.2 | |
| 6 | $ME \rightarrow SIM$ | FETCH | |
| 7 | | PROACTIVE COMMAND: | [deactivate timer 2] |
| | | TIMER MANAGEMENT 1.5.2 | |
| 8 | $ME \rightarrow SIM$ | | [action in contradiction with the current timer |
| | | MANAGEMENT 1.5.2A | state] |
| | | OF | |
| | | TERMINAL RESPONSE: TIMER IMANAGEMENT 1.5.2B | |
| 9 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: TIMER | |
| | | MANAGEMENT 1.5.3 | |
| 10 | $ME \rightarrow SIM$ | FETCH | |
| 11 | | PROACTIVE COMMAND: | [deactivate timer 3] |
| | | TIMER MANAGEMENT 1.5.3 | |
| 12 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: TIMER | [action in contradiction with the current timer |
| | | MANAGEMENT 1.5.3A | state] |
| | | or TERMINAL RESPONSE: TIMER | |
| | | MANAGEMENT 1.5.3B | |
| 13 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | CIIVI / IVIL | PENDING: TIMER | |
| | | MANAGEMENT 1.5.4 | |
| 14 | $ME \rightarrow SIM$ | FETCH | |
| • | • | • | • |

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|--|---|
| 15 | | PROACTIVE COMMAND: | [deactivate timer 4] |
| | | TIMER MANAGEMENT 1.5.4 | |
| 16 | $ME \to SIM$ | TERMINAL RESPONSE: TIMER | [action in contradiction with the current timer |
| | | MANAGEMENT 1.5.4A | state] |
| | | Or | |
| | | TERMINAL RESPONSE: TIMER | |
| 17 | $SIM \rightarrow ME$ | MANAGEMENT 1.5.4B PROACTIVE COMMAND | |
| '' | Olivi IVIC | PENDING: TIMER | |
| | | MANAGEMENT 1.5.5 | |
| 18 | $ME \to SIM$ | FETCH | |
| 19 | | PROACTIVE COMMAND: | [deactivate timer 5] |
| | | TIMER MANAGEMENT 1.5.5 | |
| 20 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: TIMER | [action in contradiction with the current timer |
| | | MANAGEMENT 1.5.5A | state] |
| | | or TERMINAL RESPONSE: TIMER | |
| | | MANAGEMENT 1.5.5B | |
| 21 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: TIMER | |
| | | MANAGEMENT 1.5.6 | |
| 22 | $ME \to SIM$ | | |
| 23 | | PROACTIVE COMMAND: | [deactivate timer 6] |
| 24 | $ME \rightarrow SIM$ | TIMER MANAGEMENT 1.5.6 TERMINAL RESPONSE: TIMER | [action in contradiction with the current timer |
| | IVIL -> SIIVI | MANAGEMENT 1.5.6A | state |
| | | or | [] |
| | | TERMINAL RESPONSE: TIMER | |
| | | MANAGEMENT 1.5.6B | |
| 25 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: TIMER MANAGEMENT 1.5.7 | |
| 26 | $ME \rightarrow SIM$ | | |
| 27 | IVIL -> SIIVI | PROACTIVE COMMAND: | [deactivate timer 7] |
| | | TIMER MANAGEMENT 1.5.7 | [Laster Action 1] |
| 28 | $ME \to SIM$ | TERMINAL RESPONSE: TIMER | [action in contradiction with the current timer |
| | | MANAGEMENT 1.5.7A | state] |
| | | or | |
| | | TERMINAL RESPONSE: TIMER | |
| 29 | QIM . ME | MANAGEMENT 1.5.7B PROACTIVE COMMAND | |
| 23 | JIIVI → IVIE | PENDING: TIMER | |
| | | MANAGEMENT 1.5.8 | |
| 30 | $ME \to SIM$ | FETCH | |
| 31 | | PROACTIVE COMMAND: | [deactivate timer 8] |
| | | TIMER MANAGEMENT 1.5.8 | |
| 32 | $ME \to SIM$ | TERMINAL RESPONSE: TIMER | [action in contradiction with the current timer |
| | | MANAGEMENT 1.5.8A | state] |
| | | or TERMINAL RESPONSE: TIMER | |
| | | MANAGEMENT 1.5.8B | |
| | | | I |

PROACTIVE COMMAND: TIMER MANAGEMENT 1.5.1

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT Command qualifier: deactivate the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 1

Coding:

| BER-TLV: | D0 | 0C | 81 | 03 | 01 | 27 | 01 | 82 | 02 | 81 | 82 | A4 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | 01 | | | | | | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.5.1A

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: Deactivate Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier

Identifier of timer: 1

Coding:

| BER-TLV: | 81 | 03 | 01 | 27 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 24 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | A4 | 01 | 01 | | | | | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.5.1B

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: Deactivate Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Coding:

BER-TLV: 81 03 01 27 01 82 02 82 81 83 01 24

PROACTIVE COMMAND: TIMER MANAGEMENT 1.5.2

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT Command qualifier: deactivate the Timer

Device identities

Source device: SIM Destination device: ME

Timer identifier

Identifier of timer: 2

Coding:

| BER-TLV: | D0 | 0C | 81 | 03 | 01 | 27 | 01 | 82 | 02 | 81 | 82 | A4 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | 02 | | | | | | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.5.2A

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT

Command qualifier: Deactivate Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier

Identifier of timer: 2

Coding:

| BER-TLV: | 81 | 03 | 01 | 27 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 24 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | A4 | 01 | 02 | | | | | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.5.2B

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: Deactivate Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Coding:

BER-TLV: 81 03 01 27 01 82 02 82 81 83 01 24

PROACTIVE COMMAND3: TIMER MANAGEMENT 1.5.3

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT deactivate the Timer

Device identities

Source device: SIM Destination device: ME

Timer identifier

Identifier of timer: 3

| BER-TLV: | D0 | 0C | 81 | 03 | 01 | 27 | 01 | 82 | 02 | 81 | 82 | A4 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | 03 | | | | | | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.5.3A

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: Deactivate Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier

Identifier of timer: 3

Coding:

| BER-TLV: | 81 | 03 | 01 | 27 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 24 |
|---------------------------------------|----|----|----|----|----|----|----|----|----|----|----|----|
| · · · · · · · · · · · · · · · · · · · | A4 | 01 | 03 | | | | | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.5.3B

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: Deactivate Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Coding:

BER-TLV: 81 03 01 27 01 82 02 82 81 83 01 24

PROACTIVE COMMAND: TIMER MANAGEMENT 1.5.4

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT deactivate the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 4

| BER-TLV: | D0 | 0C | 81 | 03 | 01 | 27 | 01 | 82 | 02 | 81 | 82 | A4 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| <u> </u> | 01 | 04 | | | | | | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.5.4A

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT

Command qualifier: Deactivate Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier

Identifier of timer: 4

Coding:

| BER-TLV: | 81 | 03 | 01 | 27 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 24 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | A4 | 01 | 04 | | | | | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.5.4B

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: Deactivate Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Coding:

BER-TLV: 81 03 01 27 01 82 02 82 81 83 01 24

PROACTIVE COMMAND: TIMER MANAGEMENT 1.5.5

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT deactivate the Timer

Device identities

Source device: SIM Destination device: ME

Timer identifier

Identifier of timer: 5

| BER-TLV: | D0 | 0C | 81 | 03 | 01 | 27 | 01 | 82 | 02 | 81 | 82 | A4 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| - | 01 | 05 | | | | | | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.5.5A

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: Deactivate Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier

Identifier of timer: 5

Coding:

| BER-TLV: | 81 | 03 | 01 | 27 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 24 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | A4 | 01 | 05 | | | | | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.5.5B

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT

Command qualifier: Deactivate Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Coding:

BER-TLV: 81 03 01 27 01 82 02 82 81 83 01 24

PROACTIVE COMMAND: TIMER MANAGEMENT 1.5.6

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT deactivate the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 6

| BER-TLV: | D0 | 0C | 81 | 03 | 01 | 27 | 01 | 82 | 02 | 81 | 82 | A4 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | 06 | | | | | | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.5.6A

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: Deactivate Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier

Identifier of timer: 6

Coding:

| BER-TLV: | 81 | 03 | 01 | 27 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 24 |
|---------------------------------------|----|----|----|----|----|----|----|----|----|----|----|----|
| · · · · · · · · · · · · · · · · · · · | A4 | 01 | 06 | | | | | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.5.6B

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: Deactivate Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Coding:

BER-TLV: 81 03 01 27 01 82 02 82 81 83 01 24

PROACTIVE COMMAND: TIMER MANAGEMENT 1.5.7

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT deactivate the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 7

| BER-TLV: | D0 | 0C | 81 | 03 | 01 | 27 | 01 | 82 | 02 | 81 | 82 | A4 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | 07 | | | | | | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.5.7A

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT

Command qualifier: Deactivate Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier

Identifier of timer: 7

Coding:

| BER-TLV: | 81 | 03 | 01 | 27 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 24 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | A4 | 01 | 07 | | | | | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.5.7B

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: Deactivate Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Coding:

| BE | R-TLV: | 81 | 03 | 01 | 27 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 24 | ١ |
|----|--------|----|----|----|----|----|----|----|----|----|----|----|----|---|
|----|--------|----|----|----|----|----|----|----|----|----|----|----|----|---|

PROACTIVE COMMAND: TIMER MANAGEMENT 1.5.8

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT deactivate the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 8

| BER-TLV: | D0 | 0C | 81 | 03 | 01 | 27 | 01 | 82 | 02 | 81 | 82 | A4 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | 08 | | | | | | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.5.8A

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: Deactivate Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier

Identifier of timer: 8

Coding:

| BER-TLV: | 81 | 03 | 01 | 27 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 24 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | A4 | 01 | 08 | | | | | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.5.8B

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: Deactivate Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

| BER-TLV: | 81 | 03 | 01 | 27 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 24 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | | | | | | | | | | | | |

Expected Sequence 1.6 (TIMER MANAGEMENT, start 8 timers successfully)

| Step | Direction | MESSAGE / Action | Comments |
|----------|----------------------------|--|----------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: TIMER MANAGEMENT 1.6.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | , 0,,,,, | PROACTIVE COMMAND: | [timer 1] |
| | | TIMER MANAGEMENT 1.6.1 | |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: TIMER | [command performed successfully] |
| 5 | $SIM \to ME$ | MANAGEMENT 1.6.1 PROACTIVE COMMAND | |
| | O / IVIL | PENDING: TIMER | |
| | | MANAGEMENT 1.6.2 | |
| 6 7 | $ME \rightarrow SIM$ | PROACTIVE COMMAND: | [timor 2] |
| ' | | PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.2 | [timer 2] |
| 8 | $ME \to SIM$ | TERMINAL RESPONSE: TIMER | [command performed successfully] |
| | 0114 | MANAGEMENT 1.6.2 | |
| 9 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: TIMER | |
| | | MANAGEMENT 1.6.3 | |
| 10 | $ME \to SIM$ | FETCH | |
| 11 | | PROACTIVE COMMAND: | [timer 3] |
| 12 | $ME \to SIM$ | TIMER MANAGEMENT 1.6.3 TERMINAL RESPONSE: TIMER | [command performed successfully] |
| '- | IVIL -> SIIVI | MANAGEMENT 1.6.3 | [command performed adocessially] |
| 13 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: TIMER | |
| 14 | $ME \rightarrow SIM$ | MANAGEMENT 1.6.4 FETCH | |
| 15 | / Olivi | PROACTIVE COMMAND: | [timer 4] |
| | | TIMER MANAGEMENT 1.6.4 | |
| 16 | $ME \to SIM$ | TERMINAL RESPONSE: TIMER | [command performed successfully] |
| 17 | $SIM \to ME$ | MANAGEMENT 1.6.4 PROACTIVE COMMAND | |
| '' | O / IVIL | PENDING: TIMER | |
| 10 | | MANAGEMENT 1.6.5 | |
| 18 19 | $ME \rightarrow SIM$ | FETCH PROACTIVE COMMAND: | [timer 5] |
| 19 | | TIMER MANAGEMENT 1.6.5 | [timor o] |
| 20 | $ME \to SIM$ | TERMINAL RESPONSE: TIMER | [command performed successfully] |
| 24 | CINA . NAT | MANAGEMENT 1.6.5 PROACTIVE COMMAND | |
| 21 | $SIM \rightarrow ME$ | PENDING: TIMER | |
| | | MANAGEMENT 1.6.6 | |
| 22 | $\text{ME} \to \text{SIM}$ | FETCH | F: 0 |
| 23 | | PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.6 | [timer 6] |
| 24 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: TIMER | [command performed successfully] |
| | | MANAGEMENT 1.6.6 | , |
| 25 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: TIMER MANAGEMENT 1.6.7 | |
| 26 | $ME \to SIM$ | FETCH | |
| 27 | | PROACTIVE COMMAND: | [timer 7] |
| 20 | ME OIM | TIMER MANAGEMENT 1.6.7 | [command performed augment all a |
| 28 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.7 | [command performed successfully] |
| 29 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: TIMER | |
| 20 | ME OIM | MANAGEMENT 1.6.8 | |
| 30 31 | $ME \rightarrow SIM$ | FETCH PROACTIVE COMMAND: | [timer 8] |
| | | TIMER MANAGEMENT 1.6.8 | [|
| 32 | $ME \to SIM$ | | [command performed successfully] |
| | | MANAGEMENT 1.6.8 | |

PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.1

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 1

Timer value

Value of timer: 5 s

Coding:

| BER-TLV: | D0 | 11 | 81 | 03 | 01 | 27 | 00 | 82 | 02 | 81 | 82 | A4 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | 01 | A5 | 03 | 00 | 00 | 50 | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.1

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier

Identifier of timer: 1

Coding:

| BER-TLV: | 81 | 03 | 01 | 27 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | A4 | 01 | 01 | | | | | | | | | |

PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.2

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 2

Timer value

Value of timer: 5 s

Coding:

| BER-TLV: | D0 | 11 | 81 | 03 | 01 | 27 | 00 | 82 | 02 | 81 | 82 | A4 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | 02 | A5 | 03 | 00 | 00 | 50 | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.2

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier

Identifier of timer: 2

Coding:

| BER-TLV: | 81 | 03 | 01 | 27 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | A4 | 01 | 02 | | | | | | | | | |

PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.3

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM Destination device: ME

Timer identifier

Identifier of timer: 3

Timer value

Value of timer: 5 s

Coding:

| BER-TLV: | D0 | 11 | 81 | 03 | 01 | 27 | 00 | 82 | 02 | 81 | 82 | A4 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | 03 | A5 | 03 | 00 | 00 | 50 | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.3

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier

Identifier of timer: 3

Coding:

| BER-TLV: | 81 | 03 | 01 | 27 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | A4 | 01 | 03 | | | | | | | | | |

PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.4

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 4

Timer value

Value of timer: 5 s

Coding:

| BER-TLV: | D0 | 11 | 81 | 03 | 01 | 27 | 00 | 82 | 02 | 81 | 82 | A4 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | 04 | A5 | 03 | 00 | 00 | 50 | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.4

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier

Identifier of timer: 4

Coding:

| BER-TLV: | 81 | 03 | 01 | 27 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| ` | A4 | 01 | 04 | | | | | | | | | |

PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.5

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM Destination device: ME

Timer identifier

Identifier of timer: 5

Timer value

Value of timer: 5 s

Coding:

| BER-TLV: | D0 | 11 | 81 | 03 | 01 | 27 | 00 | 82 | 02 | 81 | 82 | A4 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | 05 | A5 | 03 | 00 | 00 | 50 | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.5

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier

Identifier of timer: 5

Coding:

| BER-TLV: | 81 | 03 | 01 | 27 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | A4 | 01 | 05 | | | | | | | | | |

PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.6

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 6

Timer value

Value of timer: 5 s

Coding:

| BER-TLV: | D0 | 11 | 81 | 03 | 01 | 27 | 00 | 82 | 02 | 81 | 82 | A4 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | 06 | A5 | 03 | 00 | 00 | 50 | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.6

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier

Identifier of timer: 6

Coding:

| BER-TLV: | 81 | 03 | 01 | 27 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | A4 | 01 | 06 | | | | | | | | | |

PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.7

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM Destination device: ME

Timer identifier

Identifier of timer: 7

Timer value

Value of timer: 5 s

Coding:

| BER-TLV: | D0 | 11 | 81 | 03 | 01 | 27 | 00 | 82 | 02 | 81 | 82 | A4 | |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|--|
| · | 01 | 07 | A5 | 03 | 00 | 00 | 50 | | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.7

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier

Identifier of timer: 7

| BER-TLV: | 81 | 03 | 01 | 27 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | Α4 | 01 | 07 | | | | | | | | | |

PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.8

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 8

Timer value

Value of timer: 5 s

Coding:

| BER-TLV: | D0 | 11 | 81 | 03 | 01 | 27 | 00 | 82 | 02 | 81 | 82 | A4 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | 80 | A5 | 03 | 00 | 00 | 50 | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.8

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result:

Command performed successfully

Timer identifier

Identifier of timer: 8

Coding:

| BER-TLV: | 81 | 03 | 01 | 27 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | A4 | 01 | 08 | | | | | | | | | |

27.22.4.21.1.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.6.

27.22.4.21.2 ENVELOPE TIMER EXPIRATION (normal)

27.22.4.21.2.1 Definition and applicability

See clause 3.2.2.

27.22.4.21.2.2 Conformance requirement

The ME shall support the ENVELOPE (TIMER EXPIRATION) command as defined in the following technical specifications:

• 3GPP TS 11.14 clause 4.10, clause 10.1 and clause 10.2.

The ME shall support the TIMER MANAGEMENT as defined in the following technical specifications:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.21, clause 6.8, clause 12.6, clause 12.7, clause 12.37 and clause 12.38.

27.22.4.21.2.3 Test purpose

To verify that the ME shall pass the identifier of the timer that has expired and its value using the ENVELOPE (TIMER EXPIRATION) command, when a timer previously started in a TIMER MANAGEMENT proactive command expires.

27.22.4.21.2.4 Method of test

27.22.4.21.2.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The timer 1 is not started.

When the SIM is busy when the envelope TIMER EXPIRATION is sent, either the ME retries periodically to send the envelope or it waits for a status not indicating busy.

27.22.4.21.2.4.2 Procedure

Expected Sequence 2.1 (TIMER EXPIRATION, pending proactive SIM command)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|------------------------------------|-----------------------------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: TIMER | |
| | | MANAGEMENT 2.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | | PROACTIVE COMMAND: TIMER | [timer 1] |
| | | MANAGEMENT 2.1.1 | |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: TIMER | [command performed successfully] |
| | | MANAGEMENT 2.1.1 | |
| 5 | $ME \rightarrow SIM$ | ENVELOPE: TIMER EXPIRATION | |
| | | 2.1.1 | |
| 6 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | [response to envelope is "91 xx"] |
| | | PENDING: MORE TIME X.1(or an | |
| | | other SAT command tested before | |
| | | to ensure it is properly supported | |
| | | by the mobile). | |
| 7 | $ME \rightarrow SIM$ | FETCH | |

PROACTIVE COMMAND: TIMER MANAGEMENT 2.1.1

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM Destination device: ME

Timer identifier

Identifier of timer:

Timer value

Value of timer: 0 h 0 min 10 s

| BER-TLV: | D0 | 11 | 81 | 03 | 01 | 27 | 00 | 82 | 02 | 81 | 82 | A4 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | 01 | A5 | 03 | 00 | 00 | 01 | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 2.1.1

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier

Identifier of timer: 1

Coding:

| BER-TLV: | 81 | 03 | 01 | 27 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | A4 | 01 | 01 | | | | | | | | | |

ENVELOPE: TIMER EXPIRATION 2.1.1

Logically:

Device identities

Source device: ME Destination device: SIM

Timer identifier

Timer 1 Timer value

 $\begin{array}{lll} \mbox{Hour:} & \mbox{'00'} \\ \mbox{Minute:} & \mbox{'00'} \\ \mbox{Second:} & \mbox{'10'} \pm 1 \mbox{ s} \\ \end{array}$

| BER-TLV: | D7 | 0C | 82 | 02 | 82 | 81 | A4 | 01 | 01 | A5 | 03 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | XX | | | | | | | | | | |

Expected Sequence 2.2 (TIMER EXPIRATION, SIM application toolkit busy)

| Step | Direction | MESSAGE / Action | Comments |
|-------|---|--|--|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: TIMER | |
| | | MANAGEMENT 2.2.1 | |
| 2 | $ME \rightarrow SIM$ | | r: 41 |
| 3 | | PROACTIVE COMMAND: TIMER | [timer 1] |
| 4 | ME SIM | MANAGEMENT 2.2.1 TERMINAL RESPONSE: TIMER | [command performed successfully] |
| 4 | IVIE -> SIIVI | MANAGEMENT 2.2.1 | [confinant performed successibility] |
| 5 | MF → SIM | ENVELOPE: TIMER EXPIRATION | |
| | , | 2.2.1A | |
| 6 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION BUSY | [SIM is busy; response to the envelope = "93 |
| | | | 00"] |
| | | | [SIM is busy during 10 seconds. If the ME |
| | | | periodically retries to send the envelope until |
| | | | it is accepted, then step 7a-10a apply. If the |
| | | | ME does not periodically retry to send the envelope, e.g. it waits for a TERMINAL |
| | | | RESPONSE processed by the SIM with status |
| | | | '90 00', then step 7b – 14b apply] |
| 7a | $ME \rightarrow SIM$ | ENVELOPE: TIMER EXPIRATION | [Branch applies for MEs periodically retrying |
| | | 2.2.1B | to send the envelope] |
| 8a | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION BUSY | |
| 0- | | ENVELORE: TIMER EVELORE | 00"] |
| 9a | $ME \rightarrow SIM$ | ENVELOPE: TIMER EXPIRATION 2.2.1C | |
| 10a | SIM ME | SW1/SW2=90 00 | |
| 100 | OIIVI -> IVIL | 000 170002=30 00 | |
| 7b | $ME \rightarrow SIM$ | STATUS or other command | [Branch applies for MEs not periodically |
| | | | retrying to send the envelope (in compliance |
| | | | with TS 11.14[15], cl. 10.1)] |
| | | | Stans 7h 12h are reported mayimal 100 |
| | | | Steps 7b – 12b are repeated maximal 100 times (to prevent infinite testing) or until the |
| | | | terminals sends ENVELOPE: TIMER |
| | | | EXPIRATION 2.2.1B in step 13b or at any |
| | | | time during steps 7b – 12b (in latter case step |
| | | | 13b is obsolete). |
| 8b | $SIM \rightarrow ME$ | Response to the command issued | [SW1/SW2=91 xx] |
| | | in step 7b | |
| | | PROACTIVE COMMAND | |
| 9b | $ME \rightarrow SIM$ | PENDING FETCH | |
| 10b | | PROACTIVE COMMAND: e.g. | |
| 100 | JIIVI → IVIE | MORE TIME 2.2.2 | |
| 11b | MF → SIM | TERMINAL RESPONSE: e.g. | [command performed successfully] |
| | | MORE TIME 2.2.2 | |
| 12b | $SIM \rightarrow ME$ | Response to the command issued | [SW1/SW2 = 90 00] |
| | | in step 11b | |
| 13b | $ME \rightarrow SIM$ | ENVELOPE: TIMER EXPIRATION | |
| 4.41- | 0114 14- | 2.2.1B | |
| 14b | $SIM \rightarrow ME$ | SW1/SW2=90 00 | |

PROACTIVE COMMAND: TIMER MANAGEMENT 2.2.1

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 1

Timer value

Value of timer: 0 h 0 min 30 s

Coding:

| BER-TLV: | D0 | 11 | 81 | 03 | 01 | 27 | 00 | 82 | 02 | 81 | 82 | A4 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | 01 | A5 | 03 | 00 | 00 | 03 | | | | | |

TERMINAL RESPONSE: TIMER MANAGEMENT 2.2.1

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier

Identifier of timer: 1

Coding:

| BER-TLV: | 81 | 03 | 01 | 27 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | A4 | 01 | 01 | | | | | | | | | |

ENVELOPE: TIMER EXPIRATION 2.2.1A

Logically:

Device identities

Source device: ME Destination device: SIM

Timer identifier
Timer 1

Timer value

Hour: '00' Minute: '00' Second: '30' \pm 1 s

Coding:

| BER-TLV: | D7 | 0C | 82 | 02 | 82 | 81 | A4 | 01 | 01 | A5 | 03 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | XX | | | | | | | | | | |

ENVELOPE: TIMER EXPIRATION 2.2.1B

Logically:

Device identities

Source device: ME
Destination device: SIM

Timer identifier

Timer 1 Timer value

Hour: '00'

Minute: '00'

Second: \geq timer in clause 2.2.1A

Coding:

| BER-TLV: | D7 | 0C | 82 | 02 | 82 | 81 | A4 | 01 | 01 | A5 | 03 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | XX | | | | | | | | | | |

ENVELOPE: TIMER EXPIRATION 2.2.1C

Logically:

Device identities

Source device: ME Destination device: SIM

Timer identifier

Timer 1

Timer value

Hour: '00' Minute: '00'

Second: \geq timer in 2.2.1B

Coding:

| BER-TLV: | D7 | 0C | 82 | 02 | 82 | 81 | A4 | 01 | 01 | A5 | 03 | 00 | |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|--|
| | 00 | XX | | | | | | | | | | | |

PROACTIVE COMMAND: MORE TIME 2.2.2

Logically:

Command details

Command number:

Command type: MORE TIME

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Coding:

TERMINAL RESPONSE: MORE TIME 2.2.2

Logically:

Command details

Command number: 1

Command type: MORE TIME

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

| | l | 00 | | 00 | | 0.0 | | 0.0 | | 0.2 | | |
|-----------|------|------|-------|------|------|-----|------|-----|------|------|------|------|
| BER-TLV: | Ι Ω1 | 1 03 | Λ1 | | 00 | | 1 02 | | Ι Ω1 | | l 01 | 00 |
| IDENTILV. | 1 01 | เบอ | I U I | 1 02 | I UU | 02 | UZ | 02 | | 1 00 | 1 01 | I UU |

27.22.4.21.2.5 Test requirement

The ME shall operate in the manner defined in expected sequences 2.1 to 2.2.

27.22.4.22 SET UP IDLE MODE TEXT

27.22.4.22.1 SET UP IDLE MODE TEXT (normal)

27.22.4.22.1.1 Definition and applicability

See clause 3.2.2.

27.22.4.22.1.2 Conformance requirement

• 3GPP TS 11.14 [15] clause 4.7, clause 5.2, clause 6.4.22, clause 6.6.22, clause 6.4.16, clause 6.6.16, clause 11.6, clause 6.8, clause 11, clause 11.1, clause 12.25, clause 6.4.7 and clause 6.6.13.

Additionally the ME shall support the REFRESH proactive SIM facility as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.1, clause 6.4.7, clause 6.6.13, clause 6.11, clause 12.6, clause 12.12, clause 13.4 and clause 14.

27.22.4.22.1.3 Test purpose

To verify that the text passed to the ME is displayed as idle mode text.

27.22.4.22.1.4 Method of test

27.22.4.22.1.4.1 Initial conditions

The ME is connected to the SIM Simulator and the System Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on, performed the PROFILE DOWNLOAD procedure and be in update idle mode on the System Simulator.

27.22.4.22.1.4.2 Procedure

Expected Sequence 1.1 (SET UP IDLE MODE TEXT, display idle mode text)

| Step | Direction | Message / Action | Comments |
|------|-----------------------|---------------------------|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | [Idle Mode Text] |
| | | PENDING: SET UP IDLE MODE | |
| | | TEXT 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SET UP | |
| | | IDLE MODE TEXT 1.1.1 | |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP | [Command performed successfully] |
| | | IDLE MODE TEXT 1.1.1 | |
| 5 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |
| 6 | $USER \to ME$ | Select idle screen | Only if idle screen not already available |
| 7 | $ME \rightarrow USER$ | Display "Idle Mode Text" | |

PROACTIVE COMMAND: SET UP IDLE MODE TEXT 1.1.1

Logically:

Command details

Command number:

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: ME

Text String

Data coding scheme: unpacked, 8 bit data
Text: "Idle Mode Text"

Coding:

| BER-TLV: | D0 | 1A | 81 | 03 | 01 | 28 | 00 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0F | 04 | 49 | 64 | 6C | 65 | 20 | 4D | 6F | 64 | 65 | 20 |
| | 54 | 65 | 78 | 74 | | | | | | | | |

TERMINAL RESPONSE: SET UP IDLE MODE TEXT 1.1.1

Logically:

Command details

Command number: 1

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 28 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|-------------------|----------|----|----------|----|-----|----|----|-----|------------|----|----------|----|
| D = 1 \ 1 = \ 1 . | . | | . | | ~ ~ | ~_ | | - U | O . | - | . | |

Expected Sequence 1.2 (SET UP IDLE MODE TEXT, replace idle mode text)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|---------------------------|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SET UP IDLE MODE | |
| | | TEXT 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SET UP | [Idle Mode Text] |
| | | IDLE MODE TEXT 1.1.1 | |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP | |
| | | IDLE MODE TEXT 1.1.1 | |
| 5 | $USER \to ME$ | Select idle screen | Only if idle screen not already available |
| 6 | $ME \rightarrow USER$ | Display "Idle Mode Text" | |
| 7 | $SIM \to ME$ | PROACTIVE COMMAND | [Idle Mode Text] |
| | | PENDING: SET UP IDLE MODE | |
| | | TEXT 1.2.1 | |
| 8 | $ME \rightarrow SIM$ | FETCH | |
| 9 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SET UP | [Idle Mode Text] |
| | | IDLE MODE TEXT 1.2.1 | |
| 10 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP | |
| | | IDLE MODE TEXT 1.2.1 | |
| 11 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |
| 12 | | Select idle screen | Only if idle screen not already available |
| 13 | $ME \rightarrow USER$ | Display "Toolkit Test" | |

PROACTIVE COMMAND: SETUP IDLE MODE TEXT 1.2.1

Logically:

Command details

Command number: 1

Command type: SETUP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: ME

Text String

Data coding scheme: unpacked, 8 bit data
Text: "Toolkit Test"

Coding:

| BER-TLV: | D0 | 18 | 81 | 03 | 01 | 28 | 00 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0D | 04 | 54 | 6F | 6F | 6C | 6B | 69 | 74 | 20 | 54 | 65 |
| | 73 | 74 | | | | | | | | | | |

TERMINAL RESPONSE: SET UP IDLE MODE TEXT 1.2.1

Logically:

Command details

Command number:

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 28 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
|----------|----|----|----|----|----|----|----|----|----|----|----|----|

Expected Sequence 1.3 (SET UP IDLE MODE TEXT, remove idle mode text)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--|---|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: | |
| | | SET UP IDLE MODE TEXT 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | | ["Idle Mode Text"] |
| | | IDLE MODE TEXT 1.1.1 | |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP | |
| | | IDLE MODE TEXT 1.1.1 | |
| 5 | | Select idle screen | Only if idle screen not already available |
| 6 | $ME \rightarrow USER$ | Display "Idle Mode Text" | |
| 7 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: | |
| | | SET UP IDLE MODE TEXT 1.3.1 | |
| 8 | $ME \rightarrow SIM$ | FETCH | |
| 9 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SET UP | [Remove idle mode text] |
| | | IDLE MODE TEXT 1.3.1 | |
| 10 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP | |
| | | IDLE MODE TEXT 1.3.1 | |
| 11 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION ENDED | |
| 12 | $USER \rightarrow ME$ | Select idle screen | Only if idle screen not already available |
| 13 | $ME \rightarrow USER$ | Display idle screen / "Idle Mode Text" | |
| | | not to be displayed | |

PROACTIVE COMMAND: SETUP IDLE MODE TEXT 1.3.1

Logically:

Command details

Command number:

Command type: SETUP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: SIM Destination device: ME

Text String: zero length TLV

Coding:

| BER-TLV: | D0 | 0B | 81 | 03 | 01 | 28 | 00 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | | | | | | | | | | | |

TERMINAL RESPONSE: SET UP IDLE MODE TEXT 1.3.1

Logically:

Command details

Command number: 1

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 01 | 03 | 01 | 28 | 00 | 92 | 02 | 92 | 01 | 92 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| DEK-ILV. | 01 | 03 | UI | | 00 | 02 | 02 | 82 | 01 | ೦೦ | UI | UU |

Expected Sequence 1.4 (SET UP IDLE MODE TEXT, competing information on ME display)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--------------------------------------|---|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: SET UP IDLE MODE | |
| | | TEXT 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SET UP | ["Idle Mode Text"] |
| | | IDLE MODE TEXT 1.1.1 | |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP | [Command performed successfully] |
| 5 | USER → ME | Select idle screen | Only if idle screen not already available |
| 6 | ME → USER | Display "Idle Mode Text" | only in tallo delegal field all cardy available |
| 7 | SS → ME | SMS PP 1.4.1 | [Display immediate SMS] |
| 8 | ME → USER | Display "Test Message" | [Siopiay illimodiate citie] |
| 9 | USER → ME | Clear display and select idle | |
| | OOLIK 7 WIL | screen | |
| 10 | ME → USER | | |
| 11 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: DISPLAY TEXT 1.4.1 | |
| 12 | $ME \to SIM$ | FETCH | |
| 13 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: | [Normal priority, wait for user to clear |
| | | DISPLAY TEXT 1.4.1 | message, unpacked, 8 bit data] |
| 14 | $ME \rightarrow USER$ | Display "Toolkit Test 1" | |
| 15 | $USER \rightarrow ME$ | Clear Message | |
| 16 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: | [Command performed successfully] |
| | | DISPLAY TEXT 1.4.1 | |
| 17 | | Display "Idle Mode Text" | |
| 18 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: PLAY TONE 1.4.1 | |
| 19 | $ME \rightarrow SIM$ | FETCH | |
| 20 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: PLAY | |
| 21 | ME LICED | TONE 1.4.1 | |
| 21 | ME → USER | Display "Dial Tone" | |
| | | Play a standard supervisory dial | |
| | | tone through the external ringer for | |
| | | a duration of 5 s | |
| 22 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: PLAY | [Command performed successfully] |
| | / 5 | TONE 1.4.1 | , |
| 23 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |
| 24 | $ME \rightarrow USER$ | Display "Idle Mode Text" | |

SMS-PP 1.4.1

Logically:

SMS TPDU

TP-MTI SMS-DELIVER

TP-MMS No more messages waiting for the MS in this SC TP-RP TP-Reply-Path is not set in this SMS-DELIVER TP-UDHI TP-UD field contains only the short message TP-SRI A status report will not be returned to the ME

TP-OA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "1234" TP-PID '00'

TP-DCS

Coding Group General Data Coding Compression Text is uncompressed

Message Class Class 0

Alphabet GSM 7 bit default alphabet

TP-SCTS: 01/01/98 00:00:00 +0

TP-UDL 12

TP-UD "Test Message"

Coding:

| Coding | 04 | 04 | 91 | 21 | 43 | 00 | 10 | 89 | 10 | 10 | 00 | 00 |
|--------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | 00 | 0C | D4 | F2 | 9C | 0E | 6A | 96 | E7 | F3 | F0 |
| | B9 | 0C | | | | | | | | | | |

PROACTIVE COMMAND: DISPLAY TEXT 1.4.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text String

Data coding scheme: unpacked, 8 bit data
Text: "Toolkit Test 1"

Coding:

| BER-TLV: | D0 | 1A | 81 | 03 | 01 | 21 | 80 | 82 | 02 | 81 | 02 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0F | 04 | 54 | 6F | 6F | 6C | 6B | 69 | 74 | 20 | 54 | 65 |
| | 73 | 74 | 20 | 31 | | | | | | | | |

TERMINAL RESPONSE: DISPLAY TEXT 1.4.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER- | ·TLV: | 81 | 03 | 01 | 21 | 80 | 82 | 02 | 82 | 81 | 83 | 01 | 00 | 1 |
|------|-------|----|----|----|----|----|----|----|----|----|----|----|----|---|
|------|-------|----|----|----|----|----|----|----|----|----|----|----|----|---|

PROACTIVE COMMAND: PLAY TONE 1.4.1

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Earpiece
Alpha identifier: "Dial Tone"

TONe: Standard supervisory tones: dial tone

Duration

Time unit: Seconds
Time interval: 5

Coding:

| BER-TLV: | D0 | 1B | 81 | 03 | 01 | 20 | 00 | 82 | 02 | 81 | 03 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 09 | 44 | 69 | 61 | 6C | 20 | 54 | 6F | 6E | 65 | 8E | 01 |
| | 01 | 84 | 02 | 01 | 05 | | | | | | | |

TERMINAL RESPONSE: PLAY TONE 1.4.1

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 20 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|-----------|----|----|----|----|----|----|----|----|----|----|-----|----|
| DLIX-ILV. | 01 | 03 | UI | 20 | 00 | 02 | 02 | 02 | 01 | 00 | O I | 00 |

Expected Sequence 1.5 (SET UP IDLE MODE TEXT, ME power cycled)

| Step | Direction | MESSAGE / Action | Comments |
|------|--------------------------|----------------------------------|---|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: SET UP IDLE MODE | |
| | | TEXT 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SET UP | ["Idle Mode Text"] |
| | | IDLE MODE TEXT 1.1.1 | |
| 4 | $ME \rightarrow SIM$ | | [command performed successfully] |
| | | IDLE MODE TEXT 1.1.1 | |
| 5 | $USER \to ME$ | Select idle screen | Only if idle screen not already available |
| 6 | $ME \rightarrow USER$ | Display "Idle Mode Text" | |
| 7 | $USER \to ME$ | Power off ME | |
| 8 | $ME \Leftrightarrow SIM$ | GSM TERMINATION | |
| | | PROCEDURE | |
| 9 | $USER \to ME$ | Power on ME | |
| 10 | $ME \Leftrightarrow SIM$ | GSM ACTIVATION PROCEDURE | |
| 11 | $ME \Leftrightarrow SIM$ | SIM INITIALIZATION | |
| 12 | $USER \to ME$ | Select idle screen | Only if idle screen not already available |
| 13 | $ME \rightarrow USER$ | Display idle screen / "Idle Mode | |
| | | Text" not to be displayed | |

Expected Sequence 1.6 (SET UP IDLE MODE TEXT, REFRESH with SIM Initialization)

| Step | Direction | MESSAGE / Action | Comments |
|------|--------------------------|----------------------------------|---|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | [Idle Mode Text] |
| | | PENDING: SET UP IDLE MODE | |
| | | TEXT 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SET UP | |
| | | IDLE MODE TEXT 1.1.1 | |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP | |
| | | IDLE MODE TEXT 1.1.1 | |
| 5 | | Select idle screen | Only if idle screen not already available |
| 6 | $ME \rightarrow USER$ | Display "Idle Mode Text" | |
| 7 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: REFRESH 1.6.1 | |
| 8 | $ME \rightarrow SIM$ | FETCH | |
| 9 | $SIM \to ME$ | PROACTIVE COMMAND: | [SIM Initialization] |
| | | REFRESH 1.6.1 | |
| 10 | $ME \Leftrightarrow SIM$ | SIM INITIALIZATION | |
| 11 | $USER \to ME$ | Select idle screen | Only if idle screen not already available |
| 12 | $ME \rightarrow USER$ | Display idle screen / "Idle Mode | |
| | | Text" not to be displayed | |
| 13 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: | [Command performed successfully] |
| | | REFRESH 1.6.1A | |
| | | or | |
| | | TERMINAL RESPONSE: | [Command performed successfully with |
| | | REFRESH 1.6.1B | additional files read] |
| 14 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |

PROACTIVE COMMAND: REFRESH 1.6.1

Logically:

Command details

Command number: 1

Command type: REFRESH
Command qualifier: SIM Initialization

Device identities

Source device: SIM
Destination device: ME

Coding:

| BER-TLV: | D0 | 09 | 81 | 03 | 01 | 01 | 03 | 82 | 02 | 81 | 82 |
|----------|----|----|-----|----|----------|-----|----|----|----|-----|----|
| | | | • . | | . | • . | | ~- | ~- | • . | |

TERMINAL RESPONSE: REFRESH 1.6.1A

Logically:

Command details

Command number: 1

Command type: REFRESH
Command qualifier: SIM Initialization

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 01 | 03 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|-------------------|----------|----|----------|----------|----|----------------|------------|-----|------|----|----|----|
| D = 1 \ 1 = \ 1 . | . | 00 | . | . | 00 | _ _ | ~ <u> </u> | - C | , o. | | | |

TERMINAL RESPONSE: REFRESH 1.6.1B

Logically:

Command details

Command number: 1

Command type: REFRESH
Command qualifier: SIM Initialization

Device identities

Source device: ME Destination device: SIM

Result

General Result: REFRESH performed with additional EFs read

Coding:

BER-TLV: 81 03 01 01 03 82 02 82 81 83 01 03

Expected Sequence 1.7 (SET UP IDLE MODE TEXT, large text string)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|---------------------------------------|---|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | [large text string] |
| | | PENDING: SET UP IDLE MODE | |
| | | TEXT 1.7.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SET UP | |
| | | IDLE MODE TEXT 1.7.1 | |
| 4 | $ME \rightarrow SIM$ | | [command performed successfully] |
| | | IDLE MODE TEXT 1.7.1 | |
| 5 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |
| 6 | $USER \to ME$ | Select idle screen | Only if idle screen not already available |
| 7 | $ME \rightarrow USER$ | Display "The SIM shall supply a | [274 characters] |
| | | text string, which shall be | |
| | | displayed by the ME as an idle | |
| | | mode text if the ME is able to do it. | |
| | | The presentation style is left as an | |
| | | implementation decision to the ME | |
| | | manufacturer. The idle mode text | |
| | | shall be displayed in a manner that | |
| | | ensures that ne" | |

PROACTIVE COMMAND: SET UP IDLE MODE TEXT 1.7.1

Logically:

Command details

Command number: 1

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: ME

Text String

Data coding scheme: packed, SMS default alphabet

Text: "The SIM shall supply a text string, which shall be displayed by the ME as an idle

mode text if the ME is able to do it. The presentation style is left as an implementation decision to the ME manufacturer. The idle mode text shall be

displayed in a manner that ensures that ne"

Coding:

| BER-TLV: | D0 | 81 | FD | 81 | 03 | 01 | 28 | 00 | 82 | 02 | 81 | 82 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 8D | 81 | F1 | 00 | 54 | 74 | 19 | 34 | 4D | 36 | 41 | 73 |
| | 74 | 98 | CD | 06 | CD | EB | 70 | 38 | 3B | 0F | 0A | 83 |
| | E8 | 65 | 3C | 1D | 34 | A7 | CB | D3 | EE | 33 | 0B | 74 |
| | 47 | A7 | C7 | 68 | D0 | 1C | 1D | 66 | В3 | 41 | E2 | 32 |
| | 88 | 9C | 9E | C3 | D9 | E1 | 7C | 99 | 0C | 12 | E7 | 41 |
| | 74 | 74 | 19 | D4 | 2C | 82 | C2 | 73 | 50 | D8 | 0D | 4A |
| | 93 | D9 | 65 | 50 | FB | 4D | 2E | 83 | E8 | 65 | 3C | 1D |
| | 94 | 36 | 83 | E8 | E8 | 32 | A8 | 59 | 04 | A5 | E7 | A0 |
| | B0 | 98 | 5D | 06 | D1 | DF | 20 | F2 | 1B | 94 | A6 | BB |
| | A8 | E8 | 32 | 08 | 2E | 2F | CF | CB | 6E | 7A | 98 | 9E |
| | 7E | BB | 41 | 73 | 7A | 9E | 5D | 06 | A5 | E7 | 20 | 76 |
| | D9 | 4C | 07 | 85 | E7 | A0 | B0 | 1B | 94 | 6E | C3 | D9 |
| | E5 | 76 | D9 | 4D | 0F | D3 | D3 | 6F | 37 | 88 | 5C | 1E |
| | A7 | E7 | E9 | B7 | 1B | 44 | 7F | 83 | E8 | E8 | 32 | A8 |
| | 59 | 04 | B5 | C3 | EE | BA | 39 | 3C | A6 | D7 | E5 | 65 |
| | B9 | 0B | 44 | 45 | 97 | 41 | 69 | 32 | BB | 0C | 6A | BF |
| | C9 | 65 | 10 | BD | 8C | A7 | 83 | E6 | E8 | 30 | 9B | 0D |
| | 12 | 97 | 41 | E4 | F4 | 1C | CE | 0E | E7 | CB | 64 | 50 |
| | DA | 0D | 0A | 83 | DA | 61 | B7 | BB | 2C | 07 | D1 | D1 |
| | 61 | 3A | A8 | EC | 9E | D7 | E5 | E5 | 39 | 88 | 8E | 0E |
| | D3 | 41 | EE | 32 | | | | | | | | |
| | | | | | | | | | | | | |

TERMINAL RESPONSE: SET UP IDLE MODE TEXT 1.7.1

Logically:

Command details

Command number:

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 28 00 82 02 82 81 83 01 00

27.22.4.22.1.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.7.

27.22.4.22.2 SET UP IDLE MODE TEXT (Icon support)

27.22.4.22.2.1 Definition and applicability

See clause 3.2.2.

27.22.4.22.2.2 Conformance requirement

27.22.4.22.2.3 Test purpose

To verify that the ME text and / or icon passed to the ME is displayed by the ME as an idle mode text.

To verify that the icon identifier provided with the text string can replace the text string or accompany it.

To verify that if both an alpha identifier or text string, and an icon are provided with a proactive command, and both are requested to be displayed, but the ME is not able to display both together on the screen, then the alpha identifier or text string takes precedence over the icon.

To verify that if the SIM provides an icon identifier with a proactive command, then the ME shall inform the SIM if the icon could not be displayed by sending the general result "Command performed successfully, but requested icon could not be displayed".

To verify that if the ME receives an icon identifier with a proactive command, and either an empty, or no alpha identifier / text string is given by the SIM, then the ME shall reject the command with general result "Command data not understood by ME".

27.22.4.22.2.4 Method of test

27.22.4.22.2.4.1 Initial conditions

The ME is connected to both the SIM Simulator and the System Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on, performed the PROFILE DOWNLOAD procedure and be in updated idle mode on the System Simulator.

27.22.4.22.2.4.2 Procedure

Expected Sequence 2.1A (SET UP IDLE MODE TEXT, Icon is self-explanatory, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|---------------------------|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | [Icon is self-explanatory] |
| | | PENDING: SET UP IDLE MODE | |
| | | TEXT 2.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SET UP | |
| | | IDLE MODE TEXT 2.1.1 | |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP | [command performed successfully] |
| | | IDLE MODE TEXT 2.1.1A | |
| | | | |
| 5 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |
| 6 | | | Only if idle screen not already available |
| 7 | $ME \rightarrow USER$ | Display the icon | |

PROACTIVE COMMAND: SET UP IDLE MODE TEXT 2.1.1

Logically:

Command details

Command number:

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: ME
Text String: "Idle text"

Icon identifier

Icon qualifier: icon is self-explanatory
Icon identifier: <record 1 in EF IMG>

Coding:

| BER-TLV: | D0 | 19 | 81 | 03 | 01 | 28 | 00 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0A | 04 | 49 | 64 | 6C | 65 | 20 | 74 | 65 | 78 | 74 | 9E |
| | 02 | 00 | 01 | | | | | | | | | |

TERMINAL RESPONSE: SET UP IDLE MODE TEXT 2.1.1A

Logically:

Command details

Command number: 1

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 28 00 82 02 82 81 83 01 00

Expected Sequence 2.1B (SET UP IDLE MODE TEXT, Icon is self-explanatory, requested icon could not be displayed)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--------------------------------------|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | [Icon is self-explanatory] |
| | | PENDING: SET UP IDLE MODE | |
| | | TEXT 2.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SET UP | |
| | | IDLE MODE TEXT 2.1.1 | |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP | [Command performed successfully, but |
| | | IDLE MODE TEXT 2.1.1B | requested icon could not be displayed] |
| 5 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |
| 6 | $USER \to ME$ | | Only if idle screen not already available |
| 7 | $ME \rightarrow USER$ | Display "Idle text" without the icon | |

TERMINAL RESPONSE: SET UP IDLE MODE TEXT 2.1.1B

Logically:

Command details

Command number: 1

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be displayed

Coding:

| BER-TLV: | 81 | 03 | l 01 | 28 | 00 | 82 | 02 | 82 | l 81 | 83 | 01 | 04 |
|----------|-----|----|------|----|----|----|----|----|----------|----|----|-----|
| | • . | | | | | | ~- | | . | | | • . |

Expected Sequence 2.2A (SET UP IDLE MODE TEXT, Icon is not self-explanatory, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|---------------------------------|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | [Icon is not self-explanatory] |
| | | PENDING: SET UP IDLE MODE | |
| | | TEXT 2.2.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SET UP | |
| | | IDLE MODE TEXT 2.2.1 | |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP | [command performed successfully] |
| | | IDLE MODE TEXT 2.2.1A | |
| 5 | $SIM \to ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |
| 6 | $USER \to ME$ | Select idle screen | Only if idle screen not already available |
| 7 | $ME \rightarrow USER$ | Display icon #1 and "Idle text" | |

PROACTIVE COMMAND: SET UP IDLE MODE TEXT 2.2.1

Logically:

Command details

Command number: 1

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: ME
Text String: "Idle text"

Icon identifier

Icon qualifier: icon is not self-explanatory
Icon identifier: <record 1 in EF IMG>

Coding:

| BER-TLV: | D0 | 19 | 81 | 03 | 01 | 28 | 00 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0A | 04 | 49 | 64 | 6C | 65 | 20 | 74 | 65 | 78 | 74 | 9E |
| | 02 | 01 | 01 | | | | | | | | | |

TERMINAL RESPONSE: SET UP IDLE MODE TEXT 2.2.1A

Logically:

Command details

Command number:

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 28 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|

Expected Sequence 2.2B (SET UP IDLE MODE TEXT, Icon is not self-explanatory, requested icon could not be displayed)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--------------------------------------|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | [Icon is not self-explanatory] |
| | | PENDING: SET UP IDLE MODE | |
| | | TEXT 2.2.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SET UP | |
| | | IDLE MODE TEXT 2.2.1 | |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP | [Command performed successfully, but |
| | | IDLE MODE TEXT 2.2.1B | requested icon could not be displayed] |
| 5 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |
| 6 | $USER \to ME$ | Select idle screen | Only if idle screen not already available |
| 7 | $ME \rightarrow USER$ | Display "Idle text" without the icon | |

TERMINAL RESPONSE: SET UP IDLE MODE TEXT 2.2.1B

Logically:

Command details

Command number:

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be displayed

Coding:

| | - | | | | | | | | | | | |
|-----------|------|-----|------|------|------|------|------------|----|------|-----|------|------|
| BER-TLV: | 1 01 | U.3 | I 01 | 20 | 00 | 02 | $^{\circ}$ | 92 | 1 01 | 0.2 | Ι Λ1 | Π4 |
| IDENTILV. | | เบอ | | 1 20 | 1 00 | 1 02 | 1 02 | 02 | | 00 | 1 01 | 1 04 |

Expected Sequence 2.3A (SET UP IDLE MODE TEXT, Icon is self-explanatory, colour icon, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|---------------------------|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | [Icon is self-explanatory] |
| | | PENDING: SET UP IDLE MODE | |
| | | TEXT 2.3.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SET UP | |
| | | IDLE MODE TEXT 2.3.1 | |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP | [command performed successfully] |
| | | IDLE MODE TEXT 2.3.1A | |
| 5 | $SIM \to ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |
| 6 | $USER \to ME$ | Select idle screen | Only if idle screen not already available |
| 7 | $ME \rightarrow USER$ | Display the icon | |

PROACTIVE COMMAND: SET UP IDLE MODE TEXT 2.3.1

Logically:

Command details

Command number: 1

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: ME
Text String: "Idle text"

Icon identifier

Icon qualifier: icon is self-explanatory
Icon identifier: <record 2 in EF IMG>

Coding:

| BER-TLV: | D0 | 19 | 81 | 03 | 01 | 28 | 00 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0A | 04 | 49 | 64 | 6C | 65 | 20 | 74 | 65 | 78 | 74 | 9E |
| | 02 | 00 | 02 | | | | | | | | | |

TERMINAL RESPONSE: SET UP IDLE MODE TEXT 2.3.1A

Logically:

Command details

Command number:

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 28 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | | | | | | | | | | | | |

Expected Sequence 2.3B (SET UP IDLE MODE TEXT, Icon is self-explanatory, colour icon, requested icon could not be displayed)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--------------------------------------|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | [Icon is self-explanatory] |
| | | PENDING: SET UP IDLE MODE | · |
| | | TEXT 2.3.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SET UP | |
| | | IDLE MODE TEXT 2.3.1 | |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP | [requested icon could not be displayed] |
| | | IDLE MODE TEXT 2.3.1B | |
| 5 | $SIM \to ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |
| 6 | $USER \to ME$ | Select idle screen | Only if idle screen not already available |
| 7 | $ME \rightarrow USER$ | Display 'Idle text' without the icon | |

TERMINAL RESPONSE: SET UP IDLE MODE TEXT 2.3.1B

Logically:

Command details

Command number: 1

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: ME

Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be displayed

Coding:

BER-TLV: 81 03 01 28 00 82 02 82 81 83 01 04

Expected Sequence 2.4 (SET UP IDLE MODE TEXT, Icon is not self-explanatory, empty text string)

| Step | Direction | MESSAGE / Action | Comments |
|------|--------------|---------------------------|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | [Icon is not self-explanatory, empty text string] |
| | | PENDING: SET UP IDLE MODE | |
| | | TEXT 2.4.1 | |
| 2 | $ME \to SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SET UP | |
| | | IDLE MODE TEXT 2.4.1 | |
| 4 | $ME \to SIM$ | TERMINAL RESPONSE: SET UP | |
| | | IDLE MODE TEXT 2.4.1 | |
| 5 | $SIM \to ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |

PROACTIVE COMMAND: SET UP IDLE MODE TEXT 2.4.1

Logically:

Command details

Command number: 1

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: SIM Destination device: ME

Text string

Contents: null data object

Icon identifier

Icon qualifier: icon is not self-explanatory
Icon identifier: <record 1 in EF IMG>

Coding:

| BER-TLV: | D0 | 0F | 81 | 03 | 01 | 28 | 00 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | 9E | 02 | 01 | 01 | | | | | | | |

TERMINAL RESPONSE: SET UP IDLE MODE TEXT 2.4.1

Logically:

Command details

Command number: 1

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command data not understood by ME

Coding:

| BER-TLV: | 81 | 03 | 01 | 28 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 32 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|

27.22.4.22.2.5 Test requirement

The ME shall operate in the manner defined in expected sequences 2.1A to 2.4.

27.22.4.22.3 SET UP IDLE MODE TEXT (UCS2 support)

27.22.4.22.3.1 Definition and applicability

See clause 3.2.2.

27.22.4.22.3.2 Conformance requirement

The ME shall support the UCS2 facility for the coding of the Cyrillic alphabet, as defined in:

• ISO/IEC 10646 [17].

27.22.4.22.3.3 Test purpose

To verify that the UCS2 coded text string is displayed by the ME as an idle mode text.

27.22.4.22.3.4 Method of test

27.22.4.22.3.4.1 Initial conditions

The ME is connected to both the SIM Simulator and the System Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on, performed the PROFILE DOWNLOAD procedure and be in updated idle mode on the System Simulator.

27.22.4.22.3.4.2 Procedure

Expected Sequence 3.1 (SET UP IDLE MODE TEXT, UCS2 alphabet text)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|---------------------------|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | ["Hello" in Russian] |
| | | PENDING: SET UP IDLE MODE | |
| | | TEXT 3.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SET UP | |
| | | IDLE MODE TEXT 3.1.1 | |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP | |
| | | IDLE MODE TEXT 3.1.1 | |
| 5 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |
| 6 | | | Only if idle screen not already available |
| 7 | $ME \rightarrow USER$ | Display " ЗДРАВСТВУЙТЕ" | ["Hello" in Russian] |

PROACTIVE COMMAND: SET UP IDLE MODE TEXT 3.1.1

Logically:

Command details

Command number: 1

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: ME

Text String

Data coding scheme: UCS2 (16bit)

Text: "ЗДРАВСТВУЙТЕ"

Coding:

| BER-TLV: | D0 | 24 | 81 | 03 | 01 | 28 | 00 | 82 | 02 | 81 | 82 | 8D |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 19 | 08 | 04 | 17 | 04 | 14 | 04 | 20 | 04 | 10 | 04 | 12 |
| | 04 | 21 | 04 | 22 | 04 | 12 | 04 | 23 | 04 | 19 | 04 | 22 |
| | 04 | 15 | | | | | | | | | | |

TERMINAL RESPONSE: SET UP IDLE MODE TEXT 3.1.1

Logically:

Command details

Command number: 1

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: 81 03 01 | | 82 02 82 | 81 83 01 0 | 00 |
|-------------------|--|----------|------------|----|
|-------------------|--|----------|------------|----|

27.22.4.22.3.5 Test requirement

The ME shall operate in the manner defined in expected sequence 3.1.

27.22.4.23 RUN AT COMMAND

27.22.4.23.1 RUN AT COMMAND (normal)

27.22.4.23.1.1 Definition and applicability

See clause 3.2.2.

27.22.4.23.1.2 Conformance requirement

The ME shall support the Proactive SIM: RUN AT COMMAND facility as defined in:

- 3GPP TS 11.14 [15] clause 6.4.23, clause 6.6.23, clause 5.2, clause 6.8, clause 12.6, clause 12.7, clause 12.2, clause 12.40, clause 12.31 and clause 12.41.
- 3GPP TS 27.007 [18].

27.22.4.23.1.3 Test purpose

To verify that the ME responds to an AT Command contained within a RUN AT COMMAND as though it were initiated by an attached TE, and returns an AT Response within a TERMINAL RESPONSE to the SIM.

27.22.4.23.1.4 Method of test

27.22.4.23.1.4.1 Initial conditions

The ME is connected to the SIM Simulator. The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

Prior to the test the ME shall be connected to the TE.

The TA-TE interface is set to 8-bit operation.

27.22.4.23.1.4.2 Procedure

Expected Sequence 1.1(RUN AT COMMAND, no alpha identifier presented, request IMSI)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|--------------------------------|-------------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: RUN AT COMMAND | |
| | | 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: RUN | [no alpha identifier, request IMSI] |
| | | AT COMMAND 1.1.1 | |
| 4 | | The ME may give information to | |
| | | the user concerning what is | |
| | | happening | |
| 5 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: RUN AT | [Command performed successfully, AT |
| | | COMMAND 1.1.1 | Response containing IMSI] |

PROACTIVE SIM COMMAND: RUN AT COMMAND 1.1.1

Logically:

Command details

Command number:

Command type: RUN AT COMMAND

Command qualifier: "00"

Device identities

Source device: SIM Destination device: ME

AT Command

AT Command string: "AT+CIMI"

Coding:

| BER-TLV: | D0 | 12 | 81 | 03 | 01 | 34 | 00 | 82 | 02 | 81 | 82 | A8 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| · | 07 | 41 | 54 | 2B | 43 | 49 | 4D | 49 | | | | |

TERMINAL RESPONSE: RUN AT COMMAND 1.1.1

Logically:

Command details

Command number: 1

Command type: RUN AT COMMAND

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

AT Response

AT Response string: IMSI

Coding:

| BER-TLV: | 81 | 03 | 01 | 34 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | A9 | 08 | 09 | 10 | 10 | 10 | 32 | 54 | 76 | 98 | | |

Expected Sequence 1.2 (RUN AT COMMAND, null data alpha identifier presented, request IMSI)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|--------------------------------------|--|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: RUN AT COMMAND | |
| | | 1.2.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: RUN | [null data alpha identifier, request IMSI] |
| | | AT COMMAND 1.2.1 | |
| 4 | ME | The ME should not give any | |
| | | information to user on the fact that | |
| | | the ME is performing an AT | |
| | | command | |
| 5 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: RUN AT | [Command performed successfully, AT |
| | | COMMAND 1.1.1 | Response containing IMSI] |

PROACTIVE SIM COMMAND: RUN AT COMMAND 1.2.1

Logically:

Command details

Command number:

Command type: RUN AT COMMAND

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha Identifier null data object

AT Command

AT Command string: "AT+CIMI"

Coding:

| BER-TLV: | D0 | 14 | 81 | 03 | 01 | 34 | 00 | 82 | 02 | 81 | 82 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | A8 | 07 | 41 | 54 | 2B | 43 | 49 | 4D | 49 | | |

Expected Sequence 1.3 (RUN AT COMMAND, alpha identifier presented, request IMSI)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|---------------------------|-------------------------------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: RUN AT COMMAND | |
| | | 1.3.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: RUN | [alpha identifier, request IMSI] |
| | | AT COMMAND 1.3.1 | |
| 4 | $ME \rightarrow USER$ | Display "Run AT Command" | |
| 5 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: RUN AT | [Command performed successfully, AT |
| | | COMMAND 1.1.1 | Response containing IMSI] |

PROACTIVE SIM COMMAND: RUN AT COMMAND 1.3.1

Logically:

Command details

Command number: 1

Command type: RUN AT COMMAND

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha Identifier

Alpha Identifier "Run AT Command"

AT Command

AT Command string: "AT+CIMI"

Coding:

| BER-TLV: | D0 | 22 | 81 | 03 | 01 | 34 | 00 | 82 | 02 | 81 | 82 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0E | 52 | 75 | 6E | 20 | 41 | 54 | 20 | 43 | 6F | 6D | 6D |
| | 61 | 6E | 64 | A8 | 07 | 41 | 54 | 2B | 43 | 49 | 4D | 49 |

27.22.4.23.1.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.3.

27.22.4.23.2 RUN AT COMMAND (Icon support)

27.22.4.23.2.1 Definition and applicability

See clause 3.2.2.

27.22.4.23.2.2 Conformance requirement

The ME shall support the Proactive SIM: RUN AT COMMAND facility as defined in:

- 3GPP TS 11.14 [15] clause 6.4.23, clause 6.6.23, clause 5.2, clause 6.8, clause 12.6, clause 12.7, clause 12.2, clause 12.40, clause 12.31 and clause 12.41.
- 3GPP TS 27.007 [18].

27.22.4.23.2.3 Test purpose

To verify that the ME responds to an AT Command contained within a RUN AT COMMAND as though it were initiated by an attached TE, and returns an AT Response within a TERMINAL RESPONSE to the SIM.

In addition to verify that if an icon is provided by the SIM, the icon indicated in the command may be used by the ME to inform the user, in addition to, or instead of the alpha identifier, as indicated with the icon qualifier.

27.22.4.23.2.4 Method of test

27.22.4.23.2.4.1 Initial conditions

The ME is connected to the SIM Simulator. The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

Prior to the test the ME shall be connected to the TE.

The TA-TE interface is set to 8-bit operation.

The ME screen shall be in its normal stand-by display.

27.22.4.23.2.4.2 Procedure

Expected Sequence 2.1A (RUN AT COMMAND, basic icon self explanatory, request IMSI, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--------------------------------|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: RUN AT COMMAND | |
| | | 2.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: RUN | [BASIC-ICON, self-explanatory, request IMSI] |
| | | AT COMMAND 2.1.1 | |
| 4 | $ME \rightarrow USER$ | Display BASIC ICON without the | |
| | | alpha identifier | |
| | | | |
| 5 | $ME \rightarrow SIM$ | | [Command performed successfully, AT |
| | | COMMAND 2.1.1A | response containing IMSI] |
| | | | |

PROACTIVE COMMAND: RUN AT COMMAND 2.1.1

Logically:

Command details

Command number: 1

Command type: RUN AT COMMAND

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha Identifier

Alpha identifier: "Basic Icon"

AT Command

AT Command string: "AT+CIMI"

Icon identifier:

Icon qualifier: icon is self-explanatory Icon identifier: record 1 in $EF_{(IMG)}$

Coding:

| BER-TLV: | D0 | 22 | 81 | 03 | 01 | 34 | 00 | 82 | 02 | 81 | 82 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0A | 42 | 61 | 73 | 69 | 63 | 20 | 49 | 63 | 6F | 6E | A8 |
| | 07 | 41 | 54 | 2B | 43 | 49 | 4D | 49 | 9E | 02 | 00 | 01 |

TERMINAL RESPONSE: RUN AT COMMAND 2.1.1A

Logically:

Command details

Command number:

Command type: RUN AT COMMAND

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

AT Response

AT Response string: IMSI

Coding:

| BER-TLV: 81 03 01 34 00 82 02 | 82 81 | 83 01 | 00 |
|-------------------------------|-------|-------|----|

| Α9 | 80 | 09 | 10 | 10 | 10 | 32 | 54 | 76 | 98 | |
|----|----|----|----|----|----|----|----|----|----|--|

Expected Sequence 2.1B (RUN AT COMMAND, basic icon self explanatory, request IMSI, requested icon could not be displayed)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|----------------------------------|--|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: RUN AT COMMAND | |
| | | 2.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: RUN | [BASIC-ICON, self-explanatory, request IMSI] |
| | | AT COMMAND 2.1.1 | |
| 4 | $ME \rightarrow USER$ | Display 'Basic Icon' without the | |
| | | BASIC-ICON | |
| 5 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: RUN AT | [Command performed but requested icon |
| | | COMMAND 2.1.1B | could not be displayed, AT response |
| | | | containing IMSI] |

TERMINAL RESPONSE: RUN AT COMMAND 2.1.1B

Logically:

Command details

Command number:

Command type: RUN AT COMMAND

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result:

Command performed successfully, but requested icon could not be displayed

AT Response

AT Response string: IMSI

Coding:

| BER-TLV: | 81 | 03 | 01 | 34 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 04 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | A9 | 08 | 09 | 10 | 10 | 10 | 32 | 54 | 76 | 98 | | |

Expected Sequence 2.2A (RUN AT COMMAND, colour icon self explanatory, request IMSI, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-----------------------------|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: RUN AT COMMAND | |
| | | 2.2.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: RUN | [COLOUR-ICON, self-explanatory, request |
| | | AT COMMAND 2.2.1 | IMSI] |
| 4 | $ME \rightarrow USER$ | Display COLOUR-ICON without | |
| | | the alpha identifier | |
| | | | |
| 5 | $ME \to SIM$ | TERMINAL RESPONSE: RUN AT | [Command performed successfully, AT |
| | | COMMAND 2.1.1A | response containing IMSI] |
| | | | |

PROACTIVE COMMAND: RUN AT COMMAND 2.2.1

Logically:

Command details

Command number: 1

Command type: RUN AT COMMAND

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha Identifier

Alpha identifier: "Colour Icon"

AT Command

AT Command string: "AT+CIMI"

Icon identifier:

 $\begin{array}{ll} \hbox{Icon qualifier:} & \hbox{icon is self-explanatory} \\ \hbox{Icon identifier:} & \hbox{record 2 in } EF_{(IMG)} \\ \end{array}$

Coding:

| BER-TLV: | D0 | 23 | 81 | 03 | 01 | 34 | 00 | 82 | 02 | 81 | 82 | A8 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0B | 43 | 6F | 6C | 6F | 75 | 72 | 20 | 49 | 63 | 6F | 6E |
| | A8 | 07 | 41 | 54 | 2B | 43 | 49 | 4D | 49 | 9E | 02 | 00 |
| | 02 | | | | | | | | | | | |

Expected Sequence 2.2B (RUN AT COMMAND, colour icon self explanatory, request IMSI, requested icon could not be displayed)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-----------------------------------|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: RUN AT COMMAND | |
| | | 2.2.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: RUN | [COLOUR-ICON, self-explanatory, request |
| | | AT COMMAND 2.2.1 | IMSI] |
| 4 | $ME \rightarrow USER$ | Display 'Colour Icon' without the | |
| | | COLOUR-ICON | |
| 5 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: RUN AT | [Command performed but requested icon |
| | | COMMAND 2.1.1B | could not be displayed, AT response |
| | | | containing IMSI] |

Expected Sequence 2.3A (RUN AT COMMAND, basic icon non self-explanatory, request IMSI, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|---------------------------------|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: RUN AT COMMAND | |
| | | 2.3.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: RUN | [BASIC-ICON, non self-explanatory, request |
| | | AT COMMAND 2.3.1 | IMSI] |
| 4 | $ME \rightarrow USER$ | Display "Basic Icon" and BASIC- | |
| | | ICON | |
| | | | |
| 5 | $ME \rightarrow SIM$ | | [Command performed successfully, AT |
| | | COMMAND 2.1.1A | response containing IMSI] |
| | | | |

PROACTIVE COMMAND: RUN AT COMMAND 2.3.1

Logically:

Command details

Command number: 1

Command type: RUN AT COMMAND

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha Identifier

Alpha identifier: "Basic Icon"

AT Command

AT Command string: "AT+CIMI"

Icon identifier

Icon qualifier: icon is non self-explanatory

Icon identifier: record 1 in $EF_{(IMG)}$

Coding:

| BER-TLV: | D0 | 22 | 81 | 03 | 01 | 34 | 00 | 82 | 02 | 81 | 82 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0A | 42 | 61 | 73 | 69 | 63 | 20 | 49 | 63 | 6F | 6E | A8 |
| | 07 | 41 | 54 | 2B | 43 | 49 | 4D | 49 | 9E | 02 | 01 | 01 |

Expected Sequence 2.3B (RUN AT COMMAND, basic icon non self-explanatory, request IMSI, requested icon could not be displayed)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|------------------------------|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: RUN AT COMMAND | |
| | | 2.3.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: RUN | [BASIC-ICON, non self-explanatory, request |
| | | AT COMMAND 2.3.1 | IMSI] |
| 4 | $ME \rightarrow USER$ | Display "Basic Icon" without | |
| | | BASIC-ICON | |
| 5 | $ME \to SIM$ | TERMINAL RESPONSE: RUN AT | [Command performed but requested icon |
| | | COMMAND 2.1.1B | could not be displayed, AT response |
| | | | containing IMSI] |

Expected Sequence 2.4A (RUN AT COMMAND, colour icon non self-explanatory, request IMSI, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|---------------------------|-------------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: RUN AT COMMAND | |
| | | 2.4.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: RUN | [COLOUR-ICON, non self-explanatory, |
| | | AT COMMAND 2.4.1 | request IMSI] |
| 4 | $ME \to USER$ | Display "Colour Icon" and | |
| | | COLOUR-ICON | |
| | | | |
| 5 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: RUN AT | [Command performed successfully, AT |
| | | COMMAND 2.1.1A | response containing IMSI] |
| | | | |

PROACTIVE COMMAND: RUN AT COMMAND 2.4.1

Logically:

Command details

Command number: 1

Command type: RUN AT COMMAND

Command qualifier: "00"

Device identities

Source device: SIM Destination device: ME

Alpha Identifier

Alpha identifier: "Colour Icon"

AT Command

AT Command string: "AT+CIMI"

Icon identifier:

 $\begin{array}{ll} \hbox{Icon qualifier:} & \hbox{icon is self-explanatory} \\ \hbox{Icon identifier:} & \hbox{record 2 in } EF_{(IMG)} \\ \end{array}$

Coding:

| BER-TLV: | D0 | 23 | 81 | 03 | 01 | 34 | 00 | 82 | 02 | 81 | 82 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0B | 43 | 6F | 6C | 6F | 75 | 72 | 20 | 49 | 63 | 6F | 6E |
| | A8 | 07 | 41 | 54 | 2B | 43 | 49 | 4D | 49 | 9E | 02 | 01 |
| | 02 | | | | | | | | | | | |

Expected Sequence 2.4B (RUN AT COMMAND, colour icon non self-explanatory, request IMSI, requested icon could not be displayed)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-------------------------------|---------------------------------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: RUN AT COMMAND | |
| | | 2.4.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: RUN | [COLOUR-ICON, non self-explanatory, |
| | | AT COMMAND 2.4.1 | request IMSI] |
| 4 | $ME \rightarrow USER$ | Display "Colour Icon" without | |
| | | COLOUR-ICON | |
| 5 | $ME \rightarrow SIM$ | | [Command performed but requested icon |
| | | COMMAND 2.1.1B | could not be displayed, AT response |
| | | | containing IMSI] |

Expected Sequence 2.5 (RUN AT COMMAND, basic icon non self-explanatory, no alpha identifier presented)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|--|-------------------------------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: RUN AT COMMAND | |
| | | 2.5.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | | PROACTIVE COMMAND: RUN AT COMMAND 2.5.1 | [BASIC-ICON, non self-explanatory] |
| 4 | $ME \to SIM$ | TERMINAL RESPONSE: RUN AT | [Command data not understood by ME] |
| 4 | | COMMAND 2.5.1 | [Command data not understood by ME] |

PROACTIVE COMMAND: RUN AT COMMAND 2.5.1

Logically:

Command details

Command number: 1

Command type: RUN AT COMMAND

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

AT Command

AT Command string: "AT+CIMI"

Icon identifier

Icon qualifier: icon is non self-explanatory

420

Icon identifier: record 1 in $EF_{(IMG)}$

Coding:

| BER-TLV: | D0 | 16 | 81 | 03 | 01 | 34 | 00 | 82 | 02 | 81 | 82 | A8 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 07 | 41 | 54 | 2B | 43 | 49 | 4D | 49 | 9E | 02 | 01 | 01 |

TERMINAL RESPONSE: RUN AT COMMAND 2.5.1

Logically:

Command details

Command number:

Command type: RUN AT COMMAND

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Result

General Result: Command data not understood by ME

Coding:

| BER-TLV: | 81 | 03 | 01 | 34 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 32 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|

27.22.4.23.2.5 Test requirement

The ME shall operate in the manner defined in expected sequences 2.1 to 2.5.

27.22.4.24 SEND DTMF

27.22.4.24.1 SEND DTMF (Normal)

27.22.4.24.1.1 Definition and applicability

See clause 3.2.2.

27.22.4.24.1.2 Conformance requirement

The ME shall support the Proactive SIM: Send DTMF facility as defined in:

• 3GPP TS 11.14 [15] clause 6.1, clause 6.4.24, clause 6.6.24, clause 12.12.2, clause 5.2, clause 12.6, clause 12.7, clause 12.2 and clause 12.44.

27.22.4.24.1.3 Test purpose

To verify that after a call has been successfully established the ME sends the DTMF string contained in the SEND DTMF proactive SIM command to the network, and returns a successful response in the TERMINAL RESPONSE command sent to the SIM.

To verify that the ME does not locally generate audible DTMF tones and play them to the user.

To verify that if the ME is in idle mode it informs the SIM using TERMINAL RESPONSE '20' with the additional information "Not in speech call".

To verify that the ME displays the text contained in the SEND DTMF proactive SIM command.

To verify that if an alpha identifier is provided by the SIM and is a null data object the ME does not give any information to the user on the fact that the ME is performing a SEND DTMF command.

27.22.4.24.1.4.1 Initial conditions

The ME is connected to the SIM Simulator and only connected to the System Simulator if the System Simulator is mentioned in the sequence table.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on, performed the PROFILE DOWNLOAD procedure and be in updated idle mode on the System Simulator.

27.22.4.24.1.4. 2 Procedure

Expected Sequence 1.1 (SEND DTMF, normal)

Some details of the DTMF protocol have been left out for clarity.

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--|------------------------------------|
| 1 | $User \rightarrow ME$ | Set up a call to "+0123456789" | |
| 2 | $ME \to SS$ | The ME attempts to set up a call to | |
| | | "+0123456789" | |
| 3 | $SS \rightarrow ME$ | The ME receives the CONNECT | |
| | | message from the system | |
| | 0114 145 | simulator. | |
| 4 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: SEND DTMF 1.1.1 | |
| 5 | $ME \rightarrow SIM$ | FETCH | |
| 6 | | PROACTIVE COMMAND: SEND | |
| | SIIVI -> IVIL | DTMF 1.1.1 | |
| 7 | ME → USER | = | |
| | | concerning what is happening. | |
| | | | |
| | | Do not locally generate audible | |
| | | DTMF tones and play them to the | |
| | | user. | |
| 8 | $ME \rightarrow SS$ | Start DTMF 1.1 | ["1"] |
| 9 | ME | 0 | No DTMF sending for 3 seconds ±20% |
| 10 | $ME \rightarrow SS$ | Start DTMF 1.2 | ["2"] |
| 11 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND | [Command performed successfully] |
| 12 | CIM . ME | DTMF 1.1.1 | |
| 12 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION ENDED | |
| 13 | User → ME | End the call | |

PROACTIVE COMMAND: SEND DTMF 1.1.1

Logically:

Command details

Command number:

Command type: SEND DTMF

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network
DTMF String: "1" pause "2"

Coding:

| BER-TLV: | D0 | 0D | 81 | 03 | 01 | 14 | 00 | 82 | 02 | 81 | 83 | AC | l |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|---|
| | 02 | C1 | F2 | | | | | | | | | | 1 |

Start DTMF 1.1

Logically:

DTMF String: "1"

Start DTMF 1.2

Logically:

DTMF String: "2"

TERMINAL RESPONSE: SEND DTMF 1.1.1

Logically:

Command details

Command number: 1

Command type: SEND DTMF

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 14 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|-----|----|-----|----|----|----|----|----|-----|----|-----|----|
| | • • | | • • | | | ~- | ~- | ~- | • . | | • . | |

Expected Sequence 1.2 (SEND DTMF, containing alpha identifier)

Some details of the DTMF protocol have been left out for clarity.

| Step | Direction | MESSAGE / Action | Comments |
|------|---|-------------------------------------|---|
| 1 | $User \to ME$ | Set up a call to "+0123456789" | |
| 2 | $ME \to SS$ | The ME attempts to set up a call to | |
| | | "+0123456789" | |
| 3 | $SS \rightarrow ME$ | The ME receives the CONNECT | |
| | | message from the system | |
| 4 | $SIM \rightarrow ME$ | simulator. PROACTIVE COMMAND | |
| 4 | SIIVI → IVIE | PENDING: SEND DTMF 1.2.1 | |
| 5 | $ME \rightarrow SIM$ | FETCH | |
| 6 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SEND | |
| | OIIVI 7 IVIL | DTMF 1.2.1 | |
| 7 | $ME \rightarrow USER$ | Display "Send DTMF" | Alpha identifier |
| | | | |
| | | Do not locally generate audible | |
| | | DTMF tones and play them to the | |
| | ME 00 | user. | F!! 4 !!3 |
| 8 | $ME \rightarrow SS$ | Start DTMF 1.1 | ["1"] |
| 10 | $ME \rightarrow SS$ | Start DTMF 1.2 Start DTMF 1.3 | ["2"] |
| 11 | $ME \rightarrow SS$ | Start DTMF 1.4 | ["3"] ["4"] |
| 12 | $ME \rightarrow SS$ $ME \rightarrow SS$ | Start DTMF 1.5 | ["5"] |
| 13 | $ME \rightarrow SS$ | Start DTMF 1.6 | ["6"] |
| 14 | $ME \rightarrow SS$ | Start DTMF 1.7 | ["7"] |
| 15 | $ME \rightarrow SS$ | Start DTMF 1.8 | ["8"] |
| 16 | ME → SS | Start DTMF 1.9 | ["9"] |
| 17 | $ME \rightarrow SS$ | Start DTMF 1.10 | ["0"] |
| 18 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND | [Command performed successfully] |
| - | , | DTMF 1.1.1 | , |
| 19 | $SIM \to ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |
| 20 | $User \to ME$ | End the call | |

PROACTIVE COMMAND: SEND DTMF 1.2.1

Logically:

Command details

Command number: 1

Command type: SEND DTMF

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Network

Alpha identifier: "Send DTMF"

DTMF String: "1234567890"

Coding:

| BER-TLV: | D0 | 1B | 81 | 03 | 01 | 14 | 00 | 82 | 02 | 81 | 83 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 09 | 53 | 65 | 6E | 64 | 20 | 44 | 54 | 4D | 46 | AC | 05 |
| | 21 | 43 | 65 | 87 | 09 | | | | | | | |

Start DTMF 1.3

Logically:

DTMF String: "3"

Start DTMF 1.4

Logically:

DTMF String: "4"

Start DTMF 1.5

Logically:

DTMF String: "5"

Start DTMF 1.6

Logically:

DTMF String: "6"

Start DTMF 1.7

Logically:

DTMF String: "7"

Start DTMF 1.8

Logically:

DTMF String: "8"

Start DTMF 1.9

Logically:

DTMF String: "9"

Start DTMF 1.10

Logically:

DTMF String: "0"

Expected Sequence 1.3 (SEND DTMF, containing alpha identifier with null data object)

Some details of the DTMF protocol have been left out for clarity.

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-------------------------------------|--|
| 1 | $User \to ME$ | Set up a call to "+0123456789" | |
| 2 | $ME \to SS$ | The ME attempts to set up a call to | |
| _ | | "+0123456789" | |
| 3 | $SS \rightarrow ME$ | The ME receives the CONNECT | |
| | | message from the system | |
| 4 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| 7 | SIIVI -> IVIE | PENDING: SEND DTMF 1.3.1 | |
| 5 | $ME \rightarrow SIM$ | FETCH | |
| 6 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SEND | Alpha identifier with null data object |
| | | DTMF 1.3.1 | , |
| 7 | $ME \rightarrow USER$ | Do not give any information to the | |
| | | user on the fact that the ME is | |
| | | performing a SEND DTMF | |
| | | command. | |
| | | Do not locally generate audible | |
| | | DTMF tones and play them to the | |
| | | user. | |
| 8 | $ME \to SS$ | Start DTMF 1.1 | ["1"] |
| 9 | ME | | No DTMF sending for 30 seconds ±20% |
| 10 | $ME \to SS$ | Start DTMF 1.2 | ["2"] |
| 11 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND | [Command performed successfully] |
| 40 | | DTMF 1.1.1 | |
| 12 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION | |
| 13 | Lloor MC | ENDED End the call | |
| 13 | User \rightarrow ME | Liiu iiie Cali | |

PROACTIVE COMMAND: SEND DTMF 1.3.1

Logically:

Command details

Command number: 1

Command type: SEND DTMF

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "" (null data object)

DTMF String: "1" pause "2"

Coding:

| BER-TLV: | D0 | 13 | 81 | 03 | 01 | 14 | 00 | 82 | 02 | 81 | 83 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | AC | 06 | C1 | CC | CC | CC | CC | 2C | | | |

Expected Sequence 1.4 (SEND DTMF, mobile is not in a speech call)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|--|--|
| 1 | | PROACTIVE COMMAND PENDING: SEND DTMF 1.1.1 | [Mobile is not in a speech call] |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SEND DTMF 1.1.1 | |
| 4 | | TERMINAL RESPONSE: SEND DTMF 1.4.1 | [ME currently unable to process command, not in speech call] |
| 5 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION ENDED | |

TERMINAL RESPONSE: SEND DTMF 1.4.1

Logically:

Command details

Command number: 1

Command type: SEND DTMF

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: ME currently unable to process command

Additional information: Not in speech call

Coding:

| BER-TLV: | 81 | 03 | 01 | 14 | 00 | 82 | 02 | 82 | 81 | 83 | 02 | 20 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| • | 07 | | | | | | | | | | | |

27.22.4.24.1.5 Test requirement

The ME shall operate in the manner defined in expected sequences.

27.22.4.24.2 SEND DTMF (Display of icons)

27.22.4.24.2.1 Definition and applicability

See clause 3.2.2.

27.22.4.24.2.2 Conformance requirement

The ME shall support the Proactive SIM: Send DTMF facility as defined in:

• 3GPP TS 11.14 [15] clause 6.1, clause 6.4.24, clause 6.6.24, clause 12.12.2, clause 5.2, clause 12.6, clause 12.7, clause 12.2, clause 12.44, clause 12.31 and clause 6.5.4.

27.22.4.24.2.3 Test purpose

To verify that after a call has been successfully established the ME send the DTMF string contained in the SEND DTMF proactive SIM command to the network, and returns a successful response in the TERMINAL RESPONSE command sent to the SIM.

To verify that the ME do not locally generate audible DTMF tones and play them to the user.

To verify that the ME displays the text contained in the SEND DTMF proactive SIM command.

To verify that the ME displays the icons which are referred to in the contents of the SEND DTMF proactive SIM command.

27.22.4.24.2.4 Method of test

27.22.4.24.2.4.1 Initial conditions

The ME is connected to the SIM Simulator and only connected to the System Simulator if the System Simulator is mentioned in the sequence table.

Prior to this test the ME shall have been powered on, performed the PROFILE DOWNLOAD procedure and be in updated idle mode on the System Simulator.

The elementary files are coded as Toolkit default.

27.22.4.24.2.4.2 Procedure

Expected Sequence 2.1A (SEND DTMF, BASIC ICON self explanatory, successful)

Some details of the DTMF protocol have been left out for clarity.

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|---|------------------------------------|
| 1 | $User \rightarrow ME$ | Set up a call to "+0123456789" | |
| 2 | $ME \rightarrow SS$ | The ME attempts to set up a call to "+0123456789" | |
| 3 | $SS \to ME$ | The ME receives the CONNECT message from the system simulator. | |
| 4 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: SEND DTMF 2.1.1 | |
| 5 | $ME \rightarrow SIM$ | FETCH | |
| 6 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SEND DTMF 2.1.1 | [BASIC-ICON, self-explanatory] |
| 7 | $ME \rightarrow USER$ | Display the BASIC-ICON | |
| | | Do not locally generate audible DTMF tones and play them to the user. | |
| 8 | ME 	o SS | Start DTMF 1.1 | ["1"] |
| 9 | ME | | No DTMF sending for 3 seconds ±20% |
| 10 | $ME \rightarrow SS$ | Start DTMF 1.2 | ["2"] |
| 11 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND DTMF 2.1.1A | [Command performed successfully] |
| 12 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION ENDED | |
| 13 | $User \to ME$ | End the call | |

PROACTIVE COMMAND: SEND DTMF 2.1.1

Logically:

Command details

Command number: 1

Command type: SEND DTMF

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Network

Alpha identifier: "Basic Icon"

DTMF String: "1" pause "2"

Icon identifier

 $\begin{array}{ll} \mbox{Icon qualifier:} & \mbox{icon is self-explanatory} \\ \mbox{Icon identifier:} & \mbox{record 1 in } \mbox{EF}_{(IMG)} \end{array}$

Coding:

| BER-TLV: | D0 | 1D | 81 | 03 | 01 | 14 | 00 | 82 | 02 | 81 | 83 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0A | 42 | 61 | 73 | 69 | 63 | 20 | 49 | 63 | 6F | 6E | AC |
| | 02 | C1 | F2 | 9E | 02 | 00 | 01 | | | | | |

DTMF Request 2.1.1

Logically:

DTMF String: \$DTMF_2.1\$ = "C1 F2" (given as example)

TERMINAL RESPONSE: SEND DTMF 2.1.1A

Logically:

Command details

Command number: 1

Command type: SEND DTMF

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 14 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|-----|----|----|------|
| | | 00 | 0. | | 00 | 02 | 02 | 02 | U . | 00 | 0. | - 00 |

Expected Sequence 2.1B (SEND DTMF, BASIC ICON self explanatory, requested icon could not be displayed)

Some details of the DTMF protocol have been left out for clarity.

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|---|---|
| 1 | $User \to ME$ | Set up a call to "+0123456789" | |
| 2 | $ME \to SS$ | The ME attempts to set up a call to "+0123456789" | |
| 3 | $SS \to ME$ | The ME receives the CONNECT message from the system | |
| 4 | $SIM \rightarrow ME$ | simulator. PROACTIVE COMMAND PENDING: SEND DTMF 2.1.1 | |
| 5 | $ME \rightarrow SIM$ | FETCH | |
| 6 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SEND DTMF 2.1.1 | [BASIC-ICON, self-explanatory] |
| 7 | $ME \rightarrow USER$ | Display "Basic Icon" without the icon | |
| | | Do not locally generate audible DTMF tones and play them to the user. | |
| 8 | $ME \rightarrow SS$ | Start DTMF 1.1 | ["1"] |
| 9 | ME | | No DTMF sending for 3 seconds ±20 % |
| 10 | $ME \to SS$ | Start DTMF 1.2 | ["2"] |
| 11 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND DTMF 2.1.1B | [Command performed successfully, but requested icon could not be displayed] |
| 12 | $SIM \to ME$ | PROACTIVE SIM SESSION ENDED | |
| 13 | $User \to ME$ | End the call | |

TERMINAL RESPONSE: SEND DTMF 2.1.1B

Logically:

Command details

Command number: 1

Command type: SEND DTMF

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be displayed

Coding:

| BER-TLV: | l 81 | 03 | 01 | 14 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 04 |
|----------|------|----|-----|----|----|----|----|----|-----|----|-----|-------|
| | • | | • . | | | | ~- | ~- | • . | | • . | • • • |

Expected Sequence 2.2A (SEND DTMF, COLOUR-ICON self explanatory, successful)

Some details of the DTMF protocol have been left out for clarity.

| Step | Direction | MESSAGE / Action | Comments |
|---------|--|--|--|
| 1 | $User \to ME$ | Set up a call to "+0123456789" | |
| 2 | $ME \to SS$ | The ME attempts to set up a call to | |
| | | "+0123456789" | |
| 3 | $SS \rightarrow ME$ | The ME receives the CONNECT | |
| | | message from the system | |
| 4 | OINA ME | simulator. | |
| 4 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: SEND DTMF 2.2.1 | |
| 5 | $ME \rightarrow SIM$ | FETCH | |
| 6 | SIM → ME | . = . * | [COLOUR-ICON] |
| | Olivi 7 IVIL | DTMF 2.2.1 | [6626666] |
| 7 | $ME \rightarrow USER$ | Display the COLOUR-ICON | |
| | | | |
| | | Do not locally generate audible | |
| | | DTMF tones and play them to the | |
| | ME 00 | USEr. | F!! 4 !!3 |
| 8 | $ME \rightarrow SS$ | Start DTMF 1.1 | ["1"] |
| 9 10 | $\begin{array}{c} ME \\ ME \to SS \end{array}$ | Start DTMF 1.2 | No DTMF sending for 3 seconds ±20% ["2"] |
| 11 | | TERMINAL RESPONSE: SEND | |
| '' | $ME \rightarrow SIM$ | DTMF 2.1.1A | [Command performed successfully] |
| 12 | $SIM \to ME$ | PROACTIVE SIM SESSION | |
| | CIIVI / IVIL | ENDED | |
| 13 | $User \to ME$ | End the call | |

PROACTIVE COMMAND: SEND DTMF 2.2.1

Logically:

Command details

Command number:

Command type: SEND DTMF

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Network

Alpha identifier: "Colour Icon"

DTMF String: "1" pause "2"

Icon identifier:

Icon qualifier: icon is self-explanatory Icon identifier: record 2 in $EF_{(IMG)}$

Coding:

| BER-TLV: | D0 | 1E | 81 | 03 | 01 | 14 | 00 | 82 | 02 | 81 | 83 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0B | 43 | 6F | 6C | 6F | 75 | 72 | 20 | 49 | 63 | 6F | 6E |
| | AC | 02 | C1 | F2 | 9F | 02 | 00 | 02 | | | | |

Expected Sequence 2.2B (SEND DTMF, COLOUR-ICON self explanatory, requested icon could not be displayed)

Some details of the DTMF protocol have been left out for clarity.

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|---|---|
| 1 | $User \to ME$ | Set up a call to "+0123456789" | |
| 2 | $ME \rightarrow SS$ | The ME attempts to set up a call to | |
| 3 | $SS \to ME$ | "+0123456789" The ME receives the CONNECT message from the system | |
| 4 | $SIM \to ME$ | simulator. PROACTIVE COMMAND PENDING: SEND DTMF 2.2.1 | |
| 5 | $ME \rightarrow SIM$ | FETCH | |
| 6 | $SIM \to ME$ | PROACTIVE COMMAND: SEND DTMF 2.2.1 | [COLOUR-ICON] |
| 7 | $ME \rightarrow USER$ | Display "Colour Icon" without the icon | |
| | | Do not locally generate audible DTMF tones and play them to the user. | |
| 8 | $ME \rightarrow SS$ | Start DTMF 1.1 | ["1"] |
| 9 | ME | | No DTMF sending for 3 seconds ±20% |
| 10 | $ME \to SS$ | Start DTMF 1.2 | ["2"] |
| 11 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND DTMF 2.1.1B | [Command performed successfully, but requested icon could not be displayed] |
| 12 | $SIM \to ME$ | PROACTIVE SIM SESSION ENDED | |
| 13 | $User \to ME$ | End the call | |

Expected Sequence 2.3A (SEND DTMF, Alpha identifier & BASIC-ICON, not self-explanatory, successful)

Some details of the DTMF protocol have been left out for clarity.

| Step | Direction | MESSAGE / Action | Comments |
|---------|----------------------|--|---|
| 1 | $User \to ME$ | Set up a call to "+0123456789" | |
| 2 | $ME \to SS$ | The ME attempts to set up a call to | |
| | | "+0123456789" | |
| 3 | $SS \to ME$ | The ME receives the CONNECT | |
| | | message from the system | |
| | 0114 145 | simulator. | |
| 4 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: SEND DTMF 2.3.1 | |
| 5 | $ME \rightarrow SIM$ | FETCH | |
| 6 | SIM → ME | PROACTIVE COMMAND: SEND | [Alpha identifier & BASIC-ICON, not self- |
| | SIIVI → IVIE | DTMF 2.3.1 | explanatory] |
| 7 | ME → USER | _ · · · · · · _ · · · · · | oxplanatory |
| | , 002it | BASIC-ICON | |
| | | | |
| | | | |
| | | Do not locally generate audible | |
| | | DTMF tones and play them to the | |
| | | user. | 50.4.03 |
| 8 | $ME \rightarrow SS$ | Start DTMF 1.1 | ["1"] |
| 9 10 | ME | Start DTMF 1.2 | No DTMF sending for 3 seconds ±20 % |
| | $ME \rightarrow SS$ | | ["2"] |
| 11 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND DTMF 2.1.1A | [Command performed successfully] |
| | | DTWF 2.1.1A | |
| 12 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION | |
| '- | CIIVI / IVIL | ENDED | |
| 13 | $User \to ME$ | End the call | |

PROACTIVE COMMAND: SEND DTMF 2.3.1

Logically:

Command details

Command number:

Command type: SEND DTMF

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Network

Alpha identifier: "Send DTMF"

DTMF String: "1" pause "2"

Icon identifier:

Icon qualifier: icon is not self-explanatory

Icon identifier: record 1 in $EF_{(IMG)}$

Coding:

| BER-TLV: | D0 | 1C | 81 | 03 | 01 | 14 | 00 | 82 | 02 | 81 | 83 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 09 | 53 | 65 | 6E | 64 | 20 | 44 | 54 | 4D | 46 | AC | 02 |
| | C1 | F2 | 9E | 02 | 01 | 01 | | | | | | |

Expected Sequence 2.3B (SEND DTMF, Alpha identifier & BASIC-ICON, not self-explanatory, requested icon could not be displayed)

Some details of the DTMF protocol have been left out for clarity.

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--|---|
| 1 | $User \to ME$ | Set up a call to "+0123456789" | |
| 2 | $ME \to SS$ | The ME attempts to set up a call to | |
| | | "+0123456789" | |
| 3 | $SS \rightarrow ME$ | The ME receives the CONNECT | |
| | | message from the system | |
| 4 | 0114 145 | simulator. | |
| 4 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: SEND DTMF 2.3.1 | |
| 5 | $ME \rightarrow SIM$ | FETCH | |
| 6 | IVIL / OIIVI | PROACTIVE COMMAND: SEND | [Alpha identifier & BASIC-ICON, not self- |
| | SIIVI -> IVIE | DTMF 2.3.1 | explanatory |
| 7 | ME → USER | | oxplanatory] |
| | ML 700LK | icon | |
| | | | |
| | | Do not locally generate audible | |
| | | DTMF tones and play them to the | |
| | | user. | |
| 8 | $ME \rightarrow SS$ | Start DTMF 1.1 | ["1"] |
| 9 | ME | | No DTMF sending for 3 seconds ±20% |
| 10 | $ME \rightarrow SS$ | Start DTMF 1.2 | ["2"] |
| 11 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND | [Command performed successfully, but |
| 40 | 0114 145 | DTMF 2.1.1B | requested icon could not be displayed] |
| 12 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION | |
| 13 | Lloor ME | ENDED | |
| 13 | User \rightarrow ME | End the call | |

27.22.4.24.2.5 Test requirement

The ME shall operate in the manner defined in expected sequences.

27.22.4.24.3 SEND DTMF (UCS2 support)

27.22.4.24.3.1 Definition and applicability

See clause 3.2.2.

27.22.4.24.3.2 Conformance requirement

The ME shall support the Proactive SIM: Send DTMF facility as defined in:

• 3GPP TS 11.14 [15] clause 6.1, clause 6.4.24, clause 6.6.24, clause 12.12.2, clause 5.2, clause 12.6, clause 12.7, clause 12.2 and clause 12.44.

Additionally the ME shall support the UCS2 facility for the coding of the Cyrillic alphabet, as defined in:

• ISO/IEC 10646. [17].

27.22.4.24.3.3 Test purpose

To verify that the ME displays the UCS2 text contained in the SEND DTMF proactive SIM command, and returns a successful result in the TERMINAL RESPONSE command send to the SIM.

27.22.4.24.3.4 Method of test

27.22.4.24.3.4.1 Initial conditions

The ME is connected to the SIM Simulator and only connected to the System Simulator if the System Simulator is mentioned in the sequence table.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.24.3.4.2 Procedure

Expected Sequence 3.1 (SEND DTMF, successful, UCS2 text)

Some details of the DTMF protocol have been left out for clarity.

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-------------------------------------|------------------------------------|
| 1 | $User \to ME$ | Set up a call to "+0123456789" | |
| 2 | $ME \to SS$ | The ME attempts to set up a call to | |
| _ | | "+0123456789" | |
| 3 | $SS \rightarrow ME$ | The ME receives the CONNECT | |
| | | message from the system | |
| 4 | $SIM \rightarrow ME$ | simulator. PROACTIVE COMMAND | |
| 4 | SIIVI → IVIE | PENDING: SEND DTMF 3.1.1 | |
| 5 | $ME \rightarrow SIM$ | FETCH | |
| 6 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SEND | |
| | Olivi 7 IVIL | DTMF 3.1.1 | |
| 7 | $ME \rightarrow USER$ | Display "ЗДРАВСТВУЙТЕ" | ["Hello" in Russian] |
| 8 | $ME \to SS$ | Start DTMF 1.1 | ["1"] |
| 9 | ME | | No DTMF sending for 3 seconds ±20% |
| 10 | $ME \to SS$ | Start DTMF 1.2 | ["2"] |
| 11 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND | [Command performed successfully] |
| | | DTMF 3.1.1 | |
| 12 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION | |
| 13 | Lloor ME | ENDED | |
| 13 | User → ME | End the call | |

PROACTIVE COMMAND: SEND DTMF 3.1.1

Logically:

Command details

Command number:

Command type: SEND DTMF

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network

Alpha Identifier

Text: "ЗДРАВСТВУЙТЕ"

DTMF String: "1" pause "2"

Coding:

| BER-TLV: | D0 | 28 | 81 | 03 | 01 | 14 | 00 | 82 | 02 | 81 | 83 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 19 | 80 | 04 | 17 | 04 | 14 | 04 | 20 | 04 | 10 | 04 | 12 |
| | 04 | 21 | 04 | 22 | 04 | 12 | 04 | 23 | 04 | 19 | 04 | 22 |
| | 04 | 15 | AC | 02 | C1 | F2 | | | | | | |

TERMINAL RESPONSE: SEND DTMF 3.1.1

Logically:

Command details

Command number: 1

Command type: SEND DTMF

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successful

Coding:

27.22.4.12.2.5 Test requirement

The ME shall operate in the manner defined in expected sequence 1.

27.22.4.25 LANGUAGE NOTIFICATION

27.22.4.25.1 Definition and applicability

See clause 3.2.2.

27.22.4.25.2 Conformance Requirement

The ME shall conclude the command by sending TERMINAL RESPONSE (OK) to the SIM, as soon as possible after receiving the LANGUAGE NOTIFICATION proactive SIM command.

• 3GPP TS 11.14 clause 6.4.25 and clause 6.6.25.

27.22.4.25.3 Test purpose

To verify that the ME shall send a TERMINAL RESPONSE (OK) to the SIM after the ME receives the LANGUAGE NOTIFICATION proactive SIM command.

27.22.4.25.4 Method of Test

27.22.4.25.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.25.4.2 Procedure

Expected Sequence 1.1 (LANGUAGE NOTIFICATION)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|-----------------------------|---|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: LANGUAGE | |
| | | NOTIFICATION 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: | Language specified in the command is |
| | | LANGUAGE NOTIFICATION 1.1.1 | different from the one set on the mobile. |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: | [Command performed successfully] |
| | | LANGUAGE NOTIFICATION 1.1.1 | |
| 5 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION | Language of ME may have been replaced by |
| | | ENDED | the one specified in LANGUAGE |
| | | | NOTIFICATION 1.1.1 |

PROACTIVE COMMAND: LANGUAGE NOTIFICATION 1.1.1

Logically:

Command details

Command number: 1

Command type: LANGUAGE NOTIFICATION
Command qualifier: "01" (specific language notification)

Device identities

Source device: SIM
Destination device: ME

Language

Language 'se'(Spanish) \rightarrow 73 65

or 'de'→64 65 (German) for instance: choose a language different from the one initially set on the ME to check the proper execution

of the command

Coding:

| BER-TLV: | D0 | 0D | 81 | 03 | 01 | 35 | 01 | 82 | 02 | 81 | 82 | AD |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 02 | 73 | 65 | | | | | | | | | |

TERMINAL RESPONSE: LANGUAGE NOTIFICATION 1.1.1

Logically:

Command details

Command number: 1

Command type: LANGUAGE NOTIFICATION

Command qualifier: "01"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

| BFR-TLV: | 81 | 03 | 01 | 35 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|

Expected Sequence 1.2 (LANGUAGE NOTIFICATION)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|-----------------------------|---|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: LANGUAGE | |
| | | NOTIFICATION 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: | Language specified in the command is |
| | | LANGUAGE NOTIFICATION 1.1.1 | different from the one set on the mobile. |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: | [Command performed successfully] |
| | | LANGUAGE NOTIFICATION 1.1.1 | |
| 5 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: LANGUAGE | |
| | | NOTIFICATION 1.2.1 | |
| 6 | $ME \rightarrow SIM$ | FETCH | |
| 7 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: | |
| | | LANGUAGE NOTIFICATION 1.2.1 | |
| 8 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: | [Command performed successfully] |
| | | LANGUAGE NOTIFICATION 1.2.1 | |
| 9 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION | Check that initial language is set. |
| | | ENDED | |

PROACTIVE COMMAND: LANGUAGE NOTIFICATION 1.2.1

Logically:

Command details

Command number: 1

Command type: LANGUAGE NOTIFICATION

Command qualifier: "00" (non specific language notification)

Device identities

Source device: SIM
Destination device: ME

Coding:

| BER-TLV: | D0 | 09 | 81 | 03 | 01 | 35 | 00 | 82 | 02 | 81 | 82 |
|----------|----|----|----|----|----|----|----|----|----|----|----|

TERMINAL RESPONSE: LANGUAGE NOTIFICATION 1.2.1

Logically:

Command details

Command number: 1

Command type: LANGUAGE NOTIFICATION

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 35 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|

27.22.4.25.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 and 1.2.

27.22.4.26 LAUNCH BROWSER

27.22.4.26.1 LAUNCH BROWSER (No session already launched)

27.22.4.26.1.1 Definition and applicability

See clause 3.2.2.

27.22.4.26.1.2 Conformance requirements

The ME shall support the LAUNCH BROWSER Proactive SIM Command as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clauses 6.4.26 and 6.6.26, clause 12.6, clause 12.7, clause 12.48, clause 13.2, clause 12.2, clause 12.47, clause 12.49, clause 12.50, clause 12.15 and clause 12.31.

27.22.4.26.1.3 Test purpose

To verify that when the ME is in idle state, it launches properly the browser session required in LAUNCH BROWSER, and returns a successful result in the TERMINAL RESPONSE command.

27.22.4.26.1.4 Method of test

27.22.4.26.1.4.1 Initial conditions

The ME is connected to the SIM Simulator and the System Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

A valid access to 2 different Wap gateways is required:

• the default browser parameters (IP address, gateway/proxy identity, called number, URL ...) of the tested mobile shall be properly filled to access one of the gateways ("default gateway")

With that default gateway we shall be able to access to an URL different from the default one.

• another gateway with an IP address different from the one defined in default browser parameters.

The mobile is in idle mode.

The following Bearer Parameters used are those defined in the default Test PDP context3, as specified in TS 51.010-1 [12], for test cases using packet services:

Bearer Parameters

| Precedence Class: | 02 |
|------------------------|---------|
| Delay Class: | 04 |
| Reliability Class: | 05 |
| Peak throughput class: | 05 |
| Mean throughput class: | 16 |
| Packet data protocol: | 02 (IP) |

GPRS Parameters

| Network access name: | TestGp.rs |
|----------------------|-----------|
| User login: | UserLog |
| User password: | UserPwd |

SIM/ME interface transport level

| Transport format: | UDP |
|-------------------|-------|
| Port number: | 44444 |

Data destination address 01.01.01.01

27.22.4.26.1.4.2 Procedure

Expected Sequence 1.1 (LAUNCH BROWSER, connect to the default URL)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|------------------------------------|---|
| 0 | ME | | [the ME is in idle mode] |
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: LAUNCH BROWSER | |
| | | 1.1.1 | |
| 2 | $ME \to SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | [connect to the default URL, "launch browser, |
| | | LAUNCH BROWSER 1.1.1 | if not already launched", no null alpha id.] |
| 4 | $ME \to USER$ | ME displays the alpha identifier | |
| 5 | $USER \to ME$ | The user may have to confirm the | [option: user confirmation] |
| | | launch browser. | |
| 6 | $ME \to SIM$ | TERMINAL RESPONSE: LAUNCH | [Command performed successfully] |
| | | BROWSER 1.1.1 | |
| 7 | $ME { ightarrow} SS$ | The ME attempts to launch the | |
| | | session with the default browser | |
| | | parameters and the default URL. | |
| 8 | $SIM \to ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |
| 9 | $USER \to ME$ | The user verifies that the default | |
| | | browser session is properly | |
| | | established. | |
| | | Then he/she ends the navigation. | |
| | | The ME returns in idle mode. | |

PROACTIVE COMMAND: LAUNCH BROWSER 1.1.1

Logically:

Command details

Command number:

Command type: LAUNCH BROWSER

Command qualifier: launch browser, if not already launched

Device identities

Source device: SIM
Destination device: ME
URL empty

Alpha Identifier "Default URL"

Coding:

| BER-TLV: | D0 | 18 | 81 | 03 | 01 | 15 | 00 | 82 | 02 | 81 | 82 | 31 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | 05 | 0B | 44 | 65 | 66 | 61 | 75 | 6C | 74 | 20 | 55 |
| | 52 | 4C | | | | | | | | | | |

TERMINAL RESPONSE: LAUNCH BROWSER 1.1.1

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER

Command qualifier: launch browser, if not already launched

Device identities

Source device: ME Destination device: SIM Result

General Result: Command performed successfully

Coding:

| BER-TLV: 81 0: | | 15 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 | 1 |
|----------------|--|----|----|----|----|----|----|----|----|----|---|
|----------------|--|----|----|----|----|----|----|----|----|----|---|

Expected Sequence 1.2 (LAUNCH BROWSER, connect to the specified URL, alpha identifier length=0)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--|--|
| 0 | ME | | [the ME is in idle mode] |
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: LAUNCH BROWSER | |
| | | 1.2.1 | |
| 2 | / 0 | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: | [connect to defined URL, "launch browser, if |
| | | | not already launched, alpha identifier |
| | | | length=0] |
| 4 | $ME \rightarrow USER$ | No information should be | |
| 5 | LICED ME | displayed. | [antion, upor confirmation] |
| 5 | $USER \to ME$ | The user may have to confirm the launch browser. | [option: user confirmation] |
| 6 | ME 	o SIM | 1-3-3 | [Command performed successfully] |
| | IVIL → SIIVI | BROWSER 1.2.1 | [Continuate performed successibility] |
| 7 | ME→SS | The ME attempts to connect the | |
| | WE 700 | URL specified in the LAUNCH | |
| | | BROWSER command. | |
| 8 | $SIM \to ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |
| 9 | $USER \to ME$ | The user verifies that the URL is | |
| | | properly connected. | |
| | | Then he/she ends the navigation. | |
| | | The ME returns in idle mode. | |

PROACTIVE COMMAND: LAUNCH BROWSER 1.2.1

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER

Command qualifier: launch browser, if not already launched

Device identities

Source device: SIM
Destination device: ME

URL http://xxx.yyy.zzz (note: this URL shall be different from the default URL, but it can

be reached from the gateway defined by default in the browser parameters of the

mobile)

Alpha Identifier empty

| BER-TLV: | D0 | 1F | 81 | 03 | 01 | 15 | 00 | 82 | 02 | 81 | 82 | 31 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 12 | 68 | 74 | 74 | 70 | 3A | 2F | 2F | 78 | 78 | 78 | 2E |
| | 70 | 70 | 70 | 2E | 7Δ | 7Δ | 7Δ | 05 | 00 | | | |

TERMINAL RESPONSE: LAUNCH BROWSER 1.2.1

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER

Command qualifier: launch browser, if not already launched

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | Λ1 | 15 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|-----------|----|----|-----|----|----|----|----|----|----|----|----|----|
| DLIX-ILV. | 01 | 03 | U I | 10 | 00 | 02 | 02 | 02 | 01 | 03 | Οī | 00 |

Expected Sequence 1.3 (LAUNCH BROWSER, Browser identity, no alpha identifier)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|------------------------------------|---|
| 0 | ME | | [the ME is in idle mode] |
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: LAUNCH BROWSER | |
| | | 1.3.1 | |
| 2 | / 0 | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | [connect to the default URL, "launch browser, |
| | | LAUNCH BROWSER 1.3.1 | if not already launched, browser identity] |
| 4 | $ME \to USER$ | ME may display a default message | |
| | | of its own. | |
| 5 | $USER \to ME$ | The user may confirm the launch | [option: user confirmation] |
| | | browser. | |
| 6 | $ME \to SIM$ | TERMINAL RESPONSE: LAUNCH | [Command performed successfully] |
| | | BROWSER 1.3.1 | |
| 7 | $ME { ightarrow} SS$ | The ME attempts to connect the | |
| | | default URL. | |
| 8 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |
| 9 | $USER \to ME$ | The user verifies that the default | |
| | | browser session is properly | |
| | | established. | |
| | | Then he/she ends the navigation. | |
| | | The ME returns in idle mode. | |

PROACTIVE COMMAND: LAUNCH BROWSER 1.3.1

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER

Command qualifier: launch browser, if not already launched

Device identities

Source device: SIM
Destination device: ME
Browser Identity default
URL empty

| BER-TLV: | D0 | 0E | 81 | 03 | 01 | 15 | 00 | 82 | 02 | 81 | 82 | 30 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | 00 | 31 | 00 | | | | | | | | |

TERMINAL RESPONSE: LAUNCH BROWSER 1.3.1

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER

Command qualifier: launch browser, if not already launched

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 15 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|-----------|----|----|----|----|----|----|----|----|----|----|----|----|
| DEIX-IEV. | 01 | 00 | 01 | 10 | 00 | 02 | 02 | 02 | 01 | 00 | 01 | 00 |

Expected Sequence 1.4 (LAUNCH BROWSER, only GPRS bearer specified and gateway/proxy identity, GPRS supported by SS)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|------------------------------------|---|
| 0 | ME | | [the ME is in idle mode], GPRS supported by |
| | | | SS, GPRS supported by the ME and |
| | | | activated] |
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: LAUNCH BROWSER | |
| | | 1.4.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: | [connect to the default URL, "launch browser, |
| | | LAUNCH BROWSER 1.4.1 | if not already launched, 1 bearer specified, |
| | | N | gateway/proxy id specified] |
| 4 | | ME may display a default message | |
| 5 | $USER \to ME$ | The user may confirm the launch | [option: user confirmation] |
| | | browser. | 10 1 (1) |
| 6 | $ME \rightarrow SIM$ | | [Command performed successfully] |
| | | BROWSER 1.4.1 | |
| | | | |
| 7 | ME→SS | The ME attempts to connect the | |
| , | IVIE→SS | default URL using the requested | |
| | | bearer and proxy identity | |
| 8 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |
| 9 | $USER \to ME$ | The user verifies that the browser | |
| | COLITY IVIL | session is properly established | |
| | | with the required bearer. Then | |
| | | he/she ends the navigation. | |
| | | The ME returns in idle mode. | |

PROACTIVE COMMAND: LAUNCH BROWSER 1.4.1

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER

Command qualifier: launch browser, if not already launched

Device identities

Source device: SIM
Destination device: ME
URL empty
Bearer GPRS

Gateway/Proxy id

DCSunpacked, 8 bits data

Text string abc.def.ghi (different from the default IP address)

Coding::

| BER-TLV: | D0 | 1C | 81 | 03 | 01 | 15 | 00 | 82 | 02 | 81 | 82 | 31 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | 32 | 01 | 03 | 0D | 0C | 04 | 61 | 62 | 63 | 2E | 64 |
| | 65 | 66 | 2E | 67 | 68 | 69 | | | | | | |

TERMINAL RESPONSE: LAUNCH BROWSER 1.4.1

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER

Command qualifier: launch browser, if not already launched

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 15 00 82 02 82 81 83 01 00

Expected Sequence 1.5 Void

27.22.4.26.1.5 Test Requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.4

27.22.4.26.2 LAUNCH BROWSER (Interaction with current session)

27.22.4.26.2.1 Definition and applicability

See clause 3.2.2.

27.22.4.26.2.2 Conformance requirements

The ME shall support the LAUNCH BROWSER Proactive SIM Command as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clauses 6.4.26 and 6.6.26, clause 12.6, clause 12.7, clause 12.48, clause 13.2, clause 12.2, clause 12.47, optional clause 12.49, optional clause 12.50, clause 12.15 and clause 12.31.

27.22.4.26.2.3 Test purpose

To verify that when the ME is already busy in a browser session, it launches properly the browser session required in LAUNCH BROWSER, and returns a successful result in the TERMINAL RESPONSE.

27.22.4.26.2.4 Method of test

27.22.4.26.2.4.1 Initial conditions

The ME is connected to the SIM Simulator and the System Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

A valid access to a Wap gateway is required. The default browser parameters (IP address, gateway/proxy identity, called number...) of the tested mobile shall be properly filled to access that gateway.

The mobile is busy in a browser session, the user navigates in pages different from the URL defined by default in browser parameters.

27.22.4.26.2.4.2 Procedure

Expected Sequence 2.1 (LAUNCH BROWSER, use the existing browser, connect to the default URL)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|-------------------------------------|--|
| 0 | ME | The user is navigating in a browser | [Browser is in use, the current session is not |
| | 0114 145 | session (not default URL). | secured] |
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: LAUNCH BROWSER 2.1.1 | |
| 2 | ME 	o SIM | FETCH | |
| 3 | / 0 | PROACTIVE COMMAND: | [connect to the default URL, "use the existing |
| 3 | SIIVI -> IVIL | | browser", no null alpha id.] |
| 4 | $MF \rightarrow USFR$ | ME displays the alpha identifier | browed , no nan aipha ia.j |
| 5 | | | [user confirmation] |
| | | browser. | , |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: LAUNCH | [Command performed successfully] |
| | | BROWSER 2.1.1 | |
| 7 | $ME { ightarrow} SS$ | The ME does not close the existing | |
| | | session and attempts to connect | |
| | | the default URL. | |
| 8 | SIM 	o ME | PROACTIVE SIM SESSION | |
| 0 | SIIVI → IVIE | FNDFD | |
| 9 | $USER \to ME$ | The user verifies that the default | |
| | 00211 7 1112 | URL is connected; and the | |
| | | previous URL can be retrieved. | |
| | | Then he/she ends the navigation | |
| | | with the default URL. | |

PROACTIVE COMMAND: LAUNCH BROWSER 2.1.1

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER
Command qualifier: use the existing browser

Device identities

Source device: SIM
Destination device: ME
URL empty

Alpha Identifier "Default URL"

| BER-TLV: | D0 | 18 | 81 | 03 | 01 | 15 | 02 | 82 | 02 | 81 | 82 | 31 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | 05 | 0B | 44 | 65 | 66 | 61 | 75 | 6C | 74 | 20 | 55 |

| 52 | 4C | | | | | |
|----|----|--|--|--|--|--|

TERMINAL RESPONSE: LAUNCH BROWSER 2.1.1

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER
Command qualifier: use the existing browser

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| F | BER-TLV: | 81 | 03 | 01 | 15 | 02 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|---|------------|----|----|----|----|----|----|----|----|-----|----|----|----|
| | JLI\ L\. | 01 | 00 | 01 | 10 | 02 | 02 | 02 | 02 | O I | 00 | 01 | 00 |

Expected Sequence 2.2 (LAUNCH BROWSER, close the existing browser session and launch new browser session, connect to the default URL)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|-------------------------------------|---|
| 0 | ME | The user is navigating in a browser | [Browser is in use, the current session is not |
| | | session (not default URL) | secured] |
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: LAUNCH BROWSER | |
| 2 | ME CIM | 2.2.1 | |
| 2 3 | ME → SIM | FETCH PROACTIVE COMMAND: | [connect to the default LIDL "close the |
| 3 | $SIM \rightarrow ME$ | LAUNCH BROWSER 2.2.1 | [connect to the default URL, "close the existing browser session and launch new |
| | | LAUNCH BROWSER 2.2.1 | browser session", no null alpha id.] |
| 4 | ME → USER | ME displays the alpha identifier | browser session , no num dipria id.] |
| 5 | USER → ME | The user confirms the launch | [user confirmation] |
| | OOLIT / IIIL | browser. | [|
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: LAUNCH | [Command performed successfully] |
| | | BROWSER 2.2.1 | |
| 7 | ME→SS | The ME closes the existing | |
| | | session and attempts to launch the | |
| | | session with the default browser | |
| 8 | OIM ME | parameters and the default URL. | |
| 0 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION | |
| 9 | USER → ME | The user verifies that the default | |
| | OOLIK 7 WIL | URL is connected; and the | |
| | | previous URL cannot be retrieved | |
| | | (to verify the previous session has | |
| | | been closed). | |
| | | Then he/she does not end the | |
| | | navigation. | |

PROACTIVE COMMAND: LAUNCH BROWSER 2.2.1

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER

Command qualifier: close the existing browser session and launch new browser sessionDevice identities

Source device: SIM
Destination device: ME

URL empty

Alpha Identifier "Default URL"

Coding:

| BER-TLV: | D0 | 18 | 81 | 03 | 01 | 15 | 03 | 82 | 02 | 81 | 82 | 31 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | 05 | 0B | 44 | 65 | 66 | 61 | 75 | 6C | 74 | 20 | 55 |
| | 52 | 4C | | | | | | | | | | |

TERMINAL RESPONSE: LAUNCH BROWSER 2.2.1

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER

Command qualifier: close the existing browser session and launch new browser session

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 15 | 03 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|-----------|-----|----|----|----|----|----|----|----|----|----|-----|----|
| DLIX ILV. | 0 1 | 00 | 01 | 10 | 00 | 02 | 02 | 02 | 01 | 00 | 0 1 | 00 |

Expected Sequence 2.3 (LAUNCH BROWSER, if not already launched)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|------------------------------------|--|
| 0 | ME | 5 5 | [Browser is in use, the current session is not |
| | | session (not default URL) | secured] |
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: LAUNCH BROWSER | |
| | | 2.3.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | [connect to the default URL, "launch browser, |
| | | LAUNCH BROWSER 2.3.1 | if not already launched] |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: LAUNCH | [ME unable to process command - browser |
| | | BROWSER 2.3.1 | unavailable] |
| 5 | $SIM \to ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |
| 6 | $USER \ \to ME$ | The user verifies that the default | |
| | | URL has not been connected. | |
| | | Then he/she ends the navigation. | |
| | | The ME returns in idle mode. | |

PROACTIVE COMMAND: LAUNCH BROWSER 2.3.1

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER

Command qualifier: launch browser, if not already launched

Device identities

Source device: SIM
Destination device: ME
URL empty

| BER-TLV: | D0 | 0B | 81 | 03 | 01 | 15 | 00 | 82 | 02 | 81 | 82 | 31 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | | | | | | | | | | | |

TERMINAL RESPONSE: LAUNCH BROWSER 2.3.1

Logically:

Command details

Command number:

Command type: LAUNCH BROWSER

Command qualifier: launch browser, if not already launched

Device identities

Source device: ME Destination device: SIM

Result

General Result: Launch browser generic error code

Additional data Browser unavailable

Coding:

| BER-TLV: | 81 | 03 | 01 | 15 | 00 | 82 | 02 | 82 | 81 | 83 | 02 | 26 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 02 | | | | | | | | | | | |

27.22.4.26.2.5 Test Requirement

The ME shall operate in the manner defined in expected sequences 2.1 to 2.3.

27.22.4.26.3 LAUNCH BROWSER (UCS2 support)

27.22.4.26.3.1 Definition and applicability

See clause 3.2.2.

27.22.4.26.3.2 Conformance requirements

The ME shall support the LAUNCH BROWSER Proactive SIM Command as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clauses 6.4.26 and 6.6.26, clause 12.6, clause 12.7, clause 12.48, clause 13.2, clause 12.2, clause 12.47, optional clause 12.49, optional clause 12.50, clause 12.15 and clause 12.31.

Additionally the ME shall support the UCS2 facility for the coding of the Cyrillic alphabet, as defined in:

• ISO/IEC 10646 [17].

27.22.4.26.2.3 Test purpose

To verify that the ME performs a proper user confirmation with an USC2 alpha identifier, launches the Wap session required in LAUNCH BROWSER and returns a successful result in the TERMINAL RESPONSE command send to the SIM.

27.22.4.26.3.4 Method of test

27.22.4.26.3.4.1 Initial conditions

The ME is connected to the SIM Simulator and the System Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

A valid access to 2 different Wap gateways is required:

• the default browser parameters (IP address, gateway/proxy identity, called number, URL ...) of the tested mobile shall be properly filled to access one of the gateways ("default gateway").

With that default gateway we shall be able to access to an URL different from the default one.

• another gateway with an IP address different from the one defined in default browser parameters.

The mobile is busy in a browser session, the user navigates in pages different from the URL defined by default in browser parameters.

27.22.4.26.3.4.2 Procedure

Expected Sequence 3.1 (LAUNCH BROWSER, use the existing browser, connect to the default URL)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|---|---|
| 0 | ME | The user is navigating in a browser | [Browser is in use, the current session is not |
| 1 | $SIM \rightarrow ME$ | session (not default URL) PROACTIVE COMMAND PENDING: LAUNCH BROWSER 3.1.1 | secured]] |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: LAUNCH BROWSER 3.1.1 | [connect to the default URL, "use the existing browser", alpha id. In UCS2] |
| 4 | $ME \rightarrow USER$ | ME displays the alpha identifier "ЗДРАВСТВУЙТЕ" | ["Hello" in Russian] |
| 5 | $USER \to ME$ | The user confirms the launch browser. | [user confirmation] |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: LAUNCH BROWSER 3.1.1 | [Command performed successfully] |
| 7 | ME→SS | The ME does not close the existing session and attempts to connect the default URL. | |
| 8 | $SIM \to ME$ | PROACTIVE SIM SESSION ENDED | |
| 9 | USER → ME | The user verifies that the default URL is connected; and the previous URL can be retrieved. Then he/she ends the navigation with the default URL. | |

PROACTIVE COMMAND: LAUNCH BROWSER 3.1.1

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER
Command qualifier: use the existing browser

Device identities

Source device: SIM
Destination device: ME
URL empty

Alpha Identifier

Data coding scheme: UCS2 (16 bits)
Text: "ЗДРАВСТВУЙТЕ"

| BER-TLV: | D0 | 26 | 81 | 03 | 01 | 15 | 02 | 82 | 02 | 81 | 82 | 31 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | 05 | 19 | 80 | 04 | 17 | 04 | 14 | 04 | 20 | 04 | 10 |
| | 04 | 12 | 04 | 21 | 04 | 22 | 04 | 12 | 04 | 23 | 04 | 19 |
| | 04 | 22 | 04 | 15 | | | | | | | | |

TERMINAL RESPONSE: LAUNCH BROWSER 3.1.1

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER
Command qualifier: use the existing browser

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 15 | 02 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|

27.22.4.26.3.5 Test Requirement

The ME shall operate in the manner defined in expected sequence 3.1.

27.22.4.26.4 LAUNCH BROWSER (icons support)

27.22.4.26.4.1 Definition and applicability

See clause 3.2.2.

27.22.4.26.4.2 Conformance requirements

The ME shall support the LAUNCH BROWSER Proactive SIM Command as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clauses 6.4.26 and 6.6.26, clause 12.6, clause 12.7, clause 12.48, clause 13.2, clause 12.2, clause 12.47, optional clause 12.49, optional clause 12.50, clause 12.15 and clause 12.31.

27.22.4.26.4.3 Test purpose

To verify that the ME performs a proper user confirmation with an icon identifier, launches the browser session required in LAUNCH BROWSER and returns a successful result in the TERMINAL RESPONSE command send to the SIM.

27.22.4.26.4.4 Method of test

27.22.4.26.4.4.1 Initial conditions

The ME is connected to the SIM Simulator and the System Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

A valid access to 2 different Wap gateways is required:

• the default browser parameters (IP address, gateway/proxy identity, called number, URL ...) of the tested mobile shall be properly filled to access one of the gateways ("default gateway").

With that default gateway we shall be able to access to an URL different from the default one.

• another gateway with an IP address different from the one defined in default browser parameters.

The mobile is busy in a browser session, the user navigates in pages different from the URL defined by default in browser parameters.

27.22.4.26.4.4.2 Procedure

Expected Sequence 4.1A (LAUNCH BROWSER, use the existing browser, icon not self explanatory, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|---|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | [Browser is in use, the current session is not |
| | | PENDING: LAUNCH BROWSER | secured]] |
| | | 4.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: | [connect to the default URL, "use the existing |
| | | | browser", no null alpha id.] |
| 4 | $ME \rightarrow USER$ | | ["Not self explan."] |
| 5 | LICED ME | and the icon The user confirms the launch | [upor confirmation] |
| 5 | $USER \to ME$ | browser. | [user confirmation] |
| 6 | ME 	o SIM | 1 | [Command performed successfully] |
| | IVIL -> SIIVI | BROWSER 4.1.1 A | [Command performed successiony] |
| | | Britaria Eric IIII A | |
| | | | |
| 7 | $ME { ightarrow} SS$ | The ME does not close the existing | |
| | | session and attempts to connect | |
| _ | | the default URL. | |
| 8 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |
| 9 | $USER \to ME$ | The user verifies that the default | |
| | | URL is connected; and the | |
| | | previous URL can be retrieved. | |
| | | Then he/she ends the navigation with the default URL. | |
| | | with the delauit OKL. | |

PROACTIVE COMMAND: LAUNCH BROWSER 4.1.1

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER
Command qualifier: use the existing browser

Device identities

Source device: SIM
Destination device: ME
URL empty

Alpha Identifier "Not self explan."

Icon identifier:

 $\begin{array}{ll} \text{Icon qualifier:} & \text{not self-explanatory} \\ \text{Icon identifier:} & \text{record 1 in } \text{EF}_{\text{(IMG)}} \\ \end{array}$

Coding:

| BER-TLV: | D0 | 21 | 81 | 03 | 01 | 15 | 02 | 82 | 02 | 81 | 82 | 31 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | 05 | 10 | 4E | 6F | 74 | 20 | 73 | 65 | 6C | 66 | 20 |
| | 65 | 78 | 70 | 6C | 61 | 6E | 2E | 1E | 02 | 01 | 01 | |

TERMINAL RESPONSE: LAUNCH BROWSER 4.1.1 A

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER
Command qualifier: use the existing browser

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BE | R-TLV: | 81 | 03 | 01 | 15 | 02 | 82 | 02 | 82 | 81 | 83 | 01 | 00 | 1 |
|----|--------|----|----|----|----|----|----|----|----|----|----|----|----|---|
|----|--------|----|----|----|----|----|----|----|----|----|----|----|----|---|

Expected Sequence 4.1B (LAUNCH BROWSER, use the existing browser, icon not self explanatory, requested icon could not be displayed)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|------------------------------------|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | [Browser is in use, the current session is not |
| | | PENDING: LAUNCH BROWSER | secured]] |
| | | 4.1.1 | |
| 2 | $ME \to SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | [connect to the default URL, "use the existing |
| | | LAUNCH BROWSER 4.1.1 | browser", no null alpha id.] |
| 4 | $ME \to USER$ | ME displays the alpha identifier | ["Not self explan."] |
| | | Without the icon | |
| 5 | $USER \to ME$ | The user confirms the launch | [user confirmation] |
| | | browser. | |
| 6 | $ME \to SIM$ | | [Command performed successfully but |
| | | | requested icon could not be displayed] |
| 7 | ME→SS | The ME does not close the existing | |
| | | session and attempts to connect | |
| | | the default URL. | |
| 8 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |
| 9 | $USER \to ME$ | The user verifies that the default | |
| | | URL is connected; and the | |
| | | previous URL can be retrieved. | |
| | | Then he/she ends the navigation | |
| | | with the default URL. | |

TERMINAL RESPONSE: LAUNCH BROWSER 4.1.1 B

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER
Command qualifier: use the existing browser

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully but requested icon could not be displayed

| BER-TLV: | 81 | 03 | 01 | 15 | 02 | 82 | 02 | 82 | 81 | 83 | 01 | 04 | |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|--|
|----------|----|----|----|----|----|----|----|----|----|----|----|----|--|

Expected Sequence 4.2A (LAUNCH BROWSER, use the existing browser, icon self explanatory, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--|--|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | [Browser is in use, the current session is not |
| | | PENDING: LAUNCH BROWSER | secured]] |
| | | 4.2.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: | [connect to the default URL, "use the existing |
| | | LAUNCH BROWSER 4.2.1 | browser", alpha id. In UCS2] |
| 4 | $ME \rightarrow USER$ | ME displays only the icon | ["Self explan."] |
| 5 | $USER \to ME$ | The user confirms the launch | [user confirmation] |
| | | browser. | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: LAUNCH | [Command performed successfully] |
| _ | | BROWSER 4.2.1 A | |
| 7 | ME→SS | The ME does not close the existing | |
| | | session and attempts to connect the default URL. | |
| 8 | $SIM \rightarrow ME$ | PROACTIVE SIM SESSION | |
| 0 | SIIVI → IVIE | ENDED | |
| 9 | USER → ME | The user verifies that the default | |
| | OSLIN - IVIL | URL is connected; and the | |
| | | previous URL can be retrieved. | |
| | | Then he/she ends the navigation | |
| | | with the default URL. | |

PROACTIVE COMMAND: LAUNCH BROWSER 4.2.1

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER
Command qualifier: use the existing browser

Device identities

Source device: SIM
Destination device: ME
URL empty
Alpha Identifier "Self explan."

Icon identifier:

 $\begin{tabular}{ll} Icon qualifier: & self-explanatory \\ Icon identifier: & record 1 in EF_{(IMG)} \end{tabular}$

Coding:

| BER-TLV: | D0 | 1D | 81 | 03 | 01 | 15 | 02 | 82 | 02 | 81 | 82 | 31 | ĺ |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|---|
| | 00 | 05 | 0C | 53 | 65 | 6C | 66 | 20 | 65 | 78 | 70 | 6C | ĺ |
| | 61 | 6E | 2E | 1E | 02 | 00 | 01 | | | | | | l |

TERMINAL RESPONSE: LAUNCH BROWSER 4.2.1 A

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER
Command qualifier: use the existing browser

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 15 | 02 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|

Expected Sequence 4.2B (LAUNCH BROWSER, use the existing browser, icon self explanatory, requested icon could not be displayed)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|---|---|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: LAUNCH BROWSER | [Browser is in use, the current session is not secured]] |
| | | 4.2.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: LAUNCH BROWSER 4.2.1 | [connect to the default URL, "use the existing browser", alpha id. In UCS2] |
| 4 | $ME \rightarrow USER$ | ME displays only the alpha identifier | ["Self explan."] |
| 5 | $USER \to ME$ | The user confirms the launch browser. | [user confirmation] |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: LAUNCH BROWSER 4.2.1 B | [Command performed successfully] |
| | | | [Command performed successfully but requested icon could not be displayed] |
| 7 | ME→SS | The ME does not close the existing session and attempts to connect the default URL. | |
| 8 | $SIM \to ME$ | PROACTIVE SIM SESSION ENDED | |
| 9 | USER → ME | The user verifies that the default URL is connected; and the previous URL can be retrieved. Then he/she ends the navigation with the default URL. | |

TERMINAL RESPONSE: LAUNCH BROWSER 4.2.1 B

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER
Command qualifier: use the existing browser

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully but requested icon could not be displayed

Coding:

BER-TLV: 81 03 01 15 02 82 02 82 81 83 01 04

27.22.4.26.3.5 Test Requirement

The ME shall operate in the manner defined in expected sequences 4.1A to 4.2B.

27.22.4.27 OPEN CHANNEL

27.22.4.27.1 Void

27.22.4.27.2 Open Channel (related to GPRS)

27.22.4.27.2.1 Definition and applicability

See clause 3.2.2.

27.22.4.27.2.2 Conformance requirements

The ME shall support the class "e" commands as defined in:

• 3GPP TS 11.14 [15].

27.22.4.27.2.3 Test purpose

To verify that the ME shall send a:

- TERMINAL RESPONSE (OK); or
- TERMINAL RESPONSE (Command performed with modification); or
- TERMINAL RESPONSE (User did not accept the proactive command);
- TERMINAL RESPONSE (ME currently unable to process command);

to the SIM after the ME receives the OPEN CHANNEL proactive command. The TERMINAL RESPONSE sent back to the SIM is the result of the ME and the network capabilities against requested parameters by the SIM.

27.22.4.27.2.4 Method of test

27.22.4.27.2.4.1 Initial conditions

The ME is connected to the SIM Simulator and the System Simulator. The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The following Bearer Parameters used are those defined in the default Test PDP context3, as specified in TS 51.010-1 [12], for test cases using packet services:

Bearer Parameters

Precedence Class: 02
Delay Class: 04
Reliability Class: 05
Peak throughput class: 05
Mean throughput class: 31
Packet data protocol: 02 (IP)

GPRS Parameters

Network access name: TestGp.rs User login: UserLog User password: UserPwd

SIM/ME interface transport level

Transport format: UDP

Port number: 44444 Data destination address 01.01.01.01

Prior to test case execution the apparatus supplier shall have provided the "Preferred buffer size supported by the terminal for Open Channel command" as requested in table A.2/5.

Pre-condition for successful execution of expected sequence 2.1:

If the terminal does not support the execution of an Open Channel (GPRS) command when no Network Access Name TLV is present in the proactive command and when no default Access Point Name is set in the terminal configuration (s.a. table A.1/30), then "TestGp.rs" shall be set and activated as default Access Point Name in the terminal configuration prior to execution of the proactive command in expected sequence 2.1.

27.22.4.27.2.4.2 Procedure

Expected Sequence 2.1 (OPEN CHANNEL, immediate link establishment, GPRS, no local address, no alpha identifier, no network access name)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|---|----------------------------------|
| 1 | $USER \to$ | Set and activate APN "TestGp.rs" in the | [see initial conditions] |
| | ME | terminal configuration if required | |
| 2 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: | |
| | | OPEN CHANNEL 2.1.1 | |
| 3 | $ME \rightarrow SIM$ | FETCH | |
| 4 | $SIM \rightarrow ME$ | PROACTIVE COMMAND : OPEN | |
| | | CHANNEL 2.1.1 | |
| 5 | $ME \rightarrow user$ | The ME may display channel opening | |
| | | information | |
| 6 | $ME \rightarrow SS$ | PDP context activation request | |
| 7 | $SS \rightarrow ME$ | PDP context activation accept | |
| 8 | $ME \rightarrow SIM$ | TERMINAL RESPONSE : OPEN | [Command performed successfully] |
| | | CHANNEL 2.1.1 A | |
| | | or | |
| | | TERMINAL RESPONSE : OPEN | |
| | | CHANNEL 2.1.1B | |

PROACTIVE COMMAND: OPEN CHANNEL 2.1.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: SIM
Destination device: ME

Bearer

Bearer type: GPRS

Bearer parameter:

Precedence Class: 02

Delay Class: 04
Reliability Class: 05
Peak throughput class: 05
Mean throughput class: 31
Packet data protocol: 02 (IP)

Buffer

Buffer size: 1400
Text String: UserLog (User login)
Text String: UserPwd (User password)

SIM/ME interface transport level

Transport format: UDP
Port number: 44444
Data destination address 01.01.01.01

Coding:

| BER-TLV: | D0 | 36 | 81 | 03 | 01 | 40 | 01 | 82 | 02 | 81 | 82 | 35 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 07 | 02 | 02 | 04 | 05 | 05 | 1F | 02 | 39 | 02 | 05 | 78 |
| | 0D | 08 | F4 | 55 | 73 | 65 | 72 | 4C | 6F | 67 | 0D | 08 |
| | F4 | 55 | 73 | 65 | 72 | 50 | 77 | 64 | 3C | 03 | 01 | AD |
| | 9C | 3E | 05 | 21 | 01 | 01 | 01 | 01 | | | | |

TERMINAL RESPONSE: OPEN CHANNEL 2.1.1A

Logically:

Command details

Command number:

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Channel status Channel identifier 1 and link established or PDP context activated

Bearer description

Bearer type: GPRS

Bearer parameter:

Precedence Class: 02
Delay Class: 04
Reliability Class: 05
Peak throughput class: 05
Mean throughput class: 31
Packet data protocol: 02 (IP)

Buffer

Buffer size: 1400

Coding:

| BER-TLV: | 81 | 03 | 01 | 40 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 38 | 02 | 81 | 00 | 35 | 07 | 02 | 02 | 04 | 05 | 05 | 1F |
| | 02 | 39 | 02 | 05 | 78 | | | | | | | |

TERMINAL RESPONSE: OPEN CHANNEL 2.1.1B

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Channel status Channel identifier 1 and link established or PDP context activated

Bearer description

Bearer type: GPRS

Bearer parameter:

Precedence Class: 00

Delay Class: 04
Reliability Class: 05
Peak throughput class: 05
Mean throughput class: 31
Packet data protocol: 02 (IP)

Buffer

Buffer size: 1400

Coding:

| BER-TLV: | 81 | 03 | 01 | 40 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 38 | 02 | 81 | 00 | 35 | 07 | 02 | 00 | 04 | 05 | 05 | 1F |
| | 02 | 39 | 02 | 05 | 78 | | | | | | | |

Expected Sequence 2.2 (OPEN CHANNEL, immediate link establishment GPRS, no alpha identifier, with network access name)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------------|--|----------------------------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: OPEN | |
| | | CHANNEL 2.2.1 | |
| 2 | $ME \to SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND : OPEN CHANNEL 2.2.1 | |
| 4 | $\text{ME} \to \text{user}$ | The ME may display channel opening information | |
| | | | |
| 5 | $ME \rightarrow SS$ | PDP context activation request | |
| 6 | $SS \to ME$ | PDP context activation accept | |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE : OPEN CHANNEL 2.2.1A | [Command performed successfully] |
| | | or | |
| | | TERMINAL RESPONSE : OPEN CHANNEL 2.2.1B | |

PROACTIVE COMMAND: OPEN CHANNEL 2.2.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: SIM
Destination device: ME

Bearer

Bearer type: GPRS

Bearer parameter:

Precedence Class: 02
Delay Class: 04
Reliability Class: 05
Peak throughput class: 05
Mean throughput class: 31
Packet data protocol: 02 (IP)

Buffer

Buffer size: 1400 Network access name: TestGp.rs

Text String: UserLog (User login)
Text String: UserPwd (User password)

SIM/ME interface transport level

Transport format: UDP
Port number: 44444
Data destination address 01.01.01.01

Coding:

| BER-TLV: | D0 | 42 | 81 | 03 | 01 | 40 | 01 | 82 | 02 | 81 | 82 | 35 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 07 | 02 | 02 | 04 | 05 | 05 | 1F | 02 | 39 | 02 | 05 | 78 |
| | 47 | 0A | 06 | 54 | 65 | 73 | 74 | 47 | 70 | 02 | 72 | 73 |
| | 0D | 08 | F4 | 55 | 73 | 65 | 72 | 4C | 6F | 67 | 0D | 08 |
| | F4 | 55 | 73 | 65 | 72 | 50 | 77 | 64 | 3C | 03 | 01 | AD |
| | 9C | 3E | 05 | 21 | 01 | 01 | 01 | 01 | | | | |

TERMINAL RESPONSE: OPEN CHANNEL 2.2.1A

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Channel status Channel identifier 1 and link established or PDP context activated

Bearer Description:

Bearer Type: GPRS

Bearer parameter:

Precedence Class: 02
Delay Class: 04
Reliability Class: 05
Peak throughput class: 05
Mean throughput class: 31
Packet data protocol: 02 (IP)

Buffer

Buffer size 1400

Coding:

| BER-TLV: | 81 | 03 | 01 | 40 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| _ | 38 | 02 | 81 | 00 | 35 | 07 | 02 | 02 | 04 | 05 | 05 | 1F |
| | 02 | 39 | 02 | 05 | 78 | | | | | | | |

TERMINAL RESPONSE: OPEN CHANNEL 2.2.1B

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Channel status Channel identifier 1 and link established or PDP context activated

Bearer Description:

Bearer Type: GPRS

Bearer parameter:

Precedence Class: 00 Delay Class: 04 Reliability Class: 05 457

Peak throughput class: 05 Mean throughput class: 31 Packet data protocol: 02 (IP)

Buffer

Buffer size 1400

Coding:

| BER-TLV: | 81 | 03 | 01 | 40 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 38 | 02 | 81 | 00 | 35 | 07 | 02 | 00 | 04 | 05 | 05 | 1F |
| | 02 | 39 | 02 | 05 | 78 | | | | | | | |

Expected Sequence 2.3 (OPEN CHANNEL, immediate link establishment, GPRS, with alpha identifier)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------------|---|----------------------------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: OPEN | |
| | | CHANNEL 2.3.1 | |
| 2 | $ME \to SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND : OPEN CHANNEL 2.3.1 | |
| 4 | $\text{ME} \to \text{user}$ | Confirmation phase with alpha ID | 'Open ID' |
| 5 | $user \to ME$ | The user confirms | |
| 6 | $ME \rightarrow SS$ | PDP context activation request | |
| 7 | $SS \to ME$ | PDP context activation accept | |
| 8 | $ME \rightarrow SIM$ | TERMINAL RESPONSE : OPEN CHANNEL 2.1.1A | [Command performed successfully] |
| | | or | |
| | | TERMINAL RESPONSE : OPEN CHANNEL 2.1.1B | |

PROACTIVE COMMAND: OPEN CHANNEL 2.3.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: SIM
Destination device: ME
Alpha Identifier Open ID

Bearer

Bearer type: GPRS

Bearer parameter:

Precedence Class: 02
Delay Class: 04
Reliability Class: 05
Peak throughput class: 05
Mean throughput class: 31
Packet data protocol: 02 (IP)

Buffer

Buffer size: 1400 Network access name: TestGp.rs

Text String: UserLog (User login)
Text String: UserPwd (User password)

SIM/ME interface transport level

Transport format: UDP
Port number: 44444
Data destination address 01.01.01.01

| BER-TLV: | D0 | 4B | 81 | 03 | 01 | 40 | 01 | 82 | 02 | 81 | 82 | 05 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 07 | 4F | 70 | 65 | 6E | 20 | 49 | 44 | 35 | 07 | 02 | 02 |
| | 04 | 05 | 05 | 1F | 02 | 39 | 02 | 05 | 78 | 47 | 0A | 06 |
| | 54 | 65 | 73 | 74 | 47 | 70 | 02 | 72 | 73 | 0D | 08 | F4 |
| | 55 | 73 | 65 | 72 | 4C | 6F | 67 | 0D | 80 | F4 | 55 | 73 |
| | 65 | 72 | 50 | 77 | 64 | 3C | 03 | 01 | AD | 9C | 3E | 05 |
| | 21 | 01 | 01 | 01 | 01 | | | | | | | |

Expected Sequence 2.4 (OPEN CHANNEL, immediate link establishment, GPRS, with null alpha identifier)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------------|--------------------------------|---|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: OPEN CHANNEL | |
| | | 2.4.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND : OPEN | |
| | | CHANNEL 2.4.1 | |
| 4 | $\text{ME} \to \text{user}$ | Confirmation phase | [The ME should not give any information] |
| 5 | $user \to ME$ | The user confirms | [Only if the ME asks for user confirmation] |
| 6 | $ME \rightarrow SS$ | PDP context activation request | |
| 7 | $SS \rightarrow ME$ | PDP context activation accept | |
| 8 | $ME \rightarrow SIM$ | TERMINAL RESPONSE : OPEN | [Command performed successfully] |
| | | CHANNEL 2.1.1A | |
| | | or | |
| | | TERMINAL RESPONSE : OPEN | |
| | | CHANNEL 2.1.1B | |

PROACTIVE COMMAND: OPEN CHANNEL 2.4.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME
Destination device: SIM

Alpha Identifier Null

Bearer

Bearer type: GPRS

Bearer parameter:

Precedence Class: 02
Delay Class: 04
Reliability Class: 05
Peak throughput class: 05
Mean throughput class: 31
Packet data protocol: 02 (IP)

Buffer

Buffer size: 1400 Network access name: . TestGp.rs

Other Address

Length: 00

Text String: UserLog (User login)
Text String: UserPwd (User password)

SIM/ME interface transport level

Transport format: UDP
Port number: 44444
Data destination address 01.01.01.01

| BER-TLV: | D0 | 46 | 81 | 03 | 01 | 40 | 01 | 82 | 02 | 81 | 82 | 05 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | 35 | 07 | 02 | 02 | 04 | 05 | 05 | 1F | 02 | 39 | 02 |
| | 05 | 78 | 47 | 0A | 06 | 54 | 65 | 73 | 74 | 47 | 70 | 02 |
| | 72 | 73 | 3E | 00 | 0D | 08 | F4 | 55 | 73 | 65 | 72 | 4C |
| | 6F | 67 | 0D | 08 | F4 | 55 | 73 | 65 | 72 | 50 | 77 | 64 |
| | 3C | 03 | 01 | AD | 9C | 3E | 05 | 21 | 01 | 01 | 01 | 01 |

Expected Sequence 2.5 (OPEN CHANNEL, immediate link establishment, GPRS, command performed with modifications (buffer size))

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--------------------------------|---------------------------------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: OPEN CHANNEL | |
| | | 2.5.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND : OPEN | |
| | | CHANNEL 2.5.1 | |
| 4 | $ME \rightarrow user$ | The ME may display channel | |
| | | opening information | |
| | | | |
| 5 | $ME \rightarrow SS$ | PDP context activation request | |
| 6 | $SS \rightarrow ME$ | PDP context activation accept | |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE : OPEN | [Command performed with modification] |
| | | CHANNEL 2.5.1A | |
| | | or | |
| | | TERMINAL RESPONSE : OPEN | |
| | | CHANNEL 2.5.1B | |

PROACTIVE COMMAND: OPEN CHANNEL 2.5.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME Destination device: SIM

Bearer

Bearer type: GPRS

Bearer parameter:

Precedence Class: 02
Delay Class: 04
Reliability Class: 05
Peak throughput class: 05
Mean throughput class: 31
Packet data protocol: 02 (IP)

Buffer

Buffer size: 65535 Network access name: TestGp.rs

Text String: UserLog (User login)
Text String: UserPwd (User password)

SIM/ME interface transport level

Transport format: UDP
Port number: 44444
Data destination address 01.01.01.01

| BER-TLV: | D0 | 42 | 81 | 03 | 01 | 40 | 01 | 82 | 02 | 81 | 82 | 35 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 07 | 02 | 02 | 04 | 05 | 05 | 1F | 02 | 39 | 02 | FF | FF |
| | 47 | 0A | 06 | 54 | 65 | 73 | 74 | 47 | 70 | 02 | 72 | 73 |
| | 0D | 08 | F4 | 55 | 73 | 65 | 72 | 4C | 6F | 67 | 0D | 80 |
| | F4 | 55 | 73 | 65 | 72 | 50 | 77 | 64 | 3C | 03 | 01 | AD |
| | 9C | 3E | 05 | 21 | 01 | 01 | 01 | 01 | | | | |

TERMINAL RESPONSE: OPEN CHANNEL 2.5.1A

Logically:

Command details

Command number:

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed with modifications (07)

Channel status Channel identifier 1 and link established or PDP context activated

Bearer description

Bearer type: GPRS

Bearer parameter:

Precedence Class: 02
Delay Class: 04
Reliability Class: 05
Peak throughput class: 05
Mean throughput class: 31
Packet data protocol: 02 (IP)

Buffer

Buffer size: The buffer size TLV shall be attached and contain the value stated in table A.2/5

"Preferred buffer size supported by the terminal for Open Channel command".

Coding:

| BER-TLV: | 81 | 03 | 01 | 40 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 07 |
|----------|----|--------|----|----|----|----|----|----|----|----|----|----|
| | 38 | 02 | 81 | 00 | 35 | 07 | 02 | 02 | 04 | 05 | 05 | 1F |
| | 02 | Note 1 | | | | | | | | | | |

Note1: The buffer size TLV shall be attached and contain the value stated in table A.2/5 "Preferred buffer size supported by the terminal for Open Channel command".

TERMINAL RESPONSE: OPEN CHANNEL 2.5.1B

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed with modifications (07)

Channel status Channel identifier 1 and link established or PDP context activated

Bearer description

Bearer type: GPRS

Bearer parameter:

Precedence Class: 00

Delay Class: 04
Reliability Class: 05
Peak throughput class: 05
Mean throughput class: 31
Packet data protocol: 02 (IP)

Buffer

Buffer size: The buffer size TLV shall be attached and contain the value stated in table A.2/5

"Preferred buffer size supported by the terminal for Open Channel command".

Coding:

| BER-TLV: | 81 | 03 | 01 | 40 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 07 |
|----------|----|--------|----|----|----|----|----|----|----|----|----|----|
| | 38 | 02 | 81 | 00 | 35 | 07 | 02 | 00 | 04 | 05 | 05 | 1F |
| | 02 | Note 1 | | | | | | | | | | |

Note1: The buffer size TLV shall be attached and contain the value stated in table A.2/5 "Preferred buffer size supported by the terminal for Open Channel command".

Expected Sequence 2.6 Void

Expected Sequence 2.7A (OPEN CHANNEL, immediate link establishment, GPRS, open command with alpha identifier, User did not accept the proactive command)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------------|-----------------------------------|---|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: OPEN CHANNEL | |
| | | 2.7.1 | |
| 2 | $ME \to SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND : OPEN | |
| | | CHANNEL 2.7.1 | |
| 4 | $\text{ME} \to \text{user}$ | Confirmation phase with alpha ID | [The ME shall display 'Open ID'] |
| 5 | $\text{user} \to \text{ME}$ | The user rejects | |
| 6 | $ME \rightarrow SS$ | No PDP context activation request | |
| | | is sent to the SS | |
| 7 | $ME \to SIM$ | TERMINAL RESPONSE : OPEN | [User did not accept the proactive command] |
| | | CHANNEL 2.7.1A | |
| | | or | |
| | | TERMINAL RESPONSE : OPEN | |
| | | CHANNEL 2.7.1B | |

Expected Sequence 2.7B (OPEN CHANNEL, immediate link establishment, GPRS, open command with alpha identifier, User did not accept the proactive command)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------------|----------------------------------|---|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: OPEN CHANNEL | |
| | | 2.7.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND : OPEN | |
| | | CHANNEL 2.7.1 | |
| 4 | $ME \rightarrow SS$ | PDP context activation request | |
| 5 | $SS \to ME$ | PDP context activation accept | |
| 6 | $\text{ME} \to \text{user}$ | Confirmation phase with alpha ID | [The ME shall display 'Open ID'] |
| 7 | $user \to ME$ | The user rejects | |
| 8 | $ME \rightarrow SIM$ | TERMINAL RESPONSE : OPEN | [User did not accept the proactive command] |
| | | CHANNEL 2.7.1A | |
| | | or | |
| | | TERMINAL RESPONSE : OPEN | |
| | | CHANNEL 2.7.1B | |

PROACTIVE COMMAND: OPEN CHANNEL 2.7.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: SIM
Destination device: ME
Alpha Identifier "Open ID"

Bearer

Bearer type: GPRS

Bearer parameter:

Precedence Class: 02
Delay Class: 04
Reliability Class: 05
Peak throughput class: 05
Mean throughput class: 31
Packet data protocol: 02 (IP)

Buffer

Buffer size: 1400

Network access name: TestGp.rs

Text String: UserLog (User login)
Text String: UserPwd (User password)

SIM/ME interface transport level

Transport format: UDP Port number: 44444

Port number: 44444 Data destination address 01.01.01.01

Coding:

| BER-TLV | D0 | 4B | 81 | 03 | 01 | 40 | 01 | 82 | 02 | 81 | 82 | 05 |
|---------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 07 | 4F | 70 | 65 | 6E | 20 | 49 | 44 | 35 | 07 | 02 | 02 |
| | 04 | 05 | 05 | 1F | 02 | 39 | 02 | 05 | 78 | 47 | 0A | 06 |
| | 54 | 65 | 73 | 74 | 47 | 70 | 02 | 72 | 73 | 0D | 08 | F4 |
| | 55 | 73 | 65 | 72 | 4C | 6F | 67 | 0D | 08 | F4 | 55 | 73 |
| | 65 | 72 | 50 | 77 | 64 | 3C | 03 | 01 | AD | 9C | 3E | 05 |
| | 21 | 01 | 01 | 01 | 01 | | | | | | | |

TERMINAL RESPONSE: OPEN CHANNEL 2.7.1A

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME
Destination device: SIM

Result

General Result: User did not accept the proactive command

Bearer description

Bearer type: GPRS

Bearer parameter:

Precedence Class: 02
Delay Class: 04
Reliability Class: 05
Peak throughput class: 05
Mean throughput class: 31
Packet data protocol: 02 (IP)

Buffer

Buffer size: Because the value depends in this case on the terminal's implementation, it shall be

ignored.

Coding:

| BER-TLV: | 81 | 03 | 01 | 40 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 22 |
|----------|----|----|----|----|----|----|----|----|----|--------|----|----|
| | 35 | 07 | 02 | 02 | 04 | 05 | 05 | 1F | 02 | Note 1 | | |

Note1: The buffer size TLV shall be present and because the value depends in this case on the terminal's

implementation, the value shall be ignored.

TERMINAL RESPONSE: OPEN CHANNEL 2.7.1B

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME Destination device: SIM

Result

General Result: User did not accept the proactive command

Bearer description

Bearer type: GPRS

Bearer parameter:

Precedence Class: 00
Delay Class: 04
Reliability Class: 05
Peak throughput class: 05
Mean throughput class: 31
Packet data protocol: 02 (IP)

Buffer

Buffer size: Because the value depends in this case on the terminal's implementation, it shall be

ignored.

Coding:

| BER-TLV: | 81 | 03 | 01 | 40 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 22 |
|----------|----|----|----|----|----|----|----|----|----|--------|----|----|
| | 35 | 07 | 02 | 00 | 04 | 05 | 05 | 1F | 02 | Note 1 | | |

Note1: The buffer size TLV shall be present and because the value depends in this case on the terminal's implementation, the value shall be ignored.

Expected Sequence 2.8 (OPEN CHANNEL, immediate link establishment, GPRS, ME busy on call)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|-----------------------------------|-------------------|
| 1 | $User \to$ | Set up a call | |
| | ME | | |
| 2 | $ME \rightarrow SS$ | SETUP CALL | |
| 3 | $SS \to ME$ | CONNECTED | |
| 4 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: OPEN CHANNEL | |
| | | 2.8.1 | |
| 5 | $ME \rightarrow SIM$ | | |
| 6 | $SIM \rightarrow ME$ | PROACTIVE COMMAND : OPEN | |
| | | CHANNEL 2.8.1 | |
| 7a | $ME \rightarrow SS$ | No PDP context activation request | |
| | | sent to the SS | |
| 7b | $ME \rightarrow SIM$ | TERMINAL RESPONSE : OPEN | [ME busy on call] |
| | | CHANNEL 2.8.1A | |
| | | or | |
| | | TERMINAL RESPONSE : OPEN | |
| | | CHANNEL 2.8.1B | |

PROACTIVE COMMAND: OPEN CHANNEL 2.8.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: SIM
Destination device: ME

Bearer

Bearer type: GPRS

Bearer parameter:

Precedence Class: 02
Delay Class: 04
Reliability Class: 05
Peak throughput class: 05
Mean throughput class: 31
Packet data protocol: 02 (IP)

Buffer

Buffer size: 1400 Network access name: TestGp.rs

Text String: UserLog (User login)
Text String: UserPwd (User password)

SIM/ME interface transport level

Transport format: UDP
Port number: 44444
Data destination address 01.01.01.01

Coding:

| BER-TLV | D0 | 42 | 81 | 03 | 01 | 40 | 01 | 82 | 02 | 81 | 82 | 35 |
|---------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 07 | 02 | 02 | 04 | 05 | 05 | 1F | 02 | 39 | 02 | 05 | 78 |
| | 47 | 0A | 06 | 54 | 65 | 73 | 74 | 47 | 70 | 02 | 72 | 73 |
| | 0D | 08 | F4 | 55 | 73 | 65 | 72 | 4C | 6F | 67 | 0D | 08 |
| | F4 | 55 | 73 | 65 | 72 | 50 | 77 | 64 | 3C | 03 | 01 | AD |
| | 9C | 3F | 05 | 21 | 01 | 01 | 01 | 01 | | | | |

TERMINAL RESPONSE: OPEN CHANNEL 2.8.1A

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME
Destination device: SIM

Result

General Result: ME currently unable to process command

Additional info: ME busy on call

Bearer

Bearer type: GPRS

Bearer parameter:

Precedence Class: 02
Delay Class: 04
Reliability Class: 05
Peak throughput class: 05
Mean throughput class: 31
Packet data protocol: 02 (IP)

Buffer

Buffer size: Because the value depends in this case on the terminal's implementation, it shall be

ignored.

Coding:

| BER-TLV: | 81 | 03 | 01 | 40 | 01 | 82 | 02 | 82 | 81 | 83 | 02 | 20 |
|----------|----|----|----|----|----|----|----|----|----|----|--------|----|
| | 02 | 35 | 07 | 02 | 02 | 04 | 05 | 05 | 1F | 02 | Note 1 | |

Note1: The buffer size TLV shall be present and because the value depends in this case on the terminal's

implementation, the value shall be ignored.

TERMINAL RESPONSE: OPEN CHANNEL 2.8.1B

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME
Destination device: SIM

Result

General Result: ME currently unable to process command

Additional info: ME busy on call

Bearer

Bearer type: GPRS

Bearer parameter:

Precedence Class: 00
Delay Class: 04
Reliability Class: 05
Peak throughput class: 05
Mean throughput class: 31
Packet data protocol: 02 (IP)

Buffer

Buffer size: Because the value depends in this case on the terminal's implementation, it shall be

ignored.

| BER-TLV: | 81 | 03 | 01 | 40 | 01 | 82 | 02 | 82 | 81 | 83 | 02 | 20 |
|----------|----|----|----|----|----|----|----|----|----|----|--------|----|
| | 02 | 35 | 07 | 02 | 00 | 04 | 05 | 05 | 1F | 02 | Note 1 | |

Note1: The buffer size TLV shall be present and because the value depends in this case on the terminal's implementation, the value shall be ignored.

27.22.4.27.2.5 Test requirement

The ME shall operate in the manner defined in expected sequences 2.1 to 2.8.

27.22.4.28 CLOSE CHANNEL

27.22.4.28.1 Definition and applicability

See clause 3.2.2.

27.22.4.28.2 Conformance requirements

The ME shall support the class "e" commands as defined in:

• 3GPP TS 11.14 [15].

27.22.4.28.3 Test purpose

To verify that the ME shall send a:

- TERMINAL RESPONSE (Command Performed Successfully); or
- TERMINAL RESPONSE (Bearer Independent Protocol Error);

to the SIM after the ME receives the CLOSE CHANNEL proactive command. The TERMINAL RESPONSE sent back to the SIM is function of the ME and the network capabilities against asked parameters by the SIM.

27.22.4.28.4 Method of Test

27.22.4.28.4.1 Initial conditions

The ME is connected to the SIM Simulator and the System Simulator. The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

For MEs supporting BIP related to GPRS in UDP (i.e condition C121 in table B.1), The PROACTIVE COMMAND: OPEN CHANNEL 1.1.1 shall be executed to open a channel successfully at the beginning of the test. The corresponding Terminal Response shall be TERMINAL RESPONSE: OPEN CHANNEL 1.1.1A or TERMINAL RESPONSE: OPEN CHANNEL 1.1.1B.

The following Bearer Parameters used are those defined in the default Test PDP context3, as specified in TS 51.010-1 [12], for test cases using packet services:

Bearer Parameters

Precedence Class: 02
Delay Class: 04
Reliability Class: 05
Peak throughput class: 05
Mean throughput class: 31
Packet data protocol: 02 (IP)

GPRS Parameters

Network access name: TestGp.rs

User login: UserLog User password: UserPwd

SIM/ME interface transport level

Transport format: UDP Port number: 44444

Data destination address 01.01.01.01

27.22.4.28.4.2 Procedure

Expected sequence 1.1 (CLOSE CHANNEL, successful)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|--|----------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | See initial conditions |
| | | PENDING: OPEN CHANNEL 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: | |
| | | OPEN CHANNEL 1.1.1 | |
| 4 | ME 	o | The ME may display channel | |
| | USER | opening information | |
| 5 | | PDP context activation request | |
| 6 | $SS \to ME$ | PDP context activation accept | |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: OPEN | [Command performed successfully] |
| | | CHANNEL 1.1.1A | |
| | | or | |
| | | TERMINAL RESPONSE: OPEN | |
| | 0114 145 | CHANNEL 1.1.1B | |
| 8 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: CLOSE CHANNEL | |
| 9 | $ME \rightarrow SIM$ | | |
| | | | |
| 10 | SIIVI → IVIE | PROACTIVE COMMAND: CLOSE CHANNEL 1.1.1 | |
| 11 | ME , CC | PDP context deactivation request | |
| 12 | | • | |
| | | PDP context deactivation accept | [Command performed augeopatully] |
| 13 | ME → SIM | TERMINAL RESPONSE CLOSE CHANNEL 1.1.1 | [Command performed successfully] |

PROACTIVE COMMAND: OPEN CHANNEL 1.1.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: SIM
Destination device: ME

Bearer

Bearer type: GPRS

Bearer parameter:

Precedence Class: 02
Delay Class: 04
Reliability Class: 05
Peak throughput class: 05
Mean throughput class: 31

Packet data protocol: 02 (IP)

Buffer

Buffer size: 1000 Network access name: TestGp.rs

Text String: UserLog (User login)
Text String: UserPwd (User password)

SIM/ME interface transport level

Transport format: UDP
Port number: 44444
Data destination address 01.01.01.01

Coding:

| BER-TLV | D0 | 42 | 81 | 03 | 01 | 40 | 01 | 82 | 02 | 81 | 82 | 35 |
|---------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 07 | 02 | 02 | 04 | 05 | 05 | 1F | 02 | 39 | 02 | 03 | E8 |
| | 47 | 0A | 06 | 54 | 65 | 73 | 74 | 47 | 70 | 02 | 72 | 73 |
| | 0D | 08 | F4 | 55 | 73 | 65 | 72 | 4C | 6F | 67 | 0D | 08 |
| | F4 | 55 | 73 | 65 | 72 | 50 | 77 | 64 | 3C | 03 | 01 | AD |
| | 9C | 3E | 05 | 21 | 01 | 01 | 01 | 01 | | | | |

TERMINAL RESPONSE: OPEN CHANNEL 1.1.1A

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Channel status Channel identifier 1 and link established or PDP context activated

Bearer description

Bearer type: GPRS

Bearer parameter:

Precedence Class: 02
Delay Class: 04
Reliability Class: 05
Peak throughput class: 05
Mean throughput class: 31
Packet data protocol: 02 (IP)

Buffer

Buffer size: 1000

Coding:

| BER-TLV: | 81 | 03 | 01 | 40 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 38 | 02 | 81 | 00 | 35 | 07 | 02 | 02 | 04 | 05 | 05 | 1F |
| | 02 | 39 | 02 | 03 | E8 | | | | | | | |

TERMINAL RESPONSE: OPEN CHANNEL 1.1.1B

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Channel status Channel identifier 1 and link established or PDP context activated

Bearer description

Bearer type: GPRS

Bearer parameter:

Precedence Class: 00
Delay Class: 04
Reliability Class: 05
Peak throughput class: 05
Mean throughput class: 31
Packet data protocol: 02 (IP)

Buffer

Buffer size: 1000

Coding:

| BER-TLV: | 81 | 03 | 01 | 40 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 38 | 02 | 81 | 00 | 35 | 07 | 02 | 00 | 04 | 05 | 05 | 1F |
| | 02 | 39 | 02 | 03 | E8 | | | | | | | |

PROACTIVE COMMAND: CLOSE CHANNEL 1.1.1

Logically:

Command details

Command number: 1

Command type: CLOSE CHANNEL

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: Channel 1

Coding:

| BER-TLV: | D0 | 09 | 81 | 03 | 01 | 41 | 00 | 82 | 02 | 81 | 21 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | | | | | | | | | | | |

TERMINAL RESPONSE: CLOSE CHANNEL 1.1.1

Logically:

Command details

Command number: 1

Command type: CLOSE CHANNEL

Command qualifier: RFU

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

| | | 00 | | | | 00 | | 00 | | 0.2 | | |
|-----------|------|-----|------|------|------|------|------|-----|----|-----|-------|------|
| BER-TLV: | Q 1 | | I ∩1 | 1 11 | 1 00 | 1 00 | -02 | | 01 | | 1 ()1 | 00 |
| IDENTILV. | 1 01 | เบอ | 1 01 | 141 | I UU | 1 02 | I UZ | OZ. | | 00 | | 1 00 |

Expected sequence 1.2 (CLOSE CHANNEL, with an invalid channel identifier)

| Step | Direction | MESSAGE / Action | Comments |
|------|---|---|----------------------------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: OPEN CHANNEL 1.1.1 | See initial conditions |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: OPEN CHANNEL 1.1.1 | |
| 4 | $\begin{array}{c} ME \to \\ USER \end{array}$ | The ME may display channel opening information | |
| 5 | $ME \rightarrow SS$ | PDP context activation request | |
| 6 | | PDP context activation accept | |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: OPEN CHANNEL 1.1.1A | [Command performed successfully] |
| 8 | | or TERMINAL RESPONSE: OPEN CHANNEL 1.1.1B PROACTIVE COMMAND PENDING: CLOSE CHANNEL 1.2.1 | |
| 9 | $ME \rightarrow SIM$ | | |
| 10 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: CLOSE CHANNEL 1.2.1 | |
| 11 | $ME \rightarrow SIM$ | TERMINAL RESPONSE CLOSE CHANNEL 1.2.1 | [Invalid channel number] |

PROACTIVE COMMAND: CLOSE CHANNEL 1.2.1

Logically:

Command details

Command number:

Command type: CLOSE CHANNEL

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: Channel 2

Coding:

| BER-TLV: | D0 | 09 | 81 | 03 | 01 | 41 | 00 | 82 | 02 | 81 | 22 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
|----------|----|----|----|----|----|----|----|----|----|----|----|

TERMINAL RESPONSE: CLOSE CHANNEL 1.2.1

Logically:

Command details

Command number:

Command type: CLOSE CHANNEL

Command qualifier: RFU

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Bearer Independent Protocol error Additional Result: Channel identifier not valid

| BER-TLV: | 81 | 03 | 01 | 41 | 00 | 82 | 02 | 82 | 81 | 83 | 02 | 3A |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| _ | 03 | | | | | | | | | | | |

Expected sequence 1.3 (CLOSE CHANNEL, on an already closed channel)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|---|----------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND PENDING: | See initial conditions |
| _ | | OPEN CHANNEL 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: OPEN | |
| 4 | | CHANNEL 1.1.1 | |
| 4 | ME → | The ME may display channel opening linformation | |
| 5 | USER | | |
| 6 | | PDP context activation request | |
| 7 | | PDP context activation accept TERMINAL RESPONSE: OPEN | [Command norformed augeocafully] |
| / | ME → SIM | CHANNEL 1.1.1A | [Command performed successfully] |
| | | or | |
| | | TERMINAL RESPONSE: OPEN | |
| | | CHANNEL 1.1.1B | |
| 8 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: | |
| | | CLOSE CHANNEL 1.1.1 | |
| 9 | $ME \rightarrow SIM$ | FETCH | |
| 10 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: CLOSE CHANNEL 1.1.1 | |
| 11 | $ME \to SS$ | PDP context deactivation request | |
| 12 | | PDP context deactivation accept | |
| 13 | l. | TERMINAL RESPONSE CLOSE | [Command performed successfully] |
| | | CHANNEL 1.1.1 | |
| 14 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: | |
| | | CLOSE CHANNEL 1.3.1 | |
| 15 | $ME \rightarrow SIM$ | | |
| 16 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: CLOSE | |
| | | CHANNEL 1.3.1 | |
| 17 | $ME \rightarrow SIM$ | TERMINAL RESPONSE CLOSE | [Channel closed] |
| | | CHANNEL 1.3.1A | |
| | | or TERMINAL RESPONSE CLOSE | [Channel identifier invalid] |
| | | CHANNEL 1.3.1B | |
| | l | O1 1/ 11 11 12 L 1.0.1D | |

PROACTIVE COMMAND: CLOSE CHANNEL 1.3.1

Logically:

Command details

Command number:

Command type: CLOSE CHANNEL

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: Channel 1

Coding:

| BER-TLV: D0 09 81 03 01 41 | 00 | 82 | 02 | 81 | 21 |
|----------------------------|----|----|----|----|----|
|----------------------------|----|----|----|----|----|

TERMINAL RESPONSE: CLOSE CHANNEL 1.3.1A

Logically:

Command details

Command number:

Command type: CLOSE CHANNEL

Command qualifier: RFU

Device identities

Source device: ME Destination device: SIM

Result

General Result: Bearer Independent Protocol error

Additional Result: Channel closed

Coding:

| BER-TLV: | 81 | 03 | 01 | 41 | 00 | 82 | 02 | 82 | 81 | 83 | 02 | 3A |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 02 | | | | | | | | | | | |

TERMINAL RESPONSE: CLOSE CHANNEL 1.3.1B

Logically:

Command details

Command number: 1

Command type: CLOSE CHANNEL

Command qualifier: RFU

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Bearer Independent Protocol error

Additional Result: Channel identifier invalid

Coding:

| BER-TLV: | 81 | 03 | 01 | 41 | 00 | 82 | 02 | 82 | 81 | 83 | 02 | 3A |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 03 | | | | | | | | | | | |

27.22.4.28.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.3.

27.22.4.29 RECEIVE DATA

27.22.4.29.1 Definition and applicability

See clause 3.2.2.

27.22.4.29.2 Conformance requirements

The ME shall support the class "e" commands as defined in:

• 3GPP TS 11.14 [15].

27.22.4.29.3 Test purpose

To verify that the ME shall send a:

- TERMINAL RESPONSE (Command Performed Successfully); or
- TERMINAL RESPONSE (ME currently unable to process command); or
- TERMINAL RESPONSE (Bearer Independent Protocol Error);

to the SIM after the ME receives the RECEIVE DATA proactive command. The TERMINAL RESPONSE sent back to the SIM is function of the ME and the network capabilities against asked parameters by the SIM.

27.22.4.29.4 Method of test

27.22.4.29.4.1 Initial conditions

The ME is connected to the SIM Simulator and the System Simulator. The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

For MEs supporting BIP related to GPRS in UDP (i.e condition C121 in table B.1), The PROACTIVE COMMAND: OPEN CHANNEL 1.1.1 shall be executed to open a channel successfully at the beginning of the test. The corresponding Terminal Response shall be TERMINAL RESPONSE: OPEN CHANNEL 1.1.1A or TERMINAL RESPONSE: OPEN CHANNEL 1.1.1B.

The PROACTIVE COMMAND: SEND DATA 1.1.1 shall be performed successfully to detect the ME's port number, which has to be addressed by the network simulator when data has to be transmitted to the card. The corresponding Terminal Response shall be TERMINAL RESPONSE: SEND DATA 1.1.1.

The following Bearer Parameters used are those defined in the default Test PDP context3, as specified in TS 51.010-1 [12], for test cases using packet services:

Bearer Parameters

Precedence Class: 02
Delay Class: 04
Reliability Class: 05
Peak throughput class: 05
Mean throughput class: 31
Packet data protocol: 02 (IP)

GPRS Parameters

Network access name: TestGp.rs
User login: UserLog
User password: UserPwd

SIM/ME interface transport level

Transport format: UDP
Port number: 44444
Data destination address 01.01.01.01

27.22.4.29.4.2 Procedure

Expected sequence 1.1 (RECEIVE DATA, already opened channel)

| Step | Direction | MESSAGE / Action | Comments |
|----------|----------------------|---|---------------------------------------|
| 1 | $SIM \rightarrow ME$ | | |
| | | 1.1.1 PENDING | |
| 2 | $ME \rightarrow SIM$ | | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SET UP EVENT LIST | |
| 4 | ME → SIM | TERMINAL RESPONSE: SET UP EVENT LIST | |
| " | IVIL -> SIIVI | 1.1.1 | |
| 5 | $SIM \rightarrow ME$ | | See initial conditions |
| | | CHANNEL 1.1.1 | |
| 6 | $ME \rightarrow SIM$ | | |
| 7 | $SIM \rightarrow ME$ | | |
| 8 | ME 	o | 1.1.1 The ME may display channel opening information | |
| | USER | The ME may display channel opening information | |
| 9 | | PDP context activation request | |
| 10 | | PDP context activation accept | |
| 11 | $ME \rightarrow SIM$ | · | [Command performed successfully] |
| | | 1.1.1 A | |
| | | or | |
| | | TERMINAL RESPONSE: OPEN CHANNEL | |
| 12 | $SIM \rightarrow ME$ | ***** | |
| 12 | SIIVI -> IVIL | DATA 1.1.1 | |
| 13 | $ME \rightarrow SIM$ | | |
| 14 | $SIM \rightarrow ME$ | | |
| | | (immediate) 1.1.1 | |
| 15 | $ME \rightarrow SS$ | Transfer of 8 Bytes of data to the SS through | [To retrieve ME's port number] |
| 16 | ME → SIM | channel 1 TERMINAL RESPONSE: SEND DATA | [Command norformed acceptable] |
| 10 | INIE -> SIINI | (immediate) 1.1.1 | [Command performed successfully] |
| 17 | $SS \rightarrow ME$ | Transfer of 1000 Bytes of data to the ME through | |
| | | channel 1 using the ME's port number, which was | |
| | | retrieved in step 15 | |
| 18 | $ME \rightarrow SIM$ | | (1000 Bytes of data in the ME buffer) |
| 19 | $SIM \rightarrow ME$ | available 1.1.1 PROACTIVE COMMAND PENDING: RECEIVE | |
| 13 | SIIVI → IVIL | DATA 1.1.1 | |
| 20 | $ME \rightarrow SIM$ | | |
| 21 | | | [200 Bytes] |
| 22 | | TERMINAL RESPONSE: RECEIVE DATA 1.1.1 | · |
| 23 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: RECEIVE | |
| 0.4 | ME 011. | DATA 1.1.2 | |
| 24 | $ME \rightarrow SIM$ | | [200 Butoo] |
| 25 26 | | PROACTIVE COMMAND: RECEIVE DATA 1.1.2 TERMINAL RESPONSE: RECEIVE DATA 1.1.2 | [200 Bytes] |
| 27 | $SIM \rightarrow ME$ | | |
| | Olivi -> IVIL | DATA 1.1.3 | |
| 28 | $ME \rightarrow SIM$ | FETCH | |
| 29 | | PROACTIVE COMMAND: RECEIVE DATA 1.1.3 | [200 Bytes] |
| 30 | $ME \rightarrow SIM$ | | |
| 31 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: RECEIVE | |
| 32 | $ME \rightarrow SIM$ | DATA 1.1.4 | |
| 32 33 | | PROACTIVE COMMAND: RECEIVE DATA 1.1.4 | [200 Bytes] |
| 34 | | TERMINAL RESPONSE: RECEIVE DATA 1.1.4 | [200 Dytes] |
| 35 | | PROACTIVE COMMAND PENDING: RECEIVE | |
| | | DATA 1.1.5 | |
| 36 | $ME \rightarrow SIM$ | | |
| 37 | $ SIM \to ME $ | PROACTIVE COMMAND: RECEIVE DATA 1.1.5 | [200 Bytes] |

38 $ME \rightarrow SIM$ TERMINAL RESPONSE: RECEIVE DATA 1.1.5

PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: ME

Event list Data available

Coding:

| BER-TLV: | D0 | 0C | 81 | 03 | 01 | 05 | 00 | 82 | 02 | 81 | 82 | 99 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| · | 01 | 09 | | | | | | | | | | |

TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: RFU

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 05 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|-----------|----|----|----|----|----|----|------------|----|----|----|----|----|
| DLIX ILV. | 0. | 00 | ٠. | 00 | 00 | Ü- | \ <u>-</u> | 0_ | 0. | 00 | 0. | 00 |

PROACTIVE COMMAND: OPEN CHANNEL 1.1.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: SIM
Destination device: ME

Bearer

Bearer type: GPRS

Bearer parameter:

Precedence Class: 02
Delay Class: 04
Reliability Class: 05
Peak throughput class: 05
Mean throughput class: 31
Packet data protocol: 02 (IP)

Buffer

Buffer size: 1000

Network access name: TestGp.rs

Text String: UserLog (User login)
Text String: UserPwd (User password)

SIM/ME interface transport level

Transport format: UDP
Port number: 44444
Data destination address 01.01.01.01

Coding:

| BER-TLV | D0 | 42 | 81 | 03 | 01 | 40 | 01 | 82 | 02 | 81 | 82 | 35 |
|---------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 07 | 02 | 02 | 04 | 05 | 05 | 1F | 02 | 39 | 02 | 03 | E8 |
| | 47 | 0A | 06 | 54 | 65 | 73 | 74 | 47 | 70 | 02 | 72 | 73 |
| | 0D | 08 | F4 | 55 | 73 | 65 | 72 | 4C | 6F | 67 | 0D | 08 |
| | F4 | 55 | 73 | 65 | 72 | 50 | 77 | 64 | 3C | 03 | 01 | AD |
| | 9C | 3E | 05 | 21 | 01 | 01 | 01 | 01 | | | | |

TERMINAL RESPONSE: OPEN CHANNEL 1.1.1A

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Channel status Channel identifier 1 and link established or PDP context activated

Bearer description

Bearer type: GPRS

Bearer parameter:

Precedence Class: 02
Delay Class: 04
Reliability Class: 05
Peak throughput class: 05
Mean throughput class: 31
Packet data protocol: 02 (IP)

Buffer

Buffer size: 1000

Coding:

| BER-TLV: | 81 | 03 | 01 | 40 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 38 | 02 | 81 | 00 | 35 | 07 | 02 | 02 | 04 | 05 | 05 | 1F |
| | 02 | 39 | 02 | 03 | E8 | | | | | | | |

TERMINAL RESPONSE: OPEN CHANNEL 1.1.1B

Logically:

Command details

Command number:

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Channel status Channel identifier 1 and link established or PDP context activated

Bearer description

Bearer type: GPRS

Bearer parameter:

Precedence Class: 00
Delay Class: 04
Reliability Class: 05
Peak throughput class: 05
Mean throughput class: 31
Packet data protocol: 02 (IP)

Buffer

Buffer size: 1000

Coding:

| BER-TLV: | 81 | 03 | 01 | 40 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 38 | 02 | 81 | 00 | 35 | 07 | 02 | 00 | 04 | 05 | 05 | 1F |
| | 02 | 39 | 02 | 03 | E8 | | | | | | | |

PROACTIVE COMMAND: SEND DATA 1.1.1

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Send Immediately

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data

Channel Data: 00 01 .. 07 (8 Bytes of data)

Coding:

| BER-TLV: | D0 | 13 | 81 | 03 | 01 | 43 | 01 | 82 | 02 | 81 | 21 | B6 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 08 | 00 | 01 | 02 | 03 | 04 | 05 | 06 | 07 | | | |

TERMINAL RESPONSE: SEND DATA 1.1.1

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Send Immediately

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Channel data length: More than 255 bytes of space available in the Tx buffer

| BER-TLV: | 81 | 03 | 01 | 43 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | B7 | 01 | FF | | | | | | | | | |

ENVELOPE: EVENT DOWNLOAD - Data available 1.1.1

Logically:

Event list

Event: Data available

Device identities

Source device: ME Destination device: SIM

Channel status

Channel status: Channel 1 open, link established

Channel Data Length

Channel data length: FF (more than 255 bytes are available)

Coding:

| BER-TLV: | D6 | 0E | 99 | 01 | 09 | 82 | 02 | 82 | 81 | B8 | 02 | 81 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | B7 | 01 | FF | | | | | | | | |

PROACTIVE COMMAND: RECEIVE DATA 1.1.1

Logically:

Command details

Command number:

Command type: RECEIVE DATA

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data Length

Channel Data Length: 200

Coding:

| BER-TLV: | D0 | 0C | 81 | 03 | 01 | 42 | 00 | 82 | 02 | 81 | 21 | B7 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| · | 01 | C8 | | | | | | | | | | |

PROACTIVE COMMAND: RECEIVE DATA 1.1.2

Logically:

Command details

Command number: 2

Command type: RECEIVE DATA

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data Length

Channel Data Length: 200

Coding:

| BER-TLV: | D0 | 0C | 81 | 03 | 02 | 42 | 00 | 82 | 02 | 81 | 21 | B7 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | C8 | | | | | | | | | | |

PROACTIVE COMMAND: RECEIVE DATA 1.1.3

Logically:

Command details

Command number: 3

Command type: RECEIVE DATA

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data Length

Channel Data Length: 200

Coding:

| BER-TLV: | D0 | 0C | 81 | 03 | 03 | 42 | 00 | 82 | 02 | 81 | 21 | B7 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | C8 | | | | | | | | | | |

PROACTIVE COMMAND: RECEIVE DATA 1.1.4

Logically:

Command details

Command number: 4

Command type: RECEIVE DATA

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data Length

Channel Data Length: 200

Coding:

| BER-TLV: | D0 | 0C | 81 | 03 | 04 | 42 | 00 | 82 | 02 | 81 | 21 | B7 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| · | 01 | C8 | | | | | | | | | | |

PROACTIVE COMMAND: RECEIVE DATA 1.1.5

Logically:

Command details

Command number: 5

Command type: RECEIVE DATA

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data Length

Channel Data Length: 200

Coding:

| BER-TLV: | D0 | 0C | 81 | 03 | 05 | 42 | 00 | 82 | 02 | 81 | 21 | B7 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | C8 | | | | | | | | | | |

TERMINAL RESPONSE: RECEIVE DATA 1.1.1

Logically:

Command details

Command number: 1

Command type: RECEIVE DATA

Command qualifier: RFU

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully Channel Data : 00 01 02 .. C7 (200 Bytes of data)

Channel data length: FF

Coding:

| BER-TLV: | 81 | 03 | 01 | 42 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| - | B6 | 81 | C8 | 00 | 01 | 02 | | C7 | B7 | 01 | FF | |
| | | | | | | | | | | | | |

TERMINAL RESPONSE: RECEIVE DATA 1.1.2

Logically:

Command details

Command number: 2

Command type: RECEIVE DATA

Command qualifier: RFU

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Channel Data: C8 C9 CA .. FF 00 01 .. 8F (200 Bytes of data)

Channel data length: FF

Coding:

| BER-TLV: | 81 | 03 | 02 | 42 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 | i |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|---|
| | B6 | 81 | C8 | C8 | C9 | CA | | FF | 00 | 01 | 02 | | i |
| | 8F | B7 | 01 | FF | | | | | | | | _ | i |

TERMINAL RESPONSE: RECEIVE DATA 1.1.3

Logically:

Command details

Command number: 3

Command type: RECEIVE DATA

Command qualifier: RFU

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Channel Data : 90 91 .. FF 00 01 – 57 (200 Bytes of data)

Channel data length: FF

| BER-TLV: | 81 | 03 | 03 | 42 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | B6 | 81 | C8 | 90 | 91 | 92 | | FF | 00 | 01 | 02 | |
| | 57 | B7 | 01 | FF | | | | | | | | |

TERMINAL RESPONSE: RECEIVE DATA 1.1.4

Logically:

Command details

Command number: 4

Command type: RECEIVE DATA

Command qualifier: RFU

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully
Channel Data: 58 59 .. FF 00 01 .. 1F (200 Bytes of data)

Channel data length: C8

Coding:

| BER-TLV: | 81 | 03 | 04 | 42 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | B6 | 81 | C8 | 58 | 59 | 5A | | FF | 00 | 01 | 02 | |
| | 1F | B7 | 01 | C8 | | | | | | | | |

TERMINAL RESPONSE: RECEIVE DATA 1.1.5

Logically:

Command details

Command number: 5

Command type: RECEIVE DATA

Command qualifier: RFU

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully Channel Data: 20 21 .. E7 (200 Bytes of data)

Channel data length: 00

Coding:

| BER-TLV: | 81 | 03 | 05 | 42 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | B6 | 81 | C8 | 20 | 21 | 22 | | E7 | B7 | 01 | 00 | |
| | | | | | | | | | | | | |

27.22.4.29.5 Test requirement

The ME shall operate in the manner defined in expected sequence 1.1.

27.22.4.30 SEND DATA

27.22.4.30.1 Definition and applicability

See clause 3.2.2.

27.22.4.30.2 Conformance requirements

The ME shall support the class "e" commands as defined in:

• 3GPP TS 11.14 [15].

27.22.4.30.3 Test purpose

To verify that the ME shall send a:

- TERMINAL RESPONSE (Command Performed Successfully); or
- TERMINAL RESPONSE (ME currently unable to process command); or
- TERMINAL RESPONSE (Bearer Independent Protocol Error);
- TERMINAL RESPONSE (Proactive SIM session terminated by the user);

to the SIM after the ME receives the SEND DATA proactive command. The TERMINAL RESPONSE sent back to the SIM is the result of the ME and the network capabilities against requested parameters by the SIM.

27.22.4.30.4 Method of test

27.22.4.30.4.1 Initial conditions

The ME is connected to the SIM Simulator and the System Simulator. The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

For MEs supporting BIP related to GPRS in UDP (i.e condition C121 in table B.1), The PROACTIVE COMMAND: OPEN CHANNEL 1.1.1 shall be executed to open a channel successfully at the beginning of the test. The corresponding Terminal Response shall be TERMINAL RESPONSE: OPEN CHANNEL 1.1.1A or TERMINAL RESPONSE: OPEN CHANNEL 1.1.1B.

The following Bearer Parameters used are those defined in the default Test PDP context3, as specified in TS 51.010-1 [12], for test cases using packet services:

Bearer Parameters

Precedence Class: 02
Delay Class: 04
Reliability Class: 05
Peak throughput class: 05
Mean throughput class: 31
Packet data protocol: 02 (IP)

GPRS Parameters

Network access name: TestGp.rs User login: UserLog User password: UserPwd

SIM/ME interface transport level

Transport format: UDP
Port number: 44444
Data destination address 01.01.01.01

27.22.4.30.4.2 Procedure

Expected sequence 1.1 (SEND DATA, immediate mode)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|------------------------------------|----------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: OPEN CHANNEL 1.1.1 | See initial conditions |
| 2 | $ME \rightarrow SIM$ | I - | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: OPEN | |
| | | CHANNEL 1.1.1 | |
| 4 | $ME \to$ | The ME may display channel | |
| | USER | opening information | |
| 5 | | PDP context activation request | |
| 6 | | PDP context activation accept | |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: OPEN | [Command performed successfully] |
| | | CHANNEL 1.1.1A | |
| | | or | |
| | | TERMINAL RESPONSE: OPEN | |
| _ | | CHANNEL 1.1.1B | |
| 8 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: SEND DATA 1.1.1 | |
| 9 | $ME \rightarrow SIM$ | | |
| 10 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SEND | |
| | | DATA (immediate) 1.1.1 | |
| 11 | $ME \rightarrow SS$ | Transfer of 8 Bytes of data to the | |
| 40 | | SS through channel 1 | |
| 12 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND | [Command performed successfully] |
| | | DATA (immediate) 1.1.1 | |

PROACTIVE COMMAND: OPEN CHANNEL 1.1.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: SIM
Destination device: ME

Bearer

Bearer type: GPRS

Bearer parameter:

Precedence Class: 02
Delay Class: 04
Reliability Class: 05
Peak throughput class: 05
Mean throughput class: 31
Packet data protocol: 02 (IP)

Buffer

Buffer size: 1000 Network access name: TestGp.rs

Text String: UserLog (User login)
Text String: UserPwd (User password)

SIM/ME interface transport level

Transport format: UDP
Port number: 44444
Data destination address 01.01.01.01

| BER-TLV | D0 | 42 | 81 | 03 | 01 | 40 | 01 | 82 | 02 | 81 | 82 | 35 |
|---------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 07 | 02 | 02 | 04 | 05 | 05 | 1F | 02 | 39 | 02 | 03 | E8 |
| | 47 | 0A | 06 | 54 | 65 | 73 | 74 | 47 | 70 | 02 | 72 | 73 |
| | 0D | 08 | F4 | 55 | 73 | 65 | 72 | 4C | 6F | 67 | 0D | 08 |
| | F4 | 55 | 73 | 65 | 72 | 50 | 77 | 64 | 3C | 03 | 01 | AD |
| | 9C | 3E | 05 | 21 | 01 | 01 | 01 | 01 | | | | |

TERMINAL RESPONSE: OPEN CHANNEL 1.1.1A

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Channel status Channel identifier 1 and link established or PDP context activated

Bearer description

Bearer type: GPRS

Bearer parameter:

Precedence Class: 02
Delay Class: 04
Reliability Class: 05
Peak throughput class: 05
Mean throughput class: 31
Packet data protocol: 02 (IP)

Buffer

Buffer size: 1000

Coding:

| BER-TLV: | 81 | 03 | 01 | 40 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 38 | 02 | 81 | 00 | 35 | 07 | 02 | 02 | 04 | 05 | 05 | 1F |
| | 02 | 39 | 02 | 03 | E8 | | | | | | | |

TERMINAL RESPONSE: OPEN CHANNEL 1.1.1B

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Channel status Channel identifier 1 and link established or PDP context activated

Bearer description

Bearer type: GPRS

Bearer parameter:

Precedence Class: 00
Delay Class: 04
Reliability Class: 05
Peak throughput class: 05
Mean throughput class: 31

Packet data protocol: 02 (IP)

Buffer

Buffer size: 1000

Coding:

| BER-TLV: | 81 | 03 | 01 | 40 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 38 | 02 | 81 | 00 | 35 | 07 | 02 | 00 | 04 | 05 | 05 | 1F |
| | 02 | 39 | 02 | 03 | E8 | | | | | | | |

PROACTIVE COMMAND: SEND DATA 1.1.1

Logically:

Command details

Command number:

Command type: SEND DATA
Command qualifier: Send Immediately

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data

Channel Data: 00 01 .. 07 (8 Bytes of data)

Coding:

| BER-TLV: | D0 | 13 | 81 | 03 | 01 | 43 | 01 | 82 | 02 | 81 | 21 | B6 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| · | 08 | 00 | 01 | 02 | 03 | 04 | 05 | 06 | 07 | | | |

TERMINAL RESPONSE: SEND DATA 1.1.1

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Send Immediately

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Channel data length: More than 255 bytes of space available in the Tx buffer

| BER-TLV: | 81 | 03 | 01 | 43 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | B7 | 01 | FF | | | | | | | | | |

Expected sequence 1.2 (SEND DATA, Store mode)

| Step | Direction | MESSAGE / Action | Comments |
|------|---|---|--|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: OPEN CHANNEL 1.1.1 | See initial conditions |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: OPEN CHANNEL 1.1.1 | |
| 4 | $\begin{array}{c} ME \to \\ USER \end{array}$ | The ME may display channel opening information | |
| 5 | $ME \to SS$ | PDP context activation request | |
| 6 | $SS \rightarrow ME$ | PDP context activation accept | |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: OPEN CHANNEL 1.1.1A | [Command performed successfully] |
| _ | | or TERMINAL RESPONSE: OPEN CHANNEL 1.1.1B | |
| 8 | | PROACTIVE COMMAND PENDING: SEND DATA 1.2.1 | |
| 9 | $ME \rightarrow SIM$ | | |
| 10 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SEND DATA (store mode) 1.2.1 | Send 500 Bytes of data (200 + 200 + 100) |
| 11 | $ME \rightarrow SIM$ | TERMINAL RESPÓNSE: SEND DATA (store mode) 1.2.1 | [Command performed successfully] |
| 12 | $SIM \rightarrow ME$ | , , | |
| 13 | $ME \rightarrow SIM$ | FETCH | |
| 14 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SEND DATA (store mode) 1.2.2 | [200 Bytes] |
| 15 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND DATA (store mode) 1.2.2 | [Command performed successfully] |
| 16 | $SIM \to ME$ | PROACTIVE COMMAND PENDING: SEND DATA 1.2.3 | |
| 17 | $ME \rightarrow SIM$ | | |
| 18 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SEND DATA (Immediate mode) 1.2.3 | [100 Bytes] |
| 19 | $ME \rightarrow SS$ | Transfer of 500 Bytes of data to the SS through channel 1 | |
| 20 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND DATA (Immediate mode) 1.2.3 | [Command performed successfully] |

PROACTIVE COMMAND: SEND DATA 1.2.1

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Store mode

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data

Channel Data: 00 01 .. C7 (200 Bytes of data)

Coding:

| BER-TLV: | D0 | 81 | D4 | 81 | 03 | 01 | 43 | 00 | 82 | 02 | 81 | 21 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | B6 | 81 | C8 | 00 | 01 | | C7 | | | | | |

TERMINAL RESPONSE: SEND DATA 1.2.1

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Store mode

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Channel data length: More than 255 bytes of space available in the Tx buffer

Coding:

| BER-TLV: | 81 | 03 | 01 | 43 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | B7 | 01 | FF | | | | | | | | | |

PROACTIVE COMMAND: SEND DATA 1.2.2

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Store mode

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data

Channel Data : C8 C9 .. FF 00 01 .. 8F (200 Bytes of data)

Coding:

| BER-TLV: | D0 | 81 | D4 | 81 | 03 | 01 | 43 | 00 | 82 | 02 | 81 | 21 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | В6 | 81 | C8 | C8 | C9 | | FF | 00 | 01 | | 8F | |

TERMINAL RESPONSE: SEND DATA 1.2.2

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Store mode

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Channel data length: More than 255 bytes of space available in the Tx buffer

Coding:

| BER-TLV: | 81 | 03 | 01 | 43 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | B7 | 01 | FF | | | | | | | | | |

PROACTIVE COMMAND: SEND DATA 1.2.3

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Immediate mode

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data

Channel Data: 90 91 .. F3 (100 Bytes of data)

Coding:

| BER-TLV: | D0 | 6F | 81 | 03 | 01 | 43 | 01 | 82 | 02 | 81 | 21 | B6 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 64 | 90 | 91 | | F3 | | | | | | | |

TERMINAL RESPONSE: SEND DATA 1.2.3

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Immediate mode

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Channel data length: More than 255 bytes of space available in the Tx buffer

Coding:

| BER-TLV: | 81 | 03 | 01 | 43 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| · | B7 | 01 | FF | | | | | | | | | |

Expected sequence 1.3 (SEND DATA, Store mode, Tx buffer fully used)

| Step | Direction | MESSAGE / Action | Comments |
|----------|---|---|--|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: OPEN | See initial conditions |
| | | CHANNEL 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: OPEN CHANNEL | |
| | | 1.1.1 | |
| 4 | $ME \to$ | The ME may display channel opening | |
| _ | USER | information | |
| 5 | | PDP context activation request | |
| 6 | | PDP context activation accept | |
| 7 | $ME \to SIM$ | | [Command performed successfully] |
| | | 1.1.1A | |
| | | or TERMINAL RESPONSE: OPEN CHANNEL | |
| | | 1.1.1B | |
| 8 | $SIM \to ME$ | PROACTIVE COMMAND PENDING: SEND | |
| | 7 III 2 | DATA 1.3.1 | |
| 9 | $ME \rightarrow SIM$ | FETCH | |
| 10 | | PROACTIVE COMMAND: SEND DATA (store | Send 1000 Bytes of data by packet of 200 |
| | | mode) 1.3.1 | Bytes |
| 11 | $ME \to SIM$ | TERMINAL RESPONSE: SEND DATA (store | [Command performed successfully] |
| 4.0 | | mode) 1.3.1 | |
| 12 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: SEND | |
| 13 | $ME \to SIM$ | DATA 1.3.2 | |
| 14 | | PROACTIVE COMMAND: SEND DATA (store | [200 Bytes] |
| 14 | | mode) 1.3.2 | [200 Bytes] |
| 15 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND DATA (store | [Command performed successfully] |
| | , | mode) 1.3.2 | [, |
| 16 | $SIM \to ME$ | PROACTIVE COMMAND PENDING: SEND | |
| | | DATA 1.3.3 | |
| 17 | $ME \rightarrow SIM$ | | |
| 18 | $SIM \rightarrow ME$ | <u> </u> | [200 Bytes] |
| 40 | | mode) 1.3.3 | 10 |
| 19 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND DATA (store mode) 1.3.3 | [Command performed successfully] |
| 20 | $SIM \to ME$ | PROACTIVE COMMAND PENDING: SEND | |
| | Olivi — IVIE | DATA 1.3.4 | |
| 21 | $ME \rightarrow SIM$ | | |
| 22 | | PROACTIVE COMMAND: SEND DATA (store | [200 Bytes] |
| | | mode) 1.3.4 | |
| 23 | $ME \to SIM$ | TERMINAL RESPONSE: SEND DATA (store | [Command performed successfully] |
| | | mode) 1.3.4 | |
| 24 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: SEND | |
| 25 | NAT CINA | DATA 1.3.5 FETCH | |
| 25 26 | | PROACTIVE COMMAND: SEND DATA | [200 Bytes] |
| 20 | | (immediate) 1.3.5 | [200 Dyles] |
| 27 | $ME \to SS$ | Transfer of 1000 Bytes of data to the SS | |
| | / 00 | through channel 1 | |
| 28 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND DATA | [Command performed successfully] |
| | | (immediate) 1.3.5 | |

PROACTIVE COMMAND: SEND DATA 1.3.1

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Store mode

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data

Channel Data: 00 01 02 .. C7 (200 Bytes of data)

Coding:

| BER-TLV: | D0 | 81 | D4 | 81 | 03 | 01 | 43 | 00 | 82 | 02 | 81 | 21 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | B6 | 81 | C8 | 00 | 01 | 02 | | C7 | | | | |

TERMINAL RESPONSE: SEND DATA 1.3.1

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Store mode

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Channel data length: More than 255 bytes of space available in the Tx buffer

Coding:

| BER-TLV: | 81 | 03 | 01 | 43 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| · | B7 | 01 | FF | | | | | | | | | |

PROACTIVE COMMAND: SEND DATA 1.3.2

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Store mode

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data

Channel Data: C8 C9 CA .. FF 00 01 .. 8F (200 Bytes of data)

Coding:

| BER-TLV: | D0 | 81 | D4 | 81 | 03 | 01 | 43 | 00 | 82 | 02 | 81 | 21 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | B6 | 81 | C8 | C8 | C9 | CA | | FF | 00 | 02 | | 8F |

TERMINAL RESPONSE: SEND DATA 1.3.2

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Store mode

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Channel data length: More than 255 bytes of space available in the Tx buffer

Coding:

| BER-TLV: | 81 | 03 | 01 | 43 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | B7 | 01 | FF | | | | | | | | | |

PROACTIVE COMMAND: SEND DATA 1.3.3

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Store mode

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data

Channel Data : 90 91 .. FF 00 01 .. 57 (200 Bytes of data)

Coding:

| BER-TLV: | D0 | 81 | D4 | 81 | 03 | 01 | 43 | 00 | 82 | 02 | 81 | 21 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | B6 | 81 | C8 | 90 | 91 | | FF | 00 | 01 | | 57 | |

TERMINAL RESPONSE: SEND DATA 1.3.3

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Store mode

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Channel data length: More than 255 bytes of space available in the Tx buffer

Coding:

| BER-TLV: | 81 | 03 | 01 | 43 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | B7 | 01 | FF | | | | | | | | | |

PROACTIVE COMMAND: SEND DATA 1.3.4

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Store mode

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data

Channel Data : 58 59 .. FF 00 01 .. 1F (200 Bytes of data)

| BER-TLV: | D0 | 81 | D4 | 81 | 03 | 01 | 43 | 00 | 82 | 02 | 81 | 21 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | B6 | 81 | C8 | 58 | 59 | | FF | 00 | 01 | | 1F | |

TERMINAL RESPONSE: SEND DATA 1.3.4

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Store mode

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Channel data length: 200 bytes of space available in the Tx buffer

Coding:

| BER-TLV: | 81 | 03 | 01 | 43 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | B7 | 01 | C8 | | | | | | | | | |

PROACTIVE COMMAND: SEND DATA 1.3.5

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Send Immediately

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data

Channel Data: 20 21 .. E7 (200 Bytes of data)

Coding:

| BER-TLV: | D0 | 81 | D4 | 81 | 03 | 01 | 43 | 01 | 82 | 02 | 81 | 21 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | B6 | 81 | C8 | 20 | 21 | | E7 | | | | | |

TERMINAL RESPONSE: SEND DATA 1.3.5

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Send Immediately

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Channel data length: More than 255 bytes of space available in the Tx buffer

| BER-TLV: | 81 | 03 | 01 | 43 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | B7 | 01 | FF | | | | | | | | | |

Expected sequence 1.4 (SEND DATA, 2 consecutive SEND DATA Store mode)

| Cton | Direction | MESSACE / Action | Comments |
|------|---|---|---|
| Step | Direction | MESSAGE / Action PROACTIVE COMMAND PENDING: OPEN | Comments See initial conditions |
| 1 | SIM → ME | CHANNEL 1.1.1 | See initial conditions |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: OPEN CHANNEL 1.1.1 | |
| 4 | $\begin{array}{c} ME \to \\ USER \end{array}$ | The ME may display channel opening information | |
| 5 | $ME \rightarrow SS$ | PDP context activation request | |
| 6 | | PDP context activation accept | |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: OPEN CHANNEL | [Command performed successfully] |
| | WIE 7 SIW | 1.1.1A or TERMINAL RESPONSE: OPEN CHANNEL | [command portormed addecedamy] |
| 8 | $SIM \to ME$ | 1.1.1B PROACTIVE COMMAND PENDING: SEND DATA 1.3.1 | |
| 9 | $ME \rightarrow SIM$ | | |
| 10 | | PROACTIVE COMMAND: SEND DATA | Send 1000 Bytes of data by packets of 200 |
| 11 | ME → SIM | (store mode) 1.3.1 TERMINAL RESPONSE: SEND DATA | Bytes [Command performed successfully] |
| | IVIE 7 OIIVI | (store mode) 1.3.1 | [Command performed edecederally] |
| 12 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: SEND DATA 1.3.2 | |
| 13 | $ME \rightarrow SIM$ | FETCH | |
| 14 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SEND DATA (store mode) 1.3.2 | [200 Bytes] |
| 15 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND DATA (store mode) 1.3.2 | [Command performed successfully] |
| 16 | $SIM \rightarrow ME$ | PROACTIVÉ COMMAND PENDING: SEND DATA 1.3.3 | |
| 17 | $ME \rightarrow SIM$ | FETCH | |
| 18 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SEND DATA (store mode) 1.3.3 | [200 Bytes] |
| 19 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND DATA (store mode) 1.3.3 | [Command performed successfully] |
| 20 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: SEND DATA 1.3.4 | |
| 21 | $ME \rightarrow SIM$ | FETCH | |
| 22 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SEND DATA | [200 Bytes] |
| 23 | $ME \rightarrow SIM$ | (store mode) 1.3.4 TERMINAL RESPONSE: SEND DATA | [Command performed successfully] |
| 24 | $SIM \rightarrow ME$ | (store mode) 1.3.4 PROACTIVE COMMAND PENDING: SEND DATA 1.3.5 | |
| 25 | $ME \rightarrow SIM$ | FETCH | |
| 26 | SIM → ME | PROACTIVE COMMAND: SEND DATA (immediate) 1.3.5 | |
| 27 | $ME \rightarrow SS$ | Transfer of 1000 Bytes of data to the SS through channel 1 | |
| 28 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND DATA (immediate) 1.3.5 | [Command performed successfully] |
| 29 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: SEND DATA 1.3.1 | |
| 30 | $ME \rightarrow SIM$ | FETCH | |
| 31 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SEND DATA | Send 1000 Bytes of data by packets of 200 |
| | | (store mode) 1.3.1 | Bytes |
| 32 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND DATA (store mode) 1.3.1 | [Command performed successfully] |
| 33 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: SEND DATA 1.3.2 | |
| 34 | $ME \rightarrow SIM$ | FETCH | |
| 35 | $SIM \to ME$ | PROACTIVE COMMAND: SEND DATA | [200 Bytes] |
| 36 | $ME \rightarrow SIM$ | (store mode) 1.3.2 TERMINAL RESPONSE: SEND DATA | [Command performed successfully] |
| | | (store mode) 1.3.2 | |
| 37 | $ SIM \to ME $ | PROACTIVE COMMAND PENDING: SEND DATA 1.3.3 | |

| 38 | $ME \rightarrow SIM$ | FETCH | |
|----|----------------------|---|----------------------------------|
| 39 | $SIM \to ME$ | PROACTIVE COMMAND: SEND DATA | [200 Bytes] |
| | | (store mode) 1.3.3 | |
| 40 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND DATA | [Command performed successfully] |
| 41 | $SIM \rightarrow ME$ | (store mode) 1.3.3 PROACTIVE COMMAND PENDING: SEND | |
| "' | SIIVI → IVIL | DATA 1.3.4 | |
| 42 | $ME \rightarrow SIM$ | | |
| 43 | $SIM \to ME$ | PROACTIVE COMMAND: SEND DATA | [200 Bytes] |
| | | (store mode) 1.3.4 | |
| 44 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND DATA | [Command performed successfully] |
| 4- | | (store mode) 1.3.4 | |
| 45 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: SEND DATA 1.3.5 | |
| 46 | ME → SIM | | |
| | | | |
| 47 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SEND DATA | |
| 40 | | (immediate) 1.3.5 | |
| 48 | $ME \rightarrow SS$ | Transfer of 1000 Bytes of data to the SS | |
| | | through channel 1 | |
| 49 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND DATA | [Command performed successfully] |
| | | (immediate) 1.3.5 | |

Expected sequence 1.5 (SEND DATA, immediate mode with a bad channel identifier)

| Step | Direction | MESSAGE / Action | Comments |
|------|---|--|----------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND PENDING: OPEN CHANNEL 1.1.1 | See initial conditions |
| 2 | $ME \rightarrow SIM$ | | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: OPEN CHANNEL 1.1.1 | |
| 4 | $\begin{array}{c} ME \to \\ USER \end{array}$ | The ME may display channel opening information | |
| 5 | $ME \to SS$ | PDP context activation request | |
| 6 | $SS \to ME$ | PDP context activation accept | |
| 7 | $ME \to SIM$ | TERMINAL RESPONSE: OPEN CHANNEL 1.1.1A | [Command performed successfully] |
| | | or | |
| | | TERMINAL RESPONSE: OPEN | |
| | | CHANNEL 1.1.1B | |
| 8 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SEND DATA 1.5.1 | |
| 9 | $ME \to SIM$ | FETCH | |
| 10 | $SIM \to ME$ | PROACTIVE COMMAND: SEND | |
| | | DATA (immediate) 1.5.1 | |
| 11 | $ME \rightarrow SIM$ | | [Invalid channel number] |
| | | DATA (immediate) 1.5.1 | |

PROACTIVE COMMAND: SEND DATA 1.5.1

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Send Immediately

Device identities

Source device: SIM
Destination device: Channel 2

Channel Data

Channel Data: 00 01 .. 07 (8 Bytes of data)

| BER-TLV: | D0 | 13 | 81 | 03 | 01 | 43 | 01 | 82 | 02 | 81 | 22 | B6 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 08 | 00 | 01 | 02 | 03 | 04 | 05 | 06 | 07 | | | |

TERMINAL RESPONSE: SEND DATA 1.5.1

Logically:

Command details

Command number:

Command type: SEND DATA
Command qualifier: Send Immediately

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Bearer Independent Protocol error (3A)
Additional Result: Channel identifier not valid (03)

Coding:

| BER-TLV: | 81 | 03 | 01 | 43 | 01 | 82 | 02 | 82 | 81 | 83 | 02 | 3A |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 03 | | | | | | | | | | | |

Expected sequence 1.6 Void

27.22.4.30.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.5.

27.22.4.31 GET CHANNEL STATUS

27.22.4.31.1 Definition and applicability

See clause 3.2.2.

27.22.4.31.2 Conformance requirements

The ME shall support the class "e" commands as defined in:

• 3GPP TS 11.14 [15].

27.22.4.31.3 Test purpose

To verify that the ME shall send a TERMINAL RESPONSE (Command Performed Successfully) to the SIM after the ME receives the GET STATUS proactive command. The TERMINAL RESPONSE sent back to the SIM is function of the ME and the network capabilities against asked parameters by the SIM.

27.22.4.31.4 Method of test

27.22.4.31.4.1 Initial conditions

The ME is connected to the SIM Simulator and the System Simulator. The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

For MEs supporting BIP related to GPRS in UDP (i.e condition C121 in table B.1), The PROACTIVE COMMAND: OPEN CHANNEL 1.1.1 shall be executed to open a channel successfully at the beginning of the test. The

corresponding Terminal Response shall be TERMINAL RESPONSE: OPEN CHANNEL 1.1.1A or TERMINAL RESPONSE: OPEN CHANNEL 1.1.1B.

The following Bearer Parameters used are those defined in the default Test PDP context3, as specified in TS 51.010-1 [12], for test cases using packet services:

Bearer Parameters

Precedence Class: 02
Delay Class: 04
Reliability Class: 05
Peak throughput class: 05
Mean throughput class: 31
Packet data protocol: 02 (IP)

GPRS Parameters

Network access name: TestGp.rs

User login: UserLog User password: UserPwd

SIM/ME interface transport level

Transport format: UDP Port number: 44444

Data destination address 01.01.01.01

27.22.4.31.4.2 Procedure

Expected sequence 1.1 (GET STATUS, without any BIP channel opened)

For that test, no channel has been opened.

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|------------------------|----------------------------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET CHANNEL | |
| | | STATUS 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: GET | |
| | | STATUS 1.1.1 | |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE GET | [Command performed successfully] |
| | | STATUS 1.1.1 A | |
| | | Or | |
| | | TERMINAL RESPONSE: GET | |
| | | STATUS 1.1.1B | |
| | | Or | |
| | | TERMINAL RESPONSE: GET | |
| | | STATUS 1.1.1C | |

PROACTIVE COMMAND: GET STATUS 1.1.1

Logically:

Command details

Command number: 1

Command type: GET STATUS

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: ME

| BER-TLV: | D0 | 09 | 81 | 03 | 01 | 44 | 00 | 82 | 02 | 81 | 82 |
|----------|----|----|----|----|----|----|----|----|----|----|----|

TERMINAL RESPONSE: GET STATUS 1.1.1A

Logically:

Command details

Command number: 1

Command type: GET STATUS

Command qualifier:

RFU

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 44 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | | | | | | | | | | | | |

TERMINAL RESPONSE: GET STATUS 1.1.1B

Logically:

Command details

Command number: 1

Command type: GET STATUS

Command qualifier: RFU

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Channel status

Channel status: No Channel available, link not established or PDP context not activated

Coding:

| BER-TLV: | 81 | 03 | 01 | 44 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| _ | B8 | 02 | 00 | 00 | | | | | | | | |

TERMINAL RESPONSE: GET STATUS 1.1.1C

Logically:

Command details

Command number: 1

Command type: GET STATUS

Command qualifier: RFU

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Channel status

Channel 1 status: Channel identifier 1, Link not established or PDP context not activated

Channel 2 status: Channel identifier 2, Link not established or PDP context not activated

.

.

Channel n status: Channel identifier n, Link not established or PDP context not activated

The number of channel status data objects shall be same as the number of channels (n) supported by the ME

Coding:

| BER-TLV: | 81 | 03 | 01 | 44 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|-------|----|----|----|----|----|----|----|----|----|----|----|
| | Note1 | | | | | | | | | | | |

Note1: The Terminal Response shall contain as many channel status TLVs as channels are supported by the ME. Each channel status TLV coding shall indicate the corresponding channel identifier and shall state "Link not established or PDP context not activated". As an example, if the mobile supports two channels then the corresponding channel status data objects coding would be: 'B8 02 01 00 B8 02 02 00'.

Expected sequence 1.2 (GET STATUS, with a BIP channel currently opened)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|--------------------------------|----------------------------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | See initial conditions |
| | | PENDING: OPEN CHANNEL | |
| | | 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: OPEN | |
| | | CHANNEL 1.1.1 | |
| 4 | $ME \rightarrow SS$ | PDP context activation request | |
| 5 | | PDP context activation accept | |
| 6 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: OPEN | [Command performed successfully] |
| | | CHANNEL 1.1.1A | |
| | | or | |
| | | TERMINAL RESPONSE: OPEN | |
| _ | | CHANNEL 1.1.1B | |
| 7 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: GET CHANNEL | |
| | | STATUS 1.2.1 | |
| 8 | $ME \rightarrow SIM$ | | |
| 9 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: GET | |
| 4.0 | | STATUS 1.2.1 | |
| 10 | $ME \rightarrow SIM$ | TERMINAL RESPONSE GET | [Command performed successfully] |
| | | STATUS 1.2.1 A | |
| | | Or | |
| | | TERMINAL RESPONSE: GET | |
| | | STATUS 1.2.1B | |

PROACTIVE COMMAND: OPEN CHANNEL 1.1.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: SIM
Destination device: ME

Bearer

Bearer type: GPRS

Bearer parameter:

Precedence Class: 02
Delay Class: 04
Reliability Class: 05
Peak throughput class: 05
Mean throughput class: 31

Packet data protocol: 02 (IP)

Buffer

Buffer size: 1000 Network access name: TestGp.rs

Text String: UserLog (User login)
Text String: UserPwd (User password)

SIM/ME interface transport level

Transport format: UDP
Port number: 44444
Data destination address 01.01.01.01

Coding:

| | BER-TLV | D0 | 42 | 81 | 03 | 01 | 40 | 01 | 82 | 02 | 81 | 82 | 35 |
|---|---------|----|----|----|----|----|----|----|----|----|----|----|----|
| _ | | 07 | 02 | 02 | 04 | 05 | 05 | 1F | 02 | 39 | 02 | 03 | E8 |
| | | 47 | 0A | 06 | 54 | 65 | 73 | 74 | 47 | 70 | 02 | 72 | 73 |
| | | 0D | 08 | F4 | 55 | 73 | 65 | 72 | 4C | 6F | 67 | 0D | 80 |
| | | F4 | 55 | 73 | 65 | 72 | 50 | 77 | 64 | 3C | 03 | 01 | AD |
| | | 9C | 3E | 05 | 21 | 01 | 01 | 01 | 01 | | | | |

TERMINAL RESPONSE: OPEN CHANNEL 1.1.1A

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Channel status Channel identifier 1 and link established or PDP context activated

Bearer description

Bearer type: GPRS

Bearer parameter:

Precedence Class: 02
Delay Class: 04
Reliability Class: 05
Peak throughput class: 05
Mean throughput class: 31
Packet data protocol: 02 (IP)

Buffer

Buffer size: 1000

Coding:

| BER-TLV: | 81 | 03 | 01 | 40 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 38 | 02 | 81 | 00 | 35 | 07 | 02 | 02 | 04 | 05 | 05 | 1F |
| | 02 | 39 | 02 | 03 | E8 | | | | | | | |

TERMINAL RESPONSE: OPEN CHANNEL 1.1.1B

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Channel status Channel identifier 1 and link established or PDP context activated

Bearer description

Bearer type: GPRS

Bearer parameter:

Precedence Class: 00
Delay Class: 04
Reliability Class: 05
Peak throughput class: 05
Mean throughput class: 31
Packet data protocol: 02 (IP)

Buffer

Buffer size: 1000

Coding:

| BER-TLV: | 81 | 03 | 01 | 40 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 38 | 02 | 81 | 00 | 35 | 07 | 02 | 00 | 04 | 05 | 05 | 1F |
| | 02 | 39 | 02 | 03 | E8 | | | | | | | |

PROACTIVE COMMAND: GET STATUS 1.2.1

Logically:

Command details

Command number: 1

Command type: GET STATUS

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: ME

Coding:

| BER-TLV: D0 09 81 03 01 4 | 44 00 82 02 81 8 | 32 |
|---------------------------------------|----------------------------|----|
|---------------------------------------|----------------------------|----|

TERMINAL RESPONSE: GET STATUS 1.2.1A

Logically:

Command details

Command number: 1

Command type: GET STATUS

Command qualifier: RFU

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Channel status

Channel status: Channel 1 open, link established or PDP context activated

| BER-TLV: | 81 | 03 | 01 | 44 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| _ | B8 | 02 | 81 | 00 | | | | | | | | |

TERMINAL RESPONSE: GET STATUS 1.2.1B

Logically:

Command details

Command number: 1

Command type: GET STATUS

Command qualifier: RFU

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Channel status

Channel 1 status: Channel identifier 1 open, Link established or PDP context activated

Channel 2 status: Channel identifier 2, Link not established or PDP context not activated

.

.

Channel n status: Channel identifier n, Link not established or PDP context not activated

The number of channel status data objects shall be same as the number of channels(n) supported by the ME

Coding:

| BER-TLV: | 81 | 03 | 01 | 44 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|------|----|----|----|----|----|----|----|----|----|----|----|
| | Note | | | | | | | | | | | |
| | 1 | | | | | | | | | | | |

Note1: The Terminal Response shall contain as many channel status TLVs as channels are supported by the ME. The channel status TLV coding of the opened channel shall state "Link established or PDP context activated". Each other channel status TLV coding shall indicate the corresponding channel identifier and shall state "Link is not established or PDP context not activated". As an example, if the mobile supports two channels and channel 1 is opened then the corresponding channel status data objects coding would be: 'B8 02 81 00 B8 02 02 00'.

Expected sequence 1.3 (GET STATUS, after a link dropped)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------------|---|----------------------------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: SET UP EVENT LIST 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SET UP EVENT LIST | |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1 | [Command performed successfully] |
| 5 | $SIM \rightarrow ME$ | CHANNEL 1.1.1 | See initial conditions |
| 6 | $ME \to SIM$ | | |
| 7 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: OPEN CHANNEL 1.1.1 | |
| 8 | $ME \to SS$ | PDP context activation request | |
| 9 | | PDP context activation request | |
| 10 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: OPEN CHANNEL 1.1.1A | [Command performed successfully] |
| | | TERMINAL RESPONSE: OPEN CHANNEL 1.1.1B | |
| 11 | $SS \rightarrow ME$ | DROP LINK | |
| 12 | $ME \rightarrow SIM$ | ENVELOPE EVENT DOWNLOAD: CHANNEL STATUS 1.3.1 | [Link dropped] |
| 13 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING: GET STATUS 1.3.1 | |
| 14 | $\text{ME} \to \text{SIM}$ | FETCH | |
| 15 | $SIM \to ME$ | PROACTIVE COMMAND: GET STATUS 1.3.1 | |
| 16 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: GET STATUS 1.3.1A Or | [Command performed successfully] |
| | | TERMINAL RESPONSE: GET STATUS 1.3.1B | |
| | | TERMINAL RESPONSE: GET STATUS 1.3.1C | |
| | | TERMINAL RESPONSE: GET STATUS 1.3.1D Or | |
| | | TERMINAL RESPONSE: GET STATUS 1.3.1E | |

TERMINAL RESPONSE: GET STATUS 1.3.1A

Same as TERMINAL RESPONSE: GET STATUS 1.1.1A

TERMINAL RESPONSE: GET STATUS 1.3.1B

Same as TERMINAL RESPONSE: GET STATUS 1.1.1B

TERMINAL RESPONSE: GET STATUS 1.3.1C

Same as TERMINAL RESPONSE: GET STATUS 1.1.1C

TERMINAL RESPONSE: GET STATUS 1.3.1D

Logically:

Command details

Command number:

Command type: GET STATUS

Command qualifier: RFU

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Channel status

Channel status: Channel 1, link dropped

Coding:

| BER-TLV: | 81 | 03 | 01 | 44 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | B8 | 02 | 01 | 05 | | | | | | | | |

TERMINAL RESPONSE: GET STATUS 1.3.1E

Logically:

Command details

Command number: 1

Command type: GET STATUS

Command qualifier: RFU

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Channel status

Channel 1 status: Channel identifier 1, link dropped

Channel 2 status: Channel identifier 2, Link not established or PDP context not activated

.

.

Channel n status: Channel identifier n, Link not established or PDP context not activated

The number of channel status data objects shall be same as the number of channels(n) supported by the ME

Coding:

| BER-TLV: | 81 | 03 | 01 | 44 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|-------|----|----|----|----|----|----|----|
| | B8 | 02 | 01 | 05 | Note1 | | | | | | | |

Note1: The Terminal Response shall contain as many channel status TLVs as channels are supported by the ME. Each channel status TLV coding except that one for which the link was dropped by the SS shall indicate the corresponding channel identifier and shall state "Link not established or PDP context not activated". As an example, if the mobile supports two channels then the corresponding channel status data objects coding would be: 'B8 02 01 05 B8 02 02 00'.

PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00

Device identities

Source device: SIM
Destination device: ME

Event list

Event 1: Channel Status

Coding:

| BER-TLV: | D0 | 0C | 81 | 03 | 01 | 05 | 00 | 82 | 02 | 81 | 82 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| · | 99 | 01 | 0A | | | | | | | | |

TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 05 | 00 | 82 | 02 | 82 | l 81 | 83 | l 01 | 00 |
|----------|----|----|----|----|----|----|----|----|------|----|----------|----|
| D | ٠. | | ٠. | 00 | | U- | U- | U | , o. | | . | 00 |

ENVELOPE EVENT DOWNLOAD: CHANNEL STATUS 1.3.1

Logically:

Event list

Event list: Channel Status

Device identities

Source device: ME Destination device: SIM

Channel status

Channel status: Channel 1, link dropped

Coding:

| BER-TLV: | D6 | 0B | 99 | 01 | 0A | 82 | 02 | 82 | 81 | B8 | 02 | 01 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| · | 05 | | | | | | | | | | | |

PROACTIVE COMMAND: GET STATUS 1.3.1

Logically:

Command details

Command number:

Command type: GET STATUS

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: ME

Coding:

| BER-TLV: | D0 | 09 | 81 | 03 | 01 | 44 | 00 | 82 | 02 | 81 | 82 |
|----------|----|----|----|----|----|----|----|----|----|----|----|

27.22.4.31.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.3.

27.22.5 Data Download to SIM

27.22.5.1 SMS-PP Data Download

27.22.5.1.1 Definition and applicability

See clause 3.2.2.

27.22.5.1.2 Conformance requirement

The ME shall support the Proactive SIM: SMS-PP Data Download facility as defined in the following technical specifications:

• 3GPP TS 11.14 [15] clause 4.3, clause 5, clause 7.1, clause 12.1, clause 12.7 and clause 12.13.

27.22.5.1.3 Test purpose

To verify that the ME transparently passes the "data download via SMS Point-to-point" messages to the SIM.

To verify that the ME returns the RP-ACK message back to the system Simulator, if the SIM responds with '90 00' or '91 XX'.

To verify that the ME returns the response data from the SIM back to the system Simulator in the TP-User-Data element of the RP-ACK message, if the SIM responds with '9F XX'.

27.22.5.1.4 Method of Test

27.22.5.1.4.1 Initial conditions

The ME is connected to the system Simulator and the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.5.1.4.2 Procedure

Expected Sequence 1.1 Void

Expected Sequence 1.2 (SMS-PP Data Download, General Data Coding, GET RESPONSE, Acknowledgement)

| Step | Direction | MESSAGE / Action | Comments |
|------|---|-----------------------------------|------------------------|
| 1 | $SS \to ME$ | SMS-PP Data Download Message | |
| | | 1.2.1 | |
| 2 | $ME \rightarrow USER$ | The ME shall not display the | |
| | | message or alert the user of a | |
| | | short message waiting. | |
| 3 | ME 	o SIM | ENVELOPE: SMS-PP | |
| | / | DOWNLOAD 1.2.2 | |
| 4 | $SIM \to ME$ | RESPONSE DATA AVAILABLE | [SW1 / SW2 of '9F 0B'] |
| 5 | $ME \to SIM$ | GET RESPONSE | |
| 6 | $SIM \to ME$ | SMS-PP Data Download SIM | |
| | | Acknowledgement 1.2.4 | |
| 7 | $ME \to SS$ | SMS-PP Data Download SIM | |
| | | Acknowledgement 1.2.4 in the TP- | |
| | | User-Data element of the RP-ACK | |
| | | message. The values of protocol | |
| | | identifier and data coding scheme | |
| | | in RP-ACK shall be as in the | |
| | | original message. | |

Expected Sequence 1.3 (SMS-PP Data Download, General Data Coding, FETCH, MORE TIME)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--------------------------------|------------------------|
| 1 | $SS \to ME$ | SMS-PP Data Download Message | |
| _ | | 1.3.1 | |
| 2 | $ME \rightarrow USER$ | | |
| | | message or alert the user of a | |
| | | short message waiting | |
| 3 | $ME \rightarrow SIM$ | | [SW1 / SW2 of '91 0B'] |
| | | DOWNLOAD 1.3.2 | |
| 4 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: MORE TIME 1.3.4 | |
| 5 | $ME \to SS$ | RP-ACK | |
| 6 | $ME \to SIM$ | FETCH | |
| 7 | $SIM \to ME$ | PROACTIVE COMMAND: MORE | |
| | | TIME 1.3.4 | |
| 8 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: MORE | |
| | | TIME 1.3.5 | |
| 9 | $SIM \to ME$ | PROACTIVE SIM SESSION | |
| | | ENDED | |

PROACTIVE COMMAND: MORE TIME 1.3.4

Logically:

Command details

Command number: 1

Command type: MORE TIME

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

| BER-TLV: | D0 | 00 | 0.4 | 00 | 0.4 | 00 | 00 | 0.2 | 00 | 0.4 | 0.0 |
|-----------|----|------|-----|-----|------|----|----|-----|----|------|-----|
| IBER-ILV: | D0 | l 09 | 81 | เบง | I UT | UZ | 00 | ÖΖ | 02 | 1 81 | ÖΖ |

TERMINAL RESPONSE: MORE TIME 1.3.5

Logically:

Command details

Command number:

Command type: MORE TIME

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 02 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 | |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|--|
|----------|----|----|----|----|----|----|----|----|----|----|----|----|--|

Expected Sequence 1.4 (SMS-PP Data Download, General Data Coding)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|---|----------|
| 1 | $SS \to ME$ | SMS-PP Data Download Message | |
| 2 | ME | 1.4.1 The ME shall not display the message or alert the user of a | |
| 3 | $ME \to SIM$ | short message waiting ENVELOPE: SMS-PP DOWNLOAD 1.4.2 | |
| 4 | $SIM \rightarrow ME$ | SW1 / SW2 of '90 00' | |
| 5 | $ME \to SS$ | RP-ACK | |

SMS-PP (Data Download) Message 1.2.1 / 1.3.1 / 1.4.1

Logically:

SMS TPDU

TP-MTI SMS-DELIVER

TP-MMS No more messages waiting for the MS in this SC
TP-RP TP-Reply-Path is not set in this SMS-DELIVER
TP-UDHI TP-UD field contains only the short message
TP-SRI A status report will not be returned to the SME

TP-OA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "1234"

TP-PID SIM Data download

TP-DCS

Coding Group General Data Coding Compression Text is uncompressed

Message Class Class 2 SIM Specific Message

Alphabet 8 bit data

TP-SCTS: 01/01/98 00:00:00 +0

TP-UDL 13

TP-UD "Short Message"

| Coding | 04 | 04 | 91 | 21 | 43 | 7F | 16 | 89 | 10 | 10 | 00 | 00 |
|--------|----|----|----|----|----|----|----|----|----|----|----|----|
| - | 00 | 00 | 0D | 53 | 68 | 6F | 72 | 74 | 20 | 4D | 65 | 73 |
| | 73 | 61 | 67 | 65 | | | | | | | | ļ |

ENVELOPE: SMS-PP DOWNLOAD 1.2.2 / 1.3.2 / 1.4.2,

Logically:

SMS-PP Download

Device identities

Source device: Network
Destination device: SIM

Address

TON International number

NPI "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

SMS TPDU

TP-MTI SMS-DELIVER

TP-MMS No more messages waiting for the MS in this SC
TP-RP TP-Reply-Path is not set in this SMS-DELIVER
TP-UDHI TP-UD field contains only the short message
TP-SRI A status report will not be returned to the SME

TP-OA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "1234"

TP-PID SIM Data download

TP-DCS

Coding Group
Compression

General Data Coding
Text is uncompressed

Message Class Class 2 SIM Specific Message

Alphabet 8 bit data

TP-SCTS: 01/01/98 00:00:00 +0

TP-UDL 13

TP-UD "Short Message"

Coding:

| BER-TLV: | D1 | 2D | 82 | 02 | 83 | 81 | 06 | 09 | 91 | 11 | 22 | 33 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 44 | 55 | 66 | 77 | F8 | 8B | 1C | 04 | 04 | 91 | 21 | 43 |
| | 7F | 16 | 89 | 10 | 10 | 00 | 00 | 00 | 00 | 0D | 53 | 68 |
| | 6F | 72 | 74 | 20 | 4D | 65 | 73 | 73 | 61 | 67 | 65 | |

Expected Sequence 1.5 Void

Expected Sequence 1.6 (SMS-PP Data Download, with Data Coding / Message Class)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|--------------------------------|----------|
| 1 | $SS \rightarrow ME$ | SMS-PP Data Download Message | |
| | | 1.6.1 | |
| 2 | ME | The ME shall not display the | |
| | | message or alert the user of a | |
| | | short message waiting | |
| 3 | $ME \rightarrow SIM$ | ENVELOPE: SMS-PP | |
| | | DOWNLOAD 1.6.2 | |
| 4 | $SIM \rightarrow ME$ | SW1 / SW2 of '90 00' | |
| 5 | $ME \rightarrow SS$ | RP-ACK | |

SMS-PP (Data Download) Message 1.6.1

Logically:

SMS TPDU

TP-MTI SMS-DELIVER

TP-MMS No more messages waiting for the MS in this SC TP-RP TP-Reply-Path is not set in this SMS-DELIVER

TP-UDHI TP-UD field contains only the short message TP-SRI A status report will not be returned to the SME

TP-OA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "1234"

TP-PID SIM Data download

TP-DCS

Coding Group Data Coding / Message Class

Message Coding 8 bit data

Message Class Class 2 SIM Specific Message

TP-SCTS: 01/01/98 00:00:00 +0

TP-UDL 13

TP-UD "Short Message"

Coding:

| Coding | 04 | 04 | 91 | 21 | 43 | 7F | F6 | 89 | 10 | 10 | 00 | 00 |
|--------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | 00 | 0D | 53 | 68 | 6F | 72 | 74 | 20 | 4D | 65 | 73 |
| | 73 | 61 | 67 | 65 | | | | | | | | |

ENVELOPE: SMS-PP DOWNLOAD 1.6.2

Logically:

SMS-PP Download

Device identities

Source device: Network
Destination device: SIM

Address

TON International number

NPI "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

SMS TPDU

TP-MTI SMS-DELIVER

TP-MMS No more messages waiting for the MS in this SC
TP-RP TP-Reply-Path is not set in this SMS-DELIVER
TP-UDHI TP-UD field contains only the short message
TP-SRI A status report will not be returned to the SME

TP-OA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "1234"

TP-PID SIM Data download

TP-DCS

Coding Group Data Coding / Message Class

Message Coding 8 bit data

Message Class Class 2 SIM Specific Message

TP-SCTS: 01/01/98 00:00:00 +0

TP-UDL 13

TP-UD "Short Message"

| BER-TLV: | D1 | 2D | 82 | 02 | 83 | 81 | 06 | 09 | 91 | 11 | 22 | 33 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 44 | 55 | 66 | 77 | F8 | 8B | 1C | 04 | 04 | 91 | 21 | 43 |
| | 7F | F6 | 89 | 10 | 10 | 00 | 00 | 00 | 00 | 0D | 53 | 68 |
| | 6F | 72 | 74 | 20 | 4D | 65 | 73 | 73 | 61 | 67 | 65 | |

SMS-PP Data Download SIM Acknowledgement 1.2.4

Coding:

| Coding | 50 | 68 | 69 | 6C | 20 | 48 | 6F | 6F | 6B | 65 | 72 |
|--------|----|----|----|----|----|----|----|----|----|----|----|

27.22.5.1.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.2 to 1.6.

27.22.5.2 SMS-CB Data Download

27.22.5.2.1 Definition and applicability

See clause 3.2.2.

27.22.5.2.2 Conformance requirement

The ME shall support the Proactive SIM: SMS-CB Data Download facility as defined in:

• 3GPP TS 11.14 [15] clause 4.3, clause 5, clause 7.2, clause 12.5 and clause 12.7.

27.22.5.2.3 Test purpose

To verify that the ME transparently passes the "data download via SMS Cell Broadcast" messages to the SIM, which contain a message identifier found in EF_{CBMID} .

27.22.5.2.4 Method of Test

27.22.5.2.4.1 Initial conditions

The ME is connected to the system Simulator and the SIM Simulator.

The elementary files are coded as Toolkit default with the following exeception:

EF LP shall contain an entry indicating "English".

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.5.2.4.2 Procedure

Expected Sequence 1.1 (SMS-CB (Data Download), ENVELOPE(SMS-CB DOWNLOAD), ME does not display message)

| Step | Direction | MESSAGE / Action | Comments |
|------|--------------|--|----------------------------|
| 1 | $SS \to ME$ | SMS-CB (DATA DOWNLOAD) | Message identifier '10 01' |
| 2 | | 1.1 ENVELOPE (SMS-CB DOWNLOAD) 1.1 | |
| 3 | $SIM \to ME$ | SW1, SW2 '90 00' | |

SMS-CB (Data Download) Message 1.1

Logically:

Message Content

Serial Number

Geographical scope: Cell wide, normal display mode

Message code: 1

Update number: 1
Message Identifier: "1001"

Data coding Scheme

Message Coding: English, language using the GSM 7 bit default alphabet

Page Parameter

Total number of pages: 1 Page number: 1

Content of message: "Cell Broadcast "...

Coding:

| Coding | C0 | 11 | 10 | 01 | 01 | 11 | C3 | 32 | 9B | 0D | 12 | CA |
|--------|----|----|----|----|----|----|----|----|----|----|----|----|
| | DF | 61 | F2 | 38 | 3C | A7 | 83 | 40 | 20 | 10 | 08 | 04 |
| | 02 | 81 | 40 | 20 | 10 | 08 | 04 | 02 | 81 | 40 | 20 | 10 |
| | 08 | 04 | 02 | 81 | 40 | 20 | 10 | 08 | 04 | 02 | 81 | 40 |
| | 20 | 10 | 08 | 04 | 02 | 81 | 40 | 20 | 10 | 80 | 04 | 02 |
| | 81 | 40 | 20 | 10 | 08 | 04 | 02 | 81 | 40 | 20 | 10 | 80 |
| | 04 | 02 | 81 | 40 | 20 | 10 | 80 | 04 | 02 | 81 | 40 | 20 |
| | 10 | 08 | 04 | 02 | | | | | | | | |

ENVELOPE: SMS-CB DOWNLOAD 1.1

Logically:

Cell Broadcast Download

Device identities

Source device: Network Destination device: SIM

Cell Broadcast page

Serial Number

Geographical scope: Cell wide, normal display mode

Message code: 1 Update number: 1 Message Identifier: "1001"

Data coding Scheme

Message Coding: English, language using the GSM 7 bit default alphabet

Page Parameter
Number of pages: 1
Page number: 1

Content of message: "Cell Broadcast " ...

| BER-TLV: | D2 | 5E | 82 | 02 | 83 | 81 | 8C | 58 | C0 | 11 | 10 | 01 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | 11 | C3 | 32 | 9B | 0D | 12 | CA | DF | 61 | F2 | 38 |
| | 3C | A7 | 83 | 40 | 20 | 10 | 80 | 04 | 02 | 81 | 40 | 20 |
| | 10 | 08 | 04 | 02 | 81 | 40 | 20 | 10 | 08 | 04 | 02 | 81 |
| | 40 | 20 | 10 | 08 | 04 | 02 | 81 | 40 | 20 | 10 | 08 | 04 |
| | 02 | 81 | 40 | 20 | 10 | 08 | 04 | 02 | 81 | 40 | 20 | 10 |
| | 08 | 04 | 02 | 81 | 40 | 20 | 10 | 08 | 04 | 02 | 81 | 40 |
| | 20 | 10 | 08 | 04 | 02 | 81 | 40 | 20 | 10 | 08 | 04 | 02 |

Expected Sequence 1.2 (SMS-CB(DATA DOWNLOAD), ENVELOPE(SMS-CB DATA DOWNLOAD), FETCH, MORE TIME, ME does not display message)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------------|-------------------------|----------------------------|
| 1 | $SS \to ME$ | SMS-CB (DATA DOWNLOAD) | Message identifier '10 01' |
| | | 1.1 | |
| 2 | $\text{ME} \to \text{SIM}$ | ENVELOPE (SMS-CB | |
| | | DOWNLOAD) 1.1 | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND | SW1/SW2 '91 0B' |
| | | PENDING: MORE TIME 1.1 | |
| 4 | $\text{ME} \to \text{SIM}$ | FETCH 1.1 | |
| 5 | $SIM \to ME$ | PROACTIVE COMMAND:MORE | |
| | | TIME 1.1 | |
| 6 | $ME \to SIM$ | TERMINAL RESPONSE: MORE | |
| | | TIME 1.1 | |
| 7 | $SIM \to ME$ | SW1/SW2 '90 00' | SIM session ended |

PROACTIVE COMMAND: MORE TIME 1.1

Logically:

Command details

Command number:

Command type: MORE TIME

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Coding:

| BER-TLV: | D0 | 09 | 81 | 03 | 01 | 02 | 00 | 82 | 02 | 81 | 82 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
|----------|----|----|----|----|----|----|----|----|----|----|----|

TERMINAL RESPONSE: MORE TIME 1.1

Logically:

Command details

Command number: 1

Command type: MORE TIME

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

| BER-TLV: | 01 | 02 | 01 | 02 | 00 | 02 | 02 | 0.2 | 01 | 02 | Ω1 | 00 |
|----------|----|----|----|----|----|----|----|-----|----|----|----|----|
| DER-ILV. | 01 | US | UI | UZ | UU | 02 | UZ | 02 | 01 | ၀၁ | UI | 00 |

Expected Sequence 1.3 (SMS-CB (DATA DOWNLOAD), ME displays message)

| Step | Direction | MESSAGE / Action | Comments |
|------|-------------|--------------------------------------|--|
| 1 | $SS \to ME$ | SMS-CB (DATA DOWNLOAD) 1.2 | Message identifier '03 E7' |
| 2a | ME → USER | ME may display the message | |
| 2b | ME → SIM | ME shall not download the CB | |
| | | message to the SIM using | |
| | | ENVELOPE (SMS-CB download) | |
| 3 | USER → ME | The user shall use a MMI dependent | [only if message has not been displayed in |
| | | procedure to initiate the display of | step 2a] |
| | | the received CB message | |
| 4 | ME → USER | ME displays the message | [only if message has not been displayed in |
| | | | step 2a] |

SMS-CB (Data Download) Message 1.2

Logically:

Message Content

Serial Number

Geographical scope: Cell wide, normal display mode

Message code: 1
Update number: 1
Message Identifier: "03E7"

Data coding Scheme

Message Coding: English, language using the GSM 7 bit default alphabet

Page Parameter

Total number of pages: 1 Page number: 1

Content of message: "Cell Broadcast".

Coding:

| Coding | C0 | 11 | 03 | E7 | 01 | 11 | C3 | 32 | 9B | 0D | 12 | CA |
|--------|----|----|----|----|----|----|----|----|----|----|----|----|
| | DF | 61 | F2 | 38 | 3C | A7 | 83 | 40 | 20 | 10 | 08 | 04 |
| | 02 | 81 | 40 | 20 | 10 | 08 | 04 | 02 | 81 | 40 | 20 | 10 |
| | 08 | 04 | 02 | 81 | 40 | 20 | 10 | 08 | 04 | 02 | 81 | 40 |
| | 20 | 10 | 80 | 04 | 02 | 81 | 40 | 20 | 10 | 08 | 04 | 02 |
| | 81 | 40 | 20 | 10 | 08 | 04 | 02 | 81 | 40 | 20 | 10 | 08 |
| | 04 | 02 | 81 | 40 | 20 | 10 | 08 | 04 | 02 | 81 | 40 | 20 |
| | 10 | 08 | 04 | 02 | | | | | | | | |

27.22.5.2.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.3.

27.22.6 CALL CONTROL BY SIM

27.22.6.1 Procedure for Mobile Originated calls

27.22.6.1.1 Definition and applicability

See clause 3.2.2.

27.22.6.1.2 Conformance requirement

The ME shall support the CALL CONTROL facility as defined in:

• 3GPP TS 11.14 [15] clause 9.1.1.

27.22.6.1.3 Test purpose

To verify that for all call set-up attempts , even those resulting from a SET UP CALL proactive SIM command, the ME shall first pass the call set-up details (dialled digits and associated parameters) to the SIM, using the ENVELOPE (CALL CONTROL).

To verify that if the SIM responds with '90 00', the ME shall set up the call with the dialled digits and other parameters as sent to the SIM.

To verify that if the SIM responds with '9F XX', the ME shall use the GET RESPONSE command to get the response data. The response data from the SIM shall indicate to the ME whether to set up the call as proposed, not set up the call, set up a call using the data supplied by the SIM.

To verify that, in the case where the initial call set-up request results from a proactive SET UP CALL, if the call control result is "not allowed" or "allowed with modifications", the ME shall inform the SIM using TERMINAL RESPONSE "interaction with call control by SIM or MO short message control by SIM, action not allowed".

To verify that it is possible for the SIM to request the ME to set up an emergency call by supplying the number "112" as the response data.

27.22.6.1.4 Method of tests

27.22.6.1.4.1 Initial conditions

The ME is connected to the SIM Simulator and System Simulator and has performed the location update procedure.

The GSM parameters of the system simulator are:

- Mobile Country Code (MCC) = 001;
- Mobile Network Code (MNC) = 01;
- Location Area Code (LAC) = 0001;
- Cell Identity value = 0001.

The PCS 1900 parameters of the system simulator are:

- Mobile Country Code (MCC) = 001;
- Mobile Network Code (MNC) = 011;
- Location Area Code (LAC) = 0001;
- Cell Identity value = 0001.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The elementary files are coded as SIM Application Toolkit default with the following exception:

The call control service is allocated and activated in the SIM Service Table.

27.22.6.1.4.2 Procedure

Expected Sequence 1.1 (CALL CONTROL BY SIM, set up call attempt by user, the SIM responds with '90 00')

| Step | Direction | Message / Action | Comments |
|------|----------------------|--|---|
| 1 | $User \to ME$ | Set up a call to | |
| | | "+01234567890123456789" | |
| 2 | $ME \rightarrow SIM$ | ENVELOPE CALL CONTROL | [Option A shall apply for GSM parameters] |
| | | 1.1.1A | |
| | | Or | |
| | | ENVELOPE CALL CONTROL | [Option B shall apply for PCS1900 |
| | | 1.1.1B | parameters] |
| 3 | $SIM \rightarrow ME$ | 90 00 | |
| 4 | ME 	o SS | The ME sets up the call without modification | [Set up call to "+01234567890123456789" |

ENVELOPE CALL CONTROL 1.1.1A

Logically:

Device identities

Source device: ME Destination device: SIM

Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "01234567890123456789"

Capability configuration parameters 1

This parameter is optional. If present, the contents shall not be checked.

Subaddress

This parameter is optional. If present, the contents shall not be checked.

Location Information

MCC & MNC the mobile country and network code (00F110)

LAC the location Area Code (0001)
Cell ID Cell Identity Value (0001)

Capability configuration parameters 2

This parameter is optional. If present, the contents shall not be checked.

Coding:

| BER-TLV: | D4 | Note 1 | 82 | 02 | 82 | 81 | 86 | 0B | 91 | 10 | 32 | 54 |
|----------|----|-----------|----|----|----|----|-----------|-----------|-----------|----|----|----|
| | 76 | 98 | 10 | 32 | 54 | 76 | 98 | Note 2 | Note 3 | 13 | 07 | 00 |
| | F1 | 10 | 00 | 01 | 00 | 01 | Note 4 | | | | | |

ENVELOPE CALL CONTROL 1.1.1B

Logically:

Device identities

Source device: ME Destination device: SIM

Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "01234567890123456789"

Capability configuration parameters 1

This parameter is optional. If present, the contents shall not be checked.

Subaddress

This parameter is optional. If present, the contents shall not be checked.

Location Information

MCC & MNC the mobile country and network code (001110)

LAC the location Area Code (0001)
Cell ID Cell Identity Value (0001)

Capability configuration parameters 2

This parameter is optional. If present, the contents shall not be checked.

Coding:

| BER-TLV: | D4 | Note 1 | 82 | 02 | 82 | 81 | 86 | 0B | 91 | 10 | 32 | 54 |
|----------|----|-----------|----|----|----|----|-----------|-----------|-----------|----|----|----|
| | 76 | 98 | 10 | 32 | 54 | 76 | 98 | Note 2 | Note 3 | 13 | 07 | 00 |
| | 11 | 10 | 00 | 01 | 00 | 01 | Note 4 | | | | | |

Note 1: Length of BER-TLV is '1A' plus the actual length of all the present optional SIMPLE-TLV data objects.

Note 2: Capability configuration parameters 1 may be present at this place. If present, it may take up several octets.

Note 3: Subaddress may be present at this place. If present, it may take up several octets.

Note 4: Capability configuration parameters 2 may be present at this place. If present, it may take up several octets.

Expected Sequence 1.2 (CALL CONTROL BY SIM , set up call attempt by user, allowed without modification)

| Step | Direction | Message / Action | Comments |
|------|----------------------|---------------------------------|---|
| 1 | $User \to ME$ | Set up a call to | |
| | | "+01234567890123456789" | |
| 2 | $ME \rightarrow SIM$ | ENVELOPE CALL CONTROL | [Option A shall apply for GSM parameters] |
| | | 1.2.1 A | |
| | | or | |
| | | ENVELOPE CALL CONTROL | [Option B shall apply for PCS1900 |
| | | 1.2.1B | parameters] |
| 3 | $SIM \rightarrow ME$ | 9F 02 | |
| 4 | $ME \rightarrow SIM$ | GET RESPONSE | |
| | | | |
| 5 | $SIM \rightarrow ME$ | CALL CONTROL RESULT 1.2.1 | [Call control result: "Allowed, no |
| | | | modification"] |
| 6 | $ME \rightarrow SS$ | The ME sets up the call without | [Set up call to "+01234567890123456789"] |
| | | modification | |

ENVELOPE CALL CONTROL 1.2.1A

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "01234567890123456789"

Capability configuration parameters 1

This parameter is optional. If present, the contents shall not be checked.

Subaddress

This parameter is optional. If present, the contents shall not be checked.

Location Information

MCC & MNC the mobile country and network code (00F110)

LAC the location Area Code (0001)
Cell ID Cell Identity Value (0001)

Capability configuration parameters 2

This parameter is optional. If present, the contents shall not be checked.

Coding:

| BER-TLV: | D4 | Note 1 | 82 | 02 | 82 | 81 | 86 | 0B | 91 | 10 | 32 | 54 |
|----------|----|-----------|----|----|----|----|-----------|-----------|-----------|----|----|----|
| | 76 | 98 | 10 | 32 | 54 | 76 | 98 | Note 2 | Note 3 | 13 | 07 | 00 |
| | F1 | 10 | 00 | 01 | 00 | 01 | Note 4 | | | | | |

ENVELOPE CALL CONTROL 1.2.1B

Logically:

Device identities

Source device: ME Destination device: SIM

Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "01234567890123456789"

Capability configuration parameters 1

This parameter is optional. If present, the contents shall not be checked.

Subaddress

This parameter is optional. If present, the contents shall not be checked.

Location Information

MCC & MNC the mobile country and network code (001110)

LAC the location Area Code (0001)
Cell ID Cell Identity Value (0001)

Capability configuration parameters 2

This parameter is optional. If present, the contents shall not be checked.

Coding:

| BER-TLV: | D4 | Note 1 | 82 | 02 | 82 | 81 | 86 | 0B | 91 | 10 | 32 | 54 |
|----------|----|-----------|----|----|----|----|-----------|-----------|-----------|----|----|----|
| | 76 | 98 | 10 | 32 | 54 | 76 | 98 | Note 2 | Note 3 | 13 | 07 | 00 |
| | 11 | 10 | 00 | 01 | 00 | 01 | Note 4 | | | | | |

Note 1: Length of BER-TLV is '1A' plus the actual length of all the present optional SIMPLE-TLV data objects.

Note 2: Capability configuration parameters 1 may be present at this place. If present, it may take up several octets.

Note 3: Subaddress may be present at this place. If present, it may take up several octets.

Note 4: Capability configuration parameters 2 may be present at this place. If present, it may take up several octets.

CALL CONTROL RESULT 1.2.1

Logically:

Call control result : '00' = Allowed, no modification

Coding:

BER-TLV: 00 00

Expected Sequence 1.3A (CALL CONTROL BY SIM , set up call attempt resulting from a set up call proactive command, allowed without modification)

| Step | Direction | Message / Action | Comments |
|------|---|--|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND: SET | [This test applies to MEs asking for user |
| | | UP CALL 1.3.1 PENDING | confirmation before sending the |
| | | | ENVELOPE CALL CONTROL command] |
| 2 | ME→SIM | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SET UP CALL 1.3.1 | [Set up call to "+012340123456"] |
| 4 | ME 	o | ME displays "+012340123456" | |
| | USER | during user confirmation phase. | |
| 5 | $\begin{array}{c} USER \to \\ ME \end{array}$ | The user confirms the call set up | [user confirmation] |
| 6 | $ME \rightarrow SIM$ | ENVELOPE CALL CONTROL | [Option A shall apply for GSM |
| | | 1.3.1A | parameters] |
| | | or | |
| | | ENVELOPE CALL CONTROL | [Option B shall apply for PCS1900 |
| | | 1.3.1B | parameters] |
| 7 | $SIM \rightarrow ME$ | | |
| 8 | $ME \rightarrow SIM$ | GET RESPONSE | |
| 9 | $SIM \rightarrow ME$ | CALL CONTROL RESULT 1.3.1 | [Call control result: "Allowed, no modification"] |
| 10 | $ME \rightarrow SS$ | The ME sets up the call without modification | [Set up call to "+012340123456"] |
| 11 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP CALL 1.3.1 | [command performed successfully] |

Expected Sequence 1.3 B (CALL CONTROL BY SIM, set up call attempt resulting from a set up call proactive command, allowed without modification)

| Step | Direction | Message / Action | Comments |
|------|---|---|---|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SET | [This test applies to MEs asking for user |
| | | UP CALL 1.3.1 PENDING | confirmation after sending the |
| | | | ENVELOPE CALL CONTROL command] |
| 2 | ME→SIM | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SET UP CALL 1.3.1 | [Set up call to "+012340123456"] |
| 4 | $ME \rightarrow SIM$ | ENVELOPE CALL CONTROL 1.3.1A or | [Option A shall apply for GSM parameters] |
| | | ENVELOPE CALL CONTROL 1.3.1B | [Option B shall apply for PCS1900 parameters] |
| 5 | $SIM \rightarrow ME$ | 9F 02 | |
| 6 | $ME \rightarrow SIM$ | GET RESPONSE | |
| 7 | $SIM \rightarrow ME$ | CALL CONTROL RESULT 1.3.1 | [Call control result: "Allowed, no modification"] |
| 8 | $\begin{array}{c} ME \to \\ USER \end{array}$ | ME displays "+012340123456" during user confirmation phase. | |
| 9 | $\begin{array}{c} USER \to \\ ME \end{array}$ | The user confirms the call set up | [user confirmation] |
| 10 | $ME \rightarrow SS$ | The ME sets up the call without modification | [Set up call to "+012340123456"] |
| 11 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP CALL 1.3.1 | [command performed successfully] |

PROACTIVE COMMAND: SET UP CALL 1.3.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: Only if not currently busy on another call

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "+012340123456"

Address

TON: International

NPI: "ISDN / telephone numbering plan"

Dialling number string "012340123456"

Coding:

| BER-TLV: | D0 | 21 | 81 | 03 | 01 | 10 | 00 | 82 | 02 | 81 | 83 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| _ | 05 | 0D | 2B | 30 | 31 | 32 | 33 | 34 | 30 | 31 | 32 |
| | 33 | 34 | 35 | 36 | 86 | 07 | 91 | 10 | 32 | 04 | 21 |
| | 43 | 65 | | | | | | | | | |

ENVELOPE CALL CONTROL 1.3.1A

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "012340123456"

Capability configuration parameters 1

This parameter is optional. If present, the contents shall not be checked.

Subaddress

This parameter is optional. If present, the contents shall not be checked.

Location Information

MCC & MNC the mobile country and network code (00F110)

LAC the location Area Code (0001)
Cell ID Cell Identity Value (0001)

Capability configuration parameters 2

This parameter is optional. If present, the contents shall not be checked.

Coding:

| BER-TLV: | D4 | Note | 02 | 02 | 82 | 81 | 06 | 07 | 91 | 10 | 32 |
|----------|----|------|----|----|-----------|-----------|----|----|----|----|----|
| | 04 | 21 | 43 | 65 | Note 2 | Note 3 | 13 | 07 | 00 | F1 | 10 |
| | 00 | 01 | 00 | 01 | Note 4 | | | | | | |

ENVELOPE CALL CONTROL 1.3.1B

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "012340123456"

Capability configuration parameters 1

This parameter is optional. If present, the contents shall not be checked.

Subaddress

This parameter is optional. If present, the contents shall not be checked.

Location Information

MCC & MNC the mobile country and network code (001110)

LAC the location Area Code (0001)
Cell ID Cell Identity Value (0001)

Capability configuration parameters 2

This parameter is optional. If present, the contents shall not be checked.

Coding:

| BER-TLV: | D4 | Note 1 | 02 | 02 | 82 | 81 | 06 | 07 | 91 | 10 | 32 |
|----------|----|-----------|----|----|-----------|-----------|----|----|----|----|----|
| | 04 | 21 | 43 | 65 | Note 2 | Note 3 | 13 | 07 | 00 | 11 | 10 |
| | 00 | 01 | 00 | 01 | Note 4 | | | | | | |

Note 1: Length of BER-TLV is '16' plus the actual length of all the present optional SIMPLE-TLV data objects.

Note 2: Capability configuration parameters 1 may be present at this place. If present, it may take up several octets.

Note 3: Subaddress may be present at this place. If present, it may take up several octets.

Note 4: Capability configuration parameters 2 may be present at this place. If present, it may take up several octets.

CALL CONTROL RESULT 1.3.1

Logically:

Call control result : '00' = Allowed, no modification

Coding:

BER-TLV: 00 00

TERMINAL RESPONSE: SET UP CALL 1.3.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: Only if not currently busy on another call

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 10 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----------|----|----------|----|----|----|----|----|----|----|----|----|
| D | . | - | . | | 00 | | ~_ | | | | | |

Expected Sequence 1.4 (CALL CONTROL BY SIM, set up call attempt by user, not allowed)

| Step | Direction | Message / Action | Comments |
|------|----------------------|---------------------------------|--------------------------------------|
| 1 | $User \to ME$ | Set up a call to | |
| | | "+01234567890123456789" | |
| 2 | $ME \rightarrow SIM$ | ENVELOPE CALL CONTROL | [Option A shall apply for GSM |
| | | 1.4.1 A | parameters] |
| | | or | |
| | | ENVELOPE CALL CONTROL | [Option B shall apply for PCS1900 |
| | | 1.4.1B | parameters] |
| 3 | $SIM \to ME$ | 9F 02 | |
| 4 | $ME \rightarrow SIM$ | GET RESPONSE | |
| | | | |
| 5 | $SIM \rightarrow ME$ | CALL CONTROL RESULT 1.4.1 | [Call control result: "not Allowed"] |
| 6 | $ME \rightarrow SS$ | The ME does not set up the call | |

ENVELOPE CALL CONTROL 1.4.1A

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "+01234567890123456789"

Capability configuration parameters 1

This parameter is optional. If present, the contents shall not be checked.

Subaddress

This parameter is optional. If present, the contents shall not be checked.

Location Information

MCC & MNC the mobile country and network code (00F110)

LAC the location Area Code (0001)
Cell ID Cell Identity Value (0001)

Capability configuration parameters 2

This parameter is optional. If present, the contents shall not be checked.

Coding:

| BER-TLV: | D4 | Note 1 | 82 | 02 | 82 | 81 | 86 | 0B | 91 | 10 | 32 | 54 |
|----------|----|-----------|----|----|----|----|-----------|-----------|-----------|----|----|----|
| | 76 | 98 | 10 | 32 | 54 | 76 | 98 | Note 2 | Note 3 | 13 | 07 | 00 |
| | F1 | 10 | 00 | 01 | 00 | 01 | Note 4 | | | | | |

ENVELOPE CALL CONTROL 1.4.1B

Logically:

Device identities

Source device: ME Destination device: SIM

Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "+01234567890123456789"

Capability configuration parameters 1

This parameter is optional. If present, the contents shall not be checked.

Subaddress

This parameter is optional. If present, the contents shall not be checked.

Location Information

MCC & MNC the mobile country and network code (001110)

LAC the location Area Code (0001) Cell ID Cell Identity Value (0001)

Capability configuration parameters 2

This parameter is optional. If present, the contents shall not be checked.

Coding:

| BER-TLV: | D4 | Note 1 | 82 | 02 | 82 | 81 | 86 | 0B | 91 | 10 | 32 | 54 |
|----------|----|-----------|----|----|----|----|-----------|-----------|-----------|----|----|----|
| | 76 | 98 | 10 | 32 | 54 | 76 | 98 | Note 2 | Note 3 | 13 | 07 | 00 |
| | 11 | 10 | 00 | 01 | 00 | 01 | Note 4 | | | | | |

Note 1: Length of BER-TLV is '1A' plus the actual length of all the present optional SIMPLE-TLV data objects.

Note 2: Capability configuration parameters 1 may be present at this place. If present, it may take up several octets.

Note 3: Subaddress may be present at this place. If present, it may take up several octets.

Note 4: Capability configuration parameters 2 may be present at this place. If present, it may take up several octets.

CALL CONTROL RESULT 1.4.1

Logically:

Call control result: '01' = not Allowed

Coding:

BER-TLV: 01 00

Expected Sequence 1.5A (CALL CONTROL BY SIM , set up call attempt resulting from a set up call proactive command, not allowed)

| Step | Direction | Message / Action | Comments |
|------|----------------------|--|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND: SET UP CALL 1.5.1 PENDING | [This test applies to MEs asking for user confirmation before sending the ENVELOPE CALL CONTROL command] |
| 2 | ME→SIM | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SET UP CALL 1.5.1 | [Set up call to "+012340123456" |
| 4 | $ME \to USER$ | ME displays "+012340123456" during user confirmation phase. | |
| 5 | $USER \to ME$ | The user confirms the call set up | [user confirmation] |
| 6 | ME 	o SIM | ENVELOPE CALL CONTROL 1.5.1A or ENVELOPE CALL CONTROL 1.5.1B | [Option A shall apply for GSM parameters] [Option B shall apply for PCS1900 parameters] |
| 7 | $SIM \rightarrow ME$ | 9F 02 | parametersj |
| 8 | ME → SIM | GET RESPONSE | |
| 9 | $SIM \to ME$ | CALL CONTROL RESULT 1.5.1 | [Call control result: "Not Allowed"] |
| 10 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP CALL 1.5.1 | [Permanent Problem - Interaction with Call Control by SIM] |
| 11 | $ME \to SS$ | The ME does not set up the call | |

Expected Sequence 1.5 B (CALL CONTROL BY SIM , set up call attempt resulting from a set up call proactive command, not allowed)

| Step | Direction | Message / Action | Comments |
|------|----------------------|--|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND: SET UP CALL 1.5.1 PENDING | [This test applies to MEs asking for user confirmation after sending the ENVELOPE CALL CONTROL command] |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SET UP CALL 1.5.1 | [Set up call to "+012340123456" |
| 4 | $ME \rightarrow SIM$ | ENVELOPE CALL CONTROL 1.5.1A or ENVELOPE CALL CONTROL 1.5.1B | [Option A shall apply for GSM parameters] [Option B shall apply for PCS1900 parameters] |
| 5 | $SIM \rightarrow ME$ | 9F 02 | parameters |
| 6 | $ME \rightarrow SIM$ | GET RESPONSE | |
| 7 | $SIM \to ME$ | CALL CONTROL RESULT 1.5.1 | [Call control result: "Not Allowed"] [No user confirmation phase because Call Control has disallowed the request] |
| 8 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP CALL 1.5.1 | [Permanent Problem - Interaction with Call Control by SIM] |
| 9 | $ME \to SS$ | The ME does not set up the call | |

PROACTIVE COMMAND: SET UP CALL 1.5.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: Only if not currently busy on another call

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "+012340123456"

Address

TON: International

NPI: "ISDN / telephone numbering plan"

Dialling number string "012340123456"

Coding:

| BER-TLV: | D0 | 21 | 81 | 03 | 01 | 10 | 00 | 82 | 02 | 81 | 83 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 05 | 0D | 2B | 30 | 31 | 32 | 33 | 34 | 30 | 31 | 32 |
| | 33 | 34 | 35 | 36 | 86 | 07 | 91 | 10 | 32 | 04 | 21 |
| | 43 | 65 | | | | | | | | | |

ENVELOPE CALL CONTROL 1.5.1A

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "012340123456"

Capability configuration parameters 1

This parameter is optional. If present, the contents shall not be checked.

Subaddress

This parameter is optional. If present, the contents shall not be checked.

Location Information

MCC & MNC the mobile country and network code (00F110)

LAC the location Area Code (0001)
Cell ID Cell Identity Value (0001)

Capability configuration parameters 2

This parameter is optional. If present, the contents shall not be checked.

Coding:

| BER-TLV: | D4 | Note 1 | 02 | 02 | 82 | 81 | 06 | 07 | 91 | 10 | 32 |
|----------|----|-----------|----|----|-----------|-----------|----|----|----|----|----|
| | 04 | 21 | 43 | 65 | Note 2 | Note 3 | 13 | 07 | 00 | F1 | 10 |
| | 00 | 01 | 00 | 01 | Note 4 | | | | | | |

ENVELOPE CALL CONTROL 1.5.1B

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "012340123456"

Capability configuration parameters 1

This parameter is optional. If present, the contents shall not be checked.

Subaddress

This parameter is optional. If present, the contents shall not be checked.

Location Information

MCC & MNC the mobile country and network code (001110)

LAC the location Area Code (0001)
Cell ID Cell Identity Value (0001)

Capability configuration parameters 2

This parameter is optional. If present, the contents shall not be checked.

Coding:

| BER-TLV: | D4 | Note 1 | 02 | 02 | 82 | 81 | 06 | 07 | 91 | 10 | 32 |
|----------|----|-----------|----|----|-----------|-----------|----|----|----|----|----|
| | 04 | 21 | 43 | 65 | Note 2 | Note 3 | 13 | 07 | 00 | 11 | 10 |
| | 00 | 01 | 00 | 01 | Note 4 | | | | | | |

Note 1: Length of BER-TLV is '16' plus the actual length of all the present optional SIMPLE-TLV data objects.

Note 2: Capability configuration parameters 1 may be present at this place. If present, it may take up several octets.

Note 3: Subaddress may be present at this place. If present, it may take up several octets.

Note 4: Capability configuration parameters 2 may be present at this place. If present, it may take up several octets

CALL CONTROL RESULT 1.5.1

Logically:

Call control result: '01' = not Allowed

Coding:

BER-TLV: 01 00

TERMINAL RESPONSE: SET UP CALL 1.5.1

Logically:

Command details

Command number:

Command type: SET UP CALL

Command qualifier: Only if not currently busy on another call

Device identities

Source device: ME Destination device: SIM

Result

General Result: Interaction with call control by SIM or MO short message control by SIM,

permanent problem

Additional information: Action not allowed

| BER-TLV: | 81 | 03 | 01 | 10 | 00 | 82 | 02 | 82 | 81 | 83 | 02 | 39 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | | | | | | | | | | | |

Expected Sequence 1.6 (CALL CONTROL BY SIM, set up call attempt by user, allowed with modifications)

| Step | Direction | Message / Action | Comments |
|------|----------------------|----------------------------|-------------------------------------|
| 1 | $User \to ME$ | Set up a call to | |
| | | "+01234567890123456789" | |
| 2 | $ME \rightarrow SIM$ | ENVELOPE CALL CONTROL | [Option A shall apply for GSM |
| | | 1.6.1 A | parameters] |
| | | or | |
| | | ENVELOPE CALL CONTROL | [Option B shall apply for PCS1900 |
| | | 1.6.1B | parameters] |
| 3 | $SIM \to ME$ | 9F 08 | |
| 4 | $ME \to SIM$ | GET RESPONSE | |
| | | | |
| 5 | $SIM \to ME$ | CALL CONTROL RESULT 1.6.1 | [Call control result: "Allowed with |
| | | | modifications",] |
| 6 | $ME \to SS$ | The ME sets up the call to | |
| | | "+010203" | |

ENVELOPE CALL CONTROL 1.6.1A

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "01234567890123456789"

Capability configuration parameters 1

This parameter is optional. If present, the contents shall not be checked.

Subaddress

This parameter is optional. If present, the contents shall not be checked.

Location Information

MCC & MNC the mobile country and network code (00F110)

LAC the location Area Code (0001)
Cell ID Cell Identity Value (0001)

Capability configuration parameters 2

This parameter is optional. If present, the contents shall not be checked.

Coding:

| BER-TLV: | D4 | Note 1 | 82 | 02 | 82 | 81 | 86 | 0B | 91 | 10 | 32 | 54 |
|----------|----|-----------|----|----|----|----|-----------|-----------|-----------|----|----|----|
| | 76 | 98 | 10 | 32 | 54 | 76 | 98 | Note 2 | Note 3 | 13 | 07 | 00 |
| | F1 | 10 | 00 | 01 | 00 | 01 | Note 4 | | | | | |

ENVELOPE CALL CONTROL 1.6.1B

Logically:

Device identities

Source device: ME Destination device: SIM

Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "01234567890123456789"

Capability configuration parameters 1

This parameter is optional. If present, the contents shall not be checked.

Subaddress

This parameter is optional. If present, the contents shall not be checked.

Location Information

MCC & MNC the mobile country and network code (001110)

LAC the location Area Code (0001)
Cell ID Cell Identity Value (0001)

Capability configuration parameters 2

This parameter is optional. If present, the contents shall not be checked.

Coding:

| BER-TLV: | D4 | Note 1 | 82 | 02 | 82 | 81 | 86 | 0B | 91 | 10 | 32 | 54 |
|----------|----|-----------|----|----|----|----|-----------|-----------|-----------|----|----|----|
| | 76 | 98 | 10 | 32 | 54 | 76 | 98 | Note 2 | Note 3 | 13 | 07 | 00 |
| | 11 | 10 | 00 | 01 | 00 | 01 | Note 4 | | | | | |

Note 1: Length of BER-TLV is '1A' plus the actual length of all the present optional SIMPLE-TLV data objects.

Note 2: Capability configuration parameters 1 may be present at this place. If present, it may take up several octets.

Note 3: Subaddress may be present at this place. If present, it may take up several octets.

Note 4: Capability configuration parameters 2 may be present at this place. If present, it may take up several octets.

CALL CONTROL RESULT 1.6.1

Logically:

Call control result: '02' = Allowed with modifications

Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "010203"

| | | | | 0.4 | 0.4 | 4.0 | 00 | |
|----------|----|----|----|-----|-----|-----|----|----|
| BER-TLV: | 02 | 06 | 86 | 04 | 91 | 10 | 20 | 30 |

Expected Sequence 1.7A (CALL CONTROL BY SIM, set up call attempt resulting from a set up call proactive command, allowed with modifications)

| Step | Direction | Message / Action | Comments |
|------|-----------------------|--|--|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND: SET UP CALL 1.7.1 PENDING | [This test applies to MEs asking for user confirmation before sending the ENVELOPE CALL CONTROL command] |
| 2 | ME→SIM | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SET UP CALL 1.7.1 | [Set up call to "+012340123456"] |
| 4 | $ME \rightarrow USER$ | ME displays "+012340123456" during user confirmation phase. | |
| 5 | $USER \to ME$ | The user confirms the call set up | [user confirmation] |
| 6 | $ME \rightarrow SIM$ | ENVELOPE CALL CONTROL 1.7.1A or ENVELOPE CALL CONTROL 1.7.1B | [Option A shall apply for GSM parameters] [Option B shall apply for PCS1900 parameters] |
| 7 | $SIM \to ME$ | 9F 0B | |
| 8 | $ME \to SIM$ | GET RESPONSE | |
| 9 | $SIM \to ME$ | CALL CONTROL RESULT 1.7.1 | [Call control result: "Allowed with modifications"] |
| 10 | $ME \to SS$ | The ME sets up the call to "+0111111111111" | |
| 11 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP CALL 1.7.1 | [command performed successfully] |

Expected Sequence 1.7 B (CALL CONTROL BY SIM, set up call attempt resulting from a set up call proactive command, allowed with modifications)

| Step | Direction | Message / Action | Comments |
|------|-----------------------|---|---|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SET UP CALL 1.7.1 PENDING | [This test applies to MEs asking for user confirmation after sending the ENVELOPE CALL CONTROL command] |
| 2 | ME→SIM | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SET UP CALL 1.7.1 | [Set up call to "+012340123456"] |
| 4 | $ME \rightarrow SIM$ | ENVELOPE CALL CONTROL 1.7.1A or | [Option A shall apply for GSM parameters] |
| | | ENVELOPE CALL CONTROL 1.7.1B | [Option B shall apply for PCS1900 parameters] |
| 5 | $SIM \to ME$ | 9F 0B | |
| 6 | $ME \rightarrow SIM$ | GET RESPONSE | |
| 7 | $SIM \to ME$ | CALL CONTROL RESULT 1.7.1 | [Call control result: "Allowed with modifications"] |
| 8 | $ME \rightarrow USER$ | ME displays "+012340123456" during user confirmation phase. | |
| 9 | $USER \to ME$ | The user confirms the call set up | [user confirmation] |
| 10 | $ME \rightarrow SS$ | The ME sets up the call to "+0111111111111" | [call is set up to modified address] |
| 11 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP CALL 1.7.1 | [command performed successfully] |

PROACTIVE COMMAND: SET UP CALL 1.7.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: Only if not currently busy on another call

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: '+012340123456"

Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "012340123456"

Coding:

| BER-TLV: | D0 | 21 | 81 | 03 | 01 | 10 | 00 | 82 | 02 | 81 | 83 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 05 | 0D | 2B | 30 | 31 | 32 | 33 | 34 | 30 | 31 | 32 |
| | 33 | 34 | 35 | 36 | 86 | 07 | 91 | 10 | 32 | 04 | 21 |
| | 43 | 65 | | | | | | | | | |

ENVELOPE CALL CONTROL 1.7.1A

Logically:

Device identities

Source device: ME Destination device: SIM

Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "012340123456"

Capability configuration parameters 1

This parameter is optional. If present, the contents shall not be checked.

Subaddress

This parameter is optional. If present, the contents shall not be checked.

Location Information

MCC & MNC the mobile country and network code (00F110)

LAC the location Area Code (0001)
Cell ID Cell Identity Value (0001)

Capability configuration parameters 2

This parameter is optional. If present, the contents shall not be checked.

Coding:

| BER-TLV: | D4 | Note 1 | 02 | 02 | 82 | 81 | 06 | 07 | 91 | 10 | 32 |
|----------|----|-----------|----|----|-----------|-----------|----|----|----|----|----|
| | 04 | 21 | 43 | 65 | Note 2 | Note 3 | 13 | 07 | 00 | F1 | 10 |
| | 00 | 01 | 00 | 01 | Note 4 | | | | | | |

ENVELOPE CALL CONTROL 1.7.1B

Logically:

Device identities

Source device: ME Destination device: SIM

Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "012340123456"

Capability configuration parameters 1

This parameter is optional. If present, the contents shall not be checked.

Subaddress

This parameter is optional. If present, the contents shall not be checked.

Location Information

MCC & MNC the mobile country and network code (001110)

LAC the location Area Code (0001)
Cell ID Cell Identity Value (0001)

Capability configuration parameters 2

This parameter is optional. If present, the contents shall not be checked.

Coding:

| BER-TLV: | D4 | Note 1 | 02 | 02 | 82 | 81 | 06 | 07 | 91 | 10 | 32 |
|----------|----|-----------|----|----|-----------|-----------|----|----|----|----|----|
| | 04 | 21 | 43 | 65 | Note 2 | Note 3 | 13 | 07 | 00 | 11 | 10 |
| | 00 | 01 | 00 | 01 | Note 4 | | | | | | |

Note 1: Length of BER-TLV is '16' plus the actual length of all the present optional SIMPLE-TLV data objects.

Note 2: Capability configuration parameters 1 may be present at this place. If present, it may take up several octets.

Note 3: Subaddress may be present at this place. If present, it may take up several octets.

Note 4: Capability configuration parameters 2 may be present at this place. If present, it may take up several octets.

CALL CONTROL RESULT 1.7.1

Logically:

Call control result: '02' = Allowed with modifications

Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "01111111111"

Coding:

| BER-TLV: 02 09 86 07 91 10 11 11 11 11 11 |
|---|
|---|

TERMINAL RESPONSE: SET UP CALL 1.7.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: Only if not currently busy on another call

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Expected Sequence 1.8 (CALL CONTROL BY SIM, set up call attempt by user, allowed with modifications: emergency call)

| Step | Direction | Message / Action | Comments |
|------|---------------|-----------------------------------|-------------------------------------|
| 1 | $User \to ME$ | Set up a call to | |
| | | "+01234567890123456789" | |
| 2 | $ME \to SIM$ | ENVELOPE CALL CONTROL 1.8.1A | [Option A shall apply for GSM |
| | | | parameters] |
| | | or | |
| | | ENVELOPE CALL CONTROL 1.8.1B | [Option B shall apply for PCS1900 |
| | | | parameters |
| 3 | $SIM \to ME$ | 9F 07 | |
| 4 | $ME \to SIM$ | GET RESPONSE | |
| 5 | $SIM \to ME$ | CALL CONTROL RESULT 1.8.1 | [Call control result: "Allowed with |
| | | | modifications"] |
| 6 | $ME \to SS$ | The ME sets up an emergency call; | |

ENVELOPE CALL CONTROL 1.8.1A

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "01234567890123456789"

Capability configuration parameters 1

This parameter is optional. If present, the contents shall not be checked.

Subaddress

This parameter is optional. If present, the contents shall not be checked.

Location Information

MCC & MNC the mobile country and network code (00F110)

LAC the location Area Code (0001)
Cell ID Cell Identity Value (0001)

Capability configuration parameters 2

This parameter is optional. If present, the contents shall not be checked.

Coding:

| BER-TLV: | D4 | Note 1 | 82 | 02 | 82 | 81 | 86 | 0B | 91 | 10 | 32 | 54 |
|----------|----|-----------|----|----|----|----|-----------|-----------|-----------|----|----|----|
| | 76 | 98 | 10 | 32 | 54 | 76 | 98 | Note 2 | Note 3 | 13 | 07 | 00 |
| | F1 | 10 | 00 | 01 | 00 | 01 | Note 4 | | | | | |

ENVELOPE CALL CONTROL 1.8.1B

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "01234567890123456789"

Capability configuration parameters 1

This parameter is optional. If present, the contents shall not be checked.

Subaddress

This parameter is optional. If present, the contents shall not be checked.

Location Information

MCC & MNC the mobile country and network code (001110)

LAC the location Area Code (0001)
Cell ID Cell Identity Value (0001)

Capability configuration parameters 2

This parameter is optional. If present, the contents shall not be checked.

Coding:

| BER-TLV: | D4 | Note 1 | 82 | 02 | 82 | 81 | 86 | 0B | 91 | 10 | 32 | 54 |
|----------|----|-----------|----|----|----|----|-----------|-----------|-----------|----|----|----|
| | 76 | 98 | 10 | 32 | 54 | 76 | 98 | Note 2 | Note 3 | 13 | 07 | 00 |
| | 11 | 10 | 00 | 01 | 00 | 01 | Note 4 | | | | | |

Note 1: Length of BER-TLV is '1A' plus the actual length of all the present optional SIMPLE-TLV data objects.

Note 2: Capability configuration parameters 1 may be present at this place. If present, it may take up several octets.

Note 3: Subaddress may be present at this place. If present, it may take up several octets.

Note 4: Capability configuration parameters 2 may be present at this place. If present, it may take up several octets.

CALL CONTROL RESULT 1.8.1

Logically:

Call control result Allowed, with modification

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Address value "112"

Coding:

| BER-TLV: | 02 | 05 | 86 | 03 | 81 | 11 | F2 |
|----------|----|----|----|----|----|----|----|
| | 02 | 00 | 00 | 00 | 01 | | _ |

Expected Sequence 1.9 (CALL CONTROL BY SIM , set up call attempt by user, allowed with modifications: number in $\mathsf{EF}_{\mathsf{ECC}}$)

| Step | Direction | Message / Action | Comments |
|------|----------------------|--------------------------------------|-------------------------------------|
| 1 | $User \to ME$ | Set up a call to | |
| | | "+01234567890123456789" | |
| 2 | $ME \rightarrow SIM$ | ENVELOPE CALL CONTROL | [Option A shall apply for GSM |
| | | 1.9.1A | parameters] |
| | | or | |
| | | ENVELOPE CALL CONTROL 1.9.1B | |
| | | | parameters] |
| 3 | $SIM \rightarrow ME$ | 9F 07 | |
| 4 | $ME \rightarrow SIM$ | GET RESPONSE | |
| 5 | $SIM \rightarrow ME$ | CALL CONTROL RESULT 1.9.1 | [Call control result: "Allowed with |
| | | | modifications"] |
| 6 | $ME \to SS$ | The ME sets up call with the dialled | |
| | | digits "1020". The ME does not set | |
| | | up an emergency call, but stes up a | |
| | | normal call | |

ENVELOPE CALL CONTROL 1.9.1A

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "01234567890123456789"

Capability configuration parameters 1

This parameter is optional. If present, the contents shall not be checked.

Subaddress

This parameter is optional. If present, the contents shall not be checked.

Location Information

MCC & MNC the mobile country and network code (00F110)

LAC the location Area Code (0001)
Cell ID Cell Identity Value (0001)

Capability configuration parameters 2

This parameter is optional. If present, the contents shall not be checked.

Coding:

| BER-TLV: | D4 | Note 1 | 82 | 02 | 82 | 81 | 86 | 0B | 91 | 10 | 32 | 54 |
|----------|----|-----------|----|----|----|----|-----------|-----------|-----------|----|----|----|
| | 76 | 98 | 10 | 32 | 54 | 76 | 98 | Note 2 | Note 3 | 13 | 07 | 00 |
| | F1 | 10 | 00 | 01 | 00 | 01 | Note 4 | | | | | |

ENVELOPE CALL CONTROL 1.9.1B

Logically:

Device identities

Source device: ME Destination device: SIM

Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "01234567890123456789"

Capability configuration parameters 1

This parameter is optional. If present, the contents shall not be checked.

Subaddress

This parameter is optional. If present, the contents shall not be checked.

Location Information

MCC & MNC the mobile country and network code (001110)

LAC the location Area Code (0001)
Cell ID Cell Identity Value (0001)

Capability configuration parameters 2

This parameter is optional. If present, the contents shall not be checked.

| BER-TLV: | D4 | Note | 82 | 02 | 82 | 81 | 86 | 0B | 91 | 10 | 32 | 54 |
|----------|----|------|----|----|----|----|------|------|------|----|----|----|
| | 76 | 98 | 10 | 32 | 54 | 76 | 98 | Note | Note | 13 | 07 | 00 |
| | 11 | 10 | 00 | 01 | 00 | 01 | Note | 2 | 3 | | | |
| | 11 | 10 | 00 | UI | 00 | 01 | 4 | | | | | |

Note 1: Length of BER-TLV is '1A' plus the actual length of all the present optional SIMPLE-TLV data objects.

Note 2: Capability configuration parameters 1 may be present at this place. If present, it may take up several octets.

Note 3: Subaddress may be present at this place. If present, it may take up several octets.

Note 4: Capability configuration parameters 2 may be present at this place. If present, it may take up several octets.

CALL CONTROL RESULT 1.9.1

Logically:

Call control result Allowed, with modification

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Address value "1020"

Coding:

| BER-TLV: | 02 | 05 | 86 | 03 | 81 | 01 | 02 |
|----------|----|----|----|----|----|----|----|

Expected Sequence 1.10 (CALL CONTROL BY SIM, set up call attempt by user to an emergency call)

| Step | Direction | Message / Action | Comments |
|------|----------------------|-----------------------------|----------|
| 1 | $User \to ME$ | Set up a call to "112" | |
| 2 | $ME \rightarrow SIM$ | The ME does not send any | |
| | | ENVELOPE CALL CONTROL | |
| 3 | $ME \to SS$ | The ME sets up an emergency | |
| | | call | |

Expected Sequence 1.11 (CALL CONTROL BY SIM , set up call through call register, the SIM responds with '90 00')

Pre-condition: the ME has a mean to register the last dialled number(s), and the ME will store dialled numbers allowed by call control in its register.

| Step | Direction | Message / Action | Comments |
|------|----------------------|--|---|
| 1 | $User \to ME$ | Set up a call to "+01234567890123456789" | |
| 2 | $ME \rightarrow SIM$ | ENVELOPE CALL CONTROL 1.1.1A | [Option A shall apply for GSM parameters] |
| | | or | |
| | | ENVELOPE CALL CONTROL 1.1.1B | [Option B shall apply for PCS1900 parameters] |
| 3 | $SIM \rightarrow ME$ | 90 00 | |
| 4 | $ME \to SS$ | The ME sets up the call without modification | [Set up call to "+01234567890123456789"] |
| 5 | $USER \to ME$ | End Call. | |
| 6 | $USER \to ME$ | Recall the last dialled number | |
| 7 | $ME \rightarrow SIM$ | ENVELOPE CALL CONTROL 1.1.1A | [Option A shall apply for GSM parameters] |
| | | or ENVELOPE CALL CONTROL | [Option B shall apply for PCS1900 |
| | | 1.1.1B | parameters] |
| 8 | $SIM \rightarrow ME$ | 90 00 | |
| 9 | $ME \to SS$ | The ME sets up the call without modification | [Set up call to "+01234567890123456789"] |
| 10 | $USER \to ME$ | End Call. | |

Expected Sequence 1.12 (CALL CONTROL BY SIM, set up call through call register, allowed without modification)

Pre-condition: the ME has a mean to register the last dialled number(s), and the ME will store dialled numbers allowed by call control in its register.

| Step | Direction | Message / Action | Comments |
|------|----------------------|--|---|
| 1 | $User \to ME$ | Set up a call to "+0123456789" | |
| 2 | $ME \rightarrow SIM$ | ENVELOPE CALL CONTROL 1.2.1A or | [Option A shall apply for GSM parameters] |
| | | ENVELOPE CALL CONTROL 1.2.1B | [Option B shall apply for PCS1900 parameters] |
| 3 | $SIM \to ME$ | 9F 02 | |
| 4 | $ME \to SIM$ | GET RESPONSE | |
| 5 | $SIM \to ME$ | CALL CONTROL RESULT 1.2.1 | [Call control result: "Allowed, no modification"] |
| 6 | $ME \to SS$ | The ME sets up the call without modification | [Set up call to "+01234567890123456789"] |
| 7 | $User \to ME$ | End the call then call the last dialled number | |
| 8 | $ME \rightarrow SIM$ | ENVELOPE CALL CONTROL 1.2.1A or | [Option A shall apply for GSM parameters] |
| | | ENVELOPE CALL CONTROL | [Option B shall apply for PCS1900 parameters] |
| 9 | $SIM \to ME$ | 9F 02 | [Call control result: "Allowed, no modification"] |
| 10 | $ME \to SIM$ | GET RESPONSE | |
| 11 | $SIM \to ME$ | CALL CONTROL RESULT 1.2.1 | |
| 12 | $ME \to SS$ | The ME sets up the call without modification | [Set up call to "+01234567890123456789"] |

Expected Sequence 1.13 (CALL CONTROL BY SIM, set up call through call register, not allowed)

Pre-condition: the ME has a mean to register the last dialled number(s), and the ME will store dialled numbers not allowed by call control in its register.

| Step | Direction | Message / Action | Comments |
|--------|--|---|---|
| 1 | $User \to ME$ | Set up a call to "+0123456789" | |
| 2 | $ME \to SIM$ | ENVELOPE CALL CONTROL 1.4.1A or | [Option A shall apply for GSM parameters] |
| | | ENVELOPE CALL CONTROL 1.4.1B | [Option B shall apply for PCS1900 parameters] |
| 3 | $SIM \to ME$ | 9F 02 | |
| 4 | $ME \rightarrow SIM$ | GET RESPONSE | |
| 5 6 | $\begin{array}{c} SIM \to ME \\ ME \to SS \end{array}$ | CALL CONTROL RESULT 1.4.1 The ME does not set up the call | [Call control result: "not Allowed"] |
| 7 | User → ME | The user calls the last dialled number | |
| 8 | $ME \to SIM$ | ENVELOPE CALL CONTROL 1.4.1A | [Option A shall apply for GSM parameters] |
| | | ENVELOPE CALL CONTROL | [Option B shall apply for PCS1900 parameters] |
| 9 | $SIM \to ME$ | 9F 02 | |
| 10 | $ME \rightarrow SIM$ | GET RESPONSE | |
| 11 | $SIM \to ME$ | CALL CONTROL RESULT 1.4.1 | [Call control result: "not Allowed"] |
| 12 | $ME \to SS$ | The ME does not set up the call | |

Expected Sequence 1.14 (CALL CONTROL BY SIM , set up call through call register, allowed with modifications)

Pre-condition: the ME has a mean to register the last dialled number(s), and the ME will store dialled numbers allowed with modification by call control in its register.

| Step | Direction | Message / Action | Comments |
|------|----------------------|--|---|
| 1 | $User \to ME$ | Set up a call to "+0123456789" | |
| 2 | $ME \to SIM$ | ENVELOPE CALL CONTROL 1.6.1A | [Option A shall apply for GSM parameters] |
| | | or ENVELOPE CALL CONTROL 1.6.1B | [Option B shall apply for PCS1900 parameters] |
| 3 | $SIM \to ME$ | 9F 08 | |
| 4 | $ME \to SIM$ | GET RESPONSE | |
| 5 | $SIM \to ME$ | CALL CONTROL RESULT 1.6.1 | [Call control result: "Allowed with modifications"] |
| 6 | $ME \to SS$ | The ME sets up the call to "+010203" | |
| 7 | $User \to ME$ | End the call and then set up a call to "+01234567890123456789" | |
| 8 | $ME \rightarrow SIM$ | ENVELOPE CALL CONTROL 1.6.1A or | [Option A shall apply for GSM parameters] |
| | | ENVELOPE CALL CONTROL 1.6.1B | [Option B shall apply for PCS1900 parameters] |
| 9 | $SIM \to ME$ | 9F 08 | |
| 10 | $ME \to SIM$ | GET RESPONSE | |
| 11 | $SIM \to ME$ | CALL CONTROL RESULT 1.6.1 | [Call control result: "Allowed with modifications"] |
| 12 | $ME \rightarrow SS$ | The ME sets up the call to "+010203" | |

27.22.6.1.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.14.

27.22.6.2 Procedure for Supplementary (SS) Services

27.22.6.2.1 Definition and applicability

See clause 3.2.2.

27.22.6.2.2 Conformance requirement

The ME shall support the CALL CONTROL facility as defined in the following technical specifications:

• 3GPP TS 11.14 [15] clause 9.1.2.

27.22.6.2.3 Test purpose

To verify that the ME first pass the supplementary service control string corresponding to the supplementary service operation to the SIM, using the ENVELOPE (CALL CONTROL) command.

To verify that, if the SIM responds with '90 00', the ME shall send the supplementary service operation with the information as sent to the SIM.

To verify that, if the SIM responds with '9F XX', the ME shall use the GET RESPONSE command to get the response data. The response data from the SIM shall indicate to the ME whether to send the supplementary service operation as proposed, not send the SS operation, or instead send the SS operation using the data supplied by the SIM.

27.22.6.2.4 Method of tests

27.22.6.2.4.1 Initial conditions

The ME is connected to the SIM Simulator and the System Simulator.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The elementary files are coded as SIM Application Toolkit default with the following exception:

The call control service is allocated and activated in the SIM Service Table.

The GSM parameters of the system simulator are:

- Mobile Country Code (MCC) = 001;
- Mobile Network Code (MNC) = 01;
- Location Area Code (LAC) = 0001;
- Cell Identity value = 0001.

The PCS 1900 parameters of the system simulator are:

- Mobile Country Code (MCC) = 001;
- Mobile Network Code (MNC) = 011;
- Location Area Code (LAC) = 0001;
- Cell Identity value = 0001.

27.22.6.2.4.2 Procedure

Expected Sequence 2.1 (CALL CONTROL BY SIM, send SS, the SIM responds with '90 00')

| Step | Direction | Message / Action | Comments |
|------|----------------------|--------------------------------------|---|
| 1 | $User \to ME$ | The user selects the facility of the | |
| | | ME which requires an | |
| | | unconditional call forward | |
| | | supplementary service operation | |
| | | to be sent to the network (System | |
| | | Simulator). | |
| 2 | $ME \rightarrow SIM$ | ENVELOPE CALL CONTROL | Option A shall apply for GSM |
| | | 2.1.1A | parameters] |
| | | or | |
| | | ENVELOPE CALL CONTROL | [Option B shall apply for PCS1900 |
| | | 2.1.1B | parameters |
| 3 | $SIM \rightarrow ME$ | 90 00 | |
| 4 | $ME \rightarrow SS$ | REGISTER 2.1 | [The ME sends the supplementary |
| | / 55 | | service operation with the information as |
| | | | sent to the SIMI |
| 5 | $SS \rightarrow ME$ | RELEASE COMPLETE (SS | , |
| | | RETURN RESULT) 2.1 | |

ENVELOPE CALL CONTROL 2.1.1A

Logically:

Device identities

Source device: ME Destination device: SIM

SS String

TON/NPI: "FF"
Dialling number string "*21**10#"

Location Information

MCC & MNC the mobile country and network code (00F110)

LAC the location Area Code (0001)
Cell ID Cell Identity Value (0001)

Coding:

| BER-TLV: | D4 | 14 | 82 | 02 | 82 | 81 | 89 | 05 | FF | 2A | A1 | 1A |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | B0 | 13 | 07 | 00 | F1 | 10 | 00 | 01 | 00 | 01 | | _ |

ENVELOPE CALL CONTROL 2.1.1B

Logically:

Device identities

Source device: ME Destination device: SIM

SS String

TON/NPI: "FF"
Dialling number string "*21**10#"

Location Information

MCC & MNC the mobile country and network code (001110)

LAC the location Area Code (0001)
Cell ID Cell Identity Value (0001)

| BER-TLV: | D4 | 14 | 82 | 02 | 82 | 81 | 89 | 05 | FF | 2A | A1 | 1A |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | B0 | 13 | 07 | 00 | 11 | 10 | 00 | 01 | 00 | 01 | | |

REGISTER 2.1

Logically (only SS argument):

ACTIVATE SS ARGUMENT

SS-Code:

- Call Forwarding Unconditional

TeleserviceCode

- All Tele Services

Coding:

| Coding | 30 | 06 | 04 | 01 | 21 | 83 | 01 | 00 | | | | |
|--------|----|----|----|----|----|----|----|----|--|--|--|--|
|--------|----|----|----|----|----|----|----|----|--|--|--|--|

RELEASE COMPLETE (SS RETURN RESULT) 2.1

Logically (only from operation code):

ACTIVATE SS RETURN RESULT

Forwarding Info

SS-Code

- Call Forwarding Unconditional

Forward Feature List

ForwardingFeature

TeleserviceCode

- All Tele Services

SS-Status

- state ind.: operative

- provision ind.: provisioned - registration ind.: registered

- activation ind.: active

| Coding | 0C | A0 | 0D | 04 | 01 | 21 | 30 | 08 | 30 | 06 | 83 | 01 |
|--------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | 84 | 01 | 07 | | | | | | | | |

Expected Sequence 2.2 (CALL CONTROL BY SIM, send SS, allowed without modifications)

| Step | Direction | Message / Action | Comments |
|------|----------------------|--|---|
| 1 | $User \to ME$ | The user selects the facility of the | |
| | | ME which requires an | |
| | | unconditional call forward | |
| | | supplementary service operation | |
| | | to be sent to the network (System | |
| 2 | 145 0114 | Simulator). | Continue A shall apply for CCM |
| 2 | $ME \rightarrow SIM$ | ENVELOPE CALL CONTROL 2.2.1A | [Option A shall apply for GSM |
| | | or | parameters] |
| | | ENVELOPE CALL CONTROL | [Option B shall apply for PCS1900 |
| | | 2.2.1B | parameters] |
| 3 | $SIM \rightarrow ME$ | 9F 02 | [|
| 4 | $ME \rightarrow SIM$ | GET RESPONSE | |
| | | | |
| 5 | $SIM \to ME$ | CALL CONTROL RESULT 2.2.1 | [Call control result: "Allowed without |
| | | | modifications"] |
| 6 | $ME \to SS$ | REGISTER 2.1 | The ME sends the supplementary service |
| | | | operation with the information as sent to |
| 7 | CC ME | DELEASE COMPLETE (SS | the SIM |
| ' | $SS \rightarrow ME$ | RELEASE COMPLETE (SS RETURN RESULT) 2.1 | |
| | | RETURN RESULT) 2.1 | |

ENVELOPE CALL CONTROL 2.2.1A

Logically:

Device identities

Source device: ME
Destination device: SIM

SS String

TON/NPI: "FF"
Dialling number string "*21**10#"

Location Information

MCC & MNC the mobile country and network code (00F110)

LAC the location Area Code (0001)
Cell ID Cell Identity Value (0001)

Coding:

| BER-TLV: | D4 | 14 | 82 | 02 | 82 | 81 | 89 | 05 | FF | 2A | A1 | 1A |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | B0 | 13 | 07 | 00 | F1 | 10 | 00 | 01 | 00 | 01 | | |

ENVELOPE CALL CONTROL 2.2.1B

Logically:

Device identities

Source device: ME Destination device: SIM

SS String

TON/NPI: "FF"
Dialling number string "*21**10#"

Location Information

MCC & MNC the mobile country and network code (001110)

LAC the location Area Code (0001)
Cell ID Cell Identity Value (0001)

| BER-TLV: | D4 | 14 | 82 | 02 | 82 | 81 | 89 | 05 | FF | 2A | A1 | 1A |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | B0 | 13 | 07 | 00 | 11 | 10 | 00 | 01 | 00 | 01 | | |

CALL CONTROL RESULT 2.2.1

Logically:

Call control result Allowed, no modifications

Coding:

BER-TLV: 00 00

Expected Sequence 2.3 (CALL CONTROL BY SIM, send SS, not allowed)

| Step | Direction | Message / Action | Comments |
|------|----------------------|--------------------------------------|--------------------------------------|
| 1 | $User \to ME$ | The user selects the facility of the | |
| | | ME which requires an | |
| | | unconditional call forward | |
| | | supplementary service operation | |
| | | to be sent to the network (System | |
| | | Simulator). | |
| 2 | $ME \rightarrow SIM$ | ENVELOPE CALL CONTROL | [Option A shall apply for GSM |
| | | 2.3.1A | parameters] |
| | | or | |
| | | ENVELOPE CALL CONTROL | [Option B shall apply for PCS1900 |
| | | 2.3.1B | parameters] |
| 3 | $SIM \to ME$ | | |
| 4 | $ME \to SIM$ | GET RESPONSE | |
| | | | |
| 5 | $SIM \rightarrow ME$ | CALL CONTROL RESULT 2.3.1 | [Call control result: "Not Allowed"] |
| 6 | $ME \to SS$ | The ME does not send the | |
| | | supplementary service operation | |

ENVELOPE CALL CONTROL 2.3.1A

Logically:

Device identities

Source device: ME Destination device: SIM

SS String

TON/NPI: "FF"
Dialling number string "*21#"

Location Information

MCC & MNC the mobile country and network code (00F110)

LAC the location Area Code (0001)
Cell ID Cell Identity Value (0001)

Coding:

| BER-TLV: | D4 | 12 | 82 | 02 | 82 | 81 | 89 | 03 | FF | 2A | B1 | 13 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 07 | 00 | F1 | 10 | 00 | 01 | 00 | 01 | | | | |

ENVELOPE CALL CONTROL 2.3.1B

Logically:

Device identities

Source device: ME

Destination device: SIM

SS String

TON/NPI: "FF"
Dialling number string "*21#"

Location Information

MCC & MNC the mobile country and network code (001110)

LAC the location Area Code (0001)
Cell ID Cell Identity Value (0001)

Coding:

| BER-TLV: | D4 | 12 | 82 | 02 | 82 | 81 | 89 | 03 | FF | 2A | B1 | 13 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 07 | 00 | 11 | 10 | 00 | 01 | 00 | 01 | | | | |

CALL CONTROL RESULT 2.3.1

Logically:

Call control result Not Allowed

Coding:

BER-TLV: 01 00

Expected Sequence 2.4 (CALL CONTROL BY SIM, send SS, allowed with modifications)

| Step | Direction | Message / Action | Comments |
|------|----------------------|---|--|
| 1 | $User \to ME$ | The user selects the facility of the ME which requires an | |
| | | unconditional call forward | |
| | | supplementary service operation | |
| | | to be sent to the network (System Simulator). | |
| 2 | $ME \rightarrow SIM$ | ENVELOPE CALL CONTROL 2.4.1A or | [Option A shall apply for GSM parameters] |
| | | ENVELOPE CALL CONTROL 2.4.1B | [Option B shall apply for PCS1900 parameters] |
| 3 | $SIM \to ME$ | 9F 07 | |
| 4 | $ME \to SIM$ | GET RESPONSE | |
| 5 | $SIM \to ME$ | CALL CONTROL RESULT 2.4.1 | [Call control result: "Allowed with modifications"] |
| 6 | $ME \rightarrow SS$ | REGISTER 2.4 | [The ME sends the supplementary service operation with the information as sent by the SIM] |
| 7 | $SS \to ME$ | RELEASE COMPLETE (SS RETURN RESULT) 2.4 | Solit by the Chin |

ENVELOPE CALL CONTROL 2.4.1A

Logically:

Device identities

Source device: ME Destination device: SIM

SS String

TON/NPI: "FF"
Dialling number string "*21#"

Location Information

MCC & MNC the mobile country and network code (00F110)

LAC the location Area Code (0001)

Cell ID Cell Identity Value (0001)

Coding:

| BER-TLV: | D4 | 12 | 82 | 02 | 82 | 81 | 89 | 03 | FF | 2A | B1 | 13 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 07 | 00 | F1 | 10 | 00 | 01 | 00 | 01 | | | | |

ENVELOPE CALL CONTROL 2.4.1B

Logically:

Device identities

Source device: ME Destination device: SIM

SS String

TON/NPI: "FF"
Dialling number string "*21#"

Location Information

MCC & MNC the mobile country and network code (001110)

LAC the location Area Code (0001)
Cell ID Cell Identity Value (0001)

Coding:

| BER-TLV: | D4 | 12 | 82 | 02 | 82 | 81 | 89 | 03 | FF | 2A | B1 | 13 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| _ | 07 | 00 | 11 | 10 | 00 | 01 | 00 | 01 | | | | |

CALL CONTROL RESULT 2.4.1

Logically:

Call control result Allowed, with modifications

SS String

TON/NPI "FF" SS String "*#21#"

Coding:

| Coding 02 06 | 89 (|)4 FF | BA | 12 | FB |
|--------------|------|-------|----|----|----|
|--------------|------|-------|----|----|----|

REGISTER 2.4

Logically (only SS argument):

INTERROGATE SS ARGUMENT

SS-Code

- Call Forwarding Unconditional

Coding:

| Coding | 30 | 03 | 04 | 01 | 21 | |
|--------|----|----|----|----|----|--|
| | | | | | | |

RELEASE COMPLETE (SS RETURN RESULT) 2.4

Logically (only from operation code):

INTERROGATE SS RESULT

Call Forwarding Unconditional

SS-Status

- state ind .: operative

provision ind.: provisionedregistration ind.: registeredactivation ind.: not active

Coding:

| Coding | 80 | 01 | 06 | | | |
|--------|----|----|----|--|--|--|

27.22.6.2.5 Test requirement

The ME shall operate in the manner defined in expected sequences 2.1 to 2.4.

27.22.6.3 Interaction with Fixed Dialling Number (FDN)

27.22.6.3.1 Definition and applicability

See clause 3.2.2.

27.22.6.3.2 Conformance requirement

The ME shall support the CALL CONTROL facility as defined in:

• 3GPP TS 11.14 [15] clause 9.1.4.

27.22.6.3.3 Test purpose

To verify that the ME checks that the number entered through the MMI is on the FDN list.

To verify that, if the MMI input does not pass the FDN check, the call shall not be set up.

To verify that, if the MMI input does pass the FDN check, the ME shall pass the dialled digits and other parameters to the SIM, using the ENVELOPE (CALL CONTROL) command.

To verify that, if the SIM responds with "allowed, no modification", the ME shall set up the call as proposed.

To verify that, if the SIM responds with "not allowed", the ME shall not set up the call.

To verify that, if the SIM responds with "allowed with modifications", the ME shall set up the call in accordance with the response from the SIM. If the modifications involve changing the dialled digits, the ME shall not re-check this modified number against the FDN list.

27.22.6.3.4 Method of tests

27.22.6.3.4.1 Initial conditions

The ME is connected to the SIM Simulator and the System Simulator.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The elementary files are coded as SIM Application Toolkit default with the following exceptions:

The call control service is allocated and activated in the SIM Service Table.

Fixed Dialling Number service is enabled.

The GSM parameters of the system simulator are:

• Mobile Country Code (MCC) = 001;

- Mobile Network Code (MNC) = 01;
- Location Area Code (LAC) = 0001;
- Cell Identity value = 0001.

The PCS 1900 parameters of the system simulator are:

- Mobile Country Code (MCC) = 001;
- Mobile Network Code (MNC) = 011;
- Location Area Code (LAC) = 0001;
- Cell Identity value = 0001.

27.22.6.3.4.2 Procedure

Expected Sequence 3.1 (CALL CONTROL BY SIM, set up a call not in EF_{FDN})

| Step | Direction | Message / Action | Comments |
|------|---------------------|--|----------|
| 1 | $User \to ME$ | The user sets up a call to "4321" | |
| 2 | / • | The ME does not send the ENVELOPE (CALL CONTROL) command to the SIM. | |
| 3 | $ME \rightarrow SS$ | The ME does not set up the call. | |

Expected Sequence 3.2 (CALL CONTROL BY SIM , set up a call in EF_FDN , the SIM responds with '90 00')

| Step | Direction | Message / Action | Comments |
|------|----------------------|----------------------------------|-----------------------------------|
| 1 | $User \to ME$ | The user sets up a call to "123" | |
| 2 | $ME \rightarrow SIM$ | ENVELOPE CALL CONTROL | [Option A shall apply for GSM |
| | | 3.2.1A | parameters] |
| | | or | |
| | | ENVELOPE CALL CONTROL | [Option B shall apply for PCS1900 |
| | | 3.2.1B | parameters] |
| 3 | $SIM \rightarrow ME$ | 90 00 | |
| 4 | $ME \to SS$ | The ME sets up the call without | [Set up call to "123"] |
| | | modification | |

ENVELOPE CALL CONTROL 3.2.1A

Logically:

Device identities

Source device: ME Destination device: SIM

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Dialling number string "123" Capability configuration parameters 1

This parameter is optional. If present, the contents shall not be checked.

Subaddress

This parameter is optional. If present, the contents shall not be checked.

Location Information

MCC & MNC the mobile country and network code (00F110)

LAC the location Area Code (0001)
Cell ID Cell Identity Value (0001)

Capability configuration parameters 2

This parameter is optional. If present, the contents shall not be checked.

Coding:

| BER-TLV: | D4 | Note 1 | 82 | 02 | 82 | 81 | 86 | 03 | 81 | 21 | F3 | Note 2 |
|----------|--------|--------|----|----|----|----|----|----|----|----|--------|--------|
| | Note 3 | 13 | 07 | 00 | F1 | 10 | 00 | 01 | 00 | 01 | Note 4 | |

ENVELOPE CALL CONTROL 3.2.1B

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Dialling number string "123"

Capability configuration parameters 1

This parameter is optional. If present, the contents shall not be checked.

Subaddress

This parameter is optional. If present, the contents shall not be checked.

Location Information

MCC & MNC the mobile country and network code (001110)

LAC the location Area Code (0001)
Cell ID Cell Identity Value (0001)

Capability configuration parameters 2

This parameter is optional. If present, the contents shall not be checked.

Coding:

| BER-TLV: | D4 | Note 1 | 82 | 02 | 82 | 81 | 86 | 03 | 81 | 21 | F3 | Note 2 |
|----------|--------|--------|----|----|----|----|----|----|----|----|--------|--------|
| | Note 3 | 13 | 07 | 00 | 11 | 10 | 00 | 01 | 00 | 01 | Note 4 | |

- Note 1: Length of BER-TLV is '12' plus the actual length of all the present optional SIMPLE-TLV data objects.
- Note 2: Capability configuration parameters 1 may be present at this place. If present, it may take up several octets.
- Note 3: Subaddress may be present at this place. If present, it may take up several octets.
- Note 4: Capability configuration parameters 2 may be present at this place. If present, it may take up several octets.

Expected Sequence 3.3 (CALL CONTROL BY SIM , set up a call in EF_FDN , Allowed without modifications)

| Step | Direction | Message / Action | Comments |
|------|----------------------|-----------------------------------|--|
| 1 | $User \to ME$ | The user sets up a call to "9876" | |
| 2 | $ME \rightarrow SIM$ | ENVELOPE CALL CONTROL | [Option A shall apply for GSM |
| | | 3.3.1A | parameters] |
| | | or | |
| | | | [Option B shall apply for PCS1900 |
| | | 3.3.1B | parameters] |
| 3 | $SIM \to ME$ | 9F 02 | |
| 4 | $ME \rightarrow SIM$ | GET RESPONSE | |
| 5 | $SIM \to ME$ | CALL CONTROL RESULT 3.3.1 | [Call control result: "Allowed without |
| | | | modifications"] |
| 6 | $ME \to SS$ | The ME sets up the call without | [Set up call to "9876"] |
| | | modification | |

ENVELOPE CALL CONTROL 3.3.1A

Logically:

Device identities

Source device: ME Destination device:

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Dialling number string "9876" Capability configuration parameters 1

This parameter is optional. If present, the contents shall not be checked.

Subaddress

This parameter is optional. If present, the contents shall not be checked.

Location Information

MCC & MNC the mobile country and network code (00F110)

LAC the location Area Code (0001) Cell ID Cell Identity Value (0001)

Capability configuration parameters 2

This parameter is optional. If present, the contents shall not be checked.

Coding:

| BER-TLV: | D4 | Note 1 | 82 | 02 | 82 | 81 | 86 | 03 | 81 | 89 | 67 | Note 2 |
|----------|--------|--------|----|----|----|----|----|----|----|----|--------|--------|
| | Note 3 | 13 | 07 | 00 | F1 | 10 | 00 | 01 | 00 | 01 | Note 4 | |

ENVELOPE CALL CONTROL 3.3.1B

Logically:

Device identities

Source device: ME Destination device: SIM

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Dialling number string "9876" Capability configuration parameters 1

This parameter is optional. If present, the contents shall not be checked.

Subaddress

This parameter is optional. If present, the contents shall not be checked.

Location Information

MCC & MNC the mobile country and network code (001110)

LAC the location Area Code (0001) Cell ID Cell Identity Value (0001)

Capability configuration parameters 2

This parameter is optional. If present, the contents shall not be checked.

Coding:

| BER-TLV: | D4 | Note 1 | 82 | 02 | 82 | 81 | 86 | 03 | 81 | 89 | 67 | Note 2 |
|----------|--------|--------|----|----|----|----|----|----|----|----|--------|--------|
| | Note 3 | 13 | 07 | 00 | 11 | 10 | 00 | 01 | 00 | 01 | Note 4 | |

Note 1: Length of BER-TLV is '12' plus the actual length of all the present optional SIMPLE-TLV data objects.

Note 2: Capability configuration parameters 1 may be present at this place. If present, it may take up several octets.

Note 3: Subaddress may be present at this place. If present, it may take up several octets.

Note 4: Capability configuration parameters 2 may be present at this place. If present, it may take up several octets

CALL CONTROL RESULT 3.3.1

Logically:

Call control result Allowed, no modifications

Coding:

BER-TLV: 00 00

Expected Sequence 3.4 (CALL CONTROL BY SIM, set up a call in EF_{FDN}, Not Allowed)

| Step | Direction | Message / Action | Comments |
|------|----------------------|-----------------------------------|--------------------------------------|
| 1 | $User \to ME$ | The user sets up a call to "9876" | |
| 2 | $ME \to SIM$ | ENVELOPE CALL CONTROL | [Option A shall apply for GSM |
| | | 3.4.1A | parameters] |
| | | or | |
| | | ENVELOPE CALL CONTROL | [Option B shall apply for PCS1900 |
| | | 3.4.1B | parameters] |
| 3 | $SIM \rightarrow ME$ | 9F 02 | |
| 4 | $ME \to SIM$ | GET RESPONSE | |
| 5 | $SIM \to ME$ | CALL CONTROL RESULT 3.4.1 | [Call control result: "Not Allowed"] |
| 6 | $ME \to SS$ | The ME does not set up the call | |

ENVELOPE CALL CONTROL 3.4.1A

Logically:

Device identities

Source device: ME Destination device: SIM

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Dialling number string "9876" Capability configuration parameters 1

This parameter is optional. If present, the contents shall not be checked.

Subaddress

This parameter is optional. If present, the contents shall not be checked.

Location Information

MCC & MNC the mobile country and network code (00F110)

LAC the location Area Code (0001)
Cell ID Cell Identity Value (0001)

Capability configuration parameters 2

This parameter is optional. If present, the contents shall not be checked.

Coding:

| BER-TLV: | D4 | Note 1 | 82 | 02 | 82 | 81 | 86 | 03 | 81 | 89 | 67 | Note 2 |
|----------|--------|--------|----|----|----|----|----|----|----|----|--------|--------|
| | Note 3 | 13 | 07 | 00 | F1 | 10 | 00 | 01 | 00 | 01 | Note 4 | |

ENVELOPE CALL CONTROL 3.4.1B

Logically:

Device identities

Source device: ME Destination device: SIM

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Dialling number string "9876"

Capability configuration parameters 1

This parameter is optional. If present, the contents shall not be checked.

Subaddress

This parameter is optional. If present, the contents shall not be checked.

Location Information

MCC & MNC the mobile country and network code (001110)

LAC the location Area Code (0001)
Cell ID Cell Identity Value (0001)

Capability configuration parameters 2

This parameter is optional. If present, the contents shall not be checked.

Coding:

| BER-TLV: | D4 | Note 1 | 82 | 02 | 82 | 81 | 86 | 03 | 81 | 89 | 67 | Note 2 |
|----------|--------|--------|----|----|----|----|----|----|----|----|--------|--------|
| | Note 3 | 13 | 07 | 00 | 11 | 10 | 00 | 01 | 00 | 01 | Note 4 | |

Note 1: Length of BER-TLV is '12' plus the actual length of all the present optional SIMPLE-TLV data objects.

Note 2: Capability configuration parameters 1 may be present at this place. If present, it may take up several octets.

Note 3: Subaddress may be present at this place. If present, it may take up several octets.

Note 4: Capability configuration parameters 2 may be present at this place. If present, it may take up several octets.

CALL CONTROL RESULT 3.4.1

Logically:

Call control result Not Allowed

Coding:

BER-TLV: 01 00

Expected Sequence 3.5 (CALL CONTROL BY SIM, set up a call in EF_{FDN}, Allowed with modifications)

| Step | Direction | Message / Action | Comments |
|------|----------------------|---|---|
| 1 | $User \to ME$ | The user sets up a call to "9876" | |
| 2 | $ME \rightarrow SIM$ | ENVELOPE CALL CONTROL 3.5.1A | [Option A shall apply for GSM parameters] |
| | 0114 145 | 3.5.1B | [Option B shall apply for PCS1900 parameters] |
| 3 | $SIM \rightarrow ME$ | 9F 07 | |
| 4 | $ME \to SIM$ | GET RESPONSE | |
| 5 | $SIM \to ME$ | CALL CONTROL RESULT 3.5.1 | [Call control result: "Allowed with modifications"] |
| 6 | $ME \to SS$ | The ME sets up the call with data sent by the SIM | [Set up call to "3333"] |

ENVELOPE CALL CONTROL 3.5.1A

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Dialling number string "9876" Capability configuration parameters 1

This parameter is optional. If present, the contents shall not be checked.

Subaddress

This parameter is optional. If present, the contents shall not be checked.

Location Information

MCC & MNC the mobile country and network code (00F110)

LAC the location Area Code (0001)
Cell ID Cell Identity Value (0001)

Capability configuration parameters 2

This parameter is optional. If present, the contents shall not be checked.

Coding:

| BER-TLV: | D4 | Note 1 | 82 | 02 | 82 | 81 | 86 | 03 | 81 | 89 | 67 | Note 2 |
|----------|-------|--------|----|----|----|----|----|----|----|----|--------|--------|
| | Note3 | 13 | 07 | 00 | F1 | 10 | 00 | 01 | 00 | 01 | Note 4 | |

ENVELOPE CALL CONTROL 3.5.1B

Logically:

Device identities

Source device: ME Destination device: SIM

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Dialling number string "9876" Capability configuration parameters 1

This parameter is optional. If present, the contents shall not be checked.

Subaddress

This parameter is optional. If present, the contents shall not be checked.

Location Information

MCC & MNC the mobile country and network code (001110)

LAC the location Area Code (0001)
Cell ID Cell Identity Value (0001)

Capability configuration parameters 2

This parameter is optional. If present, the contents shall not be checked.

Coding:

| BER-TLV: | D4 | Note 1 | 82 | 02 | 82 | 81 | 86 | 03 | 81 | 89 | 67 | Note 2 |
|----------|-------|--------|----|----|----|----|----|----|----|----|--------|--------|
| | Note3 | 13 | 07 | 00 | 11 | 10 | 00 | 01 | 00 | 01 | Note 4 | |

Note 1: Length of BER-TLV is '12' plus the actual length of all the present optional SIMPLE-TLV data objects.

Note 2: Capability configuration parameters 1 may be present at this place. If present, it may take up several octets.

Note 3: Subaddress may be present at this place. If present, it may take up several octets.

Note 4: Capability configuration parameters 2 may be present at this place. If present, it may take up several octets.

CALL CONTROL RESULT 3.5.1

Logically:

Call control result Allowed with modifications

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Address value "3333"

Coding:

| BER-TLV: 02 | 05 | 86 | 03 | 81 | 33 | 33 |
|-------------|----|----|----|----|----|----|
|-------------|----|----|----|----|----|----|

27.22.6.3.5 Test requirement

The ME shall operate in the manner defined in expected sequences 3.1 to 3.5.

27.22.6.4 Support of Barred Dialling Number (BDN) service

27.22.6.4.1 Definition and applicability

See clause 3.2.2.

27.22.6.4.2 Conformance requirement

The ME shall support the CALL CONTROL facility as defined in:

• 3GPP TS 11.14 [15] clause 9.1.5.

27.22.6.4.3 Test purpose

To verify that, if Barred Dialling Number service is enabled, the ME checks the number entered through the MMI against EF_{BDN} .

To verify that, if the SIM responds with "not allowed", the ME does not set up the call.

To verify that, if the SIM responds with "allowed, no modification", the ME shall set up the call (or the supplementary service operation) as proposed.

To verify that, if the SIM responds with "allowed with modifications", the ME sets up the call in accordance with the response from the SIM. If the modifications involve changing the dialled number the ME does not re-check this modified number against the FDN list when FDN is enabled.

27.22.6.4.4 Method of tests

27.22.6.4.4.1 Initial conditions

The ME is connected to the SIM Simulator and the Systems Simulator.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The elementary files are coded as SIM Application Toolkit default with the following exceptions:

The call control service is allocated and activated in the SIM Service Table.

Barred Dialling Number service is enabled.

Prior to the execution of expected sequence 4.4 the FDN service shall be enabled.

The GSM parameters of the system simulator are:

- Mobile Country Code (MCC) = 001;
- Mobile Network Code (MNC) = 01;
- Location Area Code (LAC) = 0001;

• Cell Identity value = 0001.

The PCS 1900 parameters of the system simulator are:

- Mobile Country Code (MCC) = 001;
- Mobile Network Code (MNC) = 011;
- Location Area Code (LAC) = 0001;
- Cell Identity value = 0001.

27.22.6.4.4.2 Procedure

Expected Sequence 4.1 (CALL CONTROL BY SIM, set up a call in EF_{BDN})

| Step | Direction | Message / Action | Comments |
|------|----------------------|---------------------------------------|---|
| 1 | $User \to ME$ | The user sets up a call to "321" | |
| 2 | $ME \rightarrow SIM$ | ENVELOPE CALL CONTROL 4.1.1A | [Option A shall apply for GSM parameters] |
| | | or ENVELOPE CALL CONTROL 4.1.1B | [Option B shall apply for PCS1900 parameters] |
| 3 | $SIM \to ME$ | 9F 02 | |
| 4 | $ME \to SIM$ | GET RESPONSE | |
| 5 | $SIM \to ME$ | CALL CONTROL RESULT 4.1.1 | [Call control result: "Not Allowed"] |
| 6 | $ME \to SS$ | The ME does not set up the call | |

ENVELOPE CALL CONTROL 4.1.1A

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Dialling number string "321" Capability configuration parameters 1

This parameter is optional. If present, the contents shall not be checked.

Subaddress

This parameter is optional. If present, the contents shall not be checked.

Location Information

MCC & MNC the mobile country and network code (00F110)

LAC the location Area Code (0001)
Cell ID Cell Identity Value (0001)

Capability configuration parameters 2

This parameter is optional. If present, the contents shall not be checked.

Coding:

| BER-TLV: | D4 | Note 1 | 82 | 02 | 82 | 81 | 86 | 03 | 81 | 23 | F1 | Note 2 |
|----------|--------|--------|----|----|----|----|----|----|----|----|--------|--------|
| | Note 3 | 13 | 07 | 00 | F1 | 10 | 00 | 01 | 00 | 01 | Note 4 | |

ENVELOPE CALL CONTROL 4.1.1B

Logically:

Device identities

Source device: ME

Destination device: SIM

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Dialling number string "321" Capability configuration parameters 1

This parameter is optional. If present, the contents shall not be checked.

Subaddress

This parameter is optional. If present, the contents shall not be checked.

Location Information

MCC & MNC the mobile country and network code (001110)

LAC the location Area Code (0001)
Cell ID Cell Identity Value (0001)

Capability configuration parameters 2

This parameter is optional. If present, the contents shall not be checked.

Coding:

| BER-TLV: | D4 | Note 1 | 82 | 02 | 82 | 81 | 86 | 03 | 81 | 23 | F1 | Note 2 |
|----------|--------|--------|----|----|----|----|----|----|----|----|--------|--------|
| - | Note 3 | 13 | 07 | 00 | 11 | 10 | 00 | 01 | 00 | 01 | Note 4 | |

Note 1: Length of BER-TLV is '12' plus the actual length of all the present optional SIMPLE-TLV data objects.

Note 2: Capability configuration parameters 1 may be present at this place. If present, it may take up several octets.

Note 3: Subaddress may be present at this place. If present, it may take up several octets.

Note 4: Capability configuration parameters 2 may be present at this place. If present, it may take up several octets.

CALL CONTROL RESULT 4.1.1

Logically:

Call control result Not Allowed

Coding:

BER-TLV: 01 00

Expected Sequence 4.2 (CALL CONTROL BY SIM , set up a call not in $\mathsf{EF}_{\mathsf{BDN}}$, Allowed without modifications)

| Step | Direction | Message / Action | Comments |
|------|---------------|--|--|
| 1 | $User \to ME$ | The user sets up a call to "1234" | |
| 2 | $ME \to SIM$ | ENVELOPE CALL CONTROL 4.2.1A | [Option A shall apply for GSM parameters] |
| | | or ENVELOPE CALL CONTROL 4.2.1B | [Option B shall apply for PCS1900 parameters] |
| 3 | $SIM \to ME$ | 9F 02 | |
| 4 | $ME \to SIM$ | GET RESPONSE | |
| 5 | $SIM \to ME$ | CALL CONTROL RESULT 4.2.1 | [Call control result: "Allowed without modifications"] |
| 6 | $ME \to SS$ | The ME sets up the call without modification | [Set up call to "1234"] |

ENVELOPE CALL CONTROL 4.2.1A

Logically:

Device identities

Source device: ME Destination device: SIM

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Dialling number string "1234" Capability configuration parameters 1

This parameter is optional. If present, the contents shall not be checked.

Subaddress

This parameter is optional. If present, the contents shall not be checked.

Location Information

MCC & MNC the mobile country and network code (00F110)

LAC the location Area Code (0001)
Cell ID Cell Identity Value (0001)

Capability configuration parameters 2

This parameter is optional. If present, the contents shall not be checked.

Coding:

| BER-TLV: | D4 | Note 1 | 82 | 02 | 82 | 81 | 86 | 03 | 81 | 21 | 43 | Note 2 |
|----------|--------|--------|----|----|----|----|----|----|----|----|--------|--------|
| - | Note 3 | 13 | 07 | 00 | F1 | 10 | 00 | 01 | 00 | 01 | Note 4 | |

ENVELOPE CALL CONTROL 4.2.1B

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Dialling number string "1234" Capability configuration parameters 1

This parameter is optional. If present, the contents shall not be checked.

Subaddress

This parameter is optional. If present, the contents shall not be checked.

Location Information

MCC & MNC the mobile country and network code (001110)

LAC the location Area Code (0001)
Cell ID Cell Identity Value (0001)

Capability configuration parameters 2

This parameter is optional. If present, the contents shall not be checked.

Coding:

| BER-TLV: | D4 | Note 1 | 82 | 02 | 82 | 81 | 86 | 03 | 81 | 21 | 43 | Note 2 |
|----------|--------|--------|----|----|----|----|----|----|----|----|--------|--------|
| | Note 3 | 13 | 07 | 00 | 11 | 10 | 00 | 01 | 00 | 01 | Note 4 | |

Note 1: Length of BER-TLV is '12' plus the actual length of all the present optional SIMPLE-TLV data objects.

Note 2: Capability configuration parameters 1 may be present at this place. If present, it may take up several octets.

Note 3: Subaddress may be present at this place. If present, it may take up several octets.

Note 4: Capability configuration parameters 2 may be present at this place. If present, it may take up several octets.

CALL CONTROL RESULT 4.2.1

Logically:

Call control result Allowed, no modifications

Coding:

BER-TLV: 00 00

Expected Sequence 4.3 (CALL CONTROL BY SIM , set up a call not in $\mathsf{EF}_{\mathsf{BDN}}$, Allowed with modifications)

| Step | Direction | Message / Action | Comments |
|------|----------------------|---|---|
| 1 | $User \to ME$ | The user sets up a call to "1111" | |
| 2 | $ME \rightarrow SIM$ | ENVELOPE CALL CONTROL 4.3.1A | [Option A shall apply for GSM parameters] |
| | | or ENVELOPE CALL CONTROL 4.3.1B | [Option B shall apply for PCS1900 parameters] |
| 3 | $SIM \to ME$ | 9F 07 | |
| 4 | $ME \to SIM$ | GET RESPONSE | |
| 5 | $SIM \to ME$ | CALL CONTROL RESULT 4.3.1 | [Call control result: "Allowed with modifications"] |
| 6 | $ME \to SS$ | The ME sets up the call with data sent by the SIM | [Set up call to "2222"] |

ENVELOPE CALL CONTROL 4.3.1A

Logically:

Device identities

Source device: ME Destination device: SIM

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Dialling number string "1111" Capability configuration parameters 1

This parameter is optional. If present, the contents shall not be checked.

Subaddress

This parameter is optional. If present, the contents shall not be checked.

Location Information

MCC & MNC the mobile country and network code (00F110)

LAC the location Area Code (0001)
Cell ID Cell Identity Value (0001)

Capability configuration parameters 2

This parameter is optional. If present, the contents shall not be checked.

Coding:

| BER-TLV: | D4 | Note 1 | 82 | 02 | 82 | 81 | 86 | 03 | 81 | 11 | 11 | Note 2 |
|----------|--------|--------|----|----|----|----|----|----|----|----|--------|--------|
| | Note 3 | 13 | 07 | 00 | F1 | 10 | 00 | 01 | 00 | 01 | Note 4 | |

ENVELOPE CALL CONTROL 4.3.1B

Logically:

Device identities

Source device: ME Destination device: SIM Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Dialling number string "1111" Capability configuration parameters 1

This parameter is optional. If present, the contents shall not be checked.

Subaddress

This parameter is optional. If present, the contents shall not be checked.

Location Information

MCC & MNC the mobile country and network code (001110)

LAC the location Area Code (0001)
Cell ID Cell Identity Value (0001)

Capability configuration parameters 2

This parameter is optional. If present, the contents shall not be checked.

Coding:

| BER-TLV: | D4 | Note 1 | 82 | 02 | 82 | 81 | 86 | 03 | 81 | 11 | 11 | Note 2 |
|----------|--------|--------|----|----|----|----|----|----|----|----|--------|--------|
| | Note 3 | 13 | 07 | 00 | 11 | 10 | 00 | 01 | 00 | 01 | Note 4 | |

Note 1: Length of BER-TLV is '12' plus the actual length of all the present optional SIMPLE-TLV data objects.

Note 2: Capability configuration parameters 1 may be present at this place. If present, it may take up several octets.

Note 3: Subaddress may be present at this place. If present, it may take up several octets.

Note 4: Capability configuration parameters 2 may be present at this place. If present, it may take up several octets.

CALL CONTROL RESULT 4.3.1

Logically:

Call control result Allowed with modifications

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Address value "2222"

Coding:

| BER-TLV: | 02 | 05 | 86 | 03 | 81 | 22 | 22 |
|----------|----|----|----|----|----|----|----|
|----------|----|----|----|----|----|----|----|

Expected Sequence 4.4 (CALL CONTROL BY SIM , FDN and BDN enabled, set up a call in EF_{FDN} , Allowed with modifications)

| Step | Direction | Message / Action | Comments |
|------|----------------------|---|--|
| 1 | $User \to ME$ | The user sets up a call to "123" | |
| 2 | $ME \rightarrow SIM$ | ENVELOPE CALL CONTROL 4.4.1A Or | [Option A shall apply for GSM parameters] |
| | | ENVELOPE CALL CONTROL 4.4.1B | [Option B shall apply for PCS1900 parameters] |
| 3 | $SIM \to ME$ | 9F 0A | |
| 4 | $ME \to SIM$ | GET RESPONSE | |
| 5 | $SIM \rightarrow ME$ | CALL CONTROL RESULT 4.4.1 | [Call control result: "Allowed with modifications"] |
| 6 | $ME \rightarrow SS$ | The ME sets up the call with data sent by the SIM | [Set up call to "987654321"the ME does not re-check this modified number against the FDN list] |

ENVELOPE CALL CONTROL 4.4.1A

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Dialling number string "123"

Capability configuration parameters 1

This parameter is optional. If present, the contents shall not be checked.

Subaddress

This parameter is optional. If present, the contents shall not be checked.

Location Information

MCC & MNC the mobile country and network code (00F110)

LAC the location Area Code (0001)
Cell ID Cell Identity Value (0001)

Capability configuration parameters 2

This parameter is optional. If present, the contents shall not be checked.

Coding:

| BER-TLV: | D4 | Note 1 | 82 | 02 | 82 | 81 | 86 | 03 | 81 | 21 | F3 | Note 2 |
|----------|--------|--------|----|----|----|----|----|----|----|----|--------|--------|
| | Note 3 | 13 | 07 | 00 | F1 | 10 | 00 | 01 | 00 | 01 | Note 4 | |

ENVELOPE CALL CONTROL 4.4.1B

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Dialling number string "123" Capability configuration parameters 1

This parameter is optional. If present, the contents shall not be checked.

Subaddress

This parameter is optional. If present, the contents shall not be checked.

Location Information

MCC & MNC the mobile country and network code (001110)

LAC the location Area Code (0001) Cell ID Cell Identity Value (0001)

Capability configuration parameters 2

This parameter is optional. If present, the contents shall not be checked.

Coding:

| BER-TLV: | D4 | Note 1 | 82 | 02 | 82 | 81 | 86 | 03 | 81 | 21 | F3 | Note 2 |
|----------|--------|--------|----|----|----|----|----|----|----|----|--------|--------|
| | Note 3 | 13 | 07 | 00 | 11 | 10 | 00 | 01 | 00 | 01 | Note 4 | |

Note 1: Length of BER-TLV is '12' plus the actual length of all the present optional SIMPLE-TLV data objects.

Note 2: Capability configuration parameters 1 may be present at this place. If present, it may take up several octets.

Note 3: Subaddress may be present at this place. If present, it may take up several octets.

Note 4: Capability configuration parameters 2 may be present at this place. If present, it may take up several octets.

CALL CONTROL RESULT 4.4.1

Logically:

Call control result Allowed with modifications

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Address value "987654321"

Coding:

| BER-TLV: | 02 | 08 | 86 | 06 | 81 | 89 | 67 | 45 | 23 | F1 |
|----------|----|----|----|----|----|----|----|----|----|----|

27.22.6.4.5 Test requirement

The ME shall operate in the manner defined in expected sequences 4.1 to 4.4.

27.22.7 EVENT DOWNLOAD

27.22.7.1 MT Call Event

27.22.7.1.1 MT Call Event (normal)

27.22.7.1.1.1 Definition and applicability

See clause 3.2.2.

27.22.7.1.1.2 Conformance requirement

The ME shall support the EVENT: MT Call event as defined in:

• 3GPP TS 11.14 [15] clause 4.7, clause 5.2, clause 6.4.16, clause 6.8, clause 11, clause 11.1 and clause 12.25.

27.22.7.1.1.3 Test purpose

To verify that the ME informs the SIM that an Event: MT Call has occurred using the ENVELOPE (EVENT DOWNLOAD - MT Call) command.

27.22.7.1.1.4 Method of test

27.22.7.1.1.4.1 Initial conditions

The ME is connected to the SIM Simulator and the System Simulator.

The ME shall be powered on and perform the PROFILE DOWNLOAD procedure.

27.22.7.1.1.4.2 Procedure

Expected Sequence 1.1 (EVENT DOWNLOAD -MT Call event)

| Step | Direction | Message / Action | Comments |
|------|----------------------|----------------------------|------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SET UP EVENT LIST | |
| | | 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SET UP | |
| | | EVENT LIST 1.1.1 | |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP | |
| | | EVENT LIST 1.1.1 | |
| 5 | $SS \to ME$ | CALL SET UP without CLI | [MT Call Set Up Without CLI] |
| 6 | $ME \rightarrow SIM$ | ENVELOPE: EVENT DOWNLOAD | |
| | | - MT Call 1.1.1 | |
| 7 | $SS \to ME$ | CALL DISCONNECT | |
| 8 | $SS \to ME$ | CALL SET UP with CLI | [MT Call Set Up With CLI] |
| 9 | $ME \rightarrow SIM$ | ENVELOPE: EVENT DOWNLOAD | |
| | | - MT Call 1.1.2 | |
| 10 | $SS \to ME$ | CALL DISCONNECT | |

PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM
Destination device: ME

Event list

Event 1: MT call

Coding:

| BER-TLV: | D0 | 0C | 81 | 03 | 01 | 05 | 00 | 82 | 02 | 81 | 82 | 99 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| _ | 01 | 00 | | | | | | | | | | |

TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

| | Ī | BER-TLV: | 81 | 03 | 01 | 05 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|--|---|----------|----|----|----|----|----|----|----|----|----|----|----|----|
|--|---|----------|----|----|----|----|----|----|----|----|----|----|----|----|

EVENT DOWNLOAD - MT CALL 1.1.1

Logically:

Event list: MT call event

Device identities

Source device: Network
Destination device: SIM

Transaction identifier:

Ti value: 0 (bit 5-7) Ti flag: 0 (bit 8)

Coding:

| BER-TLV: | D6 | 0A | 19 | 01 | 00 | 82 | 02 | 83 | 81 | 1C | 01 | 00 |
|-----------|----|-----|----|----|----|----|----|----|-----|----|-----|----|
| DLIX ILV. | | 0/1 | 10 | 01 | 00 | 02 | 02 | 00 | 0 1 | 10 | 0 1 | 00 |

EVENT DOWNLOAD - MT CALL 1.1.2

Logically:

Event list: MT call event

Device identities

Source device: Network
Destination device: SIM

Transaction identifier:

Ti value: 0 (bit 5-7) Ti flag: 0 (bit 8)

Address:

TON Unknown

NPI "ISDN / telephone numbering plan"

Dialling number string "9876"

Coding:

| BER-TLV: | D6 | 0F | 19 | 01 | 00 | 82 | 02 | 83 | 81 | 1C | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| _ | 86 | 03 | 81 | 89 | 67 | | | | | | | |

27.22.7.1.1.5 Test requirement

The behaviour of the test is as defined in 'Expected Sequence 1.1'.

27.22.7.2 Call Connected Event

27.22.7.2.1 Call Connected Event (MT and MO call)

27.22.7.2.1.1 Definition and applicability

See clause 3.2.2.

27.22.7.2.1.2 Conformance requirement

The ME shall support the EVENT: Call Connected event as defined in:

• 3GPP TS 11.14 [15] clause 4.7, clause 5.2, clause 6.4.16, clause 6.8, clause 11, clause 11.2 and clause 12.25.

27.22.7.2.1.3 Test purpose

To verify that the ME informs the SIM that an Event: Call Connected has occurred using the ENVELOPE (EVENT DOWNLOAD -Call Connected) command.

27.22.7.2.1.4 Method of test

27.22.7.2.1.4.1 Initial conditions

The ME is connected to the SIM Simulator and the System Simulator.

The ME shall be powered on and perform the PROFILE DOWNLOAD procedure.

27.22.7.2.1.4.2 Procedure

Expected Sequence 1.1 (EVENT DOWNLOAD -CALL CONNECTED)

| Step | Direction | Message / Action | Comments |
|------|----------------------|---|--------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SET UP EVENT LIST | |
| | | 1.1.1 | |
| 2 | $ME \to SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1 | [EVENT: Call Connected active] |
| 4 | $ME \to SIM$ | TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1 | |
| 5 | $SS \to ME$ | SETUP | [MT Call] Ti = 0 |
| 6 | $USER \to$ | Accept Call Set Up | |
| | ME | | |
| 7 | $ME \rightarrow SS$ | CONNECT | |
| 8 | $ME \rightarrow SIM$ | ENVELOPE: EVENT DOWNLOAD - Call Connected 1.1.1 | |
| 9 | $SS \to ME$ | DISCONNECT | |
| 10 | $USER \to$ | Initiate Call to "123" | |
| | ME | | |
| 11 | $ME \to SS$ | SETUP | [MO Call] Ti = 0 |
| 12 | | CONNECT | |
| 13 | $ME \to SIM$ | ENVELOPE: EVENT DOWNLOAD | |
| | | - Call Connected 1.1.2 | |
| 14 | $USER \to$ | End Call | |
| | ME | | |
| 15 | $ME \rightarrow SS$ | DISCONNECT | |

PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM Destination device: ME

Event list

Event 1: Call Connected

Coding:

| BER-TLV: | D0 | 0C | 81 | 03 | 01 | 05 | 00 | 82 | 02 | 81 | 82 | 99 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| _ | 01 | 01 | | | | | | | | | | |

TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: 81 | 03 | 01 | 05 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|-------------|----|----|----|----|----|----|----|----|----|----|----|
|-------------|----|----|----|----|----|----|----|----|----|----|----|

EVENT DOWNLOAD - CALL CONNECTED 1.1.1

Logically:

Event list: Call connected

Device identities

Source device: ME
Destination device: SIM

Transaction identifier:

Ti value: 0 (bit 5-7) Ti flag: 1 (bit 8)

Coding:

| BER-TLV: D6 0A 19 01 01 82 02 82 81 1C 01 | 80 | |
|---|----|--|
|---|----|--|

EVENT DOWNLOAD - CALL CONNECTED 1.1.2

Logically:

Event list: Call connected

Device identities

Source device: Network
Destination device: SIM

Transaction identifier:

Ti value: 0 (bit 5-7) Ti flag: 1 (bit 8)

Coding:

| BER-TLV: D6 0A 19 01 01 82 02 83 81 1C 01 80 | BER-TLV: |
|--|----------|
|--|----------|

27.22.7.2.1.5 Test requirement

The behaviour of the test is as defined in 'Expected Sequence 1.1'.

27.22.7.2.2 Call Connected Event (ME supporting SET UP CALL)

27.22.7.2.2.1 Definition and applicability

See clause 3.2.2.

27.22.7.2.2.2 Conformance requirement

Additionally the ME shall support the SET UP CALL Proactive SIM Command as defined in:

• 3GPP TS 11.14 [15] clause 11.2.2, clause 6.4.13 and clause 6.6.12.

27.22.7.2.2.3 Test purpose

To verify that the ME informs the SIM that an Event: Call Connected has occurred using the ENVELOPE (EVENT DOWNLOAD -Call Connected) command.

27.22.7.2.2.4 Method of test

27.22.7.2.2.4.1 Initial conditions

The ME is connected to the SIM Simulator and the System Simulator.

The ME shall be powered on and perform the PROFILE DOWNLOAD procedure.

27.22.7.2.4.2 Procedure

Expected Sequence 2.1 (EVENT DOWNLOAD -CALL CONNECTED, ME supporting SET UP CALL)

| Step | Direction | Message / Action | Comments |
|------|----------------------|--|--------------------------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: SET UP EVENT LIST | |
| | | 2.1.1 | |
| 2 | $ME \rightarrow SIM$ | | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SET UP EVENT LIST 2.1.1 | [EVENT: Call Connected active] |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP EVENT LIST 2.1.1 | |
| 5 | $SIM \rightarrow ME$ | PROACTIVE COMMAND PENDING | |
| 6 | $ME \rightarrow SIM$ | FETCH | |
| 7 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SET UP CALL 2.1.1 | [SAT Call] |
| 8 | ME | ME displays "+012340123456" | ME BEHAVIOUR: SET UP CALL |
| | \rightarrow USER | during the user confirmation phase. | |
| 9 | $USER \to$ | Confirm call set up | |
| | ME | · | |
| 10 | $ME \rightarrow SS$ | SETUP | Ti=0 |
| 11 | $SS \to ME$ | CONNECT | |
| 12 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP CALL 2.1.1 | |
| 13 | $ME \to SIM$ | ENVELOPE: CALL CONNECTED 2.1.1 | |

PROACTIVE COMMAND: SET UP EVENT LIST 2.1.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM
Destination device: ME

Event list

Event 1: Call Connected

| BER-TLV: | D0 | 0C | 81 | 03 | 01 | 05 | 00 | 82 | 02 | 81 | 82 | 99 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | 01 | | | | | | | | | | |

TERMINAL RESPONSE: SET UP EVENT LIST 2.1.1

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 05 00 82 02 82 81 83 01 00

PROACTIVE COMMAND: SET UP CALL 2.1.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: Only if not currently busy on another call

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "+012340123456"

Address

TON: International

NPI: "ISDN / telephone numbering plan"

Dialling number string "012340123456"

Coding:

| BER-TLV: | D0 | 21 | 81 | 03 | 01 | 10 | 00 | 82 | 02 | 81 | 83 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 05 | 0D | 2B | 30 | 31 | 32 | 33 | 34 | 30 | 31 | 32 |
| | 33 | 34 | 35 | 36 | 86 | 07 | 91 | 10 | 32 | 04 | 21 |
| | 43 | 65 | | | | | | | | | |

TERMINAL RESPONSE: SET UP CALL 2.1.1

Logically:

Command details

Command number:

Command type: SET UP CALL

Command qualifier: Only if not currently busy on another call

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

| | 0.4 | 00 | 0.4 | 40 | 00 | 0.0 | 00 | 0.0 | 0.4 | 00 | 0.4 | |
|----------|------|----|------|------|----|-----|----|------|------|----|-----|----|
| BER-TLV: | I 81 | 03 | l 01 | I 10 | 00 | 82 | 02 | 1 82 | l 81 | 83 | 01 | 00 |

EVENT DOWNLOAD - CALL CONNECTED 2.1.1

Logically:

Event list: Call connected

Device identities

Source device: Network
Destination device: SIM

Transaction identifier:

Ti value: 0 (bit 5-7)
Ti flag: 1 (bit 8)

Coding:

| BER-TLV: | D6 | 0A | 19 | 01 | 01 | 82 | 02 | 83 | 81 | 1C. | 01 | 80 |
|-----------|----|----|----|-----|-----|----|----|----|----|-----|----|----|
| DLIX-ILV. | 00 | UA | 13 | O I | O I | 02 | 02 | 00 | 01 | 10 | 01 | 00 |

27.22.7.2.2.5 Test requirement

The behaviour of the test is as defined in 'Expected Sequence 1.1'.

27.22.7.3 Call Disconnected Event

27.22.7.3.1 Call Disconnected Event

27.22.7.3.1.1 Definition and applicability

See clause 3.2.2.

27.22.7.3.1.2 Conformance requirement

The ME shall support the EVENT: Call Disconnected event as defined in:

• 3GPP TS 11.14 [15] clause 4.7, clause 5.2, clause 6.4.16, clause 6.8, clause 11, clause 11.3 and clause 12.25.

27.22.7.3.1.3 Test purpose

To verify that the ME informs the SIM that an Event: Call Disconnected has occurred using the ENVELOPE (EVENT DOWNLOAD -Call Disconnected) command.

27.22.7.3.1.4 Method of test

27.22.7.3.1.4.1 Initial conditions

The ME is connected to the SIM Simulator and the System Simulator.

The ME shall be powered on and perform the PROFILE DOWNLOAD procedure.

27.22.7.3.1.4.2 Procedure

Expected Sequence 1.1 (EVENT DOWNLOAD -CALL DISCONNECTED)

| al call |
|---------|
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |

PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM
Destination device: ME

Event list

Event 1: Call Disconnected

Coding:

| BER-TLV: | D0 | 0C | 81 | 03 | 01 | 05 | 00 | 82 | 02 | 81 | 82 | 99 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | 02 | | | | | | | | | | |

TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 05 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
|----------|----|----|----|----|----|----|----|----|----|----|----|----|

EVENT DOWNLOAD - CALL DISCONNECTED 1.1.1

Logically:

Event list: Call Disconnected

Device identities

Source device: Network
Destination device: SIM

Transaction identifier:

Ti value: 0 (bit 5-7) Ti flag: 0 (bit 8)

Cause:

Coding:

| BER-TLV: | D6 | 0A | 19 | 01 | 02 | 82 | 02 | 83 | 81 | 1C | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
|----------|----|----|----|----|----|----|----|----|----|----|----|----|

EVENT DOWNLOAD - CALL DISCONNECTED 1.1.2A

Logically:

Event list: Call Disconnected

Device identities

Source device: ME Destination device: SIM

Transaction identifier:

Ti value: 0 (bit 5-7) Ti flag: 1 (bit 8)

| BER-TLV: D6 0A 19 01 | 02 82 | 02 82 | 81 1C | 01 80 | ٦ |
|----------------------|-------|-------|-------|-------|---|
|----------------------|-------|-------|-------|-------|---|

EVENT DOWNLOAD - CALL DISCONNECTED 1.1.2B

Logically:

Event list: Call Disconnected

Device identities

Source device: ME Destination device: SIM

Transaction identifier:

Ti value: 0 (bit 5-7)
Ti flag: 1 (bit 8)

Cause: normal call clearing

Coding:

| BER-TLV: | D6 | 0E | 19 | 01 | 02 | 82 | 02 | 82 | 81 | 1C | 01 | 80 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 9A | 02 | 60 | 90 | | | | | | | | |

EVENT DOWNLOAD - CALL DISCONNECTED 1.1.2C

Logically:

Event list: Call Disconnected

Device identities

Source device: ME
Destination device: SIM

Transaction identifier:

Ti value: 0 (bit 5-7) Ti flag: 1 (bit 8)

Cause: normal call clearing

Coding:

| BER-TLV: | D6 | 0E | 19 | 01 | 02 | 82 | 02 | 82 | 81 | 1C | 01 | 80 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 9A | 02 | E0 | 90 | | | | | | | | |

EVENT DOWNLOAD - CALL DISCONNECTED 1.1.3A

Logically:

Event list: Call Disconnected

Device identities

Source device: Network
Destination device: SIM

Transaction identifier:

Ti value: 0 (bit 5-7)
Ti flag: 0 (bit 8)

Cause: normal call clearing

Coding:

| BER-TLV: | D6 | 0E | 19 | 01 | 02 | 82 | 02 | 83 | 81 | 1C | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 9A | 02 | 60 | 90 | | | | | | | | |

EVENT DOWNLOAD - CALL DISCONNECTED 1.1.3B

Logically:

Event list: Call Disconnected

Device identities

Source device: Network

Destination device: SIM

Transaction identifier:

Ti value: 0 (bit 5-7) Ti flag: 0 (bit 8)

Cause: normal call clearing

Coding:

| BER-TLV: | D6 | 0E | 19 | 01 | 02 | 82 | 02 | 83 | 81 | 1C | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| _ | 9A | 02 | E0 | 90 | | | | | | | | |

EVENT DOWNLOAD - CALL DISCONNECTED 1.1.4A

Logically:

Event list: Call Disconnected

Device identities

Source device: ME Destination device: SIM

Transaction identifier:

Ti value: 0 (bit 5-7)
Ti flag: 1 (bit 8)
Cause: radio link failure

Coding:

| BER-TLV: | D6 | 0C | 19 | 01 | 02 | 82 | 02 | 82 | 81 | 1C | 01 | 80 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 9A | 00 | | | | | | | | | | |

EVENT DOWNLOAD - CALL DISCONNECTED 1.1.4B

Logically:

Event list: Call Disconnected

Device identities

Source device: ME Destination device: SIM

Transaction identifier:

Ti value: 0 (bit 5-7)
Ti flag: 0 (bit 8)

Cause: radio link failure

Coding:

| BER-TLV: | D6 | 0C | 19 | 01 | 02 | 82 | 02 | 82 | 81 | 1C | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 9A | 00 | | | | | | | | | | |

27.22.7.3.1.5 Test requirement

The behaviour of the test is as defined in 'Expected Sequence 1.1'.

27.22.7.4 Location Status Event

27.22.7.4.1 Location Status Event (normal)

27.22.7.4.1.1 Definition and applicability

See clause 3.2.2.

27.22.7.4.1.2 Conformance requirement

The ME shall support the EVENT: Location Status event as defined in:

• 3GPP TS 11.14 [15] clause 11.4 and clause 6.4.16.

27.22.7.4.1.3 Test purpose

To verify that the ME informs the SIM that an Event: MM_IDLE state has occurred using the ENVELOPE (EVENT DOWNLOAD - Location Status) command.

27.22.7.4.1.4 Method of test

27.22.7.4.1.4.1 Initial conditions

The ME is connected to the SIM Simulator and the System Simulator.

The ME shall be powered on and perform the PROFILE DOWNLOAD procedure.

The GSM parameters of the system simulator are:

- Mobile Country Code (MCC) = 001;
- Mobile Network Code (MNC) = 01;
- Location Area Code (LAC) = 0001;
- Cell Identity value = 0001;

The PCS 1900 parameters of the system simulator are:

- Mobile Country Code (MCC) = 001;
- Mobile Network Code (MNC) = 011;
- Location Area Code (LAC) = 0001;
- Cell Identity value = 0001.

Two cells are defined. Cell 1 has location area code 1 and cell 2 has location area code 2.

MS is in service on Cell 1.

27.22.7.4.1.4.2 Procedure

Expected Sequence 1.1(EVENT DOWNLOAD -LOCATION STATUS)

| Step | Direction | Message / Action | Comments |
|------|---|--|---|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: SET UP EVENT LIST | |
| | 145 0114 | 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | | |
| 3 | SIM → ME | PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1 | |
| 4 | ME CIM | TERMINAL RESPONSE: SET UP | |
| - | IVIE -> SIIVI | EVENT LIST 1.1.1 | |
| 5 | SS | Cell 1 is switched off | |
| | | | |
| 6 | $ME \rightarrow SIM$ | ENVELOPE: EVENT DOWNLOAD | |
| | | - Location Status 1.1.1 | |
| 7 | SS | Cell 2 is switched on after Location | |
| | | Status 'No service' has been | |
| 8 | ME | received in step 6 | |
| 0 | IVIE | ME performs cell reselection to cell | |
| 9 | $ME \rightarrow SS$ | Location Updating Request | |
| 10 | SS → ME | Location updating accept | |
| 11 | $ME \rightarrow SIM$ | | [Option A shall apply for GSM parameters] |
| | , | - Location Status 1.1.2A | [|
| | | or | |
| | | ENVELOPE: EVENT DOWNLOAD | [Option B shall apply for PCS1900 |
| | | - Location Status 1.1.2B | parameters] |
| | | | NOTE TO 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 |
| | | | [NOTE: The inclusion of the location |
| | | | information is optional: (If location status indicates normal status) |
| | | | indicates notifial status) |
| | | | |

PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00

Device identities

Source device: SIM Destination device: ME

Event list

Event 1: Location status

Coding:

| BER-TLV: | D0 | 0C | 81 | 03 | 01 | 05 | 00 | 82 | 02 | 81 | 82 | 99 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | 03 | | | | | | | | | | |

TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

574

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 05 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|

EVENT DOWNLOAD - LOCATION STATUS 1.1.1

Logically:

Event list: Location status

Device identities

Source device: ME
Destination device: SIM
Location status: No service

Coding:

EVENT DOWNLOAD - LOCATION STATUS 1.1.2A

Logically:

Event list: Location status

Device identities

Source device: ME Destination device: SIM

Location status: normal service

Location Information

MCC & MNC the mobile country and network code (00F110)

LAC the location Area Code (0002)
Cell ID Cell Identity Value (0002)

Coding:

| BER-TLV: | D6 | 13 | 19 | 01 | 03 | 82 | 02 | 82 | 81 | 1B | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 13 | 07 | 00 | F1 | 10 | 00 | 02 | 00 | 02 | | | |

EVENT DOWNLOAD - LOCATION STATUS 1.1.2B

Logically:

Event list: Location status

Device identities

Source device: ME Destination device: SIM

Location status: normal service

Location Information

MCC & MNC the mobile country and network code (001110)

LAC the location Area Code (0002) Cell ID Cell Identity Value (0002)

| BER-TLV: | D6 | 13 | 19 | 01 | 03 | 82 | 02 | 82 | 81 | 1B | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 13 | 07 | 00 | 11 | 10 | 00 | 02 | 00 | 02 | | | |

27.22.7.4.1.5 Test requirement

The behaviour of the test is as defined in 'Expected Sequence 1.1'.

27.22.7.5 User Activity Event

27.22.7.5.1 User Activity Event (normal)

27.22.7.5.1.1 Definition and applicability

See clause 3.2.2.

27.22.7.5.1.2 Conformance Requirement

The ME shall support the EVENT DOWNLOAD -USER ACTIVITY as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.16, clause 6.8, clause 6.6.16, clause 6.11, clause 11, clause 11.5, clause 12.6 and clause 12.25.

27.22.7.5.1.3 Test purpose

To verify that the ME performed correctly the procedure of USER ACTIVITY EVENT.

27.22.7.5.1.4 Method of Test

27.22.7.5.1.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

27.22.7.5.1.4.2 Procedure

Expected Sequence 1.1 (EVENT DOWNLOAD -USER ACTIVITY)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|----------------------------|--|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | [set up event list: event User Activity] |
| | | PENDING: SET UP EVENT LIST | · |
| | | 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SET | [set up event list: event User Activity] |
| | | UP EVENT LIST 1.1.1 | |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET | [command performed successfully] |
| | | UP EVENT LIST 1.1.1 | |
| 5 | | press any key | |
| 6 | $ME \rightarrow SIM$ | ENVELOPE EVENT | |
| | | DOWNLOAD -USER ACTIVITY | |
| | | 1.1.1 | |
| 7 | $USER \to ME$ | press any key | check if no envelope Event Download-User |
| | | | activity sending to the SIM (this event is |
| | | | reported once) |

PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: ME

Event list User Activity

Coding:

| BER-TLV: | D0 | 0C | 81 | 03 | 01 | 05 | 00 | 82 | 02 | 81 | 82 | 99 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| · | 01 | 04 | | | | | | | | | | |

TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: RFU

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 05 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|

EVENT DOWNLOAD -USER ACTIVITY 1.1.1

Logically:

Event list User Activity

Device identities

Source device: ME Destination device: SIM

Coding:

| | 82 81 | |
|--|---------|--|
|--|---------|--|

27.22.7.5.1.5 Test requirement

The ME shall operate in the manner defined in expected sequence 1.1.

27.22.7.6 Idle screen available event

27.22.7.6.1 Idle Screen Available (normal)

27.22.7.6.1.1 Definition and applicability

See clause 3.2.2.

27.22.7.6.1.2 Conformance requirement

The ME shall support the EVENT: IDLE SCREEN AVAILABLE event as defined in:

• 3GPP TS 11.14 [15] clause 4.7, clause 5.2, clause 6.4.16, clause 6.8, clause 11, clause 11.1 and clause 12.25.

27.22.7.6.1.3 Test purpose

To verify that the ME informs the SIM that an Event: Idle Screen Available has occurred using the ENVELOPE (EVENT DOWNLOAD - IDLE SCREEN AVAILABLE) command.

27.22.7.6.1.4 Method of test

27.22.7.6.1.4.1 Initial conditions

The ME is connected to the SIM Simulator and the System Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure and be in updated idle mode on the System Simulator.

27.22.7.6.1.4.2 Procedure

Expected Sequence 1.1 (EVENT DOWNLOAD - IDLE SCREEN AVAILABLE)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|--|--|
| 1 | $USER \to ME$ | Select screen other than the ME | |
| 2 | $SIM \to ME$ | idle screen PROACTIVE COMMAND PENDING: SET UP EVENT LIST | [set up event list: idle screen available] |
| | | 1.1.1 | |
| 3 | / | FETCH | |
| 4 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SET UP | [set up event list: idle screen available] |
| | | EVENT LIST 1.1.1 | |
| 5 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP | [command performed successfully] |
| | | EVENT LIST 1.1.1 | |
| 6 | $USER \to ME$ | Select ME idle screen | |
| 7 | $ME \to SIM$ | ENVELOPE: IDLE SCREEN | |
| | | AVAILABLE 1.1.1 | |
| 8 | $USER \to ME$ | Select screen other than the ME | |
| | | idle screen | |
| 9 | $USER \to ME$ | Select ME idle screen | |
| 10 | $ME \to SIM$ | ENVELOPE: IDLE SCREEN | |
| | | AVAILABLE shall not be sent to | |
| | | the SIM | |

PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM
Destination device: ME

Event list

Event 1: idle screen available

Coding:

| BER-TLV: | D0 | 0C | 81 | 03 | 01 | 05 | 00 | 82 | 02 | 81 | 82 | 99 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| · | 01 | 05 | | | | | | | | | | |

TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 05 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|

EVENT DOWNLOAD - IDLE SCREEN AVAILABLE 1.1.1

Logically:

Event list Idle screen available

Device identities

Source device: Display
Destination device: SIM

Coding:

| BER-TLV: D6 07 | 19 01 | 05 82 0 | 02 02 81 |
|--------------------|-------|-------------|--------------|
|--------------------|-------|-------------|--------------|

27.22.7.6.1.5 Test requirement

The ME shall operate in the manner defined in expected sequence 1.1.

27.22.7.7 Card reader status event

27.22.7.7.1 Card Reader Status (normal)

27.22.7.7.1.1 Definition and applicability

See clause 3.2.2.

27.22.7.7.1.2 Conformance requirement

The ME shall support the EVENT: Call Card Reader Status event as defined in:

• 3GPP TS 11.14 [15] clause 4.7, clause 4.9, clause 5.2, clause 6.4.16, clause 6.8, clause 11, clause 11.7, clause 12.25, clause 12.33, annex G, annex H, clause 12.25 and clause 12.7.

27.22.7.7.1.3 Test purpose

To verify that the ME informs the SIM that an Event: Card Reader Status has changed using the ENVELOPE (EVENT DOWNLOAD - Card Reader Status) command.

The ME-Manufacturer can assign the card reader identifier from 0 to 7.

This test applies for MEs with only one additional card reader.

In this particular case the card reader identifier 1 is chosen.

27.22.7.7.1.4 Method of test

27.22.7.7.1.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The ME shall be powered on and perform the PROFILE DOWNLOAD procedure.

27.22.7.7.1.4.2 Procedure

Expected Sequence 1.1 (EVENT DOWNLOAD, Card reader status, Card reader 1, card reader attached, no card inserted)

| Step | Direction | Message / Action | Comments |
|--------|-----------------------|---|----------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | |
| | | PENDING: SET UP EVENT LIST | |
| _ | | 1.1.1 | |
| 2 | $ME \to SIM$ | | |
| 3 | | PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1 | - |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1 | [Successfully] |
| 5 | User \rightarrow ME | Insert a card in Reader | |
| 6 | $ME \rightarrow SIM$ | ENVELOPE: CARD READER STATUS 1.1.1a | |
| 7 8 | | or ENVELOPE: CARD READER STATUS 1.1.1b Or ENVELOPE: CARD READER STATUS 1.1.1c Or ENVELOPE: CARD READER STATUS 1.1.1d Remove the card from Reader ENVELOPE: CARD READER STATUS 1.1.2a Or ENVELOPE: CARD READER STATUS 1.1.2b Or ENVELOPE: CARD READER STATUS 1.1.2c Or ENVELOPE: CARD READER STATUS 1.1.2c Or ENVELOPE: CARD READER STATUS 1.1.2c Or ENVELOPE: CARD READER STATUS 1.1.2d | |

PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM
Destination device: ME

Event list

Event 1: Card Reader Status

Coding:

| BER-TLV: | D0 | 0C | 81 | 03 | 01 | 05 | 00 | 82 | 02 | 81 | 82 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 99 | 01 | 06 | | | | | | | | |

TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 05 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
|----------|----|----|----|----|----|----|----|----|----|----|----|----|

ENVELOPE: EVENT DOWNLOAD CARD READER STATUS 1.1.1a

Logically:

Event list

Event 1: Card Reader Status

Device identities

Source device: ME Destination device: SIM

Card reader status

Identity of card reader: 01
Card reader removable: Yes
Card reader present: Yes
Card reader ID-1 size: Yes
Card present in reader: Yes
Card powered: No

Coding:

| BER-TLV: | D6 | 0A | 99 | 01 | 06 | 82 | 02 | 82 | 81 | A0 | 01 | 79 | ı |
|----------|------|------|------|----|------|----|----|----|----|------|----|----|---|
| | ו טט | 1 0/ | 1 33 | | 1 00 | 02 | 02 | 02 | | 1 70 | | 13 | |

ENVELOPE: EVENT DOWNLOAD CARD READER STATUS 1.1.1b

Logically:

Event list

Event 1: Card Reader Status

Device identities

Source device: ME Destination device: SIM

Card reader status

Identity of card reader: 01 Card reader removable: Yes Card reader present: Yes Card reader ID-1 size: No Card present in reader: Yes Card powered: No

Coding:

| BER-TLV: | D6 | 0A | 99 | 01 | 06 | 82 | 02 | 82 | 81 | A0 | 01 | 59 | l |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|---|
|----------|----|----|----|----|----|----|----|----|----|----|----|----|---|

ENVELOPE: EVENT DOWNLOAD CARD READER STATUS 1.1.1c

Logically:

Event list

Event 1: Card Reader Status

Device identities

Source device: ME
Destination device: SIM

Card reader status

Identity of card reader: 01
Card reader removable: No
Card reader present: Yes
Card reader ID-1 size: Yes
Card present in reader: Yes
Card powered: No

Coding:

| | Ī | BER-TLV: | D6 | 0A | 99 | 01 | 06 | 82 | 02 | 82 | 81 | A0 | 01 | 71 | |
|--|---|----------|----|----|----|----|----|----|----|----|----|----|----|----|--|
|--|---|----------|----|----|----|----|----|----|----|----|----|----|----|----|--|

ENVELOPE: EVENT DOWNLOAD CARD READER STATUS 1.1.1d

Logically:

Event list

Event 1: Card Reader Status

Device identities

Source device: ME Destination device: SIM

Card reader status

Identity of card reader: 01
Card reader removable: No
Card reader present: Yes
Card reader ID-1 size: No
Card present in reader: Yes
Card powered: No

Coding:

| BER-TLV: D6 0A | 99 01 | 06 82 | 02 82 | 81 | A0 | 01 | 51 | |
|----------------|-------|-------|-------|----|----|----|----|--|
|----------------|-------|-------|-------|----|----|----|----|--|

ENVELOPE: EVENT DOWNLOAD CARD READER STATUS 1.1.2a

Logically:

Event list

Event 1: Card Reader Status

Device identities

Source device: ME
Destination device: SIM

Card reader status

Identity of card reader: 01

Card reader removable: Yes
Card reader present: Yes
Card reader ID-1 size: Yes
Card present in reader: No
Card powered: No

Coding:

BER-TLV: D6 0A 99 01 06 82 02 82 81 A0 01 39

ENVELOPE: EVENT DOWNLOAD CARD READER STATUS 1.1.2b

Logically:

Event list

Event 1: Card Reader Status

Device identities

Source device: ME
Destination device: SIM

Card reader status

Identity of card reader: 01
Card reader removable: Yes
Card reader present: Yes
Card reader ID-1 size: No
Card present in reader: No
Card powered: No

Coding:

BER-TLV: D6 0A 99 01 06 82 02 82 81 A0 01 19

ENVELOPE: EVENT DOWNLOAD CARD READER STATUS 1.1.2c

Logically:

Event list

Event 1: Card Reader Status

Device identities

Source device: ME Destination device: SIM

Card reader status

Identity of card reader: 01
Card reader removable: No
Card reader present: Yes
Card reader ID-1 size: Yes
Card present in reader: No
Card powered: No

Coding:

BER-TLV: D6 0A 99 01 06 82 02 82 81 A0 01 31

ENVELOPE: EVENT DOWNLOAD CARD READER STATUS 1.1.2d

Logically:

Event list

Event 1: Card Reader Status

Device identities

Source device: ME

Destination device: SIM

Card reader status

Identity of card reader: 01
Card reader removable: No
Card reader present: Yes
Card reader ID-1 size: No
Card present in reader: No
Card powered: No

Coding:

27.22.7.7.1.5 Test requirement

The behaviour of the test is as defined in 'Expected Sequence 1.1'.

27.22.7.7.2 Card Reader Status(detachable card reader)

27.22.7.7.2.1 Definition and applicability

See clause 3.2.2.

27.22.7.7.2.2 Conformance requirement

The ME shall support the EVENT: Call Card Reader Status event as defined in:

• 3GPP TS 11.14 [15] clause 4.7, clause 4.9, clause 5.2, clause 6.4.16, clause 6.8, clause 11, clause 11.7, clause 12.25, clause 12.33, annex G, annex H, clause 12.25 and clause 12.7.

27.22.7.7.2.3 Test purpose

To verify that the ME informs the SIM that an Event: Card Reader Status has changed using the ENVELOPE (EVENT DOWNLOAD - Card Reader Status) command.

The ME-Manufacturer can assign the card reader identifier from 0 to 7.

This test applies for MEs with only one additional card reader.

In this particular case the card reader identifier 1 is chosen as an example.

27.22.7.7.2.4 Method of test

27.22.7.7.2.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The ME shall be powered on and perform the PROFILE DOWNLOAD procedure.

27.22.7.7.2.4.2 Procedure

Expected Sequence 2.1 (EVENT DOWNLOAD, Detachable reader, Card reader 1, detachable card reader not attached, no card inserted)

| Step | Direction | Message / Action | Comments |
|------|-----------------------|--------------------------------|------------------------------------|
| 1 | $SIM \rightarrow ME$ | PROACTIVE COMMAND | |
| | | PENDING: SET UP EVENT LIST | |
| | | 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | | [SET UP EVENT: Card Reader Status] |
| | | EVENT LIST 1.1.1 | |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP | [Successfully] |
| | | EVENT LIST 1.1.1 | |
| 5 | User \rightarrow ME | Attach the Card Reader to ME | |
| 6 | $ME \rightarrow SIM$ | ENVELOPE: CARD READER | |
| | | STATUS 2.1.1a | |
| | | Or | |
| | | ENVELOPE: CARD READER | |
| | | STATUS 2.1.1b | |
| 7 | | Detach the Card Reader from ME | |
| 8 | $ME \rightarrow SIM$ | ENVELOPE: CARD READER | |
| | | STATUS 2.1.2a | |
| | | Or | |
| | | ENVELOPE: CARD READER | |
| | | STATUS 2.1.2b | |

ENVELOPE: EVENT DOWNLOAD CARD READER STATUS 2.1.1a

Logically:

Event list

Event 1: Card Reader Status

Device identities

Source device: ME
Destination device: SIM

Card reader status

Identity of card reader: 01
Card reader removable: Yes
Card reader present: Yes
Card reader ID-1 size: Yes
Card present in reader: No
Card powered: No

Coding:

| BER-TLV: | D6 | 0A | 99 | 01 | 06 | 82 | 02 | 82 | 81 | A0 | 01 | 39 | |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|--|
|----------|----|----|----|----|----|----|----|----|----|----|----|----|--|

ENVELOPE: EVENT DOWNLOAD CARD READER STATUS 2.1.1b

Logically:

Event list

Event 1: Card Reader Status

Device identities

Source device: ME Destination device: SIM

Card reader status

Identity of card reader: 01 Card reader removable: Yes Card reader present: Yes Card reader ID-1 size: No Card present in reader: No Card powered: No

Coding:

BER-TLV: D6 0A 99 01 06 82 02 82 81 A0 01 19

ENVELOPE: EVENT DOWNLOAD CARD READER STATUS 2.1.2a

Logically:

Event list

Event 1: Card Reader Status

Device identities

Source device: ME Destination device: SIM

Card reader status

Identity of card reader: 01
Card reader removable: Yes
Card reader present: No
Card reader ID-1 size: Yes
Card present in reader: No
Card powered: No

Coding:

BER-TLV: D6 0A 99 01 06 82 02 82 81 A0 01 29

ENVELOPE: EVENT DOWNLOAD CARD READER STATUS 2.1.2b

Logically:

Event list

Event 1: Card Reader Status

Device identities

Source device: ME Destination device: SIM

Card reader status

Identity of card reader: 01
Card reader removable: Yes
Card reader present: No
Card reader ID-1 size: No
Card present in reader: No
Card powered: No

Coding:

BER-TLV: D6 0A 99 01 06 82 02 82 81 A0 01 09

27.22.7.7.1.5 Test requirement

The behaviour of the test is as defined in 'Expected Sequence 2.1'.

27.22.7.8 Language selection event

27.22.7.8.1 Language selection event (normal)

27.22.7.8.1.1 Definition and applicability

See clause 3.2.2.

27.22.7.8.1.2 Conformance requirement

The ME shall support the EVENT: LANGUAGE SELECTION event as defined in:

• 3GPP TS 11.14 [15] clause 4.7, clause 5.2, clause 6.4.16, clause 6.8, clause 11, clause 11.8 and clause 12.25.

27.22.7.8.1.3 Test purpose

To verify that the ME informs the SIM that an Event: Language selection has occurred using the ENVELOPE (EVENT DOWNLOAD - LANGUAGE SELECTION) command.

27.22.7.8.1.4 Method of test

27.22.7.8.1.4.1 Initial conditions

The ME is connected to the SIM Simulator and the System Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The current language shall have been set to English. Another language has to be supported, German is an example.

27.22.7.8.1.4.2 Procedure

Expected Sequence 1.1 (EVENT DOWNLOAD - LANGUAGE SELECTION)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|--------------------------------|---|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND | [set up event list: language selection] |
| | | PENDING: SET UP EVENT LIST | |
| | | 1.1.1 | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SET UP | [set up event list: language selection] |
| | | EVENT LIST 1.1.1 | |
| 4 | $ME \to SIM$ | TERMINAL RESPONSE: SET UP | [command performed successfully] |
| | | EVENT LIST 1.1.1 | |
| 5 | $USER \to ME$ | Change the language to German. | |
| 6 | $ME \to SIM$ | ENVELOPE: LANGUAGE | |
| | | SELECTION 1.1.1 | |

PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM
Destination device: ME

Event list

Event 1: language selection

Coding:

| BER-TLV: | D0 | 0C | 81 | 03 | 01 | 05 | 00 | 82 | 02 | 81 | 82 | 99 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 01 | 07 | | | | | | | | | | |

TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 01 | 03 | Λ1 | 05 | 00 | 82 | 02 | 82 | 01 | 02 | Λ1 | 00 |
|-----------|------|------|----|----|------|----|----|----|-------|----|------|------|
| IDEK-ILV. | 1 01 | 1 03 | UI | US | 1 00 | 02 | | 02 | 1 O I | ೦೦ | l UI | i UU |
| | | | | | | _ | - | _ | | | | |

EVENT DOWNLOAD - LANGUAGE SELECTION 1.1.1

Logically:

Event list Language selection

Device identities

Source device: ME Destination device: SIM

Language

Language 'de'→64 65 (German)

Coding:

| BER-TLV: | D6 | 0B | 19 | 01 | 07 | 82 | 02 | 82 | 81 | 2D | 02 | 64 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| · | 65 | | | | | | | | | | | |

27.22.7.8.1.5 Test requirement

The ME shall operate in the manner defined in expected sequence 1.1.

27.22.7.9 Browser termination event

27.22.7.9.1 Browser termination (normal)

27.22.7.9.1.1 Definition and applicability

This test is only applicable to ME's that support the EVENT: browser termination event driven information.

27.22.7.9.1.2 Conformance requirement

The ME shall support the EVENT: Browser termination event as defined in:

• 3GPP TS 11.14 [15] clause 4.7, clause 5.2, clause 6.4.16, clause 6.8, clause 11, clause 11.9, clause 12.25, clause 12.51, annex G and clause 12.7.

27.22.7.9.1.3 Test purpose

To verify that the ME informs the SIM of an Event: Browser termination using the ENVELOPE (EVENT DOWNLOAD - Browser Termination) command.

This test applies for MEs which have a browser.

27.22.7.9.1.4 Method of test

27.22.7.9.1.4.1 Initial conditions

The ME is connected to the SIM Simulator and the System Simulator.

The ME shall be powered on and perform the PROFILE DOWNLOAD procedure.

A valid access to a Wap gateway is required. The default browser parameters (IP address, gateway/proxy identity, called number...) of the tested mobile shall be properly filled to access that gateway.

27.22.7.9.1.4.2 Procedure

Expected Sequence 1.1 (EVENT DOWNLOAD - Browser termination)

| Step | Direction | Message / Action | Comments |
|------|----------------------|-----------------------------------|-------------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND: SET UP | |
| | | EVENT LIST 1.1.1 PENDING | |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: SET UP | [EVENT: Browser termination Status] |
| | | EVENT LIST 1.1.1 | |
| 4 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SET UP | [Successfully] |
| | | EVENT LIST 1.1.1 | |
| 5 | User→ME | Launch the browser with URL | |
| | | selected by the user. | |
| 6 | $ME \rightarrow SS$ | The ME attempts to launch the | |
| | | session with the default browser | |
| | | parameters and the URL selected | |
| | | by the user. | |
| 7 | | Stop the session and the browser. | |
| 8 | $ME \rightarrow SIM$ | ENVELOPE: BROWSER | |
| | | TERMINATION 1.1.1 | |

PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM Destination device: ME

Event list

Event 1: Browser termination

Coding:

| BER-TLV: | D0 | 0C | 81 | 03 | 01 | 05 | 00 | 82 | 02 | 81 | 82 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 99 | 01 | 80 | | | | | | | | |

TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 05 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|

ENVELOPE: EVENT DOWNLOAD BROWSER TERMINATION 1.1.1

Logically:

Event list

Event 1: Browser termination

Device identities

Source device: ME
Destination device: SIM

Browser termination cause: User termination

Coding:

27.22.7.9.1.5 Test requirement

The ME shall operate in the manner defined in expected sequence 1.1.

27.22.7.10 Data available event

27.22.7.10.1 Definition and applicability

See clause 3.2.2.

27.22.7.10.2 Conformance requirements

The ME shall support the class "e" commands as defined in:

• 3GPP TS 11.14 [15].

Additionally the ME shall support ENVELOPE (EVENT DOWNLOAD - Data available).

27.22.7.10.3 Test purpose

To verify that the ME shall send an ENVELOPE (EVENT DOWNLOAD - Data available) to the SIM after the ME receives a packet of data from the server by the BIP channel previously opened.

27.22.7.10.4 Method of test

27.22.7.10.4.1 Initial conditions

The ME is connected to the SIM Simulator and only connected to the System Simulator if the System Simulator is mentioned in the sequence table.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure. The SIM must have sent the SET UP EVENT LIST to the ME to supply a set of events (event Data available).

For MEs supporting BIP related to GPRS in UDP (i.e condition C121 in table B.1), The PROACTIVE COMMAND: OPEN CHANNEL 1.1.1 shall be executed to open a channel successfully at the beginning of the test. The corresponding Terminal Response shall be TERMINAL RESPONSE: OPEN CHANNEL 1.1.1A or TERMINAL RESPONSE: OPEN CHANNEL 1.1.1B.

The PROACTIVE COMMAND: SEND DATA 1.1.1 shall be performed successfully to detect the ME's port number, which has to be addressed by the network simulator when data has to be transmitted to the card. The corresponding Terminal Response shall be TERMINAL RESPONSE: SEND DATA 1.1.1.

The following Bearer Parameters used are those defined in the default Test PDP context3, as specified in TS 51.010-1 [12], for test cases using packet services:

Bearer Parameters

Precedence Class: 02
Delay Class: 04
Reliability Class: 05
Peak throughput class: 05
Mean throughput class: 31
Packet data protocol: 02 (IP)

GPRS Parameters

Network access name: TestGp.rs

User login: UserLog User password: UserPwd

SIM/ME interface transport level

Transport format: UDP Port number: 44444

Data destination address 01.01.01.01

27.22.7.10.4.2 Procedure

Expected sequence 1.1 (EVENT DOWNLOAD - Data available)

| Step | Direction | MESSAGE / Action | Comments |
|------|-----------------------|--|----------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND PENDING: OPEN CHANNEL 1.1.1 | See initial conditions |
| 2 | $ME \rightarrow SIM$ | FETCH | |
| 3 | $SIM \rightarrow ME$ | PROACTIVE COMMAND: OPEN CHANNEL 1.1.1 | [Command performed successfully] |
| 4 | $ME \rightarrow USER$ | The ME may display channel opening information | |
| 5 | $ME \rightarrow SS$ | PDP context activation request | |
| 6 | $SS \to ME$ | PDP context activation accept | |
| 7 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: OPEN CHANNEL 1.1.1A or TERMINAL RESPONSE: OPEN CHANNEL 1.1.1B | |
| 8 | $SIM \to ME$ | PROACTIVE COMMAND PENDING: SEND DATA 1.1.1 | |
| 9 | $ME \rightarrow SIM$ | FETCH | |
| 10 | $SIM \to ME$ | PROACTIVE COMMAND: SEND DATA (immediate) 1.1.1 | |
| 11 | $ME \rightarrow SS$ | Transfer of 8 Bytes of data to the SS through channel 1 | [To retrieve ME's port number] |
| 12 | $ME \rightarrow SIM$ | TERMINAL RESPONSE: SEND DATA (immediate) 1.1.1 | [Command performed successfully] |
| 13 | $SS \to ME$ | Data sent through the BIP channel using the ME's port number, which was retrieved in step 11 | |
| 14 | $ME \rightarrow SIM$ | ENVELOPE 1.1.1 (Event-Data Available) | |

PROACTIVE COMMAND: OPEN CHANNEL 1.1.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: SIM
Destination device: ME

Bearer

Bearer type: GPRS

Bearer parameter:

Precedence Class: 02
Delay Class: 04
Reliability Class: 05
Peak throughput class: 05
Mean throughput class: 31
Packet data protocol: 02 (IP)

Buffer

Buffer size: 1000 Network access name: TestGp.rs

Text String: UserLog (User login)
Text String: UserPwd (User password)

SIM/ME interface transport level

Transport format: UDP
Port number: 44444
Data destination address 01.01.01.01

Coding:

| BER-TLV | D0 | 42 | 81 | 03 | 01 | 40 | 01 | 82 | 02 | 81 | 82 | 35 |
|---------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 07 | 02 | 02 | 04 | 05 | 05 | 1F | 02 | 39 | 02 | 03 | E8 |
| | 47 | 0A | 06 | 54 | 65 | 73 | 74 | 47 | 70 | 02 | 72 | 73 |
| | 0D | 08 | F4 | 55 | 73 | 65 | 72 | 4C | 6F | 67 | 0D | 80 |
| | F4 | 55 | 73 | 65 | 72 | 50 | 77 | 64 | 3C | 03 | 01 | AD |
| | 9C | 3E | 05 | 21 | 01 | 01 | 01 | 01 | | | | |

TERMINAL RESPONSE: OPEN CHANNEL 1.1.1A

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Channel status Channel identifier 1 and link established or PDP context activated

Bearer description

Bearer type: GPRS

Bearer parameter:

Precedence Class: 02
Delay Class: 04
Reliability Class: 05
Peak throughput class: 05
Mean throughput class: 31
Packet data protocol: 02 (IP)

Buffer

Buffer size: 1000

Coding:

| BER-TLV: | 81 | 03 | 01 | 40 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 38 | 02 | 81 | 00 | 35 | 07 | 02 | 02 | 04 | 05 | 05 | 1F |
| | 02 | 39 | 02 | 03 | E8 | | | | | | | |

TERMINAL RESPONSE: OPEN CHANNEL 1.1.1B

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Channel status Channel identifier 1 and link established or PDP context activated

Bearer description

Bearer type: GPRS

Bearer parameter:

Precedence Class: 00
Delay Class: 04
Reliability Class: 05
Peak throughput class: 05
Mean throughput class: 31
Packet data protocol: 02 (IP)

Buffer

Buffer size: 1000

Coding:

| BER-TLV: | 81 | 03 | 01 | 40 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 38 | 02 | 81 | 00 | 35 | 07 | 02 | 00 | 04 | 05 | 05 | 1F |
| | 02 | 39 | 02 | 03 | E8 | | | | | | | |

PROACTIVE COMMAND: SEND DATA 1.1.1

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Send Immediately

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data

Channel Data: 00 01 .. 07 (8 Bytes of data)

Coding:

| BER-TLV: | D0 | 13 | 81 | 03 | 01 | 43 | 01 | 82 | 02 | 81 | 21 | B6 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 08 | 00 | 01 | 02 | 03 | 04 | 05 | 06 | 07 | | | |

TERMINAL RESPONSE: SEND DATA 1.1.1

Logically:

Command details

Command number:

Command type: SEND DATA
Command qualifier: Send Immediately

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Channel data length: More than 255 bytes of space available in the Tx buffer

Coding:

| BER-TLV: | 81 | 03 | 01 | 43 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | B7 | 01 | FF | | | | | | | | | |

ENVELOPE: EVENT DOWNLOAD - Data available 1.1.1

Logically:

Event list

Event: Data available

Device identities

Source device: ME
Destination device: SIM

Channel status

Channel status: Channel 1 open, link established

Channel Data Length

Channel data length: 8 Bytes available in Rx buffer

Coding:

| BER-TLV: | D6 | 0E | 99 | 01 | 09 | 82 | 02 | 82 | 81 | B8 | 02 | 81 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 00 | B7 | 01 | 08 | | | | | | | | |

27.22.7.10.1.5 Test requirement

The ME shall operate in the manner defined in expected sequence 1.1.

27.22.7.11 Channel Status event

27.22.7.11.1 Definition and applicability

See clause 3.2.2.

27.22.7.11.2 Conformance requirements

The ME shall support the class "e" commands as defined in:

• 3GPP TS 11.14 [15].

Additionally the ME shall support ENVELOPE (EVENT DOWNLOAD - Channel Status).

27.22.7.11.3 Test purpose

To verify that the ME shall send an ENVELOPE (EVENT DOWNLOAD - Channel Status) to the SIM after the link dropped between the NETWORK and the ME.

27.22.7.11.4 Method of test

27.22.7.11.4.1 Initial conditions

The ME is connected to the SIM Simulator and the System Simulator. The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

For MEs supporting BIP related to GPRS in UDP (i.e condition C121 in table B.1), The PROACTIVE COMMAND: OPEN CHANNEL 1.1.1 shall be executed to open a channel successfully at the beginning of the test. The corresponding Terminal Response shall be TERMINAL RESPONSE: OPEN CHANNEL 1.1.1A or TERMINAL RESPONSE: OPEN CHANNEL 1.1.1B.

The following Bearer Parameters used are those defined in the default Test PDP context3, as specified in TS 51.010-1 [12], for test cases using packet services:

Bearer Parameters

Precedence Class: 02
Delay Class: 04
Reliability Class: 05
Peak throughput class: 05
Mean throughput class: 31
Packet data protocol: 02 (IP)

GPRS Parameters

Network access name: TestGp.rs

User login: UserLog User password: UserPwd

SIM/ME interface transport level

Transport format: UDP Port number: 44444

Data destination address 01.01.01.01

27.22.7.11.4.2 Procedure

Expected sequence 1.1 (EVENT DOWNLOAD - Channel Status on a link dropped)

| Step | Direction | MESSAGE / Action | Comments |
|------|----------------------|------------------------------------|----------------------------------|
| 1 | $SIM \to ME$ | PROACTIVE COMMAND PENDING: | |
| | | SET UP EVENT LIST 1.1.1 | |
| 2 | $ME \to SIM$ | FETCH | |
| 3 | $SIM \to ME$ | PROACTIVE COMMAND: SET UP | [EVENT: channel status] |
| | | EVENT LIST 1.1.1 | |
| 4 | $ME \to SIM$ | TERMINAL RESPONSE: SET UP | [command performed successfully] |
| | | EVENT LIST 1.1.1 | |
| 5 | $SIM \rightarrow ME$ | | See initial conditions |
| | | OPEN CHANNEL 1.1.1 | |
| 6 | $ME \to SIM$ | FETCH | |
| 7 | $SIM \to ME$ | PROACTIVE COMMAND: OPEN | |
| | | CHANNEL 1.1.1 | |
| 8 | $ME \to USER$ | The ME may display channel opening | |
| | ME . 00 | information | |
| 9 | $ME \rightarrow SS$ | PDP context activation request | |
| 10 | $SS \rightarrow ME$ | PDP context activation accept | |
| 11 | $ME \to SIM$ | TERMINAL RESPONSE: OPEN | [Command performed successfully] |
| | | CHANNEL 1.1.1A | |
| | | Or TEDMINIAL DECRONGE: OPEN | |
| | | TERMINAL RESPONSE: OPEN | |
| 40 | 00 ME | CHANNEL 1.1.1B | |
| 12 | $SS \rightarrow ME$ | Link dropped | |
| 13 | $ME \to SIM$ | ENVELOPE 1.1.1 (Event-Channel | |
| | | Status) | |

PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM
Destination device: ME

Event list

Event 1: Channel Status

Coding:

| BER-TLV: | D0 | 0C | 81 | 03 | 01 | 05 | 00 | 82 | 02 | 81 | 82 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 99 | 01 | 0A | | | | | | | | |

TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 05 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|-----------|----|----|-----|----|----|----|----|----|----|----|----|----|
| DLIX-ILV. | 01 | 03 | U I | UJ | 00 | 02 | 02 | 02 | 01 | 03 | Οī | 00 |

PROACTIVE COMMAND: OPEN CHANNEL 1.1.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: SIM
Destination device: ME

Bearer

Bearer type: GPRS

Bearer parameter:

Precedence Class: 02
Delay Class: 04
Reliability Class: 05
Peak throughput class: 05
Mean throughput class: 31
Packet data protocol: 02 (IP)

Buffer

Buffer size: 1000 Network access name: TestGp.rs

Text String: UserLog (User login)
Text String: UserPwd (User password)

SIM/ME interface transport level

Transport format: UDP
Port number: 44444
Data destination address 01.01.01.01

Coding:

BER-TLV

| D0 | 42 | 81 | 03 | 01 | 40 | 01 | 82 | 02 | 81 | 82 | 35 |
|----|----|----|----|----|----|----|----|----|----|----|----|
| 07 | 02 | 02 | 04 | 05 | 05 | 1F | 02 | 39 | 02 | 03 | E8 |
| 47 | 0A | 06 | 54 | 65 | 73 | 74 | 47 | 70 | 02 | 72 | 73 |
| 0D | 08 | F4 | 55 | 73 | 65 | 72 | 4C | 6F | 67 | 0D | 08 |
| F4 | 55 | 73 | 65 | 72 | 50 | 77 | 64 | 3C | 03 | 01 | AD |
| 9C | 3E | 05 | 21 | 01 | 01 | 01 | 01 | | | | |

TERMINAL RESPONSE: OPEN CHANNEL 1.1.1A

Logically:

Command details

Command number: 1

OPEN CHANNEL Command type:

Command qualifier: immediate link establishment

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Channel status Channel identifier 1 and link established or PDP context activated

Bearer description

Bearer type: **GPRS**

Bearer parameter:

Precedence Class: 02 Delay Class: 04 Reliability Class: 05 Peak throughput class: 05 Mean throughput class: Packet data protocol: 02 (IP)

Buffer

Buffer size: 1000

Coding:

| BER-TLV: | 81 | 03 | 01 | 40 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 38 | 02 | 81 | 00 | 35 | 07 | 02 | 02 | 04 | 05 | 05 | 1F |
| | 02 | 39 | 02 | 03 | E8 | | | | | | | |

TERMINAL RESPONSE: OPEN CHANNEL 1.1.1B

Logically:

Command details

Command number:

Command type: **OPEN CHANNEL**

Command qualifier: immediate link establishment

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Channel status Channel identifier 1 and link established or PDP context activated

Bearer description

Bearer type: **GPRS**

Bearer parameter:

Precedence Class: 00 Delay Class: Reliability Class: 05 Peak throughput class: 05 Mean throughput class: Packet data protocol: 02 (IP)

Buffer

Buffer size: 1000

Coding:

| BER-TLV: | 81 | 03 | 01 | 40 | 01 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 38 | 02 | 81 | 00 | 35 | 07 | 02 | 00 | 04 | 05 | 05 | 1F |
| | 02 | 39 | 02 | 03 | E8 | | | | | | | |

ENVELOPE: EVENT DOWNLOAD - Channel Status 1.1.1

Logically:

Event list

Event: Channel Status

Device identities

Source device: ME Destination device: SIM

Channel status

Channel status: Channel 1, link dropped

Coding:

| BER-TLV: | D6 | 0B | 99 | 01 | 0A | 82 | 02 | 82 | 81 | B8 | 02 | 01 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 05 | | | | | | | | | | | |

27.22.7.11.1.5 Test requirement

The ME shall operate in the manner defined in expected sequence 1.1.

27.22.8 MO SHORT MESSAGE CONTROL BY SIM

27.22.8.1 Definition and applicability

See clause 3.2.2.

27.22.8.2 Conformance requirement

The ME shall support the MO SEND SHORT MESSAGE CONTROL facility as defined in:

• 3GPP TS 11.14 [15] clause 9.2.

The ME shall also support the SEND SMS facitily as specified in

• 3GPP TS 11.14 [15] clause 6.4.10

27.22.8.3 Test purpose

To verify that for all SMS sending attempts, even those resulting from a SEND SHORT MESSAGE proactive SIM command, the ME shall first pass the RP_destination_address of the service center and the TP_Destination_Address to the SIM, using the ENVELOPE (MO Short Message CONTROL).

To verify that if the SIM responds with '90 00', the ME shall send the SMS with the address unchanged.

To verify that if the SIM responds with '93 00', the ME shall not send the SMS and may retry the command.

To verify that if the SIM responds with '9F XX', the ME shall use the GET RESPONSE command to get the response data. The response data from the SIM shall indicate to the ME whether to send the SM as proposed, not send the SM, send the SM using the data supplied by the SIM.

To verify that, in the case where the initial SM request results from a proactive SEND SHORT MESSAGE, if the MO SMS CONTROL result is "not allowed" or "allowed with modifications", the ME shall inform the SIM using TERMINAL RESPONSE "interaction with call control by SIM or MO short message control by SIM, action not allowed".

27.22.8.4 Method of tests

27.22.8.4.1 Initial conditions

The ME is connected to the System Simulator and the SIM Simulator.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The MO SMS control service is enabled.

The SMS service center address in the ME shall be set to '+112233445566778' prior to the execution of the tests.

The GSM parameters of the system simulator are:

- Mobile Country Code (MCC) = 001;
- Mobile Network Code (MNC) = 01;
- Location Area Code (LAC) = 0001;
- Cell Identity value = 0001;

The PCS 1900 parameters of the system simulator are:

- Mobile Country Code (MCC) = 001;
- Mobile Network Code (MNC) = 011;
- Location Area Code (LAC) = 0001;
- Cell Identity value = 0001.

27.22.8.4.2 Procedure

Expected Sequence 1.1 (MO SM CONTROL BY SIM , with Proactive command, Allowed, no modification')

| Step | Direction | Message / Action | Comments |
|------|------------|------------------------------------|---|
| 1 | SIM -> ME | PROACTIVE COMMAND PENDING: SEND | |
| | | SHORT MESSAGE 1.1.1 | |
| 2 | ME -> SIM | FETCH | |
| 3 | SIM -> ME | PROACTIVE COMMAND: SEND SHORT | |
| | | MESSAGE 1.1.1 | |
| 4 | ME -> USER | Display "Send SM" | [Alpha Identifier] |
| 5 | ME -> SIM | ENVELOPE: MO SHORT MESSAGE CONTROL | [Option A shall apply for GSM parameters] |
| | | 1.1.1A | |
| | | Or | |
| | | ENVELOPE: MO SHORT MESSAGE CONTROL | [Option B shall apply for PCS1900 |
| | | 1.1.1B | parameters] |
| 6 | SIM -> ME | 9F 02 | |
| 7 | | | |
| / | ME -> SIM | GET RESPONSE | |
| 8 | SIM -> ME | MO SMS CONTROL RESULT 1.1.1 | ['Allowed, no modification'] |
| 9 | ME -> SS | Send SMS-PP Message 1.1 | [The ME sends the SM containing SMS-PP |
| | 1112 > 00 | Cond Owle 11 Woodage 1.1 | (SEND SHORT MESSAGE) Message 1.1 |
| | | | without modification] |
| 10 | SS -> ME | SMS RP-ACK | |
| 11 | ME -> SIM | TERMINAL RESPONSE: SEND SHORT | |
| 1 | | MESSAGE 1.1.1 | |

PROACTIVE COMMAND: SEND SHORT MESSAGE 1.1.1

Logically:

Command details

Command number:

Command type: SEND SHORT MESSAGE

Command qualifier: packing not required

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "Send SM"

Address

TON: International number

NPI: "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding 8-bit data
Message class class 0
TP-UDL 12

TP-UD "Test Message"

Coding:

| BER-TLV: | D0 | 37 | 81 | 03 | 01 | 13 | 00 | 82 | 02 | 81 | 83 | 85 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| _ | 07 | 53 | 65 | 6E | 64 | 20 | 53 | 4D | 86 | 09 | 91 | 11 |
| | 22 | 33 | 44 | 55 | 66 | 77 | F8 | 8B | 18 | 01 | 00 | 09 |
| | 91 | 10 | 32 | 54 | 76 | F8 | 40 | F4 | 0C | 54 | 65 | 73 |
| | 74 | 20 | 4D | 65 | 73 | 73 | 61 | 67 | 65 | | | |

SMS-PP (SEND SHORT MESSAGE) Message 1.1

Logically:

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI The TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "01"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding 8-bit data
Message class class 0
TP-UDL 12

TP-UD "Test Message"

Coding:

| Coding | 01 | 01 | 09 | 91 | 10 | 32 | 54 | 76 | F8 | 40 | F4 | 0C |
|--------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 54 | 65 | 73 | 74 | 20 | 4D | 65 | 73 | 73 | 61 | 67 | 65 |

ENVELOPE MO SHORT MESSAGE CONTROL 1.1.1A

Logically:

Device identities

Source device: ME
Destination device: SIM

RP Destination Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string '112233445566778'

TP Destination Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string '012345678'

Location Information

MCC & MNC the mobile country and network code (00F110)

LAC the location Area Code (0001)
Cell ID Cell Identity Value (0001)

Coding:

| BER-TLV: | D5 | 20 | 02 | 02 | 82 | 81 | 06 | 09 | 91 | 11 | 22 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 33 | 44 | 55 | 66 | 77 | F8 | 06 | 06 | 91 | 10 | 32 |
| | 54 | 76 | F8 | 13 | 07 | 00 | F1 | 10 | 00 | 01 | 00 |
| | 01 | | | | | | | | | | |

ENVELOPE MO SHORT MESSAGE CONTROL 1.1.1B

Logically:

Device identities

Source device: ME
Destination device: SIM

RP Destination Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string '112233445566778'

TP Destination Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string '012345678'

Location Information

MCC & MNC the mobile country and network code (001110)

LAC the location Area Code (0001)
Cell ID Cell Identity Value (0001)

Coding:

| BER-TLV: | D5 | 20 | 02 | 02 | 82 | 81 | 06 | 09 | 91 | 11 | 22 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 33 | 44 | 55 | 66 | 77 | F8 | 06 | 06 | 91 | 10 | 32 |
| | 54 | 76 | F8 | 13 | 07 | 00 | 11 | 10 | 00 | 01 | 00 |
| | 01 | | | | | | | | | | |

MO SHORT MESSAGE CONTROL RESULT 1.1.1

Logically:

MO Short Message control result : '00' = Allowed, no modification

Coding:

BER-TLV: 00 00

TERMINAL RESPONSE: SEND SHORT MESSAGE 1.1.1

Logically:

Command details

Command number:

Command type: SEND SHORT MESSAGE

Command qualifier:

packing not required

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| BER-TLV: | 81 | 03 | 01 | 13 | 00 | 82 | 02 | 82 | 81 | 83 | 01 | 00 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|

Expected Sequence 1.2 (MO SM CONTROL BY SIM, with user SMS, Allowed, no modification')

| Step | Direction | Message / Action | Comments |
|------|------------|--|--|
| 1 | USER -> ME | The user makes a SMS with the user data 'Test Message' and sends it to +012345678. | [The data entered and the ME settings shall lead to the same SMS-TPDU as defined in SMS-PP (SEND SHORT MESSAGE) Message 1.2. |
| 2 | ME -> SIM | ENVELOPE: MO SHORT MESSAGE CONTROL 1.1.1A or ENVELOPE: MO SHORT MESSAGE CONTROL 1.1.1B | [Option A shall apply for GSM parameters] [Option B shall apply for PCS1900 parameters] |
| 3 | SIM -> ME | 9F 02 | paramotoroj |
| 4 | ME -> SIM | GET RESPONSE | |
| 5 | SIM -> ME | MO SHORT MESSAGE CONTROL RESULT 1.1.1 | ['Allowed, no modification'] |
| 6 | ME -> SS | Send SMS-PP Message 1.2 | [The ME sends the SM containing SMS-PP (SEND SHORT MESSAGE) Message 1.2 without modification] |
| 7 | SS -> ME | SMS RP-ACK | |

SMS-PP (SEND SHORT MESSAGE) Message 1.2

Logically:

| SMS TPDU | |
|----------|--|
| TP-MTI | SMS-SUBMIT |
| TP-RD | Instruct the SC to accept an SMS-SUBMIT for a SM |
| TP-VPF | TP-VP field present - relative format |
| TP-RP | TP-Reply-Path is not set in this SMS-SUBMIT |
| TP-UDHI | The TP-UD field contains only the short message |
| TP-SRR | A status report is not requested |
| TP-MR | "01" |
| TP-DA | |
| TON | International number |

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID 0

TP-DCS

Message coding GSM 7 bit default alphabet

Message class No message class

TP-VP Maximum

TP-UDL 12 TP-UD "Test Message"

Coding:

| Coding | 11 | 01 | 09 | 91 | 10 | 32 | 54 | 76 | F8 | 00 | 00 | FF |
|--------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0C | D4 | F2 | 9C | 0E | 6A | 96 | E7 | F3 | F0 | B9 | 0C |

Expected Sequence 1.3 (MO SM CONTROL BY SIM, with Proactive command, Not allowed')

| Step | Direction | Message / Action | Comments |
|------|------------|---|-----------------------------------|
| 1 | SIM -> ME | PROACTIVE COMMAND PENDING: SEND SHORT | |
| | | MESSAGE 1.1.1 | |
| 2 | ME -> SIM | FETCH | |
| 3 | SIM -> ME | PROACTIVE COMMAND: SEND SHORT MESSAGE 1.1.1 | |
| 4 | ME -> USER | Display "Send SM" | [Alpha Identifier] |
| 5 | ME -> SIM | ENVELOPE : MO SHORT MESSAGE CONTROL 1.1.1A | [Option A shall apply for GSM |
| | | or | parameters] |
| | | ENVELOPE : MO SHORT MESSAGE CONTROL 1.1.1B | |
| | | | |
| | | | [Option B shall apply for |
| | | | PCS1900 parameters] |
| 6 | SIM -> ME | 9F 02 | |
| 7 | ME -> SIM | GET RESPONSE | |
| 8 | SIM -> ME | MO SHORT MESSAGE CONTROL RESULT 1.3.1 | ['not Allowed'] |
| 9 | ME -> SIM | TERMINAL RESPONSE: SEND SHORT MESSAGE 1.3.1 | [Permanent Problem - Interaction |
| | | | with Call Control or MO short |
| | | | message control by SIM] |
| 10 | ME→ SS | The ME does not send the Short Message | |

MO SHORT MESSAGE CONTROL RESULT 1.3.1

Logically:

MO Short Message control result : '01' = Not Allowed

Coding:

BER-TLV: 01 00

TERMINAL RESPONSE: SEND SHORT MESSAGE 1.3.1

Logically:

Command details

Command number: 01

Command Type: SEND SHORT MESSAGE Command qualifier: packing not required

Device identities

Source device: ME Destination device: SIM

Result

General Result: Interaction with call control or MO-SM by SIM permanent

problem

Additional information: Action not allowed

Coding:

| BER-TLV: | 81 | 03 | 01 | 13 | 00 | 82 | 02 | 82 | 81 | 83 | 02 | 39 |
|----------|----|----|----|----|----|----|----|----|----|----|----|----|
| · | 01 | | | | | | | | | | | |

Expected Sequence 1.4 (MO SM CONTROL BY SIM, with user SMS, Not allowed')

| Step | Direction | Message / Action | Comments |
|------|------------|---|--|
| 1 | USER -> ME | The user makes a SMS with the user data 'Test | [The data entered and the ME settings |
| | | Message' and sends it to +012345678. | shall lead to the same SMS-TPDU as defined in SMS-PP (SEND SHORT |
| | | | MESSAGE) Message 1.2. |
| 2 | ME -> SIM | ENVELOPE : MO SHORT MESSAGE CONTROL | Option A shall apply for GSM |
| | | 1.1.1A | parameters] |
| | | or | |
| | | ENVELOPE : MO SHORT MESSAGE CONTROL | [Option B shall apply for PCS1900 |
| | | 1.1.1B | parameters] |
| 3 | SIM -> ME | 9F 02 | |
| 4 | ME -> SIM | GET RESPONSE | |
| 5 | SIM -> ME | MO SM CONTROL RESULT 1.3.1 | ['Not allowed'] |
| 6 | ME → SS | The ME does not send the Short Message | |

Expected Sequence 1.5 (MO SM CONTROL BY SIM , with Proactive command, Allowed with modifications')

| Step | Direction | Message / Action | Comments |
|------|------------|---|--|
| 1 | SIM -> ME | PROACTIVE COMMAND PENDING: SEND SHORT MESSAGE 1.1.1 | |
| 2 | ME -> SIM | FETCH | |
| 3 | SIM -> ME | PROACTIVE COMMAND: SEND SHORT MESSAGE 1.1.1 | Send SMS to '+012345678' |
| 4 | ME -> USER | Display "Send SM" | [Alpha Identifier] |
| 5 | ME -> SIM | ENVELOPE: MO SHORT MESSAGE CONTROL 1.1.1A or | [Option A shall apply for GSM parameters] |
| | | ENVELOPE: MO SHORT MESSAGE CONTROL 1.1.1B | [Option B shall apply for PCS1900 parameters] |
| 6 | SIM -> ME | 9F 15 | |
| 7 | ME -> SIM | GET RESPONSE | |
| 8 | SIM -> ME | MO SM CONTROL RESULT 1.5.1 | ['Allowed with modifications'] |
| 9 | ME -> SS | Send SMS-PP Message 1.5 | [The ME sends the SM containing SMS-PP (SEND SHORT MESSAGE) Message 1.5 with the data provided by the SIM to the changed Service Center Adress '+112233445566779'] |
| 10 | SS -> ME | SMS RP-ACK | |
| 11 | ME -> SIM | TERMINAL RESPONSE: SEND SHORT MESSAGE 1.5.1 | |

MO SHORT MESSAGE CONTROL RESULT 1.5.1

Logically:

MO Short Message control result : '02' = Allowed with modifications

RP Destination_Address of the Service Center TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string: '112233445566779'

TP Destination Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown" Dialling number string: '012345679'

Coding:

| BER-TLV: | 02 | 13 | 86 | 09 | 91 | 11 | 22 | 33 | 44 | 55 | 66 |
|----------|----|----|----|----|----|----|----|----|----|----|----|
| | 77 | F9 | 86 | 06 | 91 | 10 | 32 | 54 | 76 | F9 | |
| | | | | | | | | | | | |

SMS-PP (SEND SHORT MESSAGE) Message 1.5

Logically:

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI The TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "01"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345679"

TP-PID Short message type 0

TP-DCS

Message coding 8-bit data Message class class 0 TP-UDL 12

TP-UD "Test Message"

Coding:

| Coding: | 01 | 01 | 09 | 91 | 10 | 32 | 54 | 76 | F9 | 40 | F4 | 0C |
|---------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 54 | 65 | 73 | 74 | 20 | 4D | 65 | 73 | 73 | 61 | 67 | 65 |

TERMINAL RESPONSE: SEND SHORT MESSAGE 1.5.1

Logically:

Command details

Command number: 01

Command Type: SEND SHORT MESSAGE Command qualifier: packing not required

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

| | - 4 | 20 | ~ 4 | 4.0 | 9 | 0 | 2 | • | - 4 | | ~ 4 | |
|-----------|------|-------|-----|-----|------|----|-------|----|------|----|-----|----|
| IBER-ILV: | I 81 | 1 ()3 | ()1 | 1:3 | 1 00 | 82 | 1 ()2 | 82 | I 81 | 83 | 01 | 00 |

Expected Sequence 1.6 (MO SM CONTROL BY SIM, with user SMS, Allowed with modifications')

| Step | Direction | Message / Action | Comments |
|------|------------|--|--|
| 1 | USER -> ME | The user makes a SMS with the user data 'Test Message' and sends it to +012345678. | [The data entered and the ME settings shall lead to the same SMS-TPDU as defined in SMS-PP (SEND SHORT MESSAGE) Message 1.2. |
| 2 | ME -> SIM | ENVELOPE: MO SHORT MESSAGE CONTROL 1.1.1A or ENVELOPE: MO SHORT MESSAGE CONTROL 1.1.1B | [Option A shall apply for GSM parameters] [Option B shall apply for PCS1900 parameters] |
| 3 | SIM -> ME | 9F XX | |
| 4 | ME -> SIM | GET RESPONSE | |
| 5 | SIM -> ME | MO SM CONTROL RESULT 1.5.1 | ['Allowed with modifications'] |
| 6 | ME-> SS | Send SMS-PP Message 1.6 | [The ME sends the SM containing SMS-PP (SEND SHORT MESSAGE) Message 1.6 with the data provided by the SIM] to the changed Service Center Adress '+112233445566779' |
| 7 | SS -> ME | SMS RP-ACK | |

SMS-PP (SEND SHORT MESSAGE) Message 1.6

Logically:

SMS TPDU TP-MTI **SMS-SUBMIT** TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM TP-VPF TP-VP field present - relative format TP-Reply-Path is not set in this SMS-SUBMIT TP-RP The TP-UD field contains only the short message TP-UDHI TP-SRR A status report is not requested "01" TP-MR TP-DA TON International number NPI "ISDN / telephone numbering plan" Address value "012345679" TP-PID 0 TP-DCS Message coding GSM 7 bit default alphabet Message class No message class Maximum TP-VP

12

"Test Message"

Coding:

TP-UDL

TP-UD

| Coding | 11 | 01 | 09 | 91 | 10 | 32 | 54 | 76 | F9 | 00 | 00 | FF |
|--------|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0C | D4 | F2 | 9C | 0E | 6A | 96 | E7 | F3 | F0 | B9 | 0C |

Expected Sequence 1.7 (MO SM CONTROL BY SIM, with Proactive command, the SIM responds with '90 00', Allowed, no modification)

| Step | Direction | Message / Action | Comments |
|------|------------|--|---|
| 1 | SIM -> ME | PROACTIVE COMMAND PENDING: SEND SHORT MESSAGE 1.1.1 | |
| 2 | ME -> SIM | FETCH | |
| 3 | SIM -> ME | PROACTIVE COMMAND: SEND SHORT MESSAGE 1.1.1 | Send SMS to '+012345678' |
| 4 | ME -> USER | Display "Send SM" | [Alpha Identifier] |
| 5 | ME -> SIM | ENVELOPE : MO SHORT MESSAGE CONTROL 1.1.1A or ENVELOPE : MO SHORT MESSAGE CONTROL | [Option A shall apply for GSM parameters] |
| | | 1.1.1B | [Option B shall apply for PCS1900 parameters] |
| 6 | SIM -> ME | 90 00 | paramotoroj |
| 7 | ME ->SS | Send SMS-PP | [The ME sends the SM containing SMS-PP (SEND SHORT MESSAGE) Message 1.1 without modification] |
| 8 | SS -> ME | SMS RP-ACK | |
| 9 | ME -> SIM | TERMINAL RESPONSE: SEND SHORT MESSAGE 1.1.1 | |

Expected Sequence 1.8 (MO SM CONTROL BY SIM , Send Short Message attempt by user, the SIM responds with '90 00', Allowed, no modification)

| Step | Direction | Message / Action | Comments |
|------|----------------------|---|--|
| 1 | User → ME | The user makes a SMS with the user data 'Test Message' and sends it to +012345678. | [The data entered and the ME settings shall lead to the same SMS-TPDU as defined in SMS-PP (SEND SHORT MESSAGE) Message 1.2. |
| 2 | $ME \to SIM$ | ENVELOPE : MO SHORT MESSAGE CONTROL 1.1.1 A or ENVELOPE : MO SHORT MESSAGE CONTROL | [Option A shall apply for GSM parameters] [Option B shall apply for PCS1900 |
| | | 1.1.1B | parameters] |
| 3 | $SIM \rightarrow ME$ | 90 00 | |
| 4 | $ME \rightarrow SS$ | Send SMS-PP | [The ME sends the SM containing SMS-PP (SEND SHORT MESSAGE) Message 1.2 without modification] |
| 5 | SS -> ME | SMS RP-ACK | _ |

Expected Sequence 1.9 Void

27.22.8.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.9.

Annex A: Void

Annex B: Void

Annex C: Void

Annex D (normative): Details of Test-SIM (TestSIM)

The TestSIM shall be able to present the following data:

ANSWER TO RESET

Logically:

TS (Initial character): '3B'

T0 (Format character): '86' (Following interface characters: TD(1), number of historical characters: 6)

TD1: '00' (Following interface characters: none, Transfer protocol: T=0)

T1: 91
T2: 99
T3: 00
T4: 12
T5: C1
T6: 00

Coding:

| BER-TLV: | 3B | 86 | 00 | 91 | 99 | 00 | 12 | C1 | 00 |
|----------|----|----|----|----|----|----|----|----|----|

- 1. For a successful outcome of the command "Select MasterFile" the TestSIM shall send SW1/SW2 "9F 1B".
- 2. For a successful outcome of the command "Get Response with Length 1B" on the MasterFile the TestSIM shall respond:

RFU: '00 00'
Not allocated memory: '653 bytes'
File ID: Master File

Type of file: MF

RFU: 00 00 22 FF 01'

Length of following data: 14 bytes'

File characteristics:

Clock Stop: Not allowed Min. frequence for GSM algorithm: 13/8 MHz

Technology identification: 3V Technology SIM

CHV1: disabled

DFs in current directory: 2
EFs in current directory: 8
Number of CHV and admin. Codes: 3
RFU byte 18: 00

CHV1 status:

False representations remaining: 3
RFU-bits 7-5: 000
Secret code: Initialized

Unlock CHV1 status:

False representations remaining: 10
RFU-bits 7-5: 000
Secret code: Initialized

CHV2 status:

False representations remaining: 3
RFU-bits 7-5: 000
Secret code: Initialized

Unlock CHV2 status:

False representations remaining: 10

RFU-bits 7-5: 000
Secret code: Initialized
RFU bytes 23: 00

Reserved for admin. management: 00 83 00 FF

Status Words

SW1 / SW2: Normal ending of command

Coding:

| Coding | 00 | 00 | 02 | 8D | 3F | 00 | 01 | 00 | 00 | 22 | FF | 01 |
|--------|----|----|----|----|----|----|----|----|----|----|----|----|
| _ | 0E | 9B | 02 | 08 | 03 | 00 | 83 | 8A | 83 | 8A | 00 | 00 |
| | 83 | 00 | FF | 90 | 00 | | | | | | | |

1. For a successful outcome of the command "Select GSM" the TestSIM shall send SW1/SW2 "9F 1B".

2. For a successful outcome of the command "Select PLMN" the TestSIM shall send SW1/SW2 "9F 0F".

3. EF_{PLMN} Information:

RFU-Bytes 1-2: 00 00 File size: 102 bytes File ID: 6F30

Type of File: Elementary file

Byte 8

RFU: 00

Access Condition:

UPDATE: CHV1
READ/SEEK: CHV1
RFU-bits 4-1: 1111
INCREASE: NEVER
INVALIDATE: NEVER
REHABILITATE: NEVER

File Status:

Invalidation status: File not invalidated

Readable/updateable: Not readable/updatable when invalidated

RFU-bits 8-4, 2: 0000 0 Length of following data: 2 bytes Structure: Transparent

Length of record: 00

The initial coding of the EF_{PLMN} shall be FF FF ... FF (logically: Empty).

Annex E (normative): Details of terminal profile support

Table E.1: TERMINAL PROFILE support

| Item | Terminal Profile | Ref. | Release | Status | Support | Mnemonic |
|------|---------------------------------|------------------|---------|--------|---------|-------------------|
| 1 | Profile Download | 3GPP TS 11.14, 5 | R96 | М | | PD_Pro_Dvnl |
| 2 | SMS-PP data download | 3GPP TS 11.14, 5 | R96 | М | | PD_SMS_PP |
| 3 | Cell Broadcast data | 3GPP TS 11.14, 5 | R96 | М | | PD_CB |
| | download | · | | | | |
| 4 | Menu selection | 3GPP TS 11.14, 5 | R96 | М | | PD_Menu_sel |
| 5 | '9EXX' response code for | 3GPP TS 11.14, 5 | R97 | C224 | | PD_9EXX |
| | SIM data download error | | | | | |
| 6 | Timer expiration | 3GPP TS 11.14, 5 | R98 | М | | PD_TExpir |
| 7 | USSD string data object | 3GPP TS 11.14, 5 | R98 | М | | PD_CC_USSD_Str |
| | supported in Call Control | | | | | |
| 8 | Envelope Call Control | 3GPP TS 11.14, 5 | R99 | C225 | | PD_CC_Auto_Redial |
| | always sent to the SIM | | | | | |
| | during automatic redial | | | | | |
| | mode | 0000 70 44 44 5 | 500 | | | DD 0 1 D |
| 9 | Command result | 3GPP TS 11.14, 5 | R96 | M | | PD_Cmd_Res |
| 10 | Call Control by SIM | 3GPP TS 11.14, 5 | R96 | M | | PD_CC |
| 11 | Cell identity included in Call | 3GPP TS 11.14, 5 | R97 | М | | PD_CC_Cell_Id |
| 40 | Control by SIM | 2000 TC 44 44 E | DOO | N 4 | | DD MO CMC CC |
| 12 | MO short message control by SIM | 3GPP TS 11.14, 5 | R98 | М | | PD_MO_SMS_CC |
| 13 | Handling of the alpha | 3GPP TS 11.14, 5 | R97 | М | | PD_Alpha _ld |
| 13 | identifier | 3677 13 11.14, 3 | N91 | IVI | | FD_Aipha _iu |
| 14 | UCS2 Entry supported | 3GPP TS 11.14, 5 | R97 | C203 | | PD_UCS2_entry |
| 15 | UCS2 Display supported | 3GPP TS 11.14, 5 | R97 | C204 | | PD_UCS2_Display |
| 16 | Display of the extension text | | R98 | C205 | | PD_Disp_Ext_Text |
| 17 | DISPLAY TEXT | 3GPP TS 11.14, 5 | R96 | M | | PD_Display_Text |
| 18 | GET INKEY | 3GPP TS 11.14, 5 | R96 | M | | PD_Get_Inkey |
| 19 | GET INPUT | 3GPP TS 11.14, 5 | R96 | M | | PD_Get_Input |
| 20 | MORE TIME | 3GPP TS 11.14, 5 | R96 | M | | PD_More_Time |
| 21 | PLAY TONE | 3GPP TS 11.14, 5 | R96 | М | | PD_Play_Tone |
| 22 | POLL INTERVAL | 3GPP TS 11.14, 5 | R96 | M | | PD_Poll_interval |
| 23 | POLLING OFF | 3GPP TS 11.14, 5 | R96 | М | | PD_Polling_Off |
| 24 | REFRESH | 3GPP TS 11.14, 5 | R96 | М | | PD_Refresh |
| 25 | SELECT ITEM | 3GPP TS 11.14, 5 | R96 | М | | PD_Select_Item |
| 26 | SEND SHORT MESSAGE | 3GPP TS 11.14, 5 | R96 | М | | PD_Send_SMS |
| 27 | SEND SS | 3GPP TS 11.14, 5 | R96 | М | | PD_Send_SS |
| 28 | SEND USSD | 3GPP TS 11.14, 5 | R98 | М | | PD_Send_USSD |
| 29 | SET UP CALL | 3GPP TS 11.14, 5 | R96 | М | | PD_SetUp_Call |
| 30 | SET UP MENU | 3GPP TS 11.14, 5 | R96 | М | | PD_SetUp_Menu |
| 31 | PROVIDE LOCAL | 3GPP TS 11.14, 5 | R96 | М | | PD_Provide_Local |
| | INFORMATION (LOCI & | , , | | | | |
| | IMEI) | | | | | |

| Item | Terminal Profile | Ref. | Release | Status | Support | Mnemonic |
|----------|--------------------------------------|---|---------|-----------|---------|-------------------------------|
| 32 | PROVIDE LOCAL | 3GPP TS 11.14, 5 | R97 | M | | PD_Provide_Local_ |
| | INFORMATION (NMR) | | | | | NMR |
| 33 | SET UP EVENT LIST | 3GPP TS 11.14, 5 | R98 | M | | PD_Setup_Evt_List |
| 34 | Event: MT call | 3GPP TS 11.14, 5 | R98 | M | | PD_MT_Call |
| 35 | Event: Call connected | 3GPP TS 11.14, 5 | R98 | M | | PD_Call_Conn |
| 36 | Event: Call disconnected | 3GPP TS 11.14, 5 | R98 | M | | PD_Call_Disc |
| 37 | Event: Location status | 3GPP TS 11.14, 5 | R98 | M | | PD_Loc_Status |
| 38 | Event: User activity | 3GPP TS 11.14, 5 | R98 | M | | PD_User_Act |
| 39 | Event: Idle screen available | 3GPP TS 11.14, 5 | R98 | M | | PD_Idle_Scr_Avail |
| 40 | Event: Card reader status | 3GPP TS 11.14, 5 | R98 | C206 | | PD_Evt_Rdr_Status |
| 41 | Event: Language selection | 3GPP TS 11.14, 5 | R99 | M | | PD_Lang_Select |
| 42 | Event: Browser Termination | 3GPP TS 11.14, 5 | R99 | C212 | | PD_Browser_Term |
| 43 | Event: Data available | 3GPP TS 11.14, 5 | R99 | C223 | | PD_Data_Avail |
| 44 | Event: Channel status | 3GPP TS 11.14, 5 | R99 | C223 | | PD_Evt_Ch_Status |
| 45 | RFU | 3GPP TS 11.14, 5 | R96 | Х | | PD_RFU_45 |
| 46 | RFU | 3GPP TS 11.14, 5 | R96 | Χ | | PD_RFU_46 |
| 47 | RFU | 3GPP TS 11.14, 5 | R96 | Х | | PD_RFU_47 |
| 48 | RFU | 3GPP TS 11.14, 5 | R96 | Х | | PD_RFU_48 |
| 49 | POWER ON CARD | 3GPP TS 11.14, 5 | R98 | C206 | | PD_C_On |
| 50 | POWER OFF CARD | 3GPP TS 11.14, 5 | R98 | C206 | | PD_C_Off |
| 51 | PERFORM CARD APDU | 3GPP TS 11.14, 5 | R98 | C206 | | PD_C_APDU |
| 52 | GET READER STATUS | 3GPP TS 11.14, 5 | R98 | C206 | | PD_Get_Rdr_Status |
| | (Card reader status) | | | | | |
| 53 | GET READER STATUS | 3GPP TS 11.14, 5 | R99 | C208 | | PD_Get_Rdr_Id |
| | (Card reader identifier) | | | | | |
| 54 | RFU | 3GPP TS 11.14, 5 | R96 | Х | | PD_RFU_54 |
| 55 | RFU | 3GPP TS 11.14, 5 | R96 | Х | | PD_RFU_55 |
| 56 | RFU | 3GPP TS 11.14, 5 | R96 | X | | PD_RFU_56 |
| 57 | TIMER MANAGEMENT | 3GPP TS 11.14, 5 | R98 | M | | PD_Timer_Mgt_Start |
| | (start, stop) | | | | | _Stop |
| 58 | TIMER MANAGEMENT | 3GPP TS 11.14, 5 | R98 | M | | PD_Timer_Val |
| | (get current value) | 0000 70 44 44 5 | Doo | | | DD D |
| 59 | PROVIDE LOCAL | 3GPP TS 11.14, 5 | R98 | М | | PD_Provide_Local_ |
| | INFORMATION (date, time | | | | | D_Time |
| 60 | and time zone) Binary choice in GET | 3GPP TS 11.14, 5 | R98 | M | | PD_Bin_Get_Inkey |
| 60 | INKEY | 3GFF 13 11.14, 5 | 1 130 | IVI | | PD_biii_Get_irikey |
| 61 | SET UP IDLE MODE TEXT | 3GPP TS 11 14 5 | R98 | М | | PD Stup Id Mod T |
| " | DET OF IBEE MOBE TEXT | 0011 10 11.14, 0 | 1130 | 101 | | xt |
| 62 | RUN AT COMMAND (i.e. | 3GPP TS 11 14 5 | R98 | C209 | | PD_Run_AT |
| 02 | class "b" is supported) | 0011 10 11.14, 0 | 1130 | 0203 | | D_Ran_/ |
| 63 | 2nd alpha identifier in SET | 3GPP TS 11.14, 5 | R98 | C226 | | PD SetUp Call Sec |
| | UP CALL | | 1100 | 0220 | | _Alpha_ld |
| 64 | 2nd capability configuration | 3GPP TS 11.14, 5 | R98 | C210 | | PD_Cap_Conf_Para |
| | parameter | .,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,, | | | | m |
| 65 | Sustained DISPLAY TEXT | 3GPP TS 11.14, 5 | R98 | C211 | | PD_Sustained_Displ |
| | | , , , | | | | _Txt |
| 66 | SEND DTMF command | 3GPP TS 11.14, 5 | R98 | М | | PD_Send_DTMF |
| 67 | PROVIDE LOCAL | 3GPP TS 11.14, 5 | R98 | М | | PD_Provide_Local_B |
| | INFORMATION - BCCH | | | | | CCH_List |
| 68 | PROVIDE LOCAL | 3GPP TS 11.14, 5 | R99 | M | | PD_Provide_Local_L |
| | INFORMATION (language) | | | | | S |
| 69 | PROVIDE LOCAL | 3GPP TS 11.14, 5 | R99 | M | | PD_Provide_Local_T |
| | INFORMATION (Timing | | | | | Α |
| <u> </u> | Advance) | 00DD T0 :: : : = | D.C. | | | DD 1 11 11 |
| 70 | LANGUAGE | 3GPP TS 11.14, 5 | R99 | M | | PD_Lang_Notif |
| 74 | NOTIFICATION | 00DD T0 44 44 5 | DCC | 0040 | | DD Laurah Diii. |
| 71 | LAUNCH BROWSER | 3GPP TS 11.14, 5 | R99 | C212 | | PD_Launch_Brws |
| 72 | RFU Soft kova support for | 3GPP TS 11.14, 5 | R96 | X C242 | | PD_RFU_72 |
| 73 | Soft keys support for SELECT ITEM | 3GPP TS 11.14, 5 | R99 | C213 | | PD_Softkey_Select_I tem |
| 74 | Soft Keys support for SET | 3GPP TS 11.14, 5 | R99 | C213 | | PD_Softkey_SetUp |
| ' 4 | UP MENU | 0011 10 11.14, 5 | 1133 | 0213 | | _Menu |
| 75 | RFU | 3GPP TS 11.14, 5 | R96 | Х | | PD_RFU_75 |
| _ , _ | • | 10011.17,0 | 1100 | | | ı. <u>5_</u> i.i <u>6_</u> i0 |

| Item | Terminal Profile | Ref. | Release | Status | Support | Mnemonic |
|------|--|------------------|---------|--------|---------|------------------|
| 76 | RFU | 3GPP TS 11.14, 5 | R96 | Χ | | PD_RFU_76 |
| 77 | RFU | 3GPP TS 11.14, 5 | R96 | X | | PD_RFU_77 |
| 78 | RFU | 3GPP TS 11.14, 5 | R96 | Χ | | PD_RFU_78 |
| 79 | RFU | 3GPP TS 11.14, 5 | R96 | Χ | | PD_RFU_79 |
| 80 | RFU | 3GPP TS 11.14, 5 | R96 | Х | | PD_RFU_80 |
| 81 | Maximum number of soft keys available ('FF' = RFU) | 3GPP TS 11.14, 5 | R99 | C214 | | PD_Max_SoftKey |
| 82 | Maximum number of soft keys available ('FF' = RFU) | 3GPP TS 11.14, 5 | R99 | C214 | | PD_Max_SoftKey |
| 83 | Maximum number of soft keys available ('FF' = RFU) | 3GPP TS 11.14, 5 | R99 | C214 | | PD_Max_SoftKey |
| 84 | Maximum number of soft keys available ('FF' = RFU) | 3GPP TS 11.14, 5 | R99 | C214 | | PD_Max_SoftKey |
| 85 | Maximum number of soft keys available ('FF' = RFU) | 3GPP TS 11.14, 5 | R99 | C214 | | PD_Max_SoftKey |
| 86 | Maximum number of soft keys available ('FF' = RFU) | 3GPP TS 11.14, 5 | R99 | C214 | | PD_Max_SoftKey |
| 87 | Maximum number of soft keys available ('FF' = RFU) | 3GPP TS 11.14, 5 | R99 | C214 | | PD_Max_SoftKey |
| 88 | Maximum number of soft keys available ('FF' = RFU) | 3GPP TS 11.14, 5 | R99 | C214 | | PD_Max_SoftKey |
| 89 | OPEN CHANNEL | 3GPP TS 11.14, 5 | R99 | C223 | | PD_Open_Ch |
| 90 | CLOSE CHANNEL | 3GPP TS 11.14, 5 | R99 | C223 | | PD_Close_Ch |
| 91 | RECEIVE DATA | 3GPP TS 11.14, 5 | R99 | C223 | | PD_Rx_Data |
| 92 | SEND DATA | 3GPP TS 11.14, 5 | R99 | C223 | | PD_Send_Data |
| 93 | GET CHANNEL STATUS | 3GPP TS 11.14, 5 | R99 | C223 | | PD_Get_Ch_Status |
| 94 | RFU | 3GPP TS 11.14, 5 | R96 | Х | | PD_RFU_94 |
| 95 | RFU | 3GPP TS 11.14, 5 | R96 | Χ | | PD_RFU_95 |
| 96 | RFU | 3GPP TS 11.14, 5 | R96 | Х | | PD_RFU_96 |
| 97 | CSD supported by ME | 3GPP TS 11.14, 5 | R99 | C207 | | PD_CSD |
| 98 | GPRS supported by ME | 3GPP TS 11.14, 5 | R99 | C222 | | PD_GPRS |
| 99 | RFU | 3GPP TS 11.14, 5 | R96 | Х | | PD_RFU_99 |
| 100 | RFU | 3GPP TS 11.14, 5 | R96 | X | | PD_RFU_100 |
| 101 | RFU | 3GPP TS 11.14, 5 | R96 | X | | PD_RFU_101 |
| 102 | Number of channels supported by ME | 3GPP TS 11.14, 5 | R99 | C227 | | PD_Nb_Channel |
| 103 | Number of channels supported by ME | 3GPP TS 11.14, 5 | R99 | C227 | | PD_Nb_Channel |
| 104 | Number of channels supported by ME | 3GPP TS 11.14, 5 | R99 | C227 | | PD_Nb_Channel |
| 105 | Number of characters supported down the ME | 3GPP TS 11.14, 5 | R99 | C217 | | PD_Nb_Char |
| 106 | Number of characters supported down the ME | 3GPP TS 11.14, 5 | R99 | C217 | | PD_Nb_Char |
| 107 | Number of characters supported down the ME | 3GPP TS 11.14, 5 | R99 | C217 | | PD_Nb_Char |
| 108 | Number of characters supported down the ME | 3GPP TS 11.14, 5 | R99 | C217 | | PD_Nb_Char |
| 109 | Number of characters supported down the ME | 3GPP TS 11.14, 5 | R99 | C217 | | PD_Nb_Char |
| 110 | RFU | 3GPP TS 11.14, 5 | R96 | X | | PD_RFU_110 |
| 111 | RFU | 3GPP TS 11.14, 5 | R96 | X | | PD_RFU_111 |
| 112 | Screen Sizing Parameters | 3GPP TS 11.14, 5 | R99 | C216 | | PD_Screen_Siz |
| 113 | Number of characters supported across the ME display | 3GPP TS 11.14, 5 | R99 | C217 | | PD_Nb_Char_Disp |
| 114 | Number of characters supported across the ME display | 3GPP TS 11.14, 5 | R99 | C217 | | PD_Nb_Char_Disp |
| 115 | Number of characters supported across the ME display | 3GPP TS 11.14, 5 | R99 | C217 | | PD_Nb_Char_Disp |

| Item | Terminal Profile | Ref. | Release | Status | Support | Mnemonic |
|-------|-----------------------------------|--------------------------------------|------------|------------|---------|------------------|
| 116 | Number of characters | 3GPP TS 11.14, 5 | R99 | C217 | | PD_Nb_Char_Disp |
| | supported across the ME | | | | | |
| | display | | | | | |
| 117 | Number of characters | 3GPP TS 11.14, 5 | R99 | C217 | | PD_Nb_Char_Disp |
| | supported across the ME | | | | | |
| 440 | display Number of characters | 2000 TC 44 44 5 | DOO | 0047 | | DD NIb Char Dian |
| 118 | supported across the ME | 3GPP TS 11.14, 5 | R99 | C217 | | PD_Nb_Char_Disp |
| | display | | | | | |
| 119 | Number of characters | 3GPP TS 11.14, 5 | R99 | C217 | | PD_Nb_Char_Disp |
| | supported across the ME | | | | | = |
| | display | | | | | |
| 120 | Variable size fonts | 3GPP TS 11.14, 5 | R99 | C217 | | PD_Var_Font |
| | Supported | | | | | |
| 121 | Display can be resized | 3GPP TS 11.14, 5 | R99 | C218 | | PD_Disp_Resiz |
| 122 | Text Wrapping supported | 3GPP TS 11.14, 5 | R99 | C218 | | PD_Txt_Wrap |
| 123 | Text Scrolling supported | 3GPP TS 11.14, 5 | R99 | C218 | | PD_Txt_Scroll |
| 124 | RFU | 3GPP TS 11.14, 5 | R96 | X | | PD_RFU_124 |
| 125 | RFU | 3GPP TS 11.14, 5 | R96 | X | | PD_RFU_125 |
| 126 | Width reduction when in a | 3GPP TS 11.14, 5 | R99 | C217 | | PD_Width_Reduc |
| 127 | menu Width reduction when in a | 3GPP TS 11.14, 5 | R99 | C217 | | PD_Width_Reduc |
| 127 | menu | 3GPF 13 11.14, 5 | K99 | 0217 | | PD_Widin_Reduc |
| 128 | Width reduction when in a | 3GPP TS 11.14, 5 | R99 | C217 | | PD_Width_Reduc |
| 120 | menu | | 1100 | 0217 | | D_Widii_Roddo |
| 129 | TCP | 3GPP TS 11.14, 5 | R99 | C220 | | PD TCP |
| 130 | UDP | 3GPP TS 11.14, 5 | R99 | C221 | | PD_UDP |
| 131 | RFU | 3GPP TS 11.14, 5 | R96 | Х | | PD_RFU_131 |
| 132 | RFU | 3GPP TS 11.14, 5 | R96 | Х | | PD_RFU_132 |
| 133 | RFU | 3GPP TS 11.14, 5 | R96 | Х | | PD_RFU_133 |
| 134 | RFU | 3GPP TS 11.14, 5 | R96 | Х | | PD_RFU_134 |
| 135 | RFU | 3GPP TS 11.14, 5 | R96 | X | | PD_RFU_135 |
| 136 | RFU | 3GPP TS 11.14, 5 | R96 | X | | PD_RFU_136 |
| 137 | RFU | 3GPP TS 11.14, 5 | R96 | X | | PD_RFU_137 |
| 138 | RFU | 3GPP TS 11.14, 5 | R96 | X | | PD_RFU_138 |
| 139 | RFU | 3GPP TS 11.14, 5 | R96 | X | | PD_RFU_139 |
| 140 | RFU | 3GPP TS 11.14, 5 | R96 | Х | | PD_RFU_140 |
| 141 | RFU | 3GPP TS 11.14, 5 | R96 | Х | | PD_RFU_141 |
| 142 | RFU | 3GPP TS 11.14, 5 | R96 | X | | PD_RFU_142 |
| | RFU | 3GPP TS 11.14, 5 | R96 | X | | PD_RFU_143 |
| | RFU Protection | 3GPP TS 11.14, 5 | R96 | X | | PD_RFU_144 |
| 145 | Protocol Version | 3GPP TS 11.14, 5 | R99 | TBD | | |
| 146 | Protocol Version | 3GPP TS 11.14, 5 3GPP TS 11.14, 5 | R99 | TBD | | |
| 147 | Protocol Version Protocol Version | 3GPP TS 11.14, 5 | R99 R99 | TBD TBD | | |
| 148 | RFU | 3GPP TS 11.14, 5 | R99 R96 | X | | PD RFU 149 |
| 150 | RFU | 3GPP TS 11.14, 5 | R96 | X | | PD_RFU_150 |
| 151 | RFU | 3GPP TS 11.14, 5 | R96 | X | | PD_RFU_151 |
| 152 | RFU | 3GPP TS 11.14, 5 | R96 | X | | PD_RFU_152 |
| C201 | Void | 10011 10 11.14, 0 | 1130 | Vc | nid | D_I(I U_IUZ |
| C201 | Void | | | Vc | | |
| 10202 | VOIG | | | VC | | |

| Item | Terminal Profile | Ref. | Release | Status | Support | Mnemonic |
|------|-----------------------|------------------------|---------------|--------|--------------|------------------|
| C203 | IF A.1/3 THEN M | | | O_ | Ucs2_Entry | / |
| C204 | IF A.1/15 THEN M | | | O_ | Ucs2_Disp | |
| C205 | IF A.1/4 THEN M | | | O_ | _Ext_Str | |
| C206 | IF A.1/7 THEN M | | | O_ | _Dual_Slot | |
| C207 | IF A.1/12 THEN M | | | O_ | BIP_CSD | |
| C208 | IF (A.1/7 AND A.1/ | 8) THEN M | | O_ | _Dual_Slot A | AND O_Detach_Rdr |
| C209 | IF A.1/9 THEN M | | | O_ | _Run_At | |
| C210 | IF A.1/1 THEN M | | | O_ | _Cap_Conf | |
| C211 | IF A.1/2 THEN M | | | O_ | _sust_text | |
| C212 | IF A.1/10 THEN M | | | O_ | _LB | |
| C213 | IF A.1/11 THEN M | for at least one of th | e bits 1 - 2 | of O_ | Softkey | |
| | byte 10 | | | | | |
| C214 | IF C213 THEN M fo | or at least one, but n | ot for all of | the O_ | Softkey (pa | arameters) |
| | bits 1 - 8 of byte 11 | | | | | |
| C215 | Void | | | Vo | id | |
| C216 | IF A.1/13 THEN M | | | O_ | _Scr_Siz | |
| C217 | IF C216 THEN bit v | values "0" / "1" allow | ed | O_ | _Scr_Siz (pa | arameters) |
| C218 | IF A.1/14 THEN M | | | O_ | _Scr_Resiz | |
| C219 | IF C218 THEN bit v | values "0" / "1" allow | ed | O_ | Scr_Resiz | (parameters) |
| C220 | IF A.1/18 THEN M | | | O_ | TCP | |
| C221 | IF A.1/17 THEN M | | | O_ | _UDP | |
| C222 | IF A.1/21 THEN M | | | O_ | BIP_GPRS | |
| C223 | IF (C207 OR C222 |) THEN MIF A.1/27 | THEN M | O_ | BIP_CSD (| OR O_BIP_GPRS |
| C224 | IF A.1/28 THEN M | | | O_ | 9EXX | |
| C225 | IF A.1/29 THEN M | | | | _CC_Auto_F | |
| C226 | IF (C207 OR C222 |) THEN M for at leas | t one of the | e O_ | _SetUp_Call | I_Sec_Alpha_Id |
| C227 | bits 6 - 8 of byte 13 | 3 | | O_ | BIP_CSD (| OR O_BIP_GPRS |

Comments:

This static requirement for the TERMINAL PROFILE is specifying the bit coding of this command. In the support column a "Yes" (or "Y" or "y") means bit coding "1" and a "No" (or "N" or "n") and "X" means bit coding "0" in the command.

Annex F (informative): Change History

| | Meeti ng/Da te | WG doc | CR | Rev | Subject | New Ver |
|--|----------------------|--------|-------|----------------|--|---------|
| A001 Corrections to SIM Application Toolkit Test Specification 5.1.0 | | | - | | Approved as release 1996 at SMG#30 | 5.0.0 |
| A002 Editorial and coding corrections A003 A004 Correction for Very Congress of State (1988) A004 Corrections for Test Case 27.22.5.1 (SMS-PP Data Download) A004 Corrections for Test Case 27.22.5.1 (SMS-PP Data Download) A005 Corrections for Test Case 27.22.4.7 (REFRESH) A006 Corrections for Test Case 27.22.5.2 (SMS-CB Data Download) A007 Corrections for Test Case 27.22.5.2 (SMS-CB Data Download) A008 Upgrade of the MS SAT test specification to Release 99 A010 A010 Addition of Terminal Profile information, suppression of PLAV TONE A011 References to 11.0-1 replaced. Reference to 11.10-2 removed. A012 Corrections to Send Short Message, Sequence 1.4 A013 References to 11.0-1 replaced. Reference to 11.10-2 removed. A016 Corrections to Send Short Message, Sequence 1.4 A017 Corrections to Send Short Message, Sequence 1.4 A018 A019 Corrections to Send Short Message, Sequence 1.4 A019 Corrections to Terminal Response. Set Up Call 1.7.1 B4.0 A010 Correction to Terminal Response. Set Up Call 1.7.1 B4.0 A011 Correction to Terminal Response Form user' B4.0 A016 Correction of Emergency Call test cases B4.0 A017 Essential corrections to Selfaul Values for SIM Application Toolkit B4.0 B4.0 B4.0 B4.0 B4.0 B4.0 B4.0 B4.0 | | | A001 | | Corrections to SIM Application Toolkit Test Specification | 5.1.0 |
| A003 Correction of wrong coding for SIM Application Toolkit test 27.22.4.2 S.3.0 A006 Correction of wrong coding for SIM Application Toolkit 27.22 S.4.0 A006 Correction for Test Case 27.22.4.7 (REFRESH) S.5.0 A007 Corrections for Test Case 27.22.4.7 (REFRESH) S.5.0 A007 Corrections for Test Case 27.22.4.7 (REFRESH) S.5.0 A008 Upgrade of the MS SAT test specification to Release 99 8.1.0 A010 Upgrade of the MS SAT test specification to Release 99 8.1.0 A010 Addition of Terminal Profile information, suppression of PLAY TONE 1 Test sequence 1.2 Addition of Terminal Profile information, suppression of PLAY TONE 8.2.0 A011 References to 11.10-1 replaced. Reference to 11.10-2 removed. 8.3.0 A012 Corrections to Send Short Message, Sequence 1.4 A013 Reddal in Set Up Call A013 Reddal in Set Up Call A014 Correction to Terminal Response: Set Up Call 1.7.1 B.4.0 A015 Select Item: Support of "No response from user" B.4.0 A016 Correction of Terminal Response: Set Up Call 1.7.1 B.4.0 A017 Essential corrections to default values for SIM Application Toolkit testing B.4.0 B.4. | | | | | | |
| A004 Corrections for Test Case 27.22.5.1 (SMS-PP Data Download) 5.3.0 A006 Corrections for Test Case 27.22.5.7 (MEFRESH) 5.5.0 A007 Corrections for Test Case 27.22.5.7 (MEFRESH) 5.5.0 A008 Upgrade of the MS SAT test specification to Release 99 8.1.0 A0107 Addition of Terminal Profile information, suppression of PLAY TONE 2.0 1 Test sequence 1.2 Addition of Terminal Profile information, suppression of PLAY TONE 3.0 A0112 Corrections to Send Short Message, Sequence 1.4 8.4.0 A012 Corrections to Send Short Message, Sequence 1.4 8.4.0 A013 Redial in Set Up Call 8.4.0 A014 Correction to Terminal Response: Set Up Call 1.7.1 8.4.0 A015 Select Item: Support of "Yor response from user" 8.4.0 A016 Correction to Terminal Response: Set Up Call 1.7.1 8.4.0 A016 Correction of Emergency Call test cases 8.4.0 A017 Essential corrections to Display text test cases 8.5.0 A018 Essential corrections to Display text test cases 8.5.0 A019 Essential corrections to Display text test cases 8.5.0 A020 Essential corrections to Get Inkey test cases 8.5.0 A021 Essential corrections to Play Tone test cases 8.5.0 A022 Essential corrections to Play Tone test cases 8.5.0 A023 Essential corrections to Play Tone test cases 8.5.0 A024 Essential corrections to Play Tone test cases 8.5.0 A025 Essential corrections to Play Tone test cases 8.5.0 A026 Essential corrections to Play Tone test cases 8.5.0 A027 Essential corrections to Play Tone test cases 8.5.0 A028 Essential corrections to Play Tone test cases 8.5.0 A029 Essential corrections to Send Short message test cases 8.5.0 A020 Essential corrections to Send Short message test cases 8.5.0 A021 Essential corrections to Send District test cases 8.5.0 A022 Essential corrections to Send Use Additional test cases 8.5.0 A023 Essential corrections to Send District test cases 8.5.0 A024 Essential corrections to Send Distri | | | | | | |
| A006 | | | | | | |
| A006 Corrections for Test Case 27 22.4.7 (REFRESH) A007 Corrections for Test Case 27 22.4.2 (SIGMS-CD Data Download) A008 Upgrade of the MS SAT test specification to Release 99 A010 Addition of Terminal Profile information, suppression of PLAY TONE A011 References to 11.10-1 replaced. Reference to 11.10-2 removed. A012 Corrections to Send Short Message, Sequence 1.4 A013 References to 11.10-1 replaced. Reference to 11.10-2 removed. A014 Correction to Send Short Message, Sequence 1.4 A015 Redial in Set Up Call A014 Correction to Terminal Response: Set Up Call 1.7.1 A016 Correction to Terminal Response: Set Up Call 1.7.1 A016 Correction to Terminal Response: Set Up Call 1.7.1 A017 Select Item: Support of "No response from user" A018 Case Correction to Terminal Response: Set Up Call 1.7.1 A019 Essential corrections to Display text test cases Clarification on comprehension required flag usage A019 Essential corrections to Display text test cases A021 - Sesential corrections to Display text test cases A021 - Sesential corrections to Get Input test cases A022 Essential corrections to Get Input test cases A023 Essential corrections to Polling of text cases A024 Essential corrections to Polling of text cases A025 - Essential corrections to Polling of text cases A026 Essential corrections to Polling of text case A027 - Essential corrections to Polling of text case A028 Essential corrections to Polling of text cases A029 Essential corrections to Send Short message test cases A029 Essential corrections to Send Short message test cases A029 Essential corrections to Send Short message test cases A029 Essential corrections to Send District Case A020 Essential corrections to Send Use A020 Essential corrections to Send Short message test cases A029 Essential corrections to Send Use A020 Essential corrections to Send Short message test cases A029 Essential corrections to Send District Case A020 Essential corrections to Send Short Message A020 Essential corrections to Send Box A020 Essential corrections to Send Short A020 Essent | | | | | | |
| A007 Corrections for Test Case 27 22.5.2 (SMS-CB Data Download) 5.5.0 A010 A010 In Mac MS SAT test specification to Release 99 8.1.0 A011 Addition of Terminal Profile information, suppression of PLAY TONE 1 Test sequence 1.2 A011 References to 11.10-1 replaced. Reference to 11.10-2 removed. 8.3.0 A012 Corrections to Send Short Message, Sequence 1.4 8.4.0 A013 Redial in Set Up Call 8.4.0 A014 Correction to Terminal Response; Set Up Call 1.7.1 8.4.0 A015 Select tem: Support of 'No response from user' 8.4.0 A016 Correction of Terminal Response; Set Up Call 1.7.1 8.4.0 A016 Select tem: Support of 'No response from user' 8.4.0 A017 Essential corrections to default values for SIM Application Toolkit lesting A018 - Clarification on comprehension required flag usage 8.5.0 A019 Essential corrections to Bet Inkey test cases A020 Essential corrections to Get Inkey test cases A020 Essential corrections to Get Inkey test cases A021 Essential corrections to Set Up Menu test cases A022 Essential corrections to Foll Interval test cases A022 Essential corrections to Foll Interval test cases A023 Essential corrections to Poll Interval test cases A024 Essential corrections to Poll Interval test cases A025 Essential corrections to Poll Interval test cases A026 Essential corrections to Poll Interval test cases A027 Essential corrections to Poll Interval test cases A028 Essential corrections to Poll Interval test cases A029 Essential corrections to Poll Interval test cases A029 Essential corrections to Set Up Call test cases A029 Essential corrections to Set Up Call test cases A030 Essential corrections to Set Up Call test cases A030 Essential corrections to Set Up Call test cases A030 Essential corrections to Set Up Call test cases A030 Essential corrections to Set Up Call test cases A030 Essential corrections to Set Up Call test cases A030 Essential corrections to Set Option Card APDU test cases A030 Essential corrections to Set Option Card APDU test cases A030 Essential corrections to Set Option Card APDU test cases A030 Essentia | | | | | | |
| A008 Upgrade of the MS SAT test specification to Release 99 | | | | | | |
| A010r Addition of Terminal Profile Information, suppression of PLAY TONE 1 Test sequence 1.2 Test sequence 1.2 Test sequence 1.4 References to 11.10-2 removed. 8.3.0 A011 References to 11.10-1 replaced. Reference to 11.10-2 removed. 8.3.0 A013 Redial in Set Up Call Reference to 11.10-2 removed. 8.4.0 A013 Redial in Set Up Call Correction to Terminal Response: Set Up Call 1.7.1 8.4.0 A015 Select item: Support of "No response from user" 8.4.0 A015 Select item: Support of "No response from user" 8.4.0 A016 Correction of Emergency Call test cases 8.4.0 A017 Essential corrections to default values for SIM Application Toolkit selfing. A018 Clarification on comprehension required flag usage 8.5.0 A019 Essential corrections to Display test test cases A021 Essential corrections to Display test test cases A022 Essential corrections to Set Input test cases A022 Essential corrections to Get Input test cases A022 Essential corrections to Fel Inkey test cases A022 Essential corrections to Fel Inkey test cases A022 Essential corrections to Poll Interval test cases A022 Essential corrections to Polling off test case A025 Essential corrections to Polling off test case A026 Essential corrections to Provide Local Information test cases 8.5.0 A027 Essential corrections to Send Shot message test cases 8.5.0 A028 Essential corrections to Send Shot message test cases 8.5.0 A029 Essential corrections to Send Shot Test set cases A033 Essential corrections to Send USB test cases A033 Essential corrections to Reduce A034 Essential cor | | | | | | |
| A011 References to 11.10-1 replaced. Reference to 11.10-2 removed. 8.3.0 A012 Corrections to Send Shrot Message, Sequence 1.4 A013 Redial in Set Up Call A014 Correction to Terminal Response: Set Up Call 1.7.1 B. 4.40 A015 Select term: Support of "No response from user" A016 Correction of Emergency Call test cases B. 4.0 A017 Essential corrections to default values for SIM Application Toolkit testing Correction of Emergency Call test cases A017 Essential corrections to default values for SIM Application Toolkit testing A018 - Clarification on comprehension required flag usage A020 Essential corrections to Delpay test test cases A021 - Essential corrections to Get Inkey test cases A021 - Essential corrections to Get Inkey test cases A022 Essential corrections to Get Input test cases A023 Essential corrections to Get Input test cases A024 Essential corrections to Poll Interval test cases A025 - Essential corrections to Poll Interval test cases A026 Essential corrections to Poll Interval test cases A027 - Essential corrections to Polling off test case A027 - Essential corrections to Polling off test case A028 - Essential corrections to Polling off test case A029 - Essential corrections to Ranguage Notification test cases A039 - Essential corrections to Ranguage Notification test cases A039 - Essential corrections to Send Shot message test cases A039 - Essential corrections to Send Shot message test cases A039 - Essential corrections to Send Shot Text test cases A039 - Essential corrections to Send Status test cases A039 - Essential corrections to Send District Rest cases A039 - Essential corrections to Send Status test cases A039 - Essential corrections to Send District Rest cases A039 - Essential corrections to Rest Up Call test cases A039 - Essential corrections to Rest Up Call test cases A039 - Essential corrections to Call CoNTROL BY SIM (Interaction with FDW) By | | | | | | |
| A012 Corrections to Send Short Message, Sequence 1.4 8.4.0 A013 Redai an Set Up Call 8.4.0 A014 Correction to Terminal Response: Set Up Call 1.7.1 A015 Select term Support of Two response from user* 8.4.0 A016 Correction of Emergency Call test cases B.4.0 A017 Essential corrections to default values for SIM Application Toolkit setting A018 Essential corrections to default values for SIM Application Toolkit setting A018 Essential corrections to Display text test cases A020 Essential corrections to Display text test cases A020 Essential corrections to Display text test cases A021 Essential corrections to Set Input test cases A022 Essential corrections to Set Up Menu test cases A022 Essential corrections to Set Up Menu test cases A023 Essential corrections to Poll Intervall test cases A024 Essential corrections to Poll Intervall test cases A024 Essential corrections to Poll Intervall test cases A026 Essential corrections to Poll Intervall test case A027 Essential corrections to Poll Intervall test case A028 Essential corrections to Poll Intervall test cases A029 Essential corrections to Poll Intervall test cases A020 Essential corrections to Essent Set Set Set Set Set Set Set Set Set Se | | | 1 | | Test sequence 1.2 | |
| A013 Redial in Set Up Call A014 Correction to Terminal Response: Set Up Call 1.7.1 8.4.0 A015 Select tem: Support of "No response from user" 8.4.0 A016 Correction of Emergency Call test cases 8.4.0 A017 Essential corrections to default values for SIM Application Toolkit testing A018 Clarification on comprehension required flag usage 8.5.0 A019 Essential corrections to default values for SIM Application Toolkit testing A019 Essential corrections to Display test test cases A020 Essential corrections to Get Input test cases A021 - Essential corrections to Get Input test cases A022 Essential corrections to Get Input test cases A023 Essential corrections to Get Input test cases A024 Essential corrections to Play Tone test cases A025 Essential corrections to Play Tone test cases A026 Essential corrections to Play Tone test cases A027 Essential corrections to Play Tone test cases A028 Essential corrections to Play Tone test cases A029 Essential corrections to Play Tone test cases A020 Essential corrections to Provide Local Information test cases 8.5.0 A021 Essential corrections to Send Short message test cases 8.5.0 A022 Essential corrections to Send Short message test cases 8.5.0 A023 Essential corrections to Send Short message test cases 8.5.0 A029 Essential corrections to Send Sb Set cases A030 Essential corrections to Send Sb Set cases A031 Essential corrections to Send Up Call test cases A032 Essential corrections to Send Up Call test cases A033 Essential corrections to Send Up Call test cases A034 Essential corrections to Cand Up Call test cases A035 Essential corrections to Cand Up Call test cases A036 Essential corrections to Call Control Call Call Control Call Call Control Call Call Call Call Call Call Call Ca | | | | | References to 11.10-1 replaced. Reference to 11.10-2 removed. | |
| A014 Correction to Terminal Responses: Set Up Call 1.7.1 8.4.0 A015 Select Item: Support of Two responses from user? 8.4.0 A016 Correction of Emergency Call test cases 8.4.0 A017 Essential corrections to default values for SIM Application Toolkit losting. A018 Careful Careful Call Call Call Call Call Call Call Ca | | | | | | |
| A016 Select Item: Support of "No response from user" 8.4.0 A016 Correction of Emergency Call test cases 8.4.0 A017 Essential corrections to default values for SIM Application Toolkit testing 1.4.0 A018 Clarification on comprehension required flag usage 8.5.0 A019 Essential corrections to Display text test cases A020 Essential corrections to Get Inkey text test cases A021 Essential corrections to Get Inkey test cases A021 Essential corrections to Get Inkey test cases A022 Essential corrections to Set Up Menu test cases A023 Essential corrections to Set Up Menu test cases A023 Essential corrections to Set Up Menu test cases A024 Essential corrections to Poll Interval Itest cases A025 Essential corrections to Poll Interval Itest cases A026 Essential corrections to Poll Interval Itest cases A027 Essential corrections to Provide Local Information test cases 8.5.0 A028 Essential corrections to Language Notification test cases 8.5.0 A029 Essential corrections to Set Up Set Up Call Itest cases A030 Essential corrections to Set Up Call Itest cases A030 Essential corrections to Set Up Call Itest cases A031 Essential corrections to Set Up Call Itest cases A032 Essential corrections to Set Up Call Itest cases A033 Essential corrections to Set Up Call Itest cases A034 Essential corrections to Set Up Call Itest cases A035 Essential corrections to Set Up Call Itest cases A036 Essential corrections to Set Up Call Itest cases A037 Essential corrections to Set Up Call Itest cases A038 Essential corrections to Call Loon ITER Call Itest Cases A039 Essential corrections to Call Item Call It | | | | | | |
| A016 Correction of Emergency Call test cases A017 Essential corrections to default values for SIM Application Toolkit testing A018 - Clarification on comprehension required flag usage 8.5.0 A019 Essential corrections to Display text test cases A020 Essential corrections to Get Inkey test cases A021 Essential corrections to Get Inkey test cases A022 Essential corrections to Get Input test cases A022 Essential corrections to Get Input test cases A023 Essential corrections to Set Up Menu test cases A024 Essential corrections to Play Tone test cases A025 Essential corrections to Poll Intervall test case A026 Essential corrections to Poll Intervall test case A027 Essential corrections to Poll Intervall test case A028 Essential corrections to Polling off test cases A029 Essential corrections to Send Short message test cases A020 Essential corrections to Send Short message test cases A021 Essential corrections to Send Short message test cases A022 Essential corrections to Send Short message test cases A023 Essential corrections to Send Set Up Call Intervall test cases A030 Essential corrections to Send Up Call Intervall test cases A031 Essential corrections to Set Up Call Intervall test cases A032 Essential corrections to Set Up Call Intervall test cases A033 Essential corrections to Set Up Call Intervall test cases A033 Essential corrections to Power Off Card test cases A034 Essential corrections to Power Off Card test cases A035 Essential corrections to Send DTMF test cases A036 Essential corrections to CALL CONTROL BY SIM fest cases A037 Essential corrections to CALL CONTROL BY SIM fest cases A038 Essential corrections to CALL CONTROL BY SIM fest cases A039 Essential corrections to CALL CONTROL BY SIM fest cases A040 Essential corrections to Card reader status event download test cases A041 Essential corrections to Card reader status event download test cases A042 Essential corrections to Card reader status event download test cases A044 Essential corrections to Card reader status event download test cases A044 E | | | | | | |
| A017 Essential corrections to default values for SIM Application Toolkit testing A018 - Clarification on comprehension required flag usage 8.5.0 A019 Essential corrections to Display text test cases A020 Essential corrections to Get Inkey test cases A021 - Essential corrections to Get Inkey test cases A022 - Essential corrections to Set Up Menu test cases A023 Essential corrections to Set Up Menu test cases A024 Essential corrections to Set Up Menu test cases A025 - Essential corrections to Poll Interval test cases A026 - Essential corrections to Poll Interval test cases A027 - Essential corrections to Poll Interval test cases A027 - Essential corrections to Provide Local Information test cases A027 - Essential corrections to Send Short message test cases A028 - Essential corrections to Send Short message test cases A029 - Essential corrections to Send Short message test cases A030 - Essential corrections to Send Short message test cases A030 - Essential corrections to Send Short message test cases A030 - Essential corrections to Send USD test cases A030 - Essential corrections to Send USD test cases A031 - Essential corrections to Send USD test cases A032 - Essential corrections to Send USD test cases A033 - Essential corrections to Send USD test cases A034 - Essential corrections to Send USD test cases A035 - Essential corrections to Send USD test cases A036 - Essential corrections to Send DEMP test cases A037 - Essential corrections to Send DEMP test cases A038 - Essential corrections to Send DEMP test cases A039 - Essential corrections to Send DEMP test cases A039 - Essential corrections to Send DEMP test cases A039 - Essential corrections to Send DEMP test cases A039 - Essential corrections to Send DEMP test cases A039 - Essential corrections to Send DEMP test cases A039 - Essential corrections to Send DEMP test cases A040 - Essential corrections to Send DEMP test cases A040 - Essential corrections to Send DEMP test cases A040 - Essential corrections to CALL CONTROL BY SIM (Interaction with FDN/ BDN/ BDN/ | | | | | | |
| Lesting | | | | | | 8.4.0 |
| A019 Essential corrections to Display text test cases A021 - Essential corrections to Get Inkey test cases A021 - Essential corrections to Get Inkey test cases A022 Essential corrections to Set Up Menu test cases A023 Essential corrections to Play Tone test cases A024 Essential corrections to Play Tone test cases A025 - Essential corrections to Polling first test case A026 - Essential corrections to Polling first test case A027 - Essential corrections to Polling first test case A028 - Essential corrections to Polling first test cases A029 - Essential corrections to Send Short message test cases A030 - Essential corrections to Send Solt message test cases A030 - Essential corrections to Send Solt message test cases A030 - Essential corrections to Send Solt test cases A030 - Essential corrections to Send Display test cases A031 - Essential corrections to Send USSD test cases A032 - Essential corrections to Send USSD test cases A033 - Essential corrections to Send USSD test cases A034 - Essential corrections to Send USSD test cases A035 - Essential corrections to Perform Card APDU test cases A036 - Essential corrections to Perform Card APDU test cases A037 - Essential corrections to Dever Off Card test cases A038 - Essential corrections to Send DTMF test cases A039 - Essential corrections to CALL CONTROL BY SIM (Interaction with FDN BDN) test cases A039 - Essential corrections to CALL CONTROL BY SIM (Interaction with FDN BDN) test cases A040 - Essential corrections to Local reader status event download test cases A040 - Essential corrections to Laurch Browser test cases A040 - Essential corrections to Laurch Browser test cases A041 - Essential corrections to Laurch Browser test cases A042 - Essential corrections to Laurch Browser test cases A043 - Essential corrections to Card reader status event download test cases A044 - Essential corrections to Laurch Browser test cases A045 - Essential corrections to Card reader status event download test cases A046 - Essential corrections to Card reader status event download | | | | | testing | |
| A020 | | | | - | | 8.5.0 |
| A021 - Essential corrections to Get Input test cases | | | | | | |
| A022 Essential corrections to Pal Up Menu test cases A024 Essential corrections to Poll Intervall test case A025 Essential corrections to Poll Intervall test case A026 Essential corrections to Poll Intervall test case A027 Essential corrections to Provide Local Information test cases 8.5.0 A027 Essential corrections to Provide Local Information test cases 8.5.0 A028 Essential corrections to Send Short message test cases 8.5.0 A029 Essential corrections to Language Notification test cases 8.5.0 A030 Essential corrections to Send Stest cases A030 Essential corrections to Send Up Call test cases A031 Essential corrections to Send Up Call test cases A032 Essential corrections to Send Up Call test cases A033 Essential corrections to Experiment of Card Local Call Call Call Call Call Call Call C | | | | | | |
| A023 Essential corrections to Poll Intervall test case A024 Essential corrections to Poll Intervall test case A025 Essential corrections to Polling off test case A026 Essential corrections to Polling off test cases A027 Essential corrections to Polling off test cases A028 Essential corrections to Send Short message test cases A029 Essential corrections to Send Short message test cases A029 Essential corrections to Send Short message test cases A030 Essential corrections to Send St test cases A030 Essential corrections to Send St test cases A031 Essential corrections to Send USSD test cases A032 Essential corrections to Send USSD test cases A032 Essential corrections to Send USSD test cases A033 Essential corrections to Send USSD test cases A034 Essential corrections to Polle Mode Text test cases A035 Essential corrections to Perform Card APDU test cases A036 Essential corrections to Perform Card APDU test cases A037 Essential corrections to Send DTMF test cases A037 Essential corrections to CALL CONTROL BY SIM test cases A037 Essential corrections to CALL CONTROL BY SIM (Interaction with FDN/ BDN) test cases A039 Essential corrections to CALL CONTROL BY SIM (Interaction with FDN/ BDN) test cases A040 Essential corrections to Inanual pages selection and browser termination event download test cases A040 Essential corrections to Call control test cases A040 Essential corrections to Call control test cases A041 - Essential corrections to Control test cases A042 Essential corrections to Dender test cases A043 Essential corrections to Dender test cases A044 Essential corrections to Dender test cases A045 Essential corrections to Call control test cases A046 Essential corrections to Call control test cases A047 Essential corrections to Dender test cases A048 Essential corrections to Dender test cases A049 Essential corrections to Dender test cases A040 Essential corrections to Call control test cases A040 Essential corrections to Call control test cases A040 Essential corrections to Call control test cases A040 Essen | | | | - | | 8.5.0 |
| A024 Essential corrections to Poll Intervall test case A026 Essential corrections to Polling off test case 8.5.0 | | | | | | |
| A025 Essential corrections to Polling off test case | | | | | | |
| A026 Essential corrections to Provide Local Information test cases 8.5.0 | | | | _ | | 850 |
| A027 Essential corrections to Send Short message test cases 8.5.0 | | | | 1 | | |
| A028 Essential corrections to Send SS test cases A030 Essential corrections to Send SS test cases A031 Essential corrections to Send USSD test cases A031 Essential corrections to Send USSD test cases A032 Essential corrections to Send USSD test cases A033 Essential corrections to Send USSD test cases A033 Essential corrections to Power Off Card test case A034 Essential corrections to Power Off Card test case A034 Essential corrections to Perform Card APDU test cases A036 Essential corrections to Perform Card APDU test cases A036 Essential corrections to Send DTMF test cases A037 Essential corrections to Send DTMF test cases A038 Essential corrections to CALL CONTROL BY SIM fest cases A039 Essential corrections to CALL CONTROL BY SIM (Interaction with FDN/ BDN/ BDN) test cases A040 Essential corrections to Select Item test cases A040 Essential corrections to card reader status event download test cases A041 Essential corrections to card reader status event download test cases A042 Essential corrections to Close Channel test cases A043 Essential corrections to Close Channel test cases A044 Essential corrections to Deen Channel test cases A045 Essential corrections to Deen Channel test cases A046 Essential corrections to Deen Channel test cases A046 Essential corrections to Deen Channel test cases A047 Essential corrections to Deen Channel test cases A048 Essential corrections to Deen Channel test cases A049 Essential corrections to Death test cases A040 Ess | | | | - | | |
| A029 Essential corrections to Send SS test cases A030 Essential corrections to Set Up Call test cases A031 Essential corrections to Set Up Call test cases A032 Essential corrections to Send USSD test cases A032 Essential corrections to Power Off Card test cases A033 Essential corrections to Power Off Card test cases A034 Essential corrections to Power Off Card test cases A035 Essential corrections to Power Off Card test cases A036 Essential corrections to Get Reader Status test cases A037 Essential corrections to Send DTMF test cases A037 Essential corrections to CALL CONTROL BY SIM (Interaction with FDN/ BDN) test cases A038 Essential corrections to CALL CONTROL BY SIM (Interaction with FDN/ BDN) test cases A040 Essential corrections to CALL CONTROL BY SIM (Interaction with FDN/ BDN) test cases A040 Essential corrections to Card reader status event download test cases Essential corrections to card reader status event download test cases A041 Essential corrections to language selection and browser termination event download test cases A042 Essential corrections to Close Channel test cases A5.0 A044 Essential corrections to Deno Channel test cases A5.0 A044 Essential corrections to Deno Channel test cases A045 Essential corrections to Receive Data test cases A046 Essential corrections to Send Data test cases A047 Essential corrections to Send Data test cases A048 Essential corrections to Get Channel Status test cases A049 Essential corrections to Get Channel Status test cases A049 Essential corrections to CR data download test cases A049 Essential corrections to CR data download test cases A049 Essential corrections to CR data download test cases A050 Essential corrections to CR data download test cases A050 Essential corrections to CR data download test cases A050 Essential corrections to CR data download test cases A050 Essential corrections to CR data download test cases A050 Essen | | | | - | | |
| A031 Essential corrections to Send USSD test cases A032 Essential correction to Set Up Idle Mode Text test cases 8.5.0 A033 Essential corrections to Power Off Card test case A034 Essential corrections to Perform Card APDU test cases A035 Essential corrections to Perform Card APDU test cases A036 Essential corrections to Send DTMF test cases A037 Essential corrections to Send DTMF test cases A037 Essential corrections to CALL CONTROL BY SIM test cases A038 Essential corrections to CALL CONTROL BY SIM (Interaction with FDN/ BDN) test cases A039 Essential corrections to CALL CONTROL BY SIM (Interaction with FDN/ BDN) test cases A040 Essential corrections to Select Item test cases A040 Essential corrections to select Item test cases A041 Essential corrections to language selection and browser termination event download test cases A041 Essential corrections to Interactional test cases A042 Essential corrections to Close Channel test cases A043 Essential corrections to Dopen Channel test cases A044 Essential corrections to Dopen Channel test cases A045 Essential corrections to Dopen Channel test cases A046 Essential corrections to Send Data test cases A048 Essential corrections to Channel Status event download test case A049 Essential corrections to Channel Status test cases A049 Essential corrections to Cape Channel Status test cases A050 Essential corrections to Cape Channel Status test cases A050 Essential corrections to Cape Channel Status, user activity and idle screen available event download test cases A050 Essential corrections to Cape Channel Status, user activity and idle screen available event download test cases A050 Essential corrections to Cape Channel Status (with inclusion of T3-030535's contents) A051 Essential corrections to Cape Channel Status (with inclusion of T3-030535's contents) A052 Essential corrections to Cape Channel Status (with inclusion of T3-030535's contents) A053 Essent | | | | | | |
| A032 - Essential correction to Set Up Idle Mode Text test cases A034 Essential corrections to Power Off Card test cases A034 Essential corrections to Perform Card APDU test cases A035 Essential corrections to Get Reader Status test cases A036 Essential corrections to Send DTMF test cases A037 - Essential corrections to CALL CONTROL BY SIM test cases A038 - Essential corrections to CALL CONTROL BY SIM test cases A039 - Essential corrections to CALL CONTROL BY SIM (Interaction with FDN/ BDN) test cases A039 - Essential corrections to Select Item test cases A040 - Essential corrections to Select Item test cases A040 - Essential corrections to Card reader status event download test cases A041 - Essential corrections to language selection and browser termination event download test cases A042 - Essential corrections to Close Channel test cases A043 - Essential corrections to Launch Browser test cases A044 - Essential corrections to Launch Browser test cases A044 - Essential corrections to Dean Channel test cases A045 - Essential corrections to Receive Data test cases A046 - Essential corrections to Receive Data test cases A047 - Essential corrections to Send Data test cases A048 - Essential corrections to CB data download test case A049 - Essential corrections to CB data download test cases A049 - Essential corrections to CB data download test cases A050 - Essential corrections to CB data download test cases A051 - Corrections in the REFRESH test sequences (with inclusion of T3-030535's contents) A052 - Essential corrections to test requirement references A053 - Essential corrections to CALL CONTROL BY SIM (supplementary services) test case A054 - Essential corrections to CALL CONTROL BY SIM (supplementary services) test case A055 - Introduction of MO Short Message Control by SIM envelope testing A056 - Re-Introduction of Canges already approved at the last T3. A057 - Essential corrections A058 - Essential corrections to Send DTMF test cases A060 - Introduction of BIP testing in GPRS | | | A030 | - | Essential corrections to Set Up Call test cases | 8.5.0 |
| A033 Essential corrections to Power Off Card test case A034 Essential corrections to Perform Card APDU test cases A035 Essential correction to Get Reader Status test cases A036 Essential corrections to Send DTMF test cases A037 - Essential corrections to CALL CONTROL BY SIM test cases A037 - Essential corrections to CALL CONTROL BY SIM test cases A038 - Essential corrections to CALL CONTROL BY SIM (Interaction with FDN/ BDN) test cases A039 - Essential corrections to Select Item test cases A039 - Essential corrections to Select Item test cases Essential corrections to card reader status event download test cases A040 - Essential corrections to language selection and browser termination event download test cases A041 - Essential corrections to Close Channel test cases A042 - Essential corrections to Launch Browser test cases A043 - Essential corrections to Launch Browser test cases A044 - Essential corrections to Den Channel test cases A045 - Essential corrections to Receive Data test cases A046 - Essential corrections to Receive Data test cases A047 - Essential corrections to Receive Data test cases A048 - Essential corrections to Get Channel Status test cases A049 - Essential corrections to Get Channel Status test cases A050 - Essential corrections to Get Channel Status test cases A050 - Essential corrections to to Get Channel Status test cases A051 - Corrections in the REFRESH test sequences (with inclusion of T3- 030535's contents) A052 - Essential corrections to test requirement references A053 - Essential corrections to test requirement references A054 - Essential corrections to MT Call, Call connected and Call disconnected event download test cases A055 - Introduction of MO Short Message Control by SIM envelope testing A056 - Re-Introduction of MO Short Message Control by SIM envelope testing A057 - Essential corrections to DATF test cases A058 - Essential corrections to DATF test cases A060 - Introduction of BIP testing in GPRS | | | A031 | | Essential corrections to Send USSD test cases | |
| A034 Essential corrections to Perform Card APDU test cases | | | | - | | 8.5.0 |
| A035 Essential correction to Get Reader Status test cases A036 Essential corrections to Send DTMF test cases A037 - Essential corrections to CALL CONTROL BY SIM test cases A038 - Essential corrections to CALL CONTROL BY SIM (Interaction with FDM/ BDM) test cases A039 Essential corrections to Select Item test cases A040 Essential corrections to Select Item test cases A041 - Essential corrections to card reader status event download test cases A042 - Essential corrections to language selection and browser termination event download test cases A042 - Essential corrections to Close Channel test cases A043 - Essential corrections to Close Channel test cases A044 - Essential corrections to Launch Browser test cases A044 - Essential corrections to Deen Channel test cases A045 - Essential corrections to Receive Data test cases A046 - Essential corrections to Receive Data test cases A047 - Essential corrections to Channel Status event download test case A048 - Essential corrections to CB data download test cases A049 - Essential corrections to CB data download test cases A049 - Essential corrections to CB data download test cases A050 - Essential corrections to Ication status, user activity and idle screen available event download test cases A051 - Corrections in the REFRESH test sequences (with inclusion of T3-030535's contents) A052 - Essential corrections to CALL CONTROL BY SIM (supplementary services) test case A050 - Essential corrections to TALL CONTROL BY SIM (supplementary services) test case A050 - Essential corrections to TALL CONTROL BY SIM (supplementary services) test case A050 - Essential corrections to TALL CONTROL BY SIM (supplementary services) test case A050 - Essential corrections to TALL CONTROL BY SIM (supplementary services) test case A050 - Essential corrections to TALL CONTROL BY SIM (supplementary services) test case A050 - Re-Introduction of Changes already approved at the last T3. A050 - Re-Introduction of Changes already approved at the last T3. A050 - Re-Introduction of Changes already appro | | | | | | |
| A036 Essential corrections to Send DTMF test cases A037 - Essential corrections to CALL CONTROL BY SIM test cases A038 - Essential corrections to CALL CONTROL BY SIM (Interaction with FDN/ BDN) test cases A039 Essential corrections to Select Item test cases A040 Essential corrections to card reader status event download test cases A041 - Essential corrections to language selection and browser termination event download test cases A042 - Essential corrections to Close Channel test cases A043 - Essential corrections to Launch Browser test cases A044 Essential corrections to Depen Channel test cases A045 Essential corrections to Depen Channel test cases A046 Essential corrections to Receive Data test cases A047 Essential corrections to Send Data test cases A048 Essential corrections to Get Channel Status event download test case A049 Essential corrections to Get Channel Status test cases A049 Essential corrections to Get Channel Status test cases A049 Essential corrections to Deaton status, user activity and idle screen available event download test cases A050 - Essential corrections to location status, user activity and idle screen available event download test cases A051 - Corrections in the REFRESH test sequences (with inclusion of T3-030535's contents) A052 - Essential corrections to test requirement references A053 Essential corrections to CALL CONTROL BY SIM (supplementary services) test case A055 - Introduction of the Oshort Message Control by SIM' envelope testing 8.6.0 A056 - Re-Introduction of changes already approved at the last T3. A050 - Essential corrections to S27.22.4.14 'POLLING OFF' A050 - Essential corrections to Send DTMF test cases A060 - Introduction of BIP testing in GPRS | | | | | | |
| A038 - Essential corrections to CALL CONTROL BY SIM test cases | | | | | | |
| A038 - Essential corrections to CALL CONTROL BY SIM (Interaction with FDN/ BDN) test cases A040 Essential corrections to Select Item test cases A040 Essential corrections to card reader status event download test cases A041 - Essential corrections to language selection and browser termination event download test cases A042 - Essential corrections to Close Channel test cases A043 - Essential corrections to Department of Company of C | | | | | | 0.50 |
| FDN/ BDN) test cases Essential corrections to Select Item test cases A040 | | | | | | |
| A039 Essential corrections to Select Item test cases A040 Essential corrections to card reader status event download test cases A041 - Essential corrections to language selection and browser termination event download test cases A042 - Essential corrections to Close Channel test cases A043 - Essential corrections to Depen Channel test cases A044 Essential corrections to Depen Channel test cases A045 Essential corrections to Depen Channel test cases A046 Essential corrections to Receive Data test cases A047 Essential corrections to Send Data test cases A048 Essential corrections to Send Data test cases A049 Essential corrections to Get Channel Status event download test case A049 Essential corrections to Deat Channel Status test cases A050 - Essential corrections to Deat data download test cases A050 - Essential corrections to location status, user activity and idle screen available event download test cases A051 - Corrections in the REFRESH test sequences (with inclusion of T3-030535's contents) A052 - Essential corrections to test requirement references A053 Essential corrections to CALL CONTROL BY SIM (supplementary services) test case A054 - Essential corrections to MT Call, Call connected and Call disconnected event download test cases A055 - Introduction of 'MO Short Message Control by SIM' envelope testing A056 - Re-Introduction of changes already approved at the last T3. A060 - R058 - Essential corrections to 27.22.4.14 'POLLING OFF' A060 - Introduction of BIP testing in GPRS B.6.0 | | | A036 | _ | | 0.5.0 |
| A040 Essential corrections to card reader status event download test cases A041 - Essential corrections to language selection and browser termination event download test cases A042 - Essential corrections to Close Channel test cases A043 - Essential corrections to Launch Browser test cases A044 Essential corrections to Launch Browser test cases A045 Essential corrections to Receive Data test cases A046 Essential corrections to Send Data test cases A047 Essential corrections to Get Channel Status event download test case A048 Essential corrections to Get Channel Status test cases A049 Essential corrections to Data data download test cases A050 - Essential corrections to Data data download test cases A050 - Essential corrections to Incation status, user activity and idle screen available event download test cases A051 - Corrections in the REFRESH test sequences (with inclusion of T3-030535's contents) A052 - Essential corrections to test requirement references A053 - Essential corrections to CALL CONTROL BY SIM (supplementary services) test case A054 - Essential corrections to MT Call, Call connected and Call disconnected event download test cases A055 - Introduction of 'MO Short Message Control by SIM' envelope testing A056 - Re-Introduction of changes already approved at the last T3. A057 - Essential corrections A058 - Essential corrections to 27.22.4.14 'POLLING OFF' A059 - Essential corrections to Send DTMF test cases B.6.0 A060 - Introduction of BIP testing in GPRS B.6.0 | | | A039 | | | |
| A041 - Essential corrections to language selection and browser termination event download test cases A042 - Essential corrections to Close Channel test cases A043 - Essential corrections to Launch Browser test cases A044 - Essential corrections to Open Channel test cases A045 - Essential corrections to Open Channel test cases A046 - Essential corrections to Receive Data test cases A047 - Essential corrections to Send Data test cases A048 - Essential corrections to Send Data test cases A049 - Essential corrections to CB data download test cases A050 - Essential corrections to Iocation status, event download test cases A050 - Essential corrections to Iocation status, are activity and idle screen available event download test cases A051 - Corrections in the REFRESH test sequences (with inclusion of T3-030535's contents) A052 - Essential corrections to test requirement references A053 - Essential corrections to CALL CONTROL BY SIM (supplementary services) test case A054 - Essential corrections to MT Call, Call connected and Call disconnected event download test cases A055 - Introduction of 'MO Short Message Control by SIM' envelope testing A056 - Re-Introduction of changes already approved at the last T3. A057 - Essential corrections A058 - Essential corrections to 27.22.4.14 'POLLING OFF' 8.6.0 A059 - Essential corrections to Send DTMF test cases A060 - Introduction of BIP testing in GPRS 8.6.0 | | | | | | |
| event download test cases A042 - Essential corrections to Close Channel test cases A043 - Essential corrections to Launch Browser test cases A044 Essential corrections to Open Channel test cases A045 Essential corrections to Receive Data test cases A046 Essential corrections to Send Data test cases A047 Essential corrections to Send Data test cases A048 Essential corrections to Get Channel Status event download test case A049 Essential corrections to B data download test cases A050 - Essential corrections to Iocation status, user activity and idle screen available event download test cases A051 - Corrections in the REFRESH test sequences (with inclusion of T3-030535"s contents) A052 - Essential corrections to test requirement references A053 Essential corrections to CALL CONTROL BY SIM (supplementary services) test case A054 - Essential corrections to MT Call, Call connected and Call disconnected event download test cases A055 - Introduction of 'MO Short Message Control by SIM' envelope testing A056 - Re-Introduction of changes already approved at the last T3. A057 - Essential corrections A058 - Essential corrections A059 - Essential corrections to Send DTMF test cases B.5.0 A060 - Introduction of BIP testing in GPRS 8.6.0 | | | | | cases | 850 |
| A043 - Essential corrections to Launch Browser test cases A044 Essential corrections to Open Channel test cases A045 Essential corrections to Receive Data test cases A046 Essential corrections to Send Data test cases A047 Essential corrections to Send Data test cases A048 Essential corrections to Get Channel Status event download test case A049 Essential corrections to Get Channel Status test cases A049 Essential corrections to Iocation status, user activity and idle screen available event download test cases A050 - Essential corrections to location status, user activity and idle screen available event download test cases A051 - Corrections in the REFRESH test sequences (with inclusion of T3-030535"s contents) A052 - Essential corrections to test requirement references A053 Essential corrections to CALL CONTROL BY SIM (supplementary services) test case A054 - Essential corrections to MT Call, Call connected and Call disconnected event download test cases A055 - Introduction of 'MO Short Message Control by SIM' envelope testing A056 - Re-Introduction of changes already approved at the last T3. A057 - Essential corrections A058 - Essential corrections to Send DTMF test cases B.6.0 A059 - Essential corrections to Send DTMF test cases B.6.0 A060 - Introduction of BIP testing in GPRS B.5.0 | | | 7,041 | | | 0.5.0 |
| A044 Essential corrections to Open Channel test cases A045 Essential corrections to Receive Data test cases A046 Essential corrections to Send Data test cases A047 Essential corrections to Send Data test cases A048 Essential corrections to Channel status event download test case A049 Essential corrections to CB data download test cases A050 - Essential corrections to Iocation status, user activity and idle screen available event download test cases A051 - Corrections in the REFRESH test sequences (with inclusion of T3-030535's contents) A052 - Essential corrections to test requirement references A053 Essential corrections to CALL CONTROL BY SIM (supplementary services) test case A054 - Essential corrections to MT Call, Call connected and Call disconnected event download test cases A055 - Introduction of 'MO Short Message Control by SIM' envelope testing A056 - Re-Introduction of changes already approved at the last T3. A057 - Essential corrections A058 - Essential corrections to 27.22.4.14 'POLLING OFF' A059 - Essential corrections to Send DTMF test cases A060 - Introduction of BIP testing in GPRS A060 | | | A042 | - | Essential corrections to Close Channel test cases | 8.5.0 |
| A045 Essential corrections to Receive Data test cases A046 Essential corrections to Send Data test cases A047 Essential corrections to channel status event download test case A048 Essential corrections to Get Channel Status test cases A049 Essential corrections to CB data download test cases A050 - Essential corrections to location status, user activity and idle screen available event download test cases A051 - Corrections in the REFRESH test sequences (with inclusion of T3-030535"s contents) A052 - Essential corrections to test requirement references A053 Essential corrections to CALL CONTROL BY SIM (supplementary services) test case A054 - Essential corrections to MT Call, Call connected and Call disconnected event download test cases A055 - Introduction of 'MO Short Message Control by SIM' envelope testing A056 - Re-Introduction of changes already approved at the last T3. A057 - Essential corrections A058 - Essential corrections to Send DTMF test cases B.6.0 A059 - Essential corrections to Send DTMF test cases B.6.0 A060 - Introduction of BIP testing in GPRS B.6.0 | | | | | | 8.5.0 |
| A046 Essential corrections to Send Data test cases A047 Essential corrections to channel status event download test case A048 Essential corrections to Get Channel Status test cases A049 Essential corrections to CB data download test cases A050 - Essential corrections to location status, user activity and idle screen available event download test cases A051 - Corrections in the REFRESH test sequences (with inclusion of T3-030535"s contents) A051 - Essential corrections to test requirement references A052 - Essential corrections to CALL CONTROL BY SIM (supplementary services) test case A054 - Essential corrections to MT Call, Call connected and Call disconnected event download test cases A055 - Introduction of 'MO Short Message Control by SIM' envelope testing A056 - Re-Introduction of changes already approved at the last T3. A057 - Essential corrections A058 - Essential corrections to 27.22.4.14 'POLLING OFF' 8.6.0 A059 - Essential corrections to Send DTMF test cases 8.6.0 A060 - Introduction of BIP testing in GPRS | | | | | | |
| A047 Essential corrections to channel status event download test case A048 Essential corrections to Get Channel Status test cases A049 Essential corrections to CB data download test cases A050 - Essential corrections to location status, user activity and idle screen available event download test cases A051 - Corrections in the REFRESH test sequences (with inclusion of T3-030535"s contents) A052 - Essential corrections to test requirement references Essential corrections to CALL CONTROL BY SIM (supplementary services) test case A053 Essential corrections to MT Call, Call connected and Call disconnected event download test cases A054 - Essential corrections to MT Call, Call connected and Call disconnected event download test cases A055 - Introduction of 'MO Short Message Control by SIM' envelope testing A056 - Re-Introduction of changes already approved at the last T3. A057 - Essential corrections A058 - Essential corrections to 27.22.4.14 'POLLING OFF' 8.6.0 A059 - Essential corrections to Send DTMF test cases 8.6.0 A060 - Introduction of BIP testing in GPRS | | | | | | |
| A048 Essential corrections to Get Channel Status test cases A049 Essential corrections to CB data download test cases A050 - Essential corrections to location status, user activity and idle screen available event download test cases A051 - Corrections in the REFRESH test sequences (with inclusion of T3-030535's contents) A052 - Essential corrections to test requirement references A053 Essential corrections to CALL CONTROL BY SIM (supplementary services) test case A054 - Essential corrections to MT Call, Call connected and Call disconnected event download test cases A055 - Introduction of 'MO Short Message Control by SIM' envelope testing A056 - Re-Introduction of changes already approved at the last T3. A057 - Essential corrections A058 - Essential corrections to 27.22.4.14 'POLLING OFF' B.6.0 A059 - Essential corrections to Send DTMF test cases B.6.0 A060 - Introduction of BIP testing in GPRS | | | | | | |
| A049 Essential corrections to CB data download test cases A050 - Essential corrections to location status, user activity and idle screen available event download test cases A051 - Corrections in the REFRESH test sequences (with inclusion of T3-030535"s contents) A052 - Essential corrections to test requirement references A053 Essential corrections to CALL CONTROL BY SIM (supplementary services) test case A054 - Essential corrections to MT Call, Call connected and Call disconnected event download test cases A055 - Introduction of 'MO Short Message Control by SIM' envelope testing A056 - Re-Introduction of changes already approved at the last T3. A057 - Essential corrections A058 - Essential corrections to 27.22.4.14 'POLLING OFF' 8.6.0 A059 - Essential corrections to Send DTMF test cases 8.6.0 A060 - Introduction of BIP testing in GPRS | ļ | | | | | |
| A050 - Essential corrections to location status, user activity and idle screen available event download test cases A051 - Corrections in the REFRESH test sequences (with inclusion of T3-030535"s contents) A052 - Essential corrections to test requirement references A053 - Essential corrections to CALL CONTROL BY SIM (supplementary services) test case A054 - Essential corrections to MT Call, Call connected and Call disconnected event download test cases A055 - Introduction of 'MO Short Message Control by SIM' envelope testing A056 - Re-Introduction of changes already approved at the last T3. A057 - Essential corrections A058 - Essential corrections to 27.22.4.14 'POLLING OFF' 8.6.0 A059 - Essential corrections to Send DTMF test cases 8.6.0 A060 - Introduction of BIP testing in GPRS | | | | | | |
| available event download test cases A051 - Corrections in the REFRESH test sequences (with inclusion of T3-030535"s contents) A052 - Essential corrections to test requirement references 8.5.0 A053 Essential corrections to CALL CONTROL BY SIM (supplementary services) test case A054 - Essential corrections to MT Call, Call connected and Call disconnected event download test cases A055 - Introduction of 'MO Short Message Control by SIM' envelope testing 8.6.0 A056 - Re-Introduction of changes already approved at the last T3. 8.6.0 A057 - Essential corrections 8.6.0 A058 - Essential corrections to 27.22.4.14 'POLLING OFF' 8.6.0 A059 - Essential corrections to Send DTMF test cases 8.6.0 A060 - Introduction of BIP testing in GPRS 8.6.0 | - | | | <u> </u> | | 2 5 O |
| A051 - Corrections in the REFRESH test sequences (with inclusion of T3- 030535"s contents) A052 - Essential corrections to test requirement references 8.5.0 A053 Essential corrections to CALL CONTROL BY SIM (supplementary services) test case A054 - Essential corrections to MT Call, Call connected and Call disconnected event download test cases A055 - Introduction of 'MO Short Message Control by SIM' envelope testing A056 - Re-Introduction of changes already approved at the last T3. A057 - Essential corrections A058 - Essential corrections to 27.22.4.14 'POLLING OFF' 8.6.0 A059 - Essential corrections to Send DTMF test cases 8.6.0 A060 - Introduction of BIP testing in GPRS | | | A030 | _ | | 0.5.0 |
| A052 - Essential corrections to test requirement references 8.5.0 A053 Essential corrections to CALL CONTROL BY SIM (supplementary services) test case A054 - Essential corrections to MT Call, Call connected and Call disconnected event download test cases A055 - Introduction of 'MO Short Message Control by SIM' envelope testing 8.6.0 A056 - Re-Introduction of changes already approved at the last T3. 8.6.0 A057 - Essential corrections 8.6.0 A058 - Essential corrections to 27.22.4.14 'POLLING OFF' 8.6.0 A059 - Essential corrections to Send DTMF test cases 8.6.0 A060 - Introduction of BIP testing in GPRS 8.6.0 | | | A051 | - | Corrections in the REFRESH test sequences (with inclusion of T3- | 8.5.0 |
| A053 Essential corrections to CALL CONTROL BY SIM (supplementary services) test case A054 - Essential corrections to MT Call, Call connected and Call disconnected event download test cases A055 - Introduction of 'MO Short Message Control by SIM' envelope testing 8.6.0 A056 - Re-Introduction of changes already approved at the last T3. 8.6.0 A057 - Essential corrections 8.6.0 A058 - Essential corrections to 27.22.4.14 'POLLING OFF' 8.6.0 A059 - Essential corrections to Send DTMF test cases 8.6.0 A060 - Introduction of BIP testing in GPRS 8.6.0 | - | | AGES | | , , , | 950 |
| services) test case A054 - Essential corrections to MT Call, Call connected and Call disconnected event download test cases A055 - Introduction of 'MO Short Message Control by SIM' envelope testing 8.6.0 A056 - Re-Introduction of changes already approved at the last T3. 8.6.0 A057 - Essential corrections 8.6.0 A058 - Essential corrections to 27.22.4.14 'POLLING OFF' 8.6.0 A059 - Essential corrections to Send DTMF test cases 8.6.0 A060 - Introduction of BIP testing in GPRS 8.6.0 | | | | - - | Essential corrections to CALL CONTROL BY SIM (supplementary | 0.0.0 |
| A054 - Essential corrections to MT Call, Call connected and Call disconnected event download test cases A055 - Introduction of 'MO Short Message Control by SIM' envelope testing 8.6.0 A056 - Re-Introduction of changes already approved at the last T3. 8.6.0 A057 - Essential corrections 8.6.0 A058 - Essential corrections to 27.22.4.14 'POLLING OFF' 8.6.0 A059 - Essential corrections to Send DTMF test cases 8.6.0 A060 - Introduction of BIP testing in GPRS 8.6.0 | | | 7,000 | | | |
| A055 - Introduction of 'MO Short Message Control by SIM' envelope testing 8.6.0 A056 - Re-Introduction of changes already approved at the last T3. 8.6.0 A057 - Essential corrections 8.6.0 A058 - Essential corrections to 27.22.4.14 'POLLING OFF' 8.6.0 A059 - Essential corrections to Send DTMF test cases 8.6.0 A060 - Introduction of BIP testing in GPRS 8.6.0 | | | A054 | - | Essential corrections to MT Call, Call connected and Call | 8.5.0 |
| A056 - Re-Introduction of changes already approved at the last T3. 8.6.0 A057 - Essential corrections 8.6.0 A058 - Essential corrections to 27.22.4.14 'POLLING OFF' 8.6.0 A059 - Essential corrections to Send DTMF test cases 8.6.0 A060 - Introduction of BIP testing in GPRS 8.6.0 | | | AOFF | | | 960 |
| A057 | | | | ļ | | |
| A058 - Essential corrections to 27.22.4.14 'POLLING OFF' 8.6.0 A059 - Essential corrections to Send DTMF test cases 8.6.0 A060 - Introduction of BIP testing in GPRS 8.6.0 | | | + | † | | |
| A059 - Essential corrections to Send DTMF test cases 8.6.0 A060 - Introduction of BIP testing in GPRS 8.6.0 | | | | | | |
| A060 - Introduction of BIP testing in GPRS 8.6.0 | | | | - | | |
| | | | | - | | |
| TAVAL TOUR OF THE CONTROL OF THE CON | | | A061 | | Correction of image instance descriptor for colour icons | 8.7.0 |

| A062 Essential correction on I ferminal Profile for the BIP 8.7.0 | | | | | |
|--|-------|-----------|------|---|--------|
| A063 | | | A062 | | 8.7.0 |
| A064 | | | A063 | | 8.7.0 |
| A066 CR 11.10-4 R99: Essential correction of coding convention 8.7.0 Correction of Cell Broadcast message download test 8.8.0 A066 Essential corrections 8.8.0 A066 Corrections of applicability table A067 Correction of applicability table A068 Corrections of applicability table A068 Corrections of applicability table A070 Correction on allowing optional parameters in ENVELOPE(CALL 8.8.0 CONTROL) command for call set-ups when testing Call Control prioreadures A070 Correction on allowing optional parameters in ENVELOPE(CALL 8.8.0 CONTROL) command for call set-ups when testing Call Control prioreadures A070 Correction of Event Download test cases 8.9.0 A070 Correction of Event Download test cases 8.9.0 A071 Correction of Event Download test cases 8.9.0 A071 Correction of Event Download test cases 8.9.0 A072 Correction of Event Download test cases 8.9.0 A072 Correction of Event Download test cases 8.9.0 A073 Correction of Event Download test cases 8.9.0 A074 Correction of Event Download test cases 8.9.0 A075 Correction of Event Download test cases 8.10.0 A079 Correction of Event Download test case 8.10.0 Correction of Event Download test case 8.10.0 A079 Correction of Event Download test case 8.10.0 A079 Correction of Event Download test case 8.10.0 A079 Correction of Event Download test case 8.10.0 A080 Correction of PROFILE DOWNLOAD Event Case 1.00 A080 Correction of PROFILE DOWNLOAD Event Case 1.00 A080 Correction of PROFILE DOWNLOAD Event Case 1.00 A080 Correction of Event Case 8.10.0 A080 Correctio | | | | | |
| A071 | | | A065 | | |
| A067 | | | | | |
| A068 | | | A066 | Essential corrections | 8.8.0 |
| A070 | | | A067 | Support of GSM 700, GSM 850 and PCS 1900 | 8.8.0 |
| A070 | | | A068 | | 8.8.0 |
| A076 | | | A070 | Correction on allowing optional parameters in ENVELOPE(CALL CONTROL) command for call set-ups when testing Call Control | 8.8.0 |
| A076 - Essential corrections of Event Download test cases 8.9.0 | | | ۸060 | F-1-0-0-0-0-0-0 | 990 |
| A073 - Essential corrections | | | | | |
| M.072 Clarification of call hang up in 27.22.4.5 Play Tone 8.9.0 | | | | | |
| A074 - Removal of misleading comment from Refresh SIM Reset tests 8.9.0 | | | _ | | |
| A075 Correction of Send Short Message test case 8.10.0 | | | _ | | |
| A077 | | | | | |
| A076 Correction of Select Item test case | | | | Correction of Send Short Message test case | |
| A079 Correction of Language Notification test case | | | | | |
| A080 | | | | | |
| A081 | | | | | |
| A082 | | | | | |
| A083 | | | _ | | |
| A084 Correction of Refresh test case | | | | | |
| A086 Correction of MO SM CONTROL BY SIM test case 8.10.0 | | | | | |
| A086 Correction of Errors | | | | | |
| A087 Clarification of PLAY TONE test case | | 1 | | | |
| A088 - Clarification of RECEIVE DATA test case 8.10.0 | | | | | |
| A089 Corrections for Test Case 27:22.51 (SMS-PP Data Download) 8.10.0 | | | | | |
| A090 | | | | | |
| A091 Correction of Set Up Idle Mode Text test case | | | | - Modification of 27.22.1 PROFILE DOWNLOAD | |
| Roy | | | | | |
| Resential Corrections on Launch Browser | | | | | |
| TP-27 T3-050096 A094 Correction of terminal profile test 8.11.0 | | | | | |
| TP-27 T3-050097 A095 Correction of Set Up Call test 8.11.0 | TP-27 | T3-050096 | | | |
| TP-27 T3-050098 A096 Essential Corrections B.11.0 | | | | | |
| TP-27 T3-050100 A098 Correction of Call Control test cases 8.11.0 | | | _ | | |
| TP-27 T3-050100 A098 Correction of Call Control test cases 8.11.0 | TP-27 | T3-050099 | A097 | Correction of Call Connected Event test | 8.11.0 |
| TP-27 T3-050125 A099 Corrections of references 8.11.0 | TP-27 | T3-050100 | | | |
| TP-27 T3-050194 A101 Correction of network related tests 8.11.0 | TP-27 | T3-050125 | A099 | | 8.11.0 |
| TP-27 T3-050195 A102 Correction of Timer Management test S.11.0 | TP-27 | T3-050155 | A100 | Clarification on LAUNCH BROWSER test case | 8.11.0 |
| TP-27 T3-050196 A103 Correction of coding of SS RETURN RESULT in 27.22.4.12 SEND USSD SEND USSD SEND USSD SEND USSD SEND USSD SEND UP IDLE MODE TEXT (icon support) Send UP IDLE MODE TEXT | TP-27 | T3-050194 | A101 | Correction of network related tests | 8.11.0 |
| USSD | | | | | 8.11.0 |
| UP IDLE MODE TEXT (icon support) TP-27 T3-050198 A105 Correction on Timer Management test cases 8.11.0 CT-28 C6-050354 A106 Correction of coding in MT Call Even 8.12.0 CT-28 C6-050381 A107 Essential corrections 8.12.0 Ct-28 C6-050382 A109 Too many digits in PCS 1900 for the Called Party BCD number 8.12.0 CT-29 C6-050629 A110 CR 11.10-4: Correction of applicability and terminal profile support tables C6-050631 A111 CR 11.10-4: Correction of Refresh tests C6-050632 A112 CR 11.10-4: Correction of EF_BDN coding C6-050634 A127 CR 11.10-4: Correction of EF_BDN coding C6-050634 A127 CR 11.10-4: Incorrect Dialling Number string in clause 27.22.4.13.1 SEQ 1.9 for PCS 1900 C6-050640 A115 CR 11.10-4: Incorrect Ti Flag value for SET UP 1.4.1 in clause 27.22.4.16.1 C6-050642 A116 CR 11.10-4: Correction of TP-MR (TP Message Reference) of the SMS SUBMIT TPDU submitted to the SS (Network) C6-050644 A117 CR 11.10-4: Corrections in the Logical description and BER encoding in clause 27.22.6.2 and 27.22.4.11 C6-050646 A118 CR 11.10-4: Incorrect DCS in SMS-CB data download tests C6-050662 A119 CR 11.10-4: Essential Corrections in clause 27.22.8 MO SHORT MESSAGE CONTROL BY SIM C6-050664 A120 CR 11.10-4: Essential Corrections in clause 27.22.4.7.2 REFRESH (IMSI changing procedure) C6-050672 A122 CR 11.10-4 R99: Incorrect SMS-PP 1.4.1 TPDU in clause C6-050672 A122 CR 11.10-4 R99: Incorrect SMS-PP 1.4.1 TPDU in clause C6-050672 C7 11.10-4 R99: Incorrect SMS-PP 1.4.1 TPDU in clause C7-050672 C7-050672 C7 11.10-4 R99: Incorrect SMS-PP 1.4.1 TPDU in clause C7-050672 C7-050672 C7 11.10-4 R99: Incorrect SMS-PP 1.4.1 TPDU in clause C7-050672 C7-050672 C7 11.10-4 R99: Incorrect SMS-PP 1.4.1 TPDU in clause C7-050672 C7 11.10-4 R99: Incorrect SMS-PP 1.4.1 TPDU in clause C7-050672 C7 11.10-4 R99: Incorrect SMS-PP 1.4.1 TPDU in clause C7-050672 C7-050672 C7 11.10-4 R99: Incor | | | | USSD | |
| CT-28 C6-050354 A106 Correction of coding in MT Call Even 8.12.0 CT-28 C6-050381 A107 Essential corrections 8.12.0 Ct-28 C6-050382 A109 Too many digits in PCS 1900 for the Called Party BCD number 8.12.0 CT-29 C6-050629 A110 CR 11.10-4: Correction of applicability and terminal profile support tables 8.13.0 C6-050631 A111 CR 11.10-4: Correction of Refresh tests 6.050632 CC6-050634 CR 11.10-4: Correction of EF_BDN coding 6.10 CC6-050634 CR 11.10-4: Correction of EF_BDN coding 6.10 CR 11.10-4: Correction of EF_BDN coding 6.10 CR 11.10-4: Correction of EF_BDN coding 6.10 | | | | UP IDLE MODE TEXT (icon support) | |
| CT-28 C6-050381 A107 Essential corrections 8.12.0 Ct-28 C6-050382 A109 Too many digits in PCS 1900 for the Called Party BCD number 8.12.0 CT-29 C6-050629 A110 CR 11.10-4: Correction of applicability and terminal profile support tables 8.13.0 C6-050631 A111 CR 11.10-4: Correction of Refresh tests C6-050632 A122 CR 11.10-4: Correction of EF_BDN coding C6-050634 A127 CR 11.10-4: Correction of EF_BDN coding C6-050634 CR 11.10-4: Incorrect Dialling Number string in clause 27.22.4.13.1 SEQ 1.9 for PCS 1900 C6-050640 A115 CR 11.10-4: Incorrect Ti Flag value for SET UP 1.4.1 in clause 27.22.4.16.1 CR 11.10-4: Correction of TP-MR (TP Message Reference) of the SMS SUBMIT TPDU submitted to the SS (Network) C6-050644 A117 CR 11.10-4: Corrections in the Logical description and BER encoding in clause 27.22.6.2 and 27.22.4.11 C6-050646 A118 CR 11.10-4: Incorrect DCS in SMS-CB data download tests C6-050664 A120 CR 11.10-4: Essential Corrections in clause 27.22.8 MO SHORT MESSAGE CONTROL BY SIM C6-050664 A120 CR 11.10-4: Essential Corrections C6-050671 A121 CR 11.10-4: R99: Essential corrections in clause 27.22.4.7.2 REFRESH (IMSI changing procedure) C6-050672 | | | | | |
| Ct-28 C6-050382 A109 Too many digits in PCS 1900 for the Called Party BCD number 8.12.0 CT-29 C6-050629 A110 CR 11.10-4: Correction of applicability and terminal profile support tables 8.13.0 C6-050631 A111 CR 11.10-4: Correction of Refresh tests C6-050632 A112 CR 11.10-4: Correction of EF_BDN coding C6-050634 A127 CR 11.10-4: R99: Essential correction to Terminal Profile table E.1 C6-050636 A113 CR 11.10-4: Incorrect Dialling Number string in clause 27.22.4.13.1 SEQ 1.9 for PCS 1900 C6-050640 A115 CR 11.10-4: Incorrect Ti Flag value for SET UP 1.4.1 in clause 27.22.4.16.1 CR 11.10-4: Correction of TP-MR (TP Message Reference) of the SMS SUBMIT TPDU submitted to the SS (Network) C6-050644 A117 CR 11.10-4: Corrections in the Logical description and BER encoding in clause 27.22.6.2 and 27.22.4.11 C6-050646 A118 CR 11.10-4: Incorrect DCS in SMS-CB data download tests C6-050662 A119 CR 11.10-4: Essential Corrections in clause 27.22.8 MO SHORT MESSAGE CONTROL BY SIM C6-050671 A121 CR 11.10-4 R99: Essential corrections in clause 27.22.4.7.2 REFRESH (IMSI changing procedure) C6-050672 A122 CR 11.10-4 R99: Incorrect SMS-PP 1.4.1 TPDU in clause </td <td></td> <td></td> <td></td> <td></td> <td></td> | | | | | |
| CT-29 C6-050629 A110 CR 11.10-4: Correction of applicability and terminal profile support tables 8.13.0 C6-050631 A111 CR 11.10-4: Correction of Refresh tests C6-050632 A112 CR 11.10-4: Correction of EF_BDN coding C6-050634 A127 CR 11.10-4: Respection to Terminal Profile table E.1 CG-050636 A113 CR 11.10-4: Incorrect Dialling Number string in clause 27.22.4.13.1 SEQ 1.9 for PCS 1900 C6-050640 A115 CR 11.10-4: Incorrect Ti Flag value for SET UP 1.4.1 in clause 27.22.4.16.1 CR 11.10-4: Correction of TP-MR (TP Message Reference) of the SMS SUBMIT TPDU submitted to the SS (Network) C6-050644 A117 CR 11.10-4: Corrections in the Logical description and BER encoding in clause 27.22.6.2 and 27.22.4.11 C6-050646 A118 CR 11.10-4: Incorrect DCS in SMS-CB data download tests C6-050662 A119 CR 11.10-4: Essential Corrections in clause 27.22.8 MO SHORT MESSAGE CONTROL BY SIM C6-050664 A120 CR 11.10-4: Essential Corrections C6-050671 A121 CR 11.10-4 R99: Essential corrections in clause 27.22.4.7.2 REFRESH (IMSI changing procedure) C6-050672 A122 CR 11.10-4 R99: Incorrect SMS-PP 1.4.1 TPDU in clause | | | | | |
| C6-050631 A111 CR 11.10-4: Correction of Refresh tests C6-050632 A112 CR 11.10-4: Correction of EF_BDN coding C6-050634 A127 CR 11.10-4 R99: Essential correction to Terminal Profile table E.1 C6-050636 A113 CR 11.10-4: Incorrect Dialling Number string in clause 27.22.4.13.1 SEQ 1.9 for PCS 1900 C6-050640 A115 CR 11.10-4: Incorrect Ti Flag value for SET UP 1.4.1 in clause 27.22.4.16.1 C6-050642 A116 CR 11.10-4: Correction of TP-MR (TP Message Reference) of the SMS SUBMIT TPDU submitted to the SS (Network) C6-050644 A117 CR 11.10-4: Corrections in the Logical description and BER encoding in clause 27.22.6.2 and 27.22.4.11 C6-050646 A118 CR 11.10-4: Incorrect DCS in SMS-CB data download tests C6-050662 A119 CR 11.10-4: Essential Corrections in clause 27.22.8 MO SHORT MESSAGE CONTROL BY SIM C6-050664 A120 CR 11.10-4: Essential corrections C6-050671 A121 CR 11.10-4 R99: Essential corrections in clause 27.22.4.7.2 REFRESH (IMSI changing procedure) C6-050672 A122 CR 11.10-4 R99: Incorrect SMS-PP 1.4.1 TPDU in clause | | | | CR 11.10-4: Correction of applicability and terminal profile support | |
| C6-050632 A112 CR 11.10-4: Correction of EF_BDN coding C6-050634 A127 CR 11.10-4 R99: Essential correction to Terminal Profile table E.1 C6-050636 A113 CR 11.10-4: Incorrect Dialling Number string in clause 27.22.4.13.1 SEQ 1.9 for PCS 1900 C6-050640 A115 CR 11.10-4: Incorrect Ti Flag value for SET UP 1.4.1 in clause 27.22.4.16.1 C6-050642 A116 CR 11.10-4: Correction of TP-MR (TP Message Reference) of the SMS SUBMIT TPDU submitted to the SS (Network) C6-050644 A117 CR 11.10-4: Corrections in the Logical description and BER encoding in clause 27.22.6.2 and 27.22.4.11 C6-050646 A118 CR 11.10-4: Incorrect DCS in SMS-CB data download tests C6-050662 A119 CR 11.10-4: Essential Corrections in clause 27.22.8 MO SHORT MESSAGE CONTROL BY SIM C6-050664 A120 CR 11.10-4: Essential Corrections C6-050671 A121 CR 11.10-4 R99: Essential corrections in clause 27.22.4.7.2 REFRESH (IMSI changing procedure) C6-050672 A122 CR 11.10-4 R99: Incorrect SMS-PP 1.4.1 TPDU in clause | | C6-050631 | A111 | | |
| C6-050634 A127 CR 11.10-4 R99: Essential correction to Terminal Profile table E.1 C6-050636 A113 CR 11.10-4: Incorrect Dialling Number string in clause 27.22.4.13.1 SEQ 1.9 for PCS 1900 C6-050640 A115 CR 11.10-4: Incorrect Ti Flag value for SET UP 1.4.1 in clause 27.22.4.16.1 C6-050642 A116 CR 11.10-4: Correction of TP-MR (TP Message Reference) of the SMS SUBMIT TPDU submitted to the SS (Network) C6-050644 A117 CR 11.10-4: Corrections in the Logical description and BER encoding in clause 27.22.6.2 and 27.22.4.11 C6-050646 A118 CR 11.10-4: Incorrect DCS in SMS-CB data download tests C6-050662 A119 CR 11.10-4: Essential Corrections in clause 27.22.8 MO SHORT MESSAGE CONTROL BY SIM C6-050664 A120 CR 11.10-4: Essential corrections C6-050671 A121 CR 11.10-4 R99: Essential corrections in clause 27.22.4.7.2 REFRESH (IMSI changing procedure) C6-050672 A122 CR 11.10-4 R99: Incorrect SMS-PP 1.4.1 TPDU in clause | | | | | |
| C6-050636 A113 CR 11.10-4: Incorrect Dialling Number string in clause 27.22.4.13.1 SEQ 1.9 for PCS 1900 C6-050640 A115 CR 11.10-4: Incorrect Ti Flag value for SET UP 1.4.1 in clause 27.22.4.16.1 C6-050642 A116 CR 11.10-4: Correction of TP-MR (TP Message Reference) of the SMS SUBMIT TPDU submitted to the SS (Network) C6-050644 A117 CR 11.10-4: Corrections in the Logical description and BER encoding in clause 27.22.6.2 and 27.22.4.11 C6-050646 A118 CR 11.10-4: Incorrect DCS in SMS-CB data download tests C6-050662 A119 CR 11.10-4: Essential Corrections in clause 27.22.8 MO SHORT MESSAGE CONTROL BY SIM C6-050664 A120 CR 11.10-4: Essential Corrections C6-050671 A121 CR 11.10-4 R99: Essential corrections in clause 27.22.4.7.2 REFRESH (IMSI changing procedure) C6-050672 A122 CR 11.10-4 R99: Incorrect SMS-PP 1.4.1 TPDU in clause | | | | | |
| C6-050640 A115 CR 11.10-4: Incorrect Ti Flag value for SET UP 1.4.1 in clause 27.22.4.16.1 C6-050642 A116 CR 11.10-4: Correction of TP-MR (TP Message Reference) of the SMS SUBMIT TPDU submitted to the SS (Network) C6-050644 A117 CR 11.10-4: Corrections in the Logical description and BER encoding in clause 27.22.6.2 and 27.22.4.11 C6-050646 A118 CR 11.10-4: Incorrect DCS in SMS-CB data download tests C6-050662 A119 CR 11.10-4: Essential Corrections in clause 27.22.8 MO SHORT MESSAGE CONTROL BY SIM C6-050664 A120 CR 11.10-4: Essential Corrections C6-050671 A121 CR 11.10-4 R99: Essential corrections in clause 27.22.4.7.2 REFRESH (IMSI changing procedure) C6-050672 A122 CR 11.10-4 R99: Incorrect SMS-PP 1.4.1 TPDU in clause | | C6-050636 | A113 | CR 11.10-4: Incorrect Dialling Number string in clause 27.22.4.13.1 | |
| SMS SUBMIT TPDU submitted to the SS (Network) C6-050644 | | C6-050640 | A115 | CR 11.10-4: Incorrect Ti Flag value for SET UP 1.4.1 in clause 27.22.4.16.1 | |
| encoding in clause 27.22.6.2 and 27.22.4.11 C6-050646 | | | | SMS SUBMIT TPDU submitted to the SS (Network) | |
| C6-050662 A119 CR 11.10-4: Essential Corrections in clause 27.22.8 MO SHORT MESSAGE CONTROL BY SIM C6-050664 A120 CR 11.10-4: Essential Corrections C6-050671 A121 CR 11.10-4 R99: Essential corrections in clause 27.22.4.7.2 REFRESH (IMSI changing procedure) C6-050672 A122 CR 11.10-4 R99: Incorrect SMS-PP 1.4.1 TPDU in clause | | | | encoding in clause 27.22.6.2 and 27.22.4.11 | |
| MESSAGE CONTROL BY SIM | | | | | |
| C6-050671 | | | | MESSAGE CONTROL BY SIM | |
| C6-050671 | | | | | |
| C6-050672 A122 CR 11.10-4 R99: Incorrect SMS-PP 1.4.1 TPDU in clause | | C6-050671 | A121 | CR 11.10-4 R99: Essential corrections in clause 27.22.4.7.2 | |
| | | C6-050672 | A122 | CR 11.10-4 R99: Incorrect SMS-PP 1.4.1 TPDU in clause | |

| | C6-050674 | A123 | | CR 11.10-4 R99: Missing interactions in Bearer Independent Protocol test cases | |
|-------|-----------|--------------|------------|--|----------------|
| | C6-050669 | A124 | | CR 11.10-4 R99: Applicability of TC 27.22.4.7.1 and TCs related to | |
| | C6-050703 | A 126 | | FDN and BDN Correction of CB message identifier | - |
| | C6-050703 | | | Essential corrections in display icons Setup Menu and Select Item | |
| | none | none | | editorial corrections due to the CRs approved at CP-29 | 8.13.1 |
| CT-30 | | A114 | | Corrections of Set Up Call (second alpha identifier) test | 8.14.0 |
| | | A129 | | Essential Corrections of Set Up Menu test | |
| | | A130 | | Essential Corrections in clause 27.22.4.11 | |
| | | A131 | | Corrections to Select Item (icons support) | |
| | | A132 | | 27.22.7.4.1 Location Status Event (normal) | |
| | | A134 | | Correction of applicability table | |
| | | A135 | | Correction in SMS-PP 1.4.1 TPDU of clause 27.22.4.22.1 | - |
| | | A136 | | Essential Corrections of SMS-PP download message in Refresh test case | |
| | | A137 | | Essential Correction in MO SHORT MESSAGE CONTROL BY SIM Deletion of sequence 1.9 | |
| | ĺ | A138 | | Deletion of SEQ 1.3 in clause 27.22.4.13.1 | 1 |
| CT-31 | CP-060014 | A148 | | Essential Corrections in clause 27.22.4.11 | 8.15.0 |
| | | A151 | | Essential Corrections in clause 27.22.8 MO SHORT MESSAGE | |
| | | | | CONTROL BY SIM | |
| | | A147 | | Essential correction in SEQ 1.4 of clause 27.22.4.11.1 SEND SS (normal) | |
| | | A146 | | Essential corrections of Run AT Command tests | 1 |
| | | A152 | | Essential corrections to SET UP CALL test sequences |] |
| | CP-060012 | A158 | | Essential correction of Refresh IMSI changing tests |] |
| | | A141 | | Essential correction of UCS2 related test case applicability |] |
| | | A142 | | Removal of SEQ 2.2 in clause 27.22.4.12.2 | _ |
| | | A150 | | Essential correction of Channel Data length in SEQ 1.1 of clause 27.22.4.30 | |
| | | A145 | | Essential correction of SMS-CB (data download) tests | |
| | CP-060013 | A139 | | Deletion of Send Data test sequence | |
| | | A140 | | Essential correction of Provide Local Information (IMEI) test | |
| | | A143 | | Essential Correction in SEQ 1.8 of clause 27.22.8 | |
| | | A144 | | Essential correction on 27.22.7.3.1 Call Disconnected Event | - |
| | OD 000045 | A149 | | Essential correction of Channel Data length in clause 27.22.4.30 | - |
| | CP-060015 | A154 | | Essential Correction in TERMINAL RESPONSE coding of clause 27.22.4.31 | |
| | | A156 | | Essential corrections to Timer Expiration tests |] |
| | | A153 | | BER-TLV suppressions | |
| | CP-060016 | A155 | | Creation of a new TS 51.10-4, Rel-4 specification coming from TS 11.10-4 R99 | 51.010-4v4.0.0 |
| CT-32 | CP-060236 | 0001 | | Essential correction to prevent optional ME features being mandatorily tested | 4.1.0 |
| | | 0004 | | Essential correction of Language Selection Event test | 1 |
| | CP-060242 | 0002 | | Essential correction of BIP tests | 1 |
| | | 0003 | | Essential Correction in REGISTER 1.2B message coding of clause | 1 |
| | | | | 27.22.4.11.1 SEND SS (normal) | |
| | | 0005 | | Essential correction of 27.22.4.13.1 SET UP CALL, seq 1.4 | |
| | | 0006 | | Essential correction of second card reader test applicability | |
| | 1 | 0007 | | Correction of TON/NPI coding for Call Control Test case | 1 |
| 07.55 | OD 000000 | 8000 | _ | Essential corrections on 27.22.4.11.1 sequence. 1.2 | 4.0.0 |
| U1-33 | CP-060382 | 0016 | 1 | Essential correction of GET INPUT test | 4.2.0 |
| | | 0018 0019 | 1 | Essential correction of SEND DATA test | - |
| | | 0019 | 2 | Correction of various typographical errors Essential correction of BIP test cases | 1 |
| | CP-060517 | 0010 | 1 | Essential corrections Set Up Call, seq. 1.9 | 1 |
| | CP-060475 | 0012 | 1 | Essential corrections of MMI entries in table E.1 | 1 |
| | 3. 300473 | 0009 | 1 | Corrections to SET UP CALL test case 27.22.4.13.1 | 1 |
| | | | 2 | Essential corrections to SEND SS concerning | 1 |
| |] | | | longForwardedToNumber | |
| | | | 2 | Corrections to MO SHORT MESSAGE CONTROL BY SIM tests | |
| CT-34 | CP-060539 | 0023 | <u> </u> - | Essential corrections on TC 27.22.4.29, sequence 1.1 | 4.3.0 |
| | CP-060540 | 0021 | - | Correction of APN Coding in Open Channel test case | |
| | | 0013 | 2 | Essential corrections of BIP entries in table E.1 | 1 |
| | 1 | 0022 | 2 | Essential correction of Result TLV handling | 1 |
| | | 0024 | 1 | Essential correction of expected sequence in OPEN CHANNEL test | |
| CT-25 | CP-070062 | 0032 | | case Essential correction of Send USSD applicability | 4.4.0 |
| 01-33 | 01-070002 | 0032 | 1 | Essential correction of Send USSD applicability Essential correction of GPRS QoS parameter in BIP tests | 7.4.0 |
| | | 0036 | 1 | Test execution recommendation for terminals supporting both, SAT | 1 |
| | OD 070000 | | <u> </u> | and USAT | |
| 1 | CP-070063 | 0029 | I | Essential correction of 27.22.5.2 | Ī |

| | 0027 | 1 | Essential correction of Terminal Profile Support table |
|--|------|---|--|
| | 0026 | 1 | Essential correction of 27.22.4.13.1 Expected Sequence 1.7 |

History

| | Document history | | | | | | | |
|--------|------------------|-------------|--|--|--|--|--|--|
| V4.0.0 | March 2006 | Publication | | | | | | |
| V4.1.0 | June 2006 | Publication | | | | | | |
| V4.2.0 | September 2006 | Publication | | | | | | |
| V4.3.0 | November 2006 | Publication | | | | | | |
| V4.4.0 | March 2007 | Publication | | | | | | |