

# Design Review and C++

TURTLE Hatchling





Short introduction.

More on Week 7 - Programming and Git/GitHub

# Python and C++



A lot of ENGR 102 applies to C++.

There are a few new ideas but most are closely related

**PYTHON** 

Runtime Language
Unnamed variable types in declaration
Memory managed automatically
Colons
White space dependent

Basic Structures
Types of loops
Functions
Case-sensitive
Used for microcomputers
Extensive Libraries
Widely used in industry
Many use cases

Compiled Language
Named variable types
Manual memory management
Pointers
Curly Brackets
White space independent
Semi-colons at the end of statements

C++

# **Syntax**



The syntax of C++ is similar to the syntax of Python, with some key differences:

- All lines of code <u>must</u> end with a semicolon
- Whitespace like indents and new lines do not matter to C++
  - You should still make your code easy to read though
- Rather than using indents for loops, if-else, functions, etc., you use {curly braces}
- When creating variables, you must specify the type of variable
  - string, char, int, float
  - This is called static typing (as opposed to Python's dynamic typing)

### Variable Declaration



### Python

```
num = 100
dec1 = 100.5
dec2 = 100.5
letter = 'a' # "a" also acceptable
word = 'text' # "text" also acceptable
arr = [0, 1, 2]
```

#### C++

```
int num1 = 100;
float dec2 = 100.5; // less precise
double dec1 = 100.5; // more precise
char letter = 'a'; // must be 'a'
// requires '#include <string>'; way better than c-string
String letters = "text"; // must be "text"
int arr[3] = {0, 1, 2};

// alt version
int num2; // define
num2 = 100; // initialize, Required to be inside a function
```

Auto assigns type

Must assign type

## Variable Data Types




- Integers [int] (Default is signed 4 bytes)
  - o unsigned [unsigned int] Only allows positive numbers or zero
  - size
    - [short int] 2 bytes
    - [long int] 4 bytes
    - [long long int] 8 bytes
- Decimals
  - Float [float] 7 decimal digits of precision
  - Double [double] 15 decimal digits of precision
- Boolean [bool] True or False
- Character [char] A single character
- String [String] An array of characters

# Bits / Bytes



A bit represents a single binary value

- Only two possible values
- 0 or 1, on or off, true or false



A byte is a group of 8 bits

- 2<sup>8</sup> (256) possible values
- Originally arose from 8 bits being used to encode a single character (the char variable type still uses this!)

It is rare to work on memory at the bit-level, most of the time you are at least working at the byte-level

## For Loops



### Python

```
for i in range(0,3,1): # Start, End, Step
  print('Loop', i)
```

output:

Loop 0

Loop 1

Loop 2

```
C++
```

```
for(int i=0, i<3, i++){ // Start, End, Step
    std::cout << ("Loop " + i) << std::endl;
}</pre>
```

Required to declare looping variable type

### If Else Statements



### **Python**

```
if grade >= 90:
  cont dgre pln = True
  dunk on friends()
elif grade >= 70:
  cont dgre pln = True
else:
  cont dgre pln = False
```

#### C++

```
if (grade >= 90) {
    cont dgre pln = true;
    dunk on friends();
else if (grade >= 70) {
    cont dgre pln = true;
else {
    cont dgre pln = false;
    cry();
```

Curly brackets {} required

### Classes



Classes are an essential part of higher-level programming. They're kind of like creating your own variable type. You can:

- Choose what data your class will store
- Create functions that instances of your class can perform
  - These are typically called "methods"

Instances of a class are called "objects". You create objects in a very similar way to how you create a variable.

## **Using Classes**



### To create an instance of a class (an object):

#### Declaration:

```
O MyClass myObj; // create an object of MyClass called myObj
```

#### Initialization:

- To initialize an object, we use the special method called the constructor
- To call the constructor, we call it like a normal function that has the class's name
- o myObj = MyClass(arguments); // data in the object will be set according to the arguments you enter
- To find out what arguments to use, <u>you should consult the documentation!</u>

### Using methods

- o myObj.methodName(arguments);
- Again, to find out about the methods a class has, <u>you should consult the</u> <u>documentation!</u>

### **Best Practices**



- Plan before you code
- Develop code iteratively
- Comments should only explain that which is not obvious
  - Abstracted description of what a class/function does too
  - Do not copy the comment style in our example code. It is terrible for a real piece of code.
- Progressively indent loops and anything in curly brackets
- Add line breaks between unrelated thoughts
- Descriptive variable names (a, b, c are not good names)



# **Signal Processing**


### **GPIO Pins**



At the most basic level, the microcontroller either:

- Outputs a voltage to a pin
  - Often called a "write"
- Measures an input voltage from a pin
  - Often called a "read"

These voltages are called **signals** 




# Types of signal




### **Analog**

- Continuous
- How the real world works
- Infinitely many data points
- Signal noise may corrupt data
- For example, could spin a motor at variable speeds



### **Digital**

- Discrete, most commonly either 0 or 1 (called a bit)
- How computers work
- Higher sample rate better replicates continuous data
- For example, could turn an LED either off or on



### Communication



- Serial Communication
  - A series of bits sent over a single wire
- SPI
  - Fast
  - Requires four wires {SCLK, MOSI, MISO, SS (CS)}
- |2C
  - Better power consumption
  - Better for large number of peripherals
  - Requires two wires {SDA, SDL}

## **Controlling electronics**



### Most basic tools/functions for using electronics:

- pinMode(pin, mode)
  - Sets a pin to either OUTPUT mode or INPUT mode
    - (or INPUT\_PULLUP, dw about this for now)
  - Remember to do this in setup () for any pins you're using
- digitalWrite(pin, value)
  - "Writes" either a 0 or a 1 (LOW or HIGH) voltage to the specified pin
- digitalRead(pin)
  - "Reads" either a 0 or a 1 (LOW or HIGH) voltage from the pin

### Other useful functions



#### Some other useful functions

- Serial.begin (baud rate)
  - Starts the serial monitor at the specified baud rate (determines how many bits per second are sent)
  - Remember to do this in setup () if you plan on printing any debugging messages, and update platformio.ini with:
    - monitor speed = baud rate
- Serial.println(printable)
  - Prints out a message or value onto the serial monitor
  - Must have used Serial.begin (baud\_rate) before using this
- analogRead (pin) and analogWrite (pin, value)
  - o Analog versions of digitalRead and digitalWrite, probably won't have to use these
  - Only work on certain pins, check the ESP32 pinout before using



# Design Review


# What is a Design Review



It is an opportunity to get a new set of eyes on your solution and improve the design

Design Reviews often target

- Scope Creep
- Team alignment
- Potential issues and prevention
- Often happens in industry!
  - good to experience



Note: Aerospace is particularly structured with design reviews. PDR, CDR, and FRR are extremely common

## Important things to consider



- Manufacturing
  - Can parts be easily 3D-Printed?
- Sensors
  - How are they integrated and what is the input/output?
- CAD
  - Are the COTS item CAD available online
- Initial ideas:
  - How did you approach the concept?

### We Lied. Well kinda...



You'll actually be completing the project in teams of **3**. You do get to pick your own teammates. Just make sure you are under the **same Hatchling organization**.

Team formation will be sent in your orgs communication platform

### Why?

- Advanced projects are team based. Developing soft skills is just as important as technical skills
- Spreads out the workload
- Collaboration inspires innovation
- Financially responsible:)

### **Collaboration Recommendations**



Communication: Create a private discord message chat or text group chat

**CAD:** Create a shared drive among the team. Members can access SolidWorks files via GOOGLE Drive App without downloading/uploading files. (Cannot download on VOAL)

**Code:** Github (Discussed in Week 7 - Programming and Git/GitHub)



# **Breakout Groups!**

We will look over y'all's designs to give some feedback, nothing crazy but just to get you guys on the road!

### **Action Plan**



Split the room into groups of five!

One section will verify software installs Others will be doing the design review

#### Everyone will:

- Have their individual designs reviewed by a director
  - We will spend roughly five minutes on each design. Feel free to ask for more insight after everyone has gone.
- Verify GitHub account and PlatformIO VS Code setup
- Begin team formation

### **Next Milestone**



Milestone: Assembly Review

Date: Week 7: Programming and Git/GitHub (2 weeks from today)

**Expectation:** Have a detailed sketch and begin CAD of the drive system. Decide on the electronics you will use.

**Exceed Expectation:** Have a CAD assembly of a drive system. Have a finished electronics wiring diagram.

**Impact:** We will review design viability and suggest improvements. Potential to prototype your mechanism.



# SolidWorks Assembly

Next Week

Don't forget to fill out the team formation form!

