ECE 220 Computer Systems & Programming

Lecture 3 – Repeated Code: TRAPs and Subroutines

September 3, 2019



- MP1 due Thursday, 9/5, by 10pm
- Schedule mock quiz for extra credit



Outline

- Chapter 9
- Repeated code: TRAPs and Subroutines
- Key concepts
 - Lookup table: for starting address of subroutines/TRAPS (vector table)
 - Preserving register and PC values
- Instructions
 - TRAP
 - RET
 - JSR, JSRR

Last Class Example (memory Mapped I/O)

- Requires knowledge of the hardware
- One could mess up hardware registers

```
1 .ORIG x3000
3 KPOLL LDI RO, KBSR; Test For Character Input
          BRzp KPOLL
          LDI RO, KBDR
6 DPOLL LDI R1, DSR ; Test Display Regster is ready
          BRzp DPOLL
          STI RO, DDR
 9 HALT
10
                  ; Address of KBSR
  KBSR .FILL xFE00
                  ; Address of KBDR
12 KBDR .FILL xFE02
13 DSR .FILL xFE04 ; Address of DSR
14 DDR .FILL xFE06 ; Address of DDR
15 .END
```


Solution: TRAP Service Routine


- —It is desirable to provide service routines or system calls (part of operating system) to safely and conveniently perform low-level, privileged operations
 - User program invokes system call
 - Operating system code performs operation
 - Returns control to user program

How to make this idea work?

User program invokes TRAP subroutine; OS code performs operation; Returns control to user program

- The actual code of the service routine
- Mechanism for invocation
 - TRAP Instruction, e.g., TRAP x23
 - TRAP vector (8 bits)
 - How to find address service routine?






TRAP Vector Table for LC3


vector	address	symbol	routine
•••			
x20	x	GETC	read a single character (no echo)
x21	X	OUT	output a character to the monitor
x22	X	PUTS	write a string to the console
x23	X	IN	print prompt to console, read and echo
			character from keyboard
X23	X	PUTSP	write a string to the console; two chars per
			memory location
x25	X	HALT	halt the program

Look-up table decouples names of subroutines (GETC) from the location of its implementation in memory


TRAP Mechanism



TRAP Mechanism



- PC is loaded with the address of the first instruction of the corresponding service routine
 - MAR←ZEXT(trapvector)
 - MDR←MEM[MAR]
 - R7←PC (note that we save old PC in R7)
 - o PC←MDR
- Once the service routine is done, control is passed back to the user program suing <u>RET</u> instruction, which is just another name for <u>JMP R7</u> instruction
 - PC←R7 (restore old PC to return to the user program)



- o must make sure that service routine does not change R7, or we won't know where to return
- o also, must make sure R7 does not have a useful value that will be overwritten in the process of calling a TRAP

What do we need to make this work?

User program invokes or calls subroutine; OS code performs operation; Returns control to user program


- The actual code of the service routine
- Mechanism for invocation
 - TRAP Instruction, e.g., TRAP x23
 - TRAP vector
 - MAR ←ZEXT[trapvector]
 - MDR ←MEM[MAR]
 - PC←MDR
- How to return to user program after execution of OUT completes?

0.1.1		
Address	Contents	Comments
x0000		;system space;
X0023	x04A0	; Trap vector table
x00FF		; End of trap vector
x04A0	~	; code for IN
x04		; code for OUT
x3000		; user program
	TRAP x23	; call to
xFE00		; Device registers

What do we need to make this work?

User program invokes TRAP service routine; OS code performs operation; Returns control to user program

- The actual code of the service routine
- Mechanism for invocation
 - TRAP Instruction, e.g., TRAP x23
 - TRAP vector
 - MAR ←ZEXT[trapvector]
 - MDR ←MEM[MAR]
 - R7 ← PC
 - PC←MDR
- Mechanism for resuming user program
 - RET ≡ JMP R7



Address	Contents		Comments
	Contents		
x0000			;system space;
x0023	x04A0	1	; Trap vector table
x00FF			; End of trap vecto
x04A0	-	Y	; code for IN
	RET	A	
x04			; code for OUT
x3000			; user program
	TRAP x23	10	; call to
	April 1		
xFE00			; Device registers

Putting it all together: 4 Things make TRAPs work

1. TRAP instruction

- used by program to transfer control to OS subroutines
- 8-bit trap vector names one of the 256 subroutines
- 2. Trap vector table: stores starting addresses of OS subroutines
 - stored at x0000 through x00FF in memory
- 3. A set of OS subroutines
 - part of operating system -- routines start at arbitrary addresses (convention is that system code is below x3000) up to 256 routines
- 4. A linkage back to the user program (RET)
 - want execution of the user program to resume immediately after the TRAP instruction

Example:

Convert lowercase input characters to uppercase characters. The program uses a sentinel of 1 to terminate the program

```
.ORIG x3000
 2 ; Convert Lowercase Letter to Uppercase
3 ; Program terminate When press 1
 5
          LD R2, TERM
 6
          LD R3, ASCII DIFF
           NOT R3, R3;
          ADD R3, R3, \#1; 2's complement of x0020
 9 AGAIN
          TRAP x23
          ADD R1,R2,R0; Test for Terminating Character
10
11
           BRz EXIT
12
          ADD R0, R0, R3
13
           TRAP x21 ;Out
14
           BR AGAIN
15
16 EXIT
          TRAP x25 ; HALT
17
               .FILL xFFCF ;1 is used as sentinel to terminate
18 TERM
19 ASCII DIFF .FILL x0020 ; Difference between the lowercase and Uppercase ASCII
20 .END
```

Please see the Modified version (which check invalid inputs) posted on Github

TRAP Example (Needs special attention)

```
.ORIG x3000
AND RO, RO, #0
ADD R0, R0, #5
               ;init R0 and set it to 5
LD R7, COUNT
                ;Initialize to 10
IN
                ;same as 'TRAP x23'
ADD R0, R0, #1 ;increment R0
ADD R7, R7, #-1 ;decrement COUNT
HALT
.END
COUNT .FILL #10
```

- Question: What could go wrong?
- What are the values in R0 and R7 before and after IN statement?

Suggested approach:

- Caller of service routine can save (and restore): Caller-save
- Called service routine saves (and restore): Callee-save
- Saving and restoring values of registers is an example of a task computers need to perform in context switching

```
; Caller-save user program
ST RO, SaveRO
                 ; store R0 in memory
ST R7, SaveR7
                ; store R7 in memory
                   ; call TRAP which
ΙN
                   ; destroys R0 and R7
LD R7, SaveR7
                   : restore R7
                   ; consume input in R0
LD RO, SaveRO
                   : restore R0
HALT
SaveR0 .BLKW 1
SaveR7 .BLKW 1
```


What do we need to make this work? (3RD Edition Book)

User program invokes TRAP service routine; OS code performs operation; Returns control to user program

- The actual code of the service routine
- Mechanism for invocation
 - Fetch TRAP Instruction, e.g., TRAP x23
 - System Stack ← PC, PSR
 - PSR[15] is set to zero and save R6 and load R6 ← content of Saved SSP
 - MAR ←ZEXT[trapvector]
 - MDR ←MEM[MAR]
 - PC←MDR
- Mechanism for resuming user program
 - RTI
 - -pops the two values of system stack into PC and PSR.
 - Check PSR[15] and R6 is restored accordingly

Address	Contents	Comments
x0000		;system space;
x0023	x04A0	; Trap vector table
x00FF		; End of trap vecto
x04A0	4	; code for IN
	RTI	
x04		; code for OUT
x3000		; user program
	TRAP x23	; call to
	000	
xFE00		; Device registers

Key Concept: Abstraction



Observation

Example problem: Compute $y=3x^3-6x^2+7x$ for any input x > 0

Programs have lots of repetitive code fragments


```
; multiply R0 \leftarrowR1 * R2

MULT AND R0, R0, #0 ; R0 = 0


LOOP ADD R0, R0, R2 ; R0 = R0 + R2

ADD R1, R1, #-1 ; decrease counter

BRp LOOP
```



Implementation Option



Issues?

```
;; LC-3 Assembly Program
.ORIG x3000
LDI R3, Xaddr; R3 ← x
ADD R1, R3, #0;
; Multiply R4 \leftarrow R1 * R3 x^2
; Multiply R5 \leftarrow R4 * R3 x^3
; Multiply R5 \leftarrow R5 * 3 (3x<sup>3</sup>)
; Multiply R4 \leftarrow 6 * R4
```

Subroutines

- A sequence of instructions that performs a specific task (and nothing else---no side effects). This unit can then be used in programs wherever that particular task should be performed.
- Hide details of code and package them with an interface
 - Abstract away details
 - Needs only Arguments and return values
- Why is this a good idea in programming?
 - Reuse; shorter programs
 - Simplify; code comprehension
 - Teamwork; allows multiple developers to work on different pieces; libraries
- TRAPs are examples of OS subroutines

Idea

- User invokes or calls subroutine
- Subroutine code performs operation / task
- Returns control to user program with no other unexpected changes






Figure 9.7







(a) Without subroutines

(b) With subroutines

JSR and JSRR



R7 \leftarrow PC If (IR[11] == 0) PC \leftarrow BaseR Else PC \leftarrow PC+SEXT(IR[10:0])



RET \equiv JMP R7 PC \leftarrow R7

Subroutine Examples

■ Can you find the bugs in the following piece of code?

; SUBTR subroutine computes difference of two 2's complement numbers

; IN: R1, R2

; JSR SUBTR

OUT: R0 <- R1-R2

SUBTR NOT R2, R2

ADD R7, R2, #1

ADD R0, R1, R7

RET

Subroutine Examples

RET

■ Can you find the bugs in the following piece of code?

; SUBTR subroutine computes difference of two 2's complement numbers

; IN: R1, R2

; JSR SUBTR

OUT: R0 <- R1-R2


SUBTR NOT R2, R2

ADD R7, R2, #1

ADD R0, R1, R7

- Issues with this implementation
 - Argument in R2 will be changed on exit
 - Fix: save/restore R2 in the subroutine
 - \circ R7 value is modified in the subroutine, thus, we will not be able to return from it
 - Fix: do not use R7, or save/restore it in the subroutine
 - If R7 holds a useful value in the main program, it will be overwritten during the subroutine call
 - Fix: save/restore R7 in the main program
 - If SUBTR is located far enough in the memory from the point where it is called, we may not be able to reach it with JSR instruction
 - Fix: use JSRR instruction instead

Implementation (Code is on Github)



```
;; LC-3 Assembly Program
.ORIG x3000
LDI R3, Xaddr; R3 ← x
ADD R1, R3, #0;
; Multiply R4 \leftarrow R1 * R3 x^2
; Multiply R5 \leftarrow R4 * R3 x^3
; Multiply R5 \leftarrow R5 * 3 (3x<sup>3</sup>)
; Multiply R4 \leftarrow 6 * R4
```