LECTURE III

Introduction to Embedded Systems and Microcontrollers

This work by the Institute of Electrical and Electronics Engineers, UC Irvine Branch, is licensed under CC BY-NC-SA 4.0

SECTION I

Project II Review

Project 2 Review

- Official Due Date: Friday, November 15th by 11:59PM
- Ask questions and seek help (online or @Lab Hours), so you can finish it on time!
- Note: To get the \$20 refund for Fall Quarter, you must complete all Projects by the end of Fall Quarter

Learning Concepts:

- Circuit Analysis (Nodes, Voltage Drop)
- Circuit Troubleshooting
- Multimeters
- 555 Timer
- Breadboarding
- Soldering



SECTION II Project III


Project 3 Overview

 Build and program a dimmable RGB LED using the ESP32 and potentiometers.

You will learn:

- Embedded Systems
- Microcontrollers
- ESP32
- Arduino IDE
- Pulse Width Modulation (PWM)







SECTION III

What is an Embedded System?

Embedded Systems

- An embedded system is a combination of hardware and software designed for a specific purpose
 - Ex) alarm clock, camera, or MP3 player









- Contrasts from a general-purpose system, like a smartphone or laptop
 - These devices can act as an alarm, camera, and a media player combined
 - They typically have much more functionality than an embedded system

Embedded Systems

- Large-scale mechanical and electrical systems often consist of multiple, smaller embedded systems
 - Each embedded system has a function that supports the larger system
 - Ex) Airplanes in-flight entertainment system, temperature control, speed control, flight management, flight data recorder
- OPS Projects 3-7 and the Capstone project are all embedded systems

SECTION IV

Microcontrollers & ESP32

Microcontrollers

- A microcontroller (or MCU) is a small computer on a single integrated circuit
 - Complete with functionality to run and store programs
- An architecture defines the organization of hardware within the computer
 - MCUs have different architectures
 - ex. ESP32, ATmega, etc.




ESP32 Microcontroller Family

ESP32-C3Fx4 Board

- The ESP32-C3Fx4 board in your OPS kits was developed by WeAct Studios
- The ESP32 board is hobbyist-friendly
 - Wi-Fi and Bluetooth capabilities
 - ESP32 chip itself contains the processor, RAM, and flash storage
 - In OPS, we will refer to the
 ESP32-C3Fx4 board as an ESP32
 from now on for convenience

The MCU is **an SOIC** soldered to the board



ESP32-C3Fx4

SECTION V

Arduino IDE

Arduino IDE

- We will write code, compile, and upload it to the ESP32 board from our personal computers using the Arduino IDE software kit
- Download the latest IDE installer here

Arduino IDE 2.0.1


and even a live debugger.

documentation

section below. SOURCE CODE

GitHub.






Arduino IDE Setup for ESP32 (cont.)


Step 2: Once it's installed, open Arduino IDE

 Go to File -> Preferences -> paste in this link under "Additional Boards Manager URLS", then click OK: https://dl.espressif.com/dl/package_esp32_index.json





Download ESP32 Board library



- Click on the board manager tab on the right hand side
- Type in "esp32" into the search bar
- Install the library made by "Espressif Systems"

Setting the Target Board

```
File Edit Sketch Tools Help

Select Board


demo_sketch.ino.ino

1 //
2
3 void setup() {
4 // put your setup code here, to run once:

5
6 }
7
```

- Before we can upload a sketch, we must connect the ESP32 board via the USB-C to USB-A cable to the computer and configure the IDE to the correct board and USB port
- Open the Select Board dropdown and select an available ESP32 board
 - If no option appears, click Select other board and port...

Setting the Target Board (Cont'd)



Creating a Sketch

```
File Edit Sketch Tools Help


Select Board

demo_sketch.ino.ino

1 //
2
3 void setup() {
4 // put your setup code here, to run once:
5
6 }
7
```

- An Arduino source code file is called a sketch and has the .ino extension
- When the IDE opens, a new sketch will be created automatically or a previous sketch will open
 - \circ To create a new sketch, select **File** \rightarrow **New Sketch** from the menu

Editing a Sketch



- Sketches can be modified from the **code editor**, which appears just below the menu
- New sketches opened in the editor come with template code

Verifying and Uploading a Sketch

```
File Edit Sketch Tools Help

Select Board

demo_sketch.ino.ino

1 //
2
3 void setup() {
    // put your setup code here, to run once:
    5
    6 }
7
```

- Before uploading the sketch, select Verify (the checkmark icon) to compile the sketch
- Once the sketch compiles successfully, select **Upload** (the **right arrow** icon) to upload the compiled sketch to the Arduino board

SECTION VI


Basic ESP32 Pins

ESP32 Pinout Diagram

WeAct Studio ESP32-C3Fx4 Mini Core

PINOUT


- A pinout diagram is included for the ESP32
- General Purpose
 Input/Output (GPIO)
 pins are pins that can
 be set as either INPUT
 or OUTPUT.



- These are the analog and digital pins marked by the pinout diagram
- We will design an Arduino sketch to control these pins


Digital Pins

WeAct Studio ESP32-C3Fx4 Mini Core PINOUT



Prototyping with the ESP32

- The ESP32 can be seated along the DIP channel of a standard breadboard just like a DIP IC
- The ESP32's USB port should be oriented away from the board, so the connected cable doesn't obstruct the breadboard
- Circuits that interface with the ESP32 board must share a common ground with the GND pin of the board



SECTION VII

Sketch Structure

Sketch Structure

- Sketches are written in the Arduino language, which is much like C++
- Assign pins as global variables at the beginning of the sketch:

```
const int pinName = pin#;
```

- Each GPIO pin is associated with an integer
- Don't place the global variables inside functions (otherwise it won't be a global variable!)

```
const int RECEIVER = 8;
const int LED = 7;
void setup()
   pinMode(LED, OUTPUT);
   pinMode(RECEIVER, INPUT);
   Serial.begin(115200);
void loop()
   Serial.println(analogRead(RECEIVER));
   digitalWrite(LED, HIGH);
```

Sketch Structure (Cont'd)

- Just like the C++ main function,
 Arduino IDE has built-in functions
 setup and loop, which must be defined by the programmer
- setup() runs once at the beginning of program execution
 - Used to initialize pin modes
- loop () runs repeatedly in an infinite loop

```
const int RECEIVER = 8;
const int LED = 7;
void setup()
   pinMode(LED, OUTPUT);
   pinMode(RECEIVER, INPUT);
   Serial.begin(115200);
void loop()
   Serial.println(analogRead(RECEIVER));
   digitalWrite(LED, HIGH);
```

Things to do in setup

- pinMode(int pin, int mode)
 - Call this function for each digital pin you want to use
 - Pass the global variable assigned to each pin to the pin parameter
 - Specify if your pin is INPUT or OUTPUT mode
 - We read data from input pins and send data to output pins

```
const int LED = 7;
const int RECEIVER = 8;

void setup()
{
    pinMode(LED, OUTPUT);
    pinMode(RECEIVER, INPUT);
    Serial.begin(115200);
}
```

Things to do in setup (Cont'd)

- Serial.begin(115200)
 - Serial is an object that facilitates communication between the ESP32 board and the computer via USB
 - Used to print statements to the computer
 - Pass 115200 bits per second as the argument for this member function
 - Known as the baud rate

```
const int LED = 7;
const int RECEIVER = 8;

void setup()
{
   pinMode(LED, OUTPUT);
   pinMode(RECEIVER, INPUT);
   Serial.begin(115200);
}
```

SECTION VIII

Arduino IDE Functions


Digital Pin Functions



- digitalWrite(int pin, int value)
 - Sets the voltage at the output pin to either a
 HIGH (3.3V) or LOW (0V) value
- digitalRead(int pin)
 - Reads the voltage at the input pin, returning
 нісн (3.3V) or Low (0V) as an integer (1 or 0)
- Analogy light switch and light bulb:
 - You use the switch to set the bulb to either MAX brightness or MIN brightness

Digital Signals

- Computers (and microcontrollers) transfer data across wires/lines as digital (discrete) voltage signals
 - These signals are either a HIGH or LOW voltage
 - Contrasts from analog signals which can be values in a continuous range



Digital signals are translated to the Binary number system (1s and 0s)

More Basic Functions

- delay(int ms)
 - Pauses the program execution by ms milliseconds
- Serial.print("Message")
 - Sends a string to the computer connected via USB and displays the string on the Serial Monitor in the IDE
- Serial.println("Message")
 - Sends a string to the computer connected via USB and displays your string on the Serial Monitor in the IDE, followed by a newline

Using the Serial Monitor

- While the ESP32 board is connected to the personal computer via USB, select
 Serial Monitor (the magnifying glass icon) in the IDE
 - A pane will appear at the bottom of the IDE window which displays all data sent by the ESP32 board using Serial.print

Using the Serial Monitor (Cont'd)

```
File Edit Sketch Tools Help

Select Board

demo_sketch.ino.ino

1 //
2
3 void setup() {
4 // put your setup code here, to run once:
5
6 }
7
```

- In the absence of a debugger (the ESP32 is not capable of using one),
 Serial.print is an excellent tool to help debug programs
 - Print values to track across parts of your program
 - Unexpected values displayed to the Serial Monitor indicates an error

Analog Pin Functions



- analogWrite(int pin, int value)
 - Sets the average voltage on digital output pin to a value in the range 0-255 (0V to 3.3V)
 - This is a function for ~ PWM pins only
- analogRead(int pin)
 - Reads the voltage at the input pin, maps it to a value in the range 0-1023 (0V to 3.3V) and returns that value
 - Use the aliases A0, A1, A2... for the pin number
- Analogy light dimmer:
 - You use the slide to set the bulb to anywhere between MAX brightness or MIN brightness


ADC and analogRead

- analogRead utilizes the analog-to-digital converter inside the microcontroller to measure the real-world, analog signal and convert it to a digital signal
 - The measurement resolution is 10 bits, which is why the function returns values from 0-1023



PWM


- The ESP32 board (the underlying AVR microcontroller) is a digital source, meaning it can only output a HIGH (5V) or LOW (0V) voltage
 - Then how does analogwrite output analog signals?
- Pulse Width Modulation (PWM) is an oscillating digital waveform that emulates an analog output
 - By oscillating a signal from HIGH to LOW quickly, the average voltage over time will be between HIGH and LOW - an analog value




The average value, the analog value, of this waveform is **2.5V**

PWM Duty Cycle

- The duty cycle of the PWM wave is the percentage of time where the signal is HIGH
 - For example, a 50% duty cycle translates to an average value of 2.5V (50% of 5V)
 - Allows us to output a continuous range of voltages between HIGH and LOW
 - Duty cycle is controlled by a timer inside the AVR microcontroller



Arduino Reference Library



- Learn more about Arduino functions and libraries <u>here</u>
- The Arduino Reference Library includes support for devices like LCDs, Sensors, and WiFi modules


SECTION IX

Digital LED Circuit Exercises

Digital LED Circuit



Build the circuit below from the schematic. Then, complete the template code, flash it to the ESP32 board, and verify the circuit.



```
// Assign variable to pin number for LED


void setup() {
    // Configure LED pin's behavior to OUTPUT
    // Configure the Serial baud rate
}

void loop() {
    // Set LED pin to HIGH
}
```

Digital Blinking LED Circuit




Build the circuit below from the schematic. Then, complete the template code, flash it to the ESP32, and verify the circuit.



```
void setup() {
void loop() {
```


Potentiometers

- A potentiometer is a three-terminal variable resistor
- We will use the potentiometer as a voltage divider - a circuit which accepts a supply voltage and outputs a voltage which is a fraction of the supply voltage
- The voltage of the potentiometer's output pin ranges between the VCC and GND pin voltages



Potentiometers (Cont'd)

- Internally, a resistive strip connects its VCC and GND pins
 - A rotating wiper connects the output pin to the strip
- The greater the distance along the strip between the wiper and the VCC pin, the greater the resistance between the wiper and VCC
- The wiper reduces the voltage at the output pin the further it is turned clockwise (toward GND)



Digital Dimmable LED Circuit



Build the circuit below from the schematic. Then, complete the template code, flash it to the ESP32, and verify the circuit.

```
void setup() {
  // Configure the LED pin's behavior to OUTPUT
  // Configure the Pot pin behavior to INPUT
void loop() {
```

FAIR USE DISCLAIMER

Copyright Disclaimer under section 107 of the Copyright Act 1976, allowance is made for "fair use" for purposes such as criticism, comment, news reporting, teaching, scholarship, education and research.

Fair use is a use permitted by copyright statute that might otherwise be infringing.

Non-profit, educational or personal use tips the balance in favor of fair use.

CC BY-NC-SA 4.0

This work by the Institute of Electrical and Electronics Engineers, UC Irvine Branch, is licensed under CC BY-NC-SA 4.0