## LECTURE V

## **Communication Protocols I**


This work by the Institute of Electrical and Electronics Engineers, UC Irvine Branch, is licensed under CC BY-NC-SA 4.0

SECTION I

## **Project IV Review**


#### **Project 4 Review**

 Build a sundial that measures the brightness of your room by controlling a micro servo with an ESP32 and photoresistor.



#### Learning Concepts:

- ESP32 (Continued)
- Servos
- Arduino Libraries
- Tips for Programming in Arduino IDE



#### **Project Extension Requests**

- Considerations for a project extension:
  - Legitimate reason, or prove you've made significant progress (We appreciate honesty!)
  - Plan and timeline to finish the project(s)
- Deadline: Sunday 1/12/2025 to submit an extension for projects 3 and/or 4



#### **Fall Quarter Feedback Form**

- Complete Projects 1-4 + Feedback survey from fall quarter for \$20 refund
  - Refunds will be processed by week 3
  - We appreciate your feedback!





#### **Project 5**

- Build and program a music player with ESP32, customized to play your own tunes.
- Due date: 1/24/2025 at 11:59PM

#### **Learning Concepts:**

- Communication Protocols
- UART
- Pull-Up Resistor Circuits
- Serial Library






#### SECTION I

# What are Communication Protocols?


#### Communication

- Devices, like your home computer,
  communicate with other devices
  - i.e. mouse, monitor, printer, webcam, speakers, ESP32
- Industry focusing on this is called
  Internet of Things (IoT)




#### **Communication Media**

- Devices communicate over different media
  - i.e. copper wire, radio, fiber optic wire, etc.
  - Media can be wired or wireless
- Devices communicate by transmitting and receiving electrical signals over a shared medium
  - Signals may be digital (1s and 0s) or analog (i.e. AM/FM radio)



#### **Communication Protocols**



- Like humans, communicating devices must share a common "language" to understand messages transmitted between them
- The rules for how we send, receive, and interpret these signals are defined by protocols
- You already know of some protocols...

#### **Communication Protocols (Cont'd)**

- Your smartphone communicates with your wireless earbuds over a **Bluetooth** protocol
- All the laptops in the lecture hall connect to a wireless router using a WiFi protocol (a.k.a IEEE 802.11x)
- Your wired mouse connects to your computer using a Universal Serial Bus (USB) protocol








#### **Serial vs Parallel Protocols**

- Serial bits are sent over a connection one by one to a device
  - Bits are sent in a specific order
  - The most common protocols are serial
- Parallel multiple bits (often one byte) are sent simultaneously over a connection
  - This connection requires more wires, which takes up more space
  - Higher transmission rate




#### **Transmission Modes**

 Simplex protocols allow communication in only one direction

 Half-Duplex protocols allow communication in both directions but only in one direction at a time

 Full-Duplex protocols allow communication in both directions simultaneously






#### **UART Protocol**


- UART is a communication protocol with certain characteristics. It has rules for data transmission.
  - UART can be configured to full-duplex, half-duplex, atnd simplex modes
  - There are only two lines (electrical connections)
  - There is **no clock signal**/line hence the "asynchronous" part of the title
  - The data transmission speed is determined by a baud rate
    - It is quite slow compared to other protocols

#### **UART Layout**

- Two UARTs may be connected as pictured
  - The transmitter (TX) pin of one UART is connected to the receiver (RX) pin of the other
  - The are two data lines, which enables full-duplex communication
- Data is sent from the transmitter of one UART to the receiver of the other UART



## **UART in Project 5**




#### **UART Baud Rate**

- A UART sends and receives transmissions at the speed of the baud rate
  - It is configured by the programmer on each UART
  - Measured in bits per second
    - When you set Serial.begin (115200, that's 115200 bits per second!
- The baud rate must be equal on the two communicating UARTs to successfully send and receive the packets
  - Otherwise, messages are read at the wrong speed and become garbled

#### **UART Frame Format**

- Data is transmitted as segments of bits called packets
  - This data is sent one bit at a time (a.k.a serially) between UARTs
- Without modification, the UART packet follows this format:

#### **UART Packet**



#### **UART Frame Format (Cont'd)**

- The start bit indicates when the packet begins
  - The data transmission line goes from default HIGH voltage to a LOW
- The data frame, containing the data, follows the start bit
  - If the parity bit is used, it can be 5 to 8 bits. If the parity bit is not used, it can be 9 bits.

#### **UART Packet**



#### **UART Frame Format (Cont'd)**


- The parity bit is an optional bit comes after the data frame
  - used by the receiving UART to check if the data is free of errors
- The stop bit indicates the end of a packet
  - The data transmission line goes from LOW voltage back to default HIGH

#### **UART Packet**



#### **USB** on the ESP32

- Data is transmitted between the computer and ESP32 through a chip that converts USB signals to UART signals
  - Those converted signals are transmitted to and from the UART
- The ESP32's USB port is hardwired to the TX and RX pins of the board
- Do not use the UART while simultaneously using USB



#### **UART Trivia Questions**

• What is UART?

A: Circuit Design

**B:** Communication Protocol

C: Network

D: None of the above

What is UART?

A: Circuit Design

**B: Communication Protocol** 

C: Network

D: None of the above

• UART is \_\_\_\_\_.

A: Simplex

B: Half-Duplex

C: Full-Duplex

D: All of the above

• UART is \_\_\_\_\_.

A: Simplex

B: Half-Duplex

C: Full-Duplex

D: All of the above

 True or false: The (TX) pin of one UART is connected to the (TX) pin of the other

A: True

B: False

 True or false: The (TX) pin of one UART is connected to the (TX) pin of the other

A: True

B: False

**SECTION III** 

## **Arduino Serial Library**

#### **Arduino Serial Library**

- We can use the UART in ESP32 to transmit data over UART protocol
  - To do so, we will enlist the help of the <u>Serial library</u>, which is already installed in the Arduino IDE
- We will go over various functions of the Serial library in Workshop V
  - Serial.begin(int baud rate)
  - Serial.print(val/str)
  - O Serial.read()
  - Serial.write(val/str)
  - Serial.available()

## **SECTION IV**

# Pull-Up Resistor Circuits

#### **Project 5 Requirements**

#### **iPoduino**

You must build a MP3 Player with speaker sound using the DFPlayerMini module.

The player must have two buttons.



- In "Play" mode, the player must playback a song. It should resume the song that was previously paused if the "Skip/Next
  Song" button was not pressed.
- o In "Pause" mode, no song should be played.

The second button should be the "Skip/Next Song" button, which interrupts the current song and plays a new song.

- o Each press of this button must cycle through all songs loaded on the MicroSD card.
- If the player was in "Pause" mode when the "Skip/Next Song" button is pressed, the player must immediately enter "Play"
  mode.


The speaker must be silent when no song is played. No static or white noise.

The speaker must clearly output music when a song is played.

The circuit must be built on a breadboard.


### **Project 5 Requirements (Continued)**

We want to use a pushbutton to trigger an event / for a specific purpose




#### Reading Button Inputs w/ ESP32

- We will use digitalRead(int pin) to read the button's inputs.
  - Reads the voltage at the input pin, returning HIGH (3.3V) or LOW (0V) as an integer (1 or 0)
  - When the button is pressed, pin 10 is connected to GND
  - But how about the when the button is not pressed?




#### **Floating Signal**

- When the button is unpressed, we call it a floating signal
- Voltage at a signal can either return HIGH or LOW as an integer (1 or 0)
  - This is due to Electromagnetic interference (EMI) or unwanted noise




## **Pull-Up Resistor Circuit Exercise**

Let's build this circuit here:



#### **Pull-Up Resistor Circuit Exercise (Cont.)**

We use a Pull-Up Resistor to no longer make it floating signal



#### FAIR USE DISCLAIMER

Copyright Disclaimer under section 107 of the Copyright Act 1976, allowance is made for "fair use" for purposes such as criticism, comment, news reporting, teaching, scholarship, education and research.

Fair use is a use permitted by copyright statute that might otherwise be infringing.

Non-profit, educational or personal use tips the balance in favor of fair use.

#### CC BY-NC-SA 4.0

This work by the Institute of Electrical and Electronics Engineers, UC Irvine Branch, is licensed under CC BY-NC-SA 4.0