## PCB DESIGN: BOARD OUTLINE, POURS, & OVERLAYS

We will now move on to the next part of our PCB design where we will cover how to change the size of our board, lay down polygon pours, and edit text overlays.

1. Place tracks for your desired board outline by pressing Place > Keepout > Track.




Figure 1: Path to Place Keep-Out Track

2. Place tracks around your components as shown in Figure 2.




Figure 2: Completed Traces for Keep-Out Layer

Author - John Morin

3. Select all of your tracks at the same time using Ctrl+Click.




Figure 3: Selected Keep-Out Tracks

4. Define the board by going to Design > Board Shape > Define from selected objects.




Figure 4: Path to Define Board Outline

5. You should now see something similar to Figure 5.




Figure 5: Successfully Defined Board Outline

6. Change the layer that your traces reside from "Top Layer" to "Keep-Out Layer" as you've learned to do in the previous part.




Figure 6: Properties to Switch Track Layers

- 7. We will now learn how to place a Polygon Pour over our existing board.
- 8. Click on Place > Polygon Pour...




Figure 7: Path to Polygon Pour

9. Click on each one of the corners of your board as shown in Figure 8 then either click the esc key or right click to exit your pour.




Figure 8: Placing a Polygon Pour

- 10. Once you've finished pouring, you need to set a net.
- 11. Access your pours properties and change its net to "GND" as shown below.




Figure 9: Selecting Net for Pour

12. You're pour should now look like Figure 10. Do not be concerned by the green x's, we will deal with them in the next step.




Figure 10: Result of Defined Net

13. Right click on your pour and repour the polygon by selecting Polygon Actions > Repour Selected.



Figure 11: Path to Repour

14. You should now see something similar to Figure 12.




Figure 12: Properly Defined Polygon

- 15. It is often difficult to see through pours to understand what the whole board is doing. To fix this, we will need to change the transparency of the pours.
- 16. Open the "View Configuration" panel by selecting View > Panels > View Configuration.




Figure 13: Path to "View Configuration"

- 17. On the side panel, select "View Options" and look under "Object Visibility".
- 18. Slide the bar labelled "Polygons" right until you are satisfied with the transparency of your polygon.



Figure 14: Making Polygons Transparent

19. Repeat steps 8-14 on your own for the bottom layer of the board. If you did it correctly, you should see something similar to Figure 15.




Figure 15: View of Completed Bottom Polygon Pour

20. You will notice that there is one final connection that needs to be made before we're complete. This is because we have an isolated polygon node due to manufacturing constraints and our positioning. The result is that the section outlined in green is disconnected from the other ground nodes.




Figure 16: View of Incomplete Node Connection

21. While we could move some components around or use vias to remedy this issue, the simplest solution for this tutorial is to just place an extra trace connecting the two nodes as shown in Figure 17.




Figure 17: View of Final Node Connection

- 22. We will now move on to the final step of our board design which is to position our labels for the different components so that when we print the boards, we will know where to solder our components.
- 23. Right click one of your labels and select "Find Similar Objects".




Figure 18: Path to Similar Objects

24. When shown this popup, make sure both "Object Kind" and "String Type" have "Same" selected on the right column. Also make sure to uncheck "Open properties".



Figure 19: Settings to Select All Labels

25. Manually open the properties panel to change the "Text Height" to 30mil and "Stroke Width" to 5 mil (Note: mil stands for one thousandth of an inch).




Figure 20: Settings to Change Size and Width of Labels

- 26. Once you finish entering your values, you should notice that your labels are much smaller than they were before.
- 27. Organize your "Top Overlay" labels as shown in Figure 21.




Figure 21: Final View of Top Overlay

28. Now do the same for the "Bottom Overlay" (Note: I used Ctrl+F to flip the board to see how it would look like looking from the other side of the board).




Figure 22: Final View of Bottom Overlay

29. Now you're done! Your board should now look like Figure 23.




Figure 23: Finished View of Our Board

- 30. Another useful feature when viewing your board is to put it into 3D view.
- 31. To do this, simply press 3 on your keyboard.
- 32. To look at the back of the board, flip it using Ctrl+F.




Figure 24: 3D View of the Front of Board




Figure 25: 3D View of the Back of the Board