# Contents

1.	Author and Contact Information	2
2.	Prerequisites	2
3.	Installation of Application Files	2
4.	Running the application	2
5.	Access data from OPC UA Client	3
6.	Tightening System Entry Point - AddressSpace View	3
7.	Asset Data	. 4
8.	Result Data	5
9.	Subscribe to Result and Requested Result Variable	5
10.	Subscribe to Result or Other Events	. 7
11.	Validate if the Client Supports Required OPC UA Features	7
12.	Event Data	8
13.	Commands Example	9

#### 1. Author and Contact Information

- Mohit Agarwal mohit.agarwal@atlascopco.com
  - o **Editor** of VDMA OPC UA Industrial Joining Technologies Working Group.
- Contact for any questions/updates/support on using the demo and extending it.

### 2. Prerequisites

- Windows Binary
  - o Windows 10 or later (Built using Windows SDK Version: **10.0.26100**).
  - Download from the following link: Windows SDK Dowload
  - o Download Visual Studio 2022 Redistributable: VC-Redist Download
- **Docker Image: Ensure** that Docker is installed and running.
- OPC UA Test Client: Download and install any OPC UA Client. Example: UaExpert Download
- IJT CS Reference:
  - o OPC 40450 Joining Base
  - o OPC 40451 Tightening

### 3. Installation of Application Files

- Download the following files in the <u>Installation Directory: OPC\_UA\_IJT\_Server\_Simulator</u>.
  - o opcua\_ijt\_demo\_application.exe
  - o Contains multiple NodeSet files in XML format as below:
    - Opc.Ua.XXX.NodeSet2.xml
  - Optional Files
    - Multiple JSON files for simulation
      - server\_configuration.json
      - simulated\_asset\_data.json
      - ...
    - Dockerfile


## 4. Running the application

- Common Steps
  - Go to the "OPC\_UA\_IJT\_Server\_Simulator" directory.
  - o The **EndpointUrl** of the OPC UA Server would be:
    - opc.tcp://localhost:40451 or opc.tcp://YourComputerName:40451.
- Windows Binary
  - Ensure that the user has Read/Write access to the Installation Directory.
  - Launch the binary file (opcua\_ijt\_demo\_application.exe).
    - Run as Administrator or at least with Read/Write access.
- Docker Image
  - o **Run** the following commands which will run the simulator in a docker container:
    - docker build -t opcua ijt demo application.
    - docker run --rm -p 40451:40451 opcua ijt demo application

### 5. Access data from OPC UA Client


- Launch the OPC UA Client and connect to the given **EndpointUrl**.
- It will show the primary entry point: TighteningSystem.
- All the Nodes shown below are as per the Companion Specification.
- The **Simulations** node is the Application Node.

# 6. Tightening System Entry Point - AddressSpace View




#### 7. Asset Data

Browse the respective Asset Nodes from the address space and subscribe/read the respective data.



#### **Example Asset Address Space View**




#### 8. Result Data

- Result Access Options:
  - Subscribe to the Result or RequestedResult variable shown below.
  - Subscribe to events by subscribing to the Server node in the Event View.
- Simulation Options
  - Use the following three methods to simulate different types of Results. A new Result is generated upon the execution of the following methods.
    - SimulateBatch\_or\_Sync\_Result
      - To generate Batch Result.
    - SimulateJobResult
      - To generate a Job Result.
    - SimulateSingleResult
      - To generate a single live Result.
    - SimulateBulkResults
      - To generate several live Results.
  - The simulated data is similar to the examples defined in the Annexure sections of the Companion Specification.

## 9. Subscribe to Result and Requested Result Variable

- Subscribe to Result Variable or RequestedResult Variable shown below.
- Result Variable is intended for getting live results.
- RequestedResult Variable is intended for getting historical results.




• The outcome can be visualized in the **Data Access View** or **Event View** if the respective **Result** variable or **Event is subscribed.** 

### **Example Result Data Access View**


#	Display Name	Value	Datatype	Source Timestamp
1	Result	Double click to display value	ExtensionObject	1:26:59.057 PM
2	ResultContent	Double click to display value	Variant	1:26:59.058 PM
3	ResultMetaData	Double click to display value	ExtensionObject	1:26:59.060 PM
4	AssemblyType	1	Byte	1:24:58.812 PM
5	AssociatedEntities	Double click to display value	ExtensionObject	1:24:58.812 PM
5	Classification	1	Byte	1:24:58.812 PM
7	CreationTime	2025-10-05T11:26:58.969Z	DateTime	1:26:59.061 PM
В	Description	"en", "Single:Tightening:Result:4"	LocalizedText	1:26:59.061 PM
9	ExtendedMetaData	Double click to display value	ExtensionObject	1:24:58.812 PM
10	InterventionType	0	Byte	1:24:58.812 PM
11	IsGeneratedOffline	false	Boolean	1:24:58.812 PM
12	IsPartial	false	Boolean	1:24:58.812 PM
13	IsSimulated	true	Boolean	1:24:58.812 PM
14	JoiningTechnology	"en", "Tightening"	LocalizedText	1:24:58.812 PM
15	Name	Single:Tightening:Result:4	String	1:26:59.061 PM
16	OperationMode	2	Byte	1:24:58.812 PM
17	ProcessingTimes	Double click to display value	ExtensionObject	1:26:59.061 PM
18	ResultCounters	Double click to display value	ExtensionObject	1:24:58.812 PM
19	ResultEvaluation	1 (OK)	Int32	1:24:58.812 PM
20	ResultEvaluationCode	0	Int64	1:24:58.812 PM
21	ResultEvaluationDetails	"en", "OK TIGHTENING"	LocalizedText	1:24:58.812 PM
22	ResultId	2924FC62-C20F-C44C-A8D4-981B77B89A73	String	1:26:59.061 PM
23	ResultState	1	Int32	1:24:58.812 PM
24	SequenceNumber	4	Ulnt64	1:26:59.061 PM

#### 10. Subscribe to Result or Other Events

- Connect to the OPC UA Server using UaExpert or any other OPC UA Client.
- Subscribe to "Server" Object. In UaExpert, Drag and Drop the "Server" Object in the following **Configuration Window** as shown below.



- Select the "Simple Event" checkbox and it shall show as checked:
- Generate a **new Result**, and the Result will be listed in the **Events Window** as shown below.




# 11. Validate if the Client Supports Required OPC UA Features

- OPC UA Client **shall support** OPC UA Extension Objects (Custom Structure Types) to **consume** the data as per the OPC UA IJT Standard.
- The quick test to validate if the Client application supports extension objects is to subscribe to **Result variable** or **Result Event** and visualize if the data is readable from the Client.
- Refer to **previous** sections on how to **subscribe** to Result variable or Result Event.


#### 12. Event Data

Invoke the **SimulateEvents method** as shown below to generate 50+ different type of events.

**Note:** The **content** of the Events would be similar to any type of event from a joining system.




#### **Example Events View**



# 13. Commands Example

An example simulation of **EnableAsset** is provided. It takes the input of the ProductInstanceUri of the Tool.

Few error cases can be simulated when the input argument is empty or invalid. A respective error is shown in the output arguments.



#### **Example Command View**

