EEM312 Laboratory

- Today:
 - About the labs
 - Overview of Spice3

EEM312 Laboratory

- Lab rules
- Lab syllabus
- Your document open password is 312lab



EEM312 Laboratory

- Lab assistants are: Levent Özparlak – Evren Emekdaş Gökhan Gültekin – Semanur Kırıcı Umut Kocatürk
- Labs are divided into two sections (same as course sections). Verify your section as soon as possible.
- Lab homepage: http://www.baskent.edu.tr/~eemekdas
- http://www.baskent.edu.tr/~ozparlak

EEM312 Laboratory

- Contents of the lab
 - Rise time, fall time, noise margin and delay measurements both in HW and SW labs
 - Datasheet comparisons with the real measurements
 - Regenerative property of logic gates
 - Ring oscillators
 - Diodes and diode based logic gates
 - MOSFET models
 - Mosfets and measurements and comparisons
 - NMOS PMOS CMOS comparisons
 - Power dissipation of inverters
 - Domino logic implementation in Spice
 - Pass transistors logic implementations
 - Transmission gates and logics

Spice3

Circuit Simulation Program

INTRODUCTION

- Installation:
 - You may download program at

http://www.winspice.com

http://www.baskent.edu.tr/~ozparlak follow the links for the related materials: yükleme

Features:

Unlimited ©

Has no schematic editor 🕾

INTRODUCTION

- WinSpice3 is a general-purpose circuit simulation program for non-linear DC, non-linear transient, and linear AC analyses
- Circuits may contain resistors, capacitors, inductors, mutual inductors, independent voltage and current sources, four types of dependent sources, lossless and lossy transmission lines, switches, uniform distributed RC lines, and the five most common semiconductor devices: diodes, BJTs, JFETs, and MOSFETs

TYPES OF ANALYSIS

- DC Analysis
- AC Small-Signal Analysis
- Transient Analysis
- Pole-Zero Analysis
- Small-Signal Distortion Analysis
- Sensitivity Analysis
- Noise Analysis
- Analysis At Different Temperatures

CIRCUIT DESCRIPTION

- The first line in the input file must be the "TITLE", and the last line must be ".END"
- An element line that contains the element name, the circuit nodes to which the element is connected, and the values of the parameters that determine the electrical characteristics of the element specifies each element in the circuit

CIRCUIT DESCRIPTION

- The title line must be the first in the input file.
- ".END" line must always be the last in the input file.
- Comments:
 - * <any comment>

CIRCUIT DESCRIPTION

- A number field may be an integer field (12, -44), a floating point field (3.14159), either an integer or floating point number followed by an integer exponent (1e-14, 2.65e3), or either an integer or a floating point number followed by one of the following scale factors:
 - T = 10¹²
 - -G = 10
 - Mea = 10⁶
 - $K = 10^3$
 - mil = 25.4-6
 - $m = 10^{-3}$
 - u (or M) = 10⁻⁶
 - N = 10⁻⁹
 - $p = 10^{-12}$
 - f = 10⁻¹⁵
- Letters immediately following a number that are not scale factors are ignored, and letters immediately following a scale factor are ignored.

CIRCUIT DESCRIPTION

.MODEL: Device Models

.MODEL MNAME TYPE(PNAME1=PVAL1 PNAME2=PVAL2 \dots) Ex: NPN Transistor

.MODEL MOD1 NPN (BF=50 IS=1E-13 VBF=50)

TYPES

- A set of device model parameters is defined on a separate ".MODEL" line and assigned a unique model name.
- For these more complex device types, each device element line contains the device name, the nodes to which the device is connected, and the device model name.

CIRCUIT DESCRIPTION

- R Semiconductor resistor model
- C Semiconductor capacitor model
- SW Voltage controlled switch
- VSWITCH Voltage controlled switch
- CSW Current controlled switch
- ISWITCH Current controlled switch
- URC Uniform distributed RC model
- LTRA Lossy transmission line model
- D Diode model
- NPN NPN BJT model
- PNP PNP BJT model
- NJF N-channel JFET model
- PJF P-channel JFET model
- NMOS N-channel MOSFET model
- PMOS P-channel MOSFET model
- NMF N-channel MESFET model
- PMF P-channel MESFET model

CIRCUIT ELEMENTS AND MODELS

Simple Resistors

RXXXXXXX N1 N2 VALUE

Ex:

R1 1 2 100 RC1 12 17 1K

Semiconductor Resistors

RXXXXXXX N1 N2 <VALUE> <MNAME> <L=LENGTH> <W=WIDTH> <TEMP=T>

Ex:

RLOAD 2 10 10K RMOD 3 7 RMODEL L=10u W=1u

 TEMP value is the temperature at which this device is to operate, and overrides the temperature specification on the .OPTION control line.

CIRCUIT DESCRIPTION

Extra information for descriptions:

.SUBCKT subnam N1 <N2 N3 ...>

.ENDS <SUBNAM>

.INCLUDE filename

.LIB filename

CIRCUIT ELEMENTS AND MODELS

Semiconductor Resistors

If value is defined

•it overrides the geometric information and defines the resistance

olf MNAME is also defined

- Resistance may be calculated from the process information in the model MNAME and the given LENGTH and WIDTH
- If value is not defined

MNAME and LENGTH must be specified

Semiconductor Resistor Model (R)

R=RSH((L-NARROW)/(W-NARROW)) $R(T)=R(T_0)[1+TC1(T-T_0)+TC2(T-T_0)^2]$

name	parameter	units	default	example
TC1	1st order Temp. coefficient	Ω/°C	0.0	
TC2	2nd order Temp. coefficient	Ω/°C²	0.0	
RSH	sheet resistance	Ω/square		50
DEFW	default width	meters	1e-6	2e-6
NARROW	narrowing due to side etching	meters	0.0	1e-7
TNOM	parameter measurement temperature	°C	27	50

CIRCUIT ELEMENTS AND MODELS

Semiconductor Capacitors

■ If value is defined

 it overrides the geometric information and defines the resistance

olf MNAME is also defined

- Resistance may be calculated from the process information in the model MNAME and the given LENGTH and WIDTH
- If value is not defined

MNAME and LENGTH must be specified

CIRCUIT ELEMENTS AND MODELS

Simple Capacitors

CXXXXXXX N+ N- VALUE <IC=initial_condition> EX:

CBYP 13 0 1UF COSC 17 23 10U IC=3V

Semiconductor Capacitors

CXXXXXXX N1 N2 <VALUE> <MNAME> <L=LENGTH> <W=WIDTH> <IC=VAL>

EX:

CLOAD 2 10 10P CMOD 3 7 CMODEL L=10u W=1u

CIRCUIT ELEMENTS AND MODELS

Semiconductor Capacitor Model (C)

CAP=CJ(LENGTH-NARROW)(WIDTH-NARROW)+CJSW(LENGTH+WIDTH-2NARROW)

name	parameter	units	default	example
TNOM	parameter measurement temperature	°C	27	50
TC1	first order temperature coefficient	&/°C	0.0	
TC2	second order temperature coefficient.	&/°C2	0.0	
VC1	first order voltage coefficient	volt-1	0.0	
VC2	second order voltage coefficient.	volt-2	0.0	
CJ	junction bottom capacitance	F/meters2		5,00E-05
CJSW	junction side wall capacitance	F/meters		2,00E-11
DEFW	default device width	meters	1,00E-06	2,00E-06
NARROW	narrowing due to side etching	meters	0.0	1,00E-07

Inductors

LYYYYYYY N+ N- VALUE <IC=initial condition>

EX:

LLINK 42 69 1UH LSHUNT 23 51 10U IC=15.7MA

Coupled (Mutual) Inductors

KXXXXXX LYYYYYYY LZZZZZZZ VALUE

EX:

K43 LAA LBB 0.999 KXFRMR L1 L2 0.87

- Coefficient of coupling must be greater than 0 and less than or equal to 1.
- Using the 'dot' convention, place a 'dot' on the first node of each inductor.

CIRCUIT ELEMENTS AND MODELS

Voltage And Current Sources

EX:

VCC 10 0 DC 6 VIN 13 2 0.001 AC 1 SIN(0 1 1MEG) ISRC 23 21 AC 0.333 45.0 SFFM(0 1 10K 5 1K) VMEAS 12 9 VCARRIER 1 0 DISTOF1 0.1 -90.0 VMODULATOR 2 0 DISTOF2 0.01 IIN1 1 5 AC 1 DISTOF1 DISTOF2 0.001

CIRCUIT ELEMENTS AND MODELS

Voltage Controlled Switch

SXXXXXXX N+ N- NC+ NC- MODEL <ON><OFF>
N± are terminal nodes, NC± are control nodes

s1 1 2 3 4 switch1 ON s2 5 6 3 0 sm2 off Switch1 1 2 10 0 smodel1

Current Controlled Switch

WYYYYYY N+ N- VNAM MODEL <ON><OFF>

EX

w1 1 2 vclock switchmod1 W2 3 0 vramp sm1 ON wreset 5 6 vclck lossyswitch OFF

For model parameters see manual

CIRCUIT ELEMENTS AND MODELS

- DC/TRAN is the DC and transient analysis value of the source. If the source value is zero both for DC and transient analyses, this value may be omitted. If the source value is time-invariant (e.g., a power supply), then the value may optionally be preceded by the letters DC.
- ACMAG is the AC magnitude and ACPHASE is the AC phase. The source is set to this value in the AC analysis. If ACMAG is omitted following the keyword AC, a value of unity is assumed. If ACPHASE is omitted, a value of zero is assumed. If the source is not an AC small-signal input, the keyword AC and the AC values are omitted.
- DISTOF1 and DISTOF2 are the keywords that specify that the independent source has distortion inputs at the frequencies F1 and F2 respectively (see the description of the .DISTO control line). An optional magnitude and phase may follow the keywords. The default values of the magnitude and phase are 1.0 and 0.0 respectively.

Pulse

PULSE(V2 V1 TD TR TF PW PER) EX:



VIN 3 0 PULSE(-1 1 2NS 2NS 2NS 50NS 100NS)

parameter	default value	units
V1 (initial value)		Volts or Amps
V2 (pulsed value)		Volts or Amps
TD (delay time)	0.0	seconds
TR (rise time)	TSTEP	seconds
TF (fall time)	TSTEP	seconds
PW (pulse width)	TSTOP	seconds
PER(period)	TSTOP	seconds

CIRCUIT ELEMENTS AND MODELS

Junction Diodes

DXXXXXXX N+ N- MNAME <AREA> <OFF> <IC=VD(initial condition)> <TEMP=T>

EX:

DBRIDGE 2 10 DIODE1
DCLMP 3 7 DMOD 3.0 IC=0.2

CIRCUIT ELEMENTS AND MODELS

Sinusoidal

SIN(VO VA FREQ TD THETA)

VIN 3 0 SIN(0 1 100MEG 1NS 1E10)

parameters	default value	units
VO (offset)		Volts or Amps
VA (amplitude)		Volts or Amps
FREQ (frequency)	1/TSTOP	Hz
TD (delay)	0.0	seconds
THETA (damping factor)	0.0	1/seconds

CIRCUIT ELEMENTS AND MODELS

Diode Model (D)

- The DC characteristics of the diode are determined by the parameters IS and N. An ohmic resistance, RS, is included
- Charge storage effects are modeled by a transit time,
 TT, and a non-linear depletion layer capacitance which is determined by the parameters CJO, VJ, and M
- Reverse breakdown is modelled by an exponential increase in the reverse diode current and is determined by the parameters BV and IBV

For model parameters see manual

Bipolar Junction Transistors (BJTs)

QXXXXXXX NC NB NE <NS> MNAME <AREA> <OFF> <IC=VBE, VCE> <TEMP=T>

EX:

Q23 10 24 13 QMOD IC=0.6, 5.0 Q50A 11 26 4 20 MOD1

CIRCUIT ELEMENTS AND MODELS

Junction Field-Effect Transistors (JFETs)

JXXXXXXX ND NG NS MNAME <AREA> <OFF> <IC=VDS, VGS> <TEMP=T>

EX:

J1 7 2 3 JM1 OFF

CIRCUIT ELEMENTS AND MODELS

- The DC model is defined by the parameters IS, BF, NF, ISE, IKF, and NE which determine the forward current gain characteristics, IS, BR, NR, ISC, IKR, and NC which determine the reverse current gain characteristics, and VAF and VAR which determine the output conductance for forward and reverse regions.
- Three ohmic resistances RB, RC, and RE are included, where RB can be highly current dependent. Base charge storage is modelled by forward and reverse transit times, TF and TR, the forward transit time TF being bias dependent if desired.
- CJE, VJE, and MJE determine non-linear depletion layer capacitances for the B-E junction, CJC, VJC, and MJC for the B-C junction and CJS, VJS, and MJS for the C-S (Collector-Substrate) junction.

For model parameters see manual

CIRCUIT ELEMENTS AND MODELS

- JFET Models (NJF/PJF)
 - LEVEL=1 -> Shichman-Hodges
 - LEVEL=2 -> Parker-Skellern FET model
- In both models, the DC characteristics are defined by the parameters VTO and BETA, which determine the variation of drain current with gate voltage, LAMBDA, which determines the output conductance, and IS, the saturation current of the two gate junctions. Two ohmic resistances, RD and RS, are included.

MOSFETs

MXXXXXXX ND NG NS NB MNAME <L=VAL> <W=VAL> <AD=VAL> <AS=VAL> <PD=VAL> <PS=VAL> <NRD=VAL> <NRS=VAL> <OFF> <IC=VDS. VGS. VBS> <FEMP=T>

Ex:

M1 24 2 0 20 TYPE1
M31 2 17 6 10 MODM L=5U W=2U
M1 2 9 3 0 MOD1 L=10U W=5U AD=100P AS=100P PD=40U PS=40U

- PD and PS are the perimeters of the drain and source junctions
- NRD and NRS designate the equivalent number of squares of the drain and source diffusions

BATCH OUTPUT

.PLOT

.PLOT PLTYPE OV1 <(PLO1, PHI1)> <OV2 <(PLO2, PHI2)> ... OV8> EX:

.PLOT DC V(4) V(5) V(1) .PLOT TRAN V(17, 5) (2,5) I(VIN) V(17) (1,9) .PLOT AC VM(5) VM(31, 24) VDB(5) VP(5) .PLOT DISTO HD2 HD3(R) SIM2 .PLOT TRAN V(5,3) V(4) (0,5) V(7) (0,10)

V(N1<,N2>)

- V magnitude (same as VM below)
- VR real part
- VI imaginary part
- VM magnitude
- VP phase (in radians or degrees see the units variable description)
- VDB 20 log10(magnitude)

Analyses

.TRAN: Transient Analysis

.TRAN TSTEP TSTOP <TSTART <TMAX>>

.TRAN 1NS 100NS

TRAN 1NS 1000NS 500NS

.TRAN 10NS 1US

- TSTEP is the printing or plotting increment for line printer output. For use with the post processor, TSTEP is the suggested computing increment.
- TSTOP is the final time, and TSTART is the initial time. If TSTART is omitted, it is assumed to be zero. The transient analysis always begins at time zero. In the interval <zero, TSTART>, the circuit is analysed (to reach a steady state), but no outputs are stored. In the interval <TSTART, TSTOP>, the circuit is analysed and outputs are stored.
- TMAX is the maximum step size that WinSpice3

BATCH OUTPUT

I(VXXXXXXXX)

Specifies the current flowing in the independent voltage source named VXXXXXXX

- I magnitude (same as IM below)
- IR real part
- II imaginary part
- IM magnitude
- IP phase (in radians or degrees see the units variable description)
- IDB 20 log10(magnitude)
- Question:

How do we measure a current flowing in a branch?



