

Three devices on the I2C0 bus but only U97 is interesting.

Device addr 0x20 has presence detect for FMC boards if they drive a signal low
P10 is FMC_HPC0_PRSNT_M2C_B
P11 is FMC_HPC1_PRSNT_M2C_B

The Abaco FMC216 boards have three I2C devices addr 0x1C CPLD Used for SPI bus access, status etc. addr 0x50 EEPROM – Do not access addr 0x20 Voltage/Temp monitor

Two devices on the I2C1 bus
U34 is mainly ZCU102 clock chips.
U135,Device addr 0x75, enables I2C paths to FMC boards.
SC0 is FMC_HPC0_IIC_SDA/SCL
SC1 is FMC_HPC1_IIC_SDA/SCL

Five devices on the **SPI** bus. Read/write through CPLD registers. 4x DAC39J84 4-channel DACs 1x LMK04028B Clock generator

Progamming:

- 1. Read P10 and P11 pins on I2C0 port expander at address 0x20 to determine if one or two boards are connected.
- 2. Write to U135 on I2C1 at address 0x75 to enable I2C1 connection to FMC216 board 0.
- 3. Write to CPLD on board 0 to configure each DAC chip and the clock generator over the SPI bus.
- 4. If FMC216 board 1 is present, write to U135 on I2C1 at address 0x75 to disable I2C1 connection to FMC216 board 0 and connect it to board 1.
- 5. Write to CPLD on board 1 to configure each DAC chip and the clock generator over the SPI bus.