# **Microprocessors & Interfacing**

Interrupts (II)

Lecturer: Annie Guo

COMP9032 Week7

1

#### **Lecture Overview**

- Interrupts in AVR
  - External interrupts
  - Internal interrupts
    - Timers/Counters

COMP9032 Week7 2


#### **External Interrupts**

- The external interrupts are triggered through the INT7:0 pins.
  - If enabled, the interrupts can be triggered even if the INT7:0 pins are configured as outputs
    - This feature provides a way of generating a software interrupt.
  - Can be triggered by a falling or rising edge or a logic level
    - Specified in External Interrupt Control Register
      - EICRA (for INT3:0)
      - EICRB (for INT7:4)

## **External Interrupts (cont.)**


- To enable an external interrupt, two bits must be set
  - I bit in SREG
  - INTx bit in EIMSK
- To activate an external interrupt, the following must be met:
  - The interrupt must be enabled
  - The associated external pin must have a designed signal asserted.

COMP9032 Week7 3 COMP9032 Week7 4



#### **EIMSK**

- External Interrupt Mask Register
  - A bit is set to enable the related interrupt



COMP9032 Week7

6

#### **EICRA**

5

7

- External Interrupt Control Register A
  - For INT0-3
  - Defines the type of signal that activates the external interrupt
    - on rising or falling edge or level sensed.

Bit	7	6	5	4	3	2	1	0
(0x69)	ISC31	ISC30	ISC21	ISC20	ISC11	ISC10	ISC01	ISC00
Read/Write	R/W							
Initial Value	0	0	0	0	0	0	0	0

ISCn1	ISCn0	Description
0	0	The low level of INTn generates an interrupt request
0	1	Any edge of INTn generates asynchronously an interrupt request
1	0	The falling edge of INTn generates asynchronously an interrupt request
1	1	The rising edge of INTn generates asynchronously an interrupt request

COMP9032 Week7

#### **EICRB**

- External Interrupt Control Register B
  - For INT4-7
  - Defines the type of signals that activate the External Interrupt
    - on rising or falling edge or level sensed.

Bit	7	6	5	4	3	2	1	0
(0x6A)	ISC71	ISC70	ISC61	ISC60	ISC51	ISC50	ISC41	ISC40
Read/Write	R/W							
Initial Value	0	0	0	0	0	0	0	0

Table 15-3. Interrupt Sense Control<sup>(1)</sup>

		•	mapt conce control
	ISCn1	ISCn0	Description
	0	0	The low level of INTn generates an interrupt request
	0	1	Any logical change on INTn generates an interrupt request
	1	0	The falling edge between two samples of INTn generates an interrupt request
ĺ	1	1	The rising edge between two samples of INTn generates an interrupt request

#### **EIFR**

- Interrupt flag register
  - A bit in the register is set when an event-triggered interrupt is enabled and an event on the related INT pin happens.

7	6	5	4	3	2	1	0
INTF7	INTF6	INTF5	INTF4	INTF3	INTF2	INTF1	INTF0

COMP9032 Week7

## **Example 1 (solution)**

- Use an external interrupt
  - Connect the external interrupt pin to a push button
  - When the button pressed, the interrupt is generated
- In the assembly code
  - Set up the interrupt
    - · Set up the interrupt vector
    - Enable the interrupt
  - Write a service routine for this interrupt
    - Change the display pattern
    - Write the pattern to the port connected to the LEDs


## **Example 1**

• Design a system, where the state of LEDs toggles under the control of the user.



COMP9032 Week7

10



11

#### **Code for Example 1**

```
.include "m2560def.inc"
.def
          temp = r16
.def
          output = r17
.def
          count = r18
                                         ; number of interrupts
          PATTERN = 0b01010101
.egu
                                         ; set up interrupt vectors
          imp RESET
          INT0addr
                                         ; defined in m2560def.inc
.org
          imp EXT INTO
RESET:
          ser temp
                                         ; set Port C as output
          out DDRC, temp
          out PORTC, temp
          ldi output, PATTERN
                                                   : continued
```

COMP9032 Week7

13

#### **Code for Example 1 (cont.)**

```
: continued
          Idi temp, (2 << ISC00); set INTO as falling edge triggered interrupt
          sts EICRA, temp
          in temp, EIMSK
                                          ; enable INTO
          ori temp, (1<<INT0)
          out EIMSK, temp
                                          ; enable Global Interrupt
          sei
          jmp main
EXT_INT0:
          push temp
                                          ; save register
          in temp, SREG
                                          ; save SREG
          push temp
                                          ; flip the pattern
          com output
          out PORTC, output
          inc count
          pop temp
                                          ; restore SREG
          out SREG, temp
          pop temp
                                          ; restore register
          reti
```

# **Code for Example 1 (cont.)**

```
; continued
                    ; main -
main:
          clr count
          clr temp
loop:
          inc temp
                               ; a dummy task in main
           cpi temp, 0xF
                               ; the following section in red
           breg reset temp
                               ; shows the need to save SREG
                               ; in the interrupt service routine
          rjmp loop
reset_temp:
          clr temp
           rjmp loop
```

## **Example 2**

- Based on Example 1, implement a software interrupt
  - When there is an overflow in the counter that counts LED toggles, all LEDs are turned on.

COMP9032 Week7 15 COMP9032 Week7 16

14

#### **Example 2 (solution)**

- Use another external interrupt as software interrupt
  - Software generates the external interrupt request
- In main program, test if there is an overflow,
  - If there is an overflow, write a value (based on the interrupt type chosen) to the pin to invoke the interrupt.

COMP9032 Week7

17

## **Code for Example 2 (cont.)**

```
: continued
         ser temp
                                                   ; set Port C as output
         out DDRC, temp
         Idi output, PATTERN
         out PORTC, temp
         ldi temp, 0b00000010
         out DDRD, temp
                                                   ; set Port D bit 1 as output
         out PORTD, temp
         ldi temp, (2 << ISC00) | (2 << ISC10)
                                                   ; set INTO and INT1 as
         sts EICRA, temp
                                                   ; falling edge sensed interrupts
         in temp. EIMSK
                                                   : enable INTO and INT1
         ori temp, (1<<INT0) | (1<<INT1)
         out EIMSK, temp
         sei
                                                   ; enable Global interrupt
         jmp main
                                                              ; continued
```

#### **Code for Example 2**

```
.include "m2560def.inc"
.include "my macros.inc"
                                        ; macros for oneSecondDelay
.def
          temp = r16
.def
          output = r17
.def
          count = r18
.equ
          PATTERN = 0b01010101
          OVERFLOW = 0b11111111
.egu
                                        ; set up interrupt vectors
          rimp RESET
          INT0addr
.org
          rjmp EXT_INT0
          INT1addr
.org
          jmp EXT INT1
RESET:
                                                             ; continued
```

#### **Code for Example 2 (cont.)**

```
; continued
EXT_INT0:
          push temp
                                          : save register
          in temp, SREG
                                          ; save SREG
          push temp
          com output
                                          ; flip the pattern
          out PORTC, output
          inc count
                                          ; restore SREG
          pop temp
          out SREG, temp
          pop temp
                                          ; restore register
          reti
                                          : continued
```

COMP9032 Week7 19 COMP9032 Week7 20

## **Code for Example 2 (cont.)**

```
: continued
EXT INT1:
          push temp
          in temp, SREG
          push temp
          ldi output, OVERFLOW
          out PORTC, output
          oneSecondDelay
                                        ; macro for one second delay
                                        ; stored in "my_macro.inc"
          Idi output, PATTERN
                                        ; set pattern for normal LED display
                                        ; set bit for INT1
          sbi PORTD, 1
          pop temp
          out SREG, temp
          pop temp
          reti
                                                   : continued
```

COMP9032 Week7

21

#### **Timers/Counters**

- Simply binary counters
- Used in two different modes:
  - Timer
    - · Counting time periods
  - Counter
    - Counting the events or pulses or something of this nature
- Can be used to
  - Measure time duration, speed, frequency
  - Generate PWM signals
  - Schedule real-time tasks
  - etc.

#### **Code for Example 2 (cont.)**

: continued : main - does nothing but increment a counter main: clr count clr temp loop: inc temp cpi count. 0xFF breg OV ; if overflow rjmp loop OV: cbi PORTD, 1 ; clear the port bit related to INT1 ; prepare for the next sw interrupt clr count rjmp loop

COMP9032 Week7


22

## **Timers/Counters in AVR**


- In AVR, there are 8-bit and 16-bit timers/counters.
  - Timer 0 and Timer 2
    - 8-bit counters
  - Timer 1, 3-5
    - 16-bit counters
- Timer/Counter 0 is covered in the next slides
  - Similar designs can be found for other timers
    - See the Atmega2560 data sheet

COMP9032 Week7 23 COMP9032 Week7 24

#### **Timer/Counter0 Clock Source**



## 8-bit Timer/Counter Block Diagram




## 8-bit Timer/Counter

- · The counter can be initialized with
  - 0 (controlled by reset)
  - a number (controlled by count signal)
- Can count up or down
  - controlled by direction signal
- Those controlled signals are generated by hardware control logic
  - The control logic is further controlled by programmer by
    - Writing control bits into TCCRnA/TCCRnB
- Output
  - Overflow interrupt request bit
  - Output Compare interrupt request bit
  - OCn bit: Output Compare bit for waveform generation

#### TIMSK0


- Timer/Counter Interrupt Mask Register
  - Set TOIE0 (and I-bit in SREG) to enable the Overflow Interrupt
  - Set OCIE0 (and I bit in SREG) to enable Compare Match Interrupt



COMP9032 Week7 27 COMP9032 Week7 28


#### TIFR0

- Timer/Counter 0 Interrupt Flag Register
  - OCF0 bit is set for a Compare Match between the counter and the data in OCR0(A/B) (Output Compare Register).
    - When (I=1)&&(OCIE0(A/B)=1)&&(OCF0(A/B)=1), the related Timer/Counter Compare Match Interrupt is triggered.
  - OCF0(A/B) bit is cleared by hardware when the related interrupt is handled or can be cleared by writing a logic 0 to the flag




#### TCCR0A/B

• Timer Counter Control Register



#### TIFR0 (cont.)

- Timer/Counter Interrupt Flag Register
  - TOV0 bit is set when an overflow occurs in the counter.
- When (I=1)&&(TOIE0=1)&&(TOV0=1), the related Timer/Counter Overflow Interrupt is triggered.
  - In PWM mode, this bit is set when the counter changes counting direction at 0x00
- TOV0 bit is cleared by hardware when the related interrupt is handled or can be cleared by writing a logic 0 to the flag



#### **TCCR0 Bit Description**

- COM0xn/WGM0n/FOC0:
  - control the mode of operation
    - the behavior of the Timer/Counter and the output, is defined by the combination of the Waveform Generation mode (WGM02:00) and Compare Output mode (COM0x1:0) bits.
    - The simplest mode of operation is the Normal Mode (WGM02:00 =00). In this mode the counting direction is up. The counter rolls over when it passes its maximum 8-bit value (TOP = 0xFF) and then restarts from the bottom (0x00).
- Refer to Mega2560 Data Sheet (pages 118~194) for details.

COMP9032 Week7 31 COMP9032 Week7 32

#### **TCCR0** Bit Description (cont.)

- Bit 2:0 in TCCR0B
  - Control the clock selection

CS02	CS01	CS00	Description
0	0	0	No clock source (Timer/Counter stopped)
0	0	1	clk <sub>I/O</sub> /(No prescaling)
0	1	0	clk <sub>l/O</sub> /8 (From prescaler)
0	1	1	clk <sub>I/O</sub> /64 (From prescaler)
1	0	0	clk <sub>I/O</sub> /256 (From prescaler)
1	0	1	clk <sub>I/O</sub> /1024 (From prescaler)
1	1	0	External clock source on T0 pin. Clock on falling edge
1	1	1	External clock source on T0 pin. Clock on rising edge

0x25 (0x45) Read/Write Initial Value

_	0	1	2	3	4	5	6	7		
TCCR0B	CS00	CS01	CS02	WGM02	-	-	FOC0B	FOC0A		
•	R/W	R/W	R/W	R/W	R	R	W	W		
	0	0	0	0	0	0	0	0		
33			COMP9032 Week7							

COMP9032 Week7

#### **Example 3**

• Implement a scheduler that can execute a task every one second.

COMP9032 Week7

34

## **Example 3 (solution)**

- Use Timer0 to count the time
  - Let's set Timer0 prescaler to 64
    - The time-out for the setting should be
      - -256\*(clock period) = 256\*64/(16 MHz)
      - = 1024 us
        - » Namely, we can set the Timer0 overflow interrupt that is to occur every 1024 us.
        - » Note,  $Clk_{TOS} = 1/16$  MHz (obtained from the data sheet)
    - · For one second, there are
      - -1000000/1024 = 1000 interrupts
- In code,
  - Set Timer0 interrupt to occur every 1024 microseconds
  - Use a counter to count to 1000 interrupts for counting 1 second
  - To observe the 1 second time period, use LEDs that toggles every 1000 interrupts (i.e. one second).

## **Example 3**

```
; This program implements a timer that counts one second using
: Timer0 interrupt
.include "m2560def.inc"
.egu PATTERN=0b11110000
.def temp=r16
.def leds = r17
; The macro clears a word (2 bytes) in a memory
; the parameter @0 is the memory address for that word
.macro Clear
          ldi r28, low(@0)
                                          ; load the memory address to Y
          ldi r29, high(@0)
          clr temp
          st y+, temp
                                          ; clear the two bytes at @0 in SRAM
          st y, temp
.endmacro
                                                               ; continued
```

#### **Example 3**

```
: continued
.dseg
SecondCounter:
   .bvte 2
                              ; Two-byte counter for counting seconds.
TempCounter:
   .byte 2
                              ; Temporary counter. Used to determine
                              ; if one second has passed (when TempCounter=1000)
.cseg
.org 0x0000
   jmp RESET
   jmp DEFAULT
                              ; No handling for IRQ0.
   imp DEFAULT
                              ; No handling for IRQ1.
.org OVF0addr
   jmp Timer0OVF
                              ; Jump to the interrupt handler for Timer0 overflow.
   imp DEFAULT
                              ; default service for all other interrupts.
DEFAULT: reti
                              ; no service
                                                             : continued
```

**Example 3** 

```
; continued

RESET:

ser temp ; set Port C as output out DDRC, temp

rjmp main ; continued
```

COMP9032 Week7

37

#### **Example 3**

```
; continued
Timer0OVF:
                            ; interrupt subroutine to Timer0
       in temp, SREG
       push temp
                            ; Prologue starts.
       push Yh
                            ; Save all conflict registers in the prologue.
       push YL
       push r25
       push r24
                            ; Prologue ends.
       Idi r28, low(TempCounter); Load the address of the temporary
       Idi r29, high(TempCounter); counter.
                            ; Load the value of the temporary counter.
       ld r24, y+
       ld r25, y
                            ; Increase the temporary counter by one.
       adiw r25:r24, 1
                                                        ; continued
```

# **Example 3**

COMP9032 Week7

38

```
; continued
       cpi r24, low(1000)
                                     ; Check if (r25:r24)=1000
       brne NotSecond
       ldi temp, high(1000)
                                     ; 1000 = 10^6/1024
       cp r25, temp
       brne NotSecond
       com leds
       out PORTC, leds
       Clear TempCounter
                                     ; Reset the temporary counter.
       Idi r30, low(SecondCounter); Load the address of the second
       Idi r31, high(SecondCounter); counter.
       ld r24, z+
                                     ; Load the value of the second counter.
       ld r25, z
                                     ; Increase the second counter by one.
       adiw r25:r24, 1
                                                                 ; continued
```

COMP9032 Week7 39 COMP9032 Week7 40

#### **Example 3**

```
: continued
        st z, r25
                             ; Store the value of the second counter.
       st -z. r24
         rimp EndIF
NotSecond:
       st y, r25
                             ; Store the value of the temporary counter.
       st -y, r24
EndIF:
        pop r24
                             ; Epilogue starts;
        pop r25
                             ; Restore all conflict registers from the stack.
        pop YL
       pop YH
        pop temp
       out SREG, temp
        reti
                               ; Return from the interrupt.
                                                         ; continued
```

COMP9032 Week7

41

# **Reading Material**

- Chapter 10: Interrupts and Real-Time Events. Microcontrollers and Microcomputers by Fredrick M. Cady.
- Mega2560 Data Sheet.
  - External Interrupts.
  - Timer0

## **Example 3**

```
: continued
main:
         ldi leds, 0xff
         out PORTC, leds
         Idi leds, PATTERN
         Clear TempCounter
                                     ; Initialize the temporary counter to 0
                                      ; Initialize the second counter to 0
         Clear SecondCounter
         ldi temp, 0b00000000
         out TCCR0A, temp
         ldi temp, 0b00000011
         out TCCR0B, temp
                                      ; Prescaling value=64
         ldi temp, 1<<TOIE0
                                      ; =1024 microseconds
         sts TIMSKO, temp
                                      ; T/C0 interrupt enable
         sei
                                      ; Enable global interrupt
         rimp loop
                                      ; loop forever
 loop:
```

COMP9032 Week7

42

#### **Homework**

1. What do you need to do to set up an Timer0 **Output Compare Match Interrupt?** 

COMP9032 Week7 43 COMP9032 Week7

#### **Homework**

- 2. An underground oil tank monitor system has the following functions:
  - 1. read(): to read the tank oil level
  - 2. display(): to display the oil level
  - 3. main(): process a few of basic tasks: if the oil level is below the low limit, do something; if oil level is over the high limit, do something else; and other routine work.

It is required that the display should be updated every 1 minute, reading should be done at least every 10 seconds. Assume read() and display() take 1 ms and 5 ms, respectively. Design a timing schedule for those functions so that the above requirements can be met and the design leads to an easy assembly code implementation.

COMP9032 Week7

45

