
Physical Computing Inputs and Outputs

CCI / OCT 2021 Andy Sheen

What is Physical Computing?

In physical computing we build interactive systems that can sense the world and respond with actuators.

An intersection of electrical engineering, mechatronics, robotics and computer science.



Types of input

Buttons

Environmental sensors

Cameras

Distance sensors


Resistive sensors

Capacitive sensors

Motion sensors

. . .











Types of output

LEDs

Motors

Displays

Actuators

Electromagnets

Speakers

. . .
















Breadboard









LED

A Light Emitting Diode (LED) is a light that only lets electricity through it one way. If you look at the LED, you will notice that there is a difference in length of the legs. This is how we know which way to use the LED in the circuit.

The longer leg is to signify the anode. This is the side we connect to the positive of a power source. The shorter leg is the cathode. This side needs to be connected to the negative of a power source.


Once in a circuit, you can also easily identify the cathode side by the flat edge on the side of the case.







Traffic Light

3x LED (Red Green Yellow)
3x 220 Ohm Resistors
(Red Red Brown Gold)
8x Jumper Wires









Push Button

Pushbuttons (also known as tactile switches), are what we use to open and close circuits. Buttons and switches are used in electronics to allow us to interact with our circuits.












Button

1x LED
1x Push Button
1x 220 Ohm Resistor
(Red Red Brown)
1x 10k Ohm Resistor
(Brown Black Orange)
8x Jumper Wires








Circuits and Sketches

bit.ly/3uKyI

Potentiometer


A potentiometer is a resistor that allows the user to change the potential of the resistance by turning the knob. Potentiometers have three legs, the three legs are: input, output and ground. In this circuit, we are using the output of the potentiometer as a sensor value to be sampled by the analog input.


To make sure the output value is in range of the analog input, we will supply the potentiometer with 5v. This is the maximum value the analog inputs can sample.



Fading

1x LED
1x 220 Ohm Resistor
(Red Red Brown)
1x 10k Potentiometer
7x Jumper Wires






PWM (Pulse Width Modulation)


Look at the Arduino Digital pins closely, you will notice that 6 of the pins have tilda signs (~) next to the pin number.


These are to tell us that this pin can perform Pulse Width Modulation (PWM), a technique in digital computing used to create the perception of changeable voltage. Digital pins can only output 0v or 5v (On or Off). With PWM it creates the illusion that we are outputting different voltages to this. we can do this is to use the Arduino's analogWrite() function.



Knock Sensor


1x Piezo Sensor
1x 1 MegaOhm Resistor
(Brown Black Green)
4x Jumper Wires





Theremin

1x Light Dependent
Resistor
1x Piezo Buzzer
1x Push Button
1x 10k Resistor
(Brown Black Orange)
9x Jumper Wires



```
theremin | Arduino 1.8.13
                                                                                                Ø
 theremin
10 //program variables
11 int ldrMin = 0:
12 int ldrMax = 1023:
13 int freqMin = 200;
14 int freqMax = 1200;
15 int freqOutput;
16
17
18 void setup() {
19 // set up inputs and outputs
20 pinMode(piezoPin, OUTPUT);
    pinMode(buttonPin, INPUT_PULLUP); //no need for resistor!
22
23 }
24
25 void loop() {
26
    //sample the light dependent resistor
    ldrValue = analogRead(ldrPin);
29
    //map the ldr input value (0-1023) to frequency value
31 //using map() function. map(input,input_minimum,input_maximum,output_minimum,output_maximum)
    freqOutput = map(ldrValue, ldrMin, ldrMax, freqMin, freqMax);
33
    //check if button is pressed to make the sound. logic is inverted because we're using the
35 //internal pullup.
36 if (digitalRead(buttonPin) == LOW) {
      tone(piezoPin, freqOutput);
37
38 } else {
      noTone(piezoPin);
39
40 }
41
42 delay(5);
43 }
```

Done Saving.

Global variables use 178 bytes (6%) of dynamic memory, leaving 2382 bytes for local variables. Maximum

Sketch uses 5662 bytes (19%) of program storage space. Maximum is 28672 bytes.

Tilt Sensor

The tilt switch works by using a metal ball-bearing inside the switch (shake it and you'll hear it rattle!). This means that the ball-bearing is conductive, allowing electricity to flow through and close the circuit if it is touching the legs of the switch.

As this is a physical open and close of the switch we can sense a digital $On \ or \ Off \ (0 \ or \ 1)$.

We can wire a tilt switch up the same as push button.

