# **Computer Architecture**

Fall, 2019

Week 5

2019.10.7

# [group9]

- 1. [Multiple Choice]. Choose the correct statement.
  - (A) sb,sh are the instructions dealing with "byte" half word". Moreover, they store leftmost "byte" half word" data from register to RAM.
  - (B) Assume that we use sb instruction to store data "A7"; due to signed extension, the data will be stored as "AAAAAAA7".
  - (C) Assume that we use Ibu instruction to load data "A7", the data will be stored as "FFFFFA7".
  - (D) Assume that we use sb instruction to store data "A7"; due to signed extension, the data will be stored as "FFFFFFA7".

## Ans: (D)

- (A) leftmost -> rightmost
- (B) "AAAAAAA7" -> "FFFFFA7"
- (C) "FFFFFFA7" -> "000000A7"
- (D) is correct

# [group12] (對抗賽)

- 2. 在下列五種 MIPS Addressing Mode 中,請簡述各個 mode 取得 data 的方式。
  - 1. Immediate addressing
  - 2. Register addressing
  - 3. Base addressing
  - 4. PC-relative addressing
  - 5. Pseudodirect addressing

#### Ans:

- 1. 直接在 immediate 裡面
- 2. 透過 rs rt rd 取得 reg 編號 再去對應的 reg 裡面拿
- 3. 透過描述的編號去對應的 reg 裡面拿到 base address 後 再加上一個 offset(immediate 的值)去 到 memory 拿資料
- 4. Program counter 加上 immediate 的值得到 memory 位址再取得資料
- **5.** Program counter 的前 4 個 bit 連接 instruction 的地址得到 memory 位址後,再去到 memory 這個位址拿

# [group1] (對抗賽)

3. In the execution of a procedure, the program must follow some steps. What is the correct order of these 6 steps?

- A. Acquire the storage resources needed for the procedure.
- B. Perform the desired task.
- C. Put the result value in a place where the calling program can access it.
- D. Put parameters in a place where the procedure can access them.
- E. Transfer control to the procedure.
- F. Return control to the point of origin, since a procedure can be called from several points in a program.

#### Ans:

D -> E -> A -> B -> C -> F

# [group11] (對抗賽)

4. If the current value of the PC is 0x00000600, can you use a single branch instruction to get to the PC address=0010 0000 0000 0001 0100 1001 0010 01002?

#### Ans:

No. Branch is i-format.

opcode(6 bits) rs(5 bits) rd(5 bits) offset(16 bits)
--

so, the maximum distance to branch is +-2^15

Rewrite 0010 0000 0000 0001 0100 1001 0010 01002 to hexadecimal

0010 0000 0000 0001 0100 1001 0010 01002=0x2001492416

The difference between current address and destination address

 $= 0x2001492416-0x0000060016=0x2001432416=53695363610>2^15=32768$ 

Hence, we can't use a single branch instruction to get to the PC address=0010 0000 0000 0001 0100 1001 0010 0100<sub>2</sub>.

## [group10]

5. 當 caller 呼叫 subroutine 時 \$ra 暫存器會存放 caller program 的返回位置,請問若 caller 呼叫 subroutine\_1,此時\$ra 存放 caller 返回位置,subroutine\_1 呼叫 subroutine\_2,此時\$ra 存放 subroutine\_1 返回位置,subroutine\_2 呼叫 subroutine\_3,此時\$ra 存放 subroutine\_2 返回位置,請問(1)subroutine 全部執行完畢,要用什麼機制回到一開始 caller 呼叫 subroutine\_1 的返回記憶體位置?(2)此機制有什麼特性?

#### Ans:

- (1) caller 必須將\$ra 暫存器 push 到 stack 中,當完成 subroutine 後 pop 出\$ra。
- (2) Stack 設計為後進先出,剛好符合比較晚被呼叫到的 subroutine 先執行完

# [group6] (對抗賽)

6. Fill in the blanks below to practice with target addressing.

addi \$s4, \$zero, 1	80000	8	0	17	1

bne \$s1, \$s4, C2_COND	80004	5	17	20	(a)
j C1_BODY	80008	2	<b>(b)</b>		
C2_COND: addi \$s4, \$zero, 2	80012	8	0	17	2
bne \$s1, \$s4, C3_COND	80016	5	17	20	(c)
j C2_BODY	80020	2	(d)		
C3_COND: addi \$s4, \$zero, 3	80024	8	0	17	3
bne \$s1, \$s4, EXIT	80028	5	17	20	(e)
j C3_BODY	80032	2	<b>(f)</b>		
C1_BODY: addi \$s1, \$s1, 1	80036	8	17	17	1
j EXIT	80040	2	(g)		
C2_BODY: addi \$s1, \$s1, 2	80044	8	17	17	2
j EXIT	80048	2	(h)		
C3_BODY: addi \$s1, \$s1, 3	80052	8	17	17	3
EXIT:	80056				

# Ans:

- (a) 1
- **(b) 20009**
- (c) 1
- (d) 20011
- (e) 6
- (f) 20013
- (g) 20014
- (h) 20014

# [group8] (對抗賽)

7.

beq \$s0,\$s1,L1

•••

•••

L1:

假設在以上 MIPS 指令中的 L1,其相對於 beq 指令的記憶體位址超過 16 位元所可以表示的距離,則我們可以如何改寫上述指令來達成原本的目的?

# Ans:

bne \$s0,\$s1,L2 j L1 L2:... L1:

# [group3] (對抗賽)

- 8. 下列敘述哪些正確,若有錯請改出錯誤
  - (A) Leaf procedure doesn't call any other procedure
  - (B) Use lb rt, offset(rs) , 11 1111 0001 is sign extended to 32 bit in rt, the new representation is 0000 0011 0001
  - (C) This is a jump address. The first 4 bits of the program counter are 1111. If target field = 00 0000 1100 0011 1110 0101 1011, the 32-bit address = 1100 0000 0011 0000 1111 1001 0110 1100.
  - (D) Design principles: (1)Simplicity favors regularity. (2)Smaller is faster. (3)Make the common case fast. (4)Good design demands good compromises.

```
Ans: (A) (D)
數
Froup4]
臐
     void strcpy (char x[], char y[]){
圕
     int i;
     i = 0;
     while ((x[i] = y[i]) != '\0')
為
     i += 1; 
丽
      What is the MIPS assembly code? Please fill in the blanks.
不
是
      addi $sp, ____, ___
      sw $s0, 0($sp)
      add $s0, $zero, ____
      L1:
      add $t1, ___, ___
      lbu $t2, 0($t1)
      ____ $t3, $s0, $a0
      sb $t2, __($t3)
      beq $t2, ___, L2
      addi $s0, $s0, 1
     j ____
      L2:
      lw $s0, 0($sp)
      addi $___, $___, 4
```

\_\_\_\_\$\_\_\_

```
Ans:
addi $sp, $sp, -4
sw $s0, 0($sp)
add $s0, $zero, $zero
L1:
add $t1, $s0, $a1
lbu $t2, 0($t1)
add $t3, $s0, $a0
sb $t2, 0($t3)
beq $t2, $zero, L2
addi $s0, $s0, 1
j L1
L2:
lw $s0, 0($sp)
addi $sp, $sp, 4
jr $ra
```