
## **Revision History**

Revision	Release date	comment
1.0	2009/11/17	First issue
1.1	2010/1/14	Add comments
1.2	2010/1/29	Add mib of WAPI
1.3	2010/2/24	Add new configuration API support

## **Features**

- 802.11 b/g/n compatible
- AP mode and client mode support
- Security support 64/128 bits WEP, WPA, and WPA2 (TKIP and AES-CCMP)
- Auto rate adaptive
- Wireless MAC address filter
- Broadcast SSID control
- IAPP (802.11f) support
- Auto channel selection
- Driver based MP functions
- WDS function support
- Universal repeater mode support
- WMM supported for AP mode
- Support for 8192CE and 8188CE ASIC
- WPS function support
- WAPI function support

# **System Architecture**



## WLAN Driver Configuration, IOCTL and PROC

Set mac address:

"ifconfig wlan0 hw ether xxxxxxxxxxxx"

#### Set wlan MIB:

## "iwpriv wlan0 set\_mib name=value1[,value2,value3...]"

*Note 1:* value can be a single field or multiple fields separated by ',' without any space between fields. Detail parameter may be referred the following table.

*Note 2:* if the value is the type of byte array, the format of value will be a string of ASCII of 0~f, which using 2 ASCII standing for one byte. For example, when set Tx power of CCK, it will be

"iwpriv wlan0 set\_mib TxPowerCCK=08080909090a0a0a0a0b0b0b0c0c"

## Up driver:

"ifconfig wlan0 up"

### Close driver:

"ifconfig wlan0 down"

### MIB command table:

Name	Meaning	Value	Default	Comment
channel	Operation frequency used	0 for auto channel, 1-14 for		
		11b/11g		
ch_low	The lowest channel to scan and use	1-14 for 11b/11g		
ch_hi	The highest channel to scan and use	1-14 for 11b/11g		
pwrlevelCCK_A	CCK Tx power level for 14	RF module dependent		Type of byte array
	channels (28 hex digits) for path A			
pwrlevelCCK_B	CCK Tx power level for 14	RF module dependent		Type of byte array
	channels (28 hex digits) for path B	_		
pwrlevelHT40_1S	40MHz mode HT OFDM 1 spatial	RF module dependent		Type of byte array
_A	stream Tx power level for 14			
	channels (28 hex digits) for path A			
pwrlevelHT40_1S	40MHz mode HT OFDM 1 spatial	RF module dependent		Type of byte array
_B	stream Tx power level for 14			
	channels (28 hex digits) for path B			
pwrdiffHT40_2S	40MHz mode HT OFDM 2 spatial	RF module dependent		Type of byte array
	stream Tx power difference between			
	HT40_1S for 14 channels (28 hex			
	digits). Bit[3:0] for path A. Bit[7:4]			
	for path B.			
pwrdiffHT20	20MHz mode HT OFDM Tx power	RF module dependent		Type of byte array
	difference between HT40_1S for 14			
	channels (28 hex digits). Bit[3:0] for			
	path A. Bit[7:4] for path B.			
pwrdiffOFDM	Legacy OFDM Tx power difference	RF module dependent		Type of byte array
	between HT40_1S for 14 channels			
	(28 hex digits). Bit[3:0] for path A.			
	Bit[7:4] for path B.			
preamble	CCK preamble type	0 – long preamble, $1$ – short		
		preamble		
disable_ch14_ofd	Disable OFDM sending and	0 – enable, $1$ – disable		
m	receiving in channel 14			
xcap	Crystal Capacitor value	0 - 255		0 stands the value is
				not calibrated yet.
tssi1	Tx signal strength value of path A	0 - 255		0 stands the value is

				not calibrated yet.
tssi2	Tx signal strength value of path B	0 - 255		0 stands the value is
				not calibrated yet.
ther	Thermal value	0 - 255		0 stands the value is
MIMO TD made	MIMO mada assismment	1 1720 2 2720 4 1710	2	not calibrated yet.
ssid	MIMO mode assignment SSID	1 – 1T2R, 3 – 2T2R, 4 – 1T1R "string_value", SSID with 32	3	
SSIU	3310	characters in max		
defssid	If don't give SSID in Ad-hoc client	"string_value", SSID with 32	"defaultS	
ucissiu	mode and no IBSS available, it will start an IBSS with SSID given here.	chars in max	SID"	
bssid2join	Besides SSID, designate target	xxxxxxxxxxx (12 digits mac		Type of byte array
 	BSSID to join	address)		
benint	Beacon interval in ms	20-1024	100	
dtimperiod	DTIM period	1-255	1	Suggest to set 1
•	_			because patent issue
swcrypto	S/w encryption enabled/disabled	0 – disable, 1 – enable		
aclmode	Access control mode	0 - disable, 1 - accept, 2 - deny		
aclnum	Set number of ACL	Suggest set '0' whenever driver is re-initialized		
acladdr	Set access control address	xxxxxxxxxxx (12 digits mac		When acl is added, the
		address)		aclnum will be
				increased
	On and in a land on	D'(0 b'(11 fe	O CCC	automatically.
oprates	Operational rates	Bit0-bit11 for	0xfff	
basicrates	Basic rates	1,2,5.5,11,6,9,12,18,24,,36,48,54M Bit0-bit11 for	0xf	
basicrates	basic rates	1,2,5.5,11,6,9,12,18,24,,36,48,54M	UXI	
regdomain	Regulation domain	1-10 (FCC, IC, ETSI, SPAIN,	1	
reguomam	regulation domain	FRANCE, MKK, ISREAL,	1	
		MKK1, MKK2, MKK3)		
autorate	Auto rate adaptive	0 – disable, 1 – enable	1	
fixrate	Fixed Tx rate	Bit0-bit11 for		Refer when auto rate
		1,2,5.5,11,6,9,12,18,24,,36,48,54M		is disabled
		Bit12-Bit27 for		
		MCS0,MCS1,,MCS15		
disable_protection	Forcedly disable protection mode	0 – auto, $1$ – disable protection		Normally when 11g is
				used, driver will auto
				detect if legacy (11b) device is existed.
				When 11n is used,
				driver will auto detect
				if legacy (11b/g)
				device is existed. If
				yes, it will enable
				protection mode
				automatically.
disable_olbc	Forcedly OLBC detection	0 – auto, 1 – disable protection		Normally 11g AP
				should detect OLBC.
				If disabled, AP will
				enter protection mode
				only when legacy
dany lagger	Dany the association from leases	O disable 1 dany		device associated.  If enabled in B+G
deny_legacy	Deny the association from legacy STA	0 – disable, 1 – deny		mode, AP will deny
	JIA			the association from
				11B STA. If enabled
				in N mode, AP will
			I	deny the association

				from 11B/G STA.
fast_roaming	Client mode fast roaming	0 – disable, 1 – enable		
lowestMlcstRate	Use lowest basic rate to send multicast and broadcast	0 – disable, 1 – enable		
stanum	Limit max associated sta number	0-32. 0 – disable (not limit).		
authtype	802.11 Authentication type	0 – open system, 1 – shared key, 2 – auto	2	
encmode	Encryption mode	0 – disabled, 1 – WEP64, 2 – TKIP, 4 – AES(CCMP), 5 – WEP128		Set to 2 always under WPA/WPA2 mode
wepdkeyid	WEP default Tx key	0-3		
psk_enable	PSK mode	0 – disable, 1 – WPA, 2 – WPA2, 3 – WPA/WPA2 mixed		
wpa_cipher	WPA PSK cipher suite	2 –TKIP, 8 – AES(CCMP), 10 – TKIP/AES mixed		
wpa2_cipher	WPA2 PSK cipher suite	2 –TKIP, 8 – AES(CCMP), 10 – TKIP/AES mixed		
passphrase	PSK key	32 characters or 64 hex digits		
gk_rekey	Group key update time	0 – disable, >1 – enable		Time unit is second
802_1x  default_port	Flag of using 802.1x  Default state of 802.1x control port	0 – disable, 1 – enable 0 – data packet is not allowed to		When 802.1x is enabled, the Auth daemon must be invoked  Refer when 802_1x is
deraun_port	Default state of 602.1% control port	pass through until 802.1x authentication is ok 1 – data packet is allowed pass through even 802.1x authentication is not ok		set to 1
wepkey1	WEP key1	10 hex digits for WEP64, 26 hex		Type of byte array
		digits for WEP128		
wepkey2	WEP key2	10 hex digits for WEP64, 26 hex digits for WEP128		Type of byte array
wepkey3	WEP key3	10 hex digits for WEP64, 26 hex digits for WEP128		Type of byte array
wepkey4	WEP key4	10 hex digits for WEP64, 26 hex digits for WEP128		Type of byte array
opmode	Operation mode (AP or client)	16 – AP, 8 – Infrastructure client, 32 – Ad-hoc client	16	
hiddenAP	Hidden AP enable/disable	0 – disabled, 1 – enabled		
rtsthres	RTS threshold	0-2347	2347	
fragthres	Fragment threshold	256-2346	2346	
shortretry	Short retry limit	1-255	3	
longretry	Long retry limit	1-255	3	
expired_time	Client inactivity time in 10ms	>100	30000	Time unit is 10 ms.
led_type	WLAN LED type	LED0 LED1		
		0 tx rx		
		1 enable/tx/rx n/a 2 link tx/rx (d,m	)	
		3 link/rx/tx (d,m) n/a	)	
		4 link tx/rx (d)	_	
		$\begin{array}{c ccccccccccccccccccccccccccccccccccc$		
		6 enable tx/rx (d)		
		7 enable/tx/rx (d) n/a		
		8 11a tx/rx (d) 11g tx/rx (d)	d)	
		0-1 – hw control		
		2-8 – sw control		
		d – count data frames		
		m – count management frames		

iapp_enable	IAPP enable/disable	0 – disable, 1 - enable		
block_relay	Block packet relaying between	0 - relay, $1 - block relay$ and drop,		
-	associated clients	2 – block relay and indicate to		
		bridge		
deny_any	Deny the association SSID of "any"	0 – disable, 1 – enable		
	including upper and lower cases			
crc_log	Calculate CRC error packets	0 – disable, 1 – enable		
wifi_specific	Do WiFi specific check	0 – disable, 1 – enable	2	
disable_txsc	Tx shortcut enable/disable	0 – enable, 1 – enable		
disable_rxsc	Rx shortcut enable/disable	0 – enable, 1 – enable		
disable_brsc	Bridge shortcut enable/disable	0 – enable, 1 – enable		
keep_rsnie	Don't clean RSN IE while	0 – erase, 1 – keep		
	reinitialize the interface			
band	Band selection		3	
cts2self	Use cts2Self for protection mode	0 - no, 1 - yes	1	
wds_enable	WDS enable/disable	0 – disable, 1 – enable		
wds_pure	Flag to enable pure WDS mode that	0 – disable, 1 – enable		
	don't broadcast beacon and don't			
	accept any station			
wds_priority	Give WDS packets higher priority	0 – disable, 1 – enable		
wds_num	Set number of WDS	Suggest set '0' whenever driver is re-initialized		
wds_add	Set mac address of WDS AP	xxxxxxxxxxx (12 digits mac		When mac address is
		address). The max entry could be		added, the wds_num
		added is 8 in default configuration.		will be increased
				automatically.
wds_encrypt	WDS encryption mode	0 – disabled, 1 – WEP64, 2 –		
		TKIP, 4 – AES (CCMP), 5 –		
		WEP128		
wds_wepkey	WDS WEP default key	10 hex digits for WEP64, 26 hex		Type of byte array
1 1	WDG DGK I	digits for WEP128		
wds_passphrase	WDS PSK key	32 characters or 64 hex digits		
nat25_disable	Disable NAT2.5 transformation in client mode	0 – enable, 1 – disable		
macclone_enable	Enable MAC clone from the first	0 – disable, 1 – enable		
macerone_enable	incoming packet	o disusie, i chasie		
dhen best disable	Flag of adding broadcast flag into	0 – enable, 1 – disable		
direp_oest_disdore	DHCP request	o chasie, i disaste		
add_pppoe_tag	Add extra tag in PPPoE packets by	0 – disable, 1 – enable	1	When set to 0,
-III - C	NAT2.5	,		NAT2.5 can only
				support one session
				buildup at the same
				time.
clone_mac_addr	Assign the target MAC to clone	xxxxxxxxxxx (12 digits mac		Type of byte array
		address)		
nat25sc_disable	NAT2.5 shortcut enable/disable	0 – enable, 1 – disable		
show_hidden_bss	Show hidden BSS in site survey	0 – disable, 1 – enable		
ack_timeout	Set ACK timeout value	0-255		0 means using
				standard value. In unit
				of us.
private_ie	Send and get private IE	At most 64 hex digits byte array		
groupID	Group ID of virtual AP (multiple	0-65535		When AP (including
	SSID)			root and virtual) set
				the same group ID, the
				wlan traffics could be
				relayed.
				Root interface: wlan0
				Virtual interface:
				wlan0-va0~wlan0-va3

vap_enable	Tell driver if multiple AP function is enabled or disabled			If multiple AP is enabled, this mib must be set to 1.
func_off	Temporary disable wlan function	0 - normal, 1 - wlan off		
qos_enable	Support WMM and QoS	0 – disable, 1 – enable		
apsd_enable	Support WMM APSD function	0 – disable, 1 – enable		
wsc_enable	Support WiFi Protection Setup	Bit0 for client mode, Bit1 for AP mode		
pin	PIN setting for WPS	"string_value" with 8 characters in max		
supportedmcs	Supported MCS rates	Bit 0-15 for MCS0,, MCS15	Oxffff	
basicmes	Basic MCS rates	Bit 0-15 for MCS0,, MCS15		
use40M	Support 40M bandwidth in 11n mode	0 – disable, 1 – enable		
2ndchoffset	Control sideband offset	1 – secondary channel is below the primary channel, 2 – secondary channel is above the primary channel	1	
shortGI20M	Support short GI in 20M bandwidth	0 – disable, 1 – enable		
shortGI40M	Support short GI in 40M bandwidth	0 – disable, 1 – enable		
amsdu	Support packet aggratation	0 – disable, 1 – enable		
lgyEncRstrct	Restrict legacy encryption in N	Bit 0: WEP, Bit 1: TKIP		
debug_err	Flag of DEBUG_ERR() macro	Bit value defined in 8185ag_debug.h (in hex)	fffffff	
debug_info	Flag of DEBUG_INFO() macro	Bit value defined in 8185ag_debug.h (in hex)	0	
debug_warn	Flag of DEBUG_WARN() macro	Bit value defined in 8185ag_debug.h (in hex)	0	
debug_trace	Flag of DEBUG_TRACE() macro	Bit value defined in 8185ag_debug.h (in hex)	0	
ledBlinkingFreq	Multiple of wlan LED blinking frequency.	1~100	1	This value will be referred only when mib value of 'led_type' is greater than 1.
wapiType	WAPI mode	0 - Disable 1 - Certificate 2 – PSK	0	
wapiPsk	WAPI PSK	Up to 32 characters		
wapii sk wapiPsklen	WAPI PSK length	0~32		
wapi UCastKeyTyp e	Unicast key update mode	1 – Disable 2 – Time based 3 – Packet based 4 – Mix mode(Rekey when time or packet number exceeds threshold)		This object selects a mechanism for rekeying the unicast key.
wapiUCastKeyTi	Timeout threshold of time-based	Unit: sec.		
meout	unicast key update mechanism			
wapiUCastKeyPkt Num	Packet number threshold of packet based unicast key update			
	mechanism			
wapiMCastKeyTy pe	Multicast key update mode	<ul> <li>1 - Disable</li> <li>2 - Time based</li> <li>3 - Packet based</li> <li>4 - Mix mode(Rekey when time or packet number exceeds threshold)</li> </ul>		This object selects a mechanism for rekeying the multicast key.
wapiMCastKeyTi meout	Timeout threshold of time-based multicast key update mechanism	Unit: sec.		

wapiMCastKeyPl	t Packet number threshold of packet		
Num	based multicast key update		
	mechanism		

Note1: The default value of MIB will be '0' if it is not specified.

### Read wlan register command:

## "iwpriv wlan0 read\_reg type,offset"

- ➤ type could be b for byte, w for word, dw for double word
- > offset indicates the register offset in hex

### Write wlan register command:

## "iwpriv wlan0 write\_reg type,offset,value"

- ➤ type may be b for byte, w for word, dw for double word
- > offset indicates the register offset in hex
- > value for write in hex

### Read memory command:

### "iwpriv wlan0 read\_mem type,start,len"

- $\blacktriangleright$  type may be b for byte, w for word, dw for double word
- > start indicates the memory start address in hex
- len is for read length in hex

## Write memory command:

## "iwpriv wlan0 write\_mem type,start,len,value"

- *type* may be b for byte, w − for word, dw − for double word
- > start indicates the memory start address in hex
- len is for write length in hex
- > value for write in hex

### Driver based MP function:

We supported Driver based MP functions controlled by "iwpriv" utility. Please refer to "8192C Linux Driver MP.doc" for detail explanation and usages.

#### Additional IOCTL commands (for web display):

id	Meaning	Input	output	comment
0x8b30	Get station info	None	64 array of sta_info_2_web (note1)	
0x8b31	Get associated station number	None	1 word (2 bytes)	
0x8b32	Get version information	None	2 byte of version infomation	
0x8b33	Issue scan request	None	1 byte of result (-1:fail, 0: success)	
0x8b34	Get scan result and scanned	1 byte flag	4 bytes of number of entries and array of	
	BSS database	(get BSS	bss_desc (note4) with flag set to 0	
		database or		
		not)		
0x8b35	Issue join request	bss_desc to	1 byte of result (0: success, 1: scanning, 2:	
		join	fail)	
0x8b36	Get join result	None	1 byte of result (note5)	
0x8b37	Get BSS info	None	Bss_info_2_web structure (note2)	This is used typically
				in client mode
0x8b38	Get WDS info	None	8 array of wds_info (note3)	

#### Note1:

typedef struct \_sta\_info\_2\_web {

```
unsigned short
                       aid;
      unsigned char
                       addr[6];
      unsigned long
                       tx_packets;
      unsigned long
                       rx_packets;
      unsigned long
                       expired_time;
      unsigned short
                       flags; // bit2 indicate whether this entry is valid, bit3 indicates if sta is in sleeping
      unsigned char
                       TxOperaRate; // current used tx rate in 500 k bps (e.g., 108 for 55M)
      unsigned char
                       rssi; // received signal strength indication
      unsigned long
                       link_time; // 1 sec unit
      unsigned long
                       tx_fail;
     unsigned long
                       tx_bytes;
     unsigned long
                       rx_bytes;
     unsigned char
                       network;
     unsigned char
                       ht info;
      unsigned char
                       resv[6];
} sta_info_2_web;
Note2:
typedef enum _wlan_mac_state {
     STATE_DISABLED=0, STATE_IDLE, STATE_SCANNING, STATE_STARTED, STATE_CONNECTED,
STATE_WAITFORKEY
} wlan_mac_state;
typedef struct _bss_info_2_web {
     unsigned char state;
                             // defined in wlan_mac_state
     unsigned char channel;
     unsigned char txRate;
     unsigned char bssid[6];
     unsigned char rssi, sq;
     unsigned char ssid[33];
} bss_info_2_web;
Note3:
typedef struct _wds_info {
      unsigned char
                       state;
      unsigned char
                       addr[6];
      unsigned long
                       tx_packets;
      unsigned long
                       rx_packets;
      unsigned long
                       tx_errors;
      unsigned char
                       TxOperaRate;
} wds_info;
Note4:
struct ibss_priv {
     unsigned short
                       atim win;
struct bss_desc {
     unsigned char
                       bssid[6];
     unsigned char
                       ssid[32];
      unsigned char
                       *ssidptr;
      unsigned short
                       ssidlen;
      unsigned char
                       meshid[32];
     unsigned char
                       *meshidptr;
      unsigned short
                       meshidlen;
      unsigned int
                       bsstype;
      unsigned short
                       beacon_prd;
      unsigned char
                       dtim_prd;
      unsigned long
                       t_stamp[2];
      struct ibss_priv
                       ibss_par;
      unsigned short
                       capability;
      unsigned char
                       channel;
```

```
unsigned long
                    basicrate;
     unsigned long
                    supportrate;
     unsigned char
                    bdsa[6];
     unsigned char
                    rssi;
     unsigned char
                    sq;
     unsigned char
                    network;
};
Note5:
Oxff: pending
2-4: success
others: fail
Files under '/proc/wlan0':
cam_info - dump h/w encryption cam content
mib\_xxx – show mib info
sta_info – show all associated station info
     sta_keyinfo – show the encryption keys of all associated station info
     txdesc0, ..., txdesc5 – show tx descriptor contents for queue 0 to queue 5
     rxdesc – show rx descriptor contents
     buf_info – show the internal buffer pointers and counts
     desc_info – show tx and rx descriptor pointers, indexes, and register contents
     stats – show Tx, Rx, and beacon statistics
     *.txt – MAC and PHY parameter files
```

## iwcontrol Daemon Configuration

Need start daemon when:

- 802.1x daemon is used
- IAPP daemon is used
- WPS daemon is used

Note: iwcontrol daemon should be started after 802.1x, IAPP, or WPS daemon is running

#### Start daemon:

```
"iwcontrol wlan_interface ...."
> wlan_interface: wlan interface, e.g., wlan0
Note:
```

- 1. iwcontrol daemon will parse the pid files in "/var/run" and create FIFO files to do IPC with WPS, IAPP, and 1x daemon.
- 2. Multiple wireless interfaces can be supported in iwcontrol parameters.

## 802.1x Daemon Configuration

Need start daemon when:

- WPA/WPA2 is used
- WEP + 802.1x (authentication with radius server)
- No encryption + 802.1x (authentication with radius server)

Start 802.1x daemon:

"auth wlan\_interface lan\_interface auth wpa\_conf &"

- wlan\_interface: wlan interface, e.g., wlan0
- lan\_interface: lan interface, which connects to Radius server, e.g., br0
- > auth: denote to act as authenticator
- > wpa\_conf: path of wpa config file, e.g., /var/wpa-wlan0.conf
- Note:
- 1. Multiple 802.1x daemons will be created for different wireless interfaces.
- 2. PID file "/var/run/auth-wlanx.pid" will be created for each 1x daemon

## Parameter format in wpa config file:

"keyword = value"

## table of wpa parameters

keyword	value	Comment
encryption	0 – disable, 1 – WEP, 2 – WPA, 4 – WPA2 only, 6 –	
	WPA2 mixed	
ssid	"string_value", 1-32 char	
enable1x	0/1 – disable/enable 1x Radius authentication	Refer when encryption is set to 0, 1
enableMacAuth	0/1 – disable/enable MAC authentication	
SupportNonWpaClient	0/1 – disable/enable none WPA client support when	This feature is not supported now
	WPA is set	
wepKey	1 – WEP64, 2 – WEP128	Refer when encryption is set 1 (wep)
wepGroupKey	set "" as default	No use
authentication	1 – Radius, 2 – PSK (pre-shared key)	
unicastCipher	1 – TKIP, 2 – AES	
wpa2UnicastCipher	1 – TKIP, 2 – AES	
usePassphrase	0 – use psk value as key in raw data, 1 – use passphrase	
	algorithm to convert psk value	
psk	"string_value", if usePassphrase=0 (raw data), it should	
	be 64 hex digits. If usePassphrase=1, the string length	
	should be $>=8$ and $<=64$ .	
groupRekeyTime	Group key re-key time	No use
rsPort	UDP Port number of radius server	Normally 1812 is used
rsIP	IP address of radius server (e.g., 192.168.1.1)	
rsPassword	"string value", password of radius server with 31 char	
	in max	
rs2Port	UDP Port number of radius server set 2	Normally 1812 is used
rs2IP	IP address of radius server (e.g., 192.168.1.1) set 2	
rs2Password	"string_value", password of radius server with 31 char	
	in max set 2	
rsMaxReq	Max retry number of request packet with radius server	Set 3 as default
rsAWhile	Timeout time (in second) of waiting rsp packet of radius	Set 5 as default
	server	
accountRsEnabled	0/1 – disable/enable accounting radius server	
accountRsPort	UDP Port number of accounting radius server	
accountRsIP	IP address of accounting radius server	
accountRsPassword	"string_value", password of accounting radius server	
	with 31 char in max	
accountRsUpdateEnabled	0/1 – disable/enable the feature of statistic update with	
	accounting server	
accountRsUpdateTime	Update time in seconds	
accountMaxReq	Max retry number of request packet with accounting	
	radius server	
accountAWhile	Timeout time (in second)of waiting rsp packet of	
	accounting radius server	

## **IAPP Configuration**

#### Start IAPP daemon:

"iapp lan\_interface wlan\_interface ...&"

- lan\_interface: interface name which IAPP daemon use to send IAPP packet (e.g., br0)
- wlan\_interface: wlan interface, e.g., wlan0

#### Notes:

- 1. IAPP can support multiple wireless interfaces.
- 2. PID file "/var/run/iapp.pid" will be created for iapp deamon.

## **WPS Configuration**

The driver has already supported WPS function, but it needs to cooperate with WPS daemon in user level. Please refer to "*Realtek\_WPS\_user\_guide.doc*" for detail explanation and usages.

## **WAPI Configuration**

The driver has already supported WAPI function. Please refer to "WAPI Porting Guide.doc" for detail explanation and usages.

## **Configuration File support**

The driver can be configured via a *configuration file* each time an interface is up.

### Kernel configuration:

Select "Network device support": Wireless LAN (non-hamradio) ---> Config File support"; then rebuild kernel image.

#### Configuration file:

- Path: /etc/Wireless/RTL8192CD.dat
- Sytax: 'wlan\_interface'\_'mib\_command', e.g. wlan0\_ssid=xxxx.

### Notes:

- 1. Add '#' in front of comment lines.
- 2. Space is NOT allowed between 'wlan\_interface' and 'mib\_command'.
- 3. If the user needs to configure MIB values with special characters, e.g. '#', the value of 'mib\_command' MUST be quoted E.g. wlan0\_ssid="#XXXXX@##\$\$%%"
- 4. 'wlan\_interface': wlan interface, e.g., wlan0, wlan0-va0. However, please **DO NOT** configure **WDS** interfaces because WDS is configured in wlan0 interface.
- 5. 'mib\_command': MIB commands, e.g., ssid=xxxx, please refer to table "MIB command table" and following "Extended MIB command table"
- 6. MIB value should be also configured for each virtual interface separately.
- 7. Each time an interface is up, the configuration file will be loaded.

### Extended MIB command table (available only if Config File support is turned on):

Name	Meaning	Value	Default	Comment
hwaddr	MAC address of WLAN interface	12 hex digits, e.g. 00e04c8192a1	0	
	In AP+Mesh mode but not enable mesh function	0 – mesh enabled, 1 – mesh disabled	0	Available if mesh is built with kernel image

## iwconfig/iwlist support

The driver has already supported iwconfig and iwlist (Wireless Tools v29) for getting or setting some configurations.

#### Kernel configuration:

Select "Network device support ---> Wireless LAN (non-hamradio) ---> Wireless Extensions v18 support" and "Network device support ---> Wireless LAN (non-hamradio) ---> Wireless Tools v29 support"; then rebuild kernel image.

#### **iwconfig** – configure a wireless network interface.

*Notes:* Because 'iwconfig' cannot fully cover all the configurations of the AP, we suggest the users using 'iwpriv' to setup the AP.

### Synopsis of **iwconfig**:

- iwconfig [interface]
- iwconfig interface [essid X] [mode M] [freq F] [channel C] [ap A] [rate R] [rts RT] [frag FT] [enc E] [key K] [retry R]
- ➤ iwconfig --help
- iwconfig --version

#### Parameters of iwconfig

Name	Meaning	Value	Access	Comment
essid	ESSID	any string, e.g. iwconfig essid "My SSID"	GET/SET	
mode	operating mode of the device	Ad-Hoc, Managed (client mode), Master (AP mode), Repeater, Monitor	GET	
freq	operating frequency	frequency in GHz	GET/SET	
channel	operating channel value	channel value	GET/SET	
ap	MAC address	e.g. 00:e0:4c:01:23:45	GET	
rate/bit[rate]	maximum available bit rate	bit rate in Mb/s	GET	
rts[_threshold]	RTS threshold	packet size or off	GET/SET	
frag[mentation_thr eshold]	fragmentation threshold	packet size; off: based on driver setting	GET/SET	
key/enc[ryption]	WEP key settings	mode: open/restricted; keys in 10 or 32 hex-digit	GET	
retry	retry limits	number of retrys	GET	

*Notes: for more detailed information, please refer to the manual of iwconfig.* 

#### **iwlist** – Get more detailed wireless information from a wireless interface

*Notes:* Because 'iwlist' cannot fully cover all the configurations of the AP, we suggest the users using 'iwpriv' to access settings of the AP.

## Synopsis of **iwlist**:

- iwlist [interface] [keyword]
- ➤ iwlist --help
- > iwlist --version

## keywords of iwlist

Name	Meaning	Value	Comment
scanning	site survey of neighboring WLAN	list of Access Points and Ad-Hoc	
	devices	cells in range.	
channel/frequency	supported channel and frequency	frequencies in GHz corresponding	varied as domain
		to the channels	region changed
bitrate/rate	supported rate and extended	supported bit-rates in Mb/s	HT rates are not
	supported rate announced in beacon		listed by iwlist
keys/encryption	WEP encryption information	key sizes, list of available keys and	
		current transmit key	
ap/accsspoints/pee	Associated peer list	list of associated peers	
rs			
auth	Authentication capabilities	WPA, WPA2, CIPHER-TKIP,	
		CIPHER-CCMP	

Notes: for more detailed information, please refer to the manual of iwlist.

## Limitation

- H/W encryption CAM size is 32
- Multiple BSSID CAM size is 8
- Tx SKB buffer must have 8 bytes space in tail for TKIP MIC
- Support 32 wlan clients in current configuration
- Support 8 WDS number in current configuration