Chapter 3 - Top Level View of Computer Function

Luis Tarrataca

luis.tarrataca@gmail.com

CEFET-RJ

Table of Contents I

- Introduction
- 2 Computer Components
- 3 Computer Function

Basic instruction cycle

A more detailed instruction cycle

- 4 Interrupts
- 6 Multiple Interrupts
- Multiple Interrupts
- Bus Interconnection

Bus Structure

Data Lines

Address Lines

Table of Contents II

Control Lines

Multiple-Bus Hierarchies

Elements of bus design

Bus Type

Timing

8 References

Introduction

- Today we will focus on presenting a top-level view of computer function.
- We will be interested in answering the following questions:

What are the main components of computer function?



Introduction

- Today we will focus on presenting a top-level view of computer function.
- We will be interested in answering the following questions:

How are these components organized?



Introduction

- Today we will focus on presenting a top-level view of computer function.
- We will be interested in answering the following questions:

How do these components communicate with each other?



Anyone has any idea how to answer the previous questions?

- What are the main components of computer function?
- How are these components organized?
- How do these components communicate with each other?

Any ideas?



At a top level, a computer consists of:

- Central Processing Unit;
- Memory;
- I/O components.

The components are interconnected in order to execute programs.

This interconnection requires:

- Control signals to:
 - Control other components;
 - Be controlled by other components;
- Data signals to:
 - Exchange information with other components.
- An infrastructure to send / receive all these signals.

Lets have a top down look into some of these components...



Computer Components

Most computer concepts were developed by this person:



Does anyone know who this person is?

1 extra point if you answer in 10 seconds... #NOT



Computer Components

Most computer concepts were developed by John von Neumann:

- Hungarian-born scientist;
- Worked on the Manhattan Project;
- Prolific contributor to diverse fields:
 - Physics;
 - Mathematics:
 - Economics:
 - Game theory;
 - ...
- One of humanity's greatest minds.



Von Neumann architecture is based on three concepts:

- Ability to write/read data from memory;
- Ability to execute instruction sequentially;
- Ability to process inputs/outputs;



Von Neumann architecture is based on three concepts:

- Ability to write/read data from memory;
- Ability to execute instruction sequentially;
- Ability to process inputs/outputs;

But why we need these components? Any ideas?



Consider the original method for computation based on digital circuits:

- Allow us to calculate binary functions.
- Employs a small set of logical gates:
 - AND, OR, NOT, NAND, NOR, XOR, XNOR
- Employ some type of memory:
 - Flip-flop SR, JK, D

Do you see any disadvantage with using digital circuits? Any ideas?

- Rigid design:
 - Only works for a specific function...
- What if we need to calculate additional functions?
 - Requires generating a new circuit...
 - producing new truth tables;
 - algebraic simplification;
 - circuit design.
 - Basically a lot of work...



Suppose that instead of having such an hardwired circuit we have:

- A module capable of calculating arithmetic/logic functions:
 - Logic functions:
 - AND, OR, NOT, NAND, NOR, XOR, XNOR
 - Arithmetic functions:
 - addition, subtraction, multiplication, division, SHL, SHR,...

- We also need a way to control such a module:
 - Control signals indicate which operation to do;
 - Data forwarding mechanisms:
 - To provide input to the arithmetic / logic functions;
 - To store the output of such functions.

- With such a general-purpose hardware:
 - System accepts data and control signals and produces results.
 - Programmer merely needs to supply a new set of control signals.
 - instead of rewiring the hardware for each new program;



How shall the control signals be supplied?

- Program is a sequence of steps;
- At each step, an arithmetic/logical operation is performed on data;
- Each instruction thus requires its own set of control signals =)
 - Hardware interprets each instruction and generates control signals.

The Central Processing Unit (CPU) incorporates these two responsibilities:

- An instruction interpreter capable of generating control signals;
- A general-purpose module for arithmetic/logic functions.

CPU provides a way to perform arithmetic/logic operations;

Is this capability enough to have a functional computer? Any ideas?

CPU provides a way to perform arithmetic/logic operations;

Is this capability enough to have a functional computer? Any ideas?

Several other components are needed to yield a functioning computer.

Data and instructions must be provided to the system:

- Input module:
 - contains basic components for accepting data and instructions
- Output module:
 - contains the means of reporting results.

Taken together, these are referred to as I/O components.

Are these two components enough for a functional computer? Any ideas?

Data operations may require access to more than one element:

- there must be a place to store both instructions and data.
- that module is called main memory
 - to distinguish it from external storage or peripheral devices.

Von Neumman architecture

We have thus the main components of the von Neumann architecture:

- Memory module
- I/O module
- CPU

Guess what we will be doing next? Any ideas?

We will be having a more detailed look at these components...




Figure: A top level view of the main computer components (Source: (Stallings, 2015))

CPU has a set of internal registers (1/3):

- Program Counter (PC):
 - specifies the memory address of the next instruction to be executed.
- Instruction Register (IR):
 - holds the instruction currently being executed or decoded.

CPU has a set of internal registers (2/3):

- memory address register (MAR):
 - specifies memory address to be read/written;
- memory buffer register (MBR):
 - contains the data to be written into memory or...
 - receives the data read from memory;

CPU has a set of internal registers (3/3):

- I/O address register (I/OAR):
 - specifies a particular I/O device;
- I/O buffer (I/OBR) register:
 - used for the exchange of data between an I/O module and the CPU;

Memory module consists of:

- Set of sequentially numbered addresses;
- Each location contains binary information (word);
 - Data;
 - Or instructions.

I/O module responsible for:

- Transfers data from external devices to CPU and memory;
 - and vice versa
- Containing internal buffers for temporarily holding data

Computer Function

Basic function performed by a computer is execution of a program:

- Consisting of a set of instructions stored in memory;
- Processor does the actual work by executing the specified instructions;

This gives us a hint of how to perform instruction processing...



Basic instruction cycle

In its simplest form, **instruction processing** consists of two steps:

- Fetch stage:
 - processor reads instructions from memory one at a time
- Execution stage:
 - processor executes the instruction




Figure: Basic Instruction Cycle (Source: (Stallings, 2015))




Figure: Basic Instruction Cycle (Source: (Stallings, 2015))

Program execution consists of a loop:

- Fetch instruction stage;
- 2 Execute instruction stage;

At the beginning of each instruction cycle:

- Processor fetches an instruction from memory;
- Program counter holds the address of the instruction to be fetched;
 - After each instruction fetch the PC is incremented. Why?
 - In order to fetch the memory address of next instruction;

Example

Consider a computer where each instruction occupies 16-bits in memory.

- Assume that the PC is set to memory location 300;
 - Each location address contains a 16-bit word;
- The processor will next fetch the instruction at location 300.
- On succeeding instruction cycles, it will fetch instructions from locations:
 - 1 301;
 - 2 302;
 - 3 and so on.
- This sequence may be altered. Why?
 - Conditional jumps (IF's) to other areas of code.



The fetched instruction is loaded into a register in the processor

- Known as the instruction register (IR);
- Instruction specifies control signals for the processor;
- Processor interprets the instruction and performs the required action.

What types of actions are usually performed?

In general, these actions fall into four categories:

- Processor ↔ memory data transfers;
- Processor ↔ I/O peripherals data transfers;
- Data processing: arithmetic or logic operations on data;
- Control: E.g. alter the PC because of conditional jumps (IF's)

Seems confusing? Well, maybe it helps if we use an example... =)

Example (1/11)

Consider a processor:

- Containing a single data register, called an accumulator (AC).
- Both instructions and data are 16 bits long;
 - Convenient to organize memory using 16-bit words;

Example (2/11)

Instruction format is the following:



Figure: Instruction Format (Source: (Stallings, 2015))

- Opcode: code of the operation to be executed (+,-,×, ÷,etc...);
 - How many bits are reserved for the opcode? Total combinations?
- Addressing memory,
 - How many bits are reserved for the addressing memory? Total combinations?

Example (2/11)

• The instruction format is the following:




Figure: Instruction Format (Source: (Stallings, 2015))

- Opcode: code of the operation to be executed (+,-,×, ÷,etc...);
 - 4 bits are reserved, i.e there can be 2⁴ different opcodes;
- Addressing memory,
 - 12 bits are reserved, i.e. 2¹² memory words can be addressed.

Example (3/11)

Consider that we have the following opcodes:

0001	Load AC from memory
0010	
0010	Store AC to memory
0101	
0101	Add to AC from memory

Also, each number requires 16 bits and has the following representation:



Figure: Integer Format

- One bit for signal;
- 15-bits for magnitude.

Example (4/11)

Now lets try to execute the following instructions (assume **PC=300**):

- 1) Add memory contents at address 940 to the contents at address 941;
- 2 Store the result in the latter location.

Any ideas of how all the previous concepts will function and interconnect with each other?

Example (5 / 11)

Assume PC=300:




Figure: Example of Program Execution (contents of memory and registers in hexadecimal) (Source: (Stallings, 2015))

0001	Load AC from memory
0010	Store AC to memory
0101	Add to AC from memory

Example (6/11)

Assume PC=300:




Figure: Example of Program Execution (contents of memory and registers in hexadecimal) (Source: (Stallings, 2015))

0001	Load AC from memory
0010	Store AC to memory
0101	Add to AC from memory

Example (7 / 11)

Assume PC=300:




Figure: Example of Program Execution (contents of memory and registers in hexadecimal) (Source: (Stallings, 2015))

0001	Load AC from memory
0010	Store AC to memory
0101	Add to AC from memory

Example (8 / 11)

Assume PC=300:




Figure: Example of Program Execution (contents of memory and registers in hexadecimal) (Source: (Stallings, 2015))

0001	Load AC from memory
0010	Store AC to memory
0101	Add to AC from memory

Example (9/11)

Assume PC=300:




Figure: Example of Program Execution (contents of memory and registers in hexadecimal) (Source: (Stallings, 2015))

0001	Load AC from memory
0010	Store AC to memory
0101	Add to AC from memory

Example (10 / 11)

Assume PC=300:




Figure: Example of Program Execution (contents of memory and registers in hexadecimal) (Source: (Stallings, 2015))

0001	Load AC from memory
0010	Store AC to memory
0101	Add to AC from memory

Example (11 / 11)

In textual form:

- 1 The PC contains value 300, the address of the first instruction.
 - 1 This instruction (the value 1940 in hexadecimal) is loaded into the instruction register IR, and the PC is incremented;
- 2 The first 4 bits (first hexadecimal digit) in the IR indicate that the AC is to be loaded.
 - 1 The remaining 12 bits (three hexadecimal digits) specify the address (940) from which data are to be loaded.
- 3 The next instruction (5941) is fetched from location 301, and the PC is incremented.
- 1 The old contents of the AC and the contents of location 941 are added, and the result is stored in the AC.
- 5 The next instruction (2941) is fetched from location 302, and the PC is incremented.
- The contents of the AC are stored in location 941.



Some important notes:

- Last example was very simplified;
- But the overall control structure and information flow is present;
- However, there are a lot of details missing;

Lets look into a more detailed instruction cycle...

A more detailed look at the **basic instruction cycle**:




Figure: A more realistic instruction cycle state diagram (Source: (Stallings, 2015))

The states can be described as follows (1/2):

- Instruction address calculation (IAC):
 - Determine address of next instruction to be executed;
- Instruction fetch (IF):
 - Read instruction from memory into the processor;
- Instruction operation decoding (IOD):
 - Determine type of operation to be performed and operand(s) to be used.

The states can be described as follows (2/2):

- Operand address calculation (OAC):
 - Determine the address of the operand.
- Operand fetch (OF):
 - Fetch the operand from memory or read it in from I/O.
- Data operation (DO):
 - Perform the operation indicated in the instruction.
- Operand store (OS):
 - Write the result into memory or to I/O.

Now that we have seen this more detailed instruction cycle...

Do you think it is enough? Should we add other states? Is there something missing?

Now that we have seen this more detailed instruction cycle...

Do you think it is enough? Should we add other states? Is there something missing?

- What if an error occurs?
- What if we want to execute something periodically?
- What if we want to read data from an input device (e.g.: keyboard)?
- etc....

Interrupts

There exists some situations where we may want to interrupt the CPU:

- Program: arithmetic overflow, division by zero, segfault, etc...
- Timer: execute something periodically;
- I/O: exchange communication between I/O devices and the processor;
- Hardware: generated by an hardware failure
 - e.g.: power, memory parity error, etc;

Because of these reasons (and some others):

- Computers provide a mechanism to interrupt the processing;
- Any ideas of the mechanism name?



Because of these reasons (and some others):

- Virtually all computers provide a mechanism to interrupt the normal processing of the processor.
- Any ideas of the mechanism name?
 - Interruptions =)

Can you see any implications for interrupting the processor?

- 1 An interrupt request signal is sent to the processor.
- 2 The processor responds by suspending current program execution;
 - What does this imply? Any ideas? (See Slide 73)
- 3 The processor executes a routine capable of dealing with the interrupt;
 - A.k.a. interruption handler.
- 4 After the handler finishes the program returns to the original execution.
 - What does this imply? Any ideas? (See Slide 74)






Figure: Transfer of control via interrupts (Source: (Stallings, 2015))

Lets quickly remember the basic instruction cycle:




Figure: A more realistic instruction cycle state diagram (Source: (Stallings, 2015))

Lets quickly remember the **basic instruction cycle**:




Figure: A more realistic instruction cycle state diagram (Source: (Stallings, 2015))

To accommodate interrupts:

An interrupt cycle can be added to the end of instruction cycle...



To add interrupts, an interrupt cycle can be added...




Figure: Instruction Cycle State Diagram, with Interrupts (Source: (Stallings, 2015))

HINT: This is one of the most important slides of the entire semester;)



Interruption Processing (1/4)

- Processor checks to see if any interrupts have occurred
 - indicated by the presence of an interrupt signal;
- If no interrupts are pending:
 - 1 processor proceeds to the fetch cycle and...
 - 2 fetches the next instruction of the current program.



Interruption Processing (2/4)

- If an interrupt is pending, the processor does the following (1/3):
 - 1 suspends execution of the program being executed. This entails:
 - Saving the PC;
 - Saving the contents of the registers;
 - This is called saving the context of the program
 - 2 sets the PC to the starting address of an interrupt handler routine;

Interruption Processing (3/4)

- If an interrupt is pending, the processor does the following (2/3):
 - 3 The instruction cycle is restarted, but this time for the interruption handler;
 - fetch the first instruction in the interrupt handler program
 - etc...
 - Eventually the interruption routine will terminate;

Interruption Processing (4/4)

- If an interrupt is pending, the processor does the following (3/3):
 - 4 When the interrupt handler routine is completed:
 - Processor needs to resume execution of the original program;
 - Processor restores contents of the previously saved registers...
 - ...Continuing the execution of the previously saved PC;
 - This is called restoring the context of the program

Can you see any problem with the interruption scheme?

There is some overhead involved in this process:

- Extra instructions must be executed:
 - to determine the nature of the interrupt;
 - decide the appropriate action.
- However:
 - Not enough to offset the performance of waiting on, e.g., I/O operations.



We now have a basic understanding of the interruption mechanism...

But what if multiple interruptions being generated at the same time?

Example:

- A key is pressed;
- A segfault is generated;

Multiple Interrupts

Suppose that multiple interrupts can occur, e.g.: a program may be

- receiving data from a communications line:
 - an interruption is generated every time a unit of data arrives.
- printing:
 - an interruption is generated every time a print operation is completed;

How should the system deal with such cases? Any ideas?

Multiple Interrupts

Suppose that multiple interrupts can occur, e.g.: a program may be

- receiving data from a communications line:
 - an interruption is generated every time a unit of data arrives.
- printing:
 - an interruption is generated every time a print operation is completed;

How should the system deal with such cases? Any ideas?

The are two possibilities...



1st Possibility

Disable interrupts while an interrupt is being processed:

- The processor will ignore interrupt request signals;
 - Emphasis on the "ignore", interrupt signals can still be generated.
- After the interrupt handler routine completes:
 - Interrupts are enabled;
 - the processor checks to see if any interrupts have occurred.

Can you see any problem with this approach of disabling interrupts while processing an interruption?

- Some interruptions may be more important than others.
- Some important examples...
 - Nuclear reactor:
 - Plane steering;
 - Ventilator system.

2nd Possibility

Allow each interruption to have a priority:


- Higher priority interruptions can interrupt lower-priority interruptions.
- This strategy is referred to as nested interrupt processing.



Example (1/3)

Consider a system with three I/O devices:

Device	Interruption Priority
Printer	2
Disk	4
Comm. line	5



Example (2/3)

Program begins at t = 0 and at t = 10, a printer interrupt occurs:


- 1 context is saved;
- 2 execution goes to the printer interrupt service routine (ISR);
- 3 While this routine is executing (t=15), a communications interrupt occurs:
 - 1 Higher priority than the printer;
 - 2 Printer ISR is interrupted, context is saved;
 - 3 Execution goes to the communication ISR;
 - While this routine is executing, a disk interrupt occurs (t = 20);
 - Because this interrupt is of lower priority, it is simply held;
 - 3 and the communications ISR runs to completion.

Example (3/3)

- 4 When the communications ISR completes (t = 25):
 - printer ISR state is restored;
 - 2 However, there is a pending higher-priority interruption (disk);
 - Processor transfers control to the disk ISR;
 - 2 disk ISR completes at t = 35;
 - 3 printer ISR is resumed;
 - 4 printer ISR terminates at t = 40;
- 5 control returns to the original program.

Interconnection Issues

A computer consists of a set basic types of components:



These modules need to communicate with each other in order to:

- exchange data;
- exchange control signals;
- ..



Any idea how this communication can be performed?

• Through a bus...

Any idea how this communication can be performed?

• Through a bus...

Ok, so what is a "bus"? Any ideas?

Bus Interconnection

A bus is a communication pathway connecting two or more devices:

- shared transmission medium:
- connected devices can pickup the reception of all other devices.
- If several devices transmit during the same time period:
 - their signals will overlap and become garbled:
 - thus, only one device at a time can successfully transmit.

A bus consists of multiple communication lines:

- Each line transmits binary signals.
 - A sequence of binary digits can be transmitted:
 - using a single line over time (i.e. sequentially);
 - several lines can be used (i.e. in parallel).

A bus connecting major computer components is called a **system bus**.

Now that we know the basic function of the bus...

What type of information does the bus carry? Any ideas?

Bus Structure

Bus lines can be classified into three functional groups:

- data:
 - for moving data among system modules
- address
 - for specifying the source or destination of the data:
- control
 - for transmiting command information among the modules.

Lets have a quick look into each one of these...




Figure: Bus Interconnection Scheme (Source: (Stallings, 2015))

Data Lines

The data bus may consist of 32, 64, 128, or even more separate lines:

a.k.a. width of the data bus;

Each line can carry only 1 bit at a time:

• the number of lines determines how many bits can be transferred at a time.

Data bus width is key to system performance, e.g.:

- if the data bus is 32 bits wide and each instruction is 64 bits long;
- Each instruction requires two memory acesses.

Address Lines

Used to designate the source or destination of the data on the data bus:

- The width of the address bus determines the maximum system memory;
- The address lines are generally also used to address I/O addresses;
 - Higher-order bits are used to select a particular module on the bus;
 - Lower-order bits select a memory location or I/O port within the module.

Control Lines

Command signals specify operations to be performed, e.g.:

- Memory write: write bus data to a memory address;
- Memory read: read memory at memory address;
- I/O write: write bus data to an I/O address;
- I/O read: read data from an I/O address;
- Bus request: a module needs to gain control of the bus;
- Bus grant: a requesting module has been granted bus control;
- Many more control signals...



Can you see any potential problem with bus usage?

Can you see any potential problem with bus usage?

Can you see any potential problem with bus usage?

What happens if a great number of devices are connected to the bus?

Can you see any potential problem with bus usage?

What happens if a great number of devices are connected to the bus?

If a great number of devices are connected bus performance will suffer.

Multiple-Bus Hierarchies

Main variables of bus performance (1/2):

- Bus length: the more devices attached to the bus, the greater the bus length and hence the greater the propagation delay.
 - Delay determines time required for devices to coordinate bus use;
 - When bus control is passed frequently between device:
 - propagation delay can noticeably affect performance.

Main variables of bus performance (2/2):

- Bus capacity: bus has a certain data rate capacity:
 - aggregate data transfer bottleneck;
 - possible solutions:
 - increase data rate;
 - use wider bus;

Idea: Use several buses to distribute communication effort;

• This implies that there needs to be a bus hierarchy, e.g.:




Figure: Traditional Bus Architecture (Source: (Stallings, 2015))

- Local bus connecting:
 - processor;
 - cache memory;
 - one or more local devices.
- System bus:
 - where the main memory module is attached;
 - that also connects to the cache;

Note: in contemporary systems, the cache is in the same chip as the processor.




Figure: Traditional Bus Architecture (Source: (Stallings, 2015))


Elements of bus design

Parameters that can be used to classify and differentiate buses e.g.:

Туре	Bus Width
Dedicated	Address
Multiplexed	Data
Method of Arbitration	Data Transfer Type
Centralized	Read
Distributed	Write
Timing	Read-modify-write
Synchronous	Read-after-write
Asynchronous	Block

Figure: Elements of bus design (Source: (Stallings, 2015))

Lets have a look at some of these...



Bus Type

Bus lines can be separated into two generic types:

- dedicated: line is used for a single purpose:
 - e.g.: the use of separate dedicated address and data lines
- multiplexed: line is used for multiple purposes:
 - e.g.: address and data information may be transmitted over the same lines
 - Idea: use an Address Valid control line:
 - Activate Address Valid line;
 - Place the address on the bus lines;
 - Transfer the data after.

Multiplexing advantage:

use of fewer lines, which saves space and, usually, cost.

Multiplexing disadvantage:

- more complex circuitry is needed within each module;
- potential reduction in performance:
 - certain events that share the same lines cannot take place in parallel.

Timing

Refers to the way in which events are coordinated on the bus:

- synchronous timing: occurrence of events is determined by a clock.
 - bus includes a clock line, connected to a system clock;
 - A single 1-0 transmission is referred to as a clock cycle;
 - Devices on the bus can read the clock line;
 - all events start at the beginning of a clock cycle:

Synchronous Example (1/3)




Figure: Timing of Synchronous Bus Operations (Source: (Stallings, 2015))

Synchronous Example (2/3)

- Processor sets various status lines:
- Processor places a memory address on the address lines;
- 3 Once the address lines have stabilized, the processor issues an address enable signal;

Synchronous Example (3/3)

- 4 The example then depicts two operations:
 - read cycle:
 - Processor issues a read command (start of the second cycle);
 - Memory module recognizes address and, after a delay of one cycle, places the data on the data lines:
 - Processor reads the data from the data lines and drops the read signal;
 - write cycle:
 - Processor puts the data on the data lines (start of the second cycle);
 - Processor issues a write command after the data lines have stabilized;
 - Memory module copies the information from the data lines (third clock cycle).

Asynchronous Example (1/5)

Asynchronous timing: occurrence of one bus event follows and depends on the occurrence of a previous event.

E.g.: read operation using an asynchronous bus:





Figure: System bus read cycle (Source: (Stallings, 2015))



Asynchronous Example (2/5)

- Processor places address and status signals on bus;
- 2 After pausing for these signals to stabilize, it issues a read command;
 - indicating the presence of valid address and control signals.
- Memory performs the following tasks:
 - decodes the address
 - 2 places the data on the data line;
- Once the data lines have stabilized:
 - 1 memory module asserts the acknowledged line to signal the processor that the data are available.

Asynchronous Example (3/5)

- 6 Once the processor has read the data from the data lines, it deasserts the read signal;
- 6 This causes the memory module to drop the data and acknowledge lines.
- Once the acknowledge line is dropped, the processor removes the address information.

Asynchronous Example (4/5)

E.g.: write operation using an asynchronous bus:




Figure: System bus write cycle (Source: (Stallings, 2015))

Asynchronous Example (5/5)

- 1) Processor places data, status and address signals on the bus;
- 2 Memory module responds to the write command by copying the data from the data lines:
- 3 Memory module then asserts the acknowledge line.
- Processor then drops the write signal;
- Memory module drops the acknowledge signal;

Now that we have a basic understanding of each timing mechanism:

What are the main advantages / disadvantages of synchronous / asynchronous timing?

Advantages of synchronous timing:

simpler to implement and test;

Disadvantages of synchronous timing:

- less flexible than asynchronous timing;
- All devices are tied to a fixed clock rate:
 - System cannot take advantage of advances in device performance;
 - i.e. when a task finished before the next clock cycle.
- With asynchronous timing:
 - a mixture of slow and fast devices can share a bus.

References I



Stallings, W. (2015).

Computer Organization and Architecture.

Pearson Education.