gem5 tutorial

References:

• https://github.com/gem5bootcamp



Environment

The steps outlined in this tutorial have been tested on the computers located in Delta 219. These computers are equipped with:

• CPU: 13th Gen Intel(R) Core(TM) i5-13500

• RAM: 16 GB

• SSD: 954 GB

Docker Desktop is pre-installed.



Installation on Your Own Computer

You may also install Docker on your own computer. Please ensure you have at least **10 GB** of disk space available.

This instructions for **Windows** is provided.



Install WSL2 on Windows

STEP 1: Enable Windows Features

- 1. Open **File Explorer** and type Control **Panel(控制台)\Programs(程式集)** into the address bar, then press Enter.
- 2. Click on Turn Windows features on or off(開啟或關閉Windows功能).
- 3. Check the boxes for Windows Subsystem for Linux and Virtual Machine Platform.

If these options are missing, you may need to enable **virtualization technology** (Intel VT-x / AMD-V) in your computer's BIOS/UEFI settings.

4. Click OK, then select Restart now to reboot your computer.



STEP 2: Install WSL2 using PowerShell

- 1. Open **PowerShell** as Administrator.
- 2. Run the following command to install WSL2 and the default Linux distribution (Ubuntu):

3. Wait for the installation to complete. Once finished, restart your computer if prompted.



Install Docker Desktop on Windows

For Windows users:

- 1. Download the installer.
- 2. Double-click Docker Desktop Installer.exe to run the installer.
- 3. Follow the instructions in the installation wizard to authorize the installer and proceed with the installation.
- 4. Once the installation is complete, select **Close** to finish the process.



Back up files from \$HOME\workspaces\ to a flash drive

Delta 219 computers are configured to automatically revert to a previously saved system state (a restore point) without prior notice.

- Your files may be permanently deleted without warning at any time (unannounced data loss).
- You cannot predict when these reverts will occur, nor can you prevent them from happening (limited user control).

Temporary data storage:

Your files are temporarily stored in the \$HOME\workspaces\ directory. These files are deleted during the automatic system revert process.

Protecting your data:

To avoid data loss, regularly back up your data using external USB drives or cloud storage services.

Reason for automatic system reverts:

This feature is designed to maintain a consistent simulation environment for all users.



Open Docker Desktop on Windows

For Windows users:

- 1. Left-click on the **Start button** (or press the Windows key).
- 2. Select Docker Desktop (or type Docker Desktop and press Enter).
- 3. Wait until Docker Desktop has fully started

Expected outcome: Docker Desktop is open and fully initialized, ready to run containers.



Open a terminal emulator on Windows

For Windows users:

- 1. Right-click on the **Start button** (or press the [Windows key] + [x]).
- 2. Select Windows PowerShell (or press I).

Expected outcome: A terminal emulator will open.

Windows PowerShell

Copyright (C) Microsoft Corporation. 著作權所有,並保留一切權利。

請嘗試新的跨平台 PowerShell https://aka.ms/pscore6

PS C:\Users\user>



Run a container in PowerShell

For PowerShell users, run this command:

```
docker run -it `
--device /dev/kvm `
--name ee6455-gem5 `
--volume $HOME\workspaces\:/workspaces/ `
--workdir /workspaces/2025/ `
--hostname EE6455-gem5 `
ghcr.io/gem5/devcontainer:bootcamp-2024
```

Expected outcome: An interactive TTY will indicate its readiness to accept commands.

```
root@EE6455-gem5:/workspaces/2025#
```

Alternative outcome: A newer image will be downloaded before the interactive TTY displays the username, hostname, and working directory.

```
PS C:\Users\user> docker container run -it
>> --name ee6455-gem5 `
>> --volume $HOME\workspaces\:/workspaces/
>> --workdir /workspaces/2025/ `
>> --hostname EE6455-gem5
>> ghcr.io/gem5/devcontainer:bootcamp-2024
Unable to find image 'ghcr.io/gem5/devcontainer:bootcamp-2024' locally
bootcamp-2024: Pulling from gem5/devcontainer
00d679a470c4: Pull complete
c782a11a41b6: Pull complete
4f6b9996da3d: Pull complete
bb60cbcef558: Pull complete
92c0abbbf0ee: Pull complete
865d1839a002: Pull complete
2ceb23f2c7bb: Pull complete
31825ae2d134: Pull complete
Digest: sha256:dc299b8bf11b324cbd89aab82bdbe31bf9ce71a33386f2a2153a590a803d2c71
Status: Downloaded newer image for ghcr.io/gem5/devcontainer:bootcamp-2024
root@EE6455-gem5:/workspaces/2025#
```



Manage an Existing Docker Container

• Start an existing container:

```
docker start ee6455-gem5
```

Attach a shell inside a running container:

```
docker exec -it ee6455-gem5 bash
```

- Opens a new Bash shell inside the container.
- You can have multiple terminals connected at the same time.
- Stop a running container:

```
docker stop ee6455-gem5
```



• Remove a container

docker rm ee6455-gem5

Works only if the container is stopped.



Get the source code of gem5

Clone the Bootcamp Repository (inside container):

```
time git clone --recurse-submodules \
https://nas.larc-nthu.net:8443/ee6455_2025/public-gem5bootcamp-2025 /workspaces/2025/
```

Expected outcome: A repository will be cloned, including its submodules.

```
root@EE6455-gem5:/workspaces/2025# time git clone --recurse-submodules https://nas.larc-nthu.net:8443/ee6455_2025/public-gem5bootcamp-2025 /workspaces/2025/
Cloning into '/workspaces/2025'...
warning: redirecting to https://nas.larc-nthu.net:8443/ee6455_2025/public-gem5bootcamp-2025.git/
remote: Enumerating objects: 11106, done.
remote: Counting objects: 100% (130/130), done.
remote: Compressing objects: 100% (130/130), done.
remote: Total 11106 (delta 78), reused 0 (delta 0), pack-reused 10976 (from 1)
Receiving objects: 100% (11106/11106), 385.46 MiB | 11.07 MiB/s, done.
Resolving deltas: 100% (7510/7510), done.
Updating files: 100% (966/966), done.
Submodule 'gem5' (https://github.com/gem5/gem5) registered for path 'gem5'
Submodule 'gem5-resources' (https://github.com/gem5/gem5-resources) registered for path 'gem5-resources'
Cloning into '/workspaces/2025/gem5'...
remote: Enumerating objects: 295271, done.
remote: Counting objects: 100% (604/604), done.
remote: Compressing objects: 100% (329/329), done.
remote: Total 295271 (delta 460), reused 275 (delta 275), pack-reused 294667 (from 3)
Receiving objects: 100% (295271/295271), 171.33 MiB | 5.20 MiB/s, done.
Resolving deltas: 100% (225064/225064), done.
Cloning into '/workspaces/2025/gem5-resources'...
```

Run a simulation using gem5

Run this command inside the container:

```
time gem5-mesi --outdir=/workspaces/m5out/ \
/workspaces/2025/materials/01-Introduction/02-getting-started/completed/basic.py
```

Expected outcome:

- The X86DemoBoard will be simulated using x86-ubuntu-24.04-img as the workload.
- On first run, gem5 will automatically download required resources:
 - x86-linux-kernel-5.4.0-105-generic
 - x86-ubuntu-24.04-img (~4.9 GB compressed, takes some time to download and decompress)

Note: Depending on your network speed, downloading and unpacking x86-ubuntu-24.04-img may take several minutes.

```
root@EE6455-gem5:/workspaces/2025# time gem5-mesi --outdir=/workspaces/m5out/ \
/workspaces/2025/materials/01-Introduction/02-getting-started/completed/basic.py
gem5 Simulator System. https://www.gem5.org
gem5 is copyrighted software; use the --copyright option for details.
gem5 version 24.0.0.0
gem5 compiled Jul 25 2024 18:47:27
gem5 started Aug 21 2025 09:19:18
gem5 executing on EE6455-gem5, pid 14
command line: gem5-mesi --outdir=/workspaces/m5out/ /workspaces/2025/materials/01-Introduction/02-getting-started/completed/basic.py
warn: The X86DemoBoard is solely for demonstration purposes. This board is not known to be be representative of any real-world system. Use with caution.
info: Using default config
Resource 'x86-linux-kernel-5.4.0-105-generic' was not found locally. Downloading to '/root/.cache/gem5/x86-linux-kernel-5.4.0-105-generic'...
Finished downloading resource 'x86-linux-kernel-5.4.0-105-generic'.
Resource 'x86-ubuntu-24.04-img' was not found locally. Downloading to '/root/.cache/gem5/x86-ubuntu-24.04-img.gz'...
Finished downloading resource 'x86-ubuntu-24.04-img'.
Decompressing resource 'x86-ubuntu-24.04-img' ('/root/.cache/gem5/x86-ubuntu-24.04-img.gz')...
Finished decompressing resource 'x86-ubuntu-24.04-img'.
warn: Max ticks has already been set prior to setting it through the run call. In these cases the max ticks set through the `run` function is used
Global frequency set at 1000000000000 ticks per second
src/mem/dram_interface.cc:690: warn: DRAM device capacity (8192 Mbytes) does not match the address range assigned (2048 Mbytes)
src/sim/kernel_workload.cc:46: info: kernel located at: /root/.cache/gem5/x86-linux-kernel-5.4.0-105-generic
src/base/statistics.hh:279: warn: One of the stats is a legacy stat. Legacy stat is a stat that does not belong to any statistics::Group. Legacy stat is deprecated.
      0: board.pc.south_bridge.cmos.rtc: Real-time clock set to Sun Jan 1 00:00:00 2012
board.pc.com_1.device: Listening for connections on port 3456
src/base/statistics.hh:279: warn: One of the stats is a legacy stat. Legacy stat is a stat that does not belong to any statistics::Group. Legacy stat is deprecated.
src/dev/intel_8254_timer.cc:128: warn: Reading current count from inactive timer.
board.remote_gdb: Listening for connections on port 7000
src/sim/simulate.cc:199: info: Entering event queue @ 0. Starting simulation...
src/mem/ruby/system/Sequencer.cc:680: warn: Replacement policy updates recently became the responsibility of SLICC state machines. Make sure to setMRU() near callbacks in .sm files!
build/ALL/arch/x86/generated/exec-ns.cc.inc:27: warn: instruction 'fninit' unimplemented
        42m27.091s
real
        0m38.201s
user
        0m16.827s
root@EE6455-gem5:/workspaces/2025#
```



Retrieve the simulation statistics

On Windows

After the simulation finishes, open \$\text{\text} \text{\text} \text{\text} using a text editor. This file contains the detailed statistics generated by gem5.

Inside the container

You can also view the file directly inside the running container, for example by scrolling through the whole file:

root@EE6455-gem5:/workspaces/2025# less /workspaces/m5out/stats.txt



Expected outcome: The first few lines will resemble this:

```
----- Begin Simulation Statistics -----
simSeconds
                                             0.020000
                                                                            # Number of seconds simulated (Second)
simTicks
                                          20000000000
                                                                            # Number of ticks simulated (Tick)
finalTick
                                          200000000000
                                                                            # Number of ticks from beginning of simulation (restored from checkpoints and never reset) (Tick)
simFreq
                                         10000000000000
                                                                             # The number of ticks per simulated second ((Tick/Second))
                                                                            # Real time elapsed on the host (Second)
hostSeconds
                                                18.88
                                                                            # The number of ticks simulated per host second (ticks/s) ((Tick/Second))
hostTickRate
                                           1059100397
                                              2770924
                                                                            # Number of bytes of host memory used (Byte)
hostMemory
simInsts
                                              7479814
                                                                            # Number of instructions simulated (Count)
                                             34912342
                                                                            # Number of ops (including micro ops) simulated (Count)
simOps
hostInstRate
                                               396059
                                                                            # Simulator instruction rate (inst/s) ((Count/Second))
hostOpRate
                                              1848597
                                                                            # Simulator op (including micro ops) rate (op/s) ((Count/Second))
                                                                                                 # delay histogram for all message (Unspecified)
board.cache_hierarchy.ruby_system.delayHistogram::bucket_size
board.cache_hierarchy.ruby_system.delayHistogram::max_bucket
                                                                                                # delay histogram for all message (Unspecified)
                                                                       19
board.cache_hierarchy.ruby_system.delayHistogram::samples
                                                                735551
                                                                                             # delay histogram for all message (Unspecified)
board.cache_hierarchy.ruby_system.delayHistogram::mean
                                                           1.036855
                                                                                          # delay histogram for all message (Unspecified)
                                                                                           # delay histogram for all message (Unspecified)
board.cache_hierarchy.ruby_system.delayHistogram::stdev
                                                            2.687016
```



Retrieve the simulation configuration

- On Windows: open [\$HOME\workspaces\m5out\config.ini] using a text editor.
- Inside the container:

less /workspaces/m5out/config.ini

Expected outcome: The first few lines will resemble this:

```
[board]
type=System
children=cache_hierarchy clk_domain dvfs_handler iobus memory pc processor workload
auto_unlink_shared_backstore=false
cache_line_size=64
eventq_index=0
exit_on_work_items=true
init_param=0
m5ops_base=4294901760
```

```
mem_mode=timing
mem_ranges=0:2147483648 3221225472:3222274048
memories=board.memory.mem_ctrl.dram
mmap_using_noreserve=false
multi thread=false
num_work_ids=16
readfile=
redirect_paths=
shadow_rom_ranges=
shared_backstore=
symbolfile=
thermal_components=
thermal model=Null
work_begin_ckpt_count=0
work_begin_cpu_id_exit=-1
work_begin_exit_count=0
work_cpus_ckpt_count=0
work_end_ckpt_count=0
work_end_exit_count=0
```