```
Alle Aufgaben:
1.1)
const unsigned int led = 13;
const unsigned int t_on=1000, t_off=1000;
void setup () {
 pinMode ( led , OUTPUT );
void loop () {
 digitalWrite ( led , HIGH );
 delay (t_on);
 digitalWrite ( led , LOW ) ;
                                   J OSP
 delay(t_off);
}
1.2.a)
const unsigned int led = 13;
const unsigned int t_on=2500, t_off=2500;
void setup () {
 pinMode ( led , OUTPUT );
}
void loop () {
 digitalWrite ( led , HIGH );
 delay (t_on);
 digitalWrite ( led , LOW ) ;
                                        V OSP
 delay(t_off);
}
1.2.b)
const unsigned int led = 13;
const unsigned int t_on=3000, t_off=1000;
void setup () {
 pinMode ( led , OUTPUT );
void loop () {
 digitalWrite ( led , HIGH );
 delay (t_on);
 digitalWrite ( led , LOW ) ;
                                          0,59
 delay(t_off);
}
1.2.c)
const unsigned int led = 13;
```

```
const unsigned int t_on=500, t_off=500;
void setup () {
 pinMode ( led , OUTPUT );
void loop () {
 digitalWrite ( led , HIGH );
 delay (t_on);
 digitalWrite ( led , LOW ) ;
                                           259
 delay(t_off);
}
2.1)
int led = 13; // led to use for output (13 is built-in)
int dit_delay = 500;
                               // length of a dit in ms
int dah_delay = dit_delay * 3; // length of a dah in ms
// dit() and dat() already include dit_delay
int letter_delay = dah_delay - dit_delay;
// letters already include letter delay
int word_delay = dit_delay * 7 - letter_delay;
void dit() {
   Serial.print(".");
   // send a dit
   digitalWrite(led, HIGH);
   delay(dit_delay);
   digitalWrite(led, LOW);
   delay(dit_delay);
}
void dah() {
   Serial.print("-");
    // send a dah
   digitalWrite(led, HIGH);
   delay(dah_delay);
   digitalWrite(led, LOW);
   delay(dit_delay);
}
```

```
void pause_letter() {
  Serial.println("");
  delay(letter_delay);
}
void pause_word() {
  Serial.println("");
  delay(word_delay);
}
void morse_S() {
 dit(); dit(); dit();
 pause_letter();
}
void morse_O() {
 dah(); dah(); dah();
 pause_letter();
}
void morse_SOS() {
   morse_S(); morse_O(); morse_S();
   pause_word();
}
// send n in morse code
void morse_digit(int n) {
   Serial.print("morse_digit(");
   Serial.print(n);
   Serial.println(")...");
   if (n == 0) {
       dah(); dah(); dah(); dah();
   if (n == 1) {
       dit(); dah(); dah(); dah();
   if (n == 2) {
       dit(); dit(); dah(); dah();
   if (n == 3) {
       dit(); dit(); dah(); dah();
   if (n == 4) {
       dit(); dit(); dit(); dah();
    }
```

```
if (n == 5) {
       dit(); dit(); dit(); dit();
   if (n == 6) {
       dah(); dit(); dit(); dit();
   if (n == 7) {
       dah(); dah(); dit(); dit();
   if (n == 8) {
       dah(); dah(); dit(); dit();
   if (n == 9) {
       dah(); dah(); dah(); dit();
   pause_letter();
   Serial.print("morse_digit(");
   Serial.print(n);
   Serial.println(")...done");
}
void morse_number(int n) {
   Serial.print("morse_number(");
   Serial.print(n);
   Serial.println(")...");
   if (n >= 10) {
       morse_number(n / 10);
   morse_digit(n % 10);
   Serial.print("morse_number(");
   Serial.print(n);
   Serial.println(")...done");
}
void setup() {
 // put your setup code here, to run once:
 // Configure LED as output
 pinMode(led, OUTPUT);
 // Use serial port as output
 Serial.begin(9600);
}
```

```
void morse_letter(char c) {
 Serial.print("morse_letter(");
 Serial.print(c);
 Serial.println(")...");
 switch (c) {
   case 'a':{dit();dah();break;}
   case 'b':{dah();dit();dit();break;}
   case 'c':{dah();dit();dah();dit();break;}
   case 'd':{dah();dit();dit();break;}
   case 'e':{dit();break;}
   case 'f':{dit();dit();dah();dit();break;}
   case 'g':{dah();dah();dit();break;}
   case 'h':{dit();dit();dit();break;}
   case 'i':{dit();dit();break;}
   case 'j':{dit();dah();dah();break;}
   case 'k':{dah();dit();dah();break;}
   case 'l':{dit();dah();dit();dit();break;}
   case 'm':{dah();dah();break;}
   case 'n':{dah();dit();break;}
   case 'o':{dah();dah();dah();break;}
   case 'p':{dit();dah();dit();break;}
   case 'q':{dah();dah();dit();dah();break;}
   case 'r':{dit();dah();dit();break;}
   case 's':{dit();dit();break;}
   case 't':{dah();break;}
   case 'u':{dit();dit();dah();break;}
   case 'v':{dit();dit();dah();break;}
   case 'w':{dit();dah();dah();break;}
   case 'x':{dah();dit();dah();break;}
   case 'y':{dah();dit();dah();dah();break;}
   case 'z':{dah();dah();dit();break;}
 }
 pause_letter();
 Serial.print("morse_letter(");
 Serial.print(c);
 Serial.println(")...done");
}
void morse_word(String s) {
 Serial.print("morse_word(");
 Serial.print(s);
 Serial.println(")...");
 for (int i = 0; i < s.length(); i++) {
   morse_letter(s[i]);
  }
```

```
pause_word();
 Serial.print("morse_word(");
 Serial.print(s);
 Serial.println(")...done");
}
void loop() {
 // put your main code here, to run repeatedly:
 morse_SOS();
 morse_pumber(5024);
 morse_word("saarland");
 morse_word("university");
}
2.2)
int led1 = 12; // led to use for output (13 is built-in)
int led2 = 13;
int dit_delay = 500;
                             // length of a dit in ms
int dah_delay = dit_delay * 3; // length of a dah in ms
// dit() and dat() already include dit_delay
int letter_delay = dah_delay - dit_delay;
// letters already include letter delay
int word_delay = dit_delay * 7 - letter_delay;
void dit(int a) {
   Serial.print(".");
   // send a dit
   digitalWrite(a, HIGH);
   delay(dit_delay);
   digitalWrite(a, LOW);
   delay(dit_delay);
}
void dah(int a) {
   Serial.print("-");
   // send a dah
   digitalWrite(a, HIGH);
   delay(dah_delay);
   digitalWrite(a, LOW);
   delay(dit_delay);
```

```
}
void pause_letter() {
  Serial.println("");
  delay(letter_delay);
}
void pause_word() {
  Serial.println("");
  delay(word_delay);
}
void morse_S() {
 dit(led1); dit(led1); dit(led1);
 pause_letter();
}
void morse_O() {
 dah(led1); dah(led1); dah(led1);
 pause_letter();
}
void morse_SOS() {
   morse_S(); morse_O(); morse_S();
   pause_word();
}
// send n in morse code
void morse_digit(int n) {
   Serial.print("morse_digit(");
   Serial.print(n);
   Serial.println(")...");
   if (n == 0) {
       dah(led1); dah(led1); dah(led1); dah(led1);
   if (n == 1) {
       dit(led1); dah(led1); dah(led1); dah(led1);
   if (n == 2) {
       dit(led1); dit(led1); dah(led1); dah(led1); dah(led1);
   if (n == 3) {
       dit(led1); dit(led1); dah(led1); dah(led1);
   if (n == 4) {
```

```
dit(led1); dit(led1); dit(led1); dah(led1);
   if (n == 5) {
      dit(led1); dit(led1); dit(led1); dit(led1);
   if (n == 6) {
      dah(led1); dit(led1); dit(led1); dit(led1);
   if (n == 7) {
      dah(led1); dah(led1); dit(led1); dit(led1);
   if (n == 8) {
      dah(led1); dah(led1); dit(led1); dit(led1);
   if (n == 9) {
      dah(led1); dah(led1); dah(led1); dit(led1);
   pause_letter();
   Serial.print("morse_digit(");
   Serial.print(n);
   Serial.println(")...done");
}
void morse_number(int n) {
   Serial.print("morse_number(");
   Serial.print(n);
   Serial.println(")...");
   if (n >= 10) {
       morse_number(n / 10);
   morse_digit(n % 10);
   Serial.print("morse_number(");
   Serial.print(n);
   Serial.println(")...done");
}
void setup() {
 // put your setup code here, to run once:
 // Configure LED as output
 pinMode(led1, OUTPUT);
 pinMode(led2, OUTPUT);
 // Use serial port as output
```

```
Serial.begin (9600);
}
void morse_letter(char c, int a) {
 Serial.print("morse_letter(");
 Serial.print(c);
 Serial.println(")...");
 switch (c) {
   case 'b':{dah(a);dit(a);dit(a);break;}
   case 'a':{dit(a);dah(a);break;}
   case 'c': {dah(a);dit(a);dah(a);dit(a);break;}
   case 'd':{dah(a);dit(a);dit(a);break;}
   case 'e':{dit(a);break;}
   case 'f':{dit(a);dit(a);dah(a);dit(a);break;}
   case 'g':{dah(a);dah(a);dit(a);break;}
   case 'h':{dit(a);dit(a);dit(a);break;}
   case 'i':{dit(a);dit(a);break;}
   case 'j':{dit(a);dah(a);dah(a);break;}
   case 'k': {dah(a);dit(a);dah(a);break;}
   case 'l':{dit(a);dah(a);dit(a);dit(a);break;}
   case 'm':{dah(a);dah(a);break;}
   case 'n':{dah(a);dit(a);break;}
   case 'o':{dah(a);dah(a);dah(a);break;}
   case 'p':{dit(a);dah(a);dit(a);break;}
   case 'q':{dah(a);dah(a);dit(a);dah(a);break;}
   case 'r':{dit(a);dah(a);dit(a);break;}
   case 's':{dit(a);dit(a);break;}
   case 't':{dah(a);break;}
   case 'u':{dit(a);dit(a);dah(a);break;}
   case 'v':{dit(a);dit(a);dah(a);break;}
   case 'w':{dit(a);dah(a);dah(a);break;}
   case 'x':{dah(a);dit(a);dit(a);dah(a);break;}
  case 'y':{dah(a);dit(a);dah(a);break;}
   case 'z':{dah(a);dah(a);dit(a);break;}
 }
 pause_letter();
 Serial.print("morse_letter(");
 Serial.print(c);
 Serial.println(")...done");
}
void morse_word(String s, int a) {
 Serial.print("morse_word(");
 Serial.print(s);
 Serial.println(")...");
 for (int i = 0; i < s.length(); i++) {
```

```
morse_letter(s[i],a);
  }
 pause_word();
 Serial.print("morse_word(");
 Serial.print(s);
 Serial.println(")...done");
void loop() {
 // put your main code here, to run repeatedly:
 morse_SOS();
 morse_number(5024);
 morse_word("saarland", led1);
 morse_word("university", led2);
2.3
int led = 13; // led to use for output (13 is built-in)
int dit_delay = 500;
                             // length of a dit in ms
int dah_delay = dit_delay * 3; // length of a dah in ms
// dit() and dat() already include dit_delay
int letter_delay = dah_delay - dit_delay;
// letters already include letter delay
int word_delay = dit_delay * 7 - letter_delay;
void dit() {
   Serial.print(".");
   // send a dit
   digitalWrite(led, HIGH);
   delay(dit_delay);
   digitalWrite(led, LOW);
   delay(dit_delay);
}
void dah() {
   Serial.print("-");
   // send a dah
   digitalWrite(led, HIGH);
   delay(dah_delay);
```

```
digitalWrite(led, LOW);
   delay(dit_delay);
}
void pause_letter() {
  Serial.println("");
  delay(letter_delay);
}
void pause_word() {
  Serial.println("");
  delay(word_delay);
}
void morse_S() {
 dit(); dit(); dit();
 pause_letter();
}
void morse_O() {
 dah(); dah(); dah();
 pause_letter();
}
void morse_SOS() {
   morse_S(); morse_O(); morse_S();
   pause_word();
}
// send n in morse code
void morse_digit(int n) {
   Serial.print("morse_digit(");
   Serial.print(n);
   Serial.println(")...");
    if (n == 0) {
       dah(); dah(); dah(); dah();
    if (n == 1) {
       dit(); dah(); dah(); dah();
    if (n == 2) {
       dit(); dit(); dah(); dah();
    if (n == 3) {
```

```
dit(); dit(); dah(); dah();
   if (n == 4) {
      dit(); dit(); dit(); dah();
   if (n == 5) {
      dit(); dit(); dit(); dit();
   if (n == 6) {
      dah(); dit(); dit(); dit();
   if (n == 7) {
      dah(); dah(); dit(); dit();
   if (n == 8) {
      dah(); dah(); dit(); dit();
   if (n == 9) {
      dah(); dah(); dah(); dit();
   pause_letter();
   Serial.print("morse_digit(");
   Serial.print(n);
   Serial.println(")...done");
}
void morse_number(int n) {
   Serial.print("morse_number(");
   Serial.print(n);
   Serial.println(")...");
   if (n >= 10) {
       morse_number(n / 10);
   morse_digit_even(n % 10); //changed
  Serial.print("morse_number(");
   Serial.print(n);
   Serial.println(")...done");
}
void morse_digit_even(int n) {
 if (n%2==0) {
   morse_digit(n);
  }
```

```
}
void setup() {
  // put your setup code here, to run once:
 // Configure LED as output
 pinMode(led, OUTPUT);
 // Use serial port as output
 Serial.begin(9600);
void loop() {
  // put your main code here, to run repeatedly:
 morse_SOS();
 morse_number(876543210);
}
3.a)
Fehlermeldungen passiert beim Übersetzen dieses Programms,
weil es viele Syntax-Fehler gibt.
Z.b die setup funktion hat keine "()". Das Programms hat auch
eine Logikfehler in der blink_if_even Funktion.
3.b)
Es gibt Fehlermeldungen und diese bedutet dass es
Syntax-Fehlen gibt.
3.c)
Es gibt Fehlermeldungen.
3.d
const int led_red = 12;
const int led_green = 12+1;
int counter = 1;
void blink_if_even (int n ) {
  if (n % 2 == 10) { \frac{1}{100}} even
   digitalWrite ( led_red , HIGH ) ;
   digitalWrite ( led_green , LOW ) ;
  }else { // odd
   digitalWrite ( led_red , LOW ) ;
   digitalWrite ( led_green , HIGH ) ;
  } /
}
```

```
void setup() {
 pinMode ( led_red , OUTPUT );
 pinMode ( led_green , OUTPUT );
}
void loop() {
 blink_if_even ( counter );
 counter = counter + 1;
                                                   5/5
 delay (1000);
}
3 bonus)
Mit einer einfacheren Methode um die LED abwechselnd blinken
zu lassen.
Man kann im loop die erste LED eine sekunde aufleuchte lassen
und danach die zweite, sodass der loop dann diese abfolge
wiederholt.
Wenn man in einem loop durchlauf nur einmal die LEDs ändern
möchte, kann man die methode blink_if_even durch eine swap
methode ersetzten,
und den counter braucht man auch nicht:
int led1=12;
int led2=13;
int tausch=0;
void setup() {
 pinMode ( led2 , OUTPUT );
 pinMode ( led2 , OUTPUT );
}
void swap() {
  digitalWrite(led1, HIGH);
  digitalWrite(led2, LOW);
  tausch=led1;
  led1=led2;
  led2=tausch;
}
                         V + 2 Bonsspunkte
void loop() {
 swap();
 delay(1000);
                                              12/12 + 3 Donuspunhte
}
```