

Testing the MetroCluster configuration

ONTAP MetroCluster

ntap-bmegan, zachary wambold April 06, 2021

This PDF was generated from https://docs.netapp.com/us-en/ontap-metrocluster/install-ip/task_test_the_mcc_configuration.html on May 31, 2021. Always check docs.netapp.com for the latest.

Table of Contents

Γe	esting the MetroCluster configuration	
	Verifying negotiated switchover	١
	Verifying healing and manual switchback	•
	Verifying operation after power line disruption	:
	Verifying operation after loss of a single storage shelf	

Testing the MetroCluster configuration

You can test failure scenarios to confirm the correct operation of the MetroCluster configuration.

Verifying negotiated switchover

You can test the negotiated (planned) switchover operation to confirm uninterrupted data availability.

This test validates that data availability is not affected (except for Microsoft Server Message Block (SMB) and Solaris Fibre Channel protocols) by switching the cluster over to the second data center.

This test should take about 30 minutes.

This procedure has the following expected results:

• The metrocluster switchover command will present a warning prompt.

If you respond yes to the prompt, the site the command is issued from will switch over the partner site.

For MetroCluster IP configurations:

- For ONTAP 9.4 and earlier:
 - · Mirrored aggregates will become degraded after the negotiated switchover.
- For ONTAP 9.5 and later:
 - Mirrored aggregates will remain in normal state if the remote storage is accessible.
 - Mirrored aggregates will become degraded after the negotiated switchover if access to the remote storage is lost.
- For ONTAP 9.8 and later:
 - Unmirrored aggregates that are located at the disaster site will become unavailable if access to the remote storage is lost. This might lead to a controller outage.
 - 1. Confirm that all nodes are in the configured state and normal mode: metrocluster node show

2. Begin the switchover operation: metrocluster switchover

```
cluster_A::> metrocluster switchover
Warning: negotiated switchover is about to start. It will stop all
the data Vservers on cluster "cluster_B" and
automatically re-start them on cluster "cluster_A". It will
finally gracefully shutdown cluster "cluster_B".
```

3. Confirm that the local cluster is in the configured state and switchover mode: metrocluster node show

4. Confirm that the switchover operation was successful: metrocluster operation show

```
cluster_A::> metrocluster operation show

cluster_A::> metrocluster operation show

Operation: switchover
        State: successful

Start Time: 2/6/2016 13:28:50
    End Time: 2/6/2016 13:29:41
        Errors: -
```

5. Use the vserver show and network interface show commands to verify that DR SVMs and LIFs have come online.

Verifying healing and manual switchback

You can test the healing and manual switchback operations to verify that data availability is not affected (except for SMB and Solaris FC configurations) by switching back the cluster to the original data center after a negotiated switchover.

This test should take about 30 minutes.

The expected result of this procedure is that services should be switched back to their home nodes.

The healing steps are not required on systems running ONTAP 9.5 or later, on which healing is performed automatically after a negotiated switchover. On systems running ONTAP 9.6 and later, healing is also

performed automatically after unscheduled switchover.

1. If the system is running ONTAP 9.4 or earlier, heal the data aggregate: metrocluster heal aggregates

The following example shows the successful completion of the command:

```
cluster_A::> metrocluster heal aggregates
[Job 936] Job succeeded: Heal Aggregates is successful.
```

 If the system is running ONTAP 9.4 or earlier, heal the root aggregate: metrocluster heal rootaggregates

This step is required on the following configurations:

- MetroCluster FC configurations.
- MetroCluster IP configurations running ONTAP 9.4 or earlier. The following example shows the successful completion of the command:

```
cluster_A::> metrocluster heal root-aggregates
[Job 937] Job succeeded: Heal Root Aggregates is successful.
```

3. Verify that healing is completed: metrocluster node show

The following example shows the successful completion of the command:

If the automatic healing operation fails for any reason, you must issue the metrocluster heal commands manually as done in ONTAP versions prior to ONTAP 9.5. You can use the metrocluster operation show and metrocluster operation history show -instance commands to monitor the status of healing and determine the cause of a failure.

4. Verify that all aggregates are mirrored: storage aggregate show

The following example shows that all aggregates have a RAID Status of mirrored:

```
cluster A::> storage aggregate show
cluster Aggregates:
Aggregate Size Available Used% State #Vols Nodes RAID
______ _____
_____
data cluster
       4.19TB 4.13TB 2% online 8 node_A_1 raid_dp,
                                            mirrored,
                                            normal
root cluster
       715.5GB 212.7GB 70% online 1 node A 1 raid4,
                                            mirrored,
                                            normal
cluster B Switched Over Aggregates:
Aggregate Size Available Used% State #Vols Nodes RAID
_____ ______
data cluster B
        4.19TB 4.11TB 2% online 5 node_A_1 raid_dp,
                                           mirrored,
                                           normal
root_cluster_B - - - unknown - node_A_1 -
```

- 5. Boot nodes from the disaster site.
- 6. Check the status of switchback recovery: metrocluster node show

7. Perform the switchback: metrocluster switchback

```
cluster_A::> metrocluster switchback
[Job 938] Job succeeded: Switchback is successful.Verify switchback
```

8. Confirm status of the nodes: metrocluster node show

9. Confirm status of the metrocluster operation: metrocluster operation show

The output should show a successful state.

```
cluster_A::> metrocluster operation show
  Operation: switchback
     State: successful
Start Time: 2/6/2016 13:54:25
    End Time: 2/6/2016 13:56:15
     Errors: -
```

Verifying operation after power line disruption

You can test the MetroCluster configuration's response to the failure of a PDU.

The best practice is for each power supply unit (PSU) in a component to be connected to separate power supplies. If both PSUs are connected to the same power distribution unit (PDU) and an electrical disruption occurs, the site could down or a complete shelf might become unavailable. Failure of one power line is tested to confirm that there is no cabling mismatch that could cause a service disruption.

This test should take about 15 minutes.

This test requires turning off power to all left-hand PDUs and then all right-hand PDUs on all of the racks containing the MetroCluster components.

This procedure has the following expected results:

• Errors should be generated as the PDUs are disconnected.

- No failover or loss of service should occur.
 - 1. Turn off the power of the PDUs on the left-hand side of the rack containing the MetroCluster components.
 - 2. Monitor the result on the console by using the system environment sensors show -state fault and storage shelf show -errors commands.

```
cluster A::> system environment sensors show -state fault
Node Sensor State Value/Units Crit-Low Warn-Low Warn-Hi
Crit-Hi
node A 1
     PSU1
             fault
                    PSU OFF
      PSU1 Pwr In OK fault
                       FAULT
node A 2
      PSU1
                   fault
                       PSU OFF
       PSU1 Pwr In OK fault
                       FAULT
4 entries were displayed.
cluster A::> storage shelf show -errors
   Shelf Name: 1.1
    Shelf UID: 50:0a:09:80:03:6c:44:d5
Serial Number: SHFHU1443000059
Error Type Description
_____
                Critical condition is detected in storage shelf
power supply unit "1". The unit might fail. Reconnect PSU1
```

- 3. Turn the power back on to the left-hand PDUs.
- 4. Make sure that ONTAP clears the error condition.
- 5. Repeat the previous steps with the right-hand PDUs.

Verifying operation after loss of a single storage shelf

You can test the failure of a single storage shelf to verify that there is no single point of failure.

This procedure has the following expected results:

- An error message should be reported by the monitoring software.
- No failover or loss of service should occur.
- Mirror resynchronization starts automatically after the hardware failure is restored.
 - 1. Check the storage failover status: storage failover show

```
Cluster_A::> storage failover show

Node Partner Possible State Description

node_A_1 node_A_2 true Connected to node_A_2 node_A_2 node_A_1 true Connected to node_A_1 true Connected to node_A_1 entries were displayed.
```

2. Check the aggregate status: storage aggregate show

```
cluster A::> storage aggregate show
cluster Aggregates:
Aggregate Size Available Used% State #Vols Nodes
RAID Status
_____ ____
-----
node A 1data01 mirrored
        4.15TB 3.40TB 18% online 3 node_A_1
raid dp,
mirrored,
normal
node A 1root
  707.7GB 34.29GB 95% online 1 node A 1
raid dp,
mirrored,
normal
node A 2 data01 mirrored
       4.15TB 4.12TB 1% online 2 node_A_2
raid_dp,
mirrored,
normal
node_A_2_data02_unmirrored
        raid_dp,
normal
node A 2 root
       707.7GB 34.27GB 95% online 1 node A 2
raid dp,
mirrored,
normal
```

3. Verify that all data SVMs and data volumes are online and serving data: vserver show -type datanetwork interface show -fields is-home falsevolume show !vol0,!MDV*

```
cluster A::> vserver show -type data
cluster A::> vserver show -type data
                      Admin Operational Root
Vserver Type Subtype State
                              State Volume
Aggregate
SVM1 data sync-source running SVM1_root
node A 1 data01 mirrored
SVM2 data sync-source running SVM2_root
node A 2 data01 mirrored
cluster A::> network interface show -fields is-home false
There are no entries matching your query.
cluster A::> volume show !vol0,!MDV*
Vserver Volume
            Aggregate State Type Size
Available Used%
______ _____
_____
SVM1
       SVM1 root
                node A 1data01 mirrored
                          online RW 10GB
9.50GB
       5%
SVM1
       SVM1 data vol
                 node A 1data01 mirrored
                         online RW
                                         10GB
9.49GB
       5%
SVM2
       SVM2 root
                node A 2 data01 mirrored
                          online RW
                                         10GB
9.49GB 5%
SVM2
       SVM2 data vol
                 node A 2 data02 unmirrored
                          online RW
                                           1GB
972.6MB 5%
```

4. Identify a shelf in Pool 1 for node node_A_2 to power off to simulate a sudden hardware failure: storage aggregate show -r -node node-name !*root

The shelf you select must contain drives that are part of a mirrored data aggregate.

```
cluster A::> storage aggregate show -r -node node A 2 !*root
Owner Node: node A 2
Aggregate: node A 2 data01 mirrored (online, raid dp, mirrored)
(block checksums)
 Plex: /node A 2 data01 mirrored/plex0 (online, normal, active,
pool0)
  RAID Group /node A 2 data01 mirrored/plex0/rg0 (normal, block
checksums)
                                                 Usable
Physical
                                Pool Type RPM Size
   Position Disk
Size Status
   _____
   dparity 2.30.3
                                  0 BSAS 7200 827.7GB
828.0GB (normal)
                                  0 BSAS 7200 827.7GB
   parity 2.30.4
828.0GB (normal)
   data 2.30.6
                                  0 BSAS 7200 827.7GB
828.0GB (normal)
   data 2.30.8
                                  0 BSAS 7200 827.7GB
828.0GB (normal)
  data 2.30.5
                                  0 BSAS 7200 827.7GB
828.0GB (normal)
 Plex: /node A 2 data01 mirrored/plex4 (online, normal, active,
pool1)
  RAID Group /node A 2 data01 mirrored/plex4/rg0 (normal, block
checksums)
                                                 Usable
Physical
   Position Disk
                                Pool Type RPM Size
Size Status
   _____
   dparity 1.31.7
                                  1 BSAS 7200 827.7GB
828.0GB (normal)
   parity 1.31.6
                                  1 BSAS
                                           7200 827.7GB
828.0GB (normal)
   data 1.31.3
                                  1 BSAS 7200 827.7GB
828.0GB (normal)
   data 1.31.4
                                  1 BSAS
                                           7200 827.7GB
828.0GB (normal)
   data 1.31.5
                                  1 BSAS
                                            7200 827.7GB
```

```
828.0GB (normal)
Aggregate: node A 2 data02 unmirrored (online, raid dp) (block
checksums)
 Plex: /node A 2 data02 unmirrored/plex0 (online, normal, active,
pool0)
  RAID Group /node A 2 data02 unmirrored/plex0/rg0 (normal, block
checksums)
                                                  Usable
Physical
   Position Disk
                             Pool Type RPM
                                                   Size
Size Status
   _____
   dparity 2.30.12
                                   0 BSAS 7200 827.7GB
828.0GB (normal)
   parity 2.30.22
                                   0 BSAS
                                            7200 827.7GB
828.0GB (normal)
   data 2.30.21
                                   0 BSAS
                                            7200 827.7GB
828.0GB (normal)
    data 2.30.20
                                            7200 827.7GB
                                   0 BSAS
828.0GB (normal)
                                   0 BSAS
   data 2.30.14
                                            7200 827.7GB
828.0GB (normal)
```

15 entries were displayed.

- 5. Physically power off the shelf that you selected.
- 6. Check the aggregate status again: storage aggregate show``storage aggregate show`-r -node node A 2 !*root

The aggregate with drives on the powered-off shelf should have a degraded RAID status, and drives on the affected plex should have a failed status, as shown in the following example:

```
node A 1root
       707.7GB 34.29GB 95% online 1 node_A_1
raid dp,
mirrored,
normal
node A 2 data01 mirrored
        4.15TB 4.12TB 1% online 2 node_A_2
raid dp,
mirror
degraded
node A 2 data02 unmirrored
        raid dp,
normal
node A 2 root
       707.7GB 34.27GB 95% online 1 node A 2
raid_dp,
mirror
degraded
cluster A::> storage aggregate show -r -node node A 2 !*root
Owner Node: node A 2
Aggregate: node A 2 data01 mirrored (online, raid dp, mirror
degraded) (block checksums)
Plex: /node A 2 data01 mirrored/plex0 (online, normal, active,
pool0)
  RAID Group /node A 2 data01 mirrored/plex0/rg0 (normal, block
checksums)
                                                  Usable
Physical
  Position Disk
                                Pool Type RPM Size
Size Status
   _____
   dparity 2.30.3
                                  0 BSAS 7200 827.7GB
828.0GB (normal)
   parity 2.30.4
                                   0 BSAS 7200 827.7GB
828.0GB (normal)
  data 2.30.6
                                  0 BSAS 7200 827.7GB
828.0GB (normal)
```

data 2.30.8 828.0GB (normal)	0	BSAS	7200	827.7GB	
data 2.30.5	0	DCAC	7200	827.7GB	
	O	DSAS	7200	021.1GD	
828.0GB (normal)					
Plex: /node_A_2_data01_mirrored/plex4	(offli	ne, fai	led, in	active,	
pool1)					
RAID Group /node_A_2_data01_mirrored/	plex4/	rg0 (pa	rtial,	none	
checksums)					
				Usable	
Physical					
Position Disk	Pool	Type	RPM	Size	
Size Status					
dparity FAILED	_	_	_	827.7GB	
	_	_	_	027.7GB	
- (failed)				005 505	
parity FAILED	_	_	_	827.7GB	
- (failed)					
data FAILED	-	-	-	827.7GB	
- (failed)					
data FAILED	-	-	-	827.7GB	
- (failed)					
data FAILED	_	_	_	827.7GB	
- (failed)					
Aggregate: node A 2 data02 unmirrored (online	. raid	dp) (bl	ock	
checksums)	01111110	,	.αρ/ (ω_	0011	
	·	ino no	20m o 1 o	a+ i	
Plex: /node_A_2_data02_unmirrored/plex	.0 (0111	ine, no	Illial, a	ctive,	
pool0)	- / -	0 / 0 /	_		
RAID Group /node_A_2_data02_unmirrore	ed/plex	0/rg0 (normal,	block	
checksums)					
				Usable	
Physical					
Position Disk	Pool	Type	RPM	Size	
Size Status					
dparity 2.30.12	0	BSAS	7200	827.7GB	
828.0GB (normal)	J		_ 5		
parity 2.30.22	0	BSAS	7200	827.7GB	
	U	DONO	1200	021.1GD	
828.0GB (normal)	^	DCTC		005 5~-	
data 2.30.21	0	BSAS	7200	827.7GB	
828.0GB (normal)					
data 2.30.20	0	BSAS	7200	827.7GB	
828.0GB (normal)					
<u></u>					

data 2.30.14 0 BSAS 7200 827.7GB 828.0GB (normal) 15 entries were displayed.

7. Verify that the data is being served and that all volumes are still online: vserver show -type datanetwork interface show -fields is-home falsevolume show !vol0,!MDV*

aluster	A::> vserve	show -tyr	ne data			
CIUSCEI_	vaerve.	r silow cyl	Admin	Operat	ional R	oot
Vserver	Туре	Subtype		_		
Aggregat		11				
						77747
	data		ce	runnir	ıg S	VMI_root
	_data01_mirı data		70	runnir	g 9	VM2 root
	data01 mir	_		LUIIIIII	19 5	VIIZ_100C
cluster_	A::> networ	c interface	e show -fi	elds is-h	ome fal	se
There ar	e no entries	s matching	your quer	У•		
_	A::> volume					~ !
	Volume	Aggrega	ate Sta	te 1	'уре	Size
Availabl	e Used% 					
77741						
2 AMT						
SVMI	SVM1_root					
SVM1	SVM1_root	node A	_1data01_ m	irrored		
SVMI	SVM1_root	node_A_		irrored ine F	.W	10GB
	_	node_A_			W	10GB
9.50GB	_	node_A_			W	10GB
9.50GB SVM1	_	_vol	onl	ine F	W	10GB
9.50GB	5%	_vol	onl ldata01_m	ine F	W.	
9.50GB SVM1	5% SVM1_data_	_vol	onl	ine F	W.	10GB 10GB
9.50GB SVM1 9.49GB	5%	_vol	onl ldata01_m	ine F		
9.50GB	5% SVM1_data_ 5%	_vol	onl ldata01_m	ine F		
9.50GB SVM1 9.49GB	5% SVM1_data_	_vol node_A_	onl onl _ldata01_m onl	ine Firrored		
9.50GB SVM1 9.49GB	5% SVM1_data_ 5%	_vol node_A_	onl _ldata01_m onl _ldata01_m	ine F irrored ine F	₹W	10GB
9.50GB SVM1 9.49GB SVM2	5% SVM1_data_ 5% SVM2_root	_vol node_A_	onl onl _ldata01_m onl	ine F irrored ine F		
9.50GB SVM1 9.49GB SVM2 9.49GB	5% SVM1_data_ 5%	_vol node_A_	onl _ldata01_m onl _ldata01_m	ine F irrored ine F	₹W	10GB
9.50GB SVM1 9.49GB SVM2 9.49GB	5% SVM1_data_ 5% SVM2_root	_vol node_A_ node_A_	onl _ldata01_m onl _ldata01_m	ine F irrored ine F	₹W	10GB
9.50GB SVM1 9.49GB SVM2 9.49GB	5% SVM1_data_ 5% SVM2_root	_vol _node_A_ _vol	onl _ldata01_m onl _ldata01_m onl	ine F irrored ine F	₹W	10GB
9.50GB SVM1 9.49GB	5% SVM1_data_ 5% SVM2_root	_vol _node_A_ _vol	onl _ldata01_m onl _ldata01_m onl _2_data02_	ine F irrored ine F unmirrore	lW lW ∶d	10GB 10GB
9.50GB SVM1 9.49GB SVM2	5% SVM1_data_ 5% SVM2_root	_vol _node_A_ _vol	onl _ldata01_m onl _ldata01_m onl	ine F irrored ine F unmirrore	₹W	10GB

8. Physically power on the shelf.

Resynchronization starts automatically.

9. Verify that resynchronization has started: storage aggregate show

The affected aggregate should have a resyncing RAID status, as shown in the following example:

```
cluster A::> storage aggregate show
cluster Aggregates:
Aggregate Size Available Used% State #Vols Nodes
RAID Status
_____ _____
node A 1 data01_mirrored
       raid dp,
mirrored,
normal
node A 1 root
707.7GB 34.29GB 95% online 1 node_A_1
raid dp,
mirrored,
normal
node A 2 data01 mirrored
4.15TB 4.12TB 1% online 2 node_A_2
raid dp,
resyncing
node A 2 data02 unmirrored
      2.18TB 2.18TB 0% online 1 node_A_2
raid dp,
normal
node_A_2_root
      707.7GB 34.27GB 95% online 1 node A 2
raid dp,
resyncing
```

10. Monitor the aggregate to confirm that resynchronization is complete: storage aggregate show

The affected aggregate should have a normal RAID status, as shown in the following example:

```
cluster A::> storage aggregate show
cluster Aggregates:
Aggregate Size Available Used% State #Vols Nodes
RAID Status
_____
node A 1data01 mirrored
    raid_dp,
mirrored,
normal
node A 1root
    707.7GB 34.29GB 95% online 1 node_A_1
raid dp,
mirrored,
normal
node A_2_data01_mirrored
  4.15TB 4.12TB 1% online 2 node_A_2
raid dp,
normal
node A 2 data02 unmirrored
      raid_dp,
normal
node A 2 root
      707.7GB 34.27GB 95% online 1 node A 2
raid_dp,
resyncing
```

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.