
#### CS 61C:

# Great Ideas in Computer Architecture More MIPS, MIPS Functions

#### Instructors:

John Wawrzynek & Vladimir Stojanovic http://inst.eecs.Berkeley.edu/~cs61c/fa15


# Levels of Representation/Interpretation



```
temp = v[k];
v[k] = v[k+1];
v[k+1] = temp;
```

| lw | \$t0, 0(\$2) | Anything can be represented |
|----|--------------|-----------------------------|
| lw | \$t1, 4(\$2) | as a <i>number</i> ,        |
|    | \$t1, 0(\$2) | i.e., data or instructions  |
| SW | \$t0, 4(\$2) | i.e., data or ilistructions |


```
0000 1001 1100 0110 1010 1111 0101 1000 1010 1111 0101 1000 0000 1001 1100 0110 1100 0110 1100 0110 1001 1000 0000 1001 0101 1000 0000 1001 1100 0101 1010 1111
```




#### From last lecture ...

- Computer "words" and "vocabulary" are called instructions and instruction set respectively
- MIPS is example RISC instruction set used in CS61C
- Rigid format: 1 operation, 2 source operands, 1 destination
  - add, sub, mul, div, and, or, sll, srl, sra
  - lw,sw,lb,sb to move data to/from registers from/to memory
  - beq, bne, j, slt, slti for decision/flow control
- Simple mappings from arithmetic expressions, array access, in C to MIPS instructions

#### Review: Components of a Computer




# **How Program is Stored**




#### Assembler to Machine Code

(more later in course)



### **Executing a Program**



- The PC (program counter) is internal register inside processor holding <u>byte</u> address of next instruction to be executed.
- Instruction is fetched from memory, then control unit executes instruction using datapath and memory system, and updates program counter (default is add +4 bytes to PC, to move to next sequential instruction)

# Review if-else Statement

Assuming translations below, compile

```
f \rightarrow \$s0 \quad g \rightarrow \$s1 \quad h \rightarrow \$s2
  i \rightarrow \$s3 \quad j \rightarrow \$s4
if (i == j)
                              bne $s3,$s4,Else
  f = q + h;
                              add $s0,$s1,$s2
else
                              j Exit
  f = q - h; Else: sub $s0,$s1,$s2
                     Exit:
```

## Control-flow Graphs: A visualization

```
bne $s3,$s4,Else
                                     bne $s3, $s4, Else
      add $s0,$s1,$s2
        Exit
Else:sub $s0,$s1,$s2
                                     add $s0, $s1, $s2
Exit:
                                           j Exit
                                  Else: sub $s0, $s1, $s2
                                          Exit: ...
```

#### Clickers/Peer Instruction

```
addi $s0,$zero,0
Start: slt $t0,$s0,$s1
        beq $t0,$zero,Exit
        sll $t1,$s0,2
        addu $t1,$t1,$s5
       lw $t1,0($t1)
                               What is the code above?
        add $s4,$s4,$t1
        addi $s0,$s0,1
                               A: while loop
        j Start
                               B: do ... while loop
Exit:
                               C: for loop
                               D: A or C
                               E: Not a loop
```

#### Administrivia

- Fill-out the form to link bitbucket and edX accounts
  - Look-out for post on Piazza
- Advertising Guerrilla sections again
  - Tuesdays and Saturdays every two weeks
- CE applications approved for all students

#### CS61C In the News



- MIPS Creator CI20 dev board now available
  - A lot like Raspberry Pi but with MIPS CPU
  - Supports Linux and Android

1.2GHz 32-bit MIPS with integrated graphics

http://liliputing.com/2015/01/mips-creator-ci20-dev-board-now-available-for-65.html

# CS61C In the News pt. 2

#### **RISC-V ANGEL:**

- Try RISC-V in a browser
- http://riscv.org/angel/

# Six Fundamental Steps in Calling a Function


- 1. Put parameters in a place where function can access them
- 2. Transfer control to function
- 3. Acquire (local) storage resources needed for function
- 4. Perform desired task of the function
- Put result value in a place where calling code can access it and restore any registers you used
- 6. Return control to point of origin, since a function can be called from several points in a program

#### MIPS Function Call Conventions

- Registers faster than memory, so use them
- \$a0-\$a3: four argument registers to pass parameters (\$4 - \$7)
- \$v0,\$v1: two value registers to return values (\$2,\$3)
- \$ra: one *return address* register to return to the point of origin (\$31)

### Instruction Support for Functions (1/4)

```
... sum(a,b);... /* a,b:$s0,$s1 */
}
c int sum(int x, int y) {
  return x+y;
 }
```



In MIPS, all instructions are 4 bytes, and stored in memory just like data. So here we show the addresses of where the programs are stored.

#### Instruction Support for Functions (2/4)

```
... sum(a,b);... /* a,b:$s0,$s1 */
c int sum(int x, int y) {
   return x+y;
   address (shown in decimal)
    1000 add $a0,$s0,$zero # x = a
   1004 add $a1,$s1,$zero # y = b
   1008 addi $ra,$zero,1016 #$ra=1016
   1012 j sum
                  #jump to sum
   1016 ...
                        # next instruction
    2000 sum: add $v0,$a0,$a1
   2004 jr $ra # new instr. "jump register"
```

#### Instruction Support for Functions (3/4)

```
... sum(a,b);... /* a,b:$s0,$s1 */
}
int sum(int x, int y) {
  return x+y;
}
```

- Question: Why use jr here? Why not use j?
- Answer: sum might be called by many places, so we can't return to a fixed place. The calling proc to sum must be able to say "return here" somehow.

```
2000 sum: add $v0,$a0,$a1
2004 jr $ra # new instr. "jump register"
```

### Instruction Support for Functions (4/4)

 Single instruction to jump and save return address: jump and link (jal)

#### Before:

```
1008 addi $ra,$zero,1016 #$ra=1016
1012 j sum #goto sum
```

• After:

```
1008 jal sum # $ra=1012,goto sum
```

- Why have a jal?
  - Make the common case fast: function calls very common.
  - Don't have to know where code is in memory with jal!

#### MIPS Function Call Instructions

- Invoke function: jump and link instruction (jal)
   (really should be laj "link and jump")
  - "link" means form an address or link that points to calling site to allow function to return to proper address
  - Jumps to address and simultaneously saves the address of the <u>following</u> instruction in register \$ra

```
jal FunctionLabel
```

- Return from function: jump register instruction (jr)
  - Unconditional jump to address specified in register

#### **Notes on Functions**

- Calling program (caller) puts parameters into registers \$a0-\$a3 and uses jal X to invoke (callee) at address labeled X
- Must have register in computer with address of currently executing instruction
  - Instead of Instruction Address Register (better name),
     historically called Program Counter (PC)
  - It's a program's counter; it doesn't count programs!
- What value does jal X place into \$ra? ????
- jr \$ra puts address inside \$ra back into PC

# Where Are Old Register Values Saved to Restore Them After Function Call?

- Need a place to save old values before call function, restore them when return, and delete
- Ideal is stack: last-in-first-out queue (e.g., stack of plates)
  - Push: placing data onto stack
  - Pop: removing data from stack
- Stack in memory, so need register to point to it
- \$sp is the stack pointer in MIPS (\$29)
- Convention is grow from high to low addresses
  - Push decrements \$sp, Pop increments \$sp


## Example

```
int Leaf
  (int g, int h, int i, int j)
{
  int f;
  f = (g + h) - (i + j);
  return f;
}
```

- Parameter variables g, h, i, and j in argument registers \$a0, \$a1, \$a2, and \$a3, and f in \$s0
- Assume need one temporary register \$t0

### Stack Before, During, After Function

Need to save old values of \$s0 and \$t0



24

# MIPS Code for Leaf()

```
Leaf: addi $sp,$sp,-8 # adjust stack for 2 items
       sw $t0, 4($sp) # save $t0 for use afterwards
        sw $s0, 0($sp) # save $s0 for use afterwards
       add $s0,$a0,$a1 # f = g + h
       add $t0,$a2,$a3 # t0 = i + j
        sub $v0,$s0,$t0 # return value (g + h) - (i + j)
       lw $s0, 0($sp) # restore register $s0 for caller
       lw $t0, 4($sp) # restore register $t0 for caller
       addi $sp,$sp,8 # adjust stack to delete 2 items
       jr $ra # jump back to calling routine
```

# What If a Function Calls a Function? Recursive Function Calls?

- Would clobber values in \$a0 to \$a3 and \$ra
- What is the solution?

### Nested Procedures (1/2)

```
int sumSquare(int x, int y) {
  return mult(x,x)+ y;
}
```

- Something called sumSquare, now sumSquare is calling mult
- So there's a value in \$ra that sumSquare
  wants to jump back to, but this will be
  overwritten by the call to mult

Need to save **sumSquare** return address before call to **mult** 

### Nested Procedures (2/2)

- In general, may need to save some other info in addition to \$ra.
- When a C program is run, there are 3 important memory areas allocated:
  - Static: Variables declared once per program, cease to exist only after execution completes - e.g., C globals
  - Heap: Variables declared dynamically via malloc
  - Stack: Space to be used by procedure during execution; this is where we can save register values

## **Optimized Function Convention**

To reduce expensive loads and stores from spilling and restoring registers, MIPS divides registers into two categories:

#### 1. Preserved across function call

- Caller can rely on values being unchanged
- \$ra, \$sp, \$gp, \$fp, "saved registers" \$s0-\$s7

#### 2. Not preserved across function call

- Caller cannot rely on values being unchanged
- Return value registers \$v0,\$v1, Argument registers \$a0-\$a3, "temporary registers" \$t0-\$t9

# Clickers/Peer Instruction

Which statement is FALSE?

A: MIPS uses jal to invoke a function and jr to return from a function

B: jal saves PC+1 in \$ra

C: The callee can use temporary registers (\$ti) without saving and restoring them


D: The caller can rely on save registers (\$si) without fear of callee changing them

# Allocating Space on Stack

- C has two storage classes: automatic and static
  - Automatic variables are local to function and discarded when function exits
  - Static variables exist across exits from and entries to procedures
- Use stack for automatic (local) variables that don't fit in registers
- Procedure frame or activation record: segment of stack with saved registers and local variables
- Some MIPS compilers use a frame pointer (\$fp) to point to first word of frame

# Stack Before, During, After Call

#### High address



Low address a. b. c.

### Using the Stack (1/2)

- So we have a register \$sp which always points to the last used space in the stack.
- To use stack, we decrement this pointer by the amount of space we need and then fill it with info.
- So, how do we compile this?
   int sumSquare(int x, int y) {
   return mult(x,x)+ y;
   }

## Using the Stack (2/2)

```
    Hand-compile int sumSquare(int x, int y) {

                  return mult(x,x) + y; }
sumSquare:
       addi $sp,$sp,-8 # space on stack
       sw $ra, 4($sp) # save ret addr
"push" sw $a1, 0($sp) # save y
       add $a1,$a0,$zero # mult(x,x)
                   # call mult
       jal mult
       lw $a1, 0($sp) # restore y
       add $v0,$v0,$a1 # mult()+y
       lw $ra, 4($sp) # get ret addr
       addi $sp,$sp,8 # restore stack
       jr $ra
mult:
```

#### Basic Structure of a Function

#### **Prologue**

```
entry_label:
addi $sp,$sp, -framesize
sw $ra, framesize-4($sp) # save $ra
save other regs if need be

Body... (call other functions...)
```


#### **Epilogue**

```
restore other regs if need be
lw $ra, framesize-4($sp) # restore $ra
addi $sp,$sp, framesize
jr $ra
```

## Where is the Stack in Memory?

- MIPS convention
- Stack starts in high memory and grows down
  - Hexadecimal (base 16): 7fff fffc<sub>hex</sub>
- MIPS programs (text segment) in low end
  - $-00400000_{hex}$
- static data segment (constants and other static variables) above text for static variables
  - MIPS convention global pointer (\$gp) points to static
- Heap above static for data structures that grow and shrink; grows up to high addresses

# MIPS Memory Allocation



# Register Allocation and Numbering

| Name               | Register number | Usage  | Preserved on call? |
|--------------------|-----------------|--|--------------------|
| \$zero             | 0               | The constant value 0                         | n.a.               |
| \$v0-\$v1          | 2-3             | Values for results and expression evaluation | no                 |
| \$a0-\$a3          | 4-7             | Arguments                                    | no                 |
| \$t0-\$t7          | 8-15            | Temporaries                                  | no                 |
| \$s0 <b>-</b> \$s7 | 16-23           | Saved  | yes                |
| \$t8_\$t9          | 24-25           | More temporaries                             | no                 |
| \$gp               | 28              | Global pointer                               | yes                |
| \$sp               | 29              | Stack pointer                                | yes                |
| \$fp               | 30              | Frame pointer                                | yes                |
| \$ra               | 31              | Return address                               | yes                |

#### And in Conclusion...

- Functions called with jal, return with jr \$ra.
- The stack is your friend: Use it to save anything you need. Just leave it the way you found it!
- Instructions we know so far...

```
Arithmetic: add, addi, sub, addu, addiu, subu
Memory: lw, sw, lb, sb
Decision: beq, bne, slt, slti, sltiu
Unconditional Branches (Jumps): j, jal, jr
```

- Registers we know so far
  - All of them!
  - \$a0-\$a3 for function arguments, \$v0-\$v1 for return values
  - \$sp, stack pointer, \$fp frame pointer, \$ra return address

# **Bonus Slides**

#### Recursive Function Factorial

```
int fact (int n)
{
   if (n < 1) return (1);
    else return (n * fact(n-1));
}</pre>
```

#### Recursive Function Factorial

```
L1:
Fact:
  # adjust stack for 2 items
                                 \# Else part (n >= 1)
  addi $sp,$sp,-8
                                 \# arg. gets (n - 1)
  # save return address
                                 addi $a0,$a0,-1
                                 \# call fact with (n - 1)
  sw $ra, 4($sp)
  # save argument n
                                jal Fact
                                 # return from jal: restore n
  sw $a0, 0($sp)
  \# test for n < 1
                                 lw $a0, 0($sp)
                                 # restore return address
  slti $t0,$a0,1
  \# if n >= 1, go to L1
                                 lw $ra, 4($sp)
                                 # adjust sp to pop 2 items
  beg $t0,$zero,L1
                                 addi $sp, $sp,8
  # Then part (n==1) return 1
                                 \# return n * fact (n - 1)
  addi $v0,$zero,1
                                mul $v0,$a0,$v0
  # pop 2 items off stack
                                 # return to the caller
  addi $sp,$sp,8
  # return to caller
                                 jr $ra
  jr $ra
```

mul is a pseudo instruction