Package 'traudem'

April 24, 2024

```
Title Use TauDEM
Version 1.0.3
Description Simple trustworthy utility functions to use TauDEM
      (Terrain Analysis Using Digital Elevation Models <a href="https:">https:</a>
      //hydrology.usu.edu/taudem/taudem5/>) command-line interface.
      This package provides a guide to installation of TauDEM and its dependencies GDAL (Geopa-
      tial Data Abstraction Library)
      and MPI (Message Passing Interface) for different operating systems.
      Moreover, it checks that TauDEM and its dependencies are correctly installed and in-
      cluded to the PATH,
      and it provides wrapper commands for calling TauDEM methods from R.
License MIT + file LICENSE
URL https://lucarraro.github.io/traudem/,
      https://github.com/lucarraro/traudem
BugReports https://github.com/lucarraro/traudem/issues
Imports cli, purrr, rlang, sys, tools, withr
Suggests knitr, rmarkdown, testthat (>= 3.0.0), terra, shapefiles, sf,
      elevatr, fs
VignetteBuilder knitr
Config/testthat/edition 3
Config/Needs/website usethis
Encoding UTF-8
RoxygenNote 7.3.1
NeedsCompilation no
Author Luca Carraro [cre, aut],
      University of Zurich [cph, fnd],
      Maëlle Salmon [aut] (<a href="https://orcid.org/0000-0002-2815-0399">https://orcid.org/0000-0002-2815-0399</a>),
      Wael Sadek [aut],
      Kirill Müller [aut] (<a href="https://orcid.org/0000-0002-1416-3412">https://orcid.org/0000-0002-1416-3412</a>)
Maintainer Luca Carraro < Luca. Carraro@eawag.ch>
Repository CRAN
Date/Publication 2024-04-24 16:20:02 UTC
```

2 taudem_aread8

R topics documented:

taudem_aread8	2
taudem_d8flowdir	3
taudem_exec	4
taudem_moveoutletstostream	5
taudem_pitremove	7
taudem_sitrep	8
taudem_threshold	9

Index 11

taudem_aread8

D8 Contributing Area

Description

D8 Contributing Area

Usage

```
taudem_aread8(
  input_d8flowdir_grid,
  output_contributing_area_grid = NULL,
  check_edge_contamination = TRUE,
  n_processes = getOption("traudem.n_processes", 1),
  wg_file = NULL,
  outlet_file = NULL,
  outlet_layer_name = NULL,
  outlet_layer_number = NULL,
  quiet = getOption("traudem.quiet", FALSE)
)
```

Arguments

```
input_d8flowdir_grid
```

Input flow directions grid.

output_contributing_area_grid

Output contributing area grid.

 ${\tt check_edge_contamination}$

Whether to check for edge contamination.

n_processes Number of processes for mpiexec. If NULL TauDEM is called without mpiexec.

wg_file Input weight grid (optional).

outlet_layer_name

OGR layer name if outlets are not the first layer in outlet_file (optional). Layer name and layer number should not both be specified.

taudem_d8flowdir 3

```
outlet_layer_number
```

OGR layer number if outlets are not the first layer in outlet_file (optional). Layer name and layer number should not both be specified.

quiet

If FALSE output from TauDEM CLI is suppressed.

Details

See https://hydrology.usu.edu/taudem/taudem5/help53/D8ContributingArea.html

Value

Path to output file (invisibly).

Examples

```
test_dir <- withr::local_tempdir()
dir.create(test_dir)
file.copy(
    system.file("test-data", "DEM.tif", package = "traudem"),
    file.path(test_dir, "DEM.tif")
)

filled_pit <- taudem_pitremove(file.path(test_dir, "DEM.tif"))
outputs <- taudem_d8flowdir(filled_pit)
outputs
contributing_area_grid <- taudem_aread8(outputs$output_d8flowdir_grid)
contributing_area_grid</pre>
```

taudem_d8flowdir

D8 Flow Directions

Description

D8 Flow Directions

Usage

```
taudem_d8flowdir(
  input_elevation_grid,
  output_d8flowdir_grid = NULL,
  output_d8slopes_grid = NULL,
  n_processes = getOption("traudem.n_processes", 1),
  quiet = getOption("traudem.quiet", FALSE)
)
```

4 taudem_exec

Arguments

Details

See https://hydrology.usu.edu/taudem/taudem5/help53/D8FlowDirections.html

Value

List with the two output filenames.

Examples

```
test_dir <- withr::local_tempdir()
dir.create(test_dir)
  file.copy(
    system.file("test-data", "DEM.tif", package = "traudem"),
    file.path(test_dir, "DEM.tif")
)
filled_pit <- taudem_pitremove(file.path(test_dir, "DEM.tif"))
outputs <- taudem_d8flowdir(filled_pit)
outputs</pre>
```

taudem_exec

Call TauDEM

Description

Call TauDEM

Usage

```
taudem_exec(
  program,
  args,
  ...,
  n_processes = getOption("traudem.n_processes", 1),
  quiet = getOption("traudem.quiet", FALSE)
)
```

Arguments

program	TauDEM command (character). See examples.
args	Character vector of arguments. See examples.
	These dots are for future extensions and must be empty. As a consequence, all following arguments must be fully named (see examples).
n_processes	Number of processes for mpiexec. If NULL TauDEM is called without mpiexec.
quiet	If FALSE output from TauDEM CLI is suppressed.

Details

You can use this function to call more TauDEM methods than the ones with dedicated wrappers in this package. Please refer to the relative TauDEM function documentation for the syntax used to specify optional arguments. See also examples.

Value

TRUE if the call was successful, FALSE otherwise.

Examples

```
test_dir <- withr::local_tempdir()
dir.create(test_dir)
file.copy(
    system.file("test-data", "DEM.tif", package = "traudem"),
    file.path(test_dir, "DEM.tif")
)
# Default name for output file, only input command and input filename.
taudem_exec("pitremove", file.path(test_dir, "DEM.tif"))

# syntax for user-attributed output file name
taudem_exec(
    "pitremove",
    c(
        "-z", file.path(test_dir, "DEM.tif"),
        "-fel", file.path(test_dir, "filled_pits.tif")
)
)</pre>
```

taudem_moveoutletstostream

Move Outlets To Streams

Description

Move Outlets To Streams

Usage

```
taudem_moveoutletstostream(
  input_d8flowdir_grid,
  input_stream_raster_grid,
  output_moved_outlets_file = NULL,
  om_layer_name = NULL,
  max_dist = NULL,
  outlet_file,
  outlet_layer_name = NULL,
  outlet_layer_number = NULL,
  n_processes = getOption("traudem.n_processes", 1),
  quiet = getOption("traudem.quiet", FALSE)
)
```

Arguments

```
input_d8flowdir_grid
                 File name for D8 flow direction grid (input).
input_stream_raster_grid
                 File name for stream raster grid (input).
output_moved_outlets_file
                  Output OGR file where outlets have been moved.
om_layer_name
                 layer name in movedoutletsfile (optional).
max_dist
                  maximum number of grid cells to traverse in moving outlet points (optional).
outlet_file
                  input outlets file (OGR readable dataset).
outlet_layer_name
                  OGR layer name if outlets are not the first layer in outlet_file (optional).
                 Layer name and layer number should not both be specified.
outlet_layer_number
                  OGR layer number if outlets are not the first layer in outlet_file (optional).
                 Layer name and layer number should not both be specified.
n_processes
                 Number of processes for mpiexec. If NULL TauDEM is called without mpiexec.
                 If FALSE output from TauDEM CLI is suppressed.
quiet
```

Details

See https://hydrology.usu.edu/taudem/taudem5/help53/MoveOutletsToStreams.html

Value

Path to output file (invisibly).

taudem_pitremove 7

taudem_pitremove

Pit Remove

Description

Pit Remove

Usage

```
taudem_pitremove(
  input_elevation_grid,
  output_elevation_grid = NULL,
  only_4way_neighbors = FALSE,
  n_processes = getOption("traudem.n_processes", 1),
  depmask = NULL,
  quiet = getOption("traudem.quiet", FALSE)
)
```

Arguments

Whether to consider only 4 way neighbors.

depmask Depression mask file (optional).

quiet If FALSE output from TauDEM CLI is suppressed.

Details

See https://hydrology.usu.edu/taudem/taudem5/help53/PitRemove.html

Value

Path to output file (invisibly).

Examples

```
test_dir <- withr::local_tempdir()
dir.create(test_dir)
file.copy(
   system.file("test-data", "DEM.tif", package = "traudem"),
   file.path(test_dir, "DEM.tif")
)</pre>
```

8 taudem_sitrep

```
output <- taudem_pitremove(file.path(test_dir, "DEM.tif"))
output</pre>
```

taudem_sitrep

TauDEM situation report

Description

Checks installation of TauDEM and provides useful hints.

Usage

```
taudem_sitrep()
can_register_taudem()
```

Value

```
For taudem_sitrep(): None.
For can_register_taudem(): A logical scalar.
```

TauDEM installation and registration

Once you have installed TauDEM, add an environment variable pointing to the correct path. For instance on Ubuntu it could be adding this line in .Renviron (see usethis::edit_r_environ()) and then re-starting R:

```
TAUDEM_PATH='/usr/local/taudem'
or, for just the session, running this line of R code:
Sys.setenv(TAUDEM_PATH = "/usr/local/taudem")
```

Examples

```
try(taudem_sitrep(), silent = TRUE)
can_register_taudem()
```

taudem_threshold 9

taudem_threshold

Stream Definition By Threshold

Description

Stream Definition By Threshold

Usage

```
taudem_threshold(
  input_area_grid,
  output_stream_raster_grid = NULL,
  mask_file = NULL,
  threshold_parameter = 100,
  n_processes = getOption("traudem.n_processes", 1),
  quiet = getOption("traudem.quiet", FALSE)
)
```

Arguments

```
input_area_grid
```

File name for grid to be thresholded.

 $\verb"output_stream_raster_grid"$

File name for stream raster grid.

mask_file File name for grid used to mask

File name for grid used to mask the output stream raster, or general thresholded grid.

threshold_parameter

Threshold parameter.

n_processes Number of processes for mpiexec. If NULL TauDEM is called without mpiexec.

quiet If FALSE output from TauDEM CLI is suppressed.

Details

See https://hydrology.usu.edu/taudem/taudem5/help53/StreamDefinitionByThreshold.html

Value

Path to output file (invisibly).

Examples

```
test_dir <- withr::local_tempdir()
dir.create(test_dir)
file.copy(
    system.file("test-data", "DEM.tif", package = "traudem"),</pre>
```

10 taudem_threshold

```
file.path(test_dir, "DEM.tif")
)
filled_pit <- taudem_pitremove(file.path(test_dir, "DEM.tif"))
outputs <- taudem_d8flowdir(filled_pit)
outputs
contributing_area_grid <- taudem_aread8(outputs$output_d8flowdir_grid)
contributing_area_grid
thresholded <- taudem_threshold(contributing_area_grid)
thresholded</pre>
```

Index

```
can_register_taudem (taudem_sitrep), 8
taudem_aread8, 2
taudem_d8flowdir, 3
taudem_exec, 4
taudem_moveoutletstostream, 5
taudem_pitremove, 7
taudem_sitrep, 8
taudem_threshold, 9
```