

Vantage / Legrand vantagecontrols.com



# **Vantage InFusion Crestron Programming**

InFusion Keypad module

Files Used	
Infusion Keypad v1.1 (AVPA).umc Infusion Keypad v1.1 (AVPA).ush Infusion Keypad v1.1 (AVPA).usp	

Version History				
Version	Date	Notes		
1.0	03/05/08	Initial Release		
1.1	03/31/10	Added up to 96 VID's per instance, added "best practices" section		

#### **IMPORTANT NOTE**

Before using this module it is necessary for you to have read and understand the main document regarding Crestron integration with Vantage (Refer to document with the InFusion Processor module).

The following inputs must be set high (1) on the InFusion Processor module: status\_LED

This module allows the Crestron programmer to replicate the operation of a Vantage keypad with its features such as colored LED's and blinking status\*. There are settings/parameters to be filled prior to operation, make sure these values match the parameters found in Vantage program (Design Center software). This module uses "BTNPRESS" and "BTNRELEASE" logic and it can be used even if the programmer desires to implement only a single button. It was developed in a group of 96 buttons per module and the programmer is encouraged to insert buttons from several keypads into a single module. The decision to add that many VID buttons in one module derived from tests in the real world environment. Crestron systems responded faster when all the VID parameters were grouped into one instance of the module. The programmer still has the flexibility to create additional instances if more than 96 buttons are required. It is important to note that the number of modules should be kept to a minimum, in other words, the programmer should fit all the buttons on a project in very few keypad modules (preferably not more than a couple).

## 1.0 – Modes of operation

This module was developed to meet the requirements of both advanced and simple integrations. In a simple integration scenario, the buttons on Crestron side have only HIGH (on) and a LOW (off) states, therefore indicating if a keypad LED is illuminated or not. This means that on the Crestron VT Pro project the button will have only an Inactive and an Active State; this is the most basic functionality of a button in VT Pro. The button will also blink between HIGH and LOW if the LED on Vantage does so and there is an oscillator symbol attached to this module in SIMPL Windows (note that if the blinking feedback is used it will incur more load into the processor).

A more advanced integration will also replicate different LED colors in a Crestron touch panel just as they change colors in a Vantage Keypad. This feature will require the Crestron programmer to add multiple modes on a button in VT Pro. The use of this feature adds considerable load to the processor and should be used only for a few buttons.

### 1.1 – Design Center and Vision Tools Pro-e


To exemplify an advanced environment which has keypads with multiple LED colors, let's suppose that an LED style has 3 colors:

<u>First:</u> RED – The LED will be RED to indicate that a light is OFF and to facilitate the location of this button in the dark.

<u>Second:</u> GREEN – To indicate that the light is ON.

<u>Third:</u> BLINKING YELLOW – To indicate a specific state, such as if the user performs a press and hold, the program initiates a timer that will turn off the light after 5 min. During this time the LED will be blinking yellow to show the user that the 5 minutes have not been elapsed.

This is how the **Vantage Design Center** software would look:




If you are not familiar with the Design Center software simply ask your Vantage programmer to provide you with the information on how many states and what colors are being used. You will need to replicate these color settings on VTPro-e environment.


NOTE TO VANTAGE PROGRAMMERS: when creating LED styles use only Mode1 and create as many states which are needed (First, Second, Third and so on...). The practice of using Mode2, Mode3 and etc., is not recommended.

In VTPro-e on Button Properties window, add as many modes as the number of LED states, in our case we need 3 modes and they are 0, 1 and 2, each with the desired face color of our example from Design Center (see next figure for a better understanding). IMPORTANT NOTE: In this type of integration the Inactive Button modes will correspond to the solid (non-blinking) states of the LED's and the Active Button modes correspond to the OFF BLINK COLOR.

The following figure shows the VTPro-e Button Properties window with the different modes for the <u>inactive</u> state. Note the different Face Colors applied to each state, these correspond to the Design Center colors.




Now configure the <u>Active State</u> of the button (this corresponds to the <u>Off Blink State</u> of Design Center):



Since the RED and GREEN states will not have a blinking function in our scenario, the modes 0 and 1 will be irrelevant to this example, but the mode 2 will be the OFF BLINK COLOR of the YELLOW state. In this case a simple black or a dark grey to give the user an impression of an OFF LED.

#### 1.2 - SIMPL Windows

In the Keypad module a programmer can enable or disable the advanced LED COLOR functionality. This can be done by setting the signal "Button\_Colored\_LED" to 1(high) or 0 (low) for each button. Most likely the majority of installations will not require multiple colors for LED's and this signal can be set to LOW in all buttons and the VT Pro-e button can be set as described in the first paragraph of section 1.0 of this manual. The following figure shows the appearance of the Keypad Module in SIMPL Windows:



# 1.3 – Signals and parameters

Inputs		
Button1 through Button96	Digital	These are the button press signals typically coming from a touch panel. They are essentially the equivalent of a button press in a Vantage keypad. Try to fill up all 96 buttons before creating another instance of the same module. This makes the processing faster.
Button1_Colored_LED Through Button96_Colored_LED	Digital	Set this to 1(high) if multiple colors for LED's are being used. Set to 0 or "//" (low) if colors are not relevant (the VT Pro-e buttons will only change from Active to Inactive States to indicate if an LED is on or off – most common usage). It is important to note that if multiple LED colors are being used, the procedure to create buttons on VT Pro-e is different (read Modes of Operation, section 2.2 of this manual). Also the use of multicolor LED is heavier on the processor and should be kept to a few buttons only.
Blink_OSC _fast Blink_OSC _medium Blink_OSC _slow Blink_OSC _veryslow	Digital	These signals should be connected to oscillator outputs within SIMPL Windows. These oscillators will determine the pace at which LED's will blink. The default values are used in the example program. A total of four oscillators can be used to drive all keypad modules in a project. NOTE: if there is no intent of reproducing blinking LED's in the Crestron panel, simply comment out these signals or set them to 0 (LOW). This is also faster to be processed. When blinking is not used, a blinking LED in a Vantage keypad will be considered as ON or HIGH STATE in the Crestron side.
Query_Keypad	Digital	Pulse it to query the status of all LED's on the keypad. This is useful for synchronizing the status of all the LED after a crestron system reboot for example.
Vantage_rx\$	Serial	Signal coming from the main Infusion Processor Module (refer to Vantage_InFusion_Modules_Main.pdf)

Outputs		
Button1_FB through Button96_FB	Digital	These are the LED Feedback signals. If the option to use multi-color LED's is NOT being used, the HIGH and LOW of these signals will represent if the LED is either ON or OFF. If the option to use color LED's is ACTIVE, the HIGH and LOW states of these signals will represent the solid and "off blinking" states of an LED (refer to Modes of Operation, item 2.2 of this manual).
Button1_State_FB through	Analog	These signals are only used when the option to use multi-color LED's is ACTIVE. They can be commented out if use of multi-color LED's is
Button96_State_FB		DISABLED. When using multiple LED colors, this analog signal carries the button mode information (as set in VT Pro, button modes).

Parameters				
VID numbers	Parameter	These are 32 bit numbers that identify each item of a Vantage system. Ask your Vantage programmer to obtain that information. If there are fewer than 96 buttons in a project, the unused VID's should be left as "0" since this will make the program run faster.		

### 1.4 – Best practices and recommendations

This module provides the ability to reproduce some advanced Vantage features on the Crestron side such as colored LED's, blinking rates, etc. Keep in mind that these features add an extra load on the processor and it will slow processing down in busy environments.

It is desirable to use this module as a simple scheme with only basic features such as ON/OFF state. Multiple LED colors and blinking rates will slow down the processor if used in too many buttons.

This module is recommended when the replication of an actual existing keypad is desired. Please check with your Vantage programmer if the use of tasks will get the same results. In this case make use of the task module, which can reduce the amount of the overall traffic by setting status LED and status BTN to 0 on the main processor module.