COMPUTER ARCHITECTURE


Chapter 2: Instruction set architecture - ISA





Languages of Computer? Why?

- Q: Why do we need to learn the language of computers?
- A: To command a computer's hardware: speak its language





Source: http://media.apnarm.net.au/img/media/images/2013/08/14/computer language t620.jpg

Abstraction

We teach students how to use abstraction so that we can build really complex software systems.




John Hennessy ACM A.M. Turing Laureate





Instruction set architecture



MIPS32 Add Immediate Instruction

001000 00001		00010	0000000101011110	
OP Code	Addr 1	Addr 2	Immediate value	


Equivalent mnemonic:

addi \$r1, \$r2, 350




Von Neumann architecture

- Stored-program concept
- Instruction category:
 - Arithmetic
 - Data transfer
 - Logical
 - Conditional branch
 - Unconditional jump






Computer components





Instruction execution model



- Instruction fetch: from the memory
 - PC increased
 - PC stores address of the next instruction
- Execution: decode and execute



STANDARD MIPS INSTRUCTIONS



MIPS instruction set

- MIPS architecture
- MIPS Assembly Instruction
 ⇔ MIPS Machine Instruction
- Assembly:
 - add \$t0, \$s2, \$t0
- Machine:
 - 000000_10010_01000_01000_00000_100000
- Only one operation is performed per MIPS instruction
 - e.g., a + b + c needs at least two instructions



Instruction set design principle

- Simplicity favors regularity
- Smaller is faster
- Make the common case fast
- Good design demands good compromises



MIPS operands

- 1. Register: 32 32-bit registers (start with the \$ sign)
 - \$\$0-\$\$7: corresponding to variables (save)
 - \$†0-\$†9: storing temporary value
 - \$a0-\$a3
 - \$v0-\$v1
 - \$gp, \$fp, \$sp, \$ra, \$at, \$zero, \$k0-\$k1
- 2. Memory operand: 2^{30} memory words (4 byte each): accessed only by data transfer instructions
- 3. Short integer immediate: -10, 20, 2020,...

1st group: arithmetic instructions

Assembly instruction format:

Opcode	Destination	Source	Source
Opcode	register	register 1	register 2(*)

- Opcode:
 - add: DR = SR1 + SR2
 - sub: DR = SR1 SR2
 - addi: (*) SR2 is an <u>immediate</u> (e.g. 20), DR = SR1 + SR2
- Three register operands



Example

Question: what is MIPS code for the following C code


$$f = (g + h) - (i + j);$$

- If the variables g, h, i, j, and f are assigned to the register \$s0, \$s1, \$s2, \$s3, and \$s4, respectively.
- Answer:



2nd group: data transfer instructions

- Copy data b/w memory and registers in CPU
 - Register
 - Address: a value used to delineate the location of a specific data element within a memory array
- Load (I): copy data from memory to a register
- Store (s): copy data from a register to memory





Data transfer instructions

• Assembly instruction format:



- Opcode:
 - Size of data: 1 byte, 2 bytes (half of word), or 4 bytes (word)
 - Behaviors: load or store
- Register:
 - Load: destination
 - Store: source
- Memory operand: offset(base register)
 - offset: short integer number
 - Byte address: each address identifies an 8-bit byte
 - "words" are aligned in memory (address must be multiple of 4)



Memory operand

Question: given the following memory map, assume that \$\$50\$ stores value of
 8. Which is the memory operand used to access the byte storing value of 0x9A?

address:	8	9	10	11
	0x12	0x34	0x56	0x78
	0x9A	0xBC	0xDE	0xF0
address:	12	13	14	15

- Answer:
 - Address of the byte storing value of 0x9A is 12
 - If we use \$s0 as the base register, offset = 12 8 = 4
 - Memory operand: 4(\$s0)



Load instructions

- Remind: "load" means copying data from memory to a 32-bit register
- Instructions:
 - lw: load word
 - eg.: lw \$s0, 100(\$s1) #copy 4 bytes from memory to \$s0
 - Ih: load half sign extended
 - eg.: Ih \$s0, 100(\$s1) #copy 2 bytes to \$s0 and extend signed bit
 - Ihu: load half unsigned zero extended
 - Ib: load byte sign extended
 - lbu: load byte unsigned zero extended
 - Special case: lui load upper immediate
 - eg.: lui \$s0, 0x1234 #\$s0 = 0x12340000



Store instructions

- Remind: "store" means copying data from a register to memory
- Instructions:
 - sw: store word
 - eg.: sw \$s0, 100(\$s1) #copy 4 bytes in \$s0 to memory
 - sh: store half two least significant bytes
 - eg.: sh \$s0, 100(\$s1) #copy 2 bytes in \$s0 to memory
 - sb: store byte the least significant byte
 - eg.: sb \$s0, 100(\$s1) #copy 1 bytes in \$s0 to memory



Memory operands

- Main memory used for composite data
 - Arrays, structures, dynamic data
- To apply arithmetic operations
 - Load value(s) from memory into register(s)
 - Apply arithmetic operations to the register(s)
 - Store result from a register to memory (if required)
- MIPS is Big Endian
 - Most-significant byte at least address of a word
 - Little Endian: least-significant byte at least address



Example-1

C code:

$$g = h + A[8];$$

- -g in \$s1, h in \$s2, base address of A in \$s3
- Compiled MIPS code:
 - Index 8 requires offset of 32
 - 4 bytes per word



Example-2

C code:

$$A[12] = h + A[8];$$


- h in \$s2, base address of A in \$s3
- Compiled MIPS code:
 - Index 8 requires offset of 32

```
lw $t0, 32($s3) # load word
add $t0, $s2, $t0
sw $t0, 48($s3) # store word
```



Exercises

1. Given the following memory map, assume that the register \$ + 0 stores value 8 while \$ s 0 contains 0xCAFEFACE. Show the effects on memory and registers of following instructions:





Exercises

2. Convert the following C statements to equivalent MIPS assembly language if the variables f, g, and h are assigned to registers \$s0, \$s1, and \$s2 respectively. Assume that the base address of the array A and B are in registers \$s6 and \$s7, respectively.

a)
$$f = g + h + B[4]$$

b)
$$f = g - A[B[4]]$$



3rd group: logical instructions

- Instruction format: the same with arithmetic instructions
- Bitwise manipulation
 - Process operands bit by bit

Operation	C operator	MIPS opcode
Shift left	<<	sll
Shift right	>>	srl
Bitwise AND	&	and, andi
Bitwise OR		or, ori
Bitwise NOT	~	nor




Shift operations

- Shift left (sll)
 - Shift value in the first source to left and fill least significant positions with 0 bits
 - e.g., sll \$s0, \$s1, 4 # \$s0 = \$s1 << 4
 - Special case: **s**II by i bits multiplies by 2^i
- Shift right (srl)
 - Shift value in the first source to right and fill most significant positions with 0 bits
 - e.g., srl \$s0, \$s1, 4 # \$s0 = \$s1 >> 4
 - Special case: \mathbf{Srl} by i bits divides by 2^i (unsigned number only)



AND operation

Bitwise AND two source operands



- and: two source registers
 - e.g., and \$s0, \$s1, \$s2 #\$s0 = \$s1 & \$s2
- andi: the second source is a short integer number (16 bit)
 - 16 high-significant bits of the result are 0s
 - e.g., andi \$\$0, \$\$1, 100 #\$\$0 = {16'b0,\$\$1[15:0]&100}
- Useful to mask bits in a register
 - Select some bits and clear others to 0



OR operation

- Bitwise OR two source operands
 - or: two registers
 - e.g., or \$s0, \$s1, \$s2 # \$s0 = \$s1 | \$s2
 - ori: the second source is a short integer number (16 bit)
 - Copy 16 high-significant bit from the first source to destination
 - e.g., ori \$s0, \$s1, 100 # \$s0 = {\$s1[31:16],\$s1[15:0]|100}
- Useful to include bits in a word
 - Set some bits to 1, leave others unchanged



27

NOT operation

- Don't have a not instruction in MIPS ISA
 - 2-operand instruction
 - Useful to invert all bits in a register
- Can be done by the nor operator, 3-operand instruction
 - a NOR b = NOT (a OR b)
 - NOT a = NOT (a OR 0) = a NOR 0
 - e.g., nor \$\$0, \$\$0, \$zero
 - What else?



Example

- Question: assume that \$\$0\$ and \$\$1\$ are storing values 0x12345678 and
 0xCAFEFACE, respectively. What is value of \$\$2\$ after each following instructions
 - 1. sll \$s2, \$s0, 4
 - 2. and \$s2, \$s0, \$s1
 - 3. or \$s2, \$s0, \$s1
 - 4. andi \$\$2, \$\$0, 2020
- Answer:
 - 1.0x23456780
 - 2. 0x02345248
 - 3. OxDAFEFEFE
 - 4. 0x00000660



Exercise

 Find the value for \$†2 after each following sequence of instructions if the values for register \$†0 and \$†1 are

a)
$$$t0 = 0xAAAAAAAA, $t1 = 0x12345678$$

b) $$t0 = 0 \times F000D000D$, $$t1 = 0 \times 111111111$

Sequence 1:

sll \$t2, \$t0, 44 or \$t2, \$t2, \$t1

Sequence 2:

sll \$t2, \$t0, 4 andi \$t2, \$t2, -2


Sequence 3:

srl \$t2, \$t0, 3 andi \$t2, \$t2, 0xFFEF



4th group: conditional branch instructions

- Branch to a label if a condition is true; otherwise, continue sequentially
- Only <u>two</u> standard conditional branch instructions
 - beq \$rs, \$rt, L1 #branch if equal
 - If (rs == rt), go to L1
 - bne \$rs, \$rt, L1
 - If (rs != rt), go to L1
- Label: a given name
 - format: <label>: <instruction>



```
addi $t0, $zero, 0
addi $t1, $zero, 5
L1: addi $t0, $t0, 1
bne $t0, $t1, L1 #branch to L1
add $t0, $t1, $t0
```



5th group: unconditional jump instructions

- Immediately jump to a label
 - Without any condition checked
- Three standard unconditional jumps
 - j <label>
 - Jump to the label, e.g., L1
 - jal <label>
 - Jump to the label L1 and store address of the next instruction to the \$ra register
 - Used for function/procedure call
 - jr \$register
 - Jump to an instruction whose address is stored in the register
 - Used for returning to the caller function/procedure from a sub-function/procedure



32

Example

• Question: Compile the following C code into MIPS code (assume that f, g, h, i, and j are stored in registers from \$s0\$ to \$s4\$, respectively)

Answer:

Else: sub \$s0, \$s1, \$s2

Exit:

If: add \$s0, \$s1, \$s2

Exit:

- How can we compare less than or greater than?
 - e.g., if (a < b)



33

Exercise

Convert the following C code to MIPS. Assume that the base address of the save array is stored in \$\$s\$0 while i and k are stored in the registers \$\$s\$1 and \$\$s\$2, respectively

```
int save[];
int i, k;
...
i = 0;
while (save[i] == k)
  i += 1;
```



Set-on-less-than instruction

- Used for comparing less than or greater than
 - Results (destination registers) are always 0 (false) or 1 (true)
- slt \$rd, \$rs, \$rt
 - if (rs < rt) rd = 1; else rd = 0;
- slti \$rt, \$rs, immediate
 - if (rs < immediate) rt = 1; else rt = 0;
- sltu \$rd, \$rs, \$rt
 - Values are unsigned numbers
- sltui \$rt, \$rs, immediate
 - Values in registers & immediate are unsigned numbers



Example-1

Answer:

- \$\pmod 1 due to signed numbers comparison (\$\pmod 1 = -1)
- \$1 = 0 due to unsigned numbers comparison (\$1 = 4.294.967.295)



Example-2

• Question: Compile the following C code into MIPS code (assume that f, g, h, i, and j are stored in registers from \$s0 to \$s4, respectively)

Answer:

slt \$t0, \$s3, \$s4 beq \$t0, \$zero, Else add \$s0, \$s1, \$s2 j Exit

Else: sub \$s0, \$s1, \$s2

Exit:

slt \$t0, \$s3, \$s4 bne \$t0, \$zero, If sub \$s0, \$s1, \$s2 j Exit

If: add \$s0, \$s1, \$s2

Exit:



Exercise

- Convert the following C code to MIPS instructions
 - a) Sequence 1:

```
int a, b;
...
if (a >= 5) a = a + b;
else a = a - b;
```

b) Sequence 2:

```
int a, i;
for (i = 0, a = 0; i < 10; i++)
a++;
```



Branch instruction design

- Why not blt, bge, etc?
- Hardware for <, ≥, ... slower than =, ≠
 - Combining with branch involves more work per instruction, requiring a slower clock
 - All instructions penalized!
- beq and bne are the common case
- This is a good design compromise



Pseudo instructions

- Most assembler instructions represent machine instructions one-to-one
- Pseudo instructions (instructions in blue): figments of the assembler's imagination
 - Help programmer
 - Need to be converted into standard instructions
- For example
 - move \$t0, \$ $t1 \rightarrow add$ \$t0, \$zero, \$t1
 - blt \$t0, \$t1, L → slt \$at, \$t0, \$t1
 bne \$at, \$zero, L



40

PROCEDURE CALL



Procedure calling

- Caller vs. Callee
- Steps required to call a procedure
 - Place parameters in registers
 - Transfer control to procedure
 - Acquire storage for procedure
 - Perform procedure's operations
 - Place result in register for caller
 - Return to place of call

```
int main(){ // caller
...(1)
  fact(4);
  fact(1000);
int fact(int a){ //callee
```




Register usage


- \$a0 \$a3: arguments
- \$v0, \$v1: result values
- \$10 \$19: temporaries
 - Can be overwritten by callee
- \$50 \$57: saved
 - Must be saved/restored by callee

- **\$gp**: global pointer for static data
- \$sp: stack pointer
- **\$fp**: frame pointer
- \$ra: return address



Stack addressing model





Low address

Empty stack

Three elements stack

Empty stack



Procedure call instructions

Procedure call: jump and link

jal ProcedureLabel

- Address of following instruction put in \$ra
- Jumps to target address
- Procedure return: jump register

jr \$ra

- Copies \$ra to program counter
- Can also be used for computed jumps
 - e.g., for case/switch statements



Leaf procedure

- Leaf-procedure: will not call any sub-procedure or itself
 - No need to care any else, except saved registers
- C code:

```
int leaf_example (int g, h, i, j){
  int f;
  f = (g + h) - (i + j);
  return f;
}
```

- Arguments g, ..., j in \$a0, ..., \$a3
- f in \$s0 (hence, need to save \$s0 on stack)
- Result in \$v0



Main:

add sub

Leaf procedure - MIPS code

jal leaf_example

bne # addr => \$ra

leaf_example:	Label procedure name (used to call)
addi \$sp, \$sp, -4 sw \$s0, 0(\$sp)	Save \$s0 to the stack
add \$t0,\$a0,\$a1 add \$t1,\$a2,\$a3 sub \$s0,\$t0,\$t1	Procedure body
add \$v0,\$s0,\$zero	Result
lw \$s0,0(\$sp) addi \$sp,\$sp,4	Restore \$s0
jr \$ra	Return to caller



Non-leaf procedure

- Non-leaf procedure: will call at least an other procedure or itself
 - Need to care:
 - Return address (\$ra) (always!!!)
 - Caller call A (\$ra = caller: address of the instruction after jal A)
 - A call B (\$ra = A: address of the instruction after jal B)
 - Overwrite the value of \$ra
 - B return to A (\$ra = A)
 - Cannot return to Caller
 - Arguments transferred from Caller if needed (<u>sometimes!!!</u>)
 - Use the stack to backup



Non-leaf procedure - example

- Factorial calculation
- C code

```
int fact (int n){
  if (n < 1) return 1;
  else return n * fact(n - 1);
}</pre>
```

- Argument n in \$a0
- Result in \$v0



Non-leaf procedure - MIPS code

fact:

```
addi $sp, $sp, -8  # adjust stack for 2 items sw $ra, 4($sp)  # save return address sw $a0, 0($sp)  # save argument slti $t0, $a0, 1  # test for n < 1 beq $t0, $zero, L1 addi $v0, $zero, 1  # if so, result is 1 addi $sp, $sp, 8  # pop 2 items from stack jr $ra  # and return
```

No recursive call

- No change in \$a0 & \$ra
- No need to restore from stack

```
L1: addi $a0, $a0, -1 # else decrement n

jal fact # recursive call

lw $a0, 0($sp) # restore original n

lw $ra, 4($sp) # and return address

addi $sp, $sp, 8 # pop 2 items from stack

mul $v0, $a0, $v0 # multiply to get result

jr $ra # and return
```

Recursive call



Exercise

Write corresponding MIPS code for the following function

```
void strcpy (char x[], char y[]){
  int i;
  i = 0;
  while ((x[i]=y[i])!='\0')
    i += 1;
}
```

- Addresses of x, y in a0, a1
- -iin\$s0
- Ascii code of $\0$ is 0



MACHINE INSTRUCTIONS



Machine instructions

- Instructions are encoded in binary
 - Called machine code
- MIPS instructions
 - Encoded as 32-bit instruction words
 - Small number of formats encoding operation code (opcode), register numbers, ...
 - Regularity!
- Representing instructions:
 - Instruction format: R, I, and J
 - Opcode: predefined (check the reference card)
 - Operands:
 - Register numbers: predefined (check the reference card)
 - Immediate: integer to binary
 - Memory operands: offset + base register



Instruction formats

- MIPS machine instructions use one of three formats
 - R-format: encoding all-register-operands instructions and two shift instructions
 - add \$s0, \$s1, \$s2 # all operand are registers
 - sll \$s0, \$s1, 4 # shift instruction
 - I-format: encoding instructions with one operand different from registers
 - except: sll, srl, j, and jal
 - addi \$\$0, \$\$1, 100 #immediate
 - lw \$s1, 100(\$s0) #memory operand
 - J-format: encoding j and jαl
 - · j Label1



R-format instructions

ор	rs	rt	rd	shamt	funct
6 bits	5 bits	5 bits	5 bits	5 bits	6 bits

- op: <u>always</u> 0 for R-format instructions
 - 6 bits for all formats
- **rs**: first source register number
- r†: second source register number
- rd: destination register number
- shamt: shift amount (0 for non-shift instructions)
- funct: identify operators



Register numbers & some function fields


Register	Number	Register	Number	Register	Number
\$zero	0	\$†0-\$†7	8-15	\$ <i>g</i> p	28
\$at	1	\$50-\$57	16-23	\$sp	29
\$v0-\$v1	2-3	\$†8-\$†9	24-25	\$fp	30
\$a0-\$a3	4-7	\$k0-\$k1	26-27	\$ra	31

Instruction	Function field	Instruction	Function field
add	0x20 (32)	sub	0×22 (34)
and	0×24 (36)	or	0x25 (37)
nor	0×28 (39)	jr	0×08 (8)
sll	0x00 (0)	srl	0x02 (2)
slt	0×2A(42)	sltu	0x2B (43)



Example-1

Question: what is machine code of following instruction



Answer:

R-format is used to encode the above instruction

0	17	18	8	0	32
000000	10001	10010	01000	00000	100000

Machine code: 0x02324020



Example-2

 Question: what is the assembly instruction of the following MIPS machine code

- Answer:
 - Opcode (the 6 high-significant bits) is 0 ⇒ an R-format instruction

000000 00000 10000 01010 00100 000000

- Function field is $0 \Rightarrow a \parallel s \parallel s$ instruction
- The assembly instruction: sII \$†2, \$s0, 4
- Note: shift instructions don't use the rs field



MIPS I-format Instructions



op: specific values for instructions

beq \$s0, \$s1, L1

- rs: source or base address register (no destination)
 - First source register in 2 source register instructions
- rt: source or destination register
 - Second source register in 2 source register instructions
- constant/address: $-2^{15} \rightarrow 2^{15} 1$



Some opcode fields

Instruction	Opcode field	Instruction	Opcode field
addi	0x08 (8)	addiu	0x09 (9)
lbu	0x24 (36)	lhu	0x25 (37)
lb	0x20 (32)	lh	0x21 (33)
lw	0x23 (35)	SW	0x2B (43)
sb	0x28 (40)	sh	0×29 (41)
slti	0x0A (10)	sltiu	0x0B (11)
andi	0x0C (12)	ori	0x0D (13)
beq	0x04 (4)	bne	0x05 (5)



Example-1

Question: what is machine code of following instruction

Answer:

- rt (destination) rs (base register)
- I-format is used to encode the above instruction

35	19	8	32
100011	10011	01000	0000_0000_0010_0000

Machine code: 0x8E680020



Example-2

 Question: what is the assembly instruction of the following MIPS machine code

Answer:

- Opcode \neq 0 (not j and jαl) ⇒ an I-format

- Opcode = 101011 ⇒ **sw** instruction
- The assembly instruction: sw \$10, 100(\$1)



Exercise

 Write MIPS code for the following C code, then translate the MIPS code to machine code. Assume that \$\frac{1}{2}\$ stores the base of array \$A\$ (array of integers) and \$\frac{5}{2}\$ stores \$h\$

```
int A[301];
int h;
...
A[300] = h + A[300] - 2;
```



Branch & jump addressing

- Question: how can we represent labels in conditional branch and unconditional jump instructions?
- Answer: use addressing methods
 - Cannot representing label names
 - Calculate distance between the current instruction to the label
 - PC-relative addressing
 - (Pseudo) direct addressing



PC-relative addressing

- Use for encoding bne and beq instructions
- Target address (the instruction associated with the label) calculated based on PC - program counter register
 - PC is already increased by 4

target address = PC + address field
$$\times$$
 4

 When encoding branch conditional instructions, address field should be calculated by

$$address field = \frac{target address - PC}{4}$$

The number of instructions from PC to the label



Example-1

• **Question**: given the following MIPS code, what is the machine code for the conditional branch instruction?

- X + 12

- Answer:
 - I-format is used
 - Assume that the bne instruction is stored at address x
 - PC = x + 4 when processing the **bne** instruction

target address =
$$x + 12 \Rightarrow$$
 address field = $\frac{(x + 12) - (x + 4)}{4} = 2$

5 19 20 2

Machine code: 0x16740002



Example-2

• **Question**: given the following MIPS code, what is the machine code for the conditional branch instruction?

- Answer:
 - I-format is used
 - Assume that the bne instruction is stored at address x
 - PC = x + 4 when processing the **bne** instruction

• target address =
$$x - 4 \Rightarrow$$
 address field = $\frac{(x - 4) - (x + 4)}{4} = -2$


Machine code: 0x1611FFFE

16-bit 2's complement



J-format instructions

- PC-relative and I-format not good enough
 - 16 bit address field allows to jump only $\pm 2^{15}$ instructions



- J-format is used for j and jal instructions only
 - opcode: 2 for j; 3 for jal
 - address: used for calculate target address of jump instructions target address = $\{PC[31:28], address[25:0],00_2\}$
 - Need full address of instructions



Example

 Question: given the following MIPS code, what is the machine code for the unconditional jump instruction if the first instruction is stored at memory location 80000?

Answer:

- J-format is used
 - PC = 80012 when processing the j instruction \Rightarrow PC[31:28] = 0000_2
 - target address = $80000 = \{0000_2, \text{ address field}, 00_2\}$
 - \Rightarrow address field $=\frac{80000}{4}=20000$

2	20000

- Machine code: 0x08004E20



Exercise

• Decide the machine code of the following sequence. Assume that the first instruction (start label) is stored at memory address 0xFC00000C

```
        0xFC00000C
        start: add $s0, $s1, $s2

        0xFC000010
        loop: addi $t0, $t0, -1

        0xFC000014
        sw $t0, 4($t2)

        0xFC000018
        bne $t0, $t3, loop

        0xFC00001C
        j start
```



Branching far-away

- If branch target is too far to encode with 16-bit offset, assembler rewrites the code
- Example



Summary

- MIPS ISA
 - 3 types of operands
 - 5 groups of instructions
- Procedure call
- Machine code
 - 3 formats
 - Addressing methods



The end



