# Raspberry Pi - Notes, tips and tricks

Tips, hints, and tricks when working on Raspberry Pi

#notes #raspberry-pi

Last update: 2021-08-04 17:31:07

- 1. Setup Wireless
- 2. Python packages
- 3. Who is logged on?
- 4. Save power
  - 4.1. Turn off USB
  - 4.2. Turn off HDMI
  - 4.3. Throttle CPU
  - 4.4. Disable Wi-Fi & Bluetooth
  - 4.5. Disable on-board LEDs

## **6** Setup Wireless

Refer to the official guide at Raspberry Pi Configuration. Note that there are two types of access points:

**Routed** wireless access point: Create a new local network, which is not connected any other existing network

**Bridged** wireless access point: Extend an existing Ethernet network to wireless computers and devices

# **b** Python packages

Most packages can be installed using sudo apt-get install followed by python-<packagename> /\* for Python2 \*/ or python3-<packagename> .

In some cases, a package is not available on the OS package manager, so install that packages via pip from python package manager.

Install pip first:

```
sudo apt install -y python-pip python3-pip
```

Then install the target package. For example:

```
sudo apt install -y python-ws4py python3-ws4py
```

is equivalent to:

```
pip install ws4py # python2 package
```

and

```
pip3 install ws4py # python3 package
```

# **b** Who is logged on?

Use w command from procps package.

```
08:53:52 up 2:21, 2 users, load average: 0.02, 0.06, 0.07
USER TTY FROM LOGIN@ IDLE JCPU PCPU WHAT
pi pts/0 fe80::1936:b4d4: 06:34 0.00s 1.54s 0.05s w
```

# **6** Save power

Save power when running on battery by turning off unused peripherals, or features.

## Turn OFF the USB chip:

```
echo '1-1' |sudo tee /sys/bus/usb/drivers/usb/unbind
```

Turn ON the USB chip:

```
echo '1-1' |sudo tee /sys/bus/usb/drivers/usb/bind
```

### Turn OFF the HDMI output:

```
sudo /opt/vc/bin/tvservice -o
```

Turn ON the HDMI output:

```
sudo /opt/vc/bin/tvservice -p
```

**Reduce the clock** of the core by changing some parameters in the /boot/config.txt file:

#### /boot/config.txt

```
arm_freq_min=250
core_freq_min=100
sdram_freq_min=150
over_voltage_min=0
```

#### Disable Wi-Fi & Bluetooth

Starting from Raspberry Pi 3, WiFi and Bluetooth are added on hardware, so Raspbian has its method to control these signals in /boot/config.txt file:

/boot/config.txt

```
dtoverlay=pi3-disable-wifi
dtoverlay=pi3-disable-bt
```

i It's correct to use the word pi3 in the params's value, for other version of Raspberry Pi.

**b** The rfkill command can be used to soft-block the wireless connections:

```
rfkill list # displays the state of the modules
rfkill block wifi
rfkill block bluetooth
```

but this does not completely turn off the hardware of the WiFi and the Bluetooth module. They will still draw a little power in the background.

#### Disable on-board LEDs

Add below params to the /boot/config.txt file:

/boot/config.txt

```
dtparam=act_led_trigger=none
dtparam=act_led_activelow=on
```

1. Add a form in markdown:

```
id="mySearch"
    name="keywords"
    placeholder="Enter package name..."
    aria-label="Search for a package name"
    style="border:1px solid gray; padding: .25em .5em;"
    />
        <button type="submit" class="md-button">Search</button>
        </div>
</form>
```

 $\leftarrow$