Methods 1

First, we will prepare the Upwind scheme for the spatial discretization. The conditions for the Upwind scheme are listed below:

$$\phi_{i+1} = \begin{cases} \phi_I & \overline{V} > 0\\ \phi_{I+1} & \overline{V} < 0 \end{cases},$$

and

$$\left(\frac{\partial \phi}{\partial x}\right)_{i-1} = \frac{\phi_I - \phi_{I-1}}{\Delta x} \,.$$
(1)

Discretizing gives:

$$(\rho u_x)_{i+1} \phi_{i+1} - (\rho u_x)_{i-1} \phi_{i-1} = \Gamma \left(\frac{\partial \phi}{\partial x} \right)_{i+1} - \Gamma \left(\frac{\partial \phi}{\partial x} \right)_{i-1}$$

Plugging in our Upwind scheme conditions for velocity greater than zero gives:

$$[-2F - D] \phi_{I-1} + [2F + 2D] \phi_I + [D] \phi_{I+1} = 0$$

where

$$D = \frac{\Gamma}{\Delta x} \qquad F = \frac{\rho u_x}{2} \ .$$

This equation works for the interior nodes. For the boundary nodes, we will need different equations. For the left boundary:

$$[2F + 2D] \phi_I + [D] \phi_{I+1} = [2F + D] \phi_L$$
.

For the right boundary:

$$[-D] \phi_{I-1} + [-2F - 2D] \phi_I = [-2F + D] \phi_R.$$