

Contents

Ι	Fir	rst 5 Weeks	2	
1	Preface			
	1.1	Abstraction	3	
	1.2	Instruction Set Architecture		
	1.3	Efficiency		
	1.4	History	4	
	1.5	Laws	4	
	1.6	Moore's Law	4	
		1.6.1 The Power Wall	Ę	
		1.6.2 Multi-Core Era		
2	Inst	truction Set Architecture	6	
	2.1	RISC-V	7	
	2.2	Running Instructions	7	
		2.2.1 Stored Program Computer (Von Neumann)		
	2.3	Building an ISA: Operands		
		2.3.1 Registers		
		2.3.2 Immediates		
		2.3.3 Memory	Ć	

Part I First 5 Weeks

Chapter 1

Preface

1.1 Abstraction

Definition: Abstraction

Abstraction is the concept of providing a (relatively) simple interface to higher level programs, hiding unnecessary complexity.

We define a computer as a black box with multiple layers of *abstraction*. When focusing on a particular layer, we abstract away the irrelevant layers. There are three main abstraction layers:

- (i) Application Layer: Here, we translate from algorithms to code. We usually write these in high level languages (e.g. C/++, Java, etc.).
- (ii) Systems Layer: Here, we have the compiler that translate HLL¹ code to machine code, and the operating system, which deals with everything you learned in CS111.
- (iii) Hardware Layer: The hardware layer is the physical hardware (who would've thought) that makes all of this possible (e.g. CPU, RAM, etc.)!

Similar to computers, program code also has three layers of abstraction!

- (i) High-Level Language: This layer hosts all of our favorite languages (e.g. C/++, JS, etc.). This level of abstraction provides good productivity and portability².
- (ii) Assembly Language: A textual representation of hardware instructions. Assembly is architecture dependent!
- (iii) Hardware Representation: Here we have the actual binary (1's and 0's) that encode instructions and data.

1.2 Instruction Set Architecture

Definition: Instruction Set Architecture

The Instruction Set Architecture (ISA) is the set of instructions supported by a computer. There are multiple (all incompatible) ISA's and they usually come in families. ISA's usually come with privilaged and standard instruction sets.

The ISA is an *interface* between hardware and software, and as such, allows them to develop and evolve *independently*.

The software sees a functional description of the hardware: (i) Storage locations (e.g. memory) and (ii) Operations (e.g. add).

The hardware sees a list of instructions and their order.

¹HLL: **H**igh **L**evel **L**anguage.

²Most languages are hardware/architecture agnostic.

1.3 Efficiency

The main objective when architecting a computer is to make it *efficient*. Here, we define "efficient" to be:

(i) Performance³: Fast.

(ii) Power Consumption: Low.

(iii) Cost: Low.

(iv) Reliable and Secure.

1.4 History

Look at the slides for the full history. TLDR: we've come a long way. The main takeaway of this section is that we've been able to make these improvements for two major reasons: new technologies and innovative techniques.

1.5 Laws

1.6 Moore's Law

Definition: Moore's Law

Moore's Law states: "The number of transistors in an IC^a doubles every two years."

 $^a {\rm IC} :$ Integrated Circuit.

This Moore guy is pretty smart since we've been roughly on track with his prediction (up until about 2005).

Definition: Dennard's Scaling Law

Dennard's Scaling Law states: Moore's law \implies each transistor's area is reduced by 50% (or every dimension by 30%).

Naturally, it follows that:

- (i) Voltage is reduced by 30% to keep the electric field constant (remember V = EL? Me neither.).
- (ii) L is reduced \implies delays are reduced by 30% (x = Vt).
- (iii) Frequency is increased by 40% (frequency = $\frac{1}{time}$).
- (iv) Capacitance is reduced by 30% ($C = \frac{kA}{L}$).
- (v) Since $P = CV^2f$ (apparently), power consumption per transistor is reduced by 50%. As such, the power consumption of the entire chip stays the same.

Definition: Amdahl's Law

Amdahl's Law states: "The performance improvement ($speed\ up$) is limited by the part you cannot improve ($sequential\ part$)." That is,

$$speed \ up = \frac{1}{(1-p) + \frac{p}{s}}$$

where p is the part that can be improved and s is the factor of improvement.

 $^{^3}$ Performance is usually the most important metric.

1.6.1 The Power Wall

Up until 2005, we've been able to make transistors smaller (ergo faster) while keeping power consumption the same. Unfortunately, since 2005, due to *tiny* transistor sizes, the static power leakage has become so dominant that we couldn't keep the power consumption the same.

1.6.2 Multi-Core Era

Guess what's better than one CPU core? Multiple! Unfortunately, Amdahl is a party pooper and his law suggests we're hitting peak performance.

Chapter 2

Instruction Set Architecture

Definition: Instruction Set Architecture

The Instruction Set Architecture (ISA) is the set of instructions supported by a computer. There are multiple (all incompatible) ISA's and they usually come in families. ISA's usually come with privilaged and standard instruction sets.

The ISA is the contract between software and hardware, and is typically defined by giving all the programmer-visible state (registers and memory) as well as the semantics of the instructions that operate on that state. ¹

As described in the definition, many implementations of a given ISA are possible. Here are a few:

- (i) AMD, Intel, VIA processors run the AMD64 ISA.
- (ii) (Most) cellphones use the ARM ISA with varying implementations from companies including (but not limited to): Apple, Qualcomm, Samsung, Huawei

Corollary: Design Methodology

ISA's are typically designed with particular micro-architectural style(s) in mind. Here are some examples:

- (i) Accumulators \rightarrow hardwired, unpipelined.
- (ii) CISC \rightarrow microcoded.
- (iii) RISC^a \rightarrow hardwired, pipelined.
- (iv) VLIW \rightarrow fixed-latency in-order parallel pipelines.
- (v) JVM \rightarrow software interpretation.

However, they can be implemented with any micro-architectural style. Here are some examples:

- (i) Intel Ivy Bridge: Hardwired pipelined CISC (x86) machine (with some microcode support).
- (ii) Spike: Software-interpreted RISC-V machine.
- (iii) ARM Jazelle: A hardware JVM processor.

^aIn this class, we'll focus on this one!

¹Note: The IBM 360 was the first line of machines to separate ISA from implementation; i.e. *microarchitecture*.

2.1 RISC-V

RISC-V is an open-source² "RISC"-based³ ISA (royalty-free) that was developed in the 2010's at Berkeley. In this class, we'll focus on the 32-bit "base" mode; i.e. "RV32I".

It is an alternative to CISC⁴, with the main differences highlighted below:

RISC

- (i) Fixed instruction size.
- (ii) Simple (one-by-one) operation.
- (iii) Less Complex.

CISC

- (i) Variable instruction size.
- (ii) Packed operation.
- (iii) Complex (it's in the name).

Corollary: Widely Used

With the exception of x86 (Intel's ISA) and a few others, all ISA's are based off of RISC, including (but not limited to) MIPS, ARM, PowerPC, RISC-V.

2.2 Running Instructions

2.2.1 Stored Program Computer (Von Neumann)

Definition: Von Neumann Architecture

Computer hardware is a machine that reads instructions one-by-one and executes them *sequentially*. It continues this until the program terminates or finishes.

Memory Integration

Memory holds *both* the program (set of instructions) as well as the data it uses/manipulates in a linear memory array. Because of this, they can be modified during program execution, allowing for flexibility/more complex software design.

Sequential Instruction Processing

Definition: Program Counter

A Program Counter (PC) is a register that contains the address of the current instruction.

We do the following to execute a set of instructions:

- (i) The PC identifies the current instruction.
- (ii) We fetch the next instruction from memory.
- (iii) We update the state (e.g. PC and memory) as a function of the current state according to the instruction.
- (iv) Repeat until the program terminates.

²It is currently mostly maintained by the open-source community.

³RISC: Reduced Instruction Set Computers.

⁴CISC: Complex Instruction Set Computers

2.3 Building an ISA: Operands

Instructions in 32-bit RISC-V take the form:

COMMAND OPERANDS

where each instruction is fixed-size and 32-bit. Possible types of OPERANDS are:

- (i) Registers
- (ii) Immediate
- (iii) Memory

2.3.1 Registers

Definition: Register

A **register** is a small storage unit *inside* the processor to quickly access data, addresses, and instructions. It is typically smaller (and as such, faster) than memory, and can be seen by software^a. There are typically between 16 and 64 registers in modern ISA's.

Definition: Register Width

The width of a register refers to the number of bits it can hold.

A larger register width \implies more bits can be processed simultaneously, allowing for faster data processing and transfer rates. This comes at the cost of power consumption: wider registers \implies more electronic circuits are activated at once \implies higher power consumption⁵.

RISC-V Registers

RISC-V supports 32 registers and 2 sizes:

- (i) A word has a width of 32 bits.
- (ii) A double-word has a width of 64 bits.

Aside: Floating Point Registers

Note that all 32 registers store values in *integers*. Higher-end processors may include a *separate* set of registers for floating point operations.

Each register is denoted by xi, where i is an integer between 0 and 31 inclusive.

Note: x0 is hardwised to 0; i.e. it will always contain the value 0^6 .

Note: Registers are stored in a data structure called the *register file* (which will be discussed "later" [Source: Lec. 2 Slide 28]).

^aI guess we'll clarify this later. (Source: Lec. 2 Slide 24)

⁵Low-end processors use smaller registers. High-performance processors use wider and more registers.

 $^{^6\}mathrm{This}$ is useful for various operations when we need 0; e.g. resetting other registers.

2.3.2 Immediates

Definition: Immediate

An **immediate** is a *signed* constant number used in an instruction.

Example: addi

Consider the following:

Here, 5 is the immediate that is being used in the addi instruction. We can infer that this command adds two numbers, the value in x1 and 5, and stores the result in another register x2.

Corollary: IMPORTANT: Immediate Sizes

While registers are fixed at 32 bits, immediates *need not be* 32 bits in size; i.e. they are *variable* size. Why? The explanation given in class was that there is simply no room to store a 32-bit immediate.

Sign

Since many operations in RISC-V are signed, proper sign-extension is needed when necessary. There are two cases:

Case (i) LSB: Here, padding zeroes is efficient.

Case (ii) MSB: Here, we need proper sign extension (remember 2's complement? me neither).

2.3.3 Memory