

The Efika Book

Information About Using the Efika Motherboard

July 2007 edition - by Geoffrey CHARRA (V1.5)

Sponsored by



Contents

1	Introduction	3
	1.1 Objectives	3
	1.2 License	3
	1.3 Greetings	
2	Specifications of the Efika	4
	2.1 Presentation	4
	2.2 Efika Motherboard Specifications	5
	2.3 Efika Versions	
	2.4 Efika Open Client	6
<u>3</u>	Hardware Compatibility and Setup	7
	3.1 Supported Graphics Cards	7
	3.2 PSU	
	3.3 Case	9
	3.4 Storage	12
	3.4.1 Devices Directly Connected to the On-board IDE 44 Pin Connector	12
	3.4.2 Other IDE Devices	<u>13</u>
	3.5 Hardware Setup	13
	3.6 Known Hardware and/or Software Problems	17
4	Genesi Firmware	
	4.1 Presentation	17
	4.2 Firmware Version	<u>17</u>
<u>5</u>	Operating Systems	17
	5.1 Linux	<u>17</u>
	5.1.1 Global Information	<u>17</u>
	5.1.2 Installing GNU/Linux Debian	<u>23</u>
	5.1.3 Installing GNU/Linux Gentoo	
	5.1.4 Installing GNU/Linux OpenSuse	<u>31</u>
	5.1.5 Installing GNU/Linux Ubuntu	
	5.1.6 Installing GNU/Linux EdUbuntu	32
	5.1.7 Installing GNU/Linux Crux	
	5.1.8 Use your Imagination with your Efika	33
	5.2 MorphOS	36
<u>6</u>	Additional Information	36
	6.1 Where to Buy an Efika	
	6.2 Websites about the Efika	36
	6.2.1 Official Websites	36
	6.2.2 Community Websites	37

1 Introduction

1.1 Objectives

The Efika book is a free multi-language electronic book dedicated to the Efika motherboard from Genesi. It contains information about the Efika hardware, it's setup and it's supported operating systems (Linux distributions and MorphOS).

The information gathered herein was checked rigorously. However, the author does not guarantee the accuracy and declines any responsibility for any damage or any loss that could be caused, whether directly or indirectly, in all or partly, by the use of this documentation.

This information provided here is not intended to replace the official information provided by Genesi or bplan.

1.2 License

Please respect the following license which applies to this document.

Free private use: this document can be downloaded and/or copied freely for free private use.

<u>Free public use</u>: this document can be downloaded and/or copied for free public use. A link to the original site of the document (http://www.efika.org) or an associated note, is however required on the page containing the document.

<u>Commercial use</u>: any commercial use of this document is strictly prohibited, except with prior agreement of the respective authors.

In case of doubt, please contact me by email: lugduweb [AT] efika.org

1.3 Greetings

First, I would like to thank all the people having taken part directly or indirectly in this project, in particular:

- Thibaut Jeanson (Linux Debian install section additional information)
- Karoly Balogh (Linux Debian 3D desktop install)
- Johan Dams (Linux Ubuntu section)
- Péter Czanik (Linux OpenSuse and EdUbuntu sections)
- Nico Macrionitis and The Linux Crux PPC team (Linux Crux section)
- Matt Sealey (Efika technical information verification)

I would also like to thank the following people who are helping or helped me to translate this document in others languages :

- French: **David Brunet** (V1.1) & the author (all versions)
- Japanese : **Akinori Tsuji** (V1.4 R1 to R3)
- Polish: **Paweł Szczodry** (V1.4 R3)
- Italian: **Loris Cuoghi** (V0.4 and V1.4 R2)
- Swedish: **Daniel Lundh** (V1.4 R1)

- Czech : Marek Klobaska (V1.1)

- Russian : **Vlad Vinogradov** (V0.1 to V0.4)

And those who will help for future releases:

German : **Heinrich Lehmann** and **Ulrich Beckers**

- Greek : Konstantinos Margaritis

- Portuguese: Nuno Vasco Saltao Da Costa and Ricardo Rocha

- Romanian : Alexandru Lazar

- Spanish: Héctor Juan Lopez, Carlos Reinoso Espinoza and Jose Mari Rodriguez

Turkish : **Heinrich Lehmann**

I would also like to thank **Gerald J. Normandin Jr** and **Lyndon Hill** for their assistance with the English versions, respectively V1.1 and V1.4 R3.

2 Specifications of the Efika

2.1 Presentation

The Efika is based on an ATX motherboard using a RISC PowerPC processor from Freescale (MPC5200B). This tiny card targets mostly embedded applications. It also has a very low power consumption and is completely silent.



It was created in 2005 by **bplan GmbH, Genesi's research and development centre, located in Germany**. It was first shown at the Freescale Technology Forum in 2005


The Efika is quite unique: it is neither a clone of a PC standard board nor a clone of a Macintosh board. It can handle the Linux operating system (Debian, Gentoo, etc.) and will also handle MorphOS and AROS Amiga-like systems soon.

In December 2006, Genesi sold it's first boards to customers and resellers and shipped some of them to the members of the Efika developers program (see http://www.powerdeveloper.org).

2.2 Efika Motherboard Specifications

- ATX board (153x118x38 mm while using a 90° AGP adaptor)
- Open Firmware (Genesi Firmware v1.3, IEEE 1275 compliant, handles x86 peripheral BIOS)
- Freescale MPC5200B PowerPC SoC up to 466 MHz (400 MHz, 32 bit PPC + FPU 603e or e300 core, 760 MIPS)
- 128 MB DDR RAM @ 266 MHz
- 44 pin IDE connector (2 mm 90° connector for 2.5" HDD)
- 1 PCI (33/66 MHz PCI 2.2) or 1 AGP 90° riser slot (optional)
- 10/100 Mbit/s Ethernet (Realtek 8201 Phyceiver)
- 2x USB ports (1.1) OHCI
- 1x RS232 Serial port D-SUB9
- Stereo audio out, microphone and line input S/PDIF (Sigmatel STAC 9766 AC97)
- IRDA 2400 bps to 4 Mbps
- RTC clock (power management on/off)
- RoHS compliant





Note: Hi-Speed USB 2.0 support is not planned.

2.3 Efika Versions

Today, there are two versions of the Efika board:

 The pre-production version "5200" (shown at the Freescale Technology Forum 2005): in this version, the Ethernet port is swapped and the CPU is an MPC5200.





The production version "5200B" described in the previous chapter and shown below :

Future possible versions might include:

- A MPC512X processor with integrated graphics, SATA, USB2.0 and other improvements. See the Freescale product page.
- A MPC5200B or MPC512X/no-display coupled with a higher performing XGI graphics chipset

There were also discussions in some threads about the possibility of integrating an FPGA on future designs but nothing was announced officially.

2.4 Efika Open Client

The Efika Open Client is a network computer based around the Efika motherboard and directly sold by Genesi.

The Efika Open Client is available in 3 basic configurations:

- Node (for clustering and control)
- Basic (network booting graphical client)
- Plus (a full featured disk workstation).

Open Client configurations can be made with standard 2.5" hard disks or for lower power and higher resilience, a flash based device (CompactFlash or discrete IDE flash module).



Note that **keyboard and monitor are not included** in the configuration.

Specifications are as follows:

The prices given hereafter are the prices of May 2007 with the rate of corresponding exchange.

Open Client Node - headless network node (\$275 or ~€205)

- Efika 5200B motherboard
- · Industrial 18-gauge steel case
- Power Supply AC/DC adapter

Open Client Basic - network-booting thin terminal (\$325 or ~€245)

- · Efika 5200B motherboard
- · Industrial 18-gauge steel case
- Power Supply AC/DC adapter
- XGI Volari V3XE graphics (DVI-I, HDTV)
- (optional) 64 MB Compact Flash and adapter for local storage (+\$25 or ~+€15)

Open Client Plus - efficient standalone desktop solution (\$375 or ~€280)

- Efika 5200B motherboard
- · Industrial 18-gauge steel case
- Power Supply AC/DC adapter
- XGI Volari V3XE graphics (DVI-I, HDTV)
- (optional) 64 MB Compact Flash and adapter for local storage (+\$25 or ~+€15?)
- 40 GB hard disk

Note: the motherboard only can be bought for \$99 (or \sim £75) and the case only for (\$150 or \sim £110).

For more information see http://www.genesippc.com/openclient.php

3 Hardware Compatibility and Setup

3.1 Supported Graphics Cards

The MPC5200B PowerPC processor supplies a single PCI bus at 66 or 33 MHz. Off the shelf PCI at 66 MHz are not available. Thus, the Efika uses the AGP slot in PCI mode and AGP is bridged mechanically to PCI with the AGP 90° riser slot. The 66 MHz frequency is the smallest common denominator providing AGPx1, which only runs at 3.3 V: be aware that other voltages will result in damage to the board. The Hardware Layer/OpenFirmware provides x86 BIOS support, so it is possible to use standard AGPx1 graphic cards such as an ATI 9200 series card.

Please also note that a sufficiently powerful graphics board is required to offload the CPU if you want to use a graphic desktop such as GNOME (xfce or e17 is recommended). For this reason, the ATI RADEON 9250 is probably the best choice (it is the most powerful graphic board at AGPx1 and it is still quite easy to find).

The graphic card must also be **low profile** to fit at 90° on the Efika like on the picture below:



The following list is a set of cards that worked properly on Pegasos systems. They are AGPx1 and 3.3 V. They should also work on this board (but this needs to be confirmed for each board).

- ATI Radeon 7000VE (RV100)
- ATI Radeon 7200 (R100)
- ATI Radeon 7500 (RV 200)
- ATI Radeon 8500 LE (RV 200)
- ATI Radeon 8500 (RV 200)
- ATI Radeon 9000 SE (RV 250)
- ATI Radeon 9000 (RV250)
- ATI Radeon 9000 Pro (RV250)
- ATI Radeon 9100 (RV200)
- ATI Radeon 9200 SE (RV 280)
- ATI Radeon 9200 (RV 280)
- ATI Radeon 9200 Pro (RV 280)
- ATI Radeon 9250 (RV 280)
- 3DFX Voodoo3 2000 (Avenger)
- 3DFX Voodoo3 3000 (Avenger)
- 3DFX Voodoo3 3500 (Avenger)
- 3DFX Voodoo4 4500 (Napalm)
- 3DFX Voodoo5 5500 (Napalm) (this card was recognised as a Voodoo4 on Pegasos/MorphOS, only one GPU was used, thus it is not recommended)
- SIS 305
- SIS 300
- SIS 6326
- 3D Labs / Texas Instruments Permedia2 (not recommended, because there might be no 3D support on MorphOS like on Pegasos)
- 3D Labs / Texas Instruments Permedia2v (not recommended, because there might be no 3D support on MorphOS like on Pegasos)
- XGI Volari V3XE AGP


Note: XGI has released the source code to Genesi for both 2D and 3D (thanks to HAL/OF). This might be a good choice for future improvements.

3.2 **PSU**

The power consumption of the Efika is very low:

- 0.8 to 1.2 W in operation with USB and Ethernet turned on
- 1 to 3 W for a hard disk
- 5 to 15 W for a graphics card

That gives something around 20 W, so it is then possible (and recommended) to use a Pico ATX PSU (60-80 W or 120 W) such as this one :





Note: power consumption as low as 9 W has been recorded with hard disk, graphics card (ATI 9250) all running with a reasonable amount of usage but without heavy 3D running. Those numbers have to be confirmed officially.

In European countries they can be difficult to find. Here are a few shops where they can be bought around the globe :

UK: http://www.mini-itx.com
France: http://www.thinkitx.com

Nederlands: http://www.picco.nl or http://www.sallandautomatisering.nl/

USA: http://www.mini-box.com

A standard 400 W ATX PSU can also be used initially (this is what I'm currently using).

3.3 Case

It is quite hard to find a suitable case for the Efika, because the board does not have a standard format. A miniITX case can be used but must be modified a little to make the Efika fit. A 5.25" hard drive case could also be used (but this must be tried and confirmed).

Genesi now sells a black case for the Efika on its website (with/without) the Efika Open Client:



Note that this case, can also be bought from Blastwave. (http://www.blastwave.org/efika/index.html)

A second, silver, case thereafter, is bplan's design but is not for sale yet:





There is no alternate case available for sale at the moment. Instead there are several hand made cases such as the Efika cardboard box. I guess this is the easiest box to make right now and it's free:



A few other cases were made by users, such as these :

Geit (<u>http://www.geit.de/eng_efikase.html</u>)





DJBase (http://www.pegasosforum.de/album_showpage.php?pic_id=422).



3.4 Storage

3.4.1 Devices Directly Connected to the On-board IDE 44 Pin Connector

For storage, a 2.5" hard drive can be used as explained in the official installation guide, but a memory card or microdrive adaptor also works. A hard disk is better for its lower price and its higher capacity, but Compact Flash or microdrive can be interesting because they are completely noiseless and consume less power.

- IDE standard 2.5" ATA 5400 rpm disk



- Memory card with adaptor (Compact Flash)



- Memory card with adaptor (Microdrive)





3.4.2 Other IDE Devices

Genesi does not approve whatsoever of plugging cables into the IDE connector! The following section might not work at all... So it is really not recommended!

The IDE 44 pin connector could be also be used for a 3.5" HD or an ATAPI CDROM. This would need a 44 pin male/male gender changer and shorter than 10 cm IDE ribbon cable which seems to be difficult to find. Thus such a card usage does not seem recommended for a start.

The on-board MPC5200B is compliant with ATA-4 specifications (so two HDD/CDROM drives could theoretically be managed). However, Genesi says that the Efika's controller can't handle devices that are too far away from the connector (10 cm seems to be the maximal value however a value of less than 45 cm should also be possible as written in the Freescale's official MPC5200B manual).

In addition, the on-board connector is female (as opposed to standard male connectors) making it impossible to directly connect a 2.5" HDD. In consequence, a standard ribbon cable can not be used alone and a 44 pin IDE male/male gender changer such as this one is required :



But that might not work... and maybe break something...

3.5 Hardware Setup

The pictures thereafter illustrates the hardware setup of the Efika described into the official document provided with each motherboard. Note these pictures are intended to help you set up your Efika, but they do not replace the official documents.

Hardware needed:

- An Efika board
- A 2.5" hard disk (here, a Samsung 40GB ATA 5400 rpm hard disk)
- A graphic board (here, a Gigabyte ATI RADEON 9250 AGP8x used as AGP1x)
- A Power switch and a Reset switch (mine were taken from an old Morex case)
- A Power Supply Unit (standard ATX or Pico ATX)
- 4 plastic stand offs to raise up the board
- A USB keyboard and a network cable (optional)
- A screwdriver and a pliers for the hardware setup

Important notice: Genesi also recommends to put something between the hard the disk and the VGA adapter if you did not mount the board in a case, because the VGA board might touch the hard disk and it could burn the VGA, and possibly the Efika and the hard disk too.












- 1) Start by putting the plastic stand-offs under the board. This is not needed if you have an adequate case to plug it in.
- 2) Then plug your hard disk on the motherboard (the screw holes of the HD are located at the back of the board). Be careful not to break any pins while doing this!





3) Remove the bracket of your graphic board if any (use the pliers to unscrew) and put a low profile bracket instead if you have one (I didn't).



4) Plug the graphic board on the AGP riser and the AGP riser on the motherboard, then connect the power and reset switches ("PW" and "RS" marks should appear on opposite side of the AGP slot). You should obtain something like below. Now you can plug the power supply (without switching it on yet or plugging it into the wall).



5) At last, plug the network cable, the USB keyboard and the VGA. Then plug the power into the wall. You should now be able to boot your Efika. Push the power button. If your keyboard is not recognised (bplan logo without any firmware boot), just push the reset switch to reboot.



```
CV-R925128D-RH F1

Belcome to SmartFirmware(tm) for hplan EFIKA5K2

Version 1.3 (20061107101950)

SmartFirmware(tm) Copyright 1996-2001

All Rights Reserved.

Pegasos BIOS Extensions Copyright 2001-2006 by bplan CmbH.

All Rights Reserved.

ok Is
```

3.6 Known Hardware and/or Software Problems

Here is a list of current known problems that can be encountered on the Efika board:

- USB Keyboards : some keyboards are not well recognised on boot. If that happens to you, try to reset and reboot your Efika. If that still does not work, try to reset and reboot while hitting some CTRL/ALT keys.

4 Genesi Firmware

4.1 Presentation

Genesi firmware (previously named "SmartFirmware") is the command prompt shell which can be first seen when the Efika starts like on the Pegasos. It looks like white text prompt on a black background on your monitor.

The provided BIOS is an implementation of OpenFirmware (http://www.openfirmware.org/) with a few differences. Genesi firmware is based on a Forth engine (http://www.forth.org/) which is a command line interpreter, in which the instructions are executed immediately when "Enter" key is pressed. Genesi firmware amongst other things makes it possible to list the peripherals available and their properties, to modify their parameters and to initialise boot commands on a peripheral or the network.

For a detailed guide of all the commands available, refer to the online handbook: Genesi firmware User's manual: http://www.peqasosppc.com/files/SFUserManual.pdf.

This document is also available on the MorphOS CD, in the "Docs" directory.

4.2 Firmware Version

The current firmware version shipped with the Efika is Genesi firmware v1.3.

To obtain detailed information about firmware revision, type the following commands in the OpenFirmware prompt :

cd /openprom
.properties

5 Operating Systems

5.1 Linux

5.1.1 Global Information

5.1.1.1 Linux Distributions Running on Efika



Linux is an OpenSource operating system of UNIX type created by Linus Torvalds and continuing to evolve thanks to many developers in the world.

Linux became very popular because it has many interesting features :

- Free (OpenSource)
- Great range of software available for free.
- Very stable as based on the UNIX system.
- Very efficient for network applications.
- Multiuser.
- Multiplatform.

It has nevertheless some weak points:

- Not very easy to use, nor to install.
- Quite heavy, mostly on boot.
- Not very efficient for graphic applications.

Several distributions of Linux are already available on Efika:

Distribution	Links	Easy Install (*)	Interest (*)
Debian	http://www.debian.org/	8/10	9/10
Gentoo	http://www.gentoo.org/	5/10	10/10
OpenSuse	http://www.opensuse.org	tbd	
EdUbuntu	http://www.edubuntu.org	tbd	
Crux	http://cruxppc.sunsite.dk	tbd	
Ubuntu	http://www.ubuntu.com	tbd	

For additional information, see http://www.linux.org/. PenguinPPC (Linux PPC port home page) www.penguinppc.org.

PegasosPPC the home of the Pegasos computer http://www.pegasosppc.com/.

Kernel.org (where you will find the latest Linux kernel) http://www.kernel.org/.

(*) This is a personal opinion and some people might not agree.

In this ebook, we will focus on the Debian and Gentoo Linux distributions.

5.1.1.2 Hard Disk Partitioning under Linux on Efika

5.1.1.2.1 Partitioning

Like on Pegasos, Genesi firmware on the Efika does not provide the RTAS methods which allow Linux to modify NVRAM settings and make its own partitions bootable: you will have to do that manually.

If your root is on a Logical Volume Managed (LVM) partition, then /boot should be on a separate disk to be able to boot.

Genesi firmware on the Efika numbers its partitions incorrectly starting from 0 instead of 1 according to the CHRP specification. So /dev/sda1 is hd:0 and /dev/sdb1 is hd0:0; disk 0 is named "hd" and disk 1 "hd0".

/dev/sda -> first port (used for the $2.5^{\prime\prime}$ hard drive that can be plugged directly on the motherboard, at least if ATA driver is loaded before USB module).

/dev/sdb -> second port

/dev/sda1 = first port, first partition.

/dev/sda2 = first port, second partition.

/dev/sdb1 = second port, first partition.

5.1.1.2.2 Using the "parted" Tool

Parted is a partitioning command line tool used in several distribution. Using it is really easy. Here is list of the most important commands. Beware, that everything is executed immediately, there is no *undo* function. This is just a short command summary, for a complete list, visit http://www.gnu.org/software/parted/manual/

First, a little reminder about partition naming:

To get started, one needs **parted /dev/hda** to edit partitions on your primary master IDE disk. Replace the device name, if another hard drive is to be edited. When started, *parted* will drop you in some kind of command line. Anything you type there is executed immediately, so be careful!

Help will display brief help

print will list existing partitions, if there are any.

mklabel amiga creates an amiga partition table. All previous data is lost!

mklabel msdos creates an msdos partition table. All previous data is lost!

mkpart type fs start end creates a partition. It does not format the partition, but creates the correct entry in the partition table.

type is always primary in the case of Amiga partition table, a p is enough

fs in any of the following: *ext2*, *ext3*, *reiserfs*, *linux-swap*, etc.

start and **end** represent the start and end point of a partition in mega or gigabyte. $\bf M$ is appended to the number to represent a megabyte, $\bf G$ stands for gigabyte.

Example:

```
mkpart p ext2 0M 100M
mkpart p linux-swap 100M 612M
mkpart p ext3 612M 10G
mkpart p ext3 10G 40G
```

quit quits the program. There is no need to save, everything is saved as soon as you hit enter after a command.

5.1.1.2.3 Mounting Partitions of other Operating Systems

How to mount a MorphOS FFS partition under Linux?

Firstly, only FFS partitions are supported. The command is simple, in root mode, type: "mount /dev/xxxx /mnt/myamigapartition -t affs -o user,rw" (to mount the partition "xxxxx"). You can also add a line in /etc/fstab to mount your Amiga partition at each start: /dev/xxxx /mnt/myamigaparition affs user,noauto 0 0

How to mount a Linux partition under MorphOS?

For that it is necessary to download the Ext2/Ext3 filesystem for MorphOS:

http://home.elka.pw.edu.pl/%7Emszyprow/programy/ext2filesystem/.

The file ext2fs_0.4_mos.lha contains the necessary files to manage the EXT2 and EXT3 Linux filesystems. While following exactly the 'readme' file, it should not be a problem to install it and to have access to the Linux partition in a transparent way.

5.1.1.3 Tricks and Hints

5.1.1.3.1 General Information on Linux Usage for Linux Rookies

User « root »

The « root » user is the administrator, which signifies that the root has all the privileges. In a console, to go to root mode, type "su" and then the root's password. Under Debian, you can't login directly as root, but you can launch any root command by adding the "sudo" command at the beginning of the command line.

Online Help

To obtain help about a command: in a console, type « man the_command_name ».

Copy a directory and its content to another filesystem preserving permissions, ownership and links

Here is a trick using the "tar" command to perform a recursive copy without creating an intermediate tar file.

tar cf - * | (cd /target; tar xfp -)

5.1.1.3.2 Keyboard shortcuts and commands in Xorg (graphic user interface of Linux)

To go from text mode (console) to Xorg/XFree, press on "CTRL+ALT Fx" (X = 1 to 6, 7=XFree). For easily mounting/unmounting a disk, use KwikDisk from KDE menu. To kill XFree (in the event of a crash): press on "CTRL+ALT+BACKSPACE". To kill a GUI program: launch "xkill" in a console and click on the troublesome program. To kill a program in text mode, use "kill" command ("man kill" for more help).

5.1.1.3.3 Using a Linux System from Another Linux System by Changing root

If you want to use a Linux system from another one without using a boot kernel you can use the chroot command.

For example if you are under Linux Debian and that your want to use your Linux Gentoo which is installed in another partition, lets say in /dev/sda4, just do the following from a terminal:

The first time:

mkdir /mnt/gentoo
mount /dev/sda4 /mnt/gentoo

Then to change root into it:

mount -o bind /dev /mnt/gentoo/dev
mount -o bind /proc /mnt/gentoo/proc
chroot /mnt/gentoo

After having typed those commands you are logged as root under your other Linux system which can be very convenient (for example if you have problems booting a fresh kernel).

5.1.1.3.4 NFS: Network File System and Remote Compiling

NFS makes it possible to mount directories from a server computer to a client computer as local files/folders.

NFS can be used to directly transfer files from a computer to another, or to install a Linux distribution, but combined with the "chroot" command explained above, it can also be used to run your Efika applications and compilations from the client computer with a faster speed.

Personally I use a Pegasos as NFS client. This has the advantage to be PowerPC powered, so no cross compilation is needed in this case.

Note that to "chroot", on the Efika you must not use NFS on the target distribution on server side or you won't have access to the /dev and /proc directories on the NFS client. Instead, the NFS server must be run from another distribution under another partition. For example, I've used the NFS server under a Linux Debian distribution on my Efika, and the NFS client under a Linux Gentoo distribution on my Pegasos. The target distribution which I was doing "chroot" in, was a Linux Gentoo distribution installed on the Efika. This was a way to optimise compilation time. This is an example of what can be done with NFS. It's up to you to imagine other ways to use it.

Also note that if you just want to export an NFS partition from one machine (without the need to "chroot" on client side) then any client machine can import it without needing a second distribution to run on the server side.

There are many tutorials about NFS available on Internet. Here are those which helped me the most:

- Installation on Linux Gentoo:

http://gentoo-wiki.com/HOWTO Share Directories via NFS

- NFS Easy way (Ubuntu)

http://doc.gwos.org/index.php/NFS_Easy_Way

- Linux mechanics - NFS (French page - Use Google for translation)

http://linuxmecanic.frlinux.net/fr/nfs.html http://translate.google.com/translate?u=http%3A%2F%2Flinuxmecanic.frlinux.net%2Ffr %2Fnfs.html&langpair=fr%7Cen&hl=fr&ie=UTF8

In fact, the installation steps are the same on each distribution.

On the server:

- Add NFS server support to your kernel
- Install the NFS server packages
- Edit the /etc/export file on the server to configure the directories that can be mounted and the access rights. Then export it ("exportfs -a").
- Configure "portmap"
- Run services and daemons. Check it with ("rpcinfo -p")
- Configure host.deny and host.allow files

On client:

- Add NFS server support to your kernel
- Install the NFS server packages
- Mount the remote directory by hand via the /etc/fstab file

If it does not work on the first try, don't panic, check rights, ports and launched services.

5.1.1.3.5 Multiboot with bootcreator

This paragraph will be helpful after you will have installed more than one operating system on your Efika, because in this case, you will need a multiboot tool. For that, you can use "bootcreator" which is for example available in the Gentoo packages.

To install it from Linux Gentoo, just type "emerge bootcreator" from your Gentoo system.

To install it from another Linux distribution, get the sources and compile them (configure; make; make install).

Once installation is done, you need a small but empty partition which will be your boot partition with ext3 filesystem where you will put all your boot kernels. For that, you can use "parted" or "gparted" if it's installed.

Then, in all your Linux systems, you must:

1) Edit the /etc/fstab file, and add an entry such as the following one: $\tt /dev/sda1 /boot ext3 defaults 0 0$

Note: replace "/dev/sda1" by the adequate partition on your system.

- 2) Rename your current /boot partition to boot_old (for example)
- 3) Mount the new /boot partition under each of them: "mount /boot".
- 4) Copy all your boot kernels in this partition.

Then to create the possible boot entries, copy the example file from the bootcreator.example file to /boot/bootmenu.txt and edit the file to your needs.

Then to create a boot menu file, type the following command:

```
bootcreator bootmenu.txt bootmenu
```

Finally, reset your Efika and press the "Esc" key when it boots.

Under OpenFirmware, set the following environment variables to automatically boot on your bootcreator's bootmenu:

```
setenv boot-file /boot/bootmenu
setenv boot-device hd:0
setenv auto-boot? true
```

Now if you reset your Efika again (or just type boot), you should see your bootmenu.

If you have input troubles, edit your menu again, set VERSION=0 and re-create the bootmenu file.

5.1.1.3.6 Making Linux Boot Faster

Linux is not very fast at boot, so it might be very interesting to optimise it on a relative low speed computer such as Efika. Even if that can't be as fast as an operating system such as MorphOS (which does not initialise the hardware), the boot time can be reduced using a few tricks explained thereafter (but don't expect much more than a 20% time optimisation).

First, here is an interesting article from IBM about the subject:

- IBM - Boot Linux Faster (http://www-128.ibm.com/developerworks/linux/library/l-boot.html?ca=dgr-lnxw09BootFaster)

Now here is a list of ideas that will help you optimise your system to boot faster (most of those are for advanced Linux users):

- use the "initrg" tool (http://www.initng.org/) which is designed to significantly increase the speed of booting a unix-compatible system by starting processes asynchronously
- tweak the kernel to use Efika specific hardware and services only.
- tweak the kernel to load most of the drivers (except hard disk) as module, so they can be auto-loaded in parallel with the boot scripts. Examples: audio, serial ports, non-ext3 filesystems such as VFAT, AFFS...
- change boot sequence in inittab/fstab to load things in background
- set RC_STARTUP_PARALLEL to "yes" in /etc/conf.d/rc file for executing boot programs in parallel when it is possible
- boot with the "quiet" option to avoid slow text displaying
- use uncompressed kernel (probably a minor impact because the time used for accessing the disk in firmware for an uncompressed kernel, trades off the time of uncompressing a compressed kernel)
- use a lightweight desktop manager like e17 instead of Gnome or KDE
- remove some useless scripts for your system if you don't need it (ex: disk checking...)

Note that any optimisation will have an impact on other system configurations. For example you may not need the same thing if you launch a graphic desktop than if you only launch a console system.

An alternate option is to put the 5200B into "deep sleep" mode. With a switch connected to the IrDA connector you can "suspend" your Efika to a low power state instead of turning it off. Then simply push the switch and your boot time is less than a few seconds...

5.1.1.3.7 Connecting to an Efika with a Null Modem Cable

It is possible to connect to the Efika with a null modem cable and then control it from a remote computer with the "minicom" tool, so in this case, you don't need a graphic card.

Here a working config file for minicom-2.2:

```
reboot.
EFIKA 5K2 Boot Strap [RELEASE BUILD] (c) 2002-2006 bplan GmbH (BUILD 2006110113)
               CPU PVR: 0x80822014
Running on
Running on system SVR: 0x80110022
BIOS Code position: 0xFFF040D0
Setup System Config...
Setup Memory Config...
                                                                                        Done.
                                                                                        Done.
Setup PCI...
                                                                                        Done.
Setup ATA...
                                                                                        Done.
Setup USB...
                                                                                        Done.
Setup ETH...
                                                                                        Done.
Memory Test skipped (Warmboot detected)
cpu0: PowerPC,G2 CPUClock 396 Mhz BUSClock 132 Mhz (Version 0x8082,0x2014)
Welcome to SmartFirmware(tm) for bplan EFIKA5K2
Version 1.3 (20061107101950)
SmartFirmware(tm) Copyright 1996-2001 by CodeGen, Inc.
All Rights Reserved.
 Pegasos BIOS Extensions Copyright 2001–2006 by bplan GmbH.
All Rights Reserved.
ok 📗
```

```
acrux@psyke:~$ minicom -v
minicom version 2.2 (compiled Dec 12 2006)
Copyright (C) Miquel van Smoorenburg.
This program is free software; you can redistribute it and/or
modify it under the terms of the GNU General Public License
as published by the Free Software Foundation; either version
2 of the License, or (at your option) any later version.
acrux@psyke:~$ cat .minirc.dfl
# Machine-generated file - use setup menu in minicom to change parameters.
pu baudrate
                   115200
pu bits
                    8
pu parity
                   N
pu stopbits
                    1
pu minit
                    ~ ^ M~
pu rtscts
pu xonxoff
                    Yes
```

5.1.2 Installing GNU/Linux Debian

In this chapter, we will see how we can install Linux Debian on an Efika board with a USB key (and no available system at all).

5.1.2.1 Hardware and Software Requirements

- 1. A USB key (with default FAT32 filesystem).
- 2. An Efika with an empty hard disk (However data will be lost!)
- 3. An RJ-45 standard Ethernet cable connected to Internet and DHCP.
- 4. A graphic board good enough to offload the CPU (I'm using an ATI RADEON 9250 with 128Mb).

This how to focuses on the installation. For more information see the official http://www.efika.de/download/Efika.readme.pdf.

5.1.2.2 Download and Install

First download the required files from http://www.efika.info and put them on your USB key.

- Debian installer : http://www.efika.de/download/di_efika
- Debian kernel : http://www.efika.de/download/kernel efika

5.1.2.3 Installation

Before continuing, note that three of the steps described thereafter are displaying errors which are not in our case. Those steps are written in italic.

5.1.2.3.1 First installation steps

First, boot the installer from the USB key:

boot hd0:0 DI_EFIKA

Then follow the installation instructions:

Choose language: "english", "french", whatever...

Choose country: "France", whatever...

Keymap to use: Select your keyboard layout (us, fr, whatever...)

Primary network interface: eth0: Ethernet or Fast Ethernet.

Hostname: "efika", or whatever...

Domain name: leave blank

Debian, archive country: ftp.fr.debian.org was not working for me, so I've selected the German mirror. Proxy: leave blank.

Download installer components: "No kernel modules were found": this error is OK because Efika is not fully supported yet. Just answer "Yes" to continue.

Partition disks: The installer doesn't have information about the type of partition you are using...". Continue with partitioning: "Yes". Then select your partition table type.

You can either do a manual partitioning if you know how it works, or a guided partitioning to use the full disk.

If you chose the guided partitioning, the Debian installer will create a default DOS/MBR partition type.

If you chose the manual partitioning you will be able to choose the partition table format. I recommend manual partitioning (at least if you know what you are doing).

On first install, I had chosen "msdos" but it's recommended to use an "amiga" type instead to be able to install MorphOS later when it will be available. If not, a type change will lose everything which is on your disk!

Anyway, you need at least two partitions:

- a "swap": "swap"; Bootable flag: "off"
- a "root" partition "/" using ext3 filesystem ; Uses as "Ext3" ; Mountpoint : "/" ; Options :

"defaults"; Reserved blocks: "5%"; Typical usage: "standard"; Bootable flag: "on". Click "Finish" to validate, then "yes" to continue and write changes to disk. The partitions are then created and formatted.

Root password: type and confirm a password for your administrator account.

User account : type a complete user name and a login name. Then, type and confirm a password for this user.

The base system installation starts...

Install the base system: no installable kernel found. Again, that's OK, we will install the kernel manually: just click "Yes".

Software selection: leave defaults ("Desktop environment" and "Standard system")

Continue without bootloader: Still OK. "Yes".

At the end of installation (which takes almost 2 hours), note the given information on a piece of paper then reboot.

5.1.2.3.2 First Boot

For the first boot on the hard disk connected to the board, just type the following command (we still need boot from the USB key). Adapt "/dev/sda1" to your root partition name:
boot hd0:0 kernel_efika root=/dev/sda1

Under the graphical login window (GDM) do not connect yet. You would be under the GNOME desktop which is very slow and difficult to use on Efika. We are now going to install XFCE4, a lighter window manager.

- Open a console by typing on the "CONTROL" + "ALT" + "F1". Login as root with the password selected before.
- Once connected, stop GDM: /etc/init.d/gdm stop
- To install XFCE4, type the following command: apt-get install xfce4 xfce4-goodies
- Once the XFCE4 installation is finished, restart GDM: /etc/init.d/qdm start
- Back to the connection window (GDM), click on "Sessions" and select "XFCE".
- Now, login under XFCE with the password selected during installation then launch an internet browser such as Firefox or Epiphany.
- Go to http://www.efika.info and grab the debian precompiled kernel file and save it at the default location (~/Desktop/Downloads). Then, copy this file into the /boot directory.

Example:

```
su root
cp ~/Desktop/Downloads/kernel efika /boot/
```

Now, get the modules from the same internet page, save them at the default location $(\sim/Desktop/Downloads)$ and extract them :

```
su root
cd ~/Desktop/Downloads
tar zxvf modules_efika.tgz
mv ./lib/modules/2.6.19-* /lib/modules/
```

Note: check that the modules directory name is the same as the kernel name issuing a "uname -r" command and comparing it with the modules directory.

5.1.2.4 Auto-boot


Unless you have already created the boot menu with bootcreator as explained before, and set the adequate OpenFirmware variables, by default, the Efika won't boot on your fresh Debian install.

In this case, reboot your Efika and under OpenFirmware set the following system variables to boot automatically on your Debian install:

```
setenv boot-file /boot/kernel_efika root=/dev/sda1
setenv boot-device hd:0
setenv auto-boot? true
```

Now, you should have a working Linux Debian booting alone.

5.1.2.5 3D desktop



For a working 3D desktop, you need "DRI" (Direct rendering), "AIGLX" and "compiz" up and running. Unfortunately, due to a bit older than possible graphics card drivers included in Etch, it won't be fast or really usable, but it's a good toy, if you want to show the capabilities of your Efika. You can expect much better performance with recent drivers, but if you want to avoid building from sources, you have to wait a bit for that now.

5.1.2.5.1 Enabling Direct rendering

First, of all, you need DRI. If you have an ATI Radeon card, it's quite easy. Unfortunately, XGI owners still need some patching, and compiling stuff from scratch, which is beyond the scope of this description.

First, to avoid losing a working xorg.conf file, save it first ! For example: sudo cp /etc/X11/xorg.conf /etc/X11/xorg.conf_whatever

Then edit the /etc/X11/xorg.conf: sudo nano /etc/X11/xorg.conf

To have DRI working on your Radeon, just make sure your that the "Device" section is similar to this:

```
Section "Device"

Identifier "Generic Video Card"

Driver "radeon"

Option "BusType" "PCI"
```

```
Option "AccelMethod""XAA"
Option "XAANoOffscreenPixmaps" "true"
Option "EnablePageFlip" "1"
Option "ColorTiling" "1"
EndSection
```

Also, make sure that you don't have UseFBDev option, or you have it disabled. If you have a BusID option, make sure it's correct, or either disable it. You don't really need it, as auto detection really should work.

Note that the "BusType" "PCI" option line is needed, even if your Radeon is an AGP one. Because it doesn't work in AGP mode, but in PCI mode, in the Efika (like in the Pegasos II). Practically the AGP riser of the Efika is just a PCI slot, with an AGP-compatible layout. But you have to tell this to the XOrg driver, because it detects the AGP chip, and tries to use the AGP extensions - which is impossible on Efika (and Pegasos).

Also note, that to have working DRI, you need to have a section like this (normally located at the bottom of the file):

```
Section "DRI"

Mode 0666
EndSection
```

Debian installer normally makes this change automatically to /etc/x11/xorg.conf. Check it and make the change yourself if needed.

After you made all the changes, save the file.

```
Then restart X11 (mandatory).
```

Quick & dirty way: press CTRL+ALT+BACKSPACE keys (that will kill current X11 session) and then log as root and type "startx". X11 should now restart. Slow way: reboot your Efika.

Now check that you have DRI enabled by typing the following into a terminal: $glxinfo \mid grep \ direct$

```
The answer should be: direct rendering: Yes
```

If you don't have a glxinfo command, install mesa-utils package first, with the following command (as root):

```
apt-get install mesa-utils
```

If you have a libGL warning while running glxinfo, just ignore it.

So, if you have the above "direct rendering: Yes" answer, you managed to have DRI enabled, which is required to have 3D acceleration. If it doesn't work, you might not have a supported card, or you mistyped something. You might need to dig yourself into /var/log/Xorg.0.log, to see what went wrong.

5.1.2.5.2 Composite Extension, and AIGLX

To have composite extension enabled, be sure to have another section in xorg.conf, like this:

```
Section "Extensions"
Option "Composite" "Enable"
EndSection
```

You also need "dbe" module loaded. You find "Module" section in the earlier part of *xorg.conf*. I have the following modules loaded:

```
Section "Module"

Load "dbe"

Load "i2c"

Load "bitmap"

Load "ddc"

Load "dri"

Load "extmod"

Load "freetype"

Load "glx"

EndSection
```

Depending on your configuration, this list may vary. Just be sure "dbe" is included in it, before "dri" and "glx". If "vbe" and "int10" modules are there, remove them because they are irrelevant on a PowerPC computer.

Again, save the changes, and restart X. If everything is ok, you should have similar results of the following tests:

```
user@efika:~$ cat /var/log/Xorg.0.log | grep "AIGLX enabled"
(==) AIGLX enabled
user@efika:~$ cat /var/log/Xorg.0.log | grep "Compo"
(**) Extension "Composite" is enabled
```

If you've done everything right, your system is now prepared to drive compiz window manager, which is responsible for all the eyecandy and effects on your 3D desktop. We're also done with the hardware configuration part, the followings are not Efika specific at all. But in fact, if you have a Pegasos II or ODW, even the hardware configuration is the same! The very same xorg.conf just works fine on my Pegasos II/G4 + ATI Radeon 9000 configuration as well.

5.1.2.5.3 Installing compiz and gnome-themes

First, you need to install compiz, of course. Log in as root, and use apt-get, or your favourite package manager.

```
apt-get install compiz gnome-themes
```

Gnome-themes is required to let compiz use a bit better look&feel than it's default. You can proceed without it as well.

5.1.2.5.4 Compiz with XFCE4

You really shouldn't be running anything more bloated on your Efika than XFCE4, so we don't care about Gnome or KDE now. If you still run one of them, you will find gadzillions of howto's on the net, because this part is not Efika specific at all. So, to force XFCE4 to use compiz instead of xfwm4, you need to change it's default configuration.

Edit the file /usr/share/desktop-base/profiles/xdg-config/xfce4-session/xfce4-session.rc, search for the "Failsafe Session" section, and change it to look like this:

```
[Failsafe Session]
Count=4
# Client0_Command=xfwm4
Client0_Command=compiz,--fast-filter
```

Save it. Please notice the comma in the compiz line. That is no typo, you need that there. After this, log out, log in into a non-X console, and delete your *.cache* directory, where xfce4 keeps some session-specific variables cached. If you don't delete this, the default settings you've just changed, might not get applied. Don't worry, you only delete temporary files, your configuration is not affected.

```
rm -r ./.cache
```

That's it. If you've done everything right, after you log in to your X session you now should have the rotating cube, bouncy windows, and other goodies.

If you want to disable compiz later, you only need to revert the changes in *xfce4-session.rc* file, and empty *.cache* directory again, as described. The rest of the changes are not harmful at all, and can safely remain untouched, however you might be able to free up some memory, if you disable composite extension again in *xorg.conf* file.

5.1.3 Installing GNU/Linux Gentoo 5.1.3.1 New Install

5.1.3.1.1 First Way: NFS Install

To install Gentoo on your Efika by NFS install, you can follow the instructions given here: http://gentoo-wiki.com/Efika.

5.1.3.1.2 Second Way: Install from a Debian Shell

Another way to install Gentoo, is to use your Debian install and "chroot" into it. Here is a way to do it :

Open a shell and type the following commands (We suppose here that you have an empty partition on /dev/sda2).

Mount a Gentoo root filesystem:

mkdir /mnt/gentoo/
mount /dev/sda2 /mnt/gentoo/

Download a "stage1" or "stage3" tar file from one of the Gentoo mirrors. Example on: http://ftp.club-internet.fr/pub/mirrors/gentoo/releases/ppc

For a "stage1" or "stage3" install:

cd /mnt/gentoo

tar jxvpf /mnt/cdrom/stages/stage1-xxx (with <xxx> any string, press <TAB> for automatic completion)

Mount /dev and /proc :

mount -o bind /dev /mnt/gentoo/dev
mount -o bind /proc /mnt/gentoo/proc

Copy resolv.conf file (contains resolved IP adress of the computer)

cp /etc/resolv.conf /mnt/gentoo/etc/resolv.conf

Change root to use your new system as if we would have booted on it:

chroot /mnt/gentoo

Now you are ready to build your Gentoo system.

You will need to "emerge –sync", configure your /etc/make.conf file with the adequate flags and bootstrap it. This is a very long process. Please refer to the official Gentoo documentation for it.

5.1.3.1.3 Third Way: Cross-compiling

You can use your Pegasos or another computer (PPC or x86) to cross compile a Gentoo distribution for your Efika. For that, please refer to the documentation provided on Gentoo's website.

- http://www.sable.mcgill.ca/~dbelan2/crossdev/crossdev-powerpc-i686.html
- http://gentoo-wiki.com/HOWTO_Cross_Compile
- http://gentoo-wiki.com/Embedded_Gentoo

5.1.3.1.4 Fourth Way: Using a Pre-built Stage4

This is indeed, a variation of the second way install with a « stage4 » instead of a « stage1 » or a « stage3 ». For that, just follow those instructions : http://dev.gentoo.org/~humpback/efika/

This is the fastest way to install a new Gentoo system on your Efika computer. Thus, this the one I recommend for that.

As an alternate pre-built stage4, "e17ka", a LiveCD for the Efika 5K2 is available in download as a torrent. It is a gentoo-linux liveimagesystem created to have an out-of-the-box system with some useful applications. See included README file for install.

http://www.pegasos.org/downloads/torrents/e17ka.torrent

5.1.3.2 Converting a Pegasos Linux Gentoo System to an Efika Linux Gentoo System

If you are running Linux Gentoo on your Pegasos, you can convert it to an Efika distribution just by changing the CFLAGS in /etc/make.conf and by recompiling it all on the Pegasos (which is really much faster!).

To do that, follow those steps:

 First, copy all the content of your favourite Pegasos Linux Gentoo system to another partition. For that use the tar command which keeps the links.
 For example, to copy the "/" content to the /mnt/gentoo_efika partition:

```
cd / ; tar cf - . | ( cd /mnt/gentoo_efika; tar xfp - )
```

2) Then change root to the new partition (see above) mount -o bind /dev /mnt/gentoo_efika/dev mount -o bind /proc /mnt/gentoo_efika/proc chroot /mnt/gentoo efika

3) Change your CFLAGS in /etc/make.conf nano /etc/make.conf Replace the CFLAGS line by : CFLAGS="-O2 -mcpu=603e -pipe"

4) For the kernel, the best is to get the last Efika kernel sources and configuration kernel from http://dev.gentoo.org/~humpback/efika/

If needed, configure it to your needs:

cd /usr/src/linux
make menuconfig

Exit from the GUI, then compile your kernel:

make all modules_install

Now copy your kernel to your /boot partition

cp /usr/src/linux/arch/ppc/boot/images/zImage.chrp /boot/efika gentoo ker

- 5) Then you are ready to rebuild all your system (It took 5 days for my EZPegTV's Pegasos system): "emerge -e system".
- 6) Copy your entire partition to your Efika, for example by using an external USB drive and the tar command (If the whole partition is too big for a single tar, make several tar files of your system. Then extract these files to your Efika hard drive. Personally I made three tar files: one for /usr/src, another one for /usr/portage and one with the all other directories). You can also use your directory as a NFS source if installed.
- 7) Don't forget to update your /etc/fstab. Then, put the kernel to the right place if needed (see previous Debian chapter) to be able to boot.

5.1.4 Installing GNU/Linux OpenSuse

A wiki page about installing Linux OpenSuse on an Efika board is available here: http://en.opensuse.org/Efika102

5.1.5 Installing GNU/Linux Ubuntu

This chapter explains how to get Ubuntu Linux running on the Efika. The actual Ubuntu kernel is not yet used, this will come soon.

5.1.5.1 First method: The hard way, no available PowerPC machine

Note that this method is reserved to advanced Linux users (NFS and Qemu used): it's a lot easier to install Linux Debian first, and then use the second method.

This installation assumes you have an Efika without an OS installed, but you have access to a PC (non PowerPC) with GNU/Linux installed.

Get QEmu and compile with support for PowerPC. Important: compile static binary!

Then, make sure your kernel supports binfmt_misc.

Mount it:

mount -t binfmt misc none /proc/sys/fs/binfmt misc

Then register QEmu with it:

echo

Now, install debootstrap and dpkg (with the adequate installation tool of your Linux distribution).

Create the minimal Ubuntu system with debootstrap:

debootstrap --arch powerpc feisty /nfsroot/home/ubuntu/ http://archive.ubuntu.com/ubuntu

This step is why you need QEmu, as debootstrap will "chroot" into the newly created root filesystem.

Note: this tutorial assumes you will use this initially over NFS. This implies you also have NFS installed and configured.

Finally, if debootstrap completed successfully, you can now start the Efika with a PowerPC kernel (the Debian kernel from efika.info for instance).

5.1.5.2 Second method: Easy, with PowerPC machine available [recommended]

This installation assumes you have an Efika with Linux (HD or NFS) or another PowerPC machine like a Pegasos. Again, this assumes an NFS root. You can initialise and copy the filesystem to Harddrive afterwards.

First, install debootstrap and dpkg (under Debian, use the apt-get install command or Synaptic tool)

Then create the Ubuntu minimal system:

debootstrap --arch powerpc feisty /wherever/you/want http://archive.ubuntu.com/ubuntu

Note for NFS users: There is a bug with dpkg which results in an error like this: "dpkg: unable to lock dpkg status database: No locks available". To get around this, you have to mount a loop filesystem and create the Ubuntu system there with debootstrap.

To create a filesystem (1GB is more than enough, can be less):

dd if=/dev/zero of=./filesystem bs=1k count=1000k
mkfs.ext3 ./filesystem
mount -o loop ./filesystem /wherever/you/want
debootstrap --arch powerpc feisty /wherever/you/want http://archive.ubuntu.com/ubuntu

Afterwards, you can copy this root fs wherever you want and unmount the loop filesystem.

Finally, start the Efika with a PowerPC kernel like the Debian one from efika.info.

5.1.6 Installing GNU/Linux EdUbuntu

Efika can work very nicely as a thin client for EdUbuntu.

Here is what is needed:

- * a local network
- * a PowerPC machine as EdUbuntu server (preferably a Pegasos, which will be used here)
- * at least one Efika, as thin client

If all hardware is available, the first step is to download and install EdUbuntu on the 'server'. Download it from: http://www.edubuntu.org/Download

Use the DVD, which has all files necessary for booting on Pegasos, or use mkvmlinuz from an already installed Ubuntu 6.10 to create a boot kernel (or mkzimage from openSUSE, like I did). For that, you can follow the steps described in the Linux volume of the Pegasos book (http://thepegasosbook.wikipeg.org).

The normal installation does not install the LTSP (Linux Terminal Server Project) environment. There is a script to install it afterwards, but it does not seem to be working as it should be. Restarting a broken installation does not work either. This leaves us to create the LTSP environment on installation. Use the 'expert' menu point, or add the 'priority=low' boot parameter to get some more control over installation and be able to install LTSP. Some help is available at: http://www.edubuntu.org/GettingStarted

To save yourself a lot of trouble, it's better to use a network setup as suggested in the documentation: a 192.168.0.0/24 network, with EdUbuntu server at 192.168.0.254 (see some explanation at the end).

Xorg does not work on a fresh install. Please see http://www.pegasos.org/index.php?
name=News&file=article&sid=1229 how to get Xorg running on the 'server'. This will take a while, as many packages are updated over the Internet.

Use information from

https://help.ubuntu.com/community/HowToCookEdubuntu/Chapters/LTSPManagement to upgrade software inside the LTSP directory. Look for the 'Updating your LTSP clients NFS root' part. Replace 'i386' with 'powerpc' as needed. This will bring the LTSP environment up to shape, and also makes sure, that Xorg works.

Next task is to download prebuilt Efika kernel and modules from http://www.efika.info/ and copy to the appropriate directories. 'kernel_efika' goes to /var/lib/tftpboot , modules should be extracted to /opt/ltsp/powerpc/lib/modules

Also check /etc/ltsp/dhcpd.conf , probably it needs to be adjusted from i386 to powerpc. Don't forget to restart it, if anything is changed.

To get rid of some warnings, edit /opt/ltsp/powerpc/etc/lts.conf . Kernel support is missing so, make sure, that 'SOUND=False' and 'NBD_SWAP=false' are in the file.

Now Efika should be able to boot over the network with the following command:

boot kernel_efika kernel_efika ip=dhcp root=/dev/nfs

5.1.7 Installing GNU/Linux Crux

Linux CRUX ISO CDROM both supports Genesi Pegasos II and Genesi Efika boards. It can be downloaded from those URLs :

http://cruxppc.sunsite.dk/downloads/crux-ppc-2.2.0.2-rc1.iso

http://cruxppc.sunsite.dk/downloads/crux-ppc-2.2.0.2-rc1.iso.md5sum

An installation howto is available in PDF format:

http://cruxppc.sunsite.dk/releases/2.2.0.2/efika-howto.pdf

And a handbook is also available here:

http://cruxppc.sunsite.dk/releases/2.2.0.2/handbook.html

5.1.8 Use your Imagination with your Efika

5.1.8.1 Use a Nintendo Wiimote with an Efika

This section provides information to use a Nintendo Wiimote controller on an Efika. The Nintendo controller has motion sensing capability. It can give a totally new and attractive gameplay to any game.



The Wiimote communicates with the Wii via a Bluetooth wireless link. The Bluetooth controller is a Broadcom 2042 chip, which is designed to be used with devices which follow the Bluetooth Human Interface Device (HID) standard, such as keyboards and mice. The Bluetooth HID is directly based upon the USB HID standard, and much of the same documentation applies.

For more information about it, have a look at the following URL: http://www.wiili.org/index.php/Wiimote

A Wiimote is shipped with every Wii console sold, but it is also possible to buy a single one for a price between €40 and €60. We will also be using a Belkin/Sitecom CN-520 Bluetooth USB device like the one on the picture below (about €15) :



The whole will be running on a Linux Gentoo system with a kernel version higher or equal to 2.6.19. For more information about Linux Gentoo installation, see the Linux Gentoo chapter before.

5.1.8.1.1 Cwiid Driver Installation

First of all, we need to get the "CWiid" drivers. CWiid is a collection of Linux open source tools written in C for interfacing your Linux system with a Nintendo Wiimote.

Start by downloading the "Cwiid" driver sources from http://abstrakraft.org/cwiid/

Download the latest version (I personally did use the 0.5.02 version available at the following URL: http://abstrakraft.org/cwiid/downloads/cwiid-0.5.02.tgz).

Now, we must enable the "User lever driver" support into the kernel (or "uinput").

In /usr/src/linux; do "make menuconfig" to setup your kernel.

Device Drivers -> Input Device support -> Miscellaneous devices -> <M> User level driver support

Quit and save. Check that the "grep UINPUT .config" commands displays the following result : "CONFIG_INPUT_UINPUT=m".

Copy your kernel at the right place and reboot (for more information about kernel configuration, check the Linux Gentoo chapter or/and the Linux Gentoo wiki).

After reboot, launch the module with the "modprobe uinput" command. To have it launched on each boot, add the "uinput" line at the end of the /etc/modules.autoload.d/kernel-2.6 file. For that type the following command: echo "uinput" >> /etc/modules.autoload.d/kernel-2.6

Now we are ready to compile the Cwiid programs. Go into the Cwiid source directory and type the following commands :

```
./configure
make
make install
ldconfig
```

In case of any problem, see the associated README file.

Note: "configure" may fail if some packages are not installed on your system. For Bluetooth files, if you use gnome, the simplest is to emerge "emerge gnome-bluetooth" which will install all what is needed:

```
Mon Mar 26 13:49:13 2007 >>> dev-libs/openobex-1.3
Mon Mar 26 13:52:14 2007 >>> net-wireless/bluez-utils-2.25-r1
Mon Mar 26 13:56:02 2007 >>> net-wireless/libbtctl-0.6.0-r1
Mon Mar 26 14:09:09 2007 >>> net-wireless/gnome-bluetooth-0.7.0-r1
```

5.1.8.1.2 Bluetooth Configuration

Now, it's time to install and configure Bluetooth. For that, follow the Linux Gentoo Bluetooth tutorial available at http://www.gentoo.org/doc/en/bluetooth-guide.xml up to step 5 ("Detecting and Connecting to Remote Devices").

The Belkin/Sitecom CN-502 Bluetooth USB key is not listed in the peripherals supported by "bluez", but it works. Here is the console output for this device :

efika linux # Isusb

Bus 002 Device 002: ID 0a12:0001 Cambridge Silicon Radio, Ltd Bluetooth Dongle (HCI mode)

Bus 002 Device 001: ID 0000:0000 Bus 001 Device 001: ID 0000:0000

efika linux # hciconfig -a

hci0: Type: USB

BD Address: 00:10:60:A7:B1:CF ACL MTU: 192:8 SCO MTU: 64:8

UP RUNNING PSCAN ISCAN

Link policy: RSWITCH HOLD SNIFF PARK

Link mode: SLAVE ACCEPT Name: 'BlueZ at efika (0)'

Class: 0x3e0100

Service Classes: Networking, Rendering, Capturing

Device Class: Computer, Uncategorized

HCI Ver: 1.1 (0x1) HCI Rev: 0x20d LMP Ver: 1.1 (0x1) LMP Subver: 0x20d

Manufacturer: Cambridge Silicon Radio (10)

In case of a problem: if the "lsusb" command displays the Bluetooth key but the hciconfig displays nothing, just unplug the USB key, check that the Bluetooth service is launched, then replug the USB key. It should now be working.

Note that some peripherals may be recognised in HID mode instead of HCI. To change this, just type the "hid2hci" command.

5.1.8.1.3 Recognising the Wilmote

Press the "1" and "2" buttons of your wiimote simultaneously. The Wiimote's LED should now be blinking. Then type "hcitool scan" command to display the Wiimote's MAC address.

Example:

efika linux # hcitool scan

Scanning ...

00:17:AB:2B:CD:81 Nintendo RVL-CNT-01

5.1.8.1.4 wminput, wmgui and wmdemo

Now, it your time to play: wmgui and wmdemo will help you check that everything works. To make a more interesting test it is possible to use wminput with the neverball configuration file. So you will be able to control the game with the Wiimote's sensor. Great fun!

5.1.8.1.5 And now what can we do with it?

Use your imagination! This motion sensitive controller can be used with any application thanks to the configuration files. For example, you can set up UAE Amiga emulator and run your old games using the wiimote.

5.1.8.2 Use your Efika as a Media Centre Client

The idea here is to combine an Efika and a Pegasos into a client/server media centre. The Linux distribution used here, is a Linux Gentoo distribution with the MythTV software. The Pegasos contains a TV tuner card (with IR sensor) and is used as the "backend" server, the Efika being used as the "frontend" client. The Pegasos can also work alone as a frontend/backend (See EZPegTV).

This project is still in progress and more information can be found at the following URL : http://empx.charra.fr

5.2 MorphOS



MorphOS support is planned, but has not yet been released. The latest information can be found on the official MorphOS website: http://www.morphos-team.net.

6 Additional Information

6.1 Where to Buy an Efika

The Efika motherboard can be bought from Genesi's website (http://www.genesippc.com). See chapter two for prices.

You can also try to win a free Efika by submitting an interesting project at the Efika developers projects page.

It is also possible to buy Efika computers from resellers such as these :

- Relec/Pegasos Suisse Swiss http://www.pegasos-suisse.com/
- Directron USA: http://www.directron.com
- Vesalia DE: http://www.vesalia.de/

6.2 Websites about the Efika 6.2.1 Official Websites

Genesi, manufacturer of the Efika: http://www.genesippc.com/

Genesi – Efika pictures : http://www.pegasosppc.com/gallery.php?id=141; Genesi – Efika videos : http://www.pegasosppc.com/movies/efika_de.mp4

Bplan (Genesi), Efika R&D: http://www.bplan-qmbh.de/

PegasosPPC (Genesi), official site of Pegasos computers: http://www.pegasosppc.com/

Power Developer (Genesi), site PPC: http://www.powerdeveloper.org

Efika info: official information, docs and downloads for the Efika motherboard:

http://www.efika.info

Freescale, PowerPC processors: http://www.freescale.com/

Power org, PowerPC architecture technology development: http://www.power.org
Efika developers projects: http://projects.powerdeveloper.org/program/efika

6.2.2 Community Websites

Efika org: http://www.efika.org

Czech Pegasos User Group: http://www.pegasosppc.cz

Gentoo Efika wiki : http://gentoo-wiki.com/Efika

OpenSuse Efika wiki: http://en.opensuse.org/Efika102

Mupper: http://www.mupper.org

Geit: how to build an Efika case : http://www.geit.de/eng_efikase.html

DevRandom blog: http://www.devrandom.us/

Pegasos.org: http://www.pegasos.org