# Getting started:

### 1)Installation

>git clone <a href="https://github.com/wdklotz/simulinac">https://github.com/wdklotz/simulinac</a> XXX

Use the command above to clone the latest version into the directory XXX.

# 2)run the sample

make shure you use pyhton 3 cd to XXX >python simu.py [<input-file>]

3) if it works - bingo!

## 4)Input (\*.yml)

default sample input-file is

"XXX/yml/25\_09\_2017\_versuche\_70\_200MeV.yml" This input file is loaded with lots of comments which explain how to set up input for simu.py. Be aware: its syntax is YAML which is very picky with indentation!

edit filepath at the end of simu.py if you want other default input files.

## 5)Features

the new version is loaded with new features:

## 5.1)flags:

most of them are commented. if so they are set to their default values which are shown in brackets {....}. if you want to activate uncomment! most important are:

*map*: **if** False the linear T3D mappings are used for cavities **else** nonlinear mapping through the cavities is used

*sigma*: **if** True beam size is calculated from sigma matrix formalism **else** from twiss functions

*express*: **if** True quadrupoles are replaced by fast implementations of thin-lense matrices **else** the thin-lens is calculated as triplet product D\*KICK\*D

### 5.2)sections:

two sections are defined in the sample LE and HE like

- [&<section alias><space><name>,&<section alias><space><name>,....] only HE is used in the sample.

### 5.3)parameters:

physics and lattice parameter definitions like:

- <name>: &<parameter alias><space><value> | <value> | \*<parameter alias> some parameter names (see the sample input) are recognized by the program and used as starting conditions. they are: aperture, betax\_i, alfax\_i, emitx\_i, betay\_i, alfay\_i, emity\_i, sigmaz\_i, dp2p\_i, frequency and Tkin. others are of free choice to be used in element definitions

#### 5.4)elements:

definition of elements

```
1st line - <ID>: &<element alias> #any ID you like
2nd line - type: <CLASS> #defines the lattice element
attribute 1 - <key>: *<parameter alias> | <value>
```

:

attribute N - <key>: \*<parameter alias> | <value> all attribute keys with exception - sec: \*<section alias> are mandatory and depend on the element CLASS

5.4.1) element CLASS definitions available

I NOP unit D Drift

QF thick F quadrupole with **slices** option QD thick D quadrupole with **slices** option

RFG RF gap with **mapping** options (ref. T3D and A.Shishlo)

TTFG TimeTransitionFactorGap (ref. A.Shishlo) using superfish data

RFC RF cavity as triple product D\*RFG\*D

GAP Simple zero length RF-gap w/o (s,dp/p) (ref. Dr.Tiede & T.Wrangler)

M Marker

SD T3D sector dipole in x-plane
RD T3D rectangular dipole x-plane
WD T3D dipole wedge x-plane

QFth thin F quadrupole (only available as QF slice)
QDth thin D quadrupole (only available as QD slice)
QFthx thin express F quadrupole (only available as QF slice)
QDthx thin express D quadrupole (only available as QD slice)

- 5.4.2)CLASS "RFG" has a **mapping** attribute which can be either "base" or "simple". "base" is a simplified non-linear map assuming constant time-transition factors. "simple" is a linear map and gives same result as T3D matrix. Both options are only active if flag **map** is activated.
- 5.4.3)CLASS "QF" and "QD" have a **slices** attribute which can take values [1,...,N]. **if** N=1 the thick T3D matrix is used **elif** N>1 the quadrupole is cut into N slices of thin-lens quadrupoles either as D\*KICK\*D or "express"
- 5.4.4)CLASS "TTFG" has a **SFdata** attribute which has to be set to the name of the file containing the field profile data from superfish

### 6)segments:

a segment is defined as

- <seg name>: #any name you like

- \*<element alias>- \*<element alias>

7)lattice:

1st line - title: <any text> # must be present as 1st line!

lines below - [N, <seg name>,<seg name>,...,<seg name>]
lines below - [N, <seg name>,<seg name>,...,<seg name>]

number N expands the segment list behind N times