

## HARDWARE SUPPORT FOR OS

Instructor: William Zheng

Email:

will iam. zheng@digipen.edu

PHONE EXT: 1745


## Goals for this lecture

- HW and SW
- CPU I/O Communication
  - Interrupt handling
  - DMA
  - More details in chapter 13.1-13.2 of textbook
- CPU modes
  - Backward-compatibility modes
  - Privilege modes

# HW & SW

- Difference?
- Important to know the distinction
  - OS (SW)
  - But what OS can do
    - Limited by the hardware it's running on


## Computer System Components




Bus

Main Components of a Computer System

#### Motherboard




## Chipset Block Diagram



## **Device Control Registers**

- Status register
  - Done bit
  - Error bit
- Data register
  - Data to be printed
- Control registers
  - Commands



## CPU - I/O Communication

- From CPU to I/O
  - Special instructions
  - Memory-mapped I/O
    - Device data and command registers mapped to processor address space
    - Especially for large address spaces (graphics)
- From I/O to CPU
  - Polling
  - Interrupt


## Special I/O Instructions

- Instruction specially for I/O
  - I/O ports
    - Different address spaces for memory and I/O devices
  - E.g. Intel IN, OUT instructions
    - Register I/O instructions: IN/OUT move data between I/O parts and the EAX (32-bit I/O), AX (16-bit I/O) or AL (8-bit I/O) general registers.
    - Block I/O instructions: INS/OUTS move blocks of data between I/O ports and memory space

## Memory-mapped I/O - I

- Use memory read/write
  - E.g. intel MOV instructions

Specific addresses mapped to I/O devices




## Memory-mapped I/O - II

- Using software to wait //wait for I/O to be done for I/O
   //done bit is on status
- Can check status register at fixed times
- Pros
  - Fast response time (for program waiting)
- Cons
  - Low CPU utilization


```
//wait for I/O to be don
//done bit is on status
register
while (done_bit==0);
//process further data
for I/O
```

#### HW Setup for Interrupt Handling


- While waiting for I/O, do other jobs first
- Wait for I/O device to assert interrupt signal
- IF and IV register
  - Interrupt flag
  - Interrupt vector
    - A number indicating I/O controller type



## Interrupt Handling



## Interrupt-Driven I/O Cycle




## Interrupts (Cont.)

- 3 kinds of interrupt
  - Exceptions/Faults: Errors: e.g., divide by zero
  - Hardware Interrupt: I/O!
  - Software-generated interrupt: System calls
- Maskable and non-maskable
  - Maskable means turned-off
  - Usually exceptions/faults are not maskable.
- Interrupt priority
  - Interrupt handling can be interrupted by higher priority interrupts.

#### Interrupt Vector Table

- Interrupt Vector
  - Unique for each interrupt
- ISR
  - SW handling of interrupts
- Interrupt Vector Table
  - Intel IDT
    - Real addressing mode: IVT
    - Protected mode: IDT
  - Array of function pointers



# Intel Pentium Processor Event-Vector Table


vector number	description
0	divide error
1	debug exception
2	null interrupt
3	breakpoint
4	INTO-detected overflow
5	bound range exception
6	invalid opcode
7	device not available
8	double fault
9	coprocessor segment overrun (reserved)
10	invalid task state segment
11	segment not present
12	stack fault
13	general protection
14	page fault
15	(Intel reserved, do not use)
16	floating-point error
17	alignment check
18	machine check
19–31	(Intel reserved, do not use)
32–255	maskable interrupts

## Interrupts (Cont.)

- Interrupt mechanism also used for exceptions
  - Terminate process, crash system due to hardware error
- Page fault executes when memory access error
- System call executes via trap to trigger kernel to execute request
- Multi-CPU systems can process interrupts concurrently
  - If operating system designed to handle it
- Used for time-sensitive processing, frequent, must be fast

## How does CPU transfer control to ISR?


- Must know the address of a function to call a function.
- Where is the interrupt vector table located?
  - Memory
- We want to know address containing the starting address of ISR for vector N
  - Base Address + 8 \* N for 64 bit
  - Base Address + 4 \* N for 32 bit
- Question: how does the HW know where is the base?
- Hardcoded (0x0000 to 0x03ff) during real mode
- IDTR (Interrupt Descriptor Table Register) (Protected mode)
  - Who sets up the IDTR?
  - Who sets up the IDT?




#### **DMA: Motivation Scenario**

Copy 1KB from Disk 1 to Memory (Disk Read) A simple way:

- 1.CPU req Disk1 controller for 1<sup>st</sup> byte
- 2.Disk1 prepares the byte. Put it in Data-IN register.
- 3.Interrupt CPU
- 4.ISR reads the byte in Data-IN



## DMA Scenario (Fig 13.5 Textbook)



## Direct Memory Access - I

- Allow devices to read/write memory directly without CPU intervention
- Does not mean accessing the memory in the same cycle
  - Whether multiple devices (e.g. CPU) can access the memory at the same time depends on the memory design
- Allows CPU processing to be in parallel with device to memory communication
  - Reduce number of interrupts

## Direct Memory Access - II

- Used to avoid programmed I/O (one byte at a time) for large data movement
- Requires DMA controller
- Bypasses CPU to transfer data directly between I/O device and memory
- OS writes DMA command block into memory
  - Source and destination addresses
  - Read or write mode
  - Count of bytes
  - · Writes location of command block to DMA controller
  - Bus mastering of DMA controller grabs bus from CPU
    - Cycle stealing from CPU but still much more efficient
  - When done, interrupts to signal completion
- Version that is aware of virtual addresses can be even more efficient - DVMA

## Access HW device

- User program access device directly?
  - User program talks with device driver via system calls open(), read(), write() etc
  - Protect data from access-control violations
  - Erroneous use leads to crash


## How does this code execute?

```
int main()
{
    int add;
    int *add_p;
    scanf("%d", &add);
    add_p = (int*) add;
    *add_p = 0;
}

int main()

libc functions : read() and write()
Context switch from user level
to kernel mode
}
```

## MS-DOS and Intel 8088



## CPU privilege modes

- Kernel (Supervisor mode) and user mode
- Priviledged instructions
  - e.g. change the idtr value
- Other instructions
  - e.g. add, sub etc

Privileged Instructions

Other Instructions

Set of instructions supported by the CPU