Documentation

Introduction

The final purpose of this document is not necessarily to be a technical documentation of the RISC built, but should also be instructional for other students interested in computer architecture.

Instruction Set

Instructions

The instruction set consists of 32 different instructions. The first 5 bit of the operation code are interpreted as the instruction. The following instructions are implemented:

| Data transfer | 1 2 3 4 5 6 | LDW LDB MOV MOV STW STB | Load a value of a memory address into a register Load the LSB of a memory address into a register Move a value from one register to another Move an immediate value in a register Store the value of a register in a memory address Store the LSB of a register value in a memory address |
|---------------|---|---|--|
| Stack | 7 | PSH | Push register values onto the stack |
| | 8 | POP | Pop values from the stack |
| ALU | 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 | ADD SUB SUB MUL AND ORR XOR NOT LLS ALS RLS LRS ARS RRS SXT | Add the values of two registers Add an immediate value to a register Subtract the values of two registers Subtract an immediate value from a register Multiply the values of two registers Bitwise AND of the values of two registers Bitwise OR of the values of two registers Bitwise XOR of the values of two registers Bitwise inversion of the value in one register Shift the value in a register left by a variable amount Shift the value in a register arithmetically left by a variable amount Shift the value in a register right by a variable amount Shift the value in a register arithmetically right by a variable amount Shift the value in a register right by a variable amount Shift the value in a register right by a variable amount Shift the value in a register right by a variable amount Rotate the value in a register right by a variable amount Sign extension of the LSB |
| Branching | 25 | BRX | Branch to the address stored in a register |
| | 26 | BIF | Branch if a certain flag is set in the flag register |

The operation codes have the following general layout:

Architecture

| Operation Code | Mnemonic | Description |
|---------------------|----------|--|
| 0100 0001 0mmm 1nnn | LDW | Load the word that is stored at the address held by the register Rmmm into the register Rnnn. |
| 0100 1001 0mmm 1nnn | LDB | Load the least significant byte of the word at the address held by the register Rmmm into the register Rnnn. |
| 0101 Onnn bbbb bbbb | MOVE | Move the value bbbb 'bbbb into the register Rnnn. |
| 0110 0001 0mmm 1nnn | STRW | Store the value of the register Rmmm at the address held by the register Rnnn. |
| 0110 1001 0mmm 1nnn | STRB | Store the least significant byte of the value in register Rmmm at the address held by the register Rnnn. |
| 0000 00ps xxxx xxxx | PUSH | Push the declared registers x, the stack pointer s or the program counter p on the stack |
| 0000 10ps xxxx xxxx | POP | Pop values from the stack in the declared registers x, the stack pointer s or the program counter p. |
| 1000 001m mmnn nddd | ADD | Add the values of the registers Rmmm and Rnnn and store the result in the register Rddd. |
| 1000 101m mmnn nddd | SUB | Subtract the value in the register Rnnn from the value in the register Rmmm and store the result in the register Rddd. |
| 1001 001m mmnn nddd | AND | Calculate a bitwise AND of the values in the registers Rmmm and Rnnn. Store the result in the register Rddd. |
| 1001 101m mmnn nddd | OR | Calculate a bitwise OR of the values in the registers Rmmm and Rnnn. Store the result in the register Rddd. |
| 1010 0001 0mmm 1ddd | NOT | Bitwise inversion of the value in the register Rmmm. Store the result in the register Rddd. |
| 1010 1001 0mmm bbbb | LSHIFT | Shift the value in the register Rmmm by bbbb to the left. |
| 1011 0001 0mmm bbbb | RSHIFT | Shift the value in the register Rmmm by bbbb to the right. |
| 1011 1000 0000 1nnn | SIXT | Signextend the least significant byte of the value that is stored in the register Rnnn. |

ALU

The ALU consists of the following components:

- Brent-Kung Adder (BKA)
- Barrel Shifter
- Dadda Tree Multiplier (DTM)
- Logic Unit (LU)

Brent-Kung Adder

A Brent-Kung adder is a parallel prefix adder.

Barrel Shifter

The barrel shifter is able to (arithetically) shift and rotate all the bits to the left or to the right.

Dadda Tree Mulitplier

A Dadda Tree Multiplier uses a Dadda Tree to multiply two numbers.