

# 2 Kernel Structure

# Contents – 1/2

- uC/OS-II
- uC/OS-II File Structure
- Critical Sections
- Task
- Task States
- Task Control Block
- Ready List
- Task Scheduling
- Task Level Context Switching


# Contents – 2/2

- Locking and Unlocking the Scheduler
- Idle Task
- Statistics Task
- Interrupt under uC/OS-II
- Clock Tick
- uC/OS-II Initialization
- Starting uC/OS-II
- Obtaining the Current uC/OS-II Version

# uC/OS-II

- What is µC/OS-II?
  - µC/OS-II is a portable, ROMable, scalable, preemptive, real-time deterministic multitasking kernel for microprocessors, microcontrollers and DSPs.
- Applications
  - Avionics - used in the Mars Curiosity Rover!
  - Medical Equipment/Devices
  - Data Communications Equipment
  - White Goods (Appliances)
  - Mobile Phones, PDAs, Mobile Internet Devices
  - Industrial Controls
  - Consumer Electronics
  - Automotive
  - A wide range of other safety critical embedded applications

# uC/OS-II File Structure



# Critical Sections

- uC/OS-II provides 2 macros in os\_cpu.h
  - OS\_ENTER\_CRITICAL( )
  - OS\_EXIT\_CRITICAL( )
- Notes
  - Be sure not to call some kernel functions (eg: OSTimeDly) when interrupts are disabled
  - If you call a kernel function with interrupts disabled, interrupts are enabled on return

# Critical Sections - Method 1

- OS\_CRITICAL\_METHOD == 1 (os\_cpu.h)
- Code example

```
#define OS_ENTER_CRITICAL() asm( "DI" );  
#define OS_EXIT_CRITICAL() asm( "EI" );
```

- With this method, interrupt status is not preserved between before and after the macros

# Critical Sections - Method 2

- OS\_CRITICAL\_METHOD == 2 (os\_cpu.h)
- Code example

```
#define OS_ENTER_CRITICAL() asm( "PUSH PSW" );  
    asm( "DI" );  
  
#define OS_EXIT_CRITICAL() asm( "POP PSW" );
```

- With this method, interrupt status is preserved between before and after the macros

# Critical Sections - Method 3

- OS\_CRITICAL\_METHOD == 3 (os\_cpu.h)
- Use of a local variable OS\_CPU\_SR cpu\_sr;
- Code example

```
#define OS_ENTER_CRITICAL() \
    cpu_sr = get_processor_psw(); \
    disable_interrupt(); \
#define OS_EXIT_CRITICAL() \
    set_processor_psw(cpu_sr);
```

- With this method, interrupt status is preserved between before and after the macros

# Critical Sections - Method 3 on ARM

```
#define OS_CRITICAL_METHOD 3
```

```
#define OS_ENTER_CRITICAL( ) \
    cpu_sr = OS_CPU_SR_Save();
```

```
#define OS_EXIT_CRITICAL( ) \
    OS_CPU_SR_Restore(cpu_sr);
```


# Tasks

***Listing 3.2 A task is an infinite loop.***

```
void YourTask (void *pdata) (1)
{
    for (;;) {
        /* USER CODE */


        Call one of uC/OS-II's services:
        OSFlagPend();
        OSMboxPend();
        OSMutexPend();
        OSQPend();
        OSSemPend();
        OSTaskDel(OS_PRIO_SELF);
        OSTaskSuspend(OS_PRIO_SELF);
        OSTimeDly();
        OSTimeDlyHMSM();
        /* USER CODE */
    }
}
```

# Task States



# Task Control Blocks (OS\_TCB)

- When a task is created, it is assigned a task control block (OS\_TCB)
- OS\_TCBS reside in RAM
- Structure fields are organized to allow for structure packing



# typedef struct os\_tcb - 1/2

```
typedef struct os_tcb {  
    OS_STK *OSTCBStkPtr;           /* Pointer to current top of stack */  
  
#if OS_TASK_CREATE_EXT_EN > 0  
    void *OSTCBExtPtr;            /* Pointer to user definable data for TCB extension */  
    OS_STK *OSTCBStkBottom;        /* Pointer to bottom of stack */  
    INT32U OSTCBStkSize;          /* Size of task stack (in number of stack elements) */  
    INT16U OSTCBOpt;              /* Task options as passed by OSTaskCreateExt() */  
    INT16U OSTCBId;               /* Task ID (0..65535) */  
#endif  
  
    struct os_tcb *OSTCBNext;      /* Pointer to next TCB in the TCB list */  
    struct os_tcb *OSTCBPrev;      /* Pointer to previous TCB in the TCB list */  
  
#if ((OS_Q_EN > 0) && (OS_MAX_QS > 0)) || (OS_MBOX_EN > 0) || (OS_SEM_EN > 0) || (OS_MUTEX_EN > 0)  
    OS_EVENT *OSTCBEVENTptr;       /* Pointer to event control block */  
#endif  
#if ((OS_Q_EN > 0) && (OS_MAX_QS > 0)) || (OS_MBOX_EN > 0)  
    void *OSTCBMsg;                /* Message received from OSMboxPost() or OSQPost() */  
#endif
```

tick ISR uses  
this links

# typedef struct os\_tcb - 2/2

```
#if (OS_VERSION >= 251) && (OS_FLAG_EN > 0) && (OS_MAX_FLAGS > 0)
#if OS_TASK_DEL_EN > 0
    OS_FLAG_NODE *OSTCBFlagNode; /* Pointer to event flag node */
#endif
    OS_FLAGS OSTCBFlagsRdy;      /* Event flags that made task ready to run */
#endif

INT16U OSTCBDly;                /* Nbr ticks to delay task or, timeout waiting for event */
INT8U OSTCBStat;                /* Task status */
INT8U OSTCBPrio;                /* Task priority (0 == highest, 63 == lowest) */

{ INT8U OSTCBX;                 /* Bit position in group corresponding to task priority (0..7) */
  INT8U OSTCBY;                 /* Index into ready table corresponding to task priority */
  INT8U OSTCBBitX;              /* Bit mask to access bit position in ready table */
  INT8U OSTCBBitY;              /* Bit mask to access bit position in ready group */

#if OS_TASK_DEL_EN > 0
    BOOLEAN OSTCBDelReq;        /* Indicates whether a task needs to be deleted */
} OS_TCB;

    .OSTCBY      = priority >> 3;
    .OSTCBBitY  = OSMapTbl[priority >> 3];
    .OSTCBX     = priority & 0x07;
    .OSTCBBitX = OSMapTbl[priority & 0x07];
```

to make a task ready or wait fast (computed when a task is created or a task's priority is changed)

# OSTCBStat

- OS\_STAT\_RDY (=0x00): Ready to run
- OS\_STAT\_SEM (=0x01): Pending on semaphore
- OS\_STAT\_MBOX (=0x02): Pending on mailbox
- OS\_STAT\_Q (=0x04): Pending on queue
- OS\_STAT\_SUSPEND (=0x08): Task is suspended
- OS\_STAT\_MUTEX (=0x10): Pending on mutual exclusion semaphore
- OS\_STAT\_FLAG (=0x20): Pending on event flag group
- OS\_STAT\_PEND\_ANY (=0x3E): (OS\_STAT\_SEM | OS\_STAT\_MBOX | OS\_STAT\_Q | OS\_STAT\_MUTEX | OS\_STAT\_FLAG)


## INT8U OS\_TCBInit( )

- OS\_TCB is initialized by this function
- OSTaskCreate( ) or OSTaskCreateExt( ) calls this function
- OS\_TCBInit( ) has seven arguments
  - INT8U prio: the task priority
  - OS\_STK \*ptos: a pointer to the top of stack
  - OS\_STK \*pbos: a pointer to the bottom of stack
  - INT16U id: task identifier
  - INT32U stk\_size: total size of stack
  - void \*pext: value of OSTCBExtPtr
  - INT16U opt: value of OSTCBOpt

# Ready List

- Each task has unique priority level between 0 and `OS_LOWEST_PRIO`(=63) inclusive (totally 64 tasks)
- Ready list is maintained by two variables
  - `INT8U OSRdyGrp`
  - `INT8U OSRdyTbl[ 8 ]`

# Ready List - Figure



INT8U OSMapTbl[]

Index	Bit Mask
0	00000001
1	00000010
2	00000100
3	00001000
4	00010000
5	00100000
6	01000000
7	10000000

# Operations on Ready List

## ***Listing 3.7***

### ***Making a task ready to run.***

```
OSRdyGrp |= OSMapTbl[prio >> 3];  
OSRdyTbl[prio >> 3] |= OSMapTbl[prio & 0x07];
```

**OSRdyGrp |= BitY  
OSRdyTbl[Y] |= BitX**

## ***Listing 3.8***

### ***Removing a task from the ready list.***

```
if ((OSRdyTbl[prio >> 3] &= ~OSMapTbl[prio & 0x07]) == 0)  
    OSRdyGrp &= ~OSMapTbl[prio >> 3];
```

**if((OSRdyTbl[Y] &= ~BitX) == 0)  
OSRdyGrp &= ~BitY;**

**means no ready  
task in the row**

# Finding the Highest Priority Task

***Listing 3.9 Finding the highest priority task ready to run.***

```
y = OSUnMapTbl[OSRdyGrp]; /* Determine Y position in OSRdyTbl[] */  
x = OSUnMapTbl[OSRdyTbl[y]]; /* Determine X position in OSRdyTbl[Y] */  
prio = (y << 3) + x;
```

INT8U const OSUnMapTbl[] = {  
 0, 0, 1, 0, 2, 0, 1, 0, 3, 0, 2, 0, 1, 0, /\* 0x00 to 0x0F  
 4, 0, 1, 0, 2, 0, 1, 0, 3, 0, 0, 2, 0, 1, 0, /\* 0x10 to 0x1F  
 5, 0, 1, 0, 2, 0, 1, 0, 3, 0, 0, 2, 0, 1, 0, /\* 0x20 to 0x2F  
 4, 0, 1, 0, 2, 0, 1, 0, 3, 0, 1, 0, 2, 0, 1, 0, /\* 0x30 to 0x3F  
 6, 0, 1, 0, 2, 0, 1, 0, 3, 0, 1, 0, 2, 0, 1, 0, /\* 0x40 to 0x4F  
 4, 0, 1, 0, 2, 0, 1, 0, 3, 0, 1, 0, 2, 0, 1, 0, /\* 0x50 to 0x5F  
 5, 0, 1, 0, 2, 0, 1, 0, 3, 0, 1, 0, 2, 0, 1, 0, /\* 0x60 to 0x6F  
 4, 0, 1, 0, 2, 0, 1, 0, 3, 0, 1, 0, 2, 0, 1, 0, /\* 0x70 to 0x7F  
 7, 0, 1, 0, 2, 0, 1, 0, 3, 0, 1, 0, 2, 0, 1, 0, /\* 0x80 to 0x8F  
 4, 0, 1, 0, 2, 0, 1, 0, 3, 0, 1, 0, 2, 0, 1, 0, /\* 0x90 to 0x9F  
 5, 0, 1, 0, 2, 0, 1, 0, 3, 0, 1, 0, 2, 0, 1, 0, /\* 0xA0 to 0xAF  
 4, 0, 1, 0, 2, 0, 1, 0, 3, 0, 1, 0, 2, 0, 1, 0, /\* 0xB0 to 0xBF  
 6, 0, 1, 0, 2, 0, 1, 0, 3, 0, 1, 0, 2, 0, 1, 0, /\* 0xC0 to 0xCF  
 4, 0, 1, 0, 2, 0, 1, 0, 3, 0, 1, 0, 2, 0, 1, 0, /\* 0xD0 to 0xDF  
 5, 0, 1, 0, 2, 0, 1, 0, 3, 0, 1, 0, 2, 0, 1, 0, /\* 0xE0 to 0xEF  
 4, 0, 1, 0, 2, 0, 1, 0, 3, 0, 1, 0, 2, 0, 1, 0, /\* 0xF0 to 0xFF  
};

**OSRdyTbl[3] = 0xE4**

**OSRdyGrp = 0110 1000**

3 = OSUnMapTbl[ **0x68** ];  
2 = OSUnMapTbl[ **0xE4** ];  
**26** = ( **3** << 3) + **2**,

**OSRdyTbl[3] = 1110 0100**


# Task Scheduler - void OS\_Sched( )

```
void OS_Sched(void)
{
#if OS_CRITICAL_METHOD == 3
    OS_CPU_SR  cpu_sr;
#endif
    INT8U y;

    OS_ENTER_CRITICAL();
                    /* if all ISRs done & not locked */
    if ((OSIntNesting == 0) && (OSLockNesting == 0)) {
        y = OSUnMapTbl[OSRdyGrp];
        OSPrioHighRdy = (INT8U)((y << 3) + OSUnMapTbl[OSRdyTbl[y]]);
        if (OSPrioHighRdy != OSPrioCur) {
            OSTCBHighRdy = OSTCBPrioTbl[OSPrioHighRdy];
            OSCtxSwCtr++;           /* Increment context switch counter */
            OS_TASK_SW();           /* Perform a context switch */
        }
    }
    OS_EXIT_CRITICAL();
}
```


# OS\_TASK\_SW( ) - 1/3

Figure 3.6  *$\mu$ C/OS-II structures when OS\_TASK\_SW() is called.*




# OS\_TASK\_SW( ) - 2/3

Figure 3.7 Saving the current task's context.



# OS\_TASK\_SW( ) - 3/3

Figure 3.8 Resuming the current task.



# Macro OS\_TASK\_SW( )

```
#define OS_TASK_SW() OSCtxSw()
```

OSCtxSw:

```
// push current task's context
STMFD SP!, {LR}      // PC
STMFD SP!, {LR}      // LR
STMFD SP!, {R0-R12} // R0-R12
MRS R4, CPSR        // CPSR
STMFD SP!, {R4}

// OSTCFCur->OSTCBStkPtr = SP
LDR R4, _OS_TCBCur
LDR R5, [R4]
STR SP, [R5]

// OSPrioCur = OSPrioHighRdy
LDR R4, _OS_PrioCur
LDR R5, _OS_PrioHighRdy
LDRB R6, [R5]
STRB R6, [R4]

// OSTCFCur = OSTCBHighRdy
LDR R4, _OS_TCBCur
LDR R6, _OS_TCBHighRdy
LDR R6, [R6]
STR R6, [R4]

// SP = OSTCBHighRdy->OSTCBStkPtr
LDR SP, [R6]

// pop new task's context
LDMFD SP!, {R4} // CPSR
MSR SPSR_cxsf, R4
LDMFD SP!, {R0-R12,LR,PC}^ // R0-R12, LR, PC
```

# Locking the Scheduler - OSSchedLock( )

***Listing 3.12 Locking the scheduler.***

```
void OSSchedLock (void)
{
    #if OS_CRITICAL_METHOD == 3
        OS_CPU_SR  cpu_sr;
    #endif

    if (OSRunning == TRUE) {
        .          OS_ENTER_CRITICAL();
        if (OSLockNesting < 255) {
            OSLockNesting++;
        }
        OS_EXIT_CRITICAL();
    }
}
```

**OSLockNesting > 0 when  
scheduler is locked**

# Unlocking the Scheduler - OSSchedUnlock( )

***Listing 3.13    Unlocking the scheduler.***

```
void OSSchedUnlock (void)
{
#ifndef OS_CRITICAL_METHOD
    OS_CPU_SR  cpu_sr;
#endif

    if (OSRunning == TRUE) {
        OS_ENTER_CRITICAL();
        if (OSLockNesting > 0) {
            OSLockNesting--;
            if ((OSLockNesting == 0) && (OSIntNesting == 0))
                OS_EXIT_CRITICAL();
            OS_Sched();
        } else {
            OS_EXIT_CRITICAL();
        }
    } else {
        OS_EXIT_CRITICAL();
    }
}
```

# Idle Task - void OS\_TaskIdle(void \*pdata)

*Listing 3.14 The µC/OS-II idle task.*

```
void OS_TaskIdle (void *pdata)
{
    #if OS_CRITICAL_METHOD == 3
        OS_CPU_SR cpu_sr;
    #endif

    pdata = pdata;
    for (;;) {
        OS_ENTER_CRITICAL();
        OSIdleCtr++;
        OS_EXIT_CRITICAL();
        OSTaskIdleHook();
    }
}
```

a lowest priority task  
OS\_LOWEST\_PRI

32 bits counter

user supplied function

# Statistic Task

- uC/OS-II provides a task with OS\_LOWEST\_PRIO-1 that provides run-time statistic called OS\_TaskStat( ) when OS\_TASK\_STAT\_EN macro is 1
- This task executes every second and computes the percentage of CPU usage
- The computed value is placed in the variable INT8U OSCPUUsage
- If you use the statistic task, you must call OSStatInit( ) from the first and only task created before calling OSStart( )

# Initializing the Statistic Task

```
void main (void)
{
    OSInit();                  /* Initialize uC/OS-II
    /* Install uC/OS-II's context switch vector */
    /* Create your startup task (for sake of discussion, TaskStart())
    OSStart();                 /* Start multitasking
}

void TaskStart (void *pdata)
{
    /* Install and initialize µC/OS-II's ticker
    OSStatInit();              /* Initialize statistics task
    /* Create your application task(s) */
    for (;;) {
        /* Code for TaskStart() goes here! */
    }
}
```

# void OSStatInit(void)

```
void OSStatInit (void)
{
#if OS_CRITICAL_METHOD == 3
    OS_CPU_SR  cpu_sr;
#endif


OSTimeDly(2);                                /* Synchronize with clock tick */
OS_ENTER_CRITICAL();
OSIdleCtr = 0L;                            /* Clear idle counter */
OS_EXIT_CRITICAL();
                                                /* Determine MAX. idle counter value for 1 second */
OSTimeDly(OS_TICKS_PER_SEC);
OS_ENTER_CRITICAL();
OSIdleCtrMax = OSIdleCtr;
OSStatRdy = TRUE;
OS_EXIT_CRITICAL();
}
```

# Statistic Task

```
void OS_TaskStat (void *pdata)
{
#if OS_CRITICAL_METHOD == 3
    OS_CPU_SR  cpu_sr;
#endif
    INT32U      run;
    INT32U      max;
    INT8S       usage;
    OSCPUUsage = 100*(1-(OSIdleCtr
                           /OSIdleCtrMax));
    pdata = pdata;
    while (OSStatRdy == FALSE) {
        OSTimeDly(2 * OS_TICKS_PER_SEC);
    }
    max = OSIdleCtrMax / 100L;
```

```
        for (;;) {
            OS_ENTER_CRITICAL();
            OSIdleCtrRun = OSIdleCtr;
            run         = OSIdleCtr;
            OSIdleCtr   = 0L;
            OS_EXIT_CRITICAL();
            if (max > 0L) {
                usage = (INT8S)(100L - run / max);
                if (usage >= 0) {
                    OSCPUUsage = usage;
                } else {
                    OSCPUUsage = 0;
                }
            } else {
                OSCPUUsage = 0;
                max       = OSIdleCtrMax / 100L;
            }
            OSTaskStatHook();
            OSTimeDly(OS_TICKS_PER_SEC);
        }
    }
```

# Computing OSIdleCtrMax



# Interrupt Under uC/OS-II

Your ISR:

**must be written in assembly**

Save all CPU registers;

**onto the current task stack**

Call OSIntEnter() or, increment OSIntNesting directly;

if (OSIntNesting == 1) {

    OSTCBCur->OSTCBStkPtr = SP;

}

Clear interrupting device;

Re-enable interrupts (optional)

**if this is the first level interrupt**

Execute user code to service ISR;


**if you want nested interrupts**

Call OSIntExit();

Restore all CPU registers;

Execute a return from interrupt instruction;

# Servicing an Interrupt



# Tick ISR

- uC/OS-II require you provide a periodic time source to keep track of time delay and timeout
- A tick should be between 10 to 100 times per seconds or Hertz
- Tick ISR - void OSTimeTick( )

# Tick ISR - OSTimeTick()

```
void OSTimeTick (void)
{
    #if OS_CRITICAL_METHOD == 3
        OS_CPU_SR  cpu_sr;
    #endif

    OS_TCB     *ptcb;

    OSTimeTickHook();

    #if OS_TIME_GET_SET_EN > 0
        OS_ENTER_CRITICAL();
        OSTime++;
        OS_EXIT_CRITICAL();
    #endif

    if (OSRunning == TRUE) {
        ptcb = OSTCBLList;
        while (ptcb->OSTCBPrio != OS_IDLE_PRIO) {
            OS_ENTER_CRITICAL();
            if (ptcb->OSTCBDly != 0) {
                if (--ptcb->OSTCBDly == 0) {
                    if ((ptcb->OSTCBStat & OS_STAT_SUSPEND) == 0x00)
                        OSRdyGrp      |= ptcb->OSTCBBitY;
                    OSRdyTb1[ptcb->OSTCBY] |= ptcb->OSTCBBitX;
                } else {
                    ptcb->OSTCBDly = 1;
                }
            }
        }
    }
}
```

why critical section?

increment tick counter

scan each task

check tick delay

make the task ready

suspended task

created task list

## void TickTask(void \*pdata)


- If you want a task-based tick ISR, make Tick ISR post a mail and supply TickTask with highest priority

```
void TickTask (void *pdata)
{
    pdata = pdata;
    for (;;) {
        OSMboxPend(...); /* Wait for signal from Tick ISR */
        OSTimeTick();
        OS_Sched();
    }
}
```


```
void OSInit(void)
```

- OSInit( ) should be called before calling any uC/OS-II function
- OSInit( ) initialize all uC/OS-II variables and data structures
- OSInit( ) creates the idle task and the statistic task

**Figure 3.11 Variables and data structures after calling OSInit().**



# Figure 3.12 Free pools.



# Starting uC/OS-II

```
void main (void)
{
    OSInit();          /* Initialize uC/OS-II */                      */
    .
    .
    Create at least 1 task using either OSTaskCreate() or OSTaskCreateExt();
    .
    .
    OSStart();         /* Start multitasking! OSStart() will not return */}
}
```

**Figure 3.13 Variables and data structures after calling OSStart().**

