

PHYS 241: Signal Processing

William Homier¹

¹*McGill University Physics, 3600 Rue University, Montréal, QC H3A 2T8, Canada*

January 6th, 2026

Abstract

Contents

1	Introduction	1
2	Prerequisite knowledge	1
3	Basics & Voltage, Current and Resistance	1
3.1	Signal Types	1
3.1.1	Digital Signal	1
3.1.2	Analogue	1
3.2	Circuits	1
3.2.1	DC	1
3.2.2	AC	1
3.3	Waves	1
3.3.1	Properties of waves	1
3.3.2	Waveforms	2
3.4	Linear Systems	3
3.5	Electric Charge	4
3.6	Current flow	4
3.7	Electric Field & Potential	5
3.8	Potential & Ground	5
3.9	Electromotive Force	5
3.9.1	Faraday's Law	6
3.10	Ohm's Law	6
3.11	Resistors	7
3.11.1	Temperature Dependence	7
3.11.2	Power Dissipation	7
4	Circuit Theory Beyond Electronic	8
5	Capacitors & Inductors	8
6	RC and LR Circuits with AC Driving	8
7	Impedance	8
8	RLC Circuits	8
8.1	Transient Response	8
8.2	Driven RLC Circuits	8
8.3	Power Input to RLC and Circuit Network	8
9	Circuit Networks	8
10	Fourier Series	8
11	Fourier Transforms	8

12 Appendix **8**

13 Useful Links **8**

1 Introduction

2 Prerequisite knowledge

3 Basics & Voltage, Current and Resistance

3.1 Signal Types

3.1.1 Digital Signal

Definition 1. *A discretely sampled signal with a sequence of quantized values.*

3.1.2 Analogue

Definition 2. *A continuous signal (e.g., in time) representing (analogous to) some other quantity.*

Example 1. *Examples of analogue devices and computers are thermometers, sextants, and tide-predicting machines.*

3.2 Circuits

3.2.1 DC

Definition 3. *Direct Current (DC) is a form of current where voltage and current are constant over time, could be found in batteries.*

Definition 4. *A DC offset is the addition of a constant DC value to an AC signal. This shifts the entire signal up or down relative to the 0 V level, without changing the shape of the AC signal.*

3.2.2 AC

Definition 5. *Alternating Current (AC) is a form of current that changes over time, often in a sinusoidal manner. AC currents are commonly used in power distribution systems, such as household electrical outlets.*

3.3 Waves

3.3.1 Properties of waves

To describe waves, considering a sinusoidal wave of the form $A_p \sin(2\pi vt)$, we use the following terms

- Peak amplitude (A_p): maximum value of the wave from its equilibrium position .
- Peak-to-peak amplitude: total height of the wave from its maximum to its minimum value (i.e., $2A_p$).

- Frequency (v): number of cycles per second (Hz).
- Time (t): time variable.

To be able to describe AC signals effectively, we take the root mean square (RMS) amplitude $\frac{A_p}{\sqrt{2}}$ of values such as current and voltage. This is because the mean value of an AC signal is zero, and the RMS is a more meaningful measure of the signal's amplitude as it gives a positive value that is proportional to the energy in the signal.


$$I_{RMS} = \frac{I_p}{\sqrt{2}}$$

$$V_{RMS} = \frac{V_p}{\sqrt{2}}$$


3.3.2 Waveforms

Definition 6. A waveform is a graphical representation of how a signal varies over time, and can take various forms such as a sine wave, square wave, triangle wave, or sawtooth wave.

Direct current (DC). A direct current is constant in time, so its graph is a horizontal line.



Alternating current (AC). An alternating current varies periodically in time and typically oscillates about zero.



Pulsating current (DC + AC). A pulsating current is an alternating current superimposed on a non-zero DC level. This is just a matter of adding a constant DC level to an AC signal so that the signal is either shifted up or down with respect to the zero current level.




Figure 1: Pulsating direct current diagram

3.4 Linear Systems

Definition 7. *Linear systems are systems whose output can be expressed as a linear combination of the input signal(s). The principles of superposition and scaling define the properties of linear systems, where superposition means that the output of a linear system due to the addition of two input signals is the same as the sum of the outputs due to each of the input signals, and scaling means that the output of a linear system due to a scaled input signal is the same as the scaled output due to the original input signal.*

Example 2. Consider two inputs $x_1(t)$ and $x_2(t)$ to a linear system producing outputs $y_1(t) = H[x_1(t)]$ and $y_2(t) = H[x_2(t)]$, where H is some transformation function.

A linear transformation must satisfy:

$$y_{total} = \alpha y_1(t) + \beta y_2(t) = H[\alpha x_1(t) + \beta x_2(t)],$$

where α and β are constants.

Example 3 (Superposition).

$$H[x_1(t) + x_2(t)] = H[x_1(t)] + H[x_2(t)]$$

Example 4 (Scaling).

$$H[\alpha x(t)] = \alpha H[x(t)]$$

3.5 Electric Charge

Definition 8. Charge is a fundamental physical property that comes in two types: positive (+) and negative (-) (which cancel). Positive and negative charge are usually present in matter in exactly equal proportion (so matter is typically electrically neutral). Charge is conserved—can neither be created nor destroyed and is quantized in units of electronic charge $e = 1.6 \times 10^{-19} C$.

3.6 Current flow

Definition 9 (Electric Current). Charge per unit time passing a given point in a circuit.

Definition 10 (Current Flow). The flow of electrons through a wire driven by an electric field potential energy difference. Defined as the rate of charge past a point in a circuit:

$$I[\text{ampere}] = \frac{Q[\text{coulomb}]}{\text{time}[{\text{seconds}}]}$$

Definition 11 (Voltage). The electric potential energy divided by the charge. It is the energy per unit charge.

$$V[\text{volt}] = \frac{\Delta E_{\text{Electric}}[\text{joule}]}{Q[\text{coulomb}]}$$

Definition 12 (Electron-volt). The energy gained or lost by an electron when it moves through an electric potential difference of one volt, which is a unit of energy equal to the work done on an electron in accelerating it through a potential difference of 1V, equal to 1.6×10^{-19} Joule.

An electron between two charged plates has an electric potential energy given by

$$\Delta E_{\text{Electric}} = q\Delta V$$

which is converted into kinetic energy (KE) when it is ejected from between the plates.

When discussing current in a circuit, we follow the convention that it refers to the direction of the flow of positive charges.

Batteries store chemical energy potential. The cathode is surrounded by positively charged ions, and the anode by negatively charged ions. Electrons travel through a circuit from the anode to the cathode, releasing the stored chemical energy.

3.7 Electric Field & Potential

Charge emits an electric field that exerts a force on other charges. The electric field \vec{E} at a point in space is defined as the force \vec{F} experienced by a small positive test charge q placed at that point, divided by the magnitude of the test charge:

$$\vec{E} = \frac{\vec{F}}{q}$$

It takes work to move a charge against an electric field. The electric potential V at a point in space is defined as the work needed to move a positive test charge W per unit charge:

$$V = \frac{W}{q} = - \int_{\vec{r}_1}^{\vec{r}_2} \vec{E} \cdot d\vec{l}$$

If the electric field is uniform, this simplifies to

$$V = -\vec{E} \cdot \vec{d}$$

where \vec{d} is the displacement vector from point \vec{r}_1 to point \vec{r}_2 .

3.8 Potential & Ground

Definition 13 (Circuit ground). *The reference point in a circuit at which the electric potential is defined to be zero. All voltages V in a circuit are measured relative to this point. The symbol for circuit ground is , and the symbol for chassis ground is .*

Definition 14 (Earth ground). *The earth ground is a possible reference point, which is literally a metal stake or pipe tapped into the soil.*

3.9 Electromotive Force

Definition 15. *Electromotive Force (EMF)¹ is the energy provided per unit charge by a source such as a battery or generator. It is the work done to move a charge through the source, measured in volts (V).*

¹EMF is the total energy per unit charge from a source, while voltage is the potential difference measured across points in a circuit, typically less than the EMF due to internal resistance in real sources.

To better understand the concept of EMF, consider the following analogy: EMF is like a voltage credit that is then all spent by dropping it over the elements of the circuit. Think of your checking account with two columns: credit (money in) and debit (money spent). EMF is like the "credit" that is then all "spent" by dropping it over the elements of the circuit.

3.9.1 Faraday's Law

Theorem 1. *Faraday's Law states that a changing magnetic flux through a closed loop induces an electromotive force (EMF) in the loop. Mathematically, it is expressed as:*

$$\mathcal{E}_{EMF} = -\frac{d\Phi_B}{dt}$$

where \mathcal{E}_{EMF} is the induced EMF, and Φ_B is the magnetic flux through a wire loop, defined as:

$$\Phi_B = \int B \cdot da$$

3.10 Ohm's Law

Definition 16. *Ohm's Law states that the current I flowing through a conductor is directly proportional to the voltage V across it and inversely proportional to its resistance R . Mathematically, it is expressed as:*

$$I = \frac{V}{R}$$

Microscopically, Ohm's Law can be understood in terms of the motion of electrons in a conductor. When a voltage is applied across a conductor, it creates an electric field that exerts a force on the free electrons, causing them to move and create an electric current. The resistance of the conductor arises from collisions between the electrons and the atoms in the material, which impede their motion. The greater the resistance, the more collisions occur, resulting in a lower current for a given voltage. The current density J is given by Ohm's Law, which states that the current density is proportional to the electric field strength E :

$$J = \sigma E$$

Conversely, the electric field strength is given by the current density and the resistivity of the material:

$$E = J\rho_r$$

The current I is given by the current density and the cross-sectional area of the material:

$$I = AJ = A\sigma E$$

The electric field strength can also be expressed in terms of the potential difference ΔV across the material and its length l :

$$E = \Delta V/l$$

Substituting this into the expression for the current, we obtain:

$$I = \frac{A\sigma\Delta V}{l} = \frac{A\Delta V}{\rho_r l}$$

The potential difference across the material is also given by the resistance R and the current I as stated in Ohm's Law:

$$\Delta V = IR$$

Finally, the resistance can be expressed in terms of the resistivity of the material, the length of the material, and its cross-sectional area:

$$R = \frac{\rho_r l}{A}$$

3.11 Resistors

Definition 17. A resistor is a device that opposes the flow of current through it, resulting in a voltage drop across it. Resistors are characterized by their resistance value R , measured in ohms (Ω), which quantifies the amount of opposition they provide to the flow of current. According to Ohm's Law, the voltage drop V across a resistor is directly proportional to the current I flowing through it:

$$V = IR$$

When resistors are connected in series, their resistances add together to form a total resistance $R_{tot} = R_1 + R_2 + \dots + R_n$. In contrast, when resistors are connected in parallel, their resistances add inversely to form a total resistance $\frac{1}{R_{tot}} = \frac{1}{R_1} + \frac{1}{R_2} + \dots + \frac{1}{R_n}$.

3.11.1 Temperature Dependence

The temperature dependence of the resistance of many metals can be modelled by the following equation:

$$R_T = R_0[1 + \alpha(T - T_0)]$$

where R_0 is the resistance value at reference temperature T_0 , and α is the linear temperature coefficient. This equation shows that the resistance of a metal increases linearly with temperature, which is a common phenomenon observed in many metals.

3.11.2 Power Dissipation

When current flows through a resistor, electrical energy is converted into heat energy due to the resistance of the material. The power P dissipated by a resistor can be calculated using the formula:

$$P = \Delta V \cdot I$$

Using Ohm's Law, we can express the power dissipated in terms of the resistance R and either the voltage drop ΔV or the current I :

$$P = I^2 R = \frac{(\Delta V)^2}{R}$$

- 4 Circuit Theory Beyond Electronic**
- 5 Capacitors & Inductors**
- 6 RC and LR Circuits with AC Driving**
- 7 Impedance**
- 8 RLC Circuits**
 - 8.1 Transient Response**
 - 8.2 Driven RLC Circuits**
 - 8.3 Power Input to RLC and Circuit Network**
- 9 Circuit Networks**
- 10 Fourier Series**
- 11 Fourier Transforms**
- 12 Appendix**
- 13 Useful Links**