	INSTRUCTIONS:																				
	Fill out the hazard analy	sis and risk assessm	ent below.																		
	HA-001 should be for th	e lane denarture warr	ing function as disc	ussed in the lecture																	
	HA-002 should be for th																				
	Then come up with your				I in the HA-003 and H	4.004 rows															
	When finished, export your spreadsheet as a pdf file so that a reviewer can easily see your work.																				
Hazard ID								Hazard Identification						Hazardous Event Classification						ation of ASIL and Safety Goals	
Hazard ID	Situational Analysis Operational Environmental Other Details Item Usage						Deviation Details Havardous Supply Su						Hazarious Event Classification Exposure Rationale Severity Rationale Controllability Rationale						400		
	Operational Mode	Scenario	Details	Situation Details	(optional)	(function)	Situation Description	Function	Deviation	Deviation Details	(resulting effect)	Event Details	Description	(of situation)	(for exposure)	(of potential harm)	(for severity)	(of hazardous event)	(for controllability)	Determination	Safety Goal
HA-001	Normal driving	Highway	Rain	High speed		Correctly used	Normal driving on a highway during rain (slippery road) with high speed and correctly used system	Lane Departure Warning (LDW) function shall apply an oscillating steering torque to provide the driver with haptic feedback		The LDW function aplies an oscillating torque with very high torque (above limit)	vehicle	intended. The driver could lose control of the vehicle and collide with another vehicle or with road infrastructure	wheel (above limit)		The driver is driving on a highway at high speed in a rain, this probably does happen sometimes, so we will label the exposure E3.	S3	Because the driver is traveling at high speed		The malfunction was that the lane departure warning assistance was applying too high an oscillating torque and it affected the driver's ability to steer. Because driver was unable to steer, a vehicle accident would not be controllable.		The oscillating steering torque from the lane departure warning function shall be limited.
HA-002	Normal driving	Country Road	Normal conditions	High speed		Correctly used	Normal driving on country roads during normal conditions with high speed and correctly used system	Assistance (LKA) function shall apply the steering torque when active in order to stay in ego lane	Actor effect is too much	The LKA function applies a steering torque with very high torque (above limit)	vehicle	inteded. The driver could lose control of the vehicle and coolide with another vehicle or with road infrastructure	high a steering torque to the wheel		The driver is on a country road and misusing the system. That combination probably does not happen often, so we will label the exposure E2.	S3	Because the driver is traveling at high speed		The malfunction was that the lane keeping assistance was always on and had no time limit, so drivers could take both hands off the wheel. Because hands aren't on the wheel at high speeds, a vehicle accident would not be controllable.		The lane keeping assistance function shall be time limited and the additional steering torque shall end after a given time interval so that the driver cannot misuse the system for autonomous driving.
HA-003	Normal driving	Mountain pass	Normal conditions	High speed			Normal driving on a mountain pass during normal conditions with high speed and correctly used system	functional shall apply an oscillating steering torque to provide the driver with haptic feedback		The LDW function applies an oscillating torque too frequent (above limit)	vehicle	affect driver's ability to steer as intended. The driver could lose control of the vehicle and collide with another vehicle or with road infrastructure	to the steering wheel (above limit)		The driver is on a mountain pass driving at high speed. This does not happen often, so we will label the exposure E2		Because the driver is traveling at high speed		The malfunction was that the lane departure warning assistance was applying too frequent an oscillating torque and because the vehicle is travelling at high speed it affected the driver's ability to steer. Because driver was unable to steer, a vehicle accident would not be controllable.	ASIL A	The frequency of oscillating steering torque from the lane departure warning function shall be limited.
HA-004	Normal driving	Off road	Fog	Low speed		Correctly used	Normal driving off road during fog conditions with low speed and correctly used system	Lane Keeping Assistance (LKA) function shall apply the steering torque when active in order to stay in ego lane	Actor effect is too less	The LKA function applies a steering toruge with very low torque (below limit)	the road	Low steering torque can not keep the vehicle within the lane. The driver may not respond immediately and the vehicle may comes off the road	The KLA function applies too less a steering torque to the wheel		The driver is driving off road with low speed in a fog weather. This does not happen often, so we will lable the exposure E2.	S1	Because the driver is traveling at low speed	C2	The malfunction was that the lane keepig assistance was applying a too low torque. Because the vehicle was travelling at low speed, the driver may be able to respond and move the vehicle back to the ego lane. Also because the weather is foggy, it may add some delays to the driver's responsiveness. Such	QM	The torque applied by the lane keeping assistance functional shall be limited.