

# **OPC** Unified Architecture

**Specification** 

Part 10: Programs

Version 1.01 Draft

September 30th, 2010

Specification Type	Industry Standard Specification	-	
Title:	OPC Unified Architecture	Date:	September 30th, 2010
	Part 10: Programs	-	
Version:	Draft 1.01 Draft	Software Source:	MS-Word OPC UA Part 10 - Programs 1.01 DRAFT Specification.doc
Author:	OPC Foundation	_Status:	Draft

# **CONTENTS**

				Page
FΟ	REWO	ORD		vii
AG	REEM	IENT O	F USE	vii
1				
2			ocuments	
3			itions, and abbreviations	
3				
	3.1		JA Part 3 terms	
	3.2		JA Program torms	
	3.3	3.3.1	JA Program terms Function	
		3.3.2	Finite State Machine	
		3.3.3	ProgramType	
		3.3.4	Program Control Method	
		3.3.5	Program Invocation	
	3.4			
4			viations and symbols	
4		-		
	4.1		al	
	4.2	•	ams	
		4.2.1	Overview	
		4.2.2	Program Finite State Machine	
		4.2.3	Program States	
		4.2.4	State Transitions	
		4.2.5	Program State Transition Stimuli	
		4.2.6	Program Control Methods	
		4.2.7	Program State Transition Effects	
		4.2.8	Program Result Data	
		4.2.9	Program Lifetime	
5	Mode	el		8
	5.1	Gener	al	8
	5.2	Progra	mType	
		5.2.1	Overview	_
		5.2.2	ProgramType Properties	10
		5.2.3	ProgramType Components	11
		5.2.4	ProgramType Causes (Methods)	15
		5.2.5	ProgramType Effects (Events)	
		5.2.6	ProgramTransitionAuditEventType	18
		5.2.7	FinalResultData	
		5.2.8	ProgramDiagnosticType	19
Anı	nex A	- Progra	am Example	21
	A.1	Overvi	ew	21
	A.2	Domai	nDownload Program	21
		A.2.1	DomainDownload States	21
		A.2.2	DomainDownload Transitions	23
		A.2.3	DomainDownload Methods	23
		A.2.4	DomainDownload Events	23
		A.2.5	DomainDownload Model	24

# **FIGURES**

Figure 1 - Automation Facility Control	3
Figure 2 - Program Illustration	4
Figure 3 - Program States and Transitions	5
Figure 4 - Program Type	9
Figure 5 - Program FSM References	11
Figure 6 - ProgramType Causes and Effects	15
Figure 7 - Program Example 1	21
Figure 8 - DomainDownload State Diagram	22
Figure 9 - DomainDownloadType Partial State Model	28
Figure 10 – Ready To Running Model	30
Figure 11 - Opening To Sending To Closing Model	31
Figure 12 - Running To Suspended Model	33
Figure 13 - Suspended To Running Model	33
Figure 14 - Running To Halted - Aborted Model	34
Figure 15 - Suspended To Aborted Model	35
Figure 16 - Running To Completed Model	36
Figure 17 - Sequence of Operations	37

# **TABLES**

Table 1 - Program Finite State Machine	5
Table 2 - Program States	5
Table 3 - Program State Transitions	6
Table 4 - Program Control Methods	6
Table 5 - ProgramType	10
Table 6 - Program States	12
Table 7 - Program Transitions	13
Table 8 - ProgramType Causes	16
Table 9 - ProgramTransitionEventType	17
Table 10 – ProgramTransitionEvents	18
Table 11 - ProgramTransitionAuditEvent	19
Table 12 - ProgramDiagnosticType	19
Table 13 - DomainDownload States	23
Table 14 - DomainDownload Type	24
Table 15 - Transfer State Machine Type	25
Table 16 - Transfer State Machine - States	26
Table 17 - Finish State Machine Type	26
Table 18 - Finish State Machine - States	26
Table 19 – DomainDownload Type Property Attributes Variable Values	27
Table 20 - Additonal DomainDownload Transition Types	29
Table 21 - Start Method Additions	30
Table 22 - StartArguments	31
Table 23 - Intermediate Results Object	32
Table 24 - Intermediate Result Data Variables	32
Table 25 - Final Result Data	35
Table 26 - Final Result Variables	36

# **OPC FOUNDATION**

### **UNIFIED ARCHITECTURE -**

#### **FOREWORD**

This specification is for developers of OPC UA clients and servers. The specification is a result of an analysis and design process to develop a standard interface to facilitate the development of servers and clients by multiple vendors that shall inter-operate seamlessly together.

Copyright © 2006, 2007 OPC Foundation, Inc.

### **AGREEMENT OF USE**

#### COPYRIGHT RESTRICTIONS

Any unauthorized use of this specification may violate copyright laws, trademark laws, and communications regulations and statutes. This document contains information which is protected by copyright. All Rights Reserved. No part of this work covered by copyright herein may be reproduced or used in any form or by any means--graphic, electronic, or mechanical, including photocopying, recording, taping, or information storage and retrieval systems--without permission of the copyright owner.

OPC Foundation members and non-members are prohibited from copying and redistributing this specification. All copies must be obtained on an individual basis, directly from the OPC Foundation Web site <a href="http://www.opcfoundation.org">http://www.opcfoundation.org</a>.

### **PATENTS**

The attention of adopters is directed to the possibility that compliance with or adoption of OPC specifications may require use of an invention covered by patent rights. OPC shall not be responsible for identifying patents for which a license may be required by any OPC specification, or for conducting legal inquiries into the legal validity or scope of those patents that are brought to its attention. OPC specifications are prospective and advisory only. Prospective users are responsible for protecting themselves against liability for infringement of patents.

### WARRANTY AND LIABILITY DISCLAIMERS

WHILE THIS PUBLICATION IS BELIEVED TO BE ACCURATE, IT IS PROVIDED "AS IS" AND MAY CONTAIN ERRORS OR MISPRINTS. THE OPC FOUDATION MAKES NO WARRANTY OF ANY KIND, EXPRESSED OR IMPLIED, WITH REGARD TO THIS PUBLICATION, INCLUDING BUT NOT LIMITED TO ANY WARRANTY OF TITLE OR OWNERSHIP, IMPLIED WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE OR USE. IN NO EVENT SHALL THE OPC FOUNDATION BE LIABLE FOR ERRORS CONTAINED HEREIN OR FOR DIRECT, INCIDENTAL, SPECIAL, CONSEQUENTIAL, RELIANCE OR COVER DAMAGES, INCLUDING LOSS OF PROFITS, REVENUE, DATA OR USE, INCURRED BY ANY USER OR ANY THIRD PARTY IN CONNECTION WITH THE FURNISHING, PERFORMANCE, OR USE OF THIS MATERIAL, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

The entire risk as to the quality and performance of software developed using this specification is borne by you.

#### RESTRICTED RIGHTS LEGEND

This Specification is provided with Restricted Rights. Use, duplication or disclosure by the U.S. government is subject to restrictions as set forth in (a) this Agreement pursuant to DFARs 227.7202-3(a); (b) subparagraph (c)(1)(i) of the Rights in Technical Data and Computer Software clause at DFARs 252.227-7013; or (c) the Commercial Computer Software Restricted Rights clause at FAR 52.227-19 subdivision (c)(1) and (2), as applicable. Contractor / manufacturer are the OPC Foundation, 16101 N. 82nd Street, Suite 3B, Scottsdale, AZ, 85260-1830

# COMPLIANCE

The OPC Foundation shall at all times be the sole entity that may authorize developers, suppliers and sellers of hardware and software to use certification marks, trademarks or other special designations to indicate compliance with these materials. Products developed using this specification may claim compliance or conformance with this specification if and

only if the software satisfactorily meets the certification requirements set by the OPC Foundation. Products that do not meet these requirements may claim only that the product was based on this specification and must not claim compliance or conformance with this specification.

#### **TRADEMARKS**

Most computer and software brand names have trademarks or registered trademarks. The individual trademarks have not been listed here

# **GENERAL PROVISIONS**

Should any provision of this Agreement be held to be void, invalid, unenforceable or illegal by a court, the validity and enforceability of the other provisions shall not be affected thereby.

This Agreement shall be governed by and construed under the laws of the State of Minnesota, excluding its choice or law rules.

This Agreement embodies the entire understanding between the parties with respect to, and supersedes any prior understanding or agreement (oral or written) relating to, this specification.

#### **ISSUE REPORTING**

The OPC Foundation strives to maintain the highest quality standards for its published specifications, hence they undergo constant review and refinement. Readers are encouraged to report any issues and view any existing errata here: http://www.opcfoundation.org/errata

### 1 Scope

This specification specifies the standard representation of *Programs* as part of the OPC Unified Architecture and its defined information model. This includes the description of the *NodeClasses*, standard *Properties*, *Methods* and *Events* and associated behaviour and information for *Programs*.

The complete address space model including all *NodeClasses* and *Attributes* is specified in [UA Part 3]. The services such as those used to invoke the *Methods* used to manage Programs are specified in [UA Part 4].

#### 2 Reference documents

- [UA Part 1] OPC UA Specification: Part 1 Concepts, Version 1.0 or later http://www.opcfoundation.org/UA/Part1/
- [UA Part 3] OPC UA Specification: Part 3 Address Space Model, Version 1.0 or later http://www.opcfoundation.org/UA/Part3/
- [UA Part 4] OPC UA Specification: Part 4 Services, Version 1.0 or later http://www.opcfoundation.org/UA/Part4/
- [UA Part 5] OPC UA Specification: Part 5 Information Model, Version 1.1 or later http://www.opcfoundation.org/UA/Part5/
- [UA Part 7] OPC UA Specification: Part 7 Profiles, Version 1.0 or later http://www.opcfoundation.org/UA/Part7/

### 3 Terms, definitions, and abbreviations

### 3.1 OPC UA Part 1 terms

The following terms defined in [UA Part 1] of this multi-part specification apply.

- 1) EventType
- 2) Information Model
- 3) Method
- 4) Node
- 5) NodeClass
- 6) Notification
- 7) Object
- 8) ObjectInstance
- 9) ObjectType
- 10) Program
- 11) Reference
- 12) ReferenceType
- 13) Service
- 14) Session
- 15) Subscription
- 16) Variable

### 3.2 OPC UA Part 3 terms

The following terms defined in [UA Part 3] apply.

- 1. TypeDefinition Node
- 2. Property
- 3. Variable

### 3.3 OPC UA Program terms

The following terms are defined for UA Programs.

For the purposes of this document the following terms and definitions as well as the terms and definitions given in IEC 62541-1 and IEC 62541-3 apply.

#### 3.3.1 Function

programmatic task performed at a server or device, usually accomplished by computer code execution.

### 3.3.2 Finite State Machine

sequence of states and valid state transitions along with the causes and effects of those state transitions that define the actions of a *Program* in terms of discrete stages.

# 3.3.3 ProgramType

ObjectType Node that represents the type definition of a Program and is a subtype of the FiniteStateMachineType.

### 3.3.4 Program Control Method

*Method* specified by this specification having specific semantics designed for the control of a *Program* by causing a state transition.

### 3.3.5 Program Invocation

unique Object instance of a Program existing on a Server.

Note The Program Invocation is distinguished from other Object instances of the same ProgramType by the object node's unique browse path.

### 3.4 Abbreviations and symbols

API Application Programming Interface

DA Data Access

FSM Finite State Machine
HMI Human Machine Interfaces
PCM Program Control Method

PGM Program

PI Program Invocation

PLC Programmable Logic Controller

UA Unified Architecture

UML Unified Modelling Language

### 4 Concepts

#### 4.1 General

Integrated automation facilities manage their operations through the exchange of data and coordinated invocation of system functions like illustrated in Figure 1. Services are required to perform the data exchanges and to invoke the functions that constitute system operation. These functions may be invoked through human machine interfaces, cell controllers, or other supervisory control and data acquisition type systems. OPC UA defines Methods and Programs as an interoperable way to advertise, discover, and request these functions. They provide a normalizing mechanism for the semantic description, invocation of, and result reporting of these functions. Together Methods and Programs complement the other OPC UA Services and ObjectTypes to facilitate the operation of an automation environment using a client server hierarchy.




Figure 1 - Automation Facility Control

Methods and Programs model functions typically having different scopes, behaviours, lifetimes, and complexities in OPC Servers and the underlying systems. These functions are **not** normally characterized by the reading or writing of data which is accomplished with the OPC UA Attribute service set.

Methods represent basic functions in the server that can be invoked by a client. Programs by contrast, model more complex, stateful functionality in the system. For example, a method call may be used to perform a calculation or reset a counter. A Program is used to run and control a batch process, execute a machine tool part program, or manage a domain download. Methods and their invocation mechanism are described in [UA Part 3] – Address Space Model and [UA Part 4] - Services. This specification describes the extensions to, or specific use of the core capabilities defined in the first seven parts of the OPC UA multi-part specification required for Programs. Support for the feature described in this specification are described in [UA Part 7] - Profiles

# 4.2 Programs

# 4.2.1 Overview

*Programs* are complex functions in a server or underlying system that can be invoked and managed by an OPC *UA Client*. *Programs* can represent any level of functionality within a system or process in which client control or intervention is required and progress monitoring is desired. Figure 2 illustrates the model.




Figure 2 - Program Illustration

*Programs* are state full, transitioning through a prescribed sequence of states as they execute. Their behaviour is defined by a *Program Finite State Machine (PFSM)*. The elements of the PFSM describe the phases of a *Program's* execution in terms of valid transitions between a set of states, the stimuli or causes of those transitions, and the resultant effects of the transitions.

# 4.2.2 Program Finite State Machine

The states, transitions, causes and effects that compose the Program Finite State Machine are listed in Error! Reference source not found. and illustrated in Error! Reference source not found.

No.	Transition Name	Cause	From State	To State	Effect
1	HaltedToReady	Reset Method	Halted	Ready	Report Transition 1 Event/Result
2	ReadyToRunning	Start Method	Ready	Running	Report Transition 2 Event/Result
3	RunningToHalted	Halt Method or Internal (Error)	Running	Halted	Report Transition 3 Event/Result
4	RunningToReady	Internal	Running	Ready	Report Transition 4 Event/Result
5	RunningToSuspended	Suspend Method	Running	Suspended	Report Transition 5 Event/Result
6	SuspendedToRunning	Resume Method	Suspended	Running	Report Transition 6 Event/Result
7	SuspendedToHalted	Halt Method	Suspended	Halted	Report Transition 7 Event/Result
8	SuspendedToReady	Internal	Suspended	Ready	Report Transition 8 Event/Result
9	ReadyToHalted	Halt Method	Ready	Halted	Report Transition 9 Event/Result

Table 1 - Program Finite State Machine




Figure 3 - Program States and Transitions

### 4.2.3 Program States

A standard set of base states are defined for *Programs* as part of the *Program Finite State Machine*. These states represent the stages in which a *Program* can exist at an instance in time as viewed by a client. This state is the *Program's Current State*. All *Programs* must support this base set. A *Program* may or may not require a client action to cause the state to change. The states are formally defined in Table 2.

**Table 2 - Program States** 

State	Description			
Ready	The <i>Program</i> is properly initialized and may be started.			
Running	The <i>Program</i> is executing making progress towards completion.			
Suspended	The <i>Program</i> has been stopped prior to reaching a terminal state but may be resumed.			
Halted	The <i>Program</i> is in a terminal or failed state, and it cannot be started or resumed without being reset.			

The set of states defined to describe a *Program* can be expanded. Program sub states can be defined for the base states to provide more resolution to the process and to describe the cause and effects of additional stimuli and transitions. Standards bodies and industry groups may extend the base *Program Finite State Model* to conform to industry models. For example, the Halted state can

include the sub states "Aborted" and "Completed" to indicate if the function achieved a successful conclusion prior to the transition to Halted. Transitional states such as "Starting" or "Suspending" might also be extensions of the running state, for example.

### 4.2.4 State Transitions

A standard set of state transitions is defined for the *Program Finite State Machine*. These transitions define the valid changes to the *Program's* current state in terms of an initial state and a resultant state. The transitions are formally defined in Table 3.

Transition No. **Transition Name Initial State Resultant State** HaltedToReady Halted Ready ReadyToRunning Ready 2 Running 3 RunningToHalted Running Halted RunningToReady 4 Running Ready 5 RunningToSuspended Running Suspended Suspended 6 SuspendedToRunning Running 7 SuspendedToHalted Suspended Halted SuspendedToReady 8 Suspended Ready ReadyToHalted Ready Halted

**Table 3 - Program State Transitions** 

### 4.2.5 Program State Transition Stimuli

The stimuli or causes for a *Program's* state transitions can be internal to the *Server* or external. Completion of machining steps, the detection of an alarm condition, or the transmission of a data a packet are examples of internal stimuli. *Methods* are an example of external stimuli. Standard Methods are defined which act as stimuli for the control of a *Program*.

### 4.2.6 Program Control Methods

Clients manage a *Program* by calling *Methods*. The *Methods* impact a *Program*'s behaviour by causing specified state transitions. The state transitions dictate the action's performed by the *Program*. This specification defines a set of standard *Program Control Methods*. These *Methods* provide sufficient means for a client to run a *Program*.

Table 4 lists the set of defined *Program Control Methods*. Each *Method* causes transitions from specified states and must be called when the *Program* is in one of those states.

Individual *Programs* can optionally support any subset of the *Program Control Methods*. For example, some *Programs* may not be permitted to suspend and so would not provide the *Suspend* and *Resume Methods*.

*Programs* can support additional user defined *Methods*. User defined *Methods* must not change the behaviour of the base *Program Finite State Machine*.

Table 4 - Program Control Methods

Method Name	Description
Start	Causes the Program to transition from the Ready state to the Running state.
Suspend	Causes the Program to transition from the Running state to the Suspended state.
Resume	Causes the Program to transition from the Suspended state to the Running state.
Halt	Causes the Program to transition from the Ready, Running or Suspended state to the Halted state.
Reset	Causes the Program to transition from the Halted state to the Ready state.

*Program Control Methods* can include arguments that are used by the *Program.* For example, a Start method may include an options argument that specifies dynamic options used to determine some program behaviour. The arguments can differ on each *ProgramType*. The Method Call service

specified in [UA Part 4] defines a return status. This return status indicates the success of the *Program Control Method* or a reason for its failure.

### 4.2.7 Program State Transition Effects

A *Program*'s state transition generally has a cause and also yields an effect. The effect is a by product of a *Program* state transition that can be used by a *Client* to monitor the progress of the *Program*. Effects can be internal or external. An external effect of a state transition is the generation of an event notification. Each *Program* state transition is associated with a unique event. These events reflect the progression and trajectory of the *Program* through its set of defined states. The internal effects of a state transition can be the performance of some programmatic action such as the generation of data.

### 4.2.8 Program Result Data

#### 4.2.8.1 Overview

Result data is generated by a running *Program*. The result data can be intermediate or final. Result data may be associated with specific *Program* state transitions.

### 4.2.8.2 Intermediate Result Data

Intermediate result data is transient and is generated by the *Program* in conjunction with non-terminal state transitions. The data items that compose the intermediate results are defined in association with specific *Program* state transitions. Their values are relevant only at the transition.

Each *Program* state transition can be associated with different result data items. Alternately, a set of transitions can share a result data item. Percentage complete is an example of intermediate result data. The value of percentage complete is produced when the state transition occurs and is available to the client.

Clients acquire intermediate result data by subscribing to *Program* state transition events. The events specify the data items for each transition. When the transition occurs, the generated event conveys the result data values captured to the subscribed clients. If no *Client* is monitoring the *Program*, intermediate result data may be discarded.

### 4.2.8.3 Terminal Result Data

Terminal result data is the final data generated by the *Program* as it ceases execution. Total execution time, number of widgets produced, and fault condition encountered are examples of terminal result data. When the *Program* enters the terminal state, this result data can be conveyed to the client by the transition event. Terminal result data is also available within the *Program* to be read by a client after the program stops. This data persists until the program instance is rerun or deleted.

### 4.2.8.4 Monitoring Programs

Clients can monitor the activities associated with a *Program's* execution. These activities include the invocation of the management methods, the generation of result data, and the progression of the *Program* through its states. Audit Events are provided for *Method Calls* and state transitions. These events allow a record to be maintained of the clients that interacted with any Program and the Program state transitions that resulted from that interaction.

### 4.2.9 Program Lifetime

#### 4.2.9.1 Overview

*Programs* can have different lifetimes. Some programs may always be present on a *Server* while others are created and removed. Creation and removal can be controlled by a *Client* or may be restricted to local means.

A Program can be *Client* creatable. If a *Program* is client creatable, then the *Client* can add the *Program* to the server. The *Object Create Method* defined in [UA Part 3] is used to create the *Program* Instance. The initial state of the *Program* can be *Halted* or *Ready*. Some Programs, for example, may require that a resource becomes available after its creation, before it is ready to run. In this case, it would be initialized in the *Halted* state and transition to Ready when the resource is delivered.

A Program can be Client removable. If the *Program* is client removable, then the *Client* can delete the *Program* Instance from the *Server*. The *Object DeleteNode Service* defined in [UA Part 4] is used to remove the *Program* Instance. The *Program* must be in a *Halted* state to be removed. A *Program* may also be auto removable. An auto removable *Program* deletes itself when execution has terminated.

# 4.2.9.2 Program Instances

Programs can be multiple instanced or single instanced. A Server can support multiple instances of a Program if these Program instances can be run in parallel. For example, the Program may define a Start Method that has an input argument to specify which resource is acted upon by its functions. Each instance of the Program is then started designating use of different resources. The Client can discover all instances of a Program that are running on a Server. Each instance of a Program is uniquely identified on the Server and is managed independently by the Client.

# 4.2.9.3 Program Recycling

Programs can be run once or run multiple times (recycled). A program that is run once will remain in the *Halted state* indefinitely once it has run. The normal course of action would be to delete it following the inspection of its terminal results.

Recyclable *Programs* may have a limited or unlimited cycle count. These *Programs* may require a reset step to transition from the *Halted* state to the *Ready* state. This allows for replenishing resources or reinitializing parameters prior to restarting the *Program*. The *Program Control Method* "Reset" triggers this state transition and any associated actions or effects.

### 5 Model

#### 5.1 General

The Program Model extends the FiniteStateMachineType and basic ObjectType Models presented in [UA Part 5]. Each Program has a type definition that is the subtype of the FiniteStateMachineType. The ProgramType describes the Finite State Machine model supported by any Program Invocation of that type. The ProgramType also defines the property set that characterize specific aspects of that Program's behaviour such as lifetime and recycling as well as specifying the result data that is produced by the Program.




Figure 4 - Program Type

The base *ProgramType* defines the standard *Finite State Machine* specified for all *Programs*. This includes the states, transitions, transition causes (*Methods*) and effects (Events). Subtypes of the base *ProgramType* can be defined to extend or more specifically characterize the behaviour of an individual Program as illustrated with "MyProgramType" in Figure 4.

# 5.2 ProgramType

### 5.2.1 Overview

The additional properties and components that compose the *ProgramType* are listed in Table 5. No *ProgramType* specific semantics are assigned to the other base *ObjectType* or *FiniteStateMachineType Attributes* or *Properties*.

Table 5 - ProgramType

Attribute	Value						
	Includes all attributes specified for the FiniteStateMachineType						
BrowseName	ProgramType						
IsAbstract	False						
References	NodeClass	BrowseName	Data	TypeDefinition	Modelling Rule		
HasProperty	Variable	Creatable	Type Boolean	PropertyType	Rule		
HasProperty	Variable	Deletabe	Boolean	PropertyType PropertyType	Mandatory		
HasProperty	Variable	AutoDelete	Boolean	PropertyType	Mandatory		
HasProperty	Variable	RecycleCount	Int32	PropertyType			
	Variable	InstanceCount	UInt32		Mandatory		
HasProperty				PropertyType			
HasProperty	Variable	MaxInstanceCount	UInt32	PropertyType			
HasProperty	Variable	MaxRecycleCount	UInt32	PropertyType			
HasComponent	Variable	ProgramDiagnostic		ProgramDiagnosticType	Optional		
HasComponent	Object	Halted		StateType	Mandatory		
HasComponent	Object	Ready		StateType	Mandatory		
HasComponent	Object	Running		StateType	Mandatory		
HasComponent	Object	Suspended		StateType	Mandatory		
riascomponent	Object	Caopenaca		ClateType	Wandatory		
HasComponent	Object	HaltedToReady		TransitionType	Mandatory		
HasComponent	Object	ReadyToRunning		TransitionType	Mandatory		
HasComponent	Object	RunningToHalted		TransitionType	Mandatory		
HasComponent	Object	RunningToReady		TransitionType	Mandatory		
HasComponent .	Object	RunningToSuspended		TransitionType	Mandatory		
HasComponent	Object	SuspendedToRunning		TransitionType	Mandatory		
HasComponent	Object	SuspendedToHalted		TransitionType	Mandatory		
HasComponent	Object	SuspendedToReady		TransitionType	Mandatory		
HasComponent	Object	ReadyToHalted		TransitionType	Mandatory		
HasComponent	Method	Start			Optional		
HasComponent	Method	Suspend			Optional		
HasComponent	Method	Reset			Optional		
HasComponent	Method	Halt			Optional		
HasComponent	Method	Resume			Optional		
LlooCompany :	Ohioat	Final Decult Date		Page Object Trimes	Onticasi		
HasComponent	Object	FinalResultData		BaseObjectType	Optional		

### 5.2.2 ProgramType Properties

The Creatable Property is a Boolean that specifies if Program Invocations of this ProgramType can be created by an Client. If False, these Program Invocations are persistent or may only be created by the server.

The *Deletable Property* is a Boolean that specifies if a *Program Invocation* of this *ProgramType* can be deleted by an *Client*. If False, these *Program Invocations* can only be deleted by the server.

The AutoDelete Property is a Boolean that specifies if Program Invocations of this ProgramType are removed by the Server when execution terminates. If False, these Program Invocations persist on the server until they are deleted by the Client. When the Program Invocation is deleted, any result data associated with the instance is also removed.

The RecycleCount Property is an unsigned integer that specifies the number of times a Program Invocation of this type has been recycled or restarted from its starting point (not resumed). Note: The Reset Method may be required to prepare a Program to be restarted.

The MaxRecycleCount Property is an integer that specifies the maximum number of times a Program Invocation of this type can be recycled or restarted from its starting point (not resumed). If

the value is less than 0, there is no limit to the number of restarts. If the value is zero, the Program may not be recycled or restarted.

The InstanceCount Property is an unsigned integer that specifies the number of Program Invocations of this type that currently exist.

The MaxInstanceCount Property is an integer that specifies the maximum number of Program Invocations of this type that can exist simultaneously on this Server. If the value is less than 0, there is no limit.

### 5.2.3 ProgramType Components

#### 5.2.3.1 Overview

The *ProgramType Components* consists of a set of references to the object instances of *StateTypes*, *TransitionTypes*, *EventTypes* and the *Methods* that collectively define the *Program FiniteStateMachine*.




Figure 5 - Program FSM References

Figure 5 illustrates the *Component References* that define the associations between two of the *ProgramType's* states, *Ready* and *Running*. The complementary ReferenceTypes have been omitted to simplify the illustration.

### 5.2.3.2 ProgramType States

Table 6 specifies the *ProgramType's* State *Objects*. These State *Objects* are instances of the *StateType* defined in [UA Part 5] - SM Appendix. Each State is assigned a unique *StateNumber* value. Subtypes of the *ProgramType* can add references from any state to a subordinate or nested *StateMachine Object* to extend the *FinitStateMachine*.

**BrowseName** References Target BrowseName Value **Target TypeDefinition Notes** States Halted HasProperty StateNumber PropertyType ToTransition HaltedToReady TransitionType FromTransition RunningToHalted TransitionType FromTransition SuspendedToHalted TransitionType ReadyToHalted TransitionType FromTransition Ready HasProperty StateNumber 2 PropertyType HaltedToReady FromTransition TransitionType TransitionType ToTransition ReadyToRunning FromTransition RunningToReady TransitionType ToTransition ReadyToHalted TransitionType StateNumber HasProperty 3 PropertyType Running ToTransition RunningToHalted TransitionType ToTransition RunningToReady TransitionType TransitionType ToTransition RunningToSuspended FromTransition ReadyToRunning TransitionType FromTransition SuspendedToRunning TransitionType Suspended HasProperty StateNumber 4 PropertyType SuspendedToRunning TransitionType ToTransition ToTransition SuspendedToHalted TransitionType SuspendedToReady ToTransition TransitionType FromTransition RunningToSuspended TransitionType

**Table 6 - Program States** 

The Halted state is the idle state for a *Program*. It can be an initial state or a terminal state. As an initial state, the Program Invocation can not yet begin execution due to conditions at the server. As a terminal state, *Halted* can indicate either a failed or completed *Program*. A subordinate state or result can be used to distinguish the nature of the termination. The *Halted* state references four *Transition Objects*, which identify the allowed state transitions to the *Ready* state and from the *Ready*, *Running*, and *Suspended* States.

The *Ready* state indicates that the *Program* is prepared begin execution. *Programs* that are ready to begin upon their creation may transition immediately to the *Ready* State. The Ready state references four *Transition Objects*, which identify the allowed state transitions to the *Running* and *Halted* states and from the *Halted* and *Ready* states.

The Running state indicates that the *Program* is actively performing its function. The Running state references five *Transition Objects*, which identify the allowed state transitions to the *Halted*, *Ready*, and *Suspended* states and from the *Ready* and *Suspended* States.

The Suspended state indicates that the Program has stopped performing its function, but retains the ability to resume the function at the point at which it was executing when suspended. The Suspended state references four Transition Objects, which identify the allowed state transitions to the Ready, Running, and Halted state and from the Readystate.

### 5.2.3.3 ProgramType Transitions

ProgramType Transitions are instances of the TransitionType defined in [UA Part 5] — B.4 Representation of state machines in the AddressSpace which also includes the definitions of the ToState, FromState, HasCause, and HasEffect references used. Table 7 specifies the Transitions defined for the ProgramType. Each Transition is assigned a unique TransitionNumber. The Notes column indicates when a cause is referencing a methods and when effects are optional.

**Table 7 - Program Transitions** 

BrowseName	References	Target BrowseName	Value	Target TypeDefinition	Notes
Transitions		•	II.		1
HaltedToReady	HasProperty	TransitionNumber	1	PropertyType	
	ToState	Ready		StateType	
	FromState	Halted		StateType	
	HasCause	Reset			Method
	HasEffect	ProgramTransitionEventType			
	HasEffect	ProgramTransitionAuditEventType			Optional
ReadyToRunning	HasProperty	TransitionNumber	2	PropertyType	
	ToState	Running		StateType	
	FromState	Ready		StateType	
	HasCause	Start			Method
	HasEffect	ProgramTransitionEventType			
	HasEffect	ProgramTransitionAuditEventType			Optional
RunningToHalted	HasProperty	TransitionNumber	3	PropertyType	
Training For latted	ToState	Halted	1	StateType	
	FromState	Running		StateType	
	HasCause	Halt		Otato i ypo	Method
	HasEffect	ProgramTransitionEventType			Motrica
	HasEffect	ProgramTransitionAuditEventType			Optional
		· regrammanetuanizvem.vype			0 0 11 0 11 0 11
RunningToReady	HasProperty	TransitionNumber	4	PropertyType	
· · ·	ToState	Ready		StateType	
	FromState	Runnning		StateType	
	HasEffect	ProgramTransitionEventType			
	HasEffect	ProgramTransitionAuditEventType			Optional
DunningToCuppended	HasProperty	TransitionNumber	5	PropertyType	
RunningToSuspended	ToState	Running	3	StateType	
	FromState	Suspended		StateType	
	HasCause	Suspend		State Type	Method
	HasEffect	ProgramTransitionEventType			Wicthod
	HasEffect	ProgramTransitionAuditEventType			Optional
		, , , , , , , , , , , , , , , , , , ,			
SuspendedToRunning	HasProperty	TransitionNumber	6	PropertyType	
	ToState	Running		StateType	
	FromState	Suspended		StateType	
	HasCause	Resume			Method
	HasEffect	ProgramTransitionEventType			
	HasEffect	ProgramTransitionAuditEventType	-		Optional
SuspendedToHalted	HasProperty	TransitionNumber	7	PropertyType	
·	ToState	Halted		StateType	
	FromState	Suspended		StateType	
	HasCause	Halt			Method
	HasEffect	ProgramTransitionEventType			
	HasEffect	ProgramTransitionAuditEventType			Optional
SuspendedToReady	HacDronorty	TransitionNumber	8	PropertyType	
ouspendedToReady	HasProperty ToState	Ready	0	PropertyType StateType	+
	FromState	Suspended	+	StateType	1
	HasCause	Reset	+	State Type	Method
	HasEffect	ProgramTransitionEventType			
	HasEffect	ProgramTransitionAuditEventType			Optional
ReadyToHalted	HasProperty	TransitionNumber	9	PropertyType	
	ToState	Halted		StateType	+
	FromState	Ready	1	StateType	Mother
	HasCause HasEffect	Halt ProgramTransitionEventType			Method
	⊓as⊑nect	ProgramTransitionEventType	1	1	1

The HaltedToReady transition specifies the Transition from the Halted to Ready States. It may be caused by the Reset Method.

The ReadyToRunning transition specifies the Transition from the Ready to Running States. It is caused by the Start Method.

The RunningToHalted transition specifies the Transition from the Running to Halted States. It is caused by the Halt Method.

The RunningToReady transition specifies the Transition from the Running to Ready States. The RunningToSuspended transition specifies the Transition from the Running to Suspended States. It is caused by the Suspend Method.

The SuspendedToRunning transition specifies the Transition from the Suspended to Running States. It is caused by the Resume Method.

The SuspendedToHalted transition specifies the Transition from the Suspended to Halted States. It is caused by the Halt Method.

The SuspendedToReady transition specifies the Transition from the Suspended to Ready States. It is caused internally.

The ReadyToHalted transition specifies the Transition from the Ready to Halted States. It is caused by the Halt Method.

Two HasEffect references are specified for each Program Transition. These effects are events of type ProgramTransitionEventType and ProgramTransitionAuditEventType defined in Table 10. The ProgramTransitionEventType notifies Clients of the Program Transition and conveys result data. The ProgramTransitionAuditEventType can optionally be used to audit transitions that result from Program Control Methods.




Figure 6 - ProgramType Causes and Effects

# 5.2.4 ProgramType Causes (Methods)

### **5.2.4.1 Overview**

The *ProgramType* includes references to the *Causes* of specific *Program* state transitions. These causes refer to *Method* instances. *Programs* that do not support a *Program Control Method*, omit the *Causes* reference to that *Method* from the *ProgramType* references. If a *Method's Causes* reference is omitted from the *ProgramType*, a *Client* cannot cause the associated state transition. The Method instances referenced by the ProgramType identify the InputArguments and OutputArguments required for the Method calls to Program Invocations of that ProgramType. Table 8 specifies the *Methods defined as Causes for ProgramTypes*. Figure 6 illustrates the references associating the components and properties of Methods and Events with *ProgramTransitions*.

Table	8 -	<b>ProgramType</b>	Causes
-------	-----	--------------------	--------

BrowseName	References	Target BrowseName	Value	Target TypeDefinition	Notes
Causes		•	•		
Start	HasProperty	InputArguments		PropertyType	Optional
	HasProperty	OutputArguments		PropertyType	Optional
Suspend	HasProperty	InputArguments		PropertyType	Optional
	HasProperty	OutputArguments		PropertyType	Optional
Resume	HasProperty	InputArguments		PropertyType	Optional
	HasProperty	OutputArguments		PropertyType	Optional
Halt	HasProperty	InputArguments		PropertyType	Optional
	HasProperty	OutputArguments		PropertyType	Optional
Reset	HasProperty	InputArguments		PropertyType	Optional
·	HasProperty	OutputArguments		PropertyType	Optional

The Start Method causes the ReadyToRunning Program transition.

The Suspend Method causes the RunningToSuspended Program transition.

The Resume Method causes the SuspendedToRunning Program transition.

The Halt Method causes the RunningToHalted, SuspendedToHalted, or ReadyToHalted Program transition depending on the CurrentState of the Program.

The Reset Method causes the HaltedToReady Program transition.

### 5.2.4.2 Standard Attributes

The Executable Method attribute indicates if a method can currently be executed. For Program Control Methods, this means that the owning Program has a CurrentState that supports the transition caused by the Method.

#### 5.2.4.3 Standard Properties

### 5.2.4.3.1 Overview

Methods can reference a set of InputArguments. For each ProgramType, a set of InputArguments may be defined for the supported Program Control Methods. The data passed in the arguments supplements the information required by the Program to perform its function. All calls to a Program Control Method for each Program Invocation of that ProgramType must pass the specified arguments.

Methods can reference a set of OutputArguments. For each ProgramType, a set of OutputArguments is defined for the supported Program Control Methods. All calls to a Program Control Method for each Program Invocation of that ProgramType must pass the specified arguments.

# 5.2.5 ProgramType Effects (Events)

### **5.2.5.1 Overview**

The *ProgramType* includes component references to the *Effects* of each of the *Program's* state transitions. These *Effects* are *Events*. Each *Transition* must have a *HasEffect* reference to a *ProgramTransitionEventType* and can have a *ProgramTransitionAuditEventType*. When the transition occurs, event notifications of the referenced type are generated for subscribed *Clients*.

The Program Invocation may serve as the *EventNotifier* for these events or an owning object or the *Server Object* may provide the notifications.

ProgramTransitionEventTypes provide the means for delivering result data and confirming state transitions for subscribed Clients on each defined Program State Transition. ProgramTransitionAuditEventTypes allows the auditing of changes to the Program's State in conjunction with auditing client Method Calls.

### 5.2.5.2 ProgramTransitionEventType

The ProgramTransitionEventType is a subtype of the TransitionEventType. It is used with Programs to acquire intermediate or final results or other data associated with a state transition. A Program can have a unique ProgramTransitionEventType definition for any transition. Each ProgramTransitionEventType specifies the IntermediateResult data specific to the designated state transition on that program type. Each transition can yield different Intermediate result data. Table 9 specifies the ProgramTransitionEventType. Table 10 identifies the ProgramTransitionEventTypes that are specified for ProgramTypes.

Table 9 - ProgramTransitionEventType

Attribute	Value	Value					
BrowseName	ProgramTrans	ProgramTransitionEventType					
IsAbstract	True	True					
References	NodeClass	NodeClass BrowseName DataType TypeDefinition ModellingRule					
Inherits the Properties of the base TransitionEventType defined in [UA Part 5] B4.16 TransitionEventType.							
HasComponent	Object	IntermediateResult		BaseObjectType	Optional		

Transitionr identifies the Program Transition that triggered the event.

FromState identifies the State before the Program Transition.

ToState identifies the State after the Program Transition.

The *IntermediateResult* is an object that aggregates a set of variables whose values are relevant for the Program at the instant of the associated transition. The *ObjectType* for the *IntermediateResult* specifies the collection of variables using a set of *HasComponent* references.

Table 10 - ProgramTransitionEvents

BrowseName	References	Target BrowseName	Value	Target TypeDefinition	Notes
Effects					
HaltedToReadyEvent					
	HasProperty	TransitionNumber	1	PropertyType	
	HasProperty	FromStateNumber	1	PropertyType	
	HasProperty	ToStateNumber	2	PropertyType	
	HasComponent	IntermediateResults		ObjectType	Optional
ReadyToRunningEvent					
rtoady Fortaliinig_vont	HasProperty	TransitionNumber	2	PropertyType	
	HasProperty	FromStateNumber	2	PropertyType	
	HasProperty	ToStateNumber	3	PropertyType	
	HasComponent	IntermediateResults	1	ObjectType	Optional
RunningToHaltedEvent	HasProperty	TransitionNumber	3	PropertyType	
	HasProperty	FromStateNumber	3	PropertyType PropertyType	
	HasProperty	ToStateNumber	1	PropertyType	
	HasComponent	IntermediateResults	!	ObjectType	Optional
	- raccomponent			02,001.700	op.io.iai
RunningToReadyEvent					
	HasProperty	TransitionNumber	4	PropertyType	
	HasProperty	FromStateNumber	3	PropertyType	
	HasProperty	ToStateNumber	2	PropertyType	
	HasComponent	IntermediateResults		ObjectType	Optional
RunningToSuspendedEvent					
3 1	HasProperty	TransitionNumber	5	PropertyType	
	HasProperty	FromStateNumber	3	PropertyType	
	HasProperty	ToStateNumber	4	PropertyType	
	HasComponent	IntermediateResults		ObjectType	Optional
Cuppended To Dunning Tyent					
SuspendedToRunningEvent	HaaDranarty	TransitionNumber	6	Droporty/Typo	
	HasProperty	FromStateNumber	6	PropertyType PropertyType	
	HasProperty	ToStateNumber	3		
	HasProperty HasComponent	IntermediateResults	3	PropertyType ObjectType	Optional
	HasComponent	intermediateresuits		ObjectType	Optional
SuspendedToHaltedEvent					
	HasProperty	TransitionNumber	7	PropertyType	
	HasProperty	FromStateNumber	4	PropertyType	
	HasProperty	ToStateNumber	1	PropertyType	
	HasComponent	IntermediateResults		ObjectType	Optional
SuspendedToReadyEvent					
ouspended roncady Everil	HasProperty	TransitionNumber	8	PropertyType	
	HasProperty	FromStateNumber	4	PropertyType	
	HasProperty	ToStateNumber	2	PropertyType	
	HasComponent	IntermediateResults		ObjectType	Optional
ReadyToHaltedEvent	HasProperty	TransitionNumber	9	PropertyType	
	HasProperty	FromStateNumber	2	PropertyType PropertyType	
	HasProperty	ToStateNumber	1	PropertyType	<del>                                     </del>
	HasProperty HasComponent	IntermediateResults	1		Optional
	riascomponent	miennedialeResults		ObjectType	Optional

# 5.2.6 ProgramTransitionAuditEventType

The ProgramTransitionAuditEventType is a subtype of the AuditUpdateStateEventType. This EventType inherits all Properties of the AuditUpdateStateEventType defined in [UA Part 5]. It is used with Programs to provide a means to audit the Program State Transitions associated with any Client invoked Program Control Method. Table 11 specifies the definition of the ProgramTransitionAuditEventType

Table 11 - ProgramTransitionAuditEvent

Attribute	Value							
BrowseName	ProgramTrans	ProgramTransitionAuditEventType						
IsAbstract	True	True						
References	NodeClass	BrowseName	DataType	TypeDefinition	ModellingRule			
Inherits the Prope	Inherits the Properties of the AuditUpdateStateEventType defined in [UA Part 5]							
HasProperty	Variable	TransitionNumber	UInt32	PropertyType	Mandatory			

The Status Property, specified in [UA Part 5] AuditEventType, identifies whether the state transition resulted from a Program Control Method call (set Status to TRUE) or not (set Status to FALSE).

The SourceName specified in [UA Part 5] EventType identifies the Method causing the ProgramTransition when it is the result of a client invoked ProgramControlMethod, The SourceName is prefixed with "Method/" and the name of the ProgramControlMethod, "Method/Start" for example.

The ClientUserId Property, specified in [UA Part 5] AuditEventType, identifies the user of the Client that issued the Program Control Method if it is associated with this Program State Transition.

The ActionTimeStamp Property, specified in [UA Part 5] AuditEventType, identifies when the time the Program State Transition that resulted in the event being generated occurred.

The *TransitionNumber* property is a *Variable* that identifies the Transition that triggered the event.

### 5.2.7 FinalResultData

The FinalResultData ObjectType specifies the VariableTypes that are preserved when the Program has completed its function. The ObjectType includes a HasComponent for a VariableType of each variable that comprises the FinalResultData. The values of the Variables

### 5.2.8 ProgramDiagnosticType

### 5.2.8.1 Overview

The *ProgramDiagnoticType* provides information that can be used to aid in the diagnosis of *Program* problems. This object contains a collection of *Variables* that chronicle the *ProgramInvocation's* activity. Table 12 specifies the *Variables that compose the ProgramDiagnoticType*.

Table 12 - ProgramDiagnosticType

Attribute	Value							
BrowseName	ProgramDiagr	ProgramDiagnosticsType						
IsAbstract	False	False						
References	NodeClass	BrowseName	Modelling Rule					
Subtype of the Ba	seObjectType de	fined in [UA Part 5].						
HasComponent	Variable	CreateSessionId	Nodeld	Mandatory				
HasComponent	Variable	CreateClientName	String	Mandatory				
HasComponent	Variable	InvocationCreationTime	UTCTime	Mandatory				
HasComponent	Variable	LastTransitionTime	UTCTime	Mandatory				
HasComponent	Variable	LastMethodCall	String	Mandatory				
HasComponent	Variable	LastMethodSessionId	Int32	Mandatory				
HasComponent	Variable	LastMethodInputArguments	InputArguments	Mandatory				
HasComponent	Variable	LastMethodOutputArguments	OutputArguments	Mandatory				
HasComponent	Variable	LastMethodCallTime	UTCTime	Mandatory				
HasComponent	Variable	LastMethodReturnStatus	returnStatus	Mandatory				

The *CreateSessionId* contains the *SessionId* of the session on which the call to the *Create Method* was issued to create the Program Invocation.

The CreateClientName is the name of the client of the session that created the Program Invocation.

The InvocationCreationTime identifies the time the Program Invocation was created.

The LastTransitionTime identifies the time of the last program state transition that occurred.

The LastMethodCall identifies the last Program Method called on the Program Invocation.

The LastMethodSessionId contains the SessionId of the session on which the last Program Control Method call to the Program Invocation was issued.

The LastMethodClientName is the name of the client of the session that made the last Method call to the Program Invocation.

The LastMethodInputArguments preserves the values of the input arguments on the last Program Method call.

The LastMethodOutputArguments preserves the values of the output arguments on the last Program Method call.

The LastMethodCallTime identifies the time of the last Method call to the Program Invocation.

The LastMethodReturnStatus preserves the value of the returnStatus for the last Program Control Method requested for this Program Invocation.

# **Annex A - Program Example**

### A.1 Overview

This example illustrates the use of an OPC UA *Program* to manage a domain download into a control system as depicted in Figure 7. The download requires the segmented transfer of control operation data from a secondary storage device to the local memory within a control system.




Figure 7 - Program Example 1

The Domain Download has a source and a target location which are identified when the download is initiated. Each time a segment of the domain is successfully transferred, the client is notified and informed of the amount of data that has been downloaded. The client is also notified when the download is finished. The percentage of the total data received is reported periodically while the download continues. If the download fails, the cause of the failure is reported. At the completion of the download, performance information is persisted at the OPC *UA Server*.

# A.2 DomainDownload Program

The OPC *UA Client* uses the "**DomainDownload**" *Program* to manage and monitor the download of a domain at the OPC UA *Server*.

### A.2.1 DomainDownload States

The basic state model for the DomainDownload *Program* is presented in Figure 8. The *Program* has three primary states, *Ready*, *Running*, and *Halted* which are aligned with the standard states of a *ProgramType*. Additionally, the *DomainDownloadType* extends the OPC *UA ProgramType* by defining subordinate state machines for the *Program's Running* and *Halted* States. The subordinate

states describe the download operations in greater detail and allow the OPC UA *Client* to monitor the activity of the download at a finer resolution.

An instance (Program Invocation) of a DownloadDomain *Program* is created by the client each time a download is to be performed. The instance exists until explicitly removed by the client. The initial state of the *Program* is *Ready* and the terminal state is *Halted*. The DomainDownload can be temporarily suspended and then resumed or aborted. Once halted, the program may not be restarted.




Figure 8 - DomainDownload State Diagram

The sequence of state transitions is illustrated in Figure 8. Once the download is started, The Program progresses to the Opening state. After the source of the data is opened, a sequence of transfers occurs in the Sending state. When the transfer completes the objects are closed in the Closing State. If the transfer is terminated before all of the data is downloaded or an error is encountered, the download is halted, and the Program transitions to the Aborted state, otherwise the programs halts in the Completed state. The states are presented in Figure 9 along with the state transitions.

#### A.2.2 DomainDownload Transitions

The valid state transitions specified for the DomainDownload *Program* and are specified in Table 13. Each of the transitions defines a start state and end state for the transition and is identified by a unique number. Five of the transitions are from the base *ProgramType* and retain the transition identifier numbers specified for *Programs*. The additional transitions relate the base program states with the subordinate states defined for the DomainDownload. These states have been assigned unique transition identifier numbers distinct from the base Program transition identifiers. In cases where transitions occur between substates and the Program's base states, two transitions are specified. One transition identifies the base state change and a second the sub-state change. For example, Ready to Running and to Opening occurs at the same time.

The table also specifies the defined states, causes for the transitions, and the effects of each transition. Program Control Methods are used by the OPC *UA Client* to "run" the DomainDownload. The *Methods* cause or trigger the specified transitions. The transition effects are the specified EventTypes which notify the client of *Program* activity.

No.	Transition Name	Cause	From State	To State	Effect
2	ReadyToRunning	Start Method	Ready	Running	Report Transition 2 Event/Result
3	RunningToHalted	Halt Method/Error or Internal.	Running	Halted	Report Transition 3 Event/Result
5	RunningToSuspended	Suspend Method	Running	Suspended	Report Transition 5 Event/Result
6	SuspendedToRunning	Resume Method	Suspended	Running	Report Transition 6 Event/Result
7	SuspendedToHalted	Halt Method	Suspended	Halted	Report Transition 7 Event/Result
10	OpeningToSending	Internal	Opening	Sending	Report Transition 10 Event/Result
11	SendingToSending	Internal	Sending	Sending	Report Transition 11 Event/Result
12	SendingToClosing	Internal	Sending	Closing	Report Transition 12 Event/Result
13	SendingToAborted	Halt Method/Error	Opening	Aborted	Report Transition 13 Event/Result
14	ClosingToCompleted	Internal	Closing	Completed	Report Transition 14 Event/Result
15	SendingToSuspended	Suspend Method	Sending	Suspended	Report Transition 16 Event/Result
16	SuspendedToSending	Resume Method	Suspended	Sending	Report Transition 17 Event/Result
18	SuspendedToAborted	Halt Method	Suspended	Aborted	Report Transition 18 Event/Result
17	ToOpening	Internal	Ready	Opening	Report Transition 19 Event/Result

Table 13 - DomainDownload States

### A.2.3 DomainDownload Methods

Four standard Program *Methods* are specified for running the DomainDownload *Program, Start, Suspend, Resume, and Halt.* No additional *Methods* are specified. The base behaviours of these methods are defined by the *ProgramType.* The *Start Method* initiates the download activity and passes the source and destination locations for the transfer. The *Suspend Method* is used to pause the activity temporarily. The *Resume Method* reinitiates the download, when paused. The *Halt Method* aborts the download. Each of the methods causes a *Program* state transition and a sub state transition. The specific state transition depends on the current state at the time the *Method* is called. If a *Method Call* is made when the DomainDownload is in a state for which that *Method* has no associated transition, the Method returns an error status indicating invalid state for the method.

### A.2.3.1 Method Arguments

The Start Method specifies three input arguments to be passed when it is called; Domain Name, DomainSource, and DomainDestination. The other Methods require no input arguments. No output arguments are specified for the DomainDownload methods. The resultant error status for the *Program* is part of the *Call* service.

#### A.2.4 DomainDownload Events

A *ProgramTransitionEventType* is specified for each of the DomainDownload *Program* transitions. The event types trigger a specific event notification to the OPC *UA Client* when the associated state transition occurs in the running *Program* instance. The event notification identifies the transition. The SendingToSending state transition also includes intermediate result data.

#### A.2.4.1 Event Information

The SendingToSending program transition event relays intermediate result data to the OPC *UA Client* along with the notification. Each time the transition occurs, data items describing the amount and percentage of data transferred is sent to the OPC *UA Client*.

# A.2.4.2 Final Result Data

The DomainDownload Program retains final result data following a completed or aborted download. The data includes the total transaction time and the size of the domain. In the event of an aborted download, the reason for the termination is retained.

#### A.2.5 DomainDownload Model

#### A.2.5.1 Overview

The OPC UA Model for the DomainDownload.Program is presented in the following tables and figures. Collectively they define the components that constitute this program. For clarity, the figures present a progression of portions of the model that complement the contents of the tables and illustrate the Program's composition.

The type definition for the DomainDownload *Program* precisely represents the behaviour of the program in terms of OPC *UA* components. These components can be browsed by a OPC *UA Client* to interpret or validate the actions of the Program.

### A.2.5.2 DomainDownloadType

The DomainDownloadType is a subtype derived from the OPC *UA ProgramType*. It specifies the use or non-use of optional *ProgramType* components, valid extensions such as subordinate state machines, and constrained attribute values applied to instances of DomainDownload *Programs*.

Table 14 specifies the optional and extended components defined by the DomainDownload Type. Note the references to two sub State Machine Types, TransferStateMachine and FinishStateMachine. The DomainDownloadType omits references to the Reset Program Control Method and its associated state transition (HaltedToReady), which it does not support.

Table 14 - DomainDownload Type

Attribute	Value						
	Includes all non-optional attributes specified for the ProgramType						
BrowseName	DomainDown	loadType					
IsAbstract	False						
References	NodeClass	BrowseName	Data Type	TypeDefinition	Modelling Rule		
HasComponent	Object	TransferStateMachine		StateMachineType	Mandatory		
HasComponent	Object	FinishStateMachine		StateMachineType	Mandatory		
HasComponent	Variable	ProgramDiagnostic		ProgramDiagnosticType	Mandatory		
HasComponent	Object	ReadyToRunning		TransitionType	Mandatory		
HasComponent	Object	RunningToHalted		TransitionType	Mandatory		
HasComponent	Object	RunningToSuspended		TransitionType	Mandatory		
HasComponent	Object	SuspendedToRunning		TransitionType	Mandatory		
HasComponent	Object	SuspendedToHalted		TransitionType	Mandatory		
HasComponent	Method	Start			Mandatory		
HasComponent	Method	Suspend			Mandatory		
HasComponent	Method	Halt			Mandatory		
HasComponent	Method	Resume			Mandatory		
HasComponent	Object	FinalResultData		BaseObjectType	Mandatory		

Table 15 specifies the Transfer State Machine type that is a sub state machine of the DomianDownload Program Type. This State Machine Type definition identifies the State types that compose the sub states for the Program's Running State type.

**Table 15 - Transfer State Machine Type** 

Attribute	Value							
	Includes all at	Includes all attributes specified for the FiniteStateMachineType						
BrowseName	TransferStateMachineType							
IsAbstract	False							
References	NodeClass	BrowseName	Data Type	TypeDefinition	Modelling Rule			
HasComponent	Object	Opening		StateType	Mandatory			
HasComponent	Object	Sending		StateType	Mandatory			
HasComponent	Object	Closing		StateType	Mandatory			
HasComponent	Object	ReadyToOpening		TransitionType	Mandatory			
HasComponent	Object	OpeningToSending		TransitionType	Mandatory			
HasComponent	Object	SendingToClosing		TransitionType	Mandatory			
HasComponent	Object	SendingToAborted		TransitionType	Mandatory			
HasComponent	Object	SendingToSuspended		TransitionType	Mandatory			
HasComponent	Object	SuspendedToSending		TransitionType	Mandatory			
HasComponent	Method	Start			Mandatory			
HasComponent	Method	Suspend			Mandatory			
HasComponent	Method	Halt			Mandatory			
HasComponent	Method	Resume			Mandatory			

Table 16 specifies the *StateTypes* associated with the Transfer State Machine Type. All of these states are sub states of the *Running* state of the base *ProgramType*.

The Opening State is the preparation state for the domain download.

The Sending *State* is the activity state for the transfer in which the data is moved from the source to destination.

The Closing State is the cleanup phase of the download.

Table 16 defines the states of the *TransferStateMachineType*.

**Table 16 - Transfer State Machine - States** 

BrowseName	References	Target BrowseName	Value	Target TypeDefinition	Notes
States		-			
Opening	HasProperty	StateNumber	5	PropertyType	
	ToTransition	OpeningToSending		TransitionType	
	FromTransition	ToOpening		TransitionType	
	ToTransition	OpeningToSending		TransitionType	
Sending	HasProperty	StateNumber	6	PropertyType	
	FromTransition	OpeningToSending		TransitionType	
	ToTransition	SendingToSending		TransitionType	
	ToTransition	SendingToClosing		TransitionType	
	ToTransition	SendingToSuspended		TransitionType	
	FromTransition	ToSending		TransitionType	
Closing	HasProperty	StateNumber	7	PropertyType	
-	ToTransition	ClosingToCompleted		TransitionType	
	ToTransition	ClosingToAborted		TransitionType	
	FromTransition	SendingToClosing		TransitionType	

Table 17 specifies the Finish State Machine type that is a sub state machine of the DomianDownload *ProgramType*. This State Machine Type definition identifies the State types that compose the sub states for the Program's Halted State type.

Table 17 - Finish State Machine Type

Attribute	Value				
	Includes all at	tributes specified for the	e FiniteStateMad	chineType	
BrowseName	TransferState	MachineType			
IsAbstract	False				
References	NodeClass	BrowseName	Data Type	TypeDefinition	Modelling Rule
HasComponent	Object	Completed		StateType	Mandatory
HasComponent	Object	Aborted		StateType	Mandatory

Table 18 pecifies the State Types associated with the Finish State Machine Type. Note these are sfinal states and that they have no associated transitions between them.

Table 18 - Finish State Machine - States

BrowseName	References	Target BrowseName	Value	Target TypeDefinition	Notes
States					
Aborted	HasProperty	StateNumber	8	PropertyType	
	FromTransition	OpeningToAborted		TransitionType	
	FromTransition	ClosingToAborted		TransitionType	
Completed	HasProperty	StateNumber	9	PropertyType	
	FromTransition	ClosingToCompleted		TransitionType	

The Aborted State is the terminal state that indicates an incomplete or failed domain download operation.

The Completed State is the terminal state that indicates a successful domain download.

Table 19 specifies constraining behaviour of a DomainDownload.

Table 19 - DomainDownload Type Property Attributes Variable Values

NodeClass	BrowseName	Data	Data Value	Modelling
		Туре		Rule
Variable	Creatable	Boolean	True	
Variable	Deletabe	Boolean	True	Mandatory
Variable	AutoDelete	Boolean	False	Mandatory
Variable	RecycleCount	Int32	0	Mandatory
Variable	InstanceCount	UInt32	PropertyType	
Variable	MaxInstanceCount	UInt32	500	
Variable	MaxRecycleCount	UInt32	0	

A DomainDownload *Program Invocation* can be created and also destroyed by a OPC *UA Client*. The *Program Invocation* will not delete itself when halted, but will persist until explicitly removed by the OPC *UA Client*. A DomainDownload *Program Invocation* can not be reset to restart. The OPC *UA Server* will support up to 500 concurrent DomainDownload *Program Invocations*.

Figure 9 presents a partial DomainDownloadType model that illustrates the association between the states and the DomainDownload, Transfer, and Finish state machines. Note that the current state number for the sub state machines is only valid when the DomainDownload active base state references the sub state machine, Running for the Transfer current state and Halted for the Finish current state.




Figure 9 - DomainDownloadType Partial State Model

Table 20 specifies the *ProgramTransitionTypes* that are defined in addition to the OPC *UA ProgramTransitonTypes* specified for *Programs* in Table 20. These types associate the Transfer and Finish sub state machine states with the states of the base *Program*.

Table 20 - Additonal DomainDownload Transition Types

BrowseName	References	Target BrowseName	Value	Target TypeDefinition	Notes
Transitions			•		
ToSending	HasProperty	TransitionNumber	10	PropertyType	
	ToState	Sending		StateType	
	FromState	Opening		StateType	
	HasCause	Start			Method
	HasEffect	ProgramTransitionEventType			
SendingToSending	HasProperty	TransitionNumber	11	PropertyType	
	ToState	Sending		StateType	
	FromState	Sending		StateType	
	HasEffect	ProgramTransitionEventType			
SendingToClosing	HasProperty	TransitionNumber	12	PropertyType	
gonanig roomig	ToState	Closing	<u> </u>	StateType	
	FromState	Sending	+	StateType	
	HasEffect	ProgramTransitionEventType		2.0.0.700	
Condinato	LlooDromant.	TransitionNumber	12	Dron orth Tire	
SendingToAborted	HasProperty	TransitionNumber	13	PropertyType StateType	
	ToState	Aborted		StateType	
	FromState	Sending		StateType	
	HasCause	Halt			Method
	HasEffect	ProgramTransitionEventType			
ClosingToCompleted	HasProperty	TransitionNumber	14	PropertyType	
	ToState	Completed		StateType	
	FromState	Closing		StateType	
	HasEffect	ProgramTransitionEventType			
SendingToSuspended	HasProperty	TransitionNumber	15	PropertyType	
ochaing roodopended	ToState	Suspended	10	StateType	
	FromState	Sending		StateType	
	HasCause	Suspend		Ciaio i ypo	Method
	HasEffect	ProgramTransitionEventType			Wictioa
0 1 17 0 1		T	10	D 1.T	
SuspendedToSending	HasProperty	TransitionNumber	16	PropertyType	
	ToState	Sending		StateType	
	FromState	Suspended		StateType	
	HasCause	Resume			Method
	HasEffect	ProgramTransitionEventType			
SuspendedToAborted	HasProperty	TransitionNumber	18	PropertyType	
	ToState	Aborted		StateType	
	FromState	Suspended		StateType	
	HasCause	Halt			Method
	HasEffect	ProgramTransitionEventType			
	HasEffect	ProgramTransitionAuditEventType			Optional
ReadyToOpening	HasProperty	TransitionNumber	17	PropertyType	
	ToState	Opening	† · ·	StateType	
	FromState	Ready	+	StateType	
		Start	+	2.0.01,700	Method
	I Hastause				
	HasCause HasEffect	ProgramTransitionEventType			

Figure 10 through Figure 16 illustrate portions of the DomainDownloadType model. In each figure, the referenced States, Methods, Transitions and EventTypes are identified for one or two state transitions.




Figure 10 - Ready To Running Model

Figure 10 illustrates the model for the ReadyToRunning Program Transition. The transition is caused by the Start Method. The Start Method requires three input arguments. The Method *Call* service is used by the OPC *UA Client* to invoke the *Start Method* and pass the arguments. When successful, the Program Invocation enters the Running State and the subordinate Transfer Opening State. The OPC *UA Server* issues two event notifications, ReadyToRunning (2) and ToOpening (19).

**Table 21 - Start Method Additions** 

Attribute	Value				
BrowseName	Start				
IsAbstract	False				
References	NodeClass	BrowseName	DataType	TypeDefinition	ModellingRule
HasProperty	Variable	InputArgument	Argument[]	PropertyType	

Table 21 specifies that the Start Method for the DomainDownloadType requires input arguments. Table 22 identifies the Start Arguments required.

Name	Туре	Value	
Argument 1	structure		
name	String	SourcePath	
dataType	Nodeld	StringNodeld	
valueRank	Int32	-1 (-1 = scalar)	
arrayDimensions	UInt32[]	null	
description	LocalizedText	The source specifier for the domain.	
Argument 2	structure		
Name	String	DesinationPath	
dataType	Nodeld	StringNodeld	
valueRank	Int32	-1 (-1 = scalar)	
arrayDimensions	UInt32[]	null	
description	LocalizedText	The destination specifier for the domain.	
Argument 3	structure		
name	String	DomainName	
dataType	Nodeld	StringNodeld	
arrayDimensions	UInt32[]	null	
valueRank	Int32	-1 (-1 = scalar)	
description	LocalizedText	The name of the domain.	

Figure 11 illustrates the model for the Opening To Sending and the Sending to Closing Program Transitions. As specified in the transition table, these state transitions require no *Methods* to occur, but rather are driven by the internal actions of the server. Event notifiers are generated for each state transition (10-12), when they occur.




Figure 11 - Opening To Sending To Closing Model

Notice that a state transition can initiate and terminate at the same state (Sending). In this case the transition serves a purpose. The ProgramTransitionEventType effect referenced by the SendingToSending State Transition has an IntermediateResultData object reference. The IntermediateResultData object serves to identify two variables whose values are obtained each time the state transition occurs. The values are sent to the OPC *UA Client* with the event notification. Table 23 defines the IntermediateResults ObjectType and Table 25 defines the variables of the ObjectType.

Table 23 - Intermediate Results Object

Attribute	Value				
	Includes all attr	Includes all attributes specified for the ObjectType			
BrowseName	IntermediateResults				
IsAbstract	False				
References	NodeClass	BrowseName	Data	TypeDefinition	Modelling
			Type		Rule
HasComponent	Variable	AmountTransferred	Long	VariableType	Mandatory
HasComponent	Variable	PercentageTransferred	Long	VariableType	Mandatory

Table 24 - Intermediate Result Data Variables

Intermediate Result Variables	Туре	Value
Variable 1	Structure	
Name	String	AmountTransferred
dataType	Nodeld	StringNodeld
description	LocalizedText	Bytes of domain data transferred.
Variable 2	Structure	
Name	String	PercentageTransferred
dataType	Nodeld	StringNodeld
description	LocalizedText	Percentage of domain data transferred

The model for the Running To Suspended state transition is illustrated in Figure 12. The cause for this transition is the *Suspend Method*. The OPC *UA Client* can pause the download of domain data to the control. The transition from Running to Suspended evokes the event notifiers for Transition Event Types 5 and 16. Note that there is no longer a valid current state for the Transfer State Machine.




Figure 12 - Running To Suspended Model

The model for the Suspended To Running state transition is illustrated in Figure 13. The cause for this transition is the *Resume Method*. The OPC *UA Client* can resume the download of domain data to the control. The transition from Suspended to Running evokes the event notifiers for TransitionEventTypes 6 and 17. Now that the Running state is active, the Sending State of the Transfer State Machine is again specified for the CurrentStateNumber.




Figure 13 - Suspended To Running Model

The model for the Running To Halted state transition for an abnormal termination of the domain download is illustrated in Figure 14. The cause for this transition is the *Halt Method*. The OPC *UA Client* can terminate the download of domain data to the control. The transition from Running To Halted evokes the event notifiers for TransitionEventTypes 3 and 15. The TransitionEventType 15 indicates the transition from the Sending State as the Running State is exited and to the Aborted State as the Halted State is entered.




Figure 14 - Running To Halted - Aborted Model

Figure 15 illustrates the model for the Suspended To Halted state transition for an abnormal termination of the domain download. The cause for this transition is the *Halt Method*. The OPC *UA Client* can terminate the download of domain data to the control while it is suspended. The transition from Suspended To Halted evokes the event notifiers for TransitionEventTypes 7 and 18.




Figure 15 - Suspended To Aborted Model

The model for the Running To Completed state transition for a normal termination of the domain download is illustrated in Figure 16. The cause for this transition is internal. The transition from Closing To Halted evokes the event notifiers for TransitionEventTypes 3 and 14. The TransitionEventType 14 indicates the transition from the Closing State as the Running State is exited and to the Completed State as the Halted State is entered.

The DomainDownloadType includes a component reference to a FInalResultData object. This object references variables that persists information about the domain download once it has completed. This data can be read by OPC UA Clients who are not subscribed to event notifications. The result data is described in Table 25 and the variables in Table 26.

Attribute Value Includes all attributes specified for the ObjectType BrowseName FinalResultData IsAbstract False References NodeClass BrowseName Data **TypeDefinition** Modelling Type Rule Long HasComponent Variable DownloadPerformance VariableType Mandatory HasComponent Variable FailureDetails Mandatory Long VariableType

Table 25 - Final Result Data

The Domain Download net transfer data rate and detailed reason for aborted downloads is retained as final result data for each Program Invocation.

Table	26 -	Final	Result	Variables

Final Result Variables	Туре	Value
Variable 1	Structure	
Name	String	DownloadPerformance
dataType	Nodeld	Double
description	LocalizedText	Data rate for domain data transferred.
Variable 2	Structure	
Name	String	FailureDetails
dataType	Nodeld	StringNodeld
description	LocalizedText	Description of reason for abort.




Figure 16 - Running To Completed Model

# A.2.5.3 Sequence of Operations

Figure 17 illustrates a normal sequence of service exchanges between a OPC *UA Client* and OPC *UA Server* that would occur during the life cycle of a DomainDownloadType *Program Invocation*.




Figure 17 - Sequence of Operations