

MAX32600 EvKit Temperature Sensor Demonstration

April 3, 2015

1 Abstract

The MAX32600 has an external temperature sensor. In this application, we will demonstrate how to set up the real-time clock to generate interrupts every one second; set up AFE(analog front-end) and ADC(analog-to-digital converter) to get ADC samples from external temperature circuit; calculate the external temperature based on eight measurements and display the temperature in Celsius on the terminal emulator through UART.

2 Requirements

- MAX32600B EvKit
- Olimex JTAG ARM-USB-TINY-H
- . GNU ARM toolchain with newlib libc
- . USB Full-size A to B cable
- PC or Workstation with USB and terminal emulator software

3 Setup

On the MAX32600 EvKit, the UART0 device can be configured to connect to an on-board FTDI USB to serial converter for easier connectivity to a standard PC. The onboard FTDI converter is powered from the PC, not the EvKit itself, therefore, the USB to serial connectivity is alway alive without power requirements from the EvKit.

- · Connect your PC to the full-size USB-B port on the EvKit
- Depending on your operating system and drivers you may need to install the FTDI USB to serial driver.
- Open a serial terminal emulator program. On MS Windows, you may have or need to install one of several options including but not limited to; TeraTerm, PuTTY, RealTerm.
- Find the PC serial port. On MS Windows, the USB to serial converter typically enumerates itself to COM6 or higher.
- Set your terminal emulator program for the following serial options: BAUD => 115200; No parity; No flow control;
- · Compile and load the application

4 Observation

Observe the text string on the terminal emulator. The external temperature in Celsius should be updated once per second.

Source Code Overview 5

5.1 **Drivers In Use**

- Instruction Cache
- Clock Manager
- Power Manager
- IO Manager
- GPIO
- SysTick
- UART
- · Real-Time Clock
- . TMON
- AFE
- ADC

5.2 Interrupts Enabled

· Real-Time Clock

5.3 Code Operation

- . Enable Instruction Cache
- Setup Clocks (Use external 8MHz crystal and set system clock select for 48MHz PLL output divided by 2 to get 24MHz system clock)
- . Enable AFE power
- · Set UART pin mapping
- Set UART configuration (baud rate and serial controls)
- Set ADC voltage reference to 1.5V
- Set DAC voltage reference to 1.5V
- Enable clock control for real-time clock interrupts
- Set pre-scale of real-time clock to divide input clock by 212 (1Hz)
- Enable real-time clock
- · Setup real-time clock interrupts to be triggered every second
- · Wait for interrupts and get temperature every one second

5.4 External Four-Current Method

$$T_{MEAS} = \begin{array}{cc} \frac{V_{REF}}{2^{16}} & * \frac{q * [NV_{BE3} + NV_{BE2} - NV_{BE1} - NV_{BE4}]}{nk \ln \frac{I_3}{I_1} * \frac{I_2}{I_4}} \end{array}$$

Normalize results: for external sensor, the external value is inverted, so to offset and scale the NV_{BE} values:

$$NV_{BE1} = 2 \times V_{BE1} - 2^{15}$$

$$NV_{BE2} = 2 \times V_{BE2} - 2^{15}$$

$$NV_{BE3} = 2 \times V_{BE3} - 2^{15}$$

$$NV_{BE4} = 2 \times V_{BE4} - 2^{15}$$

Substituting for I_1 , I_2 , I_3 and I_4 in the denominator:

$$I_1 = \frac{V_{R1}}{R_{INT}}; \quad I_2 = \frac{V_{R2}}{R_{INT}}; \quad I_3 = \frac{V_{R3}}{R_{INT}}; \quad I_4 = \frac{V_{R4}}{R_{INT}}$$

Where:

 T_{MEAS} : temperature in Kelvin

q: electron charge which is 1.60219×10^{19}

 V_{BE1} : ADC reading with I1 as current source

 V_{BE2} : ADC reading with I2 as current source

 V_{BE3} : ADC reading with I3 as current source

 V_{BE4} : ADC reading with I4 as current source

 V_{REF} : ADC reference voltage (1.5V in this application)

n: diode ideality which is typically 1

k: Boltzmann's constant wich is 1.3807×10^{-23} Joules/Kelvin

 I_1 : current source low setting 4μ A

 I_2 : current source high setting 60μ A

 I_3 : current source high setting 64 μ A

 I_4 : current source high setting 120 μ A

 V_{R1} : ADC reading with I_1 as current source

 V_{R2} : ADC reading with I_2 as current source

 V_{R3} : ADC reading with I_3 as current source

 V_{R4} : ADC reading with I_4 as current source

216: Number of ADC steps for MAX32600 16-bit ADC

To convert the measured temperature in Kelvin to Celsius, use the following formula:

°C = K - 273.15