Product Version IC23.1 August 2023 © 2023 Cadence Design Systems, Inc. Printed in the United States of America.

Cadence Design Systems, Inc. (Cadence), 2655 Seely Ave., San Jose, CA 95134, USA.

**Trademarks**: Trademarks and service marks of Cadence Design Systems, Inc. contained in this document are attributed to Cadence with the appropriate symbol. For queries regarding Cadence's trademarks, contact the corporate legal department at the address shown above or call 800.862.4522. All other trademarks are the property of their respective holders.

**Restricted Permission:** This publication is protected by copyright law and international treaties and contains trade secrets and proprietary information owned by Cadence. Unauthorized reproduction or distribution of this publication, or any portion of it, may result in civil and criminal penalties. Except as specified in this permission statement, this publication may not be copied, reproduced, modified, published, uploaded, posted, transmitted, or distributed in any way, without prior written permission from Cadence. Unless otherwise agreed to by Cadence in writing, this statement grants Cadence customers permission to print one (1) hard copy of this publication subject to the following conditions:

- 1. The publication may be used only in accordance with a written agreement between Cadence and its customer.
- 2. The publication may not be modified in any way.
- 3. Any authorized copy of the publication or portion thereof must include all original copyright, trademark, and other proprietary notices and this permission statement.
- 4. The information contained in this document cannot be used in the development of like products or software, whether for internal or external use, and shall not be used for the benefit of any other party, whether or not for consideration.

**Disclaimer:** Information in this publication is subject to change without notice and does not represent a commitment on the part of Cadence. Except as may be explicitly set forth in such agreement, Cadence does not make, and expressly disclaims, any representations or warranties as to the completeness, accuracy or usefulness of the information contained in this document. Cadence does not warrant that use of such information will not infringe any third party rights, nor does Cadence assume any liability for damages or costs of any kind that may result from use of such information.

Cadence is committed to using respectful language in our code and communications. We are also active in the removal and replacement of inappropriate language from existing content. This product documentation may however contain material that is no longer considered appropriate but still reflects long-standing industry terminology. Such content will be addressed at a time when the related software can be updated without end-user impact.

**Restricted Rights:** Use, duplication, or disclosure by the Government is subject to restrictions as set forth in FAR52.227-14 and DFAR252.227-7013 et seq. or its successor

# **Contents**

<u>1</u>	
Relative Object Design Concepts	ć
Introduction	
Using ROD Functions Versus Database Functions	
Creating Parameterized Cells with ROD Functions	
Named Objects	
Hierarchical Name	
 <u>Handles on ROD Objects</u> 1	
System-Defined Handles	
User-Defined Handles	
Aligning Objects	
When Are ROD Alignments Recalculated?	
Separating Aligned ROD Objects	
ROD Objects in Hierarchy	
Querying Objects for Alignments	
Stretchable Parameterized Cells	
The Stretchable Pcell Process	34
Assigning Handles	
Specifying Environment Variables for Stretchable Pcells	38
Specifying the Frequency of Pcell Regeneration	
Results of Stretching a Handle	
Displaying Pcell Stretch Handles	
Stretch PCell Custom Vias	
Accessing Stretch Handles in SKILL	49
Multipart Rectangles	50
Connectivity for Multipart Rectangles	51
System-Defined Handles for Multipart Paths	52
Multipart Rectangles as ROD Objects	52
Creating a Multipart Rectangle from Other Objects	
Editing Multipart Rectangles	
Multinart Paths	54

Types of Subparts	54
Master Paths	
Offset Subpaths	58
Enclosure Subpaths	66
Sets of Subrectangles	68
Ends of Paths and Subrectangles	75
Keeping Subrectangles Out of the Corners of Subrectangle Subpaths	80
Making Paths Choppable	80
Connectivity for Multipart Paths	80
System-Defined Handles for Multipart Paths	80
Multipart Paths as ROD Objects	80
Creating a Path from Other Objects	81
Editing Multipart Paths	81
Creating Objects from Objects	85
Creating a Rectangle from Another Object	86
Creating a Polygon from Another Object	90
Creating a Path from Another Object	95
Connectivity	03
Maintaining Connections for ROD Objects	04
Preserving Maintained Connections 1	06
<u>2</u>	
Accessing Information about ROD Objects	<del>07</del>
About ROD Objects and ROD Object IDs	
Getting the ROD Object ID	
Getting the ROD Object ID Interactively	
Storing the ROD Object ID as a Variable (Avoid)	
Checking Whether an Object Is a ROD Object	
Accessing ROD Object Attributes	
Accessing Subpart Attributes1	
Examples of Using ~> to Display Information	
Getting System-Defined Handle Values with a Script	
Getting User-Defined Handle Names with a Script	24
rodCoord Objects	26

Α		
U	sing Relative Object Design Functions	129
	Aligning ROD Objects Using rodAlign	
	Creating Handles Using rodCreateHandle	
	Creating Paths with rodCreatePath	
	Creating Objects Using rodCreateRect	
	Creating a Named Rectangle	
	Creating a Multipart Rectangle with Rows/Columns of Master Rectangles	
	Filling Bounding Boxes with Master Rectangles	
	Creating Rectangles on a Terminal and Net	
	Creating Rectangular Pins	144
	Using rodGetObj	145
	Naming Shapes Using rodNameShape	149
	Unaligning All Zero-level Shapes in a Cellview Using rodUnAlign	151
	Unnaming All Named Shapes in a Cellview Using rodUnNameShape	152
	Converting Multipart Path to Polygon Using dbConvertPathToPolygon	153
<u>So</u>	<u>llutions to Problems</u>	
	Solutions for rodAlign	154
	Solutions for rodCreateHandle	
	Solutions for rodCreatePath	159
	Solutions for rodCreateRect	
	Solutions for rodGetObj	
	Solutions for rodNameShape	166
В		
	occesing the Collyiow ID	400
<u> </u>	ccessing the Cellview ID	
	Getting the Cellview ID	169
<u>C</u>		
	sing Design Rules in ROD Functions	171
<u>U</u>		
	Using Design Rules for Default Values	
	Accessing Design Rules with techGetSpacingRule	172

<u>D</u>	
Using Environment Variables with ROD	173
Checking the Value of a ROD Environment Variable	
How the System Evaluates ROD Environment Variables	
Changing the Settings of ROD Environment Variables	
List of ROD Environment Variables	
displayStretchHandles	178
distributeSingleSubRect	180
preserveAlignInfoOn	181
rodAutoName	182
stretchDuplicateHandles	
stretchHandlesLayer	185
traceTriggerFunctionsOn	
<u>updatePCellIncrement</u>	187
How Virtuoso Layout Editor Works with ROD Objects  F  Displaying Pin Names in a Layout Window  Setting the Pin Names Environment Variable in .cdsenv  Turning On Pin Names in the Display Options Form	195 195
<u>G</u>	
Code Examples	199
Using ROD to Create Multipart Paths	199
Using Stretchable Pcells	
Creating a Bus	
Creating a Contact Array	202
Creating a Guard Ring	203
Creating a Shielded Path	
Creating a Transistor	207
Getting the Resistance for a ROD Path	210

getRodPathLength Procedure
createResHandle Procedure
Stretchable MOS Transistor
Code for simplemos Transistor
Code for contcov User-Defined Function
Code for myStretch User-Defined Function
<u>H</u>
Troubleshooting22-
Warnings in the CIW
Template templateName is replacing an existing template by the same name 22
Creating instance forces unname of ROD object
ROD object ID changes after Undo
Dialog Box Messages
Why is a dialog box asking about saving the technology file? 223
<u>Index</u> 225

1

# **Relative Object Design Concepts**

Virtuoso<sup>®</sup> relative object design (ROD) is a set of high-level functions for defining simple to complex layout objects and their relationships to each other, without the need to use low-level Cadence<sup>®</sup> SKILL language functions.

This user guide is aimed at CAD engineers and assumes that you are familiar with the development and design of integrated circuits, Virtuoso<sup>®</sup> Layout Suite L editor, and SKILL programming. This user guide also assumes that you are familiar with the creation of parametrized cells using SKILL or the graphical user interface.

The topics covered in this chapter are:

**Introduction** 

<u>Using ROD Functions Versus Database Functions</u>

Creating Parameterized Cells with ROD Functions

**Handles on ROD Objects** 

**Aligning Objects** 

**ROD Objects in Hierarchy** 

Stretchable Parameterized Cells

Accessing Stretch Handles in SKILL

Multipart Paths

Creating Objects from Objects

Connectivity

Maintaining Connections for ROD Objects

Relative Object Design Concepts

## Introduction

Virtuoso<sup>®</sup> relative object design (ROD) is a set of high-level functions used for defining simple to complex layout objects and their relationships to each other, without the need to use low-level Cadence<sup>®</sup> SKILL language functions. ROD lets you create objects and define their relationships at a high level of abstraction, so you can concentrate on your design objectives. ROD automatically handles the intricacies of traversing the design hierarchy and simplifies the calculations required to create and align geometries.

A single ROD function call can accomplish a task that otherwise would require several lower-level SKILL function calls. For example, creating a pin required a series of low-level SKILL function calls, but with ROD, you can use a single function to create a shape and designate it as a pin. You can create entities such as guard rings, contact arrays, and transistors with one function call. You can also create an object from an existing object just by specifying the size of the new object.

#### ROD functions allow you to

- Create hierarchical parameterized cells
- Name rectangles, polygons, paths, lines, dots, labels, and text display objects
- Access objects by name through all levels of hierarchy
- Access points and other information stored on objects through all levels of hierarchy
- Align ROD objects to each other or to specific coordinates
- Assign handles to Pcell parameters for interactive stretching
- Create multipart rectangles and multipart paths
- Create objects from other objects

For a complete description of the ROD functions, see <u>Appendix A, "Using Relative Object Design Functions."</u>

# **Using ROD Functions Versus Database Functions**

This chapter describes in great detail the many advantages of creating and manipulating objects using ROD functions. So, why not make all objects ROD objects? Sometimes, it is better to create an object with a dbCreate function than with a rodCreate function, because the added functionality of a ROD object carries a bit more overhead.

Relative Object Design Concepts

In general, use ROD functions only when you want to:

- Specify persistent relationships between objects
- Create complex multi-part objects, such as guard rings
- Access the object from a different level of hierarchy
- Stretch handles on parameterized cells to change the value of parameters
- Create a new object from an existing object

When you want to create a simple shape, such as a rectangle or simple one-part path, and you do not intend to "relate" the shape to another object, use the <code>dbCreate</code> function. The <code>dbCreate</code> functions do not have to store the additional information required for ROD objects, and therefore, run a little more quickly and use less memory.

# **Creating Parameterized Cells with ROD Functions**

Using ROD functions to create geometries for Pcells increases your productivity by reducing the difficulty and complexity of the code you have to write. To create SKILL Pcells without ROD, you must use low-level SKILL database access functions to build and manipulate geometries. You end up spending a great deal of time and effort calculating and tracking geometry coordinates. Complex SKILL Pcells are much easier to create and maintain when you create geometries with ROD functions. Instead of writing code to compute point coordinates across levels of hierarchy, you create high-level building blocks and align them in relation to each other.

Historically, using programs to create large macro cells and full-chip assemblies required a tremendous effort by SKILL developers who were dedicated exclusively to writing Pcell code. ROD provides high-level design capture support so that even designers with limited programming experience can create complex Pcells, and those with advanced programming abilities can generate sophisticated cells and blocks.

After you capture a design in the form of parameterized code, you can generate a variety of cell modules using different parameter values and different technology rules. Also, creating a single design that captures your intention reduces errors from manipulating low-level layout objects independently of each other.

Major advantages for using ROD to create Pcells are:

■ You can base the Pcell parameters on rules from your technology file, making the Pcells tolerant of changes to your technology

Relative Object Design Concepts

■ You can assign point handles to Pcell parameters that let you update the parameters interactively by stretching the Pcell in the Virtuoso layout editor

Before you use ROD functions in Pcells, see the safety rules for creating SKILL Pcells in "Creating SKILL Parameterized Cells" in the Virtuoso Parameterized Cell Reference.

For examples of Pcells, see the *Sample Parameterized Cells Installation and Reference*.


## **Named Objects**

You can assign a name to a zero-level object (an ordinary database shape, such as a rectangle or polygon) either by naming an existing object with the rodNameShape function or by using a RODcreate function to create an object. You can also name a shape when you create it with the Virtuoso layout editor. You can access information through hierarchy about named objects, such as instances and named shapes.

#### **Hierarchical Name**

To access information about a named shape or instance through hierarchy, use its *hierarchical name* and the top-level cellview ID. A hierarchical name consists of the names of the instances through which you need to descend to reach the desired named shape or instance.

The following figure shows the hierarchy in a layout cellview containing the named shape polyRect. Its hierarchical name is INV1/ptr1/polyRect.



When you name an existing database shape using the ROD naming function, the function creates ROD information associated with the shape. This information is stored in a ROD object and is identified by a unique ROD object ID. The information contained in a ROD

Relative Object Design Concepts

object includes its name and database ID. When you create a new shape with a ROD creation function, the function creates a named database shape and a ROD object.

## **Handles on ROD Objects**

A *handle* is an attribute of, or item of information about, a ROD object, such as the coordinates of a point on the bounding box around an object, the width of the bounding box of an object, or the resistance of an object. You can access handles through all levels of hierarchy.

There are two kinds of handles: system-defined handles and user-defined handles. When you create a ROD object, the system automatically defines a number of handles for the object. The values of system-defined handles are not stored in memory but are calculated on demand when you reference the handles by their names. The values of user-defined handles are stored in memory.

The value of a system-defined point handle is the coordinates for a point on the object or on its bounding box, relative to the coordinate system of the top-level layout cellview. For a detailed description of how the system calculates coordinates through hierarchy, see <u>ROD Objects in Hierarchy</u>.

Using the <u>rodAlign</u> function, you can use handles to align one object to another object to store information, or to access information about an object that is at a lower level in the design hierarchy.

## System-Defined Handles

The system automatically defines the following types of handles for most ROD objects:

- Bounding box point handles
- Bounding box width and length handles
- Segment point handles
- Segment length handles

ROD dots, labels, and text display objects are defined by a single point, so all of their point handles evaluate to their origin point and their length and width handles evaluate to zero.

**Note:** For <u>multipart paths</u>, the system also provides the handle <u>mppBBox</u>, which contains a list of the lower-left and upper-right coordinates of the bounding box around the whole multipart path.

Relative Object Design Concepts

The following table summarizes the types of handles and the ROD object(s) to which they apply.

Table 1-1 System-Defined Handles for ROD Objects

Type of Handle	Applies to
Bounding Box Point Handles	All ROD objects except dots, labels, and text display objects
Bounding Box Width and Length Handles	All ROD objects except dots, labels, and text display objects
<u>mppBBox</u>	ROD multipart paths
Segment Point Handles	ROD rectangles, polygons, and paths
Segment Length Handles	ROD rectangles, polygons, and paths


#### **Bounding Box Point Handles**

There are nine system-defined point handles associated with the bounding box around every ROD object:

- One at each corner
- One in the center of each edge
- One in the center of the bounding box

The system automatically names and calculates values for bounding box point handles. Names indicate the position of the handle, as shown for a polygon in the following figure.

Figure 1-1 Bounding Box Point Handles for a Polygon




You can abbreviate boundingcR box point handle names as follows:

upperLeft	or	uL	lowerLeft	or	1L
upperCenter	or	uC	lowerCenter	or	1C
upperRight	or	uR	lowerRight	or	1R
centerLeft	or	cL	centerCenter	or	сС
centerRight	or	cR			

#### **Bounding Box Width and Length Handles**


The system provides floating-point handles named width and length for the width and length of the bounding box for a named object, where width is the horizontal measurement and length is the vertical measurement.

**Note:** For a rectangle, the bounding box has the same width and length as its shape.




For a polygon, the system calculates values for the width and length handles associated with the bounding box, as shown below.

Figure 1-2 Bounding Box Width and Length Handles for a Polygon




For a single-part path, the system calculates values for the width and length handles associated with the bounding box, as shown below.

Figure 1-3 Bounding Box Width and Length Handles for a Single-Part Path




For a multipart path, when the system calculates values for the width and length handles, it always uses the width and length of the bounding box around the *master path*.

Figure 1-4 Bounding Box Width and Length Handles for a Multipart Path



For multipart paths, there is one additional handle: mppBBox. The mppBBox handle contains a list of the lower-left and upper-right coordinates of the bounding box around the *whole multipart path*.

Figure 1-5 Bounding Box mppBBox Handle for the Whole Multipart Path




## **About Segments of Rectangles, Polygons, and Paths**

For rectangles, polygons, and paths that are ROD objects, the system assigns several point handles to each segment of the object. You can use these segment point handle names to reference points on the boundary of the object.


For relative object design, a segment of a rectangle or polygon is defined as an edge, or finite line between two points, partially forming the boundary of the object. For example, a six-sided polygon has six segments (six edges).

Figure 1-6 Segments of a Polygon




For paths, segments include the width of the path and both edges. For example, the following path has four segments.

Figure 1-7 Segments of a Path




The system assigns a name to each segment of the object, using the prefix segment followed by a number: segmentn, where n begins at zero and is the segment number. For ROD rectangles, segments are always numbered as if they were defined in a clockwise direction, starting in the lower-left corner.

Figure 1-8 Numbering the Segments of a Rectangle



For ROD polygons, the system numbers segments in the direction in which the polygon was created, starting with the first point defined. The six-sided polygon below was created in a clockwise direction.

Figure 1-9 Numbering the Segments of a Polygon




Relative Object Design Concepts

**Note:** If you create a polygon with the Virtuoso layout editor and then assign a name to it using the rodNameShape function, the system numbers segments starting with the first point you defined when you created the polygon.

The segments of the path below were created in a clockwise direction.

Figure 1-10 Numbering the Segments of a Path




#### Segment Point Handles for Polygons and Rectangles

For rectangles and polygons, the system calculates the following point handles:

- For each segment, three point handles: one at the beginning, middle, and end of the segment. Their names are: startn, midn, and endn, where n is the segment number. The endn handle for a segment and the startn handle for the next segment share the same point.
- For the last segment, the three handles described above, plus three more handles: startLast, midLast, and endLast.

The six-sided polygon in the following figure was created starting in the upper-left corner of the highest segment, with the segments defined clockwise.


Figure 1-11 Segment Point Handles for a Polygon



The starting point of the first segment is also the ending point of the sixth segment, so the value of the start0 point handle is the same as the value of the end5 point handle. The system calculates values for three additional point handles for the last segment of the polygon, which in this case is the sixth segment. The illustration shows three system-defined segment point handles—start0, end5, and endLast—for the same point.

For rectangles, the system always uses the lower-left corner as the starting point and defines segments in a clockwise direction.

Figure 1-12 Segment Point Handles for a Rectangle



Relative Object Design Concepts


For rectangle, the lower left corner is always its starting point, so when you rotate a rectangle, the handle values change.

#### **Segment Point Handles for Paths**

When naming segment point handles for paths, the system takes into account the direction of the path. The names of handles on the left in relation to the direction of the path contain the word *Left*, and the names of handles on the right contain the word *Right*.


For example, if the single segment below was a road, and you were driving on it in the direction shown, then the handles on the top edge of the segment are named *Left* segment handles and handles on the bottom edge of the segment are named *Right* segment handles.

Figure 1-13 Segment Point Handles for a Single-Segment Path



The point handle names for a multisegment path are shown below.


Figure 1-14 Segment Point Handles for a Multisegment Path



For paths, the system calculates the values of two additional point handles: startCenter0 and endCenterLast.

For paths with the end type flush, the startCenter0 and endCenterLast handles have the same values as the start0 and endLast handles. However, for paths with the layer extending beyond the centerline, which have an end type of variable, offset, or octagon, the startCenter0 and endCenterLast handles have different values than the start0 and endLast handles, as shown in the following figure.


Figure 1-15 Point Handles for Extended-Type Paths



For paths with an end type of flush, offset, or variable, segment point handles are on the path boundary or path centerline. However, for paths with the end type octagon, some segment point handles at the path ends and where path segments join are outside the path boundary.

For example, for the following path, the startLeft0, startRight0, endRight0, startRight1, endLeft1, endLeftLast, endRight1, and endRightLast segment point handles are located outside of the path itself.

Figure 1-16 Segment Point Handles for Paths with Octagonal Ends




#### **Segment Length Handles**

The system provides one segment length handle for each segment for objects that have segments. For paths, the system provides a length handle for the centerline of each segment, excluding extensions, if any.

**Note:** For multipart paths, the system defines handles based on the points of the master path only, with the exception of the mppBBox handle.

The system names length handles lengthn, where n is the segment number. The handle for the length of the first segment is length0. The system increases n by 1 for each additional segment, in the direction in which the object was created. (Rectangles are always created in a clockwise direction, starting in the lower-left corner.) The system also provides the handle lengthLast for the last segment.


Figure 1-17 Segment Length Handles for a Rectangle



For rectangle, the lower left corner is always its starting point, so when you rotate a rectangle, the handle values change.

The six-sided polygon in the following figure was created starting in the upper-left corner of the highest segment, with the segments defined clockwise.


Figure 1-18 Segment Length Handles for a Polygon



**Note:** If you create a polygon with the Virtuoso layout editor and then assign a name to it using the rodNameShape function, the system numbers segments starting with the first point you defined when you created the polygon.

For a path, the system computes values for segment length handles along the path centerline. The names of segment length handles for a four-segment path are shown next.

Figure 1-19 Segment Length Handles for a Multisegment Path



#### **Accessing the Path Width**

The system does not automatically compute the value for the width of a ROD path. (The width handle measures the width of the bounding box around a path.) However, you can access the path width by using the ROD object ID and the ROD attribute for the database ID of the object (dbid) with the database access operator (~>).


For a multipart path, for example, the following statement returns the width of the master path: rodId~>dbId~>width

## Why Are There Multiple Handles for the Same Point?

In some cases, the system provides more than one handle for the same point. Although multiple handles for the same point might seem redundant, they provide you with flexibility. For example, if you do not know the number of segments an object has, you can refer to points on the last segment by using point handle names containing the word Last.

For example, for an eight-sided polygon created in a clockwise direction, with the starting point in the upper-right corner, the segments are numbered segment 0 through segment 7.

Figure 1-20 Multiple Handle Names for the Same Point



### **User-Defined Handles**

You can define your own handles to store points, calculations, and other information. When you define a new handle, you specify the name (or let it default) and assign a value. The values of user-defined handles are stored in the database. The information stored can have any of the following data types:

point integer

Boolean floating-point number

string SKILL expression

If you let the name of your new handle default, the system assigns a name unique within the cellview, as follows: handle0, handle1, handle2, etc.

For example, if a layout cellview contains two ROD objects, and you create one user-defined handle for each object without specifying handle names, the system assigns the name <code>handle0</code> to the handle on the first object and <code>handle1</code> to the handle on the second object.

Relative Object Design Concepts

If you create a handle without specifying a name, you can find out what the system named the new handle. For a code example showing how to do this, see <u>Problem 3-6 Querying a System-Assigned Handle Name</u>.

## **Aligning Objects**


You can specify the position of one named object in relation to another named object with the <u>rodAlign</u> function. This is called *relative alignment*.

To align two named objects, identify the object you want to align (*aligned object*) and the object or point you want to align it to (*reference object* or *reference point*). Usually, you align objects by specifying a point handle on each object. You can also specify the distance between the two objects in the direction of the X axis, the Y axis, or both.

The alignment between two objects is preserved when you manipulate either object and when you save and close the layout cellview. For example, when you move a reference object, the aligned object moves with it.

An alignment can involve any named geometry at any level of hierarchy and any design rule that is defined in your technology file.


For example, you can align a point handle on object  $\ B$  to a point handle on object  $\ A$  (the reference object) and specify the distance between them as equal to the minimum design rule for the layer in your technology file. When you move object  $\ A$ , object  $\ B$  also moves, and vice versa.



Point handle on object B is aligned to point handle on object A.

Relative Object Design Concepts

Or you might want to align the centerLeft point handle on the object named D in the instance nTrans2 to the centerRight point handle on the reference object, B in the instance nTrans1.



## When Are ROD Alignments Recalculated?

The system automatically calculates and applies alignments for named objects whenever

- A layout cellview is opened in edit mode
- Either object involved in an alignment is edited in any way (moved, rotated, stretched, etc.), at any level of the hierarchy
- You reload your technology file

When you open a cellview in edit mode, the system automatically calculates and applies all alignments assigned to the ROD objects in the cellview.

## **Separating Aligned ROD Objects**


You can specify the separation for ROD objects in the direction of the X axis, the Y axis, or both. Usually, one or more design rules determines the value of the separation.

You can use a SKILL expression with technology file variables to calculate the separation across one or more levels of hierarchy. The system automatically reevaluates SKILL expressions used in alignment whenever it needs to recalculate the alignment.

## **ROD Objects in Hierarchy**

When you access a point handle associated with a ROD object with the rodGetHandle function or the ROD object ID and the database access operator (~>), the system automatically transforms (converts) the coordinates of the point up through the hierarchy into the coordinate system of the top-most cellview containing the object. You specify levels of hierarchy in the name of the object.

The following example shows a cellview, CCC, containing two levels of hierarchy. The first level contains the instance IB1 of cell BBB; the second level contains two instances of AAA and some zero-level objects that are not shown.



The hierarchical name for the shape polyRect in instance IA1 of AAA, where instance IA1 is in the instance IB1 of BBB, is

IB1/IA1/polyRect

The hierarchical name for the shape polyRect in instance IA2 is

IB1/IA2/polyRect

For detailed examples showing how to access objects through hierarchy, see <u>Using</u> rodGetObj.


## **Querying Objects for Alignments**

You can query any named object to see what the object is aligned to. When you query a hierarchical object, the system displays all top-level alignments for the object.

To see the alignments for an object, you can use the Virtuoso layout editor Edit Properties command (click ROD at the top of the form) or type commands in the CIW. For an example showing how to query an object in the CIW, see <a href="Examples of Using">Examples of Using</a> <a href="Examples of Using">> to Display Information</a>.

## Stretchable Parameterized Cells

When you create a SKILL Pcell, you can make its instances "stretchable" by assigning point handles to the parameters of the Pcell with the rodAssignHandleToParameter function.
This kind of handle is called a stretch handle.



You can also make Pcell custom vias stretchable.

A Pcell with stretch handles is called a *stretchable Pcell*. Assigning stretch handles to Pcell parameters lets you **graphically** change the value of those parameters for Pcell instances after you place them. You do this by selecting one or more handles and using the *Stretch* command. A handle is selectable when its layer-purpose is defined in the cellview where the Pcell is instantiated. Max number of drag figures applies to the stretch.

You are not stretching objects within the Pcell or stretching the Pcell itself. Instead, you are graphically updating the value of the parameters associated with the selected handles. Graphically stretching a Pcell instance has the same result as editing its parameters using the Edit Properties form.


**Note:** You cannot undo stretching a Pcell instance.


For more information about point handles, see <u>Handles on ROD Objects</u>.

You specify the direction in which a handle stretches as either X or Y. For example, if you have a Pcell containing a single rectangle and want to stretch the width of the rectangle, you could assign the centerRight point handle to the width parameter of the Pcell and specify a

Relative Object Design Concepts

stretch direction of X. This lets you change the value of the width parameter by stretching the centerRight point handle horizontally.





When you assign a handle to a parameter, you can define your own function to calculate the value of the Pcell parameter to which you are assigning the handle. The system passes the increment or decrement resulting from stretching the assigned handle(s) to the user-defined function as input and uses the value returned by the function to replace the value of the parameter.

#### The Stretchable Pcell Process

The process for stretching Pcells is described below.

#### As you do this:

Start the Stretch command and select one or more stretch handles.

**Note:** If you have trouble selecting stretch handles, try turning off the *Gravity On* option on the Layout Editor Options form.

Click to indicate the new location.

The system does the following:


- When you first select a stretch handle (or more than one stretch handle) for which there is display information specified, such as a parameter name and value, the system shows the information next to the upper-right corner of the Pcell.
- As you move the cursor, the system does the following, in the sequence in which the handle-to-parameter assignments are specified in the Pcell code and according to the frequency specified for regenerating the Pcell:
  - □ When there are no user-defined functions associated with the handles, the system applies the increment or decrement directly to the value of the parameters.

Relative Object Design Concepts

- ☐ When there are user-defined functions, the system sends the increment or decrement to the user-defined functions, executes the functions, and replaces the value of the parameters with the values returned by the functions.
- □ Displays an outline of the regenerated Pcell and updates the information displayed, if any.

The steps of this process repeat until you complete the stretch. For a flowchart of the process, see <u>Figure 1-21</u> on page 35.

Figure 1-21 Flowchart for the Stretchable Pcell Process



Relative Object Design Concepts

## **Assigning Handles**


To make a Pcell stretchable, in your Pcell code, you can assign


- One point handle to one parameter
- Multiple point handles to one parameter
- One point handle to multiple parameters
- Three point handles at once by specifying an edge

To assign handles to parameters, use the rodAssignHandleToParameter function. In each rodAssignHandleToParameter statement, you can assign one or more point handles to one parameter and specify one stretch direction (X or Y). To assign a handle to multiple parameters, you must write multiple rodAssignHandleToParameter statements for the Pcell.

#### **Assigning Multiple Handles to One Parameter**

You can assign more than one handle to one parameter. For example, if you assign the upperRight, centerRight, and lowerRight point handles to the width parameter of a Pcell that contains only a rectangle and specify a stretch direction of X, then you can change the value of the width parameter by stretching any or all of the three point handles horizontally.





#### **Assigning One Handle to Multiple Parameters**

You can assign one handle to two or more parameters. When you stretch the handle, the stretch might affect more than one of the associated parameters.


For example, if you want to use one handle to stretch an object in the direction of both the X and Y axes, you assign the same handle to two parameters by writing two rodAssignHandleToParameter statements. In one statement, you assign the handle to

Relative Object Design Concepts


the first parameter with a stretch direction of X, and in the other statement, you assign the same handle to a second parameter with a stretch direction of Y.

The following example shows a Pcell containing only a rectangle. You could assign the <code>upperRight</code> point handle to the <code>width</code> parameter with a stretch direction of X, and assign the <code>upperRight</code> point handle again to the <code>length</code> parameter with a stretch direction of Y. Then you can change the value of the <code>width</code> parameter by stretching the <code>upperRight</code> point handle horizontally as shown in a previous example and change the value of the <code>length</code> parameter by stretching the <code>upperRight</code> point handle vertically.

Assigning the same handle to two different parameters requires two separate rodAssignHandleToParameter statements.



You can also change the value of both the width and length parameters by stretching the upperRight point handle at any other angle.




#### **Assigning Handles by Specifying Bounding Box Edges**

You can assign three bounding box point handles for a ROD object to a Pcell parameter at once by specifying the name of the bounding box edge. Specifying an edge automatically assigns all three point handles on the edge to the same parameter. For example, for a

Relative Object Design Concepts

rectangle that is a Pcell, the bounding box edges you can specify are upperEdge, lowerEdge, leftEdge, rightEdge.

When you specify upperEdge, you simultaneously specify the three point handles on the bounding box: upperLeft, upperCenter, and upperRight.



# **Specifying Environment Variables for Stretchable Pcells**

You can set the environment variables listed below to influence what the system does when you stretch a handle:

■ updatePCellIncrement

A floating-point layout editor environment variable specifying how often the system updates Pcell parameters and regenerates the Pcell during a stretch operation. The default is at every grid snap, as defined by the technology file variable mfgGridResolution.

If you want to vary the update frequency for different handle-to-parameter assignments within the same Pcell, you can specify the  $f\_updateIncrement$  argument for the rodAssignHandleToParameter statement for each handle-to-parameter assignment. The value of the  $f\_updateIncrement$  argument overrides the value of the layout editor environment variable updatePcellIncrement.

- displayStretchHandles
  - A Boolean graphic editor and layout editor environment variable specifying whether stretch handles are displayed in layout cellviews. The default is t, which displays stretch handles.
- stretchHandlesLayer
  A string graphic editor environment variable specifying the layer on which stretch handles are displayed. The default is the y0 layer and drawing purpose.
- stretchHandleShape

A cyclic environment variable to control the default shape of the stretch handle when it is not specified through the S\_shape argument of the rodAssignHandleToParameter SKILL function. Valid values are diamond, square, or dot.

Relative Object Design Concepts

For a description of how to set graphic editor and layout editor environment variables, see <u>"Environment Variable Functions"</u> in the *Virtuoso Layout Suite XL: Basic Editing User Guide*.

# **Specifying the Frequency of Pcell Regeneration**

You specify how often the system updates Pcell parameters and regenerates the Pcell during a stretch operation with the  $f\_updateIncrement$  argument. You can also use the layout editor environment variable updatePCellIncrement to control the frequency of Pcell regeneration. The default for both is to update the Pcell parameters and regenerate the Pcell at every grid snap, as defined by the mfgGridResolution variable in your technology file.

# Results of Stretching a Handle

The results you get from stretching a handle depend on the code written for the Pcell, including

- Where the stretch handle is located
- Whether stretching the handle affects the instance boundary
- Whether the origin point of the instance is allowed to move
- How the stretch direction and stretch type are specified
- The data type of the parameter to which the handle is assigned
- Whether the parameter value is computed by a user-defined function
- Whether the instance is rotated
- The settings of the environment variable that influence stretchable Pcells
- How often the system regenerates the Pcell

#### **Results of Specifying the Stretch Type**

The stretch type determines whether the parameter is increased or decreased in relation to the stretch direction. The stretch type can be either *relative* or *absolute*.


- For a stretch type of relative, the stretch is in relation to the center of the Pcell.
- For a stretch type of *absolute*, the stretch is in relation to the X or Y axis.

Relative Object Design Concepts


The results of a stretch often depend on whether or not the origin point of the Pcell instance can move. The origin point is usually the lower-left corner. For handles in some locations, the results of a stretch are the same for both stretch types, whether the origin point can move or not.

In the following examples, the Pcell contains a single rectangle, so handles on the bounding box of the rectangle are also on the boundary of the instance. There are no user-defined functions.

In the example below, the centerRight point handle of a rectangle is assigned to the width parameter of the Pcell with the stretch direction X. The width parameter controls the width of the rectangle.



For this sample Pcell, stretching to the right always increases width no matter what the stretch type is and whether or not the origin point can move, because the handle is located in the middle of the right edge. Conversely, stretching to the left always decreases width for this Pcell.



However, for handles in most locations, the results of stretching are different for each stretch type and when the instance origin point can move or not move.


Relative Object Design Concepts

**Note:** Defining the origin point of a Pcell instance as movable is most useful when the stretch type is relative and the location of the stretch handle coincides with and affects the bounding box of the Pcell instance.


### Results for the Relative Stretch Type

For a stretch type of *relative*, stretching a handle away from the center of its ROD object increments the associated Pcell parameter, while stretching towards the center of the ROD object decrements the associated Pcell parameter. A stretch away from the center makes the object larger and a stretch towards the center makes the object smaller.

The results of stretching a handle might vary depending on whether the instance origin point can move during a stretch. In the example below, the centerLeft point handle on the rectangle is assigned to the width parameter of the instance, with a stretch direction of X. The Pcell contains only the rectangle.




When you stretch the centerLeft handle to the left (away from the center of the Pcell), the width parameter is incremented, so the width of the rectangle and instance gets larger.



Relative Object Design Concepts

In both cases, the width of the rectangle and instance gets larger. However, if the instance origin point cannot move, the width of the rectangle and instance expands to the right.

For a relative stretch, when you stretch the centerLeft handle to the right (towards from the center of the Pcell), the width parameter is decremented, so the width of the rectangle and instance gets smaller.



In both cases, the width of the rectangle and instance gets smaller. However, if the instance origin point cannot move, the width of the rectangle and instance shrinks from the right.


# Results for the Absolute Stretch Type

For a stretch type of *absolute*, stretching in a positive direction in relation to the X or Y axis increments the associated Pcell parameter, while stretching in a negative direction decrements the associated Pcell parameter.


The results of stretching a handle might vary depending on whether the origin point can move during a stretch. In the example below, the lowerCenter point handle is assigned to the

Relative Object Design Concepts

length parameter of a rectangle that comprises a Pcell. The stretch direction is specified as Y.



For an absolute stretch, when the stretch handle is on the bottom of the object and you stretch upward (in a positive direction along the Y axis), the length parameter is incremented, so the object gets larger. How the rectangle expands depends on whether the origin point can move.




When the origin can move, the edge on which the handle is located can move also, which allows the handle to move during the stretch. An absolute stretch of the <code>lowerCenter</code> point handle upward along the Y axis increases the <code>length</code> parameter, making the rectangle and instance larger by moving the edge on which the handle is located.

When the origin cannot move, the edge on which the handle is located cannot move either, which prevents the handle from moving during the stretch. An absolute stretch of the lowerCenter point handle upward along the Y axis increases the length parameter,

Relative Object Design Concepts

making the rectangle and instance larger by moving the edge *opposite* from where the handle is located.

For an absolute stretch, when the handle is on the bottom of the object and you stretch downward (in a negative direction along the Y axis), the length parameter is decremented, so the object gets smaller. How the rectangle shrinks depends on whether the origin point can move.



In both cases, the length of the rectangle and instance get smaller. When the origin can move, an absolute stretch of the <code>lowerCenter</code> point handle downward along the Y axis decrements the <code>length</code> parameter by moving the lower edge of the rectangle. However, when the origin cannot move, an absolute stretch decrements the <code>length</code> parameter by moving the edge <code>opposite</code> from where the handle is located.

#### **Results of Stretching Multiple Handles**


When you select more two or more handles to stretch at the same time, the system processes each handle in the sequence in which the handle-to-parameter assignments appear in the Pcell code. The results depend partly on how the handles affect Pcell parameters.

- When the selected handles are assigned to the **same parameter** and affect that parameter in the **same way**, the system applies only the change to the parameter from the handle that appears first in the handle-to-parameter assignments in the Pcell code; the system ignores the results of stretching the other handles.
- When the selected handles are assigned to the **same parameter** but affect the same parameter in **different ways**, the system applies the change from each handle to that same parameter, cumulatively.


Relative Object Design Concepts

■ When the selected handles affect **different parameters**, the system applies the change from each handle to each parameter individually.

In the following example, the Pcell contains a single rectangle. There are no user-defined functions for the handles.




The three point handles, upperRight, centerRight, and lowerRight, are all assigned to the width parameter of the Pcell with the stretch direction of X. The width parameter controls the width of the rectangle.



Relative Object Design Concepts

When you stretch by +3 along the X axis, all three point handles affect the width parameter in the same way, so stretching all three handles gets the same result as stretching only one or two of the handles.



#### **Stretching Multiple Handles on the Same Point**

When there are multiple stretch handles on the same point, and you select that point (or one of the handles on it), all stretch handles on the point are selected.

### Results of Dragging a Handle During a Stretch

As you move the cursor during a stretch operation, the system displays an outline of the instance and shows how it is changing. If you want to see an outline of each individual object in the Pcell and the Pcell boundary, you can turn on the *Drag Enable* property for the object layers. You can set this property by choosing the *Technology File – Edit Layers* command in the Command Interpreter Window.

#### **Replace CDFs with User-Defined Functions**


In this release, stretching a Pcell does not execute CDFs associated with the Pcell parameters. For now, you should use user-defined functions to perform tasks formerly performed by CDFs.

For more information about user-defined functions, see "<u>User-Defined Functions</u>" in the Virtuoso® Relative Object Design SKILL Reference book and the <u>S1\_userFunction</u> argument description for the rodAssignHandleToParameter function.

Relative Object Design Concepts

#### **Example of Stretching a Sample MOS Transistor**

The following Pcell contains a MOS transistor with two contact arrays.



You can stretch the MOS transistor in a negative direction towards the Y axis to reduce the number of contacts in the array from two to one, using the Virtuoso layout editor Stretch command.

- **1.** Choose *Edit Stretch*.
- 2. Select the upperCenter stretch handle on the left contact array using an area-selection box.


**Note:** If you have trouble selecting the stretch handle, try turning off the *Gravity On* option on the Layout Editor Options form.

**3.** To enter the reference point, click the upperCenter stretch handle on the left contact array.

The following information appears to the right of the Pcell: leftcov = 1 As you move the cursor down, the information changes to


leftcov = 0.25

**4.** To enter the new location, click above the bottom transistor.



**5.** Exit the *Stretch* command by pressing Escape.

The MOS transistor Pcell instance now looks like this:



# **Displaying Pcell Stretch Handles**

You can control whether Pcell stretch handles display either with the layout editor Display Options form or by setting the graphic editor and layout editor environment variable displayStretchHandles in the CIW. The default is to display stretch handles.


To specify the layer on which stretch handles are displayed, set the graphic editor environment variable stretchHandlesLayer.

#### Stretch PCell Custom Vias

Like multi-part paths, you can also stretch the ends, segments, and/or corners of custom vias. The process of stretching the custom via is given below:

- 1. Select a custom via
- 2. Display stretch handles
- 3. Stretch via using the stretch handle
- 4. Re-compute the via accordingly
- 5. During stretching, all vias in the stack will be stretched

The example below illustrates how a Pcell via might be stretched. The exact outcome of the interactive stretch operation is dependent upon the SKILL code for the via, which handles are assigned to parameters, and how those parameters control the geometry of the Pcell via.




# **Accessing Stretch Handles in SKILL**

You can use the roduT user type to access the stretch handle attributes at the SKILL level. This user type object is implemented using C/C++ in the Virtuoso environment. It is used for the stretch handle that is assigned to the Pcell parameter in the context of Pcell evaluation. The Pcell parameter allows SKILL access to attributes of the stretch handle through roduT.


# **Multipart Rectangles**

A multipart rectangle (MPR) is a single object composed of multiple parts on the same or on different layers. The parts consist of one or more named *master* rectangles and one or more arrays of unnamed *subrectangles*. Each named master rectangle is a separate object with ROD attributes, created at level zero in the hierarchy. Each unnamed subrectangle is an ordinary database shape with no ROD attributes, created at level zero in the hierarchy.

You create MPRs with the <u>rodCreatePath</u> function. For example, you might create a single master rectangle with a two-dimensional array containing four subrectangles,




a single master rectangle overlapped by rows and columns of subrectangles (a twodimensional array),




Relative Object Design Concepts

one master rectangle with two one-dimensional arrays containing five subrectangles each,



or six master rectangles and a two-dimensional array containing four subrectangles. The array of subrectangles repeats for each master rectangle (you define the array once).



# **Connectivity for Multipart Rectangles**

You can create connectivity for all master rectangles and/or for any array of subrectangles by associating them with a specific terminal and net. You can also make all master rectangles into pins and/or all subrectangles of any array into pins.

Relative Object Design Concepts

An array of unnamed subrectangles is treated as a single shape. However, you can get a list of the database IDs for the individual subrectangles within an array by using the ROD object ID for the multipart path with the database access operator (~>) and the attribute name subShapes. If you use the database ID to change connectivity information (such as terminal name) for one or more individual subrectangles, your change is propagated to all of the subrectangles in the array of subrectangles. For more information, see <a href="Accessing ROD">Accessing ROD</a> Object Attributes.

# **System-Defined Handles for Multipart Paths**

For multipart rectangles, the system defines handles based on the points of the master rectangles only. Subrectangles are ordinary database shapes with no ROD attributes. The handles for master rectangles are the same as for any ROD rectangle.

For more information, see <u>System-Defined Handles</u>.

# **Multipart Rectangles as ROD Objects**

When you create multipart rectangles, the system creates a rectangle and *ROD object* information for each master rectangle, including its name and database ID. The ROD object is identified by a *ROD object ID*. The database IDs for a multipart rectangle identify the master rectangles. Subrectangles are regular, unnamed database shapes without any ROD attributes.

For a detailed description of ROD objects and ROD object IDs, see <u>About ROD Objects and ROD Object IDs</u>.

# **Creating a Multipart Rectangle from Other Objects**

You can create a new master rectangle without specifying points by using one or more of the following as source objects: an instance or any ROD object.

For a detailed overview about creating objects from other objects, see <u>Creating Objects from Objects</u>.

# **Editing Multipart Rectangles**

For a summary of how the Virtuoso<sup>®</sup> layout editor commands work with ROD objects, see Appendix E, "How Virtuoso Layout Editor Works with ROD Objects". Using commands that

Relative Object Design Concepts

are not fully supported for ROD objects could cause the objects to lose the ROD information associated with them, changing the objects into ordinary, unnamed shapes.

When you select any part of a master rectangle or its associated subrectangles, the whole master rectangle and all associated subrectangles are selected. The master rectangle is highlighted on the current selection layer, while the arrays of subrectangles are highlighted on different layers to let you see which part is the master and which parts are arrays of subrectangles.

When you modify a multipart rectangle with the layout editor, changes to a master rectangle also affect all of its associated subrectangles; you cannot edit or copy an array of subrectangles or individual subrectangles.

# **Stretching Multipart Rectangles**

You can stretch the edges and/or corners of a master rectangle of a multipart rectangle in the same way you stretch regular rectangles, by clicking on an edge or vertex, then clicking in a new location. The system regenerates the arrays of subrectangles associated with the stretched master rectangle, changing the number of subrectangles in each array; the shape of the subrectangles does not change. You cannot stretch a master rectangle separately from its subrectangles, nor can you stretch subrectangles separately from their master rectangle.

The way that subrectangles regenerate depends on how the multipart rectangle was defined with the rodCreateRect function. For information about defining multipart rectangles, see rodCreateRect.

Relative Object Design Concepts

# **Multipart Paths**

A multipart path (MPP) is a single ROD object consisting of one or more parts at level zero in the hierarchy on the same or on different layers. You can create one-part paths, simple multipart paths, or complex multipart paths such as guard rings, transistors, buses, and shielded paths. This section provides an overview of multipart path concepts.

You can create MPPs in the ways listed below.

This section provides an overview of multipart path concepts.

- With the Virtuoso layout editor Create Multipart Path command
  - For information about using the *Create Multipart Path* command, see <u>"Creating and Editing Multipart Paths"</u> in the *Virtuoso Layout Suite L User Guide*.
- For guard rings, with the Quick Cell graphical user interface
- With the SKILL function <u>rodCreatePath</u>
- By editing the ASCII version of your technology file

For information about editing your technology file, see "multipartPathTemplates" in the Virtuoso Technology File Data: ASCII Files Reference Manual.

You create a ROD path by specifying a point list for the master path or by specifying one or more named objects as a source for the points of the master path.

A multipart path consists of a single *master path* and one or more *subparts*. The master path is an ordinary path; however, it is the defining part of a multipart path; all subparts are based on the master path. The subparts can be any combination of offset subpaths, enclosure subpaths, and sets of subrectangles.


# **Types of Subparts**

- An *offset subpath* is a path that is coincident with an edge of the master path, overlapping the master path, or separated from the master path.
- An *enclosure subpath* is a path with its centerline on the centerline of the master path and is usually narrower or wider than the master path. The system calculates its width using the width of the master path and a positive or negative enclosure value.
- A set of subrectangles consists of one or more subrectangles that are coincident with an edge of the master path, overlapping the master path, or separated from the master path

Relative Object Design Concepts

You can create any number of subparts. All subparts exist in relation to and depend on the master path. A subrectangle in a set of subrectangles is not an individual shape; it is part of that specific set of subrectangles. You cannot select or edit individual subrectangles.

For example, the multipart path shown below has one subpath and one set of subrectangles. Both the subpath and the set of subrectangles are offset from the master path.



#### **Master Paths**

You create the master path for a multipart path by specifying a list of points (point list). To control where the master path appears in relation to the point list, you can specify *justification* and an *offset*.

- Offset specifies the distance between the master path and the points in the point list.
- Justification specifies whether to offset the centerline, left edge, or right edge of the master path from the point list.
  - left offsets the left edge of the master path from the point list.
  - u right offsets the right edge of the master path from the point list.
  - center offsets the centerline of the master path from the point list.

Both offset and justification are relative to the direction of the master path. The direction of the master path is determined by the sequence in which you specify its points.

#### **Position of Master Path in Cellview**

The location of the master path in a layout cellview window in relation to the points in the point list depends on whether the offset value is positive or negative and on the direction of each segment in the point list, as shown in Table <u>1-2</u>.

Table 1-2 Position of Master Path in Relation to Point List


Direction of Point List Segment	Positive Offset	Negative Offset
Positive along X axis	Above	Below
Negative along X axis ◀	Below	Above
Positive along Y axis	Left	Right
Negative along Y axis	Right	Left

#### **Examples of Offsetting the Master Path**

The following examples show offset master paths.


# Master Path with Positive Offset, Left Justification

When the offset is positive with left justification, the left edge of the master path is offset from the point list, creating a master path on the left side of the point list.




### Master Path with Positive Offset, Right Justification

When the offset is positive with right justification, the right edge of the master path is offset from the point list, creating a master path on the left side of the point list.



#### Master Path with Positive Offset and Center Justification

When the offset is positive with center justification, the centerline of the master path is offset to the left of the point list, in relation to the direction of the point list.




Relative Object Design Concepts

When you specify a negative value for offset, the system offsets the master path to the right of the point list, using the left edge, right edge, or centerline of the master path, as specified by the justification.

#### Master Path with Negative Offset and Center Justification

When the offset is negative with center justification, the centerline of the master path is offset to the right of the point list, in relation to the direction of the point list.



# **Offset Subpaths**

You can create an offset subpath that is coincident with an edge of the master path, on the left or right side of the master path, or overlapping the master path. You can specify the width of an offset subpath or let it default to the minWidth rule for the subpath layer from the technology file. Offset subpaths inherit the same type of end as specified for the master path.

You determine where to create an offset subpath in relation to the master path by specifying the *separation* and *justification*. Both separation and justification are relative to the direction of the master path. The direction of the master path is determined by the sequence in which you specify its points.

Separation specifies the distance between the offset subpath and the master path.

Relative Object Design Concepts

- Justification specifies whether to separate edges or centerlines as follows:
  - □ left separates the right edge of the subpath from the left edge of the master path.
  - □ right separates the left edge of the subpath from the right edge of the master path.
  - center separates the centerline of the subpath from the centerline of the master path. center justification for subpaths follows the same rules as center justification for offset master paths.

# **Specifying Separation and Justification**

The location of an offset subpath in relation to the master path depends on the values of separation and justification, in relation to the direction of the master path. To create a subpath

- With its centerline on the master path centerline, specify center justification with zero separation
- Coincident with the left or right edge of the master path, specify left or right justification, respectively, and let separation default to zero
- With its centerline separated from the master path centerline, specify center justification with a positive or negative separation
- To the left or right of the master path, specify left or right justification, respectively, with a positive separation
- Overlapping the left or right edge of the master path, specify left or right justification, respectively, with a small negative separation

For a summary of how to specify separation and justification for offset subpaths, see Table <u>1-3</u>.

Table 1-3 Position of Offset Subpath in Relation to Master Path

Separation	Center Justification	Left Justification	Right Justification
Zero	Subpath centerline on master path centerline	Left edge of master path coincident with right edge of subpath	Right edge of master path coincident with left edge of subpath
Positive number	Subpath centerline on left side of master path centerline	Left edge of master path on right side of right edge of subpath	Right edge of master path on left side of left edge of subpath

Relative Object Design Concepts

Table 1-3 Position of Offset Subpath in Relation to Master Path, continued


Separation	Center Justification	Left Justification	Right Justification
Negative number	Subpath centerline on right side master path centerline	Left edge of master path on left side of right edge of subpath	Right edge of master path on right side of left edge of subpath


# **Examples of Offset Subpaths**


The following examples show offset subpaths in relation to a master path.

### Zero Separation for Offset Subpaths

When the separation value is zero (0), the offset subpath centerline is on the master path centerline, or the subpath is coincident with an edge of the master path, depending on the justification, as shown below:








## Positive Separation for Offset Subpaths

When the separation value is positive, the offset subpath is on the left or right side of the master path, depending on the justification.

For example, both Subpath A and Subpath B have positive separations.

Relative Object Design Concepts


- Subpath A has left justification, so the left edge the master path is separated from the right edge of Subpath A.
- Subpath B has right justification, so the right edge of the master path is separated from the left edge of Subpath B.



Relative Object Design Concepts

The following example shows a small, positive separation value with center justification, creating a subpath that overlaps the left edge of the master path. The subpath centerline is offset from the master path centerline.

Subpath has a small positive separation with center justification.




### Negative Separation for Offset Subpaths

When the separation value is negative, the offset subpath either overlaps the master path or is created on the side of the master path *opposite* the side specified by justification, relative to the direction of the master path.

Relative Object Design Concepts

The examples below show both small and large negative separation values with left justification. The left edge of the master path is separated from the right edge of the offset subpath.


Offset subpaths have a negative separation with left justification.



Relative Object Design Concepts

The examples below show both small and large negative separation values with right justification. The right edge of the master path is separated from the left edge of the offset subpath.

Offset subpaths have a negative separation with right justification.



Relative Object Design Concepts

The following example shows a small, negative separation with center justification, creating an offset subpath overlapping the right side of the master path. The subpath centerline is offset from the master path centerline.

Center justification

Master path
Subpath

Direction of master path

Negative separation from centerline to centerline.

Subpath has a small negative separation with center justification.

# **Enclosure Subpaths**

0:0

You create an enclosure subpath with its centerline on the centerline of the master path and its width calculated using the width of the master path plus a positive or negative enclosure value. The enclosure determines by how much the subpath is enclosed by the master path or by how much the master path is enclosed by the subpath.

You can specify the enclosure for the subpath or let it default to the minEnclosure rule from the technology file for the master path layer to the subpath layer. minEnclosure defines the minimum enclosure for the master path layer in relation to the subpath layer. Enclosure subpaths inherit the same type of ends as specified for the master path.

To define enclosure for the ends of the subpath, you can specify offsets or let the system default to the value of the  $n\_enclosure$  argument.

Relative Object Design Concepts


### **Examples of Enclosure Subpaths**

To calculate the width of an enclosure subpath, the system **subtracts** two times the enclosure value from the width of the master path:

Width of Enclosure Subpath = Width of Master Path - (2 \* Enclosure Value)

Therefore, a positive enclosure value creates a subpath that is narrower than the master path, and a negative enclosure value creates a subpath that is wider than the master path. The centerlines are always coincident.


The following examples show enclosure subpaths with positive and negative enclosure values.



The following example shows a master path with a width of 1.0 and an enclosure subpath with the enclosure value of a positive 0.2. Both ends of the subpath are offset by a negative 0.4.

Relative Object Design Concepts

Therefore, the master path encloses the subpath by 0.2 on each side, making the width of subpath 0.6. The end of the master path encloses the subpath by a negative 0.4.



# **Sets of Subrectangles**

You can create a set of subrectangles in relation to the centerline of any master path. The set can contain one or more subrectangles.

You can specify the width and length of the subrectangles or let them default to the minWidth rule for the subrectangle layer from the technology file. You can offset the centerline of the subrectangles from the master path centerline, and you can offset the edge of the first and last subrectangles from the ends of the master path. You can also specify the offset of the first and last subrectangle in a segment. The system places subrectangles on grid.

You can create connectivity for a set of subrectangles. When you specify that a set of subrectangles is a pin, each rectangle in the set becomes a pin. In the layout editor, a set of subrectangles is treated as a single shape. You cannot edit or select individual subrectangles.

Although a set of subrectangles is treated as a single shape, you can get a list of the database IDs for the individual subrectangles in the set by using the ROD object ID for the multipart path with the database access operator (~>) and the attribute name subShapes. If you use the database ID to change connectivity information (such as terminal name) for one or more individual subrectangles, your change is applied to the individual subrectangles immediately, and propagated to all of the subrectangles in the set of subrectangles when the MPP is

Relative Object Design Concepts

modified in any way (such as moved). For more information, see <u>Accessing ROD Object</u> Attributes.

**Note:** The system creates subrectangles only for orthogonal path segments (segments parallel or perpendicular to an axis). The system does not create or regenerate subrectangles in nonorthogonal segments.

# **Specifying Separation and Justification**

The location of a set of subrectangles in relation to the master path depends on the values of separation and justification, in relation to the direction of the master path, just as it does for offset subpaths. The system places subrectangles on grid, as close to the specified separation as possible. To create a set of subrectangles

- With the center of the width of the subrectangles on the master path centerline, specify center justification with zero separation
- Coincident with the left or right edge of the master path, specify left or right justification, respectively, and let separation default to zero
- With the center of the width of the subrectangles separated from the master path centerline, specify center justification with a positive or negative separation
- To the left or right of the master path, specify left or right justification, respectively, with a positive separation
- Overlapping the left or right edge of the master path, specify left or right justification, respectively, with a negative separation

For a summary of how to specify separation and justification for sets of subrectangles, see Table 1-4.

Table 1-4 Position of Subrectangles in Relation to Master Path

Separation	Center Justification	Left Justification	Right Justification
Zero	Center of width of subrectangles on master path centerline	Left edge of master path coincident with right edge of subrectangles	Right edge of master path coincident with left edge of subrectangles
Positive number	Center of width of subrectangles on left side of master path centerline	Left edge of master path on right side of right edge of subrectangles	Right edge of master path on left side of left edge of subrectangles

Relative Object Design Concepts

Table 1-4 Position of Subrectangles in Relation to Master Path

Separation	Center Justification	Left Justification	Right Justification
Negative number	Center of width of subrectangles on right side of master path centerline	Left edge of master path on left side of right edge of subrectangles	Right edge of master path on right side of left edge of subrectangles

When you specify connectivity for a set of subrectangles, the connectivity applies to all rectangles in the set. Similarly, when you specify that a set of subrectangles is a pin, all rectangles in the set become pins.


For a detailed description of how the system creates subrectangles, see <u>How the System Follows to Create Subrectangles</u> in Virtuoso® Relative Object Design SKILL Reference book.

### **Examples of Sets of Subrectangles**

The following examples show sets of subrectangles in relation to a master path.

### Zero Separation for a Set of Subrectangles

When the separation value is zero (0), the centerline of the subrectangles is on the master path centerline or the subrectangles are coincident with an edge of the master path, depending on the justification, as shown below:




#### Positive Separation for a Set of Subrectangles

When the separation value is positive, the subrectangles overlap the master path or are on the left or right side of the master path, depending on the size of the separation value and on the justification.

For example, both Subrectangles A and Subrectangles B have positive separations.

Relative Object Design Concepts


- Subrectangles A has left justification, so the left edge of the master path is separated from the right edge of Subrectangles A.
- Subrectangles B has right justification, so the right edge of the master path is separated from the left edge of Subrectangles B.



Relative Object Design Concepts

The following example shows subrectangles that overlap the left edge of the master path, created with a small, positive separation value and center justification. The subpath centerline is on the left side of the master path centerline.

Subrectangles have a small positive separation with center justification.




## Negative Separation for a Set of Subrectangles

When the separation value is negative, the set of subrectangles either overlaps the master path or is created on the side of the master path *opposite* the side specified by justification, relative to the direction of the master path.

Relative Object Design Concepts

The examples below show both small and large negative separation values with left justification. The left edge of the master path is separated from the right edge of the set of subrectangles.


Subrectangles have a negative separation with left justification.



Relative Object Design Concepts

The following example shows subrectangles that overlap the right edge of the master path, created with a small, negative separation and center justification. The master path centerline is separated from the subrectangle centerline.

Subrectangles have a small negative separation with center justification.




# **Ends of Paths and Subrectangles**

You can specify extensions for each end of a master path to make the end extend beyond the start and/or end point of the master path centerline. To specify end extensions for a master

Relative Object Design Concepts

path, use the  $n\_beginExt$  and  $n\_endExt$  arguments, with the master path  $S\_endType$  argument set to variable.



All subparts inherit the end extensions of the master path.

#### Offsetting the Ends of Subpaths and Subrectangles

You can create a subpath or set of subrectangles that is longer or shorter than the master path. You do this by specifying the  $n\_beginOffset$  and  $n\_endOffset$  arguments to offset the ends of the subpath or subrectangle from the ends of the master path. With or without an offset, subpaths and subrectangles are generated starting at the first edge of the master path.

If you do not specify offsets, the system creates the ends as follows:


- For offset subpaths and sets of subrectangles, the end offsets default to zero, so their ends are coincident with the ends of the master path.
- For enclosure subpaths
  - If you specify only  $n\_beginOffset$ ,  $n\_endOffset$  defaults to  $n\_beginOffset$ ; if you specify only  $n\_endOffset$ ,  $n\_beginOffset$  defaults to  $n\_endOffset$ .
  - ☐ If you do not specify an offset but do specify an enclosure, the offsets default to the negative of the enclosure.
  - If you specify neither an offset nor an enclosure, the system *subtracts* the value of the minEnclosure rule (from the technology file for master path layer to subpath layer) from the ends of the master path to calculate the offset for the ends of the

Relative Object Design Concepts


enclosure subpath. If the minEnclosure rule is not defined in the technology file, the system reports an error.

#### **Examples of Ends of Subpaths and Subrectangles**

When offsets of the ends are positive, the subpath extends beyond the master path. When negative, the master path extends beyond the subpath.




In the following examples of sets of subrectangles, the rectangles are 1 unit wide and 2 units long, spaced 1 unit apart.




## Positive Offsets for Ends of Subrectangles

This example shows small positive offsets for the ends of a set of subrectangles.




This example shows larger positive offsets for the ends of a set of subrectangles.




Relative Object Design Concepts

The following example shows positive offset values for the ends of a set of rectangles when the master path has extended ends.



## Negative Offsets for Ends of Subrectangles

This example shows negative offsets for the ends of a set of subrectangles.



Relative Object Design Concepts

# Keeping Subrectangles Out of the Corners of Subrectangle Subpaths

If you want to keep the corners of the segments of a subrectangle subpath free of subrectangles, you can do so by specifying the  $n\_beginSegOffset$  and  $n\_endSegOffset$  arguments. For a detailed description, see <u>Subrectangles in the Corners of Segments</u> in the Virtuoso® Relative Object Design SKILL Reference book.

# **Making Paths Choppable**

You can define one or more parts of a multipart path as choppable. When you define the master path as choppable, then all of its subpaths and subrectangles must be choppable also. When you define the master path is not choppable, you can define each subpath or set of subrectangles as choppable or not choppable.

When an object is choppable, you can use the Virtuoso layout editor *Chop* command or the rodAddMPPChopHole function to separate it into two or more paths; the results are the same with either method.

For an overview of how chopping affects multipart paths, see Chopping Multipart Paths.

# **Connectivity for Multipart Paths**

You can create connectivity for any or all parts in a multipart path by associating them with a specific terminal and net. You can also make one or more parts into pins. When you specify that a master path or a subpath is a pin, the whole path becomes a pin. When you specify that a set of subrectangles is a pin, each rectangle in that set of subrectangles becomes a pin.

# **System-Defined Handles for Multipart Paths**

The system defines handles for multipart paths based on the points of the master path only. For more information, see <a href="System-Defined Handles">System-Defined Handles</a>.

# **Multipart Paths as ROD Objects**

When you create a multipart path, the system creates both a path and a *ROD object* containing information associated with the path, including its name and database ID. The ROD object is identified by a *ROD object ID*. The database ID for a multipart path identifies the master path.

Relative Object Design Concepts

For a detailed description of ROD objects and ROD object IDs, see <u>About ROD Objects and ROD Object IDs</u>.

## **Creating a Path from Other Objects**

You can create a new path from one or more of the following: an instance or any ROD object without specifying the points for the path.

For a detailed overview about creating objects from other objects, see <u>Creating Objects from Objects</u>.

## **Editing Multipart Paths**

For a summary of how the Virtuoso layout editor commands work with ROD objects, see <u>Appendix E, "How Virtuoso Layout Editor Works with ROD Objects."</u> Using commands that are not fully supported for ROD objects could cause the objects to lose the ROD information associated with them, changing the objects into ordinary, unnamed shapes.

When you select any part of a multipart path in a layout cellview window, all shapes in the multipart path are selected and highlighted. When you modify a multipart path with the Virtuoso layout editor, changes to the master path also affect all of its subparts; you cannot edit or copy an individual subpart. For example:

- Chopping a multipart path affects all choppable parts of the multipart path.
- Stretching a segment of a multipart path stretches the segment subpaths and, for orthogonal segments, regenerates subrectangles. The number of subrectangles in a subpath changes; the shape of the subrectangles does not change.

When you edit a multipart path that has subrectangles, the system regenerates all subrectangles that occur in orthogonal segments (segments parallel or perpendicular to an axis). The system does not generate or regenerate subrectangles in nonorthogonal segments.

## **Chopping Multipart Paths**

You can define one or more parts of a multipart path as choppable.


- When you define the master path as choppable, then all of its subpaths and subrectangles must be choppable also.
- When you define the master path is not choppable, you can define each subpath or set of subrectangles as choppable or not choppable.


Relative Object Design Concepts

- If the master path is choppable, you can chop the whole multipart path into two or more separate multipart paths by chopping all the way through the master path at 90 degrees.
- If the master path is not choppable, you can chop all subparts that are specified as choppable by chopping all the way through the master path at 90 degrees. All choppable subparts are chopped where you chop over the master path.

Master path is not choppable, but subparts are choppable.


Master path is choppable; therefore all subparts are choppable.






When you chop a choppable master path, the system assigns the name of the original multipart path to the first new multipart path, where "first" is relative to the direction of the master path.

The system assigns unique names to the other new multipart paths, starting with path0, path1, and so on, as shown below.




# **Chopping Multipart Paths That Have Alignments**

When you chop through the (choppable) master path of a multipart path, alignments to other objects are lost. The following example shows what happens to an aligned object after cutting away a section of a choppable master path named pathA.




When you use the cutter to chop out part of the master path like this,



Relative Object Design Concepts

the result is two new, shorter multipart paths, neither of which are aligned to rect1.



The system keeps the name pathA with the first new multipart path and assigns a unique name in the format of pathn to the second new multipart path.


For more information about how the layout editor *Chop* command affects multipart paths, see <u>"How Chopping Affects Multipart Paths"</u> in the *Virtuoso Layout Suite L User Guide*.

#### **Stretching Multipart Paths**

You can stretch the ends, segments, and/or corners of a multipart path in the same way you stretch single-part paths; however, the master path and its subparts stretch together. You cannot stretch the master path separately from its subparts, nor can you stretch subparts separately from the master path.

Relative Object Design Concepts

In the example below, when you stretch the bottom segment downward, all parts of the multipart path stretch together. The system regenerates subrectangles to fill the orthogonal segments affected by the stretch.



You can select and stretch the chopped ends of subpaths. When the multipart path contains sets of subrectangles, the system regenerates subrectangles along orthogonal segments only.

For more information about stretching multipart paths, see <u>"Stretching Multipart Paths"</u> in the *Virtuoso Layout Suite L User Guide*.


# **Creating Objects from Objects**

Using the <u>rodCreateRect</u>, <u>rodCreatePolygon</u>, or <u>rodCreatePath</u> function, you can create a new rectangle, polygon, or path from an instance or ROD object or from multiple objects. The existing objects are referred to as *source objects*, and the new object is referred to as the *generated object*.

When the source is a single object, you specify the difference between the size of the source object and the size of the generated object. For example, from a source rectangle, the system

Relative Object Design Concepts

uses a positive size to generate an new, larger rectangle, and a negative size to generate a new, smaller rectangle.



When the source is more than one object, you specify the difference between a bounding box around all of the objects and the size of the generated object.

If you specify a negative size that is too small for generating a new object, the system reports an error. For example, when the source object is a path and you specify a negative size, its absolute value cannot be equal to or greater than half of the width of the source path. If the source path has a width of 4, you cannot generate a new path by specifying a size of -2. Applying -2 to the perimeter of the source path would produce a path with a width that is less than or equal to zero.

**Note:** In the current release, no relationship exists between a generated object and its source object(s) after the generated object is created.


# Creating a Rectangle from Another Object

You can create a new rectangle from one or more ROD objects. The system computes the point list for the new rectangle by applying the size you specify to the bounding box around the source object(s). When the source object is also a rectangle, its bounding box is the same as its shape.


The following sections show examples of creating rectangles from a variety of shapes.

## Creating a Rectangle from a Rectangle

When the source object is a rectangle,




and you specify the size as +3, the system generates a new, larger rectangle. When you specify the size as -3, the system generates a new, smaller rectangle.




## Creating a Rectangle from a Polygon

When the source object is a polygon,




and you specify the size as +3, the system computes a bounding box around the polygon and generates a new rectangle that is larger than the bounding box. When you specify the size as -3, the system generates a new rectangle that is smaller than the bounding box.




# Creating a Rectangle from a Path

When the source object is a path,




and you specify the size as +3, the system computes a bounding box for the path and generates a new rectangle that is larger than the bounding box. When the size is -3, the system generates a rectangle that is smaller than the bounding box.




#### **Creating a Rectangle from Multiple Objects**

When there are several source objects,



and you specify the size as +3, the system computes a bounding box around all of the objects and generates a new rectangle that is larger than the bounding box. When you specify the size as -3, the system generates a rectangle that is smaller than the bounding box.




# **Creating a Polygon from Another Object**

You can create a new polygon from one or more instances and/or ROD objects. The system computes the point list for the new polygon by applying the size you specify. If you specify a size that is too small for generating a new polygon, the system reports an error.


The following sections show examples of creating polygons from a variety of shapes.

## Creating a Polygon from a Rectangle

When the source object is a rectangle,




and you specify the size as +3, the system generates a new polygon that is larger than the bounding box. When you specify the size as -3, the system generates a new polygon that is smaller than the bounding box.




## Creating a Polygon from a Polygon

When the source object is a polygon,




and you specify the size as +2, the system generates a new, larger polygon. When you specify the size as -2, the system generates two new, smaller polygons that are not connected, because -2 is smaller than the narrowest part of the source polygon.




# Creating a Polygon from a Path

When the source object is a path,




and you specify the size as +3, the system generates a new polygon that is larger than the path.




Relative Object Design Concepts

When you specify the size as -2, the system generates a new polygon that is smaller than the path.




# **Creating a Polygon from Multiple Objects**

When there are several source objects,



Relative Object Design Concepts

and specify the size as +2, the system computes a bounding box around all of the objects and generates a new polygon that is larger than the bounding box. When you specify the size as -2, the system generates a new polygon that is smaller than the bounding box.



# **Creating a Path from Another Object**

You can create a new path from any ROD object or from multiple ROD objects. You can specify a size differential and also a starting and ending point or let the new path default to a self-abutting ring. When the source object is a path, the system applies the size differential to its perimeter.

When generating a path, the system does the following:

- Computes the point list for the new path by applying the size as the distance between the centerline of the generated master path and
  - □ For a single source object, the perimeter of the source object.
  - □ For multiple source objects, the bounding box around all of the source objects.

If you specify a negative size that is too small for generating a new path, the system reports an error. For example, when the source object is a path, the absolute value of a negative size cannot be greater than or equal to half of the width of the source path.

- Starts the path at the point closest to the starting point of the source object. For rectangles, instances, and multiple source objects, the generated path always starts relative to the lower-left corner of the bounding box around the source object(s).
- Creates the direction of the new path as follows:

Relative Object Design Concepts


- ☐ When the source object is a single rectangle, instance, or path, in a clockwise direction.
- □ When there are multiple source objects, in a clockwise direction.
- ☐ When the source object is a polygon, in the direction in which the polygon was created. For example, when the source polygon was created in a counter-clockwise direction, the system creates the path in a counter-clockwise direction.

**Note:** The system does not allow you to create self-intersecting master paths. If the master path you are creating would be self-intersecting, the path is not created, and a warning message is displayed in the CIW. The same is true for subpaths.

The following sections show examples of creating paths from a variety of shapes.


#### Creating a Path from a Rectangle

When the source object is a rectangle,




Relative Object Design Concepts

and you specify the size as +2, the system generates a new, larger path. When you specify the size as -2, the system generates a new, smaller path.




# Creating a Path from a Polygon

When the source object is a polygon,




Relative Object Design Concepts

and you specify the size as -1, the system generates a new path inside the perimeter of the polygon.




Here is a close up of the bottom left side of the polygon and new path:




Relative Object Design Concepts

When you specify a small enough size, in this case -5, the system generates a new path only inside the perimeter of the right side of this polygon.




When you specify the size as +2, the system generates a new path outside the perimeter of the polygon.




Relative Object Design Concepts

Here is a close up of the bottom right corner of the polygon and new path:




## Creating a Path from a Path

When the source object is a path with a width of 3,



Relative Object Design Concepts


and you specify the size as +4, the system generates a new path that is larger than the source path.




Using the source path with a width of 3 from the previous example, the system would not create a path with a size of -1.5 because the absolute value of -1.5 is greater than or equal to half of the width of the source path. The system cannot create a path unless its width is greater than zero.

Relative Object Design Concepts

Here is an example of specifying a negative size to generate a new path from an existing path. When the source path has a width of 6,




and you specify the size as -2, the system generates a new path that is smaller than the source path.




#### **Creating a Path from Multiple Objects**

When you specify multiple source objects,



the generated path forms a ring with the centerline of the master path offset from the bounding box by the size you specify. By default, the path has four segments. The new path is longer or shorter depending on whether you specify a positive or negative size.



# Connectivity

When you use a ROD function to create a shape, such as a rectangle or path, you can specify connectivity for the shape by associating it with a specific terminal and net. You can also make the shape into a pin.

Relative Object Design Concepts

To specify connectivity for an object, you must use the *ROD connectivity arguments*. You can do this within a rodCreate function, such as rodCreateRect, by specifying values for the terminal name, terminal I/O type, and pin connectivity arguments.

For a multipart path, you can create connectivity for any or all parts of the multipart path: the master path, subpaths and/or subrectangles. When you make the master path into a pin, the whole master path becomes a pin; when you make a subpath into a pin, the whole subpath becomes a pin; and when you make a set of subrectangles into a pin, each rectangle in the set becomes a pin.

When you create a repeated object with connectivity, the connectivity applies to all objects in the repeat set. For a description of the connectivity arguments, see <u>ROD Connectivity</u> <u>Arguments for Rectangles</u>.

To look at the connectivity for ROD objects, you can use the Edit Properties form. For information about this form, see <u>"Editing and Defining Properties"</u> in the *Virtuoso Layout Suite L User Guide*.

**Note:** To see terminal names for pins in a layout window, the display setting for pin names must be turned on. For information about how to change the display of pin names, see <u>Displaying Pin Names in a Layout Window</u>.


# **Maintaining Connections for ROD Objects**

The Virtuoso layout editor *Maintain Connections* option works for unaligned ROD objects. However, for objects that are aligned, ROD alignments take precedence over maintaining connections.


Relative Object Design Concepts

The following example shows the results of moving an object with the *Maintain Connections* option on, both when the object has an alignment and when it does not. In the example, there are two instances, each containing a pin, with a ROD (named) path connecting the pins.

Instances IA and IB before the move.




When objects do not have ROD alignments and the *Maintain Connections* option is on, moving instance IB causes the ROD path connecting the two pins to stretch, as shown below.



When objects do have a ROD alignment, and the *Maintain Connections* option is on, moving instance IB causes the whole ROD path to move, as shown below. The aligned path

Relative Object Design Concepts

does not stretch, so moving instance  $\[mule$  breaks the electrical connection between the two pins.



# **Preserving Maintained Connections**

If you want the *Maintain Connections* option to take precedence over ROD alignments, you must either unalign the ROD objects or remove the name from one of the aligned objects. For example, to preserve the connection between the two pins shown above while moving one of the instances, you can unalign the pin in instance IB from the ROD path or remove the name from either the IB pin or the ROD path.

To unalign an object, see <u>rodUnAlign</u>. To remove the name from an object, see <u>rodUnNameShape</u>.

2

# Accessing Information about ROD Objects

This chapter describes Virtuoso® relative object design (ROD) objects, ROD object IDs, ROD object attributes, and how to access ROD object attributes. The topics covered are

About ROD Objects and ROD Object IDs

Accessing ROD Object Attributes

rodCoord Objects

# **About ROD Objects and ROD Object IDs**

Every named database object, such as an instance, layout cellview, or named shape, automatically has relative object design information associated with it. This information is stored in a *ROD object*. A ROD object is also a database object, but it exists in relation to its associated named database object. A ROD object is identified by a unique *ROD object ID*.

A ROD object for a named shape, instance, or cellview contains the following information:

hierarchical name
cellview ID
database ID
transformation information (rotation, magnification, and offset)
alignment information, if any
number of segments (for shapes)
names and values of user-defined handles, if any
names of system-defined handles

A ROD object ID is similar to a database ID. The database ID for an object is the temporary address in memory for the object. A ROD object ID is the temporary address for the ROD object associated with a specific database object. When you look at these two IDs in the Command Interpreter Window (CIW) for a database object, the database ID might be db: 98342974 and the ROD object ID rodobj: 23970843.

You can create a new ROD database shape and its associated ROD object by using one of the rodCreate functions, such as rodCreateRectangle. You can also use the rodNameShape function to assign a name to an existing, unnamed database shape; the rodNameShape function creates a new associated ROD object for the shape.

The value of the ROD object ID is returned when you execute the function <code>rodGetObj</code>, <code>rodNameShape</code>, or a <code>rodCreate</code> function, such as <code>rodCreateRect</code>. You might want to store the value returned in a variable so that you can refer to it later. You can also get the ROD object IDs for all of the named shapes in a cellview with a ROD function; see <code>rodGetNamedShapes</code>.

**Note:** In the current release, ROD functionality is not implemented for mosaics.

# Getting the ROD Object ID

You can get the ROD object ID for a named shape, instance, or cellview in the current open design window by performing one of the following steps.

Accessing Information about ROD Objects

➤ For a named shape, or instance, type the rodGetObj function using as input either the database ID of the object or both the hierarchical name of the object and the top-level layout cellview ID:

```
rodId = rodGetObj( dbId )

or
rodId = rodGetObj( "hierarchical_name" cellview_ID )
```

where dbId is the database ID,  $hierarchical\_name$  is the hierarchical name of the object, and  $cellview\_ID$  is the cellview ID. When you want the cellview ID (the database ID for the cellview) for the current open cellview, you can use the  $\underline{deGetCellView}$  function without any arguments.

For example, you can get the names of all attributes for the named shape polyRect, where polyRect is in instance ptr1 and ptr1 is in instance INV1, by typing the following statements in the CIW:

```
cvId = deGetCellView()
rodId = rodGetObj( "INV1/ptr1/polyRect" cvId )
```

where the statement cvId = deGetCellView() returns the cellview ID for the active cellview.

➤ To get the ROD object ID for a cellview, use an empty string ("") for the hierarchical name:

```
rodId = rodGetObj( "" cvId )
```

# **Getting the ROD Object ID Interactively**

You can get the ROD object ID for one or more objects in an open layout cellview window by selecting the object(s) and typing commands in the Command Interpreter Window (CIW). Depending on whether you want to select a single object or multiple objects, do one of the following:

### Getting the ROD Object ID for a Single Object

1. Get the cellview ID for the active cellview window by typing in the CIW

```
cvId = deGetCellView()
```

- 2. Select one object in the layout cellview window.
- 3. Get the database ID of the selected object and set it equal to the variable dbId by typing in the CIW

```
dbId = car(geGetSelectedSet(cvId))
```

Accessing Information about ROD Objects

where the SKILL list operator car returns the first item in the list; in this case, the only item.

4. Get the ROD object ID of the selected object by typing in the CIW

```
rodId = rodGetObj(dbId)
```

### **Getting the ROD Object ID for Multiple Objects**

1. Get the cellview ID for the active cellview window by typing in the CIW

```
cvId = deGetCellView()
```

- 2. Select two or more objects in the layout cellview window.
- 3. Set a variable equal to a list of the database IDs of the selected objects by typing in the CIW

```
dbIdList = geGetSelectedSet(cvId)
```

To get the ROD object ID for a specific object in the list, use the SKILL list operators, such as car and cdr.

# Storing the ROD Object ID as a Variable (Avoid)

There are circumstances under which a ROD object ID might change. For example, doing an *Undo* and *Redo* assigns new ROD object IDs to all ROD objects in the cellview. Therefore, rather than storing a ROD object ID in a variable, it is safer to retrieve it when you need it. For example, rather than stating:

```
r = rodCreateRect( ?name "a" ?cvId cv ... )
... ; More lines of code here
rodAlign( ?alignObj r ... )
state the following:
rodCreateRect( ?name "a" ?cvId cv ... )
... ; More lines of code here
rodAlign( rodGetObj( "a" cv) ... )
```

For more information about the effect of *Undo* and *Redo* on ROD object IDs, see <u>Appendix H, "ROD object ID changes after Undo"</u>.

Accessing Information about ROD Objects

# Checking Whether an Object Is a ROD Object

The easiest way to find out if an object is a ROD object is with the Virtuoso layout editor *Edit Properties* command. You can also verify whether an object is a ROD object in the CIW or within a program.

### **Checking with the Edit Properties Command**

To check whether an object is a ROD object, do the following:

- **1.** In your layout cellview window, select the object.
- **2.** Choose *Edit Properties* or press q.

The Edit Properties from appears.

**3.** Look at the bottom of the for a *ROD Name* field.

If there is a *ROD Name* field, the object is a ROD object; otherwise, the object is not a ROD object.

**4.** To see the ROD properties for a ROD object, click the *ROD* button at the top of the Edit Properties form.

The form changes to show ROD properties for the selected object.

For more information about this form, see <u>"Editing and Defining Properties"</u> in the *Virtuoso Layout Suite XL: Basic Editing User Guide*.

### Checking in the CIW

To check in the CIW whether an object is a ROD object, you must first assign the object to a variable, then test the variable in either of the two ways shown below, where  $variable\_name$  is a variable whose value might be a ROD object ID:

■ Use the rodIsObj function by typing

```
rodIsObj( variable_name )
```

If rodIsObj returns t, the object is a ROD object.

■ Test for equivalency with the internal name of the ROD object data type ('rodObj) by typing

```
if( type( variable_name ) == 'rodObj
    then ...
) ; end if
```

where `rodObj is a symbol.

Accessing Information about ROD Objects

**Note:** If you edit an object identified by  $variable\_name$  and then undo the edit, the system no longer associates  $variable\_name$  with the object. Therefore, further references to  $variable\_name$  result in nil or rod:invalid. For more information see ROD object ID changes after Undo.

### **Checking in a Program**

To verify whether an input parameter to a procedure you write contains a ROD object ID, you can test to see if the data type is  $\mathbb{R}$ , the data type for ROD objects. The following sample procedure tests  $parameter\_name$  to see if the data type is  $\mathbb{R}$ :

```
procedure(printObjType( parameter_name "R" )
printf("ROD object type is: %L" parameter_name~>dbId~>objType)
) ; end procedure
```

When the data type for parameter\_name is R, the procedure prints the type of ROD object, such as inst, rect, polygon, or path, as shown below:

```
ROD object type is: "rect"
```

When the data type for  $parameter\_name$  is not  $\mathbb{R}$ , the procedure returns an error message similar to the following:

```
*Error* printObjType: argument #1 should be rodObj (type template = "R") - db:21218404
```

For information about basic Cadence<sup>®</sup> SKILL language functions, including list operators, refer to the *SKILL Language Reference Manual*.

# **Accessing ROD Object Attributes**

You can access predefined attributes for any of the following named objects: instances, cellviews, and named rectangles, polygons, paths, lines, dots, labels, and text-display objects.

Use the ROD object ID and the database access operator (~>) with

- The name of an attribute to get the value of that attribute
- One question mark (?) to get a list of the names of all attributes
- Two question marks (??) to get the names and values of all attributes

Accessing Information about ROD Objects

The following table shows the information you can access with the ROD object ID and the database access operator ( $\sim$ ).

Table 2-1 Using ~> to Access Information about ROD Objects

Attribute, Handle, or ?	Value Returned
~>?	List of names for all ROD object attributes.
~>??	List of the names and values for all attributes.
~>align	Alignment information for the ROD object.
~>chopHoles	List of lists, where each list contains the coordinates of a chop hole in a MPP; nil where there are no chop holes in the MPP.
~>cvId	ID of the top-level cellview containing the ROD object.
~>dbId	Database ID of the ROD object at the lowest level. For multipart paths, dbId identifies the master path.
~>name	Hierarchical name for the ROD object.
~>numSegments	For shapes with segments (rectangles, polygons, and paths), the number of segments in the shape.
~>subShapes	For multipart paths, the ROD object ID identifies the master path. Use ~>subShapes to list the database IDs for all subshapes (subpaths and subrectangles) associated with a multipart path. The list includes one database ID for each individual subrectangle.
~>systemHandleNames	List of the names of all system-defined handles for the ROD object.
~>transform	Transform information for the ROD object, converted to the coordinate system of the top-most cellview.  Transform information is a list of the rotation, magnification, and offset.
~>userHandleNames	List of the names of all user-defined handles for the ROD object.
~>any_handle_name	Value of the specified handle.

For information about how to get the ROD object ID, see Getting the ROD Object ID.

Accessing Information about ROD Objects

# **Accessing Subpart Attributes**

Table 2-2 Using ~> to Access Information about Subpart Attributes

Subpart Attribute	Value Returned
mppId~>subPart	List of MPP subPartIds.
subPartId~>name	Name of the specified subPartId.
subPartId~>type	Type of the specified subpart. Returns "rectangle", "enclosure path", or "offset path".
subPartId~>layer	Layer name of the specified subpart.
subPartId~>purpose	Purpose name of the specified subpart.
subPartId~>lpp	List of strings signifying the layer-purpose pair of the specified subpart.
subPartId~>choppable	Boolean(t/nil) depending on whether the specified subpart is choppable or not.
subPartId~>netName	String signifying the name of the net with which the specified subpart is associated.
subPartId~>termName	String signifying the name of the terminal with which the specified subpart is associated.
subPartId~>pin	The pinId of the specified subpart.
subPartId~>paramList	List of parameters of the specified subpart.
offsetSubPathId~>width	Width of the specified offset subpath.
offsetSubPathId~>separa tion	The distance between the specified offset subpath and the master path.
offsetSubPathId~>justif ication	The type of justification of the specified offset subpath.
offsetSubPathId~>beginO ffset	The beginOffset value of the specified offset subpath.
offsetSubPathId~>endOff set	The endOffset value of the specified offset subpath.
encSubPathId~>enclosure	The enclosure value of the specified enclosure subpath.
<pre>encSubPathId~&gt;beginOffs et</pre>	The beginOffset value of the specified enclosure subpath.

Accessing Information about ROD Objects

Table 2-2 Using ~> to Access Information about Subpart Attributes, continued

encSubPathId~>endOffset	The endOffset value of the specified enclosure subpath.
subRect~>width	The width of the specified rectangle subpart.
subRect~>length	The length of the specified rectangle subpart.
subRect~>gap	The subrectangle distribution gap value ("minimum" or "distribute") of the specified rectangle subpart.
subRect~>space	The spacing value between individual rectangles in the specified rectangle subpart.
subRect~>justification	The type of justification of the specified rectangle subpart.
subRect~>beginOffset	The beginOffset value of the specified rectangle subpart.
subRect~>endOffset	The endOffset value of the specified rectangle subpart.
subRect~>beginSegOffset	The beginSegmentOffset value of the specified rectangle subpart.
subRect~>endSegOffset	The endSegmentOffset value of the specified rectangle subpart.

**Note:** When you use the ROD object ID to access a point handle for a named object, the system automatically transforms (converts) the coordinates of the point up through the hierarchy into the coordinate system of the top-most cellview containing the object. The values of system-defined handles are calculated on demand, when you reference them.

# **Examples of Using ~> to Display Information**


The following examples show some of the ways to display information about ROD objects in the CIW.

### **Example 1: Alignment Information**

You can query any named object to see what the object is aligned to. When you query a hierarchical object, the system displays all top-level alignments for the object.

Accessing Information about ROD Objects

The figure below shows instance I1 and rectangle rect0. Instance I1 contains instance I2. Instance I2 contains the polygon I1/I2/polyRect. The polygon I1/I2/polyRect is aligned to rect0 with a separation of -10.0.



To query rect0 for alignments, type the following in the CIW:

```
cvId = deGetCellView()
rodGetObj( "rect0" cvId )~>align
```

The system displays text similar to the following in the CIW:

```
((rodObj:2585108 "cR" rodObj:2585114 "cL" -10.0 0.0 )
```

The text above means the centerRight (cR) handle on I1/I2/polyRect (rodObj:2585108) is aligned to the centerLeft (cL) handle on rectO (rodObj:2585114), with a separation of -10.0 along the X axis and no separation along the Y axis.

### **Example 2: Attribute Names**

To display all attribute names for a ROD object, get its ROD object ID and type in the CIW: rodId~>?

where the variable rodId contains the ROD object ID.

The system displays a list of attribute names similar to the following list:

Accessing Information about ROD Objects

**Note:** The attribute numSegments appears in the list only for shapes with segments: rectangles, polygons, and paths.

### **Example 3: Attribute Names and Values**

To display all attribute names and values for any ROD object (a named shape, instance, or cellview), get its ROD object ID and type in the CIW:

```
rodId~>??
```

where the variable rodId contains the ROD object ID. If you do not want to use variables and the object is in the current open cellview, the following statement gets the same result:

```
rodGetObj( "hierarchical_name" deGetCellView() ) ~>??
```

### **Example 4: Value of One Attribute**

To get the value for a particular attribute, use the attribute name instead of a question mark:

```
rodId~>attribute name
```

For example, to display the value of the system-defined handle for the point in the center of the bounding box around a ROD object, type

```
rodId~>centerCenter
```


### **Example 5: Names of User-Defined Handles**

To display the names of all user-defined handles for an object, type in the CIW:

```
rodGetObj( "hierarchical_name" cellview_ID ) ~> userHandleNames
```

Accessing Information about ROD Objects

For example, assume the following four-segment, single-layer path named path2 is in the active cellview window, and that it has several user-defined handles.



You can use the <code>deGetCellView</code> function (without any arguments) to get the database ID for the current open cellview.

#### For this example, you would type:

```
cvId = deGetCellView()
userHandNames = rodGetObj( "path2" cvId )~>userHandleNames
```

### The system displays the following information in the CIW:

```
("stringHandle" "intHandle" "floatHandle" "trueHandle" "falseHandle"
"ILExprHandle" "pointHandle"
)
```

### **Example 6: Names of System-Defined Handles**


To display the names of all system-defined handles for an object, type in the CIW:

```
\verb|rodGetObj("hierarchical_name" cellview_ID") \sim \verb|systemHandleNames|| \\
```

For more information about using rodGetObj, see rodGetObj.

Accessing Information about ROD Objects

For example, assume the following two-segment, single-layer path named path1 is in the active cellview window.



You can use the deGetCellView function (without any arguments) to get the database ID for the current open cellview. For this example, you would type:

```
cvId = deGetCellView()
sysHandNames = rodGetObj( "path1" cvId )~>systemHandleNames
```

The system displays the following information for path1 in the CIW:

```
("width" "length" "lowerLeft" "lowerCenter" "lowerRight"
    "centerLeft" "centerCenter" "centerRight" "upperLeft"
    "upperCenter" "upperRight" "length0" "start0" "startCenter0"
    "startLeft0" "startRight0" "mid0" "midLeft0" "midRight0" "end0"
    "endLeft0" "endRight0""length1" "start1" "startLeft1"
    startRight1" "mid1" "midLeft1""midRight1" "end1" "endLeft1"
    "endRight1" "lengthLast" "startLast""startLeftLast"
    "startRightLast" "midLast" "midLeftLast" "midRightLast" "endLast"
    "endCenterLast" "endLeftLast" "endRightLast" "mmpBBox" "chopHoles"
)
```


### **Example 7: Names and Values of Attributes**

To display the names and values for all attributes of an object, type in the CIW:

```
rodGetObj( "hierarchical_name" cellview_ID )~>??
```

# Accessing Information about ROD Objects

Using the same example, assume the following four-segment, single-layer path named path2 is in the active cellview window.



You can use the deGetCellView function (without any arguments) to get the database ID for the current open cellview. For this example, you would type:

```
cvId = deGetCellView()
rodGetObj( "path2" cvId ) ~>??
```

### The system displays information in the CIW that looks like this:

```
("rodObj:17653796" name "path2" cvId db:16324652
   dbId db:16325104 transform
    ((0.0 0.0) "RO" 1.0) align
   nil numSegments 4 userHandleNames
    ("stringHandle" "intHandle" "floatHandle" "trueHandle"
        "falseHandle" "ILExprHandle" "pointHandle"
    systemHandleNames
    ("width" "length" "lowerLeft" "lowerCenter" "lowerRight"
        "centerLeft" "centerCenter" "centerRight" "upperLeft"
        "upperCenter" "upperRight" "length0" "start0" "startCenter0"
        "startLeft0" "startRight0" "mid0" "midLeft0" "midRight0"
        "end0" "endLeft0" "endRight0" "length1" "start1" "startLeft1"
        "startRight1" "mid1" "midLeft1" "midRight1" "end1"
        "endLeft1" "endRight1" "length2" "start2" "startLeft2"
        "startRight2" "mid2" "midLeft2" "midRight2" "end2"
        "endLeft2" "endRight2" "length3" "start3" "startLeft3"
"startRight3" "mid3" "midLeft3" "midRight3" "end3"
```

Accessing Information about ROD Objects

```
"endLeft3" "endRight3" "lengthLast" "startLast"
    "startLeftLast" "startRightLast" "midLast" "midLeftLast"
    "midRightLast" "endLast" "endCenterLast" "endLeftLast"
    "endRightLast" "mppBBox"
)
)
```

# **Getting System-Defined Handle Values with a Script**


You can display in the CIW the values for all system-defined handles for a selected ROD object in a cellview by using the SKILL procedure rodPrintSystemHandleValues. The procedure requires the ROD object ID as input.

### Problem 2-4 Getting Values of System-Defined Handles for a Path

You want to know the values of the system-defined handles for a particular ROD object in your active cellview. Use the rodPrintSystemHandleValues procedure to display the names and values of all system-defined handles.

You can load the procedure from the Cadence hierarchy or create a procedure file yourself and load your file. Instructions for accessing or creating the <a href="mailto:rodPrintSystemHandleValues">rodPrintSystemHandleValues</a> procedure are presented in the following Solution section. To access the ROD object <a href="mailto:path1">path1</a> using its name, you need the cellview ID.

For example, there is a two-segment single-layer path named path1. Use the rodPrintSystemHandleValues procedure to display the names and values of all system-defined handles for path1.



Accessing Information about ROD Objects

### Solution 2-4 Getting Values of System-Defined Handles for a Path

First, you need to load the <code>rodPrintSystemHandleValues</code> procedure into your system. You can access the <code>rodPrintSystemHandleValues.il</code> file from the <code>samples/ROD/skill</code> directory in your Cadence hierarchy or create the procedure yourself and load your file.

- 1. Access the rodPrintSystemHandleValues procedure in one of the following ways:
  - To create the procedure yourself, use a text editor to open a new file named rodPrintSystemHandleValues.il and type or copy the following statements:

```
; rodPrintSystemHandleValues.il
procedure( rodPrintSystemHandleValues(rodObj)
prog(( handleValue handleList)
    handleList = rodObj~>systemHandleNames
    if (handleList then
        printf( "System handle names and values for %L (%L):\n"
            rodObj~>name
            rod0bj
        ) ; end of printf
        foreach ( handle handleList
            handleValue = rodGetHandle(rodObj handle)
            printf("%L %L\n" handle handleValue)
        ); end of foreach
    else
        printf("%L has no system-defined handles.\n"
            rod0bj
        ) ; end of printf
    ) ; end of if
) ; end of prog
t ; procedure always returns t
) ; end of procedure
```

To load the rodPrintSystemHandleValues.il file you created, type the following in the CIW:

```
{\tt load "} your\_path/{\tt rodPrintSystemHandleValues.il"}
```

where your\_path is the path to your procedure file.

To load the procedure from the Cadence hierarchy, type

The rodPrintSystemHandleValues procedure requires the ROD object ID as input, so next you get the ROD object ID.

**2.** Get the ROD object ID for a selected object in the active cellview window by typing the following statements in the CIW:

```
cv = deGetCellView()
rodId = rodGetObj( "hierarchical_object_name" cv )
```

Accessing Information about ROD Objects

where the first statement gets the cellview ID for the active cellview and hierarchical\_object\_name is the name of your selected ROD object. For example:

```
rodId = rodGetObj( "path1" cv )
```

**3.** Run your rodPrintSystemHandleValues procedure by typing the following statement in the CIW:

```
rodPrintSystemHandleValues(rodId)
```

In the CIW, the system displays a list of all handle names and their values. For example, for path1, the system displays the following information in the CIW:

```
rodPrintSystemHandleValues(rodId)
System handle names and values for "path1" (rod0bj:29057048)
"width" 21.0
"length" 11.0
"lowerLeft" (2.7 1.4)
"lowerCenter" (13.2 1.4)
"lowerRight" (23.7 1.4)
"centerLeft" (2.7 6.9)
"centerCenter" (13.2 6.9)
"centerRight" (23.7 6.9)
"upperLeft" (2.7 12.4)
"upperCenter" (13.2 12.4)
"upperRight" (23.7 12.4)
"length0" (20.0)
"start0" (2.7 2.4)
"startCenter0" (2.7 2.4)
"startLeft0" (2.7 3.4)
"startRight0" (2.7 1.4)
"mid0" (12.7 2.4)
"midLeft0" (12.2 3.4)
"midRight0" (13.2 1.4)
"end0" (22.7 2.4)
"endLeft0" (21.7 3.4)
"endRight0" (23.7 1.4)
"length1" 10.0
"start1" (22.7 2.4)
"startLeft1" (21.7 3.4)
"startRight1" (23.7 1.4)
"mid1" (22.7 7.4)
"midLeft1" (21.7 7.9)
"midRight1" (23.7 6.9)
"end1" (22.7 12.4)
"endLeft1" (21.7 12.4)
"endRight1" (23.7 12.4)
"lengthLast" 10.0
"startLast" (22.7 2.4)
"startLeftLast" (21.7 3.4)
"startRightLast" (23.7 1.4)
"midLast" (22.7 7.4)
"midLeftLast" (21.7 7.9)
"midRightLast" (23.7 6.9)
"endLast" (22.7 12.4)
"endCenterLast" (22.7 12.4)
"endLeftLast" (21.7 12.4)
"endRightLast" (23.7 12.4)
```

```
"mppBBox" (((2.7 1.4) (23.7 12.4)))
```

# **Getting User-Defined Handle Names with a Script**


You can display in the CIW the values for all user-defined handles for a selected ROD object in a cellview by using the SKILL procedure <code>rodPrintUserHandleValues</code>. The procedure requires the ROD object ID as input.

### Problem 2-5 Getting Values of User-Defined Handles for a Path

You want to know the values of the user-defined handles for a particular ROD object in your active cellview. Use the rodPrintUserHandleValues procedure to display the values of all handles assigned to the four-segment, single-layer path named path2. Assign the results to the local variable userHandValues.

You can load the <code>rodPrintUserHandleValues.il</code> file from the <code>samples/ROD/skill</code> directory in your Cadence hierarchy or create the procedure file yourself and load your file. Instructions for creating and loading the <code>rodPrintUserHandleValues</code> procedure are presented in the Solution section.

To access the ROD object path2 using its name, you need the cellview ID.



Accessing Information about ROD Objects

### Solution 2-5 Getting Values of User-Defined Handles for a Path

- 1. Access and load the rodPrintUserHandleValues procedure in one of the following ways:
  - To create the procedure yourself, use a text editor to open a new file named rodPrintUserHandleValues.il and type or copy the following statements:

```
; rodPrintUserHandleValues.il
procedure( rodPrintUserHandleValues(rodObj)
  prog((handle handleValue handleList)
        handleList = rodObj~>userHandleNames
        if (handleList then
        printf( "User handle names and values for %L (%L):\n"
                 rodObj~>name
                 rodObj
        ) ; end printf
        foreach (handle handleList
                 handleValue = rodGetHandle(rodObj handle)
                 printf("%L %L\n" handle handleValue)
        ) ; end foreach
        else
          printf("%L has no user-defined handles.\n" rodObj)
        ) ; end if
 ) ; end of prog
t ; procedure always returns t
) ; end of procedure
```

To load the rodPrintUserHandleValues procedure you created, type the following statements in the CIW:

```
load "your_path/rodPrintUserHandleValues.il"
```

where your\_path is the path to your procedure file.

To load the procedure from the Cadence hierarchy, type

```
load prependInstallPath("samples/ROD/skill/rodPrintUserHandleValues.il")
```

The rodPrintUserHandleValues procedure requires the ROD object ID as input, so next you get the ROD object ID.

2. Get the ROD object ID for a selected object in the active cellview window by typing the following statements in the CIW:

```
cv = deGetCellView()
rodId = rodGetObj( "hierarchical_object_name" cv )
```

where the first statement gets the cellview ID for the active cellview and hierarchical\_object\_name is the name of your selected ROD object. For example:

```
rodId = rodGetObj( "path2" cv )
```

Accessing Information about ROD Objects

**3.** Run your rodPrintUserHandleValues procedure by typing the following statements in the CIW:

```
rodPrintUserHandleValues(rodId)
```

In the CIW, the system displays a list of all user-defined handle names and their values. For example, for path2, the system displays the following information in the CIW:

```
rodPrintUserHandleValues(rodId)
User handle names and values for "path2" (rodObj:29057048)
"stringHandle" "aaa"
"intHandle" 311
"floatHandle" 3.3
"trueHandle" t
"falseHandle" nil
"ILExprHandle" 1.8
"pointHandle" (6.6 7.7)
t
```

# rodCoord Objects

A rodCoord object is a user type implemented by C/C++ in the Virtuoso environment. It is used to store values given in user unit as an integer after applying the arithmetic resolution factor and supported with arithmetic, logical, and snapping to grid operations.

A rodCoord object contains the following information:

- User input in arithmetic resolution unit
- Grid information in arithmetic unit
- Arithmetic resolution factor

A rodCoord object can be used in many basic operations, such as arithmetic and logical operations, snapping, and determining the maximum or minimum value. The main objective of using rodCoord is to standardize the solution for handling rounding orsnapping requirements.

### Advantages of using rodCoord

A rodCoord object is useful for transmitting the scale information. An arithmetic operation using both rodCoord and a scalar value is not acceptable because the operands are not compatible.

### For example,

```
rodCoord(0.01) + 20 = ??
```

Accessing Information about ROD Objects

Therefore, operands for the plus operation should be rodCoord. The same use model is true for most arithmetic and logical operators, as well as most related APIs.

# Virtuoso Relative Object Design User Guide Accessing Information about ROD Objects

A

# **Using Relative Object Design Functions**

This chapter contains information on using Virtuoso relative object design (ROD) functions.

For information on relative object design (ROD) functions, refer to the *Virtuoso Relative Object Design SKILL Reference*.

Aligning ROD Objects Using rodAlign

<u>Creating Handles Using rodCreateHandle</u>

Creating Paths with rodCreatePath

Creating Objects Using rodCreateRect

Using rodGetObj

Naming Shapes Using rodNameShape

Unaligning All Zero-level Shapes in a Cellview Using rodUnAlign

Unnaming All Named Shapes in a Cellview Using rodUnNameShape

Solutions for rodCreateHandle

Solutions for rodCreatePath

Solutions for rodCreateRect

Solutions for rodGetObj

Solutions for rodNameShape

# Aligning ROD Objects Using rodAlign

This section presents a few problems that can be solved using the <u>rodAlign</u> function. To encourage you to think about or solve them yourself, the solutions are not presented until the end of this chapter.


You can use one of the following variables to access the current cellview ID: pcCellView, tcCellView, or rodCellView. For a brief description of these variables, see <u>Using Variables in ROD Functions</u> in the *Virtuoso Relative Object Design User Guide*.

- Problem 3-1 Aligning an Object to a Point
- Problem 3-2 Aligning Two Rectangles at the Same Level of Hierarchy
- Problem 3-3 Moving an Object with rodAlign
- Problem 3-4 Aligning Objects at Different Levels in the Hierarchy

For an example showing a guard ring created using rodAlign, see Code Examples.

### Problem 3-1 Aligning an Object to a Point


Inside of a Pcell, align the lower left corner of the object named Boundary to the reference point 15:10.



Solution 3-1 Aligning an Object to a Point.

### **Problem 3-2 Aligning Two Rectangles at the Same Level of Hierarchy**

Align the center of the rectangle named polyRect to the center of the rectangle named activeRect so that their centers are coincident. The two rectangles are at the same level in the design hierarchy.




Solution 3-2 Aligning Two Rectangles at the Same Level of Hierarchy.

### Problem 3-3 Moving an Object with rodAlign

Use the rodAlign function to move the object named boundary so that its lowerCenter handle has a positive offset along the Y axis from the upperLeft handle of the reference

Using Relative Object Design Functions

object activeRect. Specify the arguments so that no alignment persists after the rodAlign function completes.




Solution 3-3 Moving an Object with rodAlign.

### **Problem 3-4 Aligning Objects at Different Levels in the Hierarchy**


In a Pcell, there are two objects named rect0 on the metal1 layer in different instances. Align the centerRight point handle on rect0 in the instance nTran1 to the centerLeft point handle of the reference object rect0 in the instance nTran2. Specify a negative separation along the X axis between the point handles as the minimum spacing rule from the technology file for the metal1 layer. Because this rodAlign statement occurs within a Pcell, you can use the Pcell variable pcCellView for the cellview ID.

Using Relative Object Design Functions

To access the technology file, use the techGetTechFile function to get the technology file ID and set it equal to the variable tfId. The techGetTechFile function requires the cellview ID or library ID as input.



### Pcell after alignment



Solution 3-4 Aligning Objects at Different Levels in the Hierarchy.

Using Relative Object Design Functions

# Creating Handles Using rodCreateHandle

This section presents you with a series of problems to solve, to help you become familiar with using the rodCreateHandle function. To encourage you to think about or solve the problems yourself, the solutions are not presented until the end of this chapter.

- Problem 3-5a Creating a Point Handle for a Cellview
- Problem 3-5b Querying a Point Handle for a Cellview
- Problem 3-6 Querying a System-Assigned Handle Name

You identify the object for which you want to create a handle by using its <u>hierarchical name</u>. To create a handle for a cellview, you must <u>supply the ROD object ID</u> for the cellview.


You might want to use information from your technology file for the values of some arguments. For example, for the  $n\_width$  argument, you can use the value of the design rule for minimum width.

You can access design rules in several ways. The problems in this section access design rules by using defaults, and by including techGetTechFile and techGetSpacingRule statements, when needed. For more detailed information about accessing design rules, see <u>Using Design Rules in ROD Functions</u>.

For a code example showing how to use rodCreateHandle to compute the resistance of a ROD path, see <u>Getting the Resistance for a ROD Path</u>.

### Problem 3-5a Creating a Point Handle for a Cellview

Create a point handle named originAAA for the origin of layout cellview AAA in the library cellLib.




Solution 3-5a Creating a Point Handle for a Cellview.

Using Relative Object Design Functions

### Problem 3-5b Querying a Point Handle for a Cellview

Find the value of the point handle named <code>originAAA</code>, which is the origin of layout cellview AAA. Instance <code>IA1</code> of cellview AAA is within cellview BBB, offset from the origin of cellview BBB by 3 units in the direction of the X and Y axes.



Solution 3-5b Querying a Point Handle for a Cellview.

### **Problem 3-6 Querying a System-Assigned Handle Name**

When you create a handle without specifying a name, the system assigns a name. For the layout cellview myCell in the library cellLib, find the system-assigned name for the last handle you created without a name.

Solution 3-6 Querying a System-Assigned Handle Name.

Using Relative Object Design Functions

# **Creating Paths with rodCreatePath**

To help you become familiar with using the <u>rodCreatePath</u> function, this section presents a problem to solve. To encourage you to think about and solve the problem yourself, the solution is not presented until the end of this chapter.

■ Problem 3-7 Create a Master Path with an Offset Subpath to the Right

For additional code examples, including computing the resistance for a ROD path, see <u>Code Examples</u>.

Using Relative Object Design Functions

### Creating Objects Using rodCreateRect

This section presents you with a series of problems to solve, to help you become familiar with using the <u>rodCreateRect</u> function. To encourage you to think about or solve the problems yourself, the solutions are not presented until the end of this chapter.

- Problem 3-8 Create One Rectangle with n\_width and n\_length
- Problem 3-9 Create One Rectangle with I\_bBox
- Problem 3-10 Create a Multipart Rectangle with One Row/Column of Master Rectangles
- Problem 3-11 Create a Multipart Rectangle with Multiple Rows/Columns of Master Rectangles
- Problem 3-12 Fill a Bounding Box with Master Rectangles

When using rodCreateRect, you might want to use information from your technology file for the values of some arguments. For example, for the  $n\_width$  argument, you can use the value of the design rule for minimum width.

You can access design rules in several ways. The problems in this section access design rules by using defaults and by including techGetTechFile and techGetSpacingRule statements, when needed. For more detailed information about accessing design rules, see <u>Using Design Rules in ROD Functions</u>.

# **Creating a Named Rectangle**

**Note:** Remember, when you want to create a rectangle that is a regular, unnamed database shape (with no ROD information), use the dbCreateRect function instead of the rodCreateRect function.


To create a named rectangle with ROD attributes, determine its size and location either by specifying the width, length, and origin  $(n\_width, n\_length, and l\_origin)$  or by specifying a bounding box  $(l\_bBox)$ . The  $l\_bBox$  argument overrides the values of the  $n\_width, n\_length$ , and  $l\_origin$  arguments.

### Problem 3-8 Create One Rectangle with n\_width and n\_length

Assume that you are in a Pcell, and create a rectangle named minMetal on the metall layer. Set the width equal to 3. Set the length equal to twice the minimum width.

Using Relative Object Design Functions


Use the techGetTechFile function to get the technology file ID, and set it equal to the variable tfId. Let the cellview ID  $(d\_cvId)$  default to the Pcell variable pcCellView, because your statement is executed inside of a Pcell.



Solution 3-8 Create One Rectangle with n\_width and n\_length

### Problem 3-9 Create One Rectangle with I\_bBox

Create a single rectangle similar to the way it was created for <u>Problem 3-8 Create One Rectangle with n\_width and n\_length</u>, but this time, use  $1\_bBox$  to specify its size and location. Make the rectangle 6 wide by 3 long, with its origin point at the coordinates 2:2.



Solution 3-9 Create One Rectangle with I\_bBox

# Creating a Multipart Rectangle with Rows/Columns of Master Rectangles

To create rows and/or columns of rectangles that are regular, unnamed database shapes, see <u>Filling a Bounding Box with Rectangles</u> in the *Virtuoso Relative Object Design SKILL Reference*.

To create a multipart rectangle with a single row of master rectangles parallel to the X axis, specify the number of rectangles (elements) with the  $x_{elementsX}$  argument. To create a single column of master rectangles parallel to the Y axis, use the  $x_{elementsY}$  argument. To create both rows and columns, use both  $x_{elements}$  arguments.


### Problem 3-10 Create a Multipart Rectangle with One Row/Column of Master Rectangles

For a Pcell, you want to create a multipart rectangle with one row of master rectangles. Add a rodCreateRect statement to the body of a pcDefinePcell statement, as follows:

Create nine minimum-size rectangles on the metal1 drawing layer in the direction of the X axis, and name them minMetal.1 through minMetal.9. Use the rules from the technology file for minimum width and minimum space between rectangles.

Let the origin of the first rectangle default to the coordinates 0:0. Let the cellview ID default to the value of the Pcell variable pcCellView, because your statement is executed inside of a Pcell.

The rectangles form a row that looks like this:




Solution 3-10 Create a Single Row or Column of Rectangles

# Problem 3-11 Create a Multipart Rectangle with Multiple Rows/Columns of Master Rectangles

Inside a Pcell, create rows and columns of master rectangles using polyRect as the base for the name, with five along the X axis and four along the Y axis, using the layer-purpose pair poly and drawing. Set the origin of the first rectangle to the coordinates 3:6.

For the X axis, make the distance between the edges of rectangles equal to three greater than the minimum spacing for the poly layer. For the Y axis, make the distance between rectangles equal to six greater than the minimum spacing for the poly layer. This time, you need the technology file ID.

The rectangles form rows and columns that looks like this:



Solution 3-11 Create Multiple Rows and Columns of Rectangles

# Filling Bounding Boxes with Master Rectangles

To fill a bounding box with master rectangles that have ROD attributes, use the  $1\_fillBox$  argument; to partially fill a bounding box, specify the maximum number of rectangles to

Using Relative Object Design Functions

repeat in the direction of the X and/or Y axis. The system creates rectangles starting in the lower left corner of the fill-bounding box.


The system gives each rectangle a unique name, using the value of the  $S\_name$  argument as a base, then adding a suffix for the row and column number, with periods in front of the row and column numbers. For example, if you specify polyRect as the base for the name, the system names the rectangle in the lower-left corner of the fill-bounding box polyRect.1.1. The system creates all rectangles at level zero in the hierarchy, so no additional hierarchy is created. Also, no bounding box is created.

To specify the maximum number of rectangles along each axis, use the  $x\_elementsX$  and  $x\_elementsY$  arguments. To specify spacing between rectangles, use the  $n\_spaceX$  and  $n\_spaceY$  arguments. When you specify both spacing and number of elements, the system creates as many rectangles as fit inside the bounding box without exceeding the numbers specified by the  $x\_elements$  arguments.

### **Problem 3-12 Fill a Bounding Box with Master Rectangles**

In a Pcell, define an 18-by-10 bounding box on the poly layer, offset from the coordinates 0:0 by 2 user units in both directions. Fill the box with master rectangles using polyRect as the base for the name and the minimum width for the poly layer. Make the distance between rectangles along the X and Y axes equal to 2.0 units.

Let the cellview ID default to the variable pcCellView, because the statement is inside of a Pcell. The fill-bounding box and rectangles look like this:



Solution 3-12 Fill a Bounding Box with Rectangles


### Using Relative Object Design Functions

### **Problem 3-13 Partially Fill a Bounding Box with Master Rectangles**

On the metall layer in a Pcell, fill a bounding box that is 18 units wide and 10 units long with master rectangles. Do not define an offset for the fill-bounding box. Set the layer purpose to drawing. Fill the box with a maximum of 3 rectangles in the direction of the X axis and 2 rectangles in the direction of the Y axis.

Specify the size of the rectangles as 2 units wide by 2 units long using the bounding box argument  $1\_bBox$ . Set the distance between rectangles along the Y axis to the minimum design rule in the technology file for the metall layer. Make the distance between rectangles along the X axis twice as large as the spacing along the Y axis. The rectangles do not fill the bounding box.

Let the cellview ID default to the variable pcCellView, because the statement is inside of a Pcell.



Solution 3-13 Partially Fill a Bounding Box with Rectangles


### **Problem 3-14 Overfill a Bounding Box with Master Rectangles**

Fill an 18-by-10 bounding box with master rectangles on the metal1 layer, with no offset. Make the rectangles as wide and long as the minimum width for the metal1 layer. Specify a maximum of six rectangles in the direction of the X axis and four rectangles in the direction of the Y axis.

Using Relative Object Design Functions

Set the distance between rectangles along the X axis to 2.5 and along the Y axis to 2.0. Let the cellview ID default to the Pcell variable pcCellview.

The bounding box and rectangles look like this:



Solution 3-14 Overfill a Bounding Box with Rectangles


### **Creating Rectangles on a Terminal and Net**

To create a shape on a specific terminal and net, specify the terminal and net name using the  $S\_termName$  argument.

### Problem 3-15 Create a Single Named Rectangle on a Terminal and Net

In a Pcell, create a rectangle named termFig on the metall layer. Assign the rectangle to the terminal and net Aout, and make the terminal direction type output.

Let the width and length default to the minimum width for the specified layer from the technology file. Let the cellview ID  $(d\_cvId)$  default to the variable pcCellview.



Solution 3-15 Create a Single Rectangle on a Terminal and Net

Using Relative Object Design Functions

### **Looking at Properties**

You can look at the properties for ROD objects with the Virtuoso layout editor *Edit – Properties* command.

### **Creating Rectangular Pins**

To create rectangular pins with the rodCreateRect function, you must specify the net and terminal name and your intention to create a pin. The system assigns the pin to the net and terminal identified by the  $S\_termName$  argument.


For a short overview of pin connectivity, see **Connectivity**.

### **Problem 3-16 Create a Rectangular Pin**

Create a rectangular pin named polyPin for the terminal and net named InOut0, using the layer-purpose pair poly and pin. Set the access direction to input-output and label the pin. Use the  $l\_bBox$  argument to determine the pin size and to place the pin in the upper-right corner of the object named trans1.

You need to define a local variable for the minimum width so that you can use it to compute the size of the bounding box for the rectangle. You also need a local variable for the coordinates of the upper-right corner of the ROD object trans1. You can use the rodPointX function to get the X coordinate from your variable for the upper-right corner and rodPointY to get the Y coordinate.

The polyPin pin looks like this:



Solution 3-16 Create a Rectangular Pin.

Using Relative Object Design Functions

# Using rodGetObj

This section presents you with a few problems to solve using the <u>rodGetObj</u> function. To encourage you to think about or solve the problems yourself, the solutions are not presented until the end of this chapter.

- Problem 3-17 Accessing Coordinates without Hierarchy
- Problem 3-18 Accessing Coordinates through One Level of Hierarchy
- Problem 3-19 Accessing Coordinates through Two Levels of Hierarchy

For more information about the ROD object ID (the value returned by the rodGetObj function), see About ROD Objects and ROD Object IDs.

**Note:** Although you can access ROD object information about mosaics, in the current release you cannot descend into a mosaic or access anything within a mosaic.

#### **Transforming Coordinates through Hierarchy**

The following problems show how the system transforms a set of coordinates up through the hierarchy to the top-level layout cellview. This information applies to the rodGetObj and rodGetHandle functions and to queries made using the ROD object ID with the database access operator (~>) to access point handles on ROD objects.

**Note:** In hierarchical names, be sure to use the *instance name*, not the cellview name.

To get the ROD object ID for an object, you must provide either the database ID, or both the hierarchical name and cellview ID as input to the rodGetObj function. When the rodGetObj function is within the body of Pcell code, you can use one of the following variables for the cellview ID:

- The pcCellView variable when rodGetObj is in a <u>pcDefinePCell</u> statement. The pcDefinePCell function automatically sets the value of the pcCellView variable to the cellview ID.
- The tcCellView variable when rodGetObj is in a <u>tcCreateCDSDeviceClass</u> function call. The tcCreateDeviceClass function automatically sets the value of the tcCellView variable to the cellview ID.

For convenience, you might want to assign these internal variables to a variable with a shorter name, for example

```
cv = pcCellView
or
cv = tcCellView
```


Using Relative Object Design Functions

You can access information about the attributes of ROD objects by using the ROD object ID and the database access operator (~>). For detailed information about how to do so, see Accessing ROD Object Attributes.

#### **Problem 3-17 Accessing Coordinates without Hierarchy**

The layout cellview AAA contains a shape named polyRect. The lower-left corner of polyRect is 3 units above and 3 units to the right of the coordinates 0:0 on the X and Y axes. The library name is rodTestLib.

Assign the cellview ID for layout cellview AAA to the local variable cv and the coordinates of the lower-left corner of polyRect to the local variable point1. What is the value of point1?



Solution 3-17 Accessing Coordinates without Hierarchy.


#### **Problem 3-18 Accessing Coordinates through One Level of Hierarchy**

The layout cellview BBB contains two instances of layout cellview AAA: IA1 and IA2. Each instance of AAA contains the shape polyRect.

Instance IA1 is offset from the coordinates 0:0 by 6 units on the X axis and 3 units on the Y axis. Instance IA2 is offset from 0:0 by 66 units and 3 units, respectively. The origin of shape polyRect is offset from the origin of each instance by 3 units and 3 units.

Using Relative Object Design Functions

Assign local variables point1 and point2 to the values of the lowerLeft point handles on the shape polyRect in instances IA1 and IA2, respectively. What are the values of point1 and point2?



Solution 3-18 Accessing Coordinates through One Level of Hierarchy.


# **Problem 3-19 Accessing Coordinates through Two Levels of Hierarchy**

The layout cellview CCC contains instance IB1 of layout cellview BBB, and instance IB1 contains instance IA1 of AAA. The named shape polyRect is in instance IA1.

Instance IB1 is 3 units above and 6 units to the right of the coordinates 0:0. Instance IA1 is offset from the origin of IB1 by 6 units and 3 units. The shape polyRect is offset from the origin of IA1 by 3 units and 3 units, respectively.

Using Relative Object Design Functions

Assign the value of the <code>lowerLeft</code> point handle for the shape <code>polyRect</code> to the local variable <code>point1</code>. What is the value of <code>point1</code>?



Solution 3-19 Accessing Coordinates through Two Levels of Hierarchy.

Using Relative Object Design Functions

# Naming Shapes Using rodNameShape

Normally, you create named rectangles and paths using the <code>rodCreateRect</code>, <code>rodCreatePolygon</code>, and <code>rodCreatePath</code> functions, so you do not need to name them. But if you want to assign a name and create ROD object information for a shape that was created with a database function, such as <code>dbCreateRect</code>, <code>dbCreatePolygon</code>, or <code>dbCreatePath</code>, you can do so with the <code>rodNameShape</code> function and the database ID of the shape. The <code>dbCreate</code> functions return the database ID of the newly created shape.

If you are working interactively in the Virtuoso layout editor and the CIW and need the database ID for an unnamed shape, follow the steps below. Use variables to hold the value returned by each function.

To get the database ID for a shape, do the following:

- 1. Select the shape in the layout cellview window.
- 2. To get the cellview ID for a selected shape in the active cellview window, type in the CIW

  cv = deGetCellView()
- **3.** To return a list of the database IDs for the selected shapes (in this case, only one shape), type in the CIW:

```
selset = geGetSelectedSet(cv)
```

**4.** To return the first element in the list (even though there is only one element), type in the CIW:


```
dbId = car(selset)
```

#### Problem 3-20 Naming a Polygon Created by dbCreatePolygon in a Pcell

The polygon shown in this problem was created inside a Pcell with the dbCreatePolygon function. The dbCreatePolygon function returns the database ID of the new polygon. In this problem, the polygon ID is stored in the variable polyDbId.

Using Relative Object Design Functions

Verify that the name testName is a valid name and that it has not been used in the cellview. Then assign the name testName to the unnamed polygon. Use a variable to save the value returned by the rodNameShape function.



Solution 3-20 Naming a Polygon Created in a Pcell

#### Problem 3-21 Naming a Shape Created in the CIW and Layout Window

You are working interactively in a layout cellview window and the CIW. You used the layout editor to create the ordinary, unnamed rectangle. Assign the name  $\mathtt{rectA}$  to the shape, using variables for values returned by functions.



Solution 3-21 Naming a Shape Created in the CIW and Layout Window

Using Relative Object Design Functions

# Unaligning All Zero-level Shapes in a Cellview Using rodUnAlign

To remove the alignments from all zero-level ROD shapes in a cellview using the <a href="modUnAlign">rodUnAlign</a> function, run the procedure shown below. This procedure does not remove alignments from shapes at levels in the hierarchy other than zero.

**1.** Set the variable cvId equal to the desired cellview ID by using your library name for library and your cell name for cell.

```
cvId = dbOpenCellViewByType( "library" "cell" "layout" )
```

2. Load the following procedure:

```
; ExUnAlignShapes -- removes alignments from all zero-level ROD
; shapes in cellview
procedure( ExUnAlignShapes( cvId )
    prog( ( shapelist shape rodId )
        ; Get list of all shapes in cellview
        shapelist = cvId~>shapes
        if(shapelist then
            ; For each shape in cellview, get rodID
            foreach ( shape shapelist
                if( rodId = rodGetObj( shape ) then
                     ; The shape is a ROD object because the ROD ID
                     ; is not nil; remove all associated alignments.
                    rodUnAlign( rodId )
                ) ;end if rodID
            ) ;end foreach
        ) ; end if shapelist
    ) ;end prog
) ;end procedure
```

**3.** Execute the procedure using the cellview ID:

ExUnAlignShapes (cvId)

Using Relative Object Design Functions

# Unnaming All Named Shapes in a Cellview Using rodUnNameShape

To remove the names from all named shapes in a cellview using the <u>rodUnNameShape</u> function, run the procedure shown below.

1. Set the variable cvId equal to the desired cellview ID by using your library name for library and your cell name for cell.

```
cvId = dbOpenCellViewByType( "library" "cell" "layout" )
```

2. Load the following procedure:

```
ExUnNameAll -- removes ROD names from all ROD objects in cellview
procedure( ExUnNameAll( cvId )
    prog( ( shapelist shape rodId )
        ; Get list of all shapes in cellview
        shapelist = cvId~>shapes
        if ( shapelist then
             ; For each shape in the cellview, get rodID
             foreach ( shape shapelist
                  rodId = rodGetObj( shape )
   ; if it has a rodId (ie., is a ROD object)
                       then remove it's ROD name
                     if( rodId then
                          rodUnNameShape( rodId )
                     ) ;end if rodId
             ) ;end foreach
        ) ;end if shapelist
    ) ;end prog
) ;end procedure
```

**3.** Execute the procedure using the cellview ID:

ExUnNameAll(cvId)

Using Relative Object Design Functions

# Converting Multipart Path to Polygon Using dbConvertPathToPolygon

By default, it is not possible to edit a subpart of a multipart path (MPP) individually, and you need to use defining parameters of the MPP to make changes to the whole structure. However, if the <code>dbId</code> supplied to the <code>dbConvertPathToPolygon</code> function is an MPP subpath ID, then the MPP subpath will be converted to a polygon and removed from the complex MPP structure.

Using Relative Object Design Functions

# **Solutions to Problems**

Here are solutions to the problems presented in this chapter.

Solutions for rodAlign

Solutions for rodCreateHandle

Solutions for rodCreatePath

Solutions for rodCreateRect

Solutions for rodGetObj

# Solutions for rodAlign

#### Solution 3-1 Aligning an Object to a Point

For the rodGetObj function, you let the cellview ID default to the local variable pcCellView, because the statement is in the body of Pcell code.

There is no separation between the lowerLeft point handle and the reference point because the  $txf\_xSep$  and  $txf\_ySep$  arguments defaulted to zero. You can align a named object directly to a specific point by specifying a value for the reference point argument  $l\_refPoint$ .

When you specify a reference point, you do not have to specify a reference object  $(R\_refObj)$  and a reference handle  $(S\_refHandle)$ . If you specify a reference point and also specify a reference object (with or without specifying a reference handle), the value of the reference point overrides the values for reference object and reference handle.

Return to Problem 3-1 Aligning an Object to a Point.

# Solution 3-2 Aligning Two Rectangles at the Same Level of Hierarchy

Using Relative Object Design Functions

To get the ROD object IDs for polyRect and activeRect using the rodGetObj function, you need the cellview ID. The reference handle arguments ( $S_refHandle$ ) and  $S_alignHandle$ ) default to the value centerCenter for both rectangles, so the center of polyRect is aligned to the center of the reference object activeRect. The  $txf_xSep$  and  $txf_ySep$  arguments default to zero, so the centers of the two rectangles are on the same point. The  $g_xSep$  maintain argument defaults to t, so this alignment is maintained.

Return to Problem 3-2 Aligning Two Rectangles at the Same Level of Hierarchy.

#### Solution 3-3 Moving an Object with rodAlign

When you specify  $g_{maintain}$  as equal to nil, the alignment operation behaves like a move. No alignment information is saved after the rodAlign function completes.

Return to Problem 3-3 Moving an Object with rodAlign.

#### Solution 3-4 Aligning Objects at Different Levels in the Hierarchy

The rectangles were specified by their hierarchical names nTran1/rect0 and nTran2/rect0. Separation along the Y axis defaulted to zero. Separation along the X axis is negative, so the aligned object is moved to the left of the reference object by the distance specified in the minSpacing rule for the metal1 layer. The alignment will be maintained because the  $g_maintain$  argument defaulted to t.

The techGetSpacingRule expression is enclosed in quotation marks so that whenever the minSpacing rule for the metall layer changes in your technology file, the system updates the alignment using the new rule. If you do not enclose the whole expression in double quotations marks, the system evaluates the expression immediately and uses the result from then on. Be sure to include a backslash in front of each double quotation mark within the string to prevent the system from interpreting it as the end of the string.

Using Relative Object Design Functions

For more detailed information about accessing design rules, see <u>Using Design Rules in ROD Functions</u>.

Return to Problem 3-4 Aligning Objects at Different Levels in the Hierarchy.

Using Relative Object Design Functions

#### Solutions for rodCreateHandle

#### Solution 3-5a Creating a Point Handle for a Cellview

First, you need the ROD object ID for the cellview, and to get it, you need the cellview ID. You can use <code>dbOpenCellViewByType</code> to get the cellview ID. Get the ROD object ID for the cellview with <code>rodGetObi</code>, where the name of the cellview is represented by a null string.

Return to <u>Problem 3-5a Creating a Point Handle for a Cellview</u>.

For more information, see <u>rodCreateHandle</u> in the *Virtuoso Relative Object Design SKILL Reference*.

#### Solution 3-5b Querying a Point Handle for a Cellview

```
cvId2 = dbOpenCellViewByType( "cellLib" "BBB" "layout" )
rodId = rodGetObj( "IA1" cvId2 )
origin = rodID~>originAAA

Or
origin = rodGetObj( "IA1" cvId2 )~>originAAA
```

First, get the ID for cellview BBB. Then either set a variable equal to the ROD object ID for cellview BBB and query the variable, or perform both actions in a single statement. The value of originAAA in the coordinate system of cellview BBB is 3:3.

Return to Problem 3-5b Querving a Point Handle for a Cellview.

#### Solution 3-6 Querying a System-Assigned Handle Name

```
cvId = dbOpenCellViewByType( "cellLib" "myCell" "layout" )
rodId = rodGetObj( "" cvId )
rodId~>userHandleNames
```

You can use the database access operator (~>) and the ROD object ID to <u>query the value of ROD object attributes</u>. The last name assigned by the system to a user-defined handle is at the end of the list of user handle names.

Using Relative Object Design Functions

Return to Problem 3-6 Querying a System-Assigned Handle Name.

Using Relative Object Design Functions

#### Solutions for rodCreatePath

#### Solution 3-7 Create a Multipart Path with an Offset Subpath on the Right

```
rodCreatePath(
                        "p1"
       ?name
       ?layer
                        "nwell"
                        0.6
       ?width
       ?pts
                        list(2:2 8:2 8:6 10:6)
       ?endType
                       "flush"
       ?offsetSubPath
                       list(
                                list( ?layer
                                                        "metal2"
                                       ?width
                                                        0.8
                                       ?justification
                                                        "right"
                                       ?sep
                                                        1.0
                                     ) ; end of sublist
                           ) ; end of offset subpath list
) ; end rodCreatePath
```

For both the master path and the offset path, the layer purpose defaults to drawing. The master path is choppable because  $g\_choppable$  defaults to t.

Because  $S_{justification}$  is set to right, the offset subpath appears on the right side of the master path, relative to the direction of the master path.

For more information, see <u>rodCreatePolygon</u> or <u>rodCreatePath</u> in the *Virtuoso Relative* Object Design SKILL Reference.

Using Relative Object Design Functions

#### Solutions for rodCreateRect

#### Solution 3-8 Create One Rectangle with n\_width and n\_length

The layer purpose defaults to drawing. To use minimum width in a calculation, you must refer to the technology file rule for minimum width directly. Do this by using the techGetSpacingRule function with the standard user-defined name for minimum width, minWidth, and the layer name, metall. Let the origin of the rectangle default to 0:0.

Return to Problem 3-8 Create One Rectangle with n width and n length.

For more information, see <u>rodCreateRect</u> in the *Virtuoso Relative Object Design SKILL Reference*.

### Solution 3-9 Create One Rectangle with I\_bBox

The rectangle is 6 by 3 with its origin at 2:2, and the upper-right corner is at 8:5.

Return to Problem 3-9 Create One Rectangle with I\_bBox.

#### Solution 3-10 Create a Single Row or Column of Rectangles

Because the rectangle width and space between rectangles was not specified, the system automatically retrieves the minimum width and minimum design rules for the metall layer from your technology file.

Using Relative Object Design Functions

Return to <u>Problem 3-10 Create a Multipart Rectangle with One Row/Column of Master Rectangles</u>.

#### **Solution 3-11 Create Multiple Rows and Columns of Rectangles**

For rectangle size, let the system use the minimum width for the poly layer from the technology file for both width and length. Set a local variable equal to the technology file ID.

Use the techGetSpacingRule function to get the minimum space between rectangles for the poly layer. Let the cellview ID default to the variable pcCellView, because the statement is executed inside of a Pcell.

Return to <u>Problem 3-11 Create a Multipart Rectangle with Multiple Rows/Columns of Master Rectangles</u>.

#### Solution 3-12 Fill a Bounding Box with Rectangles

Let the rectangle width and length default to the minimum design rules in the technology file for the poly layer and the distance between rectangles along the Y axis default to the value of the  $n\_spaceX$  argument. The layer purpose defaults to drawing.

Return to <u>Problem 3-12 Fill a Bounding Box with Master Rectangles</u>.

# Solution 3-13 Partially Fill a Bounding Box with Rectangles

Using Relative Object Design Functions

This is the first time rectangles were created in the cellview, so the names of the rectangles default to rect0.x.y. The system did not use the values for  $l\_bBox$  to determine the location of the first rectangle because using the  $l\_fillBox$  argument always causes the first rectangle to be placed in the lower-left corner of the fill-bounding box.

Use the techGetSpacingRule function to retrieve the minimum design rule for the metall layer.

Return to Problem 3-13 Partially Fill a Bounding Box with Master Rectangles.

#### Solution 3-14 Overfill a Bounding Box with Rectangles

```
rodCreateRect(
          ?fillBBox          list( 0:0 18:10 )
          ?layer          "metall"
          ?elementsX          6
          ?elementsY          4
          ?spaceX          2.5
          ?spaceY          2.0
) ; end of rodCreateRect
```

This is the second time rectangles were created in the cellview, so the names of the rectangles default to  $\mathtt{rect2.x.y.}$  When you use the  $1\_fi11BBox$  argument, the system always places the first rectangle in the lower-left corner of the fill-bounding box. The width and length of the rectangles defaults to the minimum width for the  $\mathtt{metal1}$  layer from the technology file, which is 2.0.

The number of rectangles specified with the  $n\_elements$  arguments, combined with the distance between them, exceeds the space in the fill-bounding box, so the system creates only as many rectangles as fit inside the box. In this case, the system creates four columns and three rows of rectangles.

Return to Problem 3-14 Overfill a Bounding Box with Master Rectangles.

#### Solution 3-15 Create a Single Rectangle on a Terminal and Net

Using Relative Object Design Functions

The layer purpose defaults to drawing. The origin of the rectangle defaults to 0:0. The rectangle termFig is now associated with the terminal and net Aout.

Return to Problem 3-15 Create a Single Named Rectangle on a Terminal and Net.

#### Solution 3-16 Create a Rectangular Pin

```
tfId = techGetTechFile( pcCellView )
localMinWidth = techGetSpacingRule( tfId "minWidth" "poly" )
ptUR = rodGetObj( "trans1" )~>upperRight
rodCreateRect(
                "polyPin"
    ?name
    ?pin
               t
    ?termName "InOut0"
    ?layer list("poly" "pin")
    ?pinLabel
    ?bBox
           list( list( rodPointX( ptUR ) - localMinWidth
                        rodPointY( ptUR ) - localMinWidth
                      ); list for value of lower-left corner
                  ptUR ; value of upper-right corner
                  ; end of bBox list of points
    ) ; end of rodCreateRect
```

First, the technology file ID is set equal to the variable tfld, and the local variable localMinWidth is set equal to the minimum width rule from the technology file for the poly layer. Then, the local variable ptuR is set equal to the coordinates of the upper-right corner of the bounding box around the object trans1, using the rodGetObj function. The upper-right corner of the pin has the same coordinates.

In the rodCreateRect statement, set the  $g\_pin$  argument to t for true to create a pin. Let the pin access direction default to inputOutput. Set  $g\_pinLabel$  to t to create a pin text-display label. The text of the label is the contents of the  $S\_termName$  argument, InOut0. The location of the origin of the text-display label defaulted to centerCenter.

Next, compute the coordinates for the lower-left corner of the pin bounding box as follows:

- To compute the X coordinate, use the rodAddToX function to subtract the minimum width for the poly layer from the X coordinate of pture.
- To compute the Y coordinate, use the rodAddToY function to subtract the minimum width for the poly layer from the Y coordinate of ptur.

For the upper-right corner of the pin bounding box, use the value of the ptur variable, the same point as the upper-right corner of trans1.

Using Relative Object Design Functions

Return to Problem 3-16 Create a Rectangular Pin.

Using Relative Object Design Functions

# Solutions for rodGetObj

#### **Solution 3-17 Accessing Coordinates without Hierarchy**

There is no hierarchy in layout cellview AAA.

First, you used the database function <code>dbOpenCellViewByType</code> to get the cellview ID for AAA. Then you got the ROD object ID for the object <code>polyRect</code> and used the database access operator (~>) to retrieve the system-defined point handle for the lower-left corner.

The lowerLeft point handle is at 3:3, so point1 = 3:3.

For more information, see <u>rodGetObj</u> in the *Virtuoso Relative Object Design SKILL Reference*.

Return to <u>Problem 3-17 Accessing Coordinates without Hierarchy</u>.

#### Solution 3-18 Accessing Coordinates through One Level of Hierarchy

There is one level of hierarchy. The coordinates of the lower-left corner of polyRect are 9:6 for instance IA1 and 69:6 for instance IA2, so point1 = 9:6 and point2 = 69:6.

Return to <u>Problem 3-18 Accessing Coordinates through One Level of Hierarchy</u>.

# Solution 3-19 Accessing Coordinates through Two Levels of Hierarchy

There are two levels of hierarchy. The coordinates of the lower-left corner of polyRect are 15:9, so point1 = 15:9.

Return to Problem 3-19 Accessing Coordinates through Two Levels of Hierarchy.

Using Relative Object Design Functions

# Solutions for rodNameShape

#### Solution 3-20 Naming a Polygon Created in a Pcell

To verify whether the name testName has already been used in the cellview, you need the cellview ID.

The local variable polyDbId was set equal to the database ID for the polygon when it was created, so you can use polyDbId in your rodNameShape statement. You can specify a name as a character string enclosed in quotation marks or as a symbol preceded by a single quotation mark ('). The rodNameShape function returns the ROD object ID for the shape you named.

For more information, see <u>rodNameShape</u> in the *Virtuoso Relative Object Design SKILL Reference*.

Return to Problem 3-20 Naming a Polygon Created by dbCreatePolygon in a Pcell.

# Solution 3-21 Naming a Shape Created in the CIW and Layout Window

```
cvId = deGetCellView()
selSet = geGetSelectedSet(cvId)
dbId = car(selSet)
rectRodId = rodNameShape(?name "rectA" ?shapeId dbId)
```

First, you must select the unnamed shape in the active cellview window by clicking on it. Then, get the cellview ID (cvId) using deGetCellView(). Use cvId with geGetSelectedSet to return a list of the database IDs for all objects in the selected set (in this case, just one object).

Use the variable containing the list of database IDs (selSet) with the car Cadence SKILL language function to get the first database ID in the list (dbId). Use dbId to identify the shape you want to rename with rodNameShape.

Return to Problem 3-21 Naming a Shape Created in the CIW and Layout Window.

Using Relative Object Design Functions


#### Problem 3-7 Create a Master Path with an Offset Subpath to the Right

When you create an offset subpath, you determine its location by specifying its separation from the master path  $(n\_sep)$  and its justification  $(S\_justification)$ .

Assume that you are in a Pcell. Create a three-segment master path on the <code>nwell</code> layer as shown in the following illustration, with the width equal to 0.6, end type <code>flush</code>, and the centerline on the following points: 2:2, 8:2, 8:6, 10:6. Make the master path choppable and name it p1.

In the same statement, create an offset subpath 1.0 units to the right of the master path on the metal2 layer, with a width of 0.8. Let the offset of the subpath ends default to zero. You can also let the cellview ID  $(d\_cvId)$  default to the Pcell variable pcCellView, because your statement is executed inside a Pcell.

The master path and offset subpath look something like this:



Solution 3-7 Create a Multipart Path with an Offset Subpath on the Right

# Virtuoso Relative Object Design User Guide Using Relative Object Design Functions

В

# **Accessing the Cellview ID**

You do not need to supply the cellview ID as an argument when you execute a Virtuoso<sup>®</sup> relative object design (ROD function within the body of a pcDefinePCell statement or within the body of a tcCreateCDSDeviceClass\_function call. The cellview ID defaults to the local variable pcCellView or tcCellView, respectively.

You need to specify the cellview ID when you execute a ROD function in the command interpreter window (CIW). You can get the cellview ID from the active cellview window or from the database, without opening a cellview window.

#### **Getting the Cellview ID**

To get the cellview ID, do one of the following:

➤ To get the cellview ID for the cellview in the active open cellview window, type the following:

```
cvId = deGetCellView()
```

➤ To get the cellview ID without opening a cellview window, type the following:

```
cvId = dbOpenCellViewByType( "myLib" "myCell" "layout" "w" )
```

where myLib is your library name, myCell is your cellview name, layout is the view type, and r sets the mode to read-only. The cellview will be opened only in the database, not in a window.

For more information, see <u>dbOpenCellViewByType</u>.

# Virtuoso Relative Object Design User Guide Accessing the Cellview ID

C

# **Using Design Rules in ROD Functions**

You might want to use design rules defined in your technology file as the values of some arguments of Virtuoso<sup>®</sup> relative object design (ROD) functions. You can let the value of an argument such as  $n\_width$  default to a design rule, or you can access your technology file more directly by using the techGetTechFile, techGetSpacingRule, or another technology file function.

#### **Using Design Rules for Default Values**

When you do not specify values for the keyword arguments listed below, the system automatically assigns a default, as described in the "Arguments" section for the ROD function:

```
n_width
n_length
n_spaceX
n_spaceY
n enclosure
```

The default is often the value of a design rule from the technology file. Using the rodCreateRect function as an example, when you do not specify a value for  $n\_length$ , the system assigns the value specified for  $n\_width$ . If you specified neither  $n\_length$  nor  $n\_width$ , the system looks in the technology file associated with your cellview for the minimum width rule for the specified layer, using the standard name minWidth, and assigns its value to both  $n\_length$  and  $n\_width$ .

In this case, you do not have to specify the technology file ID or the technology file name. As long as minWidth for the layer is defined in the technology file for your library, the system can find it automatically using the cellview ID.

The names for variables representing design rules are user defined; however, assigning standard names, such as minWidth, maxWidth, minSpacing, and maxSpacing, is a good practice. If your design rules do not have standard names, you must access your design rules using a technology file function, such as techGetSpacingRule.

Using Design Rules in ROD Functions

#### Accessing Design Rules with techGetSpacingRule

You can access design rules from your technology file with the techGetSpacingRule function. You must specify the technology file ID, layer name, and the name of the design rule. You can get the technology file ID with the techGetTechFile function, which requires the cellview ID or library ID.

For example, say you want to access the minimum design rule for the metall layer, and the name of your minimum width rule is minWidth. You can access minWidth in one of the ways shown below.

■ To get value of the technology file ID and store it in a variable, type the following:

To get value of the technology file ID without storing it in a variable, combine both functions in one statement, as follows:

```
\label{lem:condition} \mbox{techGetSpacingRule( techGetTechFile( $d\_cellViewId$) } \\ \mbox{"minWidth"} \\ \mbox{"metal1"} \\ \mbox{)}
```

If the techGetSpacingRule function returns nil, either minWidth is not defined for the metall layer or the technology file does not exist.

For more information about technology file design rules, see "Physical Rules SKILL Functions" in the <u>Technology File and Display Resource File SKILL Reference Manual.</u>

D

# **Using Environment Variables with ROD**

There are a number of environment variables that influence how Virtuoso<sup>®</sup> relative object design (ROD) functionality works. This section describes these environment variables.

**Note:** Only the environment variables documented in this chapter are supported for public use. All other ROD environment variables, regardless of their name or prefix, and undocumented aspects of the environment variables described below, are private and are subject to change at any time.

```
[TOPIC_START_OPEN] type=cmdref

[TOPIC_START_ATTR] title=Checking the Value of a ROD Environment Variable

[TOPIC_START_ATTR] description=

[TOPIC_START_ATTR] keywords=

[TOPIC_START_CLOSE]
```

# **Checking the Value of a ROD Environment Variable**

To determine the current value of an environment variable,

Type in the CIW
 envGetVal( "rod" "variable\_name" )
For example:
 envGetVal( "rod" "preserveAlignInfoOn" )

TOPIC END]

Using Environment Variables with ROD

```
[TOPIC_START_OPEN] type=cmdref

[TOPIC_START_ATTR] title=How the System Evaluates ROD Environment Variables

[TOPIC_START_ATTR] description=

[TOPIC_START_ATTR] keywords=

[TOPIC_START_CLOSE]
```

# **How the System Evaluates ROD Environment Variables**

The system looks for the value of a ROD environment variable as follows:

- 1. First, the system looks in the local .cdsenv file in your home directory, ~/.cdsenv
- 2. If the variables are not defined in your ~/.cdsenv file, the system looks for the system-defined default settings in the following file:

```
your_install_dir/etc/tools/rod/.cdsenv
```

```
[TOPIC_END]

[TOPIC_START_OPEN] type=cmdref

[TOPIC_START_ATTR] title=Changing the Settings of ROD Environment Variables

[TOPIC_START_ATTR] description=

[TOPIC_START_ATTR] keywords=

[TOPIC_START_CLOSE]
```

# **Changing the Settings of ROD Environment Variables**

You can change the default settings of ROD environment variables in the CIW or in your local ~/.cdsenv file, as described below.

#### **Changing Settings for Environment Variables in the CIW**

To change the value of an environment variable temporarily, do the following:

In the CIW, set the value of the variable with the following statement:

Using Environment Variables with ROD

```
envSetVal("rod" "variable_name" 'data_type value)
```

where <code>variable\_name</code> is the name of the variable. The backwards tick mark ( `) in front of <code>data\_type</code> is necessary. It tells the system not to interpret the value of the argument, but to use it literally, as a data type. For example:

```
envSetVal("rod" "preserveAlignInfoOn" 'boolean nil)
```

#### Changing Settings for Environment Variables in ~/.cdsenv

You can add ROD environment variables to the .cdsenv file in your home directory by typing them or by copying them from the .cdsenv file in the samples directory in your Cadence hierarchy.

**Note:** Do not copy lines from the rod/.cdsenv file to the .cdsenv file in your home directory. The file formats are slightly different, so the lines that result from copying do not work.

The ROD environment variable settings should look like this in your ~/.cdsenv file:

```
rod preserveAlignInfoOn boolean value rod traceTriggerFunctionsOn boolean value
```

where value is equal to t or nil.

If you do not have a .cdsenv file in your home directory, you can copy the .cdsenv file from the samples directory in your local Cadence hierarchy to your home directory and modify it.

#### Copying Variables from the Samples Directory to ~/.cdsenv

To copy ROD environment variables from the samples directory to the ~/.cdsenv file in your home directory, do the following:

- 1. In one window, open your ~/.cdsenv file.
- **2.** In another window, open <code>your\_install\_dir/dfII/samples/.cdsenv</code> where <code>your\_install\_dir</code> is the path to your Cadence hierarchy.
- **3.** In the samples/.cdsenv file, search for rod and then for the variable name, such as preserveAlignInfoOn.
- **4.** Copy the setting for the ROD environment variable and paste it into the .cdsenv file in your home directory.
- **5.** If desired, change the setting.

Using Environment Variables with ROD

- 6. Save your ~/.cdsenv file.
- **7.** To use the settings in future sessions, save the settings with *Save Defaults* on the Options menu in the CIW.

[TOPIC\_END]

[TOPIC\_START\_OPEN] type=cmdref

[TOPIC\_START\_ATTR] title=List of ROD Environment Variables

[TOPIC\_START\_ATTR] description=

[TOPIC\_START\_ATTR] keywords=

[TOPIC\_START\_CLOSE]

Using Environment Variables with ROD

#### **List of ROD Environment Variables**

- displayStretchHandles
- distributeSingleSubRect
- preserveAlignInfoOn
- rodAutoName
- stretchDuplicateHandles
- stretchHandlesLayer
- traceTriggerFunctionsOn
- updatePCellIncrement

[TOPIC\_END]

[TOPIC\_START\_OPEN] type=cmdref

[TOPIC\_START\_ATTR] title=displayStretchHandles

[TOPIC\_START\_ATTR] description=

[TOPIC\_START\_ATTR] keywords=

[TOPIC\_START\_CLOSE]

Using Environment Variables with ROD

# displayStretchHandles

```
layout displayStretchHandles boolean { t | nil }
graphic displayStretchHandles boolean { t | nil }
```

#### **Description**

Specifies whether stretch handles are displayed for stretchable Pcells (t), or not (nil). The default is nil.

#### **GUI Equivalent**

Command Options – Display
Form Field Stretch Handles

#### **Examples**

```
envGetVal("layout" "displayStretchHandles")
envSetVal("layout" "displayStretchHandles" 'boolean t)
envSetVal("layout" "displayStretchHandles" 'boolean nil)
envGetVal("graphic" "displayStretchHandles")
envSetVal("graphic" "displayStretchHandles" 'boolean t)
envSetVal("graphic" "displayStretchHandles" 'boolean nil)
```

# **Related Topics**

**Display Options Form** 

List of ROD Environment Variables

[TOPIC\_END]

Using Environment Variables with ROD

[TOPIC\_START\_OPEN] type=cmdref

[TOPIC\_START\_ATTR] title=distributeSingleSubRect

[TOPIC\_START\_ATTR] description=

[TOPIC\_START\_ATTR] keywords=

[TOPIC\_START\_CLOSE]

Using Environment Variables with ROD

# distributeSingleSubRect

```
rod distributeSingleSubRect boolean { t | nil }
```

#### **Description**

Determines where a single subrectangle is placed by the rodCreatePath function when the value of  $S\_gap$  is distribute. When nil, the subrectangle is offset as specified by  $n\_beginOffset$  and  $n\_endOffset$ . When t, the subrectangle is centered (but placed on grid), and  $n\_beginOffset$  and  $n\_endOffset$  are ignored.

The default is nil.

#### **GUI Equivalent**

None

#### **Examples**

```
envGetVal("rod" "distributeSingleSubRect")
envSetVal("rod" "distributeSingleSubRect" 'boolean t)
envSetVal("rod" "distributeSingleSubRect" 'boolean nil)
```

#### **Related Topics**

List of ROD Environment Variables

```
[TOPIC_END]
```

[TOPIC\_START\_OPEN] type=cmdref

[TOPIC\_START\_ATTR] title=preserveAlignInfoOn

[TOPIC\_START\_ATTR] description=

[TOPIC\_START\_ATTR] keywords=

[TOPIC\_START\_CLOSE]

Using Environment Variables with ROD

# preserveAlignInfoOn

```
rod preserveAlignInfoOn boolean { t | nil }
```

#### **Description**

Specifies whether alignment between ROD objects is preserved or broken when a ROD object is moved or modified. The default is t.

# **GUI Equivalent**

None

# **Examples**

```
envGetVal("rod" "preserveAlignInfoOn")
envSetVal("rod" "preserveAlignInfoOn" 'boolean t)
envSetVal("rod" "preserveAlignInfoOn" 'boolean nil)
```

# **Related Topics**

```
[TOPIC_END]
```

[TOPIC\_START\_OPEN] type=cmdref

[TOPIC\_START\_ATTR] title=rodAutoName

[TOPIC\_START\_ATTR] description=

[TOPIC\_START\_ATTR] keywords=

Using Environment Variables with ROD

#### rodAutoName

```
layout rodAutoName string { pin | rectangle | polygon | path }
```

#### **Description**

Specifies that rectangles, polygons and/or shape pins can be created as ROD objects. These shapes are given either system- or user-assigned names. The default is none.

# **GUI Equivalent**

Command Create - Pin, Create - Shape - Rectangle, Create - Shape

- Polygon, Create - Shape - Path, Create - Wiring - Wire

Form Field As ROD Object (<u>Create Pin Form</u>, <u>Create Rectangle</u>

Form, Create Polygon Form, Create Path Form)

# **Examples**

```
envGetVal("layout" "rodAutoName")
envSetVal("layout" "rodAutoName" 'string "pin")
envSetVal("layout" "rodAutoName" 'string "rectangle")
envSetVal("layout" "rodAutoName" 'string "polygon")
envSetVal("layout" "rodAutoName" 'string "path")
```

#### Related Topics

**List of ROD Environment Variables** 

[TOPIC\_END]

Using Environment Variables with ROD

[TOPIC\_START\_OPEN] type=cmdref

[TOPIC\_START\_ATTR] title=stretchDuplicateHandles

[TOPIC\_START\_ATTR] description=

[TOPIC\_START\_ATTR] keywords=

Using Environment Variables with ROD

# stretchDuplicateHandles

```
rod stretchDuplicateHandles boolean { t | nil}
```

#### **Description**

Specifies whether to stretch all the selected handles of a Pcell depending on whether they are duplicates of some other selected handles. The default is nil, which means that the stretch will apply to the selected handles that are unique and to one of the duplicated handles, for each set of the duplicated handles.

#### **GUI Equivalent**

None

# **Examples**

```
envGetVal("rod" "stretchDuplicateHandles")
envSetVal("rod" "stretchDuplicateHandles" 'boolean t)
envSetVal("rod" "stretchDuplicateHandles" 'boolean nil)
```

#### **Related Topics**

List of ROD Environment Variables

```
[TOPIC_END]

[TOPIC_START_OPEN] type=cmdref
```

[TOPIC\_START\_ATTR] title=stretchHandlesLayer

```
[TOPIC_START_ATTR] description=
```

[TOPIC\_START\_ATTR] keywords=

Using Environment Variables with ROD

# stretchHandlesLayer

graphic stretchHandlesLayer string any\_valid\_layer-pupose\_pair

#### **Description**

Specifies the layer that stretch handles are displayed on for stretchable Pcells. The default is yo drawing.

# **GUI Equivalent**

None

#### **Examples**

```
envGetVal("graphic" "stretchHandlesLayer")
envSetVal("graphic" "stretchHandlesLayer" 'string "metal1 drawing")
```

# Related Topics

List of ROD Environment Variables

```
[TOPIC_END]
```

[TOPIC\_START\_OPEN] type=cmdref

[TOPIC\_START\_ATTR] title=traceTriggerFunctionsOn

[TOPIC\_START\_ATTR] description=

[TOPIC\_START\_ATTR] keywords=

Using Environment Variables with ROD

# traceTriggerFunctionsOn

```
rod traceTriggerFunctionsOn boolean { t | nil }
```

#### **Description**

Controls the printing of trace messages for debugging. Set this variable to t when you encounter a problem that requires customer support. The default is nil.

# **GUI Equivalent**

None

#### **Examples**

```
envGetVal("rod" "traceTriggerFunctionsOn")
envSetVal("rod" "traceTriggerFunctionsOn" 'boolean t)
envSetVal("rod" "traceTriggerFunctionsOn" 'boolean nil)
```

#### **Related Topics**

List of ROD Environment Variables

```
[TOPIC_END]
```

[TOPIC\_START\_OPEN] type=cmdref

[TOPIC\_START\_ATTR] title=updatePCellIncrement

[TOPIC\_START\_ATTR] description=

[TOPIC\_START\_ATTR] keywords=

Using Environment Variables with ROD

# updatePCellIncrement

layout updatePCellIncrement every\_grid\_snap

#### **Description**

Specifies how often the system updates Pcell parameters and regenerates a Pcell during a stretch operation.

A value greater than zero is used as the grid for regeneration. A negative value forces the grid to use the technology file variable mfgGridResolution. The default is -1.0, implying mfgGridResolution is used.

#### **GUI Equivalent**

None

# **Examples**

```
envGetVal("layout" "updatePCellIncrement")
envSetVal("layout" "updatePCellIncrement" 'float -2.0)
```

# **Related Topics**

**List of ROD Environment Variables** 

[TOPIC\_END]

# Virtuoso Relative Object Design User Guide Using Environment Variables with ROD

The following tables summarize the level of support for how Virtuoso<sup>®</sup> Layout XL commands work on relative object design (ROD) objects in the current release.

Using commands that are not fully supported for ROD objects could cause the objects to lose the ROD information associated with them, changing the objects into ordinary shapes.

**Table E-1 Virtuoso Layout Editor Creation Commands** 

Create Command	Degree of ROD Support		
Rectangle r	Create and name new rectangles as ROD objects using the Create Rectangle form.		
Polygon P	Create and name new polygons as ROD objects using the Create Polygon form.		
Path p	Create and name paths as ROD objects using the <i>Create Path</i> form.		
Multipart Path	Create and name new multipart paths as ROD objects using the <i>Create Multipart Path</i> form. This form lets you choose a template from your technology file, load templates from an ASCII file, and save form values as a template in your technology file (if you have write permission) or in an ASCII file.		
Label I	You cannot create a label as a ROD object. However, you can make an existing label a ROD object by assigning it a name with the rodNameShape function.		
Instance i	An instance is automatically a ROD object because it has a unique name. The ROD object name is the same as the instance name.		
<u>Pin</u> ^p	Create and name new pins as ROD objects using the <i>Create Pin Shape</i> form.		

Table E-1 Virtuoso Layout Editor Creation Commands, continued

Pins From Labels	You cannot create a pin from a label as a ROD object. However, you can make an existing pin a ROD object by assigning it a name with the rodNameShape function.
Circle	Circles are supported as ROD objects. However, there is no user interface for naming a circle; use the rodNameShape function.
Ellipse	Ellipses are supported as ROD objects. However, there is no user interface for naming an ellipse; use the rodNameShape function. An ellipse ROD object has only bounding box handles.
Donut	Donuts are supported as ROD objects. However, there is no user interface for naming a donut; use the rodNameShape function. A donut ROD object has only bounding box handles.
Layer Generation	You cannot create a shape using a layer generation operation as a ROD object. However, you can make a generated shape a ROD object by assigning it a name with the rodNameShape function.

The Mosaic is not supported as ROD objects:

Table E-2 Virtuoso Layout Editor Editing Commands

Edit Command	Degree of ROD Support	
<u>Undo</u> u	The <i>Undo</i> command fully supports ROD objects.	
Redo U	The Redo command fully supports ROD objects.	

Table E-2 Virtuoso Layout Editor Editing Commands, continued

Move m	Moving ROD objects is supported as follows:	
	You can move a ROD object within the same cellview or another cellview.	
	Within the same cellview, moving a ROD object that has other objects aligned to it causes the aligned objects to move as well.	
	■ When you move a ROD object between cellviews, and the ROD object is aligned to another ROD object(s), the system preserves alignment only when the aligned ROD object(s) is also in the selected set; otherwise the alignment is broken.	
	Avoid rotating aligned ROD objects during a move because the aligned handle names are not updated after the move, so the results might not be what you want.	
Сору с	Copying ROD objects is supported as follows:	
	You can copy a ROD object within the same cellview or to another cellview. The system automatically assigns unique names to the copies.	
	Alignments between ROD objects in the selected set result in alignments between the corresponding copy objects.	
	■ Alignments to objects not in the selected set are ignored.	
	You can copy a whole multipart path (MPP) or a whole multipart rectangle (MPR), but not an individual subpart of an MPP or MPR.	
Stretch s	The <i>Stretch</i> command fully supports ROD objects, including stretchable parameterized cells (Pcells).	
Reshape R	Except for multipart paths and multipart rectangles, all reshapable ROD objects remain ROD objects after a <i>Reshape</i> operation.	
	When you reshape any ROD object, all alignments to that object are deleted.	

Table E-2 Virtuoso Layout Editor Editing Commands, continued

Delete del	The <i>Delete</i> command fully supports ROD objects.		
	When you delete using the <i>Net Interconnect</i> option, all ROD objects on the selected net are deleted, except for pins. For multipart paths (MPP) and multipart rectangles (MPR), when the master path or master rectangle is on the selected net, the MPP or MPR and all subparts are deleted; otherwise, no part of the MPP or MPR is deleted.		
	When you delete a segment of an MPP with the <i>Path Segment</i> option, the remaining segments of the MPP become two separate multipart paths, each with its own name.		
Properties q	You can use the <i>Edit Properties</i> command for ROD objects to:		
	<ul> <li>View system-defined and user-defined handle names and handle values</li> </ul>		
	■ View alignments for the selected ROD object		
	Modify the X and Y separation between the selected ROD object and other ROD objects.		
Search S	You can search for any ROD object by name, including rectangles, paths, polygons, and text display objects.		
Merge M	Merge is not supported for ROD objects. When ROD objects are merged, the resulting shape is not a ROD object.		
Select All ^a	The Select All command fully supports ROD objects.		
Deselect All ^d	The Deselect All command fully supports ROD objects.		
Hierarchy: Make Cell	The Make Cell command fully supports ROD objects.		

Table E-2 Virtuoso Layout Editor Editing Commands, continued

Flatten	The Flatten command fully supports ROD objects.
	To preserve the attributes of ROD objects (such as object name, alignments, multipart path subparts, and master rectangles in multipart rectangles), turn on the <i>Preserve ROD Objects</i> button in the Flatten form. When this option is off, ROD objects become ordinary unnamed objects, the subparts of multipart paths become ordinary paths and rectangles, and the master rectangles in multipart rectangles become ordinary, unnamed rectangles.
	<b>Note:</b> However if the ROD object is at top (zero-level) it does not get flattened using the Flatten command.
	The system assigns the flattened object a name based on the hierarchical name of the ROD object by replacing slashes with dashes. For example, when you flatten the ROD object ${\tt I1/I4/rect3}$ , the resulting object is named ${\tt I1-I4-rect3}$ .
Chop	Most shapes lose ROD attributes when they are chopped. For multipart paths, the effect of a chop depends on what parts are choppable and how you chop them. For details, see <a href="Chopping Multipart Paths">Chopping Multipart Paths</a> .
	When you chop the master rectangle of a multipart rectangle, all subrectangles are deleted and the shapes resulting from chopping the master rectangle are regular, unnamed database shapes.
	When you chop any ROD object, all alignments to that object are deleted.
Modify Corner	The <i>Modify Corner</i> command supports ROD polygons and ROD rectangles, except for master rectangles that are a part of a multipart rectangle.
Size	The <i>Size</i> command supports ROD objects. However, when you size a multipart path (MPP), the master path becomes a ROD polygon and inherits its name from the original MPP; all subparts become ordinary, unnamed database shapes.
	When you size any ROD object, all alignments to that object are deleted.

Table E-2 Virtuoso Layout Editor Editing Commands, continued

Split ^s	Except for ellipses, circles, donuts, multipart paths, and multipart rectangles, ROD objects remain ROD objects after a split operation.	
	When you split any ROD object, all alignments to that object are deleted.	
Attach/Detach v	The Attach/Detach commands fully support ROD objects.	
Convert To Polygon	The Convert To Polygon command fully supports ROD objects, except for rectangles and multipart rectangles. The Convert To Polygon command has no affect on rectangles and multipart rectangles.	
	When you convert a multipart path, the polygon resulting from the master path is a ROD object and takes the name of the multipart path. Subparts, if any, become unnamed, ordinary database shapes (paths and rectangles). Subparts are not converted to polygons.	
	When you convert any ROD object (except rectangles and multipart rectangles) to a polygon, all alignments to the converted object are deleted.	
Move Origin	The Move Origin command fully supports ROD objects.	
Rotate O	With the exception of multipart rectangles the <i>Rotate</i> command supports the rotation of ROD objects, unless there are alignments. Avoid rotating aligned ROD objects because aligned handle names are not updated after the rotation, so the results might not be what you want.	
	For multipart rectangles with subrectangles offset from the master rectangle corners, avoid rotation unless the offsets are all equal. The Rotate command does not rotate these offsets.	
Yank y	The Yank command does not support ROD objects. The Yank command copies only the shapes, but not the names of the shapes or the alignments. When you paste, the result is unnamed, unaligned, non-ROD shapes.	
Paste Y	The <i>Paste</i> command does not support ROD objects. If you yank and paste ROD objects, the result is unnamed, unaligned, non-ROD shapes.	

F

# **Displaying Pin Names in a Layout Window**

To see terminal names for pins in a layout window, the display setting for pin names must be turned on. You can turn on the display of pin names for just the duration of your editing session, or you can change the default.

- To temporarily turn on *Pin Names* display, use the Display Options form in a layout window and then apply the changes, but do not save them.
- To change the default for the display of pin names, either edit your local .cdsenv file or turn on *Pin Names* option in the Display Options form and save the changes.

# Setting the Pin Names Environment Variable in .cdsenv

To display terminal names for pins by setting the displayPinNames environment variable in the .cdsenv file in your home directory, do the following:

- **1.** Use a text editor to edit your ~/.cdsenv file.
- 2. Search for layout.
- 3. Search for displayPinNames.

```
By default, the setting looks like this:
```

```
layout displayPinNames boolean nil
```

**4.** Change nil to t so that the setting looks like this:

```
layout displayPinNames boolean t
```

**5.** Save your file and start the Virtuoso<sup>®</sup> layout editor.

# **Turning On Pin Names in the Display Options Form**


To display terminal names for pins by setting the *Pin Names* option in a layout window, do the following:

**1.** In your layout window, choose *Options – Display*.

Displaying Pin Names in a Layout Window

The Display Options form appears.

2. In the Display Options form, make sure the *Pin Names* option is on.




You can apply your settings to just the current editing session or save them to the current cellview or as a file.

- **3.** Apply or save your Display Option settings by doing one of the following:
  - ☐ To apply your settings to the current editing session only, click *OK* in the Display Options form.

When you save display settings to a cellview, the settings are automatically applied when you reopen the cellview.


☐ To save your settings with the cellview, turn on *Cellview* and click *Save To;* then click *OK*.



When you save to your ~/.cdsenv file (the default file), the settings automatically load when the layout editor starts.

Displaying Pin Names in a Layout Window

□ To save your settings in your ~/.cdsenv file, turn on *File* and click *Save To*, then click *OK*.



# Virtuoso Relative Object Design User Guide Displaying Pin Names in a Layout Window

G

# **Code Examples**

The examples in this appendix show how you might use Virtuoso<sup>®</sup> relative object design (ROD) functions to create some commonly used devices.

# **Using ROD to Create Multipart Paths**

Creating a Bus

Creating a Contact Array

Creating a Guard Ring


Creating a Shielded Path

Creating a Transistor

# **Using Stretchable Pcells**

Stretchable MOS Transistor

# **Creating a Bus**




```
;; Create a bus with 7 offset subpaths
procedure( bus(cv layer)
    (let (tfId layerWidth layerSpace)
        tfId = techGetTechFile(cv)
        layerWidth = techGetSpacingRule(tfId "minWidth" layer)
        layerSpace = techGetSpacingRule(tfId "minSpacing" layer)
        rodCreatePath(
            ?name
                             "bus"
            ?layer
                             laver
                             list(20:-20 40:-20 40:-30 80:-30)
            ?pts
            ?width
                             layerWidth
                            "center"
            ?justification
            ?cvId
            ?offsetSubPath
            list(
                list(
                    ?layer
                                     layer
                    ?justification
                                     "left"
                    ?sep
                                     layerSpace
                ) ;end subpath1
                list(
                    ?layer
                                     layer
                                     "left"
                    ?justification
                    ?sep
                                      (layerSpace * 2) + layerWidth
                ) ;end subpath2
                list(
                    ?layer
                                     layer
                    ?justification "left"
                                 (layerSpace * 3) + (layerWidth * 2)
                ) ;end subpath3
                list(
```

Code Examples


```
?layer layer
?justification "left"
                ?sep (layerSpace * 4) + (layerWidth * 3)
                ) ;end subpath4
                list(
                    ?layer
                                      layer
                    ?justification "left"
                    ?sep (layerSpace * 5) + (layerWidth * 4)
                ) ;end subpath5
                list(
                    ?layer layer
?justification "left"
                    ?sep (layerSpace * 6) + (layerWidth * 5)
                ) ;end subpath6
                list(
                    ?layer layer
?justification "left"
                    ?sep (layerSpace * 7) + (layerWidth * 6)
                ) ; end subpath7
            ) ;end list of lists
   ) ;end rodCreatePath
) ; end of let
) ; end of procedure
```

# **Creating a Contact Array**



```
;; Create a contact array
procedure (buildCnts (cv layer1 layer2 layer3 width1 width3 length3
        pathpnts terminal pinlabel enc offset chop)
    ; pinlabel is a boolean that determines whether a label will be
    ; created
    let( (fig )
    fig = rodCreatePath(
        ?cvId cv
        ?layer layer1
        ?width width1
        ?pts pathpnts
        ?encSubPath
        list(
            list(
                ?layer
                                  layer2
                ?enclosure
                                  enc
                ?choppable
                                  chop
                ?pin
                ?termName
                                  terminal
                ?pinLabel
                                  pinlabel
                ?pinLabelHeight length3
                                  "text"
                ?pinLabelLayer
             ) ;end enc sublist1
        ); end enc list
        ?subRect
        list(
            list(
                ?layer
                                  layer3
                ?width
                                  width3
                ?length
                                  length3
                ?endOffset
                                  offset
            ) ;end rect sublist1
        ) ;end subRect list
    ) ;end rodCreatePath
    ) ;end of let
) ;end of procedure
```

# **Creating a Guard Ring**



```
;; Create guard ring
;; This procedure is an example of how to create a guard ring
;; interactively with the layout editor. The sample code assumes that certain
;; design rules are already defined in your technology file. This code builds
;; three types of guard rings: ndiff, pdiff, and poly.
;; The arguments for this procedure are all optional.
;; If you specify no arguments, the guard ring defaults to ndiff.
;; The system prompts you for coordinates and you draw the guard ring
;; in the current open window.
;; Optionally, you can also specify the type of material and
;; cellview ID, and you can pass in a pointlist.
procedure(
   buildGuardRing(
                        @optional (type "ndiff")
                        (winId hiGetCurrentWindow())
                        (pointList nil)
                ) ; end buildGuardRing
   prog(
            cvId tfId botLayNumber topLayNumber viaLayNumber
            viaWidth botOLvia topOLvia botWidth
            prompt1 prompt2 buildCnts info
;; Check the cellView. Get the techfile ID.
        if(
            (cvId = geGetEditCellView(winId)) &&
                    cvId->objType == "cellView"
        then
```


#### Code Examples

```
tfId = techGetTechFile(cvId)
              printf("Invalid cellView %L\n" cvId)
              return()
         ) ;end if
;; Find out what layers to use based on the type of guard ring.
         botLayNumber =
              case(type
                   ("ndiff" techGetParam(tfId "ndiff"))
                   ("pdiff" techGetParam(tfId "pdiff"))
                   ("poly" techGetParam(tfId "poly"))
              ) ;end case
         topLayNumber = techGetParam(tfId "metall")
         viaLayNumber = techGetParam(tfId "cont")
;; Find the design rules.
         viaWidth = techGetSpacingRule(tfId "minWidth" viaLayNumber)
         botOLvia = techGetOrderedSpacingRule(
                       tfId "minEnclosure" botLayNumber viaLayNumber)
         topOLvia = techGetOrderedSpacingRule(
                       tfId "minEnclosure" topLayNumber viaLayNumber)
         botWidth = (2 * botOLvia) + viaWidth
;; Build a global variable list for the enter function to use.
    buildCnts info = ncons(nil)
         build\overline{C}nts\ info->cv =
                                           cvId
         buildCnts info->layer1 =
                                          botLayNumber
         buildCnts info->layer2 =
                                          topLayNumber
         buildCnts_info->layer3 =
                                          viaLayNumber
         buildCnts_info->width1 = botWidth
buildCnts_info->width3 = viaWidth
buildCnts_info->length3 = viaWidth
buildCnts_info->pathpnts = pointList
buildCnts_info->terminal = nil
         buildCnts info->pinlabel =
                                         nil
         buildCnts info->enc =
                                           (botOLvia - topOLvia)
         buildCnts info->offset =
                                           -botOLvia
         buildCnts info->chop =
;; Prompts for points if points where not passed in.
         prompt1 = "Enter the first point in the coordinate list:"
prompt2 = "Enter the next point in the coordinate list:"
         enterPath(
                        ?prompts list(prompt1 prompt2)
                       ?doneProc "quardRingDoneCB"
                       ?pathWidth botWidth
                       ?points pointList
                        ?pathStyle "flush"
                   ) ; end enterPath
         return(t)
     ) ; end proq
) ;end procedure
;; The following procedure uses a callback from the enterFunction.
;; car(args) = winId (Current window)
;; cadr(args) = exitStatus (t if applied, nil if canceled)
... caddr(args) = pointList (points entered by year)
;; caddr(args) = pointList
                                     ( points entered by user )
;; Use the variable buildCnts_info (define within the buildGuardRing ;; procedure above) to contain the layer and design rule information.
```

Code Examples


```
;;
procedure(
     guardRingDoneCB(@rest args)
     let((pointList)
          when (cadr (args) && (pointList = caddr (args)) &&
                                         length(pointList) > 1
               when (boundp ('buildCnts info) && listp (buildCnts info)
                          length(buildCnts info) == 14
                    buildCnts info->pathpnts = pointList
                     rodCreatePath(
                                         buildCnts_info->cv
buildCnts_info->layer1
buildCnts_info->width1
buildCnts_info->pathpnts
                          ?cvId
                          ?layer
                          ?width
                          ?pts
                          ?choppable nil
                          ?encSubPath list( list(
                               ?layer
                                                    buildCnts info->layer2
                               ?enclosure
                                                    buildCnts info->enc
                               ?choppable buildCnts_info->chop
?pinLabel buildCnts_info->pinlabel
?pinLabelHeight buildCnts_info->length3
?pinLabelLayer buildCnts_info->pinlabel
)); end encSubpath lists
                          ?subRect list( list(
                                                     buildCnts info->layer3
                               ?layer
                               ?width
                                                     buildCnts info->width3
                                                     buildCnts info->length3
                               ?length
                                                   buildCnts_info->offset
                               ?endOffset
                                              ) ) ;end of subRect lists
                     ) ;end of rodCreatePath
               ) ;end of 1st when
          ) ;end of 2nd when
     ) ;end of let
) ;end of procedure
```

# **Creating a Shielded Path**



```
;; Create a shielded path
procedure( shieldedPath(cv)
    errset(
    (let (tfId)
        rodCreatePath(
            ?name
                           "shieldedPath"
                           "metal1"
            ?layer
            ?pts
                           list(2:-15 2:-5 15:-5 15:-15)
            ?width
                            . 8
            ?justification "center"
            ?cvId cv
            ?offsetSubPath
            list(
                list(
                    ?layer
                                    "vapox"
                    ?justification
                                   "left"
                    ?sep
                    ?width
                                     . 4
                ) ;end of offset sublist1
                list(
                                     "vapox"
                    ?layer
                                    "right"
                    ?justification
                    ?sep
                    ?width
                ) ;end of offset sublist2
            ) ;end of offset list of lists
        ) ; end of rodCreatePath
    ) ; end of let
    t
   ) ; end of errset
) ; end of procedure
```

# **Creating a Transistor**



```
;; Create a gate
procedure( tran(cv w l name)
    let((tfId pext pcs pds cw cs mloc doc grid ptslist tran)
        tfId = techGetTechFile(cv)
        pext = techGetSpacingRule(tfId "minExtension" "poly")
        pcs = techGetSpacingRule(tfId "minSpacing" "poly" "cont")
        pds = techGetSpacingRule(tfId "minSpacing" "poly" "ndiff")
        cw = techGetSpacingRule(tfId "minWidth" "cont")
        cs = techGetSpacingRule(tfId "minSpacing" "cont")
        mloc = techGetOrderedSpacingRule(tfId "minEnclosure"
                "metal1" "cont")
        doc = techGetOrderedSpacingRule(tfId "minEnclosure"
                "ndiff" "cont")
        grid = techGetMfgGridResolution(tfId)
        ptslist = list(0.0 0:(w + 2 * pext))
        tran = rodCreatePath(
                    ?name
                                      "poly"
                    ?layer
                    ?pts
                                     ptslist
                    ?width
                                      "G"
                    ?termName
                                      "center"
                    ?justification
                    ?cvId
                    ?offsetSubPath
                    list(
                                              "poly"
                            ?layer
                            ?beginOffset
                                              0.0
                            ?endOffset
                                              -(pext + w + pds)
                            ?width
                             ?pin
                            ?termName
                        ) ;end of offset sublist1
                        list(
```

Code Examples

```
?endo_
?width
     ?pin
     ?termName "G"
) ;end of offset sublist2
list(
     ?layer
                           "metal1"
     ?justification "left"
    ?sep pcs - mloc
?beginOffset mloc - pext - doc
?endOffset mloc - pext - doc
?width cw + 2 * mloc
?pin t
?termName "S"
) ;end of offset sublist3
list(
     ?layer
                           "metal1"
     ?justification "right"
    ?sep pcs - mloc
?beginOffset mloc - pext - doc
?endOffset mloc - pext - doc
?width cw + 2 * mloc
?pin t
?termName "D"
) ;end of offset sublist4
list(
                         "ndiff"
     ?layer
     ?justification "left"
    ?sep 0.0
?beginOffset -pext
?endOffset -pext
?width doc + cw + pcs
?termName "S"
) ;end of offset sublist5
list(
     ?layer
                           "ndiff"
     ?justification "left"
    ?sep 0.0
?beginOffset -pext
?endOffset -pext
?width 2 * grid
?pin t
     ?termName
) ;end of offset sublist6
list(
                          "ndiff"
     ?layer
     ?justification "right"
    ?sep 0.0
?beginOffset -pext
?endOffset -pext
?width doc + cw + pcs
?termName "D"
) ;end of offset sublist7
list(
     ?layer
                           "ndiff"
     ?justification "right"
     ?sep 0.0
?beginOffset -pext
?endOffset -pext
```

Code Examples

```
2 * grid
                             ?width
                             ?pin
                                              "D"
                             ?termName
                        ) ;end of offset sublist8
                    ?subRect
                        list(
                             list(
                                 ?layer "cont"
                                 ?length cw
                                 ?width cw
                                 ?space cs
                                 ?justification "left"
                                 ?sep pcs
                                 ?beginOffset -(pext + doc)
                                 ?endOffset -(pext + doc)
                             ) ;end of subRect sublist1
                             list(
                                 ?layer "cont"
                                 ?length cw
                                 ?width cw
                                 ?space cs
                                 ?justification "right"
                                 ?sep pcs
                                 ?beginOffset -(pext + doc)
                                 ?endOffset -(pext + doc)
                             ) ;end of subRect sublist2
                        ) ;end of subRect list of lists
                ) ;end of rodCreatePath
    ) ;end of let
) ;end of procedure
```

Code Examples

# Getting the Resistance for a ROD Path

The following procedures create and update a user-defined handle for the resistance of a ROD path. All three procedures require the ROD object ID (rodId) as input.

getRodPathLength Goes through the list of points in a ROD path and adds up the

lengths of the segments.

getRodPathRes Gets the length and sheet resistance values for a ROD path

and calculates the resistance.

createResHandle Creates or recalculates a user-defined handle for the

resistance (res) of a ROD path.

When you calculate the resistance of a ROD path from within a Pcell, you only need to execute the createResHandle procedure once inside the Pcell because the geometries in a Pcell are recreated every time the Pcell is evaluated.

When you calculate the resistance of a ROD path from outside a Pcell, such as in an open cellview window, you must update the resistance handle (res) by executing the createResHandle procedure in the Command Interpreter Window whenever you make a change to the ROD path, such as stretching or chopping it.

Code Examples

# getRodPathLength Procedure


```
;; This procedure goes through the list of points in a ROD path
;; and adds the lengths of the segments. Returns the total length.
procedure(getRodPathLength(rodId)
    let(
                (total length 0)
            ) ; end variables for let
            for(i 0 (rodId~>numSegments - 1)
                total length = total length +
                    rodGetHandle (rodId
                    symbolToString(concat("length" i)))
            ) ;end of for
            total length
    ) ; end of let
) ;end of procedure
getRodPathRes Procedure
;; This procedure gets the length and sheet resolution values for
;; a ROD path, then calculates and returns the resistance.
;; Remember to load the procedure getRodPathLength
procedure(getRodPathRes(rodId)
    let(( corner value sheet res path width num segs num corners
      total length num squares )
      ;; Percentage of a square. Usually, values from 0.5 to 0.65
      ;; are used for corner resistance. The rodPcells sample library
      ;; uses .559 for corner resistance, so that value is used here.
      ;; Adjust the value of corner value to suit your needs.
    corner value = .559
      ;; Get the sheet resistance for the current layer.
    sheet res = techGetElectricalRule(techGetTechFile(rodId~>cvId)
      "sheetRes" rodId~>dbId~>layer)
      ;; Get path width, number of segments, number of corners,
      ;; and total path length.
   path width = rodId~>dbId~>width
   num segs = rodId~>numSegments
    num corners = num segs - 1
    total length = getRodPathLength(rodId)
      ;; Now compute the number of squares of resistance material
      ;; and calculate the total resistance value.
    num squares = (total length / path width) -
                     (num corners * corner value)
      ;; Return the resistance value.
      num squares * sheet res
  ) ; end of let
) ;end of procedure
```

Code Examples

# createResHandle Procedure

```
;; This procedure creates or updates the value of a user-defined
;; resistance handle ("res") for a ROD path, and returns the
;; resistance value.
procedure(createResHandle(rodId)
  let((res)
    when(rodId~>dbId~>objType == "path" &&
                                 (res = getRodPathRes(rodId))
        when((rodHandle = rodGetHandle(rodId "res"))
                          rodDeleteHandle(rodId "res")
        ) ;end of 2nd when
        rodCreateHandle(
             ?rodObj
                             rodId
             ?name
                             "res"
                            "float"
             ?type
             ?value
         ) ; end of rodCreateHandle
       ) ;end of 1st when
  ) ;end of let
) ;end of procedure
```

# Stretchable MOS Transistor



This is an example of a simple MOS transistor with stretchable contact arrays and user-defined functions. This code might not work with your technology file, but you can modify the code as desired. For more complex MOS code examples, see the <u>Sample Parameterized</u> <u>Cells Installation and Reference</u>.

The parameters for the sample mos transistor Pcell are specified as follows:


Parameter Name	Default Value	Parameter Description
W	1.3	Width of gate
1	0.25	Length of gate
leftcov	1.0	Left contact coverage
rightcov	1.0	Right contact coverage
leftPos	"top"	Position of left contacts
rightPos	"top"	Position of right contacts

Stretch handles are assigned to the transistor Pcell as follows:

■ To make the source contacts stretchable, the upperCenter and lowerCenter point handles on the source contact array are assigned to the Pcell parameter leftcov with the stretch type relative and the stretch direction Y.

Code Examples

■ To make the drain contacts stretchable, the upperCenter and lowerCenter point handles on the drain contact array are assigned to the Pcell parameter rightcov with the stretch type relative and the stretch direction Y.



# **Code for simplemos Transistor**

```
devices (
tcCreateDeviceClass("layout" "simplemos"
   ; class parameter name value pairs
      ( ( xtrType "ndiff" ) )
     formal parameters (name-value pairs)
       ( W
                   1.3)
       (1
                    0.25)
       (leftcov
                   1.0)
       (rightcov
                   1.0)
                   "top")
       (leftPos
                   "top")
       (rightPos
   ) ; end formal parameters
   ; access controls techfile class for layout design rules
   ; and layer info
   tfId = techParam("tfId")
   poly = techParam("poly")
                                  ; poly layer number
   pext = techGetSpacingRule(tfId "minExtension" poly)
   pcs = techGetSpacingRule(tfId "minSpacing" poly contact)
   cw = techGetSpacingRule(tfId "minWidth" contact)
   cs = techGetSpacingRule(tfId "minSpacing" contact)
   mloc = techGetOrderedSpacingRule(tfId "minEnclosure" metal1
           contact)
   doc = techGetOrderedSpacingRule(tfId "minEnclosure" diff
           contact)
   dop = techGetOrderedSpacingRule(tfId "minEnclosure" diff poly)
   pps = techGetSpacingRule(tfId "minSpacing" poly )
```

Code Examples

```
grid = techGetMfgGridResolution(tfId)
; ****** draw gate with connectivity ********
gate = rodCreateRect(
                             poly
            ?layer
            ?length
                             w + (2 * pext)
            ?width
) ; end gate rodCreateRect
topPin = rodCreateRect(
                             poly
            ?layer
            ?length
                             pext
            ?width
                             "G"
            ?termName
            ?pin
) ; end topPin rodCreateRect
botPin = rodCreateRect(
            ?layer
                             poly
            ?length
                             pext
            ?width
                             1
            ?termName
                             "G"
            ?pin
                             t
); end botrodCreateRectPin
dbReplaceProp(gate~>dbId "lxBlockOverlapCheck" "boolean" t)
rodAlign(
            ?refObj
                             gate
            ?refHandle
?alignObj
                             "lowerLeft"
                             botPin
            ?alignHandle
                             "lowerLeft"
) ; end rodAlign
rodAlign(
            ?refObj
                             gate
                            "upperLeft"
            ?refHandle
            ?aliqnObj
                             topPin
                             "upperLeft"
            ?alignHandle
) end rodAlign
; ****** draw source contacts and source diffusion********
metOvDiff = doc - mloc
metOvPoly = pcs - mloc

cntsw = w - (2*doc)
length = ((cntsw + (2*mloc)) * leftcov/grid)*grid
minLength = cw + (2 * mloc)
when(length < minLength
    length = minLength
) ; end when
leftCnts = rodCreatePath(
            ?layer
                             metal1
            ?width
                            (2*m1oc)+cw
                        list(0:0 0:length)
            ?pts
            ?justification "center"
            ?subRect list( list(
                        ?layer
                                   contact
                        ?length
                                  CW
                        ?width
                                   CW
                        ?space
                                    CS
                        ?endOffset -mloc
                    )); end subrect list
```

Code Examples

```
?termName
                                     "S"
                ?pin
                                     t
            ) ; end leftCnts rodCreatePath
leftDiff = rodCreateRect(
                            diff
                 ?layer
                 ?width
                            cw + doc + pcs + 1/2
                 ?length
                             W
            ) ; end leftDiff rodCreatePath
rodAlign(
            ?refObj
                             gate
                             "cC"
            ?refHandle
            ?alignObj
                             leftDiff
            ?alignHandle
                             "cR"
) ; end rodAlign
; ***** make source contacts stretchable ******
; The user-defined function "contcov" sets a range for the
; contacts from a 100% coverage to minimum contact width
rodAssignHandleToParameter(
            ?parameter
                             "leftcov"
            ?rodObj
                             leftCnts
                             list("upperCenter" "lowerCenter")
            ?handleName
            ?handleName
?displayName
                            "leftcov"
                             "y"
            ?stretchDir
                             "relative"
            ?stretchType
                            "contcov"
            ?userFunction
); end rodAssignHandleToParameter
; ****** set source contact alignment ******
; This is an example where rodAssignHandleToParameter is
; being used to set a parameter value and where no display
; is required.
; The userfunction "mystretch" checks which handle is
; currently being stretched and then returns the location
; where the contacts should be aligned, either to the top
; or bottom.
rodAssignHandleToParameter(
                             "leftPos"
            ?parameter
                             leftCnts
            ?rodObj
                             list("upperCenter" "lowerCenter")
            ?handleName
            ?stretchType
                            "relative"
                            "mystretch"
            ?userFunction
) ; end rodAssignHandleToParameter
case( leftPos
        ("top"
            rodAlign(
                    ?refObj
                                     gate
                                     "uL"
                    ?refHandle
                    ?alignObj
                                     leftCnts
                    ?alignHandle
                                     "uR"
                                     -metOvPoly
                    ?xSep
                    ?ySep
                                     -(pext + metOvDiff)
            ) ; end rodAlign
        ) ; end top
        ("bottom"
            rodAlign (
```

#### Code Examples

```
?refObj
                                     gate
"lowerLeft"
                    ?refHandle
                    ?alignObj
                                     leftCnts
                                     "lowerRight"
                    ?alignHandle
                    ?xSep
                                     -metOvPoly
                    ?ySep
                                     pext + metOvDiff
           ); end rodAlign
        ) ; end bottom
    ); end case
; ****** draw drain contacts and drain diffusion********
length = ((cntsw + (2*mloc)) * rightcov/grid)*grid
when (length < minLength
   length = minLength
) ; end when
rightCnts = rodCreatePath(
                ?layer
                                metal1
                ?width
                                (2*mloc)+cw
                ?pts
                                list(0:0 0:length)
                ?justification
                               "center"
                ?subRect
                                list( list(
                                ?layer
                                               contact
                                ?length
                                               CW
                                ?width
                                               CW
                                ?space
                                ?endOffset
                                              -mloc
                                )); end subrect lists
                ?termName
                ?pin
                                 t.
            ) ; end rightCnts rodCreatePath
rightDiff = rodCreateRect(
                ?layer
                                 diff
                ?width
                                 pcs + cw + doc + 1/2
                ?length
                                 W
            ) ; end rightDiff rodCreatePath
rodAlign(
            ?refObj
                             gate
                             "cC"
            ?refHandle
            ?alignObj
                             rightDiff
                            "cL"
            ?alignHandle
) ; end rodAlign
; ****** make drain contacts stretchable *******
rodAssignHandleToParameter(
                             "rightcov"
            ?parameter
            ?rodObj
                             rightCnts
            ?handleName
                             list("upperCenter" "lowerCenter")
                             "rightcov"
            ?displayName
                             "у"
            ?stretchDir
                             "relative"
            ?stretchType
            ?userFunction
                             "contcov"
) ; end rodAssignHandleToParameter
; ***** set drain contact alignment ******
rodAssignHandleToParameter(
            ?parameter
                             "rightPos"
            ?rodObj
                             rightCnts
            ?handleName
                             list("upperCenter" "lowerCenter")
```

Code Examples

```
?stretchType
                                  "relative"
                                 "mystretch"
                ?userFunction
    ) ; end rodAssignHandleToParameter
    case( rightPos
        ("top"
            rodAlign(
                     ?refObj
                                      gate
                     ?refHandle
                                      "uR"
                     ?alignObj
                                      rightCnts
                                      "uL"
                     ?alignHandle
                     ?xSep
                                     metOvPoly
                     ?ySep -(pext + metOvDiff)
            ) ; end rodAlign
        ) ; end top
        ("bottom"
            rodAlign(
                     ?refObj
                                       gate
                                       "lowerRight"
                     ?refHandle
                      ?alignObj
                                      rightCnts
                      ?alignHandle
                                       "lowerLeft"
                     ?xSep
                                      metOvPoly
                     ?ySep
                                       pext + metOvDiff
            ) ; end rodAlign
        ); end bottom
   ); end case
) ; end tcCreateDeviceClass
; Declare a cvs of device class simplemos called simplepmos
; and simplenmos
tcDeclareDevice(
                "layout"
                "simplemos"
                "simplepmos"
                ( ( xtrType "pdiff" ) )
) ; end tcDeclareDevice
tcDeclareDevice(
                "layout"
                "simplemos"
                "simplenmos"
                ( ( xtrType "ndiff" ) )
) ; end tcDeclareDevice
) ; end devices
```

#### **Code for contcov User-Defined Function**

```
;; contcov is a user-defined function specified for the pcell created
;; by simplemos.il.
; The user-defined function "contcov" sets a range for the contacts
; from 100% coverage to minimum contact width for the layer from the
; technology file.

procedure( contcov(myDefstruct)
    let(((returnVal myDefstruct->paramVal + myDefstruct->increment)
    tfId metall contact mloc cw length minLength)
    tfId = techGetTechFile((myDefstruct->rodObj)~>cvId)
    metall = techGetParam(tfId "metall")
    contact = techGetParam(tfId "cont")
```

Code Examples

```
mloc = techGetOrderedSpacingRule(tfId "minEnclosure"
                metal1 contact)
     cw = techGetSpacingRule(tfId "minWidth" contact)
    length = (myDefstruct->rodObj)~>length * returnVal
   minLength = cw + 2*mloc
    when(returnVal > 1.0 || length < minLength</pre>
         progn(warn("returnVal for parameter %s must be < 1</pre>
                or > %f\n" myDefstruct->parameter cw)
            if(returnVal > 1.0 then
                 returnVal = 1.0
            else
                 returnVal = cw
             ) ; endif
        ) ; end progn
    ) ; end when
   returnVal
  ) ; end of let
) ; end of procedure
```

### **Code for myStretch User-Defined Function**

```
;; myStretch.il is a user-defined function specified for the pcell
;; created by simplenmos.il.
; The user-defined function "mystretch" checks which handle is
; currently being stretched and then returns the location where
; the contacts should be aligned, either to the top or bottom.

procedure( mystretch(myDefstruct)
    let( (leftPos)
        if(myDefstruct->handleName == "upperCenter"
        then
        leftPos = "bottom"
    else
        leftPos = "top"
    ); endif
    myDefstruct->paramValue = leftPos
    ); end let
) ; end procedure
```

# Virtuoso Relative Object Design User Guide Code Examples



## **Troubleshooting**

This appendix describes problems you might encounter while using ROD functionality and suggests how to solve them. The problems are divided into two categories:

- Warnings in the CIW
- Dialog Box Messages

## Warnings in the CIW

Template templateName is replacing an existing template by the same name

Creating instance forces unname of ROD object

ROD object ID changes after Undo

## Template templateName is replacing an existing template by the same name

When you load an ASCII MPP template file, the system checks the names of the MPP templates in the ASCII file against the names of MPP templates that already exist in the technology file in virtual memory. If there is a name conflict, the system displays a warning in the CIW saying that an MPP template in the ASCII file is replacing an existing MPP template. The existing template in the technology file in Virtual Memory is overwritten.

#### Solution:

If you do not want to overwrite the original MPP template in your binary technology library on disk, then do not save changes to the technology file. You can also avoid overwriting existing templates by changing the duplicate names in your ASCII file to unique template names.

Troubleshooting

If you want to change the names of the MPP templates in your ASCII file right away, or you want to be able to save other changes to your technology library on disk without overwriting the original template, you need to:

- 1. Exit the layout software without saving technology file changes.
- 2. Edit your ASCII file to change template names.
- **3.** Restart the layout software.
- **4.** Reload your ASCII MPP template file.

#### Creating instance forces unname of ROD object

```
WARNING* rodiFigTriggerFunc: Creating instance named <code>instance_name</code> forced unname of ROD <code>shape_type</code> to avoid name conflict.

*WARNING* You might want to use Undo now.
```

If you create an instance using the dbCreateInst function in the CIW and a ROD shape already exists with the same name in the same cellview as the instance you are creating, the warning above appears in the CIW.

If you do not do an *undo*, the system unnames the ROD object, turning it into an ordinary shape without any ROD attributes.

#### Solution:

Immediately do an *undo*. Avoid using dbCreateInst to create instances that have the same name as ROD objects in the same cellview.

### **ROD object ID changes after Undo**

When you do an *Undo* in a cellview with the hiUndo function or *Edit – Undo*, the system restores the previous version of the cellview. Variables that used to contain ROD object IDs no longer do so. If you do a *Redo* with the hiRedo function or *Edit – Redo*, the system restores the "undone" cellview, but assigns new ROD object IDs to all ROD objects in the cellview. Therefore, you need to reset your variables for ROD objects.

**Note:** This behavior occurs only during interaction with ROD objects in the CIW.

For example, if a layout cellview is open for editing and you type the following statement in the CIW:

Troubleshooting

the system responds by creating the rectangle in the cellview and displaying its ROD object ID in the CIW as follows:

```
rodObj:22032408
```

If you do an *Undo* at any time during the same editing session, the system restores the previous version of the cellview. The rect variable no longer points to a valid ROD object. When you test rect after an *Undo*, the system displays the following:

```
rect
rod:invalid
rodIsObj( rect )
nil
```

If you follow an Undo with a Redo (with the hiRedo function or Edit - Redo), the system restores the cellview. However, the system assigns the rectangle a new ROD object ID, so the rect variable remains invalid, as it still contains the old ROD Object ID.

```
rect
rod:invalid
rodIsObj( rect )
nil
```

#### Solution:

To update the rect variable to the new ROD object ID for the rectangle, use a statement similar to this:

```
rect = rodGetObj( "myRect" geGetEditCellView() )
```

Now when you query the variable rect, the system responds with the current ROD object ID, as follows:

```
rect
rodObj:22032420
rodIsObj( rect )
```

**Note:** The name of a ROD object is persistent, but the ROD object ID might not be. Therefore, rather than storing the ROD object ID in a variable, get it whenever it is needed.

## **Dialog Box Messages**

### Why is a dialog box asking about saving the technology file?

If you are asked whether you want to save changes to your technology file when you exit the layout software, and you do not know what the changes are, it might be that an ASCII MPP

Troubleshooting

template file was loaded during your editing session. The ASCII MPP template file could contain templates with unique names, templates with names that match templates existing in your technology file, or both.

- When the ASCII MPP template file contains templates with unique names, saving changes to your technology file causes the system to add the new templates to the existing templates in your binary technology library on disk.
- When the ASCII MPP template file contains a template with a name that matches an existing template in the technology file, saving changes to your technology file causes the system to overwrite the matching template with the ASCII version. This might not be what you intended.

#### Solution:

You can verify whether templates loaded from ASCII files produced name conflicts by looking for the following message in the CDS.log file:

Template templateName is replacing an existing template by the same name

For information about what to do, see <u>Template templateName is replacing an existing template by the same name</u>.

## Index

Symbols	В
.cdsenv file 174 to 176 .il files     rodPrintSystemHandleValues.il 121     rodPrintUserHandleValues.il 124 ~> database access operator     accessing	bounding box point handles 14 to 15 width, length handles 15 to 17 bus code example 200
object attributes <u>112</u> point handle <u>32</u>	C
A	calculating alignment, when 31 CDF callback procedure 46 .cdsenv file 174 to 176 chop
accessing alignment information with ~> 113 coordinates through hierarchy 32 to 147 handles 13 system-defined 13 MPP chop holes with ~> 113 multipart path bounding box with ~> 17 named objects 12	hole in multipart path ?? to 84 chopHoles, object attribute 113 connectivity in ROD objects 104 multipart paths 80 multipart rectangles 51 contact array code example 202 cvld, object attribute 113
number of segments with ~> 113 object attribute names and values 117	D
system-defined handle names with  >> 113 handle values with a procedure 121 user-defined handles values with a procedure 124	data types user-defined handles, for 29 database access operator ~> accessing object attributes 112 point handle 32
align, object attribute <u>113</u> aligned objects, how chopping affects ?? to <u>84</u>	database ID, getting <u>149</u> dbId Also see database ID
aligning objects <u>30</u> separating <u>31</u>	object attribute 113 dbOpenCellViewByType function 169 deGetCellView function 169 Display Options Form 105
alignment when recalculate? <u>31</u> attributes	Display Options Form 195 displaying pin/terminal names 195 distributeSingleSubRect environment
accessing names and values 117	variable <u>180</u>

E	Offset Subpaths 60 offsetting ends of subparts 76
editing ROD objects, limitations 52, 81 enclosure subpath of multipart path 54 environment variable    distributeSingleSubRect 180    rodAutoName 182    stretchHandlesLayer 185 environment variables ?? to 176    preserveAlignInfoOn 181    traceTriggerFunctionsOn 186    updatePCellIncrement 187 examples    accessing    coordinates through     hierarchy 146 to 147    system-defined handle values with a	Offsetting the Master Path 56 Overfill a Bounding Box with Rectangles 142 Partially Fill a Bounding Box with Rectangles 142 Querying a Point Handle for a Cellview 135 Querying System-Assigned Handle Name 135 resistance, calculating the 210 Sets of Subrectangles 70 sheet resistance, calculating the 210 shielded path 206 transistor 207 extended-type paths 25, 26
procedure 121 user-defined handle names with a procedure 124 Aligning an Object to a Point 130 Aligning Objects at Different Levels in the Hierarchy 132 Aligning Two Rectangles at the Same Level of Hierarchy 131 bus 200 contact array 202 Create a Master Path with an Offset Subpath to the Right 167 Create a Rectangular Pin 144 Create a Single Rectangle on a Terminal and Net 143 Create a Single Row or Column of	files  .cdsenv 174 to 176 rodPrintSystemHandleValues.il 121 rodPrintUserHandleValues.il 124 functions dbOpenCellViewByType 169 deGetCellView 169 pcDefinePCell 145, 169 tcCreateDeviceClass 145, 169
Rectangles 139 Create Multiple Rows and Columns of Rectangles 140 Create One Rectangle with I_bBox 138 Create One Rectangle with n_width and n_length 137 Creating a Point Handle for a Cellview 134 Enclosure Subpaths 67 Fill a Bounding Box with Rectangles 141 length of path, calculating the 210 Moving an Object Using rodAlign 131 Naming a Polygon Created by dbCreatePolygon in a Pcell 149 Naming a Shape Created in the CIW and Layout Window 150	handles 13 accessing name attribute with ~> 113 ROD object IDs for subshapes with ~> 113 system-defined handle values with a procedure 121 user-defined handle values with a procedure 124 bounding box point 14 to 15 width, length 15 to 17 multiple for same point, benefits of 28 segment length 26 names of 21 to ?? point 21 to 25, ?? to 26

system-defined <u>13</u> for multipart paths <u>26</u>	0
user-defined <u>29</u> hierarchical names <u>12</u>	objects naming <u>12</u> stretching
L	multipart rectangles <u>53</u> offset subpath of multipart path <u>54</u>
length handles 15 of path, code example 210 segment handles, of 26   M  message URL/skdfref/	parameterized cell. See pcells paths extended type 25, 26 length calculating the total 211 of segment 26 multipart. See multipart paths resistance, calculating the 210 segment numbers 19, 21 width of 28 pcCellView variable 145, 169 pcDefinePCell function 145, 169 pcells, using ROD to create 11 pin names displaying 195 setting 195 point handles 13 bounding box 14 segment 21 polygons length of segment 26 segment numbers 19, 20 preserveAlignInfoOn environment variable 181 procedures rodPrintSystemHandleValues.il 121 rodPrintUserHandleValues.il 124
N	R
name, object attribute 113 names 12 accessing for object with ~> 113 hierarchical 12, 145 pin/terminal, displaying 195 segment handles, of 21 to 26 setting pin names 195 numSegments, object attribute 113	recalculating alignment, when 31 rectangles in multipart path, sub 54 segment numbers 20 segment point handle names 22 relative alignment, overview 30 object design, defined 9, 10

repeated object, connectivity 104 resistance code example 210	162 Create a Single Row or Column of
results of using 46	Rectangles
results of using in stretchable pcells 46 ROD object ID	160 Create Multiple Bows and Columns of
108 to 110	Create Multiple Rows and Columns of Rectangles
getting in a cellview 108	161
ROD objects 108	Create One Rectangle with I_bBox
accessing attributes 112 to 126	160
accessing through hierarchy 32 to 165	Fill a Bounding Box with Rectangles
editing limitations <u>52,</u> <u>81</u> separating <u>31</u>	<u>161</u> Overfill a Bounding Box with
rodAutoName environment variable 182	Rectangles
rodPrintSystemHandleValues.il 121	162
rodPrintUserHandleValues.il 124	Partially Fill a Bounding Box with
	Rectangles
S	<u>161</u> rodGetObj
3	Accessing Coordinates through One
segment	Level of Hierarchy
handle names 22 to 26, 27 to 28	<u>165</u>
length handles 26	Accessing Coordinates through Two
numbering ?? to <u>19, 19</u> to <u>21</u>	Levels of Hierarchy
point handles 21	165
separating aligned objects 31 setting pin names 195	Accessing Coordinates without Hierarchy
sheet resistance code example 210	165
shielded path code example 206	rodNameShape
solutions to problems for	Naming a Polygon Created in a Pcell
rodCreateAlign	166
aligning an object to a point 154	Naming a Polygon Created in the
aligning objects at different levels in the hierarchy <u>155</u>	CIW and Layout Window 166
aligning two rectangles at the same	stretch process flow, in 35
level of hierarchy <u>154</u>	stretchHandlesLayer environment
moving an object 155	variable <u>185</u>
rodCreateHandle	stretching objects
creating a point handle for a cellview <u>157</u>	multipart rectangles <u>53</u> subrectangles of multipart path <u>54</u>
creating a system-assigned handle	subShapes, attribute of multipart paths 113
name <u>157</u>	system-defined handles 13
querying a point handle for a	for multipart paths 26
cellview <u>157</u>	values, accessing with procedure 121
rodCreatePath	systemHandleNames
create a master path with an offset subpath on the right <u>159</u>	object attribute 113
rodCreateRect	_
Create a Rectangular Pin	T
<u>163</u>	
Create a Single Rectangle on a	tcCellView variable 145
Terminal and Net	tcCreateDeviceClass function 145, 169

terminal names, displaying 195
traceTriggerFunctionOn environment
variable 186
transform, object attribute 113
transforming
coordinates through
hierarchy 32 to 165
coordinates when accessing a point
handle 115
transistor code example 207

## U

updatePCellIncrement environment
variable 187
user-defined function 35, 46
user-defined handles 13
data types 29
values, accessing with a procedure 124
userHandleNames, object attribute 113

## ٧

variables pcCellView 145, 169 tcCellView 145

## W

width
handles 15
paths, of 28
width handles 15