LORAWAN PLC NETWORK

PLC M221 as LoRaWAN Node






Let's apply a Modbus to LoRaWAN converter like RS485-BL or RS485-LN

Using a RJ45 patchcord with free wires for the serial Modbus RTU port.

Blue A+

White B-

Configuring PLC Modbus settings






Polarización No

Medio físico


RS-485


ORS-232




Reading %MW0 with M221

Let's have some value in %MW0







For example inserting the value of %MW0 with animation tables




Let's read with Qmod Master


With this settings







Timestamp: 18:48:16:286 Slave Addr: 01 Function Code: 03 Starting Address: 0000 Quantity of Registers: 0001 CRC: 840A



So the right values for the Dragino RS485-BL will be:

AT+COMMAND1=01 03 00 00 00 01,1

AT+DATACUT1=7,1,4+5

Let's setup the Dragino on TTS


DevEui= A8 40 41 95 C1 82 C9 43

AT+DEUI=?


AT+APPKEY=?

AT+APPEUI=?

1. Select the end device



2. Enter registration data




Let's change the period of messages

AT+TDC=? 600000 OK

To 10 seconds

AT+TDC=10000

OK



```
AT+BAUDR=?
9600

OK


AT+PARITY=?
0

OK

AT+STOPBIT=?
0

OK
```

Let's change the PLC serial speed to 9600 so it is the default value from Dragino




You can find the PLC code here

https://github.com/xavierflorensa/Schneider-M221-as-LoRaWAN-node


We test now with Dragino RS485-LR

It Works

CMD1 = 01 03 00 00 00 01 84 0a RETURN1 = 01 03 02 00 0a 38 43 Payload = 01 00 0a



Let's change payload decoder



Now you can get these data thru mqtt by Edge computing on the receiver PLC and inject per Modbus to it.

Now let's inject the sender PLC input values on the receiver PLC

Receiver PLC is connected to a Linux machine with

Gateway hardware

CHIRP STACK network server 192.168.1.105

Node-RED 192.168.1.105

Fixed Gateway IP


Let's enter on the Chirpstack server:

http://192.168.1.105:8080/


user: admin

password: admin

We have defined an application




And a device.




We use same device as before with same DEVEUI than in The Things stack

A840412FE182624B


And we have to enter the same AppKey than in The things stack



Then we see that the device has been activated




And starts transmitting



And the data is base 64 encoded

Let's use Node-RED on same machine



```
13/6/2021 23:53:25 node: e7c5e979.290dc8
application/3/device/a840412fe182624b/rx: msg.payload: string[376]


"
{"applicationID": "3", "applicationName": "dragino_rs485_ln",
    "deviceName": "dragino_rs485_ln", "devEUI": "a840412fe182624b
    ", "txInfo":
    {"frequency": 867300000, "dr": 0}, "adr": true, "fCnt": 196, "fPort": 2, "data": "AQAA", "object":
    {"ADC_CH0V": 0, "BatV": 0.256, "Digital_IStatus": "L", "Door_status": "OPEN", "EXTI_Trigger": "FALSE", "Hum_SHT": "0.0", "TempC1": "0.00", "TempC_SHT": "0.00", "Work_mode": "IIC"}}"


13/6/2021 23:53:25 node: 7e4d0d05.278494
application/3/device/a840412fe182624b/rx: msg.payload: buffer[3]


| [ 1,  0,  0 ]

13/6/2021 23:53:25 node: e21f45b7.1eec08
application/3/device/a840412fe182624b/rx: msg.payload: number
    0
```


So we receive the right payload























Now let's activate input 1 and 2 on the sender PLC

Which is 6 coded in binary



```
application/3/device/a840412fe182624b/rx: msg.payload: string[378]

"

{"applicationID": "3", "applicationName": "dragino_rs485_ln", "deviceName": "dragino_rs485_ln", "devEUI": "a840412fe182624b ", "txInfo":

{"frequency": 8677000000, "dr": 0), "adr": true, "fCnt": 237, "fPort": 2, "data": "AQAG", "object":

{"ADC_CH0V": 0, "BatV": 0.256, "Digital_IStatus": "L", "Door_status": "OPEN", "EXTI_Trigger": "FALSE", "Hum_SHT": "0.0", "TempC1": "153.60", "TempC_SHT": "0.00", "Work_mode": "IIC"}}

14/6/2021 0:00:15 node: 7e4d0d05.278494


application/3/device/a840412fe182624b/rx: msg.payload: buffer[3]


14/6/2021 0:00:15 node: e21f45b7.1eec08

application/3/device/a840412fe182624b/rx: msg.payload: number
```

And on the receiver PLC:

We have the number 6 on the register %MW1 and outputs 1 and 2 on ON state





And that's all

You can find the Node-RED code here

https://github.com/xavierflorensa/Schneider-M221-as-LoRaWAN-node