# **Documentation**

### **ASSIST User Guide**

Robert Hilbrich, Michael Behrisch

DLR German Aerospace Center Institute of Transportation Systems

Berlin



iii

#### **DLR German Aerospace Center**

Institute of Transportation Systems Prof. Dr. Karsten Lemmer Rutherfordstraße 2 12489 Berlin

Tel: +49 531 295-3401

Robert Hilbrich

Tel: +49 30 67055-582 Fax: +49 30 67055-291 E-Mail: robert.hilbrich@dlr.de

#### **Document Identification:**

Title . . . . . . . . . . . . . . . . ASSIST User Guide Subject . . . . . . . . . . . . Documentation

Author(s) . . . . . . . Robert Hilbrich, Michael Behrisch

Filename . . . . . . . . user-guide.tex
Last saved on . . . . . . . . . 24th October 2015

#### **Document History:**

Version 0.1	Initial Version	18.08.2015
Version 0.2	Additional Structure	10.09.2015
Version 0.3	Introduction, Usage	28.09.2015

# **Contents**

1.	Intro	oduction	1					
2.	Insta	nstallation and Usage						
	2.1.	Installation	3					
	2.2.	Usage	3					
		2.2.1. Overview	3					
		2.2.2. Create a new Project and Specification	4					
		2.2.3. Generate Mappings	5					
		2.2.4. Save Mappings to Specification	5					
		2.2.5. Evaluate Solutions	5					
		2.2.6. Creating customized Metrics	5					
	2.3.	Useful Shortcuts	6					
3.	•	em Elements	7					
		Overview	7					
		Compartments	7					
		RDCs	7					
		Pins	7					
	3.5.	Equipment Interfaces	7					
4	Con	straint Semantics	9					
٦.		Basic Interface Types Constraint	9					
	7.1.	4.1.1. Intended semantics	9					
		4.1.2. Input Specification	9					
		4.1.3. Implementation Remarks	9					
	4 2	Configurable Interface Types Constraint	9					
	<b>⊤.∠.</b>	4.2.1. Intended semantics	9					
		4.2.2. Input Specification	9					
		4.2.3. Implementation Remarks	9					
	4.3.		9					
	<b>+</b> .J.	4.3.1. Intended semantics	9					
		4.3.2. Input Specification	9					
		T.J.C. IIIDUL JUCCIIICULUII	_					

II Contents

В.	Inpu	ıt Speci	ification Grammar	G
A.	Мар	ping E	xample	Α
		4.9.3.	Implementation Remarks	11
			Input Specification	
			Intended semantics	
	4.9.		Channeling - Deployment from the Pin Perspective	
			Input Specification	
			Intended semantics	
	4.8.		tion: Invalid Deployments	
			Implementation Remarks	
			Input Specification	
	4.7.		Intended semantics	
	4.7.		tion: Valid Deployments	
			Input Specification	
			Intended semantics	
	4.6.		tion: Dislocality	
			Implementation Remarks	
			Input Specification	
			Intended semantics	
	4.5.		tion: Colocality	
		4.4.3.	Implementation Remarks	10
		4.4.2.	Input Specification	10
			Intended semantics	
	4.4.		cted Pins	
		4.3.3.	Implementation Remarks	10

## 1. Introduction

The ASSIST Toolsuite is for System Engineers and System Architects of safety-critical systems. It automates the construction of a mapping between equipment interfaces and the pins of an RDC while respecting safety and reliability requirements.

The ASSIST Toolsuite aims to automate this challenging, error prone and complex task. It requires the user to specify:

- The resource requirements of the equipment interfaces,
- The features and capabilities of the RDCs and
- → safety and reliability requirements

in a textual domain specific language.

This specification of a mapping problem is automatically transferred into Constraint Satisfaction Problem (CSP). Solutions for this CSP represent correct deployments. They are automatically generated with the constraint solver *Choco3*. Solutions can also be evaluated and optimized based on pre-defined or customizable metrics.

# 2. Installation and Usage

#### 2.1. Installation

- 1. Download the zip archive and extract it to some folder. (The binary build already includes a suitable Java Runtime Environment, so you do not need to install a JRE separately.)
- 2. Start ASSIST by double clicking on ASSIST.exe (Windows only).

### 2.2. Usage

#### 2.2.1. Overview


ASSIST has been developed to support the following workflow:

- 1. Import or specify your hardware and software architecture in an **mdsl** file
- 2. Import or Specify your resource and safety requirements in the same **mdsl** file
- 3. Generate a set of valid deployments
- 4. Iterative approach: partial solutions can be fixed in ASSIST
- 5. Sort these deployments according to customizable metrics
- 6. Select an optimal deployment

7. Export the selected deployment


#### 2.2.2. Create a new Project and Specification

1. Create a new project by clicking on FILE and NEW



Please provide a suiteable name for your project and click on FINISH.


2. Create a new mapping specification by clicking on FILE and NEW. Please select MAPPING SPECIFICATION in the following dialog.



Please provide a suiteable name for your deployment specification and click on FIN-ISH.

2.2. Usage 5

3. Mappings can be generated by clicking on Mapping and Generate Mappings



#### 2.2.3. Generate Mappings

- → Available Strategies
- → Partial Solutions

#### 2.2.4. Save Mappings to Specification

→ How do I store individual mappings in ASIST?

#### 2.2.5. Evaluate Solutions

- → How do I evaluate and sort my solutions?
- → Builtin metrics vs. customized metrics

#### 2.2.6. Creating customized Metrics

→ How do I create customized metrics?

### 2.3. Useful Shortcuts

- **Ctrl-Shift-C** Comment the current line or the currently selected lines
- **Ctrl-Shift-F** Format the current file (indention of sections, ...)
- → **Ctrl-Space** Code-Completion; the current specification entry will be completed with available parameters
- → Ctrl-F Find and replace dialog
- **Ctrl-S** Save the current editor file

# 3. System Elements

- 3.1. Overview
- 3.2. Compartments
- 3.3. RDCs
- 3.4. Pins
- 3.5. Equipment Interfaces

## 4. Constraint Semantics

## 4.1. Basic Interface Types Constraint

- 4.1.1. Intended semantics
- 4.1.2. Input Specification
- 4.1.3. Implementation Remarks

## 4.2. Configurable Interface Types Constraint

- 4.2.1. Intended semantics
- 4.2.2. Input Specification
- 4.2.3. Implementation Remarks

## 4.3. Protection Level Constrains

- 4.3.1. Intended semantics
- 4.3.2. Input Specification

#### 4.3.3. Implementation Remarks

#### 4.4. Connected Pins

- 4.4.1. Intended semantics
- 4.4.2. Input Specification
- 4.4.3. Implementation Remarks

### 4.5. Restriction: Colocality

- 4.5.1. Intended semantics
- 4.5.2. Input Specification
- 4.5.3. Implementation Remarks

### 4.6. Restriction: Dislocality

- 4.6.1. Intended semantics
- 4.6.2. Input Specification
- 4.6.3. Implementation Remarks

### 4.7. Restriction: Valid Deployments

- 4.7.1. Intended semantics
- 4.7.2. Input Specification
- 4.7.3. Implementation Remarks
- 4.8. Restriction: Invalid Deployments
- 4.8.1. Intended semantics
- 4.8.2. Input Specification
- 4.9. Inverse Channeling Deployment from the Pin Perspective
- 4.9.1. Intended semantics
- 4.9.2. Input Specification
- 4.9.3. Implementation Remarks

# A. Mapping Example

In Listing A.1 an example specification is described. This example illustrates the specifications that are possible with the current version of ASSIST. Comments are used to further document the intended specification. Single-line comments are prefixed with //. Multi-line comments have to be placed between /\* and \*/. The entire specification language is white space tolerant, so that additional white spaces can be added between keywords without violating its syntax.

```
* GLOBAL PROPERTIES
       Name = "System";
       Compatible Interface Types {
           "EquipmentType0" -> "PinType0", "PinType1";
           "EquipmentType1" -> "PinType1", "PinType2";
11
       Cable Weights {
13
           "EquipmentType0" = 0.3232;
           "EquipmentType1" = 1.3232;
15
           default
                           = 2.43;
       }
17
       Protection Level Restrictions {
           RDC.Location = "LocationA" And Equipment.EmhZone1 = "LocationB" -> L1, L3;
           RDC.Location = "LocationB" And Equipment.EmhZone1 = "LocationC" -> L5;
21
       }
    }
23
    * COMPARTMENTS, RDCs, CONNECTORS and PINS
    Compartments {
       Compartment Comp1 {
29
           Manufacturer = "ManufacturerName";
           PowerSupply
                         = "PowerSupplyName";
```

```
Side
                           = "SideName":
           Zone
                           = "ZoneName";
           RDC RDC1 {
35
               Manufacturer
                              = "ManufacturerName";
               PowerSupply1
                              = "PowerSupply1Name";
               PowerSupply2
                              = "PowerSupply2Name";
               Type
                               = "RDCTypeName";
39
               ESS
                               = "ESSName";
               Location
                               = "RDCLocatioName";
41
               ResourceX
                               = -120;
               ResourceY
                               = 150;
43
               ResourceZ
                               = -1200;
45
               Connector Connector1{
                   // Available protection levels:
47
                   // None, L1, L2, L3, L4, L5, L6, L7, L8
49
                   Pin1: "PinType0"; // = protection level None
                   Pin2: "PinType0" protection level L5;
                   Pin3: "PinType1" protection level L8;
               }
               Connector Connector2{
                   Pin1: "PinType3";
57
                   Pin2: "PinType1" protection level L8;
                   Pin3: "PinType1" protection level L8;
59
61
               // ... more Connectors possible ...
63
               Connected Pins {
                   Comp1.RDC1.Connector1.Pin1, Comp1.RDC1.Connector1.Pin2 are connected;
65
                   Comp1.RDC1.Connector1.Pin3, Comp1.RDC1.Connector2.Pin2, Comp1.RDC1.Connector2
                        .Pin3 are connected;
67
               Metric Parameters {
69
                   "RDC1Parameter1" = 54;
                   // ...
           }
           // ... more RDCs possible ...
           Metric Parameters {
               "Comp1Parameter1" = 12;
79
```

```
"Comp1Parameter2" = 6;
               // ...
81
            }
        }
83
        // Another empty compartment for demo purposes
85
        Compartment Comp2 {
            RDC RDC1 {
87
               Connector Connector1{
89
        }
91
93
     * EQUIPMENT INTERFACES
95
    Interfaces {
97
        Interface EquipmentInterface1 {
            System
                       = "SystemName";
99
            SubAta
                       = "SubAtaName";
            Resource
                       = "ResourceName";
            LineName
                       = "LineName";
            WiringLane = "WiringLaneName";
            GrpInfo
                       = "GrpInfoName";
            Route
                       = "RouteName";
            PwSup1
                       = "PwSup1Name";
            EmhZone1
                       = "EmhZone1Name";
107
            Type
                       = "EquipmentType0";
            ResourceX
                       = -212;
109
            ResourceY
            ResourceZ
113
        Interface EquipmentInterface2 {
            System
                       = "SystemName";
            SubAta
                       = "SubAtaName";
            Resource
                       = "ResourceName";
            LineName
                       = "LineName";
            WiringLane = "WiringLaneName";
119
            GrpInfo
                       = "GrpInfoName";
            Route
                       = "RouteName";
            PwSup1
                       = "PwSup1Name";
            EmhZone1
                       = "EmhZone1Name";
            Type
                       = "EquipmentType1";
            ResourceX
                       = -212;
            ResourceY
            ResourceZ
```

```
}
129
    InterfaceGroups {
        // Explicit member enumeration
        Group G1 { EquipmentInterface1, EquipmentInterface2 };
        // Implicit member enumeration based on attributes
        Group G2 { interfaces with LineName = "LineName" };
        // Implicit member enumerations can be combined with an And-filter
        Group G3 { interfaces with LineName = "LineName" and GrpInfo = "GrpInfoName" };
        // Combinations of explicit and implicit member definitions are also possible
141
        Group G4 { interfaces with LineName = "LineName", EquipmentInterface2 };
143
        // Interfaces can also excluded explicitly
        Group G5 { interfaces with LineName = "LineName" } without { EquipmentInterface1 };
145
        // Interfaces can also excluded implicitly
147
        Group G6 { interfaces with LineName = "LineName" } without { interfaces with PwSup1 = "PwSup1" };
149
        // Groups can be combined
        Group G7 combines G1 and G2 and G3;
     * ADDITIONAL RESTRICTIONS
     Restrictions {
159
161
         * COLOCALITY
163
        // EquipmentInterface1 and EquipmentInterface2 must
165
        // be mapped to the same Connector (or RDC or Compartment)
        EquipmentInterface1, EquipmentInterface2 on same Connector;
        EquipmentInterface1, EquipmentInterface2 on same RDC;
169
        // This also works for groups
        G1 on same Connector;
        // .. and combinations of groups and interfaces
        G4, EquipmentInterface2, G5 on same RDC;
177
```

```
179
           DISLOCALITY
181
        // EquipmentInterface1 and EquipmentInterface2 must
183
        // be on separate Compartments (and RDCs and Connectors)
        // (the level can be set to "Compartment" or "RDC" or "Connector")
185
    // EquipmentInterface1, EquipmentInterface2 dislocal up to Connector;
187
        // All members of G1 must be on separate Connector
189
    // G1 dislocal up to Connector;
191
        // The members of G1 and G2 must not share an Connector
193
        // (while the members of G1 may be on the same Connector)
195
    // G1, G2 dislocal up to Connector;
197
199
           VALID DEPLOYMENTS
        // Valid allocations for EquipmentInterface1 are all
203
        // pins on Connector1 of RDC1 in Comp1
        // (explicit pin specification)
        Valid for EquipmentInterface1 is { Comp1.RDC1.Connector1 };
        // This also works for groups
        // (explicit pin specification)
        Valid for G1, EquipmentInterface1, G3 is { Comp1 };
        // There are also implicit pin specifications possible
        Valid for EquipmentInterface1 is { pins with Compartment.Name = "Comp1" };
213
        // Or even implicit combinations ...
215
        // EquipmentInterface1 can be allocated to all connectors
        // where the hosting RDC has a powerSupply1 attribute of Sup1 or
217
        // the hosting RDC has a powerSupply2 attribute of Sup2
        Valid for EquipmentInterface1 is { pins with RDC.PowerSupply1 = "PowerSupply1Name",
219
                                         pins with RDC.PowerSupply2 = "PowerSupply2Name" };
221
         * INVALID DEPLOYMENTS
         Invalid for EquipmentInterface1 is { Comp2.RDC1.Connector1 };
```

```
Invalid for G1, EquipmentInterface1, G3 is { Comp2 };

Invalid for EquipmentInterface1 is { pins with Compartment.Name = "UnsafeCompartment" };

Invalid for EquipmentInterface1 is { pins with RDC.PowerSupply1 = "UnsafeSupplier", pins with RDC.PowerSupply2 = "UnsafeSupplier" };

333

335

}
```

Listing A.1: ASSIST Example Specification

# **B. Input Specification Grammar**

In Listing B.1 the grammar for the input specification language is depicted. Please refer to this Listing when a specification contains syntax errors.

```
grammar ch.hilbri . assist .mappingdsl.MappingDSL with org.eclipse.xtext.common.Terminals
```

```
import "ch.hilbri.assist.datamodel.model"
    import "http://www.eclipse.org/emf/2002/Ecore" as ecore
    AssistModel:
           globalBlock
                                 = GlobalBlock
           compartmentsBlock
                                 = CompartmentsBlock
           interfacesBlock
                                 = InterfacesBlock
           (interfaceGroupsBlock)?
11
           ( restrictionsBlock
                                 = RestrictionsBlock )?
13
17
     * GLOBAL BLOCK
19
    GlobalBlock: {GlobalBlock}
           'Global' '{'
21
               ('Name' '=' systemName=STRING';'
                                                                   )?
                                                                          &
23
               ( compatibleIoTypesBlock = CompatibleIoTypesBlock
                                                                   )?
               ( cableWeightDataBlock
                                        = CableWeightDataBlock
               ( protectionLevelDataBlock = ProtectionLevelDataBlock )?
           )
27
           ,},
    CompatibleIoTypesBlock:
       'Compatible' 'Interface' 'Types' '{' (compatibleloTypes+=CompatibleloTypeEntry)+ '}'
33
    CompatibleIoTypeEntry:
       eqInterfaceloType=STRING '->' pinInterfaceloTypes+=STRING (',' pinInterfaceloTypes+=STRING)* ';'
```

```
37
   CableWeightDataBlock:
39
                                  '{' (cableWeightEntries+=CableWeightEntry)+
       'Cable' 'Weights'
                                                                            ,},
41
   CableWeightEntry:
43
       (egInterfaceIoType=STRING | defaultEntry?='default') '=' weight=Double ';'
45
   ProtectionLevelDataBlock:
47
       'Protection', 'Level', 'Restrictions', '{' (protectionLevelEntries+=ProtectionLevelEntry)+','
49
   ProtectionLevelEntry:
51
       'RDC.Location' '=' rdcLocation=STRING 'And' 'Equipment.EmhZone1' '=' emhZone1=STRING '->
           ', protectionLevel+=ProtectionLevelType (', ' protectionLevel+=ProtectionLevelType)* '; '
   * COMPARTMENTS
57
      59
   CompartmentsBlock: {CompartmentsBlock}
       'Compartments' '{'
61
          compartments+=Compartment+
63
65
   Compartment:
       'Compartment' name=ID '{'
67
                                      '=' manufacturer=STRING ';')?
                                                                               &
              ('Manufacturer'
69
                                      '=' powerSupply=STRING ';')?
                                                                               &
              ('PowerSupply'
              ('Side'
                                      '=' side=STRING ';')?
                                                                               &
              ('Zone'
                                      '=' zone=STRING ';')?
                                                                               &
              (rdcs+=RDC+)
73
          (metricParametersBlock=MetricParametersBlock)?
   RDC:
79
       'RDC' name=ID '{'
81
                                      '=' manufacturer=STRING ';')?
              ('Manufacturer'
              ('PowerSupply1'
                                      '=' powerSupply1=STRING ';')?
                                                                               &
83
              ('PowerSupply2'
                                      '=' powerSupply2=STRING ';')?
                                                                               &
```

```
'=' rdcType=STRING ';')?
                                                                                            &
                ('Type'
85
                 ('ESS'
                                            '=' ess=STRING ';')?
                                                                                            &
                                            '=' location=STRING ';')?
                                                                                            &
                 ('Location'
87
                                            '=' resourceX=SIGNEDINT ';')?
                 ('ResourceX'
                                                                                            &
                                            '=' resourceY=SIGNEDINT ';')?
                 ('ResourceY'
                                                                                            &
89
                                            '=' resourceZ=SIGNEDINT ';')?
                                                                                            &
                 ('ResourceZ'
                 (internalConnectedPinBlock=InternalConnectedPinBlock)?
                                                                                            &
91
                (connectors+=Connector)+
93
            (metricParametersBlock=MetricParametersBlock)?
95
97
    InternalConnectedPinBlock: {InternalConnectedPinBlock}
         'Connected' 'Pins' '{'
99
            (connectedPins+=ConnectedPinEntry)*
    ConnectedPinEntry:
        pins+=[PinIQualifiedName] ', 'pins+=[PinIQualifiedName] (', 'pins+=[PinIQualifiedName])?
                                                                                                     'are'
              'connected';'
    Connector:
        'Connector' name=ID '{'
109
            (pins+=Pin)*
            (metricParametersBlock=MetricParametersBlock)?
        ,},
    Pin:
        name=ID ':' eqInterfaceType=STRING ('protection' 'level' protectionLevel=ProtectionLevelType)?'
             ; ,
117
119
    enum ProtectionLevelType:
        NONE = 'None'
121
        L1
                = 'L1'
                = 'L2'
        L3
                = 'L3'
        L4
                = 'L4'
        L5
                = 'L5'
        L6
                = 'L6'
                            -
        L7
                = 'L7'
        L8
                = 'L8'
129
131
```

```
MetricParametersBlock: {MetricParametersBlock}
       'Metric Parameters' '{'
          (metricParameters+=MetricParameter)*
   MetricParameter:
       name=STRING '=' value=INT ';'
141
   * INTERFACES
143
      145
    InterfacesBlock:
       'Interfaces' '{'
147
          (eqInterfaces+=EqInterface)+
149
    EgInterface:
       'Interface' name=ID '{'
                                                 ;;)?
                             '=' system=STRING
                                                              &
              ('System'
             ('SubAta'
                             '=' subAta=STRING
                                                 ·; ·)?
                                                              &
             ('Resource'
                             '=' resource=STRING
                                                 ·; ·)?
                                                              &
157
             ('LineName'
                             '=' lineName=STRING
                                                 ·; ·)?
                                                              &
             ('WiringLane'
                             '=' wiringLane=STRING ';')?
                                                              &
159
             ('GrpInfo'
                             '=' grpInfo=STRING
                                                 ·; ·)?
                                                              &
             ('Route'
                             '=' route=STRING
                                                 ·; ·)?
                                                              &
161
             ('PwSup1'
                             '=' pwSup1=STRING
                                                 ·; ·)?
                                                              &
             ('EmhZone1'
                             '=' emhZone1=STRING ';')?
                                                              &
163
             ('Type'
                             '=' ioType=STRING
                                                              &
             ('ResourceX'
                             '=' resourceX=SIGNEDINT ';')?
                                                              &
165
              ('ResourceY'
                             '=' resourceY=SIGNEDINT ';')?
                                                              &
              ('ResourceZ'
                             '=' resourceZ=SIGNEDINT';')?
167
       ·}';
169
    * INTERFACE GROUPS
    InterfaceGroupsBlock: {InterfaceGroupsBlock}
       'InterfaceGroups' '{'
             egInterfaceGroups+=EgInterfaceGroup
179
             egInterfaceGroups+=EgInterfaceGroupWithCombinedDefinition
```

```
181
183
185
                 EqInterfaceGroup:
                               'Group' name=ID '{'
187
                                                                                                                eqInterfaces +=[EqInterface] |
189
                                                                                                                implicit Member Definitions += Implicit EqInterface Member Definition\\
191
                                                                                                                                            eqInterfaces +=[EqInterface] |
                                                                                                                                           implicit Member Definitions += Implicit EqInterface Member Definition\\
195
                                                                                                  )*
197
                                                                                                  ,},
199
201
                                                                                                   'without' '{'
                                                                                                                withoutEqInterfaces+=[EqInterface] |
                                                                                                               without Implicit Member Definitions += Implicit EqInterface Member Definition\\
207
                                                                                                                ','(
                                                                                                                                           withoutEqInterfaces+=[EqInterface] |
209
                                                                                                                                           withoutImplicitMemberDefinitions+=
                                                                                                                                                           Implicit EqInter face Member Definition\\
                                                                                                  )*
213
                                                                                                   ,},
                                                                                    )?
215
                                                                           ';';
217
219
                 ImplicitEgInterfaceMemberDefinition:
                              'interfaces' 'with' entries+=ImplicitEgInterfaceMemberDefinitionAttributesAndValues
221
                                                                                                  (\ 'and'\ entries += Implicit EqInterface Member Definition Attributes And Values) *
                 ImplicitEgInterfaceMemberDefinitionAttributesAndValues:
                               attribute = Implicit EqInterface Member Definition Attribute ~"=" 'value=STRING' In the content of the conten
227
```

```
ı
```

```
enum ImplicitEgInterfaceMemberDefinitionAttribute:
229
       NAME
                 = 'Name'
       SYSTEM
                 = 'System'
       SUBATA
                 = 'SubAta'
       LINENAME = 'LineName'
       WIRINGLANE = 'WiringLane'
       GRPINFO
                 = 'GrpInfo'
       ROUTE
                 = 'Route'
       PWSUP1
                 = 'PwSup1'
       EMHZONE1 = 'EmhZone1'
       IOTYPE
                 = 'Type'
       RESOURCE = 'Resource'
       RESOURCE_X = 'ResourceX'
241
       RESOURCE_Y = 'ResourceY'
       RESOURCE_Z = 'ResourceZ'
243
245
    EgInterfaceGroupWithCombinedDefinition:
       'Group' name=ID 'combines' combinedGroups+=[EqInterfaceGroup] ('and' combinedGroups+=[
247
           EqInterfaceGroup])+ ';'
249
    * RESTRICTIONS
     RestrictionsBlock : { RestrictionsBlock }
       'Restrictions', '{'
          (
               dislocalityRelations
                                  += DislocalityRelation
               colocalityRelations
                                  += ColocalityRelation
259
              validDeployments
                                  += ValidDeployment
              invalidDeployments
                                  += InvalidDeployment
261
       ,,,
263
265
    enum HardwareArchitectureLevelType:
       COMPARTMENT = 'Compartment' |
267
                 = 'RDC'
       CONNECTOR = 'Connector'
     DislocalityRelation:
       eqInterfaceOrGroups+=[EqInterfaceOrGroup] (', 'eqInterfaceOrGroups+=[EqInterfaceOrGroup])*
       'dislocal', 'up', 'to', hardwareLevel=HardwareArchitectureLevelType';';
    ColocalityRelation:
```

```
egInterfaceOrGroups+=[EgInterfaceOrGroup])*
        'on' 'same' hardwareLevel=HardwareArchitectureLevelType';'
279
    ValidDeployment:
281
        'Valid' 'for' eqInterfaceOrGroups+=[EqInterfaceOrGroup] (', ' eqInterfaceOrGroups+=[
            EqInterfaceOrGroup])* 'is'
283
                   (hardwareElements+=[HardwareElementlQualifiedName] | implicitHardwareElements+=
                        DeploymentImplicitDefinition)
                  (hardwareElements+=[HardwareElementlQualifiedName] | implicitHardwareElements+=
285
                  DeploymentImplicitDefinition) )*
        ,},,;
287
    InvalidDeployment:
        'Invalid' 'for' egInterfaceOrGroups+=[EgInterfaceOrGroup](',' egInterfaceOrGroups+=[
            EgInterfaceOrGroup])* 'is'
291
                   hardwareElements+=[HardwareElementlQualifiedName] | implicitHardwareElements+=
                  DeploymentImplicitDefinition)
              (',' (hardwareElements+=[HardwareElementlQualifiedName] | implicitHardwareElements+=
                  DeploymentImplicitDefinition))*
        ,},,;
295
    DeploymentImplicitDefinition:
        'pins' 'with' entries+=DeploymentImplicitDefinitionAttributeAndValue
        ('and' entries+=DeploymentImplicitDefinitionAttributeAndValue)*
301
    DeploymentImplicitDefinitionAttributeAndValue:
       attribute = DeploymentImplicitDefinitionAttribute '=' value=STRING
305
    enum DeploymentImplicitDefinitionAttribute:
        COMPARTMENT_NAME
                                  = 'Compartment.Name'
307
        COMPARTMENT_MANUFACTURER = 'Compartment.Manufacturer' |
        COMPARTMENT_POWERSUPPLY = 'Compartment.PowerSupply' |
309
        COMPARTMENT_SIDE
                                  = 'Compartment.Side'
        COMPARTMENT_ZONE
                                  = 'Compartment.Zone'
311
        RDC_NAME
                                  = 'RDC.Name'
        RDC_MANUFACTURER
                                  = 'RDC.Manufacturer'
313
        RDC_POWERSUPPLY1
                                  = 'RDC.PowerSupply1'
        RDC_POWERSUPPLY2
                                  = 'RDC.PowerSupply2'
        RDC_SIDE
                                  = 'RDC.Side'
        RDC_TYPE
                                  = 'RDC.Type'
317
        RDC_ESS
                                  = 'RDC.ESS'
        RDC_RESOURCE_X
                                  = 'RDC.ResourceX'
319
```

```
RDC_RESOURCE_Y
                      = 'RDC.ResourceY'
     RDC_RESOURCE_Z
                     = 'RDC.ResourceZ'
321
     CONNECTOR_NAME
                      = 'Connector.Name'
     PIN_NAME
                      = 'Pin.Name'
323
325
  327
   Double returns ecore:: EDouble:
331
     INT '.' INT
333
  QualifiedName:
     ID ('.'ID)*
  SIGNEDINT returns ecore:: EInt:
    '-'? INT;
```

**Listing B.1: ASSIST Input Specification Grammar**