
# Control systems

## Xin Wang

#### I. CONTROL SYSTEM



#### Notation:

- $S_{\Theta}$ : System to be controlled
- C: Controller
- Θ: System parameters
- y: Controlled variable i.e. output
- u: Control variable (accessible)
- d: Disturbance factors
- w: Reference variable i.e. point

### A. Control system objective

• Act on u to maintain  $y \approx w$  in the presence of uncertainty

$$d = \bar{d} + \Delta d$$
$$\Theta = \bar{\Theta} + \Delta \Theta$$

- $\bar{d}$  and  $\bar{\Theta}$  are known nominal values i.e. expected
- $\Delta d$  and  $\Delta \Theta$  are uncertainties
- Uncertainty  $\Delta d$  may have a known upper bound

$$|\Delta d| < \bar{D}$$


### II. CONTROLLER

- Two kinds of controllers:
  - Analog: Receives analog inputs and outputs analog
  - Digital: Processes digital sampled variables in computing devices
- Conversion between two types requires: ADC and DAC
- Converters are synchronised via clock signal period  $T_s$
- Discrete-time variables can be expressed with time index

$$t_k = kT_s \Rightarrow k$$


## A. Digital control systems

• Hybrid systems - analog and digital variables




#### III. CONVERSIONS


- Types of variables:
  - Continuous-time



Piece-wise constants: Constant value between two sampling times




- Discrete-time



- Analog: Values change with continuity
- Digital: Values are quantised


### A. A/D conversion



- Conversion uses the sampling mechanism
  - Sampling frequency:  $f_s = \frac{1}{T_s}$
- Implications:
  - Loss of information
  - Quantisation of noise and distortion

### B. D/A conversion

• Zero-order hold: Stair-wise delayed approximation continuous-time function



# IV. DIGITAL DISCRETE-TIME CONTROLLER AND CONTROL SYSTEMS

• Controller is computational algorithm

$$e[k] \qquad \qquad C \qquad \qquad U[k]$$

- Temporisation i.e. delay
- Controller computation time should satisfy:  $\Delta < T_s$

$$\begin{array}{c|c}
e[k] & u[k] \\
& \Delta & \downarrow \\
kT_s & (k+1)T_s
\end{array}$$

## A. Control System

- Error variable: e(t) = w(t) y(t)
- General requirements:
  - Static precision:  $y(t) \approx w(t)$  or e(t) = 0
  - Dynamic precision:
    - \* Quick enough response time
    - \* Dampens possible oscillations
    - \* Able to track varying variables w(t)
  - Insensitive to disturbances i.e. reject d(t)
  - Robust: Above condition hold for unknown system parameters