


4cy Wasted Spark Coil Pack Wiring



Ensure the Capacitor is wired in as close to the coil as possible. Ground it to the engine block.

Ideally wire the 12V feed to the coil pack from the fuel pump relay.

www.ExtraEFI.co.uk