## Chapter 3 Arithmetic for Computers



Chulyun Kim

<sup>\*</sup> This material is based on the lecture slides provided by Morgan Kaufmann

#### Outline



- Introduction
- Addition and Subtraction
- Multiplication
- Division
- Floating Points
- Concluding Remarks

# §3.1 Introduction

### **Arithmetic for Computers**




- Operations on integers
  - Addition and subtraction
  - Multiplication and division
  - Dealing with overflow
- Floating-point real numbers
  - Representation and operations

## Integer Addition



• Example: 7 + 6



- Overflow if result out of range
  - Adding +ve and –ve operands, no overflow
  - Adding two +ve operands
    - Overflow if result sign is 1
  - Adding two –ve operands
    - Overflow if result sign is 0

### Integer Subtraction



- Add negation of second operand
- Example: 7 6 = 7 + (-6)

```
+7: 0000 0000 ... 0000 0111

-6: 1111 1111 ... 1111 1010


+1: 0000 0000 ... 0000 0001
```

- Overflow if result out of range
  - Subtracting two +ve or two –ve operands, no overflow
  - Subtracting +ve from –ve operand
    - Overflow if result sign is o
  - Subtracting –ve from +ve operand
    - Overflow if result sign is 1

### Multiplication



Start with long-multiplication approach





Length of product is the sum of operand lengths

$$\rightarrow$$
  $(2^m-1)*(2^n-1) < 2^{m+n}$ 

#### Multiplication Hardware








#### Optimized Multiplier



Perform steps in parallel: add/shift



- One cycle per partial-product addition
  - That's ok, if frequency of multiplications is low


#### MIPS Multiplication



- Two 32-bit registers for product
  - HI: most-significant 32 bits
  - LO: least-significant 32-bits
- Instructions
  - mult rs, rt / multu rs, rt
    - 64-bit product in HI/LO
  - mfhi rd / mflo rd
    - Move from HI/LO to rd
    - Can test HI value to see if product overflows 32 bits
  - mul rd, rs, rt
    - Least-significant 32 bits of product -> rd

#### Division







*n*-bit operands yield *n*-bit quotient and remainder

- Check for 0 divisor
- Long division approach
  - If divisor ≤ dividend bits
    - 1 bit in quotient, subtract
  - Otherwise
    - o bit in quotient, bring down next dividend bit
- Restoring division
  - Do the subtract, and if remainder goes < 0, add divisor back</li>
- Signed division
  - Divide using absolute values
  - Adjust sign of quotient and remainder as required

#### Division Hardware








#### Optimized Divider





- One cycle per partial-remainder subtraction
- Looks a lot like a multiplier!
  - Same hardware can be used for both

#### MIPS Division



- Use HI/LO registers for result
  - HI: 32-bit remainder
  - LO: 32-bit quotient
- Instructions
  - -div rs, rt / divu rs, rt
  - No overflow or divide-by-o checking
    - Software must perform checks if required
  - Use mfhi, mflo to access result

## Floating Point



- Representation for non-integral numbers
  - Including very small and very large numbers
- Like scientific notation

$$-2.34 \times 10^{56}$$
 normalized  $-+0.002 \times 10^{-4}$  not normalized  $-+987.02 \times 10^{9}$ 

- In binary
  - $-\pm 1.xxxxxxx_2 \times 2^{yyyy}$
- Types float and double in C

#### Floating Point Standard



- Defined by IEEE Std 754-1985
- Developed in response to divergence of representations
  - Portability issues for scientific code
- Now almost universally adopted
- Two representations
  - Single precision (32-bit)
  - Double precision (64-bit)

### **IEEE Floating-Point Format**



single: 8 bits single: 23 bits double: 11 bits double: 52 bits

S Exponent Fraction

$$x = (-1)^{S} \times (1 + Fraction) \times 2^{(Exponent-Bias)}$$

- S: sign bit (0  $\Rightarrow$  non-negative, 1  $\Rightarrow$  negative)
- Normalize significand: 1.0 ≤ |significand| < 2.0
  - Always has a leading pre-binary-point 1 bit, so no need to represent it explicitly (hidden bit)
  - Significand is Fraction with the "1." restored
- Exponent: excess representation: actual exponent + Bias
  - Ensures exponent is unsigned
  - Single: Bias = 127; Double: Bias = 1203

#### Floating-Point Example



- Represent –0.75
  - $-0.75 = (-1)^1 \times 1.1_2 \times 2^{-1}$
  - -S = 1
  - Fraction = 1000...00<sub>2</sub>
  - Exponent = -1 + Bias
    - Single: -1 + 127 = 126 = 01111110,
    - Double:  $-1 + 1023 = 1022 = 011111111110_2$
- Single: 1011111101000... 00
- Double: 1011111111101000...00

#### Floating-Point Example



 What number is represented by the singleprecision float

#### 11000000101000...00

- -S = 1
- Fraction = 01000... 00<sub>2</sub>
- Exponent = 10000001, = 129

• 
$$X = (-1)^{1} \times (1 + 01_{2}) \times 2^{(129 - 127)}$$
  
=  $(-1) \times 1.25 \times 2^{2}$   
=  $-5.0$ 

### Interpretation of Data



- Bits have no inherent meaning
  - Interpretation depends on the instructions applied
- Computer representations of numbers
  - Finite range and precision
  - Need to account for this in programs

## **Concluding Remarks**



- ISAs support arithmetic
  - Signed and unsigned integers
  - Floating-point approximation to reals
- Bounded range and precision
  - Operations can overflow and underflow
- MIPS ISA
  - Core instructions: 54 most frequently used
    - 100% of SPECINT, 97% of SPECFP
  - Other instructions: less frequent