VE320 Intro to Semiconductor Devices

Summer 2024 — Problem Set 3

Due: 11:59pm 12th June

- 1) Explain the physical meaning of the Fermi energy level.
- 2) A silicon piece at T = 300K has $N_a = 7 \times 10^{14} cm^{-3}$ and $p_0 = 2 \times 10^5 cm^{-3}$
- a) Is the material n type or p type?
- b) What are the majority and minority carrier concentrations?
- c) What must be the concentration of donor impurities?
- 3) Silicon is doped at $N_d = 10^{15} cm^{-3}$ and $N_a = 0$.
- a) Plot the concentration of electrons versus temperature over the range $200K \le T \le 600K$. (qualitatively)
- b) For the device to operate properly, the intrinsic carriers must contribute no more than 5 percent to the total electron concentration. Calculate the maximum temperature it can work out.
- 4) The magnitude of the product $g_c(E)f_F(E)$ in the conduction band is a function of energy. Assume the Boltzmann approximation is valid.
- a) Determine the energy with respect to E_c at which the maximum occurs.
- b) Repeat part a) for the magnitude of the product $g_v(E)[1 f_F(E)]$ in the valence band.
- 5) For a particular semiconductor, $E_g=1.50 eV$, $m_p^*=10 m_n^*$, T=300 K, and $n_i=1\times 10^5 cm^{-3}$.
- a) Determine the position of the intrinsic Fermi energy level with respect to the center of the bandgap.
- b) Impurity atoms are added so that the Fermi energy level is 0.45eV below the center of the bandgap.
- i) Are acceptor or donor atoms added?
- ii) What is the concentration of impurity atoms added?
- 6) A particular semiconductor material is doped at $N_d = 2 \times 10^{14} cm^{-3}$, and $N_a = 1.2 \times 10^{14} cm^{-3}$. The thermal equilibrium electron concentration is found to be $n_0 = 1.1 \times 10^{14} cm^{-3}$. Assuming complete ionization, determine:
- a) the intrinsic carrier concentration
- b) the thermal equilibrium hole concentration

7

- a) What is meant by complete ionization?
- b) What is meant by freeze-out?