



CS/SE 3340 Computer Architecture






Instructions Representation

Adapted from "Computer Organization and Design, 4th Ed." by D. Patterson and J. Hennessy

Questions

- What is CISC and what is RISC? How they are different?
- Why RISC?
- What are the three instruction formats of MIPS: R, I and J
- What is a register/immediate/memory operand?
- How to specify a memory operand?








3

Instructions in Stored Program Computers





- Instructions represented in binary, just like data
- Instructions and data stored in memory
- Programs can operate on programs
 - e.g., compilers, linkers, ...
- Binary compatibility allows compiled programs to work on different computers
 - Standardized ISAs

Instruction Set

- The repertoire of instructions of a computer
- Different ISAs have different instruction sets
 - But with many aspects in common
- Early computers had very simple instruction sets
 - Simplified implementation
- Many modern computers also have simple instruction sets

5

CISC and RISC

CISC: Complex Instruction Set Computer RISC: Reduced Instruction Set Computer

CISC	RISC
Variable length	Single word
instruction	instruction
Variable format	Fixed-field
	decoding
Memory operands	Load/store
	architecture
Complex operations	Simple
	operations

Why RISC?

- CISC architectures were designed under many constraints
 - Small, slow and expensive memories! -> compact programs have advantages
 - On-chip registers are expensive!-> memory operands
 - Attempts to bridge the semantic gap -> high level language features in instructions set
- As technologies advances many of these constraints have become less relevant
- Processor designers wanted to exploit new advances in compiler technology to gain performance
 - Pipelining
 - Cache
- Also to facilitate chip design with simplicity and regularity

7

The MIPS Instruction Set


- Used as the example throughout the text book
- Stanford MIPS commercialized by MIPS Technologies (<u>www.mips.com</u>)
- Large share of embedded core market
 - Applications in consumer electronics, network/storage equipment, cameras, printers, ...
- Typical of many modern ISAs
- See MIPS Reference Data tear-out card

Representing Instructions

- Instructions are encoded in binary
 - Called machine code
- MIPS instructions
 - Encoded as 32-bit instruction words
 - Small number of formats encoding operation code (opcode) and operands (register numbers, ...)
 - Regularity!
- Register numbers
 - \$t0 \$t7 are reg's 8 15
 - \$t8 \$t9 are reg's 24 25
 - \$s0 \$s7 are reg's 16 23

9

MIPS Instruction Types



Trap and return from exception

MIPS R-format Instructions

op	rs	rt	rd	shamt	funct
6 bits	5 bits	5 bits	5 bits	5 bits	6 bits

- Instruction fields
 - op: operation code (opcode)
 - rs: first source register number
 - rt: second source register number
 - rd: destination register number
 - shamt: shift amount (00000 for now)
 - funct: function code (extends opcode)

11

R-format Example

op	rs	rt	rd	shamt	funct
6 bits	5 bits	5 bits	5 bits	5 bits	6 bits

add \$t0, \$s1, \$s2

special	\$s1	\$s2	\$t0	0	add
0	17	18	8	0	32
000000	10001	10010	01000	00000	100000

 $0000001000110010010000000100000_2 = 02324020_{16}$

Arithmetic Operations

- Add and subtract, three operands
 - Two sources and one destination

```
add a, b, c # a gets b + c
```

- All arithmetic operations have this form
- Design Principle 1: Simplicity favors regularity
 - Regularity makes implementation simpler
 - Simplicity enables higher performance at lower cost

13

Register Operands

- Arithmetic instructions use register operands
- MIPS has a 32 × 32-bit register file
 - Use for frequently accessed data
 - Numbered 0 to 31
 - 32-bit data called a "word"
- Assembler names
 - \$t0, \$t1, ..., \$t9 for temporary values
 - \$s0, \$s1, ..., \$s7 for saved variables
- Design Principle 2: Smaller is faster
 - c.f. main memory: millions of locations

Register Operand Example

• C code:

$$f = (g + h) - (i + j);$$

• f, ..., j in \$s0, ..., \$s4

• Compiled MIPS code:

```
add $t0, $s1, $s2
add $t1, $s3, $s4
sub $s0, $t0, $t1
```

15

MIPS I-format Instructions



- Immediate arithmetic and load/store instructions
 - rt: destination or source register number
 - Constant: -2^{15} to $+2^{15}$ 1
 - Address: offset added to base address in rs
- Design Principle 4: Good design demands good compromises
 - Different formats complicate decoding, but allow 32-bit instructions uniformly
 - Keep formats as similar as possible

Memory Operands

- Main memory used for composite large data
 - Arrays, structures, dynamic data
- To apply arithmetic operations
 - Load values from memory into registers
 - Store result from register to memory
- Memory is byte addressed
 - Each address identifies an 8-bit byte
- Words are aligned in memory
 - Address must be a multiple of 4
- MIPS supports both Big Endian and Little Endian
 - MARS uses Little Endian

17

Memory Operand Example 1

```
• C code:
```

```
g = h + A[8];
```

- g in \$s1, h in \$s2, base address of A in \$s3
- Compiled MIPS code:
 - Index 8 requires offset of 32
 - 4 bytes per word

```
lw $t0, 32($s3) # load word
add $s1, $s2, $t0

offset base register
```

Memory Operand Example 2

• C code:

```
A[12] = h + A[8];
```

- h in \$s2, base address of A in \$s3
- Compiled MIPS code:
 - Index 8 requires offset of 32

```
lw $t0, 32($s3)  # load word
add $t0, $s2, $t0
sw $t0, 48($s3)  # store word
```

19

Registers vs. Memory

- Registers are faster to access than memory
- Operating on memory data requires loads and stores
 - More instructions to be executed
- Compiler must use registers for variables as much as possible
 - Only spill to memory for less frequently used variables
 - Register optimization is important!

Immediate Operands

- Constant data specified in an instruction addi \$s3, \$s3, 4
- No subtract immediate instruction
 - Just use a negative constant addi \$s2, \$s1, -1
- Design Principle 3: Make the common case fast
 - Small constants are common
 - Immediate operand avoids a load instruction

21

The Constant Zero

- MIPS register 0 (\$zero) is the constant
 - Cannot be overwritten
- Useful for common operations
 - E.g., move between registers
 add \$t2, \$s1, \$zero