
Installation Guide for the POMtools Tool

Table of Contents

- Installation of pyRevit
- Adding the POMtools Tools to Revit




Installation of pyRevit


1. Go to the link:


https://github.com/pyrevitlabs/pyRevit/releases

2. Click on the first item in the list to start downloading the executable:




3. Then, click on the executable that you will find in your downloads and follow the installation steps below:






4. Once the installation is complete, launch your installed version of Revit. Revit should display a window similar to the one shown below and ask you whether you want to load this new add-on or not. Please select "Always Load" or "Toujours charger",




Adding the POMtools Tools to Revit


1. Open your version of Revit and click on the pyRevit tab:




2. Go to the pyRevit settings:




3. Click on "Custom Extension Directories", then on "Add Folder".




4. Once the file explorer opens, navigate to the PLUGIN_POMtools_Revit folder, then go to the pyRevitExtensions folder. Finally, confirm by clicking on "Select Folder."



- 5. Verify that your path ends with "\pyRevitExtensions" to confirm that the path has been added correctly.
- 6. Click on "Save Settings and Reload".



7. Tada! A new tab named "POMtools" should now appear.



THANK YOU