## ECE260: Fundamentals of Computer Engineering

Accessing and Addressing Memory

James Moscola
Dept. of Engineering & Computer Science
York College of Pennsylvania



#### American Standard Code for Information Interchange (ASCII)

- Common character encoding standard
- Available in 7-bit and extended 8-bit
  - 7-bit version encodes 27 (127) characters
  - 8-bit version encodes 28 (256) characters
- Not so great for languages based on non-English alphabets
- Unicode has replaced ASCII in many contexts
  - Backwards compatible with ASCII (UTF-8)
  - UTF-16 commonly used

| Binary   | Character | Binary   | Character | Binary   | Character | Binary   | Character |
|----------|-----------|----------|-----------|----------|-----------|----------|-----------|
| 00000000 | NUL       | 00100000 | SP        | 01000000 | @         | 01100000 | `         |
| 00000001 | SOH       | 00100001 | !         | 01000001 | Α         | 01100001 | a         |
| 00000010 | STX       | 00100010 | "         | 01000010 | В         | 01100010 | b         |
| 00000011 | ETX       | 00100011 | #         | 01000011 | С         | 01100011 | С         |
| 00000100 | EOT       | 00100100 | \$        | 01000100 | D         | 01100100 | d         |
| 00000101 | ENQ       | 00100101 | %         | 01000101 | E         | 01100101 | е         |
| 00000110 | ACK       | 00100110 | &         | 01000110 | F         | 01100110 | f         |
| 00000111 | BEL       | 00100111 | '         | 01000111 | G         | 01100111 | g         |
| 00001000 | BS        | 00101000 | (         | 01001000 | Н         | 01101000 | h         |
| 00001001 | HT        | 00101001 | )         | 01001001 | ı         | 01101001 | i         |
| 00001010 | LF        | 00101010 | *         | 01001010 | J         | 01101010 | j         |
| 00001011 | VT        | 00101011 | +         | 01001011 | K         | 01101011 | k         |
| 00001100 | FF        | 00101100 | ,         | 01001100 | L         | 01101100 | I         |
| 00001101 | CR        | 00101101 | -         | 01001101 | М         | 01101101 | m         |
| 00001110 | SO        | 00101110 |           | 01001110 | N         | 01101110 | n         |
| 00001111 | SI        | 00101111 | /         | 01001111 | 0         | 01101111 | О         |
| 00010000 | DLE       | 00110000 | 0         | 01010000 | Р         | 01110000 | р         |
| 00010001 | DC1       | 00110001 | 1         | 01010001 | Q         | 01110001 | q         |
| 00010010 | DC2       | 00110010 | 2         | 01010010 | R         | 01110010 | r         |
| 00010011 | DC3       | 00110011 | 3         | 01010011 | S         | 01110011 | s         |
| 00010100 | DC4       | 00110100 | 4         | 01010100 | Т         | 01110100 | t         |
| 00010101 | NAK       | 00110101 | 5         | 01010101 | U         | 01110101 | u         |
| 00010110 | SYN       | 00110110 | 6         | 01010110 | ٧         | 01110110 | v         |
| 00010111 | ETB       | 00110111 | 7         | 01010111 | W         | 01110111 | w         |
| 00011000 | CAN       | 00111000 | 8         | 01011000 | Х         | 01111000 | х         |
| 00011001 | EM        | 00111001 | 9         | 01011001 | Y         | 01111001 | У         |
| 00011010 | SUB       | 00111010 | :         | 01011010 | Z         | 01111010 | Z         |
| 00011011 | ESC       | 00111011 | ;         | 01011011 | [         | 01111011 | {         |
| 00011100 | FS        | 00111100 | <         | 01011100 | \         | 01111100 |           |
| 00011101 | GS        | 00111101 | =         | 01011101 | ]         | 01111101 | }         |
| 00011110 | RS        | 00111110 | >         | 01011110 | ۸         | 01111110 | ~         |
| 00011111 | US        | 00111111 | ?         | 01011111 | _         | 01111111 | DEL       |

## Storing Numbers: ASCII vs. UTF-16 vs. Binary

- ASCII and Unicode are great for storing text strings ... <u>not</u> so great for storing numeric data
- Example: storing the number 1,000,000,000 in 3 different formats

#### **Storing as ASCII characters**

```
Requires 10 8-bit ASCII characters

Total space requirement: 10 chars * 8 bits/char = 80 bits
```

#### **Storing as UTF-16 characters**

```
Requires 10 16-bit UTF-16 characters

Total space requirement: 10 chars * 16 bits/char = 160 bits
```

#### **Storing as binary**

```
Requires a single 32-bit word

Total space requirement: 32 bits
```

### Getting Byte Data from Memory

- Strings are commonly stored as 8-bit ASCII character sequences
- Oftentimes only need 8 bits to store your numeric data
- Different architectures offer different methods for reading a byte from memory
  - Hard way
    - Read entire word from memory, then use shifting and bitmasks to extract the desired byte
  - Easier way
    - Use a special instruction for reading a byte directly from memory

## Getting a Byte from Memory (the hard way)

- Hard way
  - Read entire word from memory
  - Shift to move desired byte into least significant byte
  - Use bitmask to clear unwanted bytes

- Example: get byte 2 from memory word 10010004<sub>hex</sub>
  - Assume \$s0 contains base address of "HELLO WORLD!"

```
Byte
3 2 1 0

L L E H  
10010000hex

O W O 10010004hex

! D L R

... ... \0
... ... \0
... ... ...
```

```
lw $t0, 4($s0)  # load entire word from memory into register $t0
srl $t0, $t0, 16  # move desired bits [23:16] into position [7:0] of register $t0
andi $t0, $t0, 0x00FF  # AND with bitmask to keep bottom 8 bits, clear top 8 bits
    # register $t0 now has the 8-bit ASCII value for "W" (i.e. 0x00000057)
```

## Getting a Byte from Memory (the MIPS way)

- MIPS provides instructions to load and store bytes
  - I-type instruction with 16-bit immediate offset
  - Load byte from memory address (\$s7 + 1)

```
Load byte with sign extension
```

```
lb $t0, 1($s7)
```

Load byte without sign extension

```
lbu $t0, 1($s7)
```


• Store byte into memory address (\$s7 + 13)

```
Store bottom 8 bits of $t0
```

```
sb $t0, 13($s7)
```

- Example: Load "W", write it back
  - Assume \$s0 contains base address of "HELLO WORLD!"

```
lbu $t0, 6($s0) # load "W" from memory into register $t0 sb $t0, 6($s0) # overwrite memory with value
```



NOTE: When loading bytes, memory address need *NOT* be a multiple of 4! Address can be ANY value:

Examples: 0x00, 0x01, 0x02, 0x03, ...

## Example: Copying a C String

- Recall C strings end with a null terminator character '\0'
- Example C code copy string y to string x

```
void strcpy (char x[], char y[]) {
  int i = 0;
  while ((x[i] = y[i]) != '\0') {
    i += 1;
  }
}
```

Note that the while condition both assigns x[i] AND compares the value to '\0'

- Assume the following:
  - Base address for x is passed to procedure in register \$a0
  - Base address for y is passed to procedure in register \$a1
  - Local variable i is stored in register \$s0

### Example: Copying a C String (continued)

• First example of strcpy directly mimics C code

```
strcpy:
   addi $sp, $sp, -4  # adjust $sp to make room on stack to save 1 word
   sw $s0, 0($sp) # As CALLEE: save $s0 for parent
   add $s0, $zero, $zero # initialize i = 0
L1: add $t1, $s0, $a1  # add offset to base address of y and store in $t1 (<u>BYTE ADDRESSED!!!</u>)
   lbu $t2, 0($t1)
                        # $t2 = y[i] (i.e. load y[i] into $t2)
   add $t3, $s0, $a0  # add offset to base address of x and store in $t3 (BYTE ADDRESSED!!!)
   sb $t2, 0($t3)
                        \# x[i] = y[i] (i.e. write to new location ... do the copy)
   beq $t2, $zero, L2 # exit loop if y[i] == 0 (i.e. it is the NULL terminator character)
   addi $s0, $s0, 1 # i = i + 1 (i.e. increment i)
           # next iteration of loop
       L1
L2: lw $s0, 0($sp) # As CALLEE: restore saved $s0 for parent
  addi $sp, $sp, 4 # pop 1 item from stack
                        # return to CALLER
        $ra
```

## Example: Copying a C String (continued ... better)

• Better example of strcpy – eliminate the \$s0 register so there is no need to save it on stack

```
strcpy:
  addi $sp, $sp, -4  # adjust $sp to make room on stack to save 1 word
 sw $s0, 0($sp) # As CALLEE: save $s0 for parent
   add $t0, $zero, $zero # initialize i = 0 in $t0 (THIS IS A LEAF PROCEDURE!!)
                       # add offset to base address of y and store in $t1 (BYTE ADDRESSED!!!)
L1: add $t1, $t0, $a1
   lbu $t2, 0($t1)
                       # $t2 = y[i] (i.e. load y[i] into $t2)
   add $t3, $t0, $a0
                       # add offset to base address of x and store in $t3 (BYTE ADDRESSED!!!)
   sb $t2, 0($t3)
                       \# x[i] = y[i] (i.e. write to new location ... do the copy)
                      # exit loop if y[i] == 0 (i.e. it is the NULL terminator character)
   beq $t2, $zero, L2
   addi $t0, $t0, 1 # i = i + 1 (i.e. increment i)
   j L1 # next iteration of loop
L2: lw $s0, 0($sp) # As CALLEE: restore saved $s0 for parent
  # return to CALLER
   jr
       $ra
```

### Example: Copying a C String (continued ... best?)

• Best[?] example of strcpy – eliminate i completely and just do pointer arithmetic

```
strcpy:
   addi $sp, $sp, -4  # adjust $sp to make room on stack to save 1 word
sw $s0, 0($sp) # As CALLEE: save $s0 for parent
<del>add $t0, $zero, $zero  # initialize i = 0 in $t0 (<u>THIS IS A LEAF PROCEDURE!!</u>)</del>
L1: add $t1, $t0, $al  # add offset to base address of y and store in $t1 (BYTE ADDRESSED!!!)
   lbu $t2, 0($a1) # $t2 = y[i] (i.e. load y[i] into $t2)
   add $t3, $s0, $a0  # add offset to base address of x and store in $t3 (BYTE ADDRESSED!!!)
   sb $t2, 0($a0)
                         \# x[i] = y[i] (i.e. write to new location ... do the copy)
                         # exit loop if y[i] == 0 (i.e. it is the NULL terminator character)
   beq $t2, $zero, L2
   addi $t0, $t0, 1 # i = i + 1 (i.e. increment i)
   addi $a0, $a0, 1
                         # increment x array pointer by 1 byte
   addi $a1, $a1, 1
                         # increment y array pointer by 1 byte
                         # next iteration of loop
        L1
                         # As CALLEE: restore saved $50 for parent
   addi $sp, $sp, 4 # pop 1 item from stack
                         # return to CALLER
        $ra
   jr
```

## Example: Copying a C String (continued ... best?)

Best[?] example of strcpy – cleaned up

```
strcpy:
L1: lbu $t2, 0($a1)  # $t2 = y[i] (i.e. load y[i] into $t2)
  sb $t2, 0($a0)  # x[i] = y[i] (i.e. write to new location ... do the copy)
  beq $t2, $zero, L2  # exit loop if y[i] == 0 (i.e. it is the NULL terminator character)
  addi $a1, $a1, 1  # increment y array pointer by 1 byte
  addi $a0, $a0, 1  # increment x array pointer by 1 byte
  j L1  # next iteration of loop

L2:
  jr $ra  # return to CALLER
```

# Getting Halfwords from Memory (the MIPS way)

- MIPS also provides instructions to load and store <u>halfwords</u>
  - I-type instruction with 16-bit immediate offset
  - Load halfword from memory address (\$s7 + 2)

```
Load halfword with sign extension

Load halfword without sign extension

The $t0, 2($s7)


Thu $t0, 2($s7)
```

• Store halfword into memory address (\$s7 + 14)

```
Store bottom 16 bits of $t0
sh $t0, 14($s7)
```

- Example: Load "D!", write it back
  - Assume \$s0 contains base address of "HELLO WORLD!"

```
lhu $t0, 10($s0)  # load "D!" from memory into register $t0
sh $t0, 10($s0)  # overwrite memory with value
```



NOTE: When loading halfwords, memory address must be multiple of 2! Examples: 0x00, 0x02, 0x04, 0x06, ...